

MEDIUM VOLTAGE PRODUCT

AdvaSense[™] KECA 80 D85 Current Sensor Instructions for installation, use and maintenance



ADVASENSE[™] KECA 80 D85 CURRENT SENSOR INSTRUCTIONS FOR INSTALLATION, USE AND MAINTENANCE

Table of contents

3 3 5	 Operating conditions Technical details Instructions for installation Safety instruction Installation conditions Installation on MV cable 		
	or insulated conductor		
6	Clamping system		
7	Secondary connections		
8	Connection to the sensor		
	Grounding terminal		
8	4. Instructions for use		
	Routine test report		
8	5. Instructions for maintenance		
8	6. Transport and storage		
8	7. Recommended procedure for		
	disposal of the sensor		
9	Dimensional drawing		
10	Configurations of clamping		
	system		

AdvaSense[™] KECA 80 D85 current sensor Instructions for installation, use and maintenance

These instructions for installation, use and maintenance are valid for KECA 80 D85 current sensor (Electronic current transformers according to IEC 60044-8 and low-power passive current transformers according to IEC 61869-10 standards) operating in indoor conditions.

01 Example of sensor label (IEC 61869-10)

1. Operating conditions

The sensor should be mounted in dry, indoor conditions without excess ingress of dust and corrosive gases. The sensor must be protected against unusually heavy deposits of dust or similar pollution, as well as against direct sunshine. The sensor is designed for standard ambient temperature between -25°C and +80°C (storage and transportation temperature between -40°C and +80°C). The altitude for mounting should be lower than 1000 m above sea level.

The current sensor type KECA 80 D85 is intended for use in current measurement in medium voltage switchgear. The current sensor shall be installed over a screened bushing insulator, screened insulated cable or any other type of screened insulated conductor. The case of sensor is made from electrically conductive plastic material which is earthed by grounding wire, the internal parts are shielded by the sensor case. The primary conductor shall be insulated in Medium and Low voltage applications and screened from the application voltage in Medium voltage applications – conductive screening shall be at ground potential. The insulation of primary conductor determines the highest permissible system voltage.

The sensor may also be used at higher altitudes when agreed upon with the manufacturer.

2. Technical details

For sensor dimensions see dimension drawings at the end of these instructions. Rated values for each individual sensor are mentioned on the rating plate glued to the sensor. Values mentioned on the rating plate must not be exceeded.

ABB	Current Sensor
KECA 80 D85	S/N 1VLT5419001587
lpr: 80 A Usr:0.150/0.180 V	derivative cl: 0.5/5P630-A2
Kpcr: 50 fr: 50/60 Hz -25/	80 °C 0.72/-//0.82 kV E
CFi: 1.0020 φο cor: +0.00	030° lth/ldyn: 85(3s)/230 kA
IEC 61869-10 Made by AE	86 24 OCT 2018 0.25 kg

01

KECA 80 D85	Type code			
S/N	Serial number			
lpr	Rated primary current			
Usr	Rated secondary voltage in V			
	corresponding to a given rated frequency			
cl.	Accuracy class			
Kpcr	Rated extended primary current factor			
CF,	Correction factors used for current sensor. Correction factors are measured and calculated separately for each sensor. Amplitude correction factor is a number by which the output signal of the sensor shall be multiplied in order to have minimum amplitude error.			
ϕ_{0cor}	Correction factors used for current sensor. Correction factors are measured and calculated separately for each sensor. Phase error correction factor is a number by which the output signal of the sensor shall be increased or decreased (depending on the sign) in order to have minimum phase error.			
fr	Rated frequency in Hz			
-25/80 °C	Ambient temperature			
lth/ldyn	Rated short-time thermal current in kA / Rated dynamic current in kA			
0.25 kg	Weight			
E	Insulation class			
IEC 61869-10	IEC – standard referred to			
24 OCT 2018	Date of production			

Tab. 1. Labels abbreviation definitions according to IEC 61869-10

ADVASENSE[™] KECA 80 D85 CURRENT SENSOR

INSTRUCTIONS FOR INSTALLATION, USE AND MAINTENANCE

02 Example of sensor label (IEC 60044-8)

03 Example of data stored in 2D Bar Code according to label parameters in picture 02 (IEC 60044-8). Same principle can be applied with label parameters in 01 (IEC 61869-10).

04 Example of Amplitude Correction factor setting for current sensor into REF601

05 Example of Amplitude and Phase error correction factors setting for current sensor into REF615 according to label parameters in picture 02 (IEC 60044-8). Same principle can be applied with label parameters in 01 (IEC 61869-10).



POSITION 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 DATA K E C A _ 8 0 _ D 8 5 _ S / N _ 1 V L 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 f s . : _ a I : 0 . 9 9 5 5 5 _ p p 42 43 1 5 C fs 64 65 66 67 68 69 70 71 72 I : + 0 . 0 8 1 7

		REF615 - Parameter Setting					
weed to an a state of the state		Group / Parameter Name	IED Value	PC Value	Unit	Min	Max
	REF615	Analog inputs					
factly Str	10	Current (3I,CT): 1					
	A second and a sec	Current (3I,CT)					
	The second	Primary current		80,0	A	1,0	6000,0
	Chamble control of the second se	Amplitude Corr A		0,9955		0,9000	1,1000
	American	Amplitude Corr B		0,9955		0,9000	1,1000
R		Amplitude Corr C		0,9955		0,9000	1,1000
		Nominal current		80	A	39	4000
		Rated secondary Val		3,000	mV/Hz	1,000	50,000
		Angle Corr A		0,0817	deg	-20,0000	20,000
		Angle Corr B		0,0817	deg	-20,0000	20,000
		Angle Corr C		0,0817	deg	-20,0000	20,000

05

04

KECA 80 D85	Type code
S/N	Serial number
lpr	Rated primary current
Usr	Rated secondary voltage in V corresponding to a given rated frequency
cl.	Accuracy class
Kpcr	Rated extended primary current factor
Cfs.	Correction factors used for current sensor. Amplitude correction factor is a number by which the output of sensor must be multiplied in order to have minimum amplitude error. Phase error correction factor is a number by which the output of the sensor must be increased or decreased (depending on the sign) in order to have minimum phase error.
al	Amplitude correction factor of a current sensor
pl	Phase error correction factor of a current sensor in degrees
fr	Rated frequency in Hz
lth/ldyn	Rated short-time thermal current in kA / Rated dynamic current in kA
0.25 kg	Weight
E	Insulation class
IEC 60044-8	IEC – standard referred to
16 Feb 2015	Date of production

Tab. 2. Labels abbreviation definitions according to IEC 60044-8

4

06 KECA 80 D85 installation

3. Instruction for installation

Safety instruction

Always ground the sensor grounding terminal.

Installation conditions

The sensor should be installed in dry, indoor conditions. The temperature during the assembly must be between 0° C and $+40^{\circ}$ C. The sensor cable should not be moved or bent if the temperature is below 0° C.

Installation on MV cable or insulated conductor The sensor is used for installation on insulated &

shielded MV cable or conductor. Before sensor installation it is necessary to adjust clamping system according to MV cable/conductor diameter. It is possible to set several sizes of diameters according to the marks marked on the clamping system. After appropriate setting of clamping system, install the sensor on the MV cable/con-

ductor using a snap-lock system. Cable sensor output must be at the top. After the fixation the sensor is automatically centered to achieve an optimal function and measurement accuracy, see Figure 6. Finally, it is necessary to install tightening strips to ensure the sensor position. The end of the shield near the sensor is grounded by a wire that passes through the sensor window, as shown also in Figure 6. The current flowing in the shield flows through the grounding lead, which is also in the sensor window. The fluxes produced by the current flow in the shield and in the grounding lead are equal but opposite in direction and, therefore, the output of the current sensor is not affected by the flow of current in the shield. The sensor can be also used without holders; in this case the maximum usable cable diameter is 85 mm.





07 Example of possible clamping system configuration

08 Sensor clamping/ opening procedure

Clamping system

It is necessary to adjust sensor diameter according to the MV cable diameter. The diameter can be adjusted using adjustable holders, see attachment drawings. For the required diameter use the marked values on the holder. The arrow on holder shows in the right direction the diameter adjustment. Both sides of the holders can be used to adjust the diameter. Thus, the diameter range can be set in two configurations. First mode allow to set diameter in the range from 20 mm to 42,5 mm. The second mode allows setting of diameter in the range from 50 mm to 80 mm, see Fig. 7 and attachment drawing. **During the clamping / opening the sensor on the cable, please use both hands according to Fig. 8.**

CONFIGURATION 1

CONFIGURATION 2





07



09 Installation of current sensor KECA 80 D85 over an insulated MV cable/ conductor (permissible angle of deviation).

10 Installation of current sensor KECA 80 D85 over an insulated MV cable/ conductor (permissible deviation in horizontal and vertical direction).

11 Connector RJ45 (IEC 60044-8)

12 Connector RJ45 (IEC 61869-10)

09

13 KECA 80 D85 sensor plug connector pin's assignment (IEC 60044-8)

14 KECA 80 D85 sensor plug connector pin's assignment (IEC 61869-10) Maximum allowed angle and distance from the center of the MV cable/straight insulated conductor and the center of the sensor is shown on Figure 9 and Figure 10.





Note: It is recommended to use a cable tie to fasten long sensor cables approximately 10 cm from the RJ45 socket.

The sensor plug connector pin's assignment is shown on Figure 12 and 13. (Front view).

Secondary connections

The secondary cable is a single shielded cable designed to give maximum EMI shielding. The secondary cable is separable part of sensor and cannot be additionally extended, shortened, branched, modified, withdrawn or changed due to the guarantee of accuracy and performance of the sensor.

The cable must be connected directly (or via a connector adapter if needed - for more information about connector adapters and coupling adapter refer to Doc. No. 1VLC000710 - Sensor Accessories) to electronic measurement equipment (e.g. IED). The electrical shielding of cable is connected to connector shielding and must be earthed on "electronic measurement equipment" side. The cable must be fixed close to metal wall or inserted inside of metal cable tray far from power cables! The minimal bending radius for the cable is 35 mm. The cable is not to be moved if the temperature is below 0 °C. If cable, connector or connector grommet is damaged please contact the manufacturer for instructions.

The used RJ45-type connectors are screened and designed to guarantee low resistance shielding; they are particularly adapted to applications where electromagnetic compatibility (EMC) is important. The connectors are robust but it is necessary to be careful during their assembly – do not use force!



15 LEMO/ODU connector

16 Grounding terminal of current sensor KECA 80 D85 A cable not connected to the relay can be left open or short-circuited without any harm for the sensor. Even during a primary short-circuit the voltage in the secondary circuit of the current sensor will be below 100 V. Nevertheless it is a good safety practice to earth cables not connected to the relay.

RJ45 plug connector has 8 contacts and locking latch coupling. The sensor connector plug must be inserted properly with the relay matting receptacle before completing the coupling with the bayonet lock. Take care and do not use excessive force to plug-in and plug-out these connectors.

Connection to the sensor

The connection between cable and sensor is provided by LEMO/ODU push-pull type connector, see Fig.14.



15

Grounding terminal

The sensor's grounding terminal is located on the sensor's terminal part and shall be connected to the ground using the grounding wire (part of sensor delivery) during the sensor operation, see Fig. 15.



4. Instructions for use

The current sensors are used:

- To convert large currents in the primary circuit of the network to the appropriate signal for the secondary equipment (e.g. IEDs)
- To insulate primary and secondary circuits from each other
- To protect secondary equipment from harmful effects or large currents during abnormal situations in the network

The use of a sensor for other purposes than those described above is forbidden.

Routine test report

The routine test report includes following tests: a) Verification of terminal marking

- b) Power-frequency withstand test on secondary terminals / Power-frequency voltage withstand test for low-voltage components
- c) Test for accuracy

Correction factors are measured separately for each sensor during routine testing and are marked on the rating plate.

The use of correction factors is required condition in order to achieve the declared accuracy class.

5. Instructions for maintenance

Excessive dust or other kinds of pollution must be brushed off the sensor. Polluted sensors can be cleaned with spirit or petrol.

Otherwise, during normal use the sensors do not need any additional maintenance.

6. Transport and storage

The permissible transport and storage temperature for sensors is -40...+80°C. During transport and storage the sensors must be protected against direct sunshine. The sensors are delivered packed into wooden boxes or transport pallets.

7. Recommended procedure for disposal of the sensor

The sensor does not contain environmentally hazardous materials. For disposal of the product after it has been taken out of use, local regulations, if there are any, should be followed.

Dimensional drawing

KECA 80 D85



Configurations of clamping system

CONFIGURATION 1		CONFIGURATION 2		
POSITION NUMBER	MAX. CABLE OUTER DIAMETER D [mm]	POSITION NUMBER	MAX. CABLE OUTER DIAMETER D [mm]	
50	50	20	20	
57.5	57.5	27.5	27.5	
65	65	35	35	
72.5	72.5	42.5	42.5	
80	80	/	/	











CONTACT US

ABB s.r.o.

ELDS Brno Videnska 117, 619 00 Brno, Czech Republic Tel: +420 547 152 021 +420 547 152 854 Fax: +420 547 152 626 E-mail: kontakt@cz.abb.com

NOTE

We reserve the right to make technical changes or modify the contents of this document without prior notice. With regard to purchase orders, the agreed particulars shall prevail. ABB does not accept any responsibility whatsoever for potential errors or possible lack of information in this document. We reserve all rights in this document and in the subject matter and illustrations contained therein. Any reproduction, disclosure to third parties or utilization of its contents in whole or in parts - is forbidden without prior written consent of ABB.

Copyright© 2023 ABB All rights reserved