


ABB INDUSTRIAL DRIVES

## ACS880 winder control program (option +N5000)

Firmware manual



## List of related manuals

*Lists of hyperlinks to product manuals	Code
ACS880-01 drives	9AKK105408A7004
ACS880-04 drive modules (200 to 710 kW, 300 to 700 hp)	9AKK105713A4819
ACS880-07 drives (45 to 710 kW, 50 to 700 hp)	9AKK105408A8149
ACS880-07 drives (560 to 2800 kW)	9AKK105713A6663
ACS880-11 drives	9AKK106930A9565
ACS880-14 drive modules (132 to 400 kW, 200 to 450 hp)	9AKK107045A8023
ACS880-17 drives (45 to 400 kW, 60 to 450 hp)	9AKK106930A3466
ACS880-17 drives (160 to 3200 kW)	9AKK106354A1499
ACS880-31 drives	9AKK106930A9564
ACS880-34 drive modules (132 to 400 kW, 200 to 450 hp)	9AKK107045A8025
ACS880-37 drives (45 to 400 kW, 60 to 450 hp)	9AKK106930A3467
ACS880-37 drives (160 to 3200 kW)	9AKK106354A1500
Other drive hardware manuals	
ACS880-04XT drive module packages (500 to 1200 kW) hardware manual	3AXD50000025169
ACS880-04 single drive module packages hardware manual	3AUA0000138495
ACS880-07CLC drives hardware manual	3AXD50000131457
ACS880-14 and -34 single drive packages hardware manual	3AXD50000022021
ACS880-104 inverter modules hardware manual	3AUA0000104271
ACS880-104LC inverter modules hardware manual	3AXD50000045610
ACS880-107 inverter units hardware manual	3AUA0000102519
Drive firmware manuals and guides	
ACS880 winder control program firmware manual	3AUA0000107532
ACS880 primary control program firmware manual	3AUA0000085967
ACS880 drives with primary control program, quick start-	3AUA0000098062
up guide	3,16,16,66,66,66
Adaptive programming application guide	3AXD50000028574
Drive application programming manual (IEC 61131-3)	3AUA0000127808
ACS880 diode supply control program firmware manual	3AUA0000103295
ACS880 IGBT supply control program firmware manual	3AUA0000131562
ACS880 distributed I/O bus supplement	3AXD50000126880
Option manuals and guides	24440000005505
ACX-AP-x assistant control panels user's manual	3AUA0000085685
Drive composer Start-up and maintenance PC tool user's manual	3AUA0000094606
Manuals and quick guides for I/O extension modules, fieldbus adapters, encoder interfaces, etc.	

You can find manuals and other product documents in PDF format on the Internet. See section *Document library on the Internet* on the inside of the back cover. For manuals not available in the Document library, contact your local ABB representative.

\*Available in the Document library.

## Firmware manual

ACS880 winder control program (option +N5000)

Table of contents



Start-up guide for ACS880 winder control program



1. Introduction to the manual	
What this chapter contains Applicability Licensing Safety instructions Target audience Contents of the manual Related documents Terms and abbreviations Cybersecurity disclaimer	 13 14 14 14 15 15
2. Start-up guide for ACS880 winder control program	
What this chapter contains  Drive start-up  Before you start  Safety  Start-up  Winder control program start-up  Before you start  Fault tracing  Start-up  3. Using the control panel	 20 20 20 20 27 27 27
4. Control locations and operating modes	
What this chapter contains  Local control vs. external control  Local control  External control  Operating modes of the drive  Speed control mode  Torque control mode  Frequency control mode  Special control modes	 40 40 41 43 44 44 44
5. Winder program features	
What this chapter contains Winder overview Winder/Unwinder Infeeder (main drive) Material properties Line speed	 46 46 47 48

Threading
Diameter calculation
Diameter hold
Tension control
Open loop
Tension torque trim
Tension speed trim
Dancer speed trim 56
Taper function
Friction compensation
Inertia compensation
Winder stall function
Torque memory
Automatic roll change
Web loss
Virtual roll
Speed control torque limitation
Tension to torque conversion
Winder control word logic
Winder status
6. Standard program features
What this chapter contains
Drive configuration and programming
Programming via parameters
Adaptive programming
Application programming
Control interfaces
Programmable analog inputs
Programmable analog outputs
Programmable digital inputs and outputs
Programmable relay outputs
Programmable I/O extensions
Fieldbus control
Master/follower functionality
External controller interface
Control of a supply unit (LSU)
Motor control
Direct torque control (DTC) 84
Reference ramping
Constant speeds/frequencies
Critical speeds/frequencies 85
Speed controller autotune 86
Oscillation damping
Rush control
Encoder support
Position counter
Jogging
Scalar motor control
Autophasing

Flux braking	
DC magnetization	
Hexagonal motor flux pattern	
Application control	
Application macros	
Process PID control	
Motor potentiometer	
Mechanical brake control	
DC voltage control	
Overvoltage control	
Undervoltage control (power loss ride-through)	
Voltage control and trip limits	
Brake chopper	120
Emergency stop	121
Motor thermal protection	122
Motor overload protection	125
Thermal protection of motor cable	126
User load curve	126
Other programmable protection functions	127
Automatic fault resets	129
Diagnostics	130
Fault and warning messages, data logging	130
Signal supervision	
Maintenance timers and counters	130
Energy saving calculators	131
Load analyzer	131
Miscellaneous	133
User parameter sets	133
Parameter checksum calculation	
User lock	134
Data storage parameters	
du/dt filter support	135
Sine filter support	135
Router mode for BCU control unit	
7. Application macros	
What this chapter contains	139
General	
Factory macro	
Default parameter settings for the Factory macro	
Default control connections for the Factory macro	
Hand/Auto macro	
Default parameter settings for the Hand/Auto macro	
Default control connections for the Hand/Auto macro	
PID control macro	
Default parameter settings for the PID control macro	
Default control connections for the PID control macro	
Sensor connection examples for the PID control macro	
Torque control macro	
Delaut parameter settings for the Torque Control Macro	1 <del>4</del> 0



Default control connections for the Torque control macro	149
Sequential control macro	150
Operation diagram	150
Selection of constant speeds	151
Default parameter settings for the Sequential control macro	151
Default control connections for the Sequential control macro	152
Fieldbus control macro	153
8. Parameters	
What this chapter contains	155
Terms and abbreviations	156
Summary of parameter groups	157
Parameter listing	160
01 Actual values	160
03 Input references	165
04 Warnings and faults	166
05 Diagnostics	173
06 Control and status words	174
07 System info	188
09 Winder actual signals	191
10 Standard DI, RO	193
11 Standard DIO, FI, FO	200
12 Standard Al	205
13 Standard AO	209
14 I/O extension module 1	213
15 I/O extension module 2	233
16 I/O extension module 3	237
19 Operation mode	241
20 Start/stop/direction	_
21 Start/stop mode	
22 Speed reference selection	260
23 Speed reference ramp	268
24 Speed reference conditioning	274
25 Speed control	279
26 Torque reference chain	290
28 Frequency reference chain	298
30 Limits	307
31 Fault functions	316
32 Supervision	326
33 Generic timer & counter	329
35 Motor thermal protection	337
36 Load analyzer	348
37 User load curve	352
40 Process PID set 1	355
41 Process PID set 2	368
43 Brake chopper	370
44 Mechanical brake control	372
45 Energy efficiency	376
46 Monitoring/scaling settings	379
47 Data storage	383



49 Panel port communication	 385
50 Fieldbus adapter (FBA)	 388
51 FBA A settings	 396
52 FBA A data in	 398
53 FBA A data out	 399
54 FBA B settings	 399
55 FBA B data in	 400
56 FBA B data out	 401
58 Embedded fieldbus	 401
60 DDCS communication	 409
61 D2D and DDCS transmit data	 421
62 D2D and DDCS receive data	 426
74 Application setup	 433
75 Winder speed settings	 438
76 Diameter calculation	 445
77 Tension/Dancer control	 449
78 Winder PID controller	 457
79 Mechanical losses compensation	 463
80 Turreting assistance	 467
81 Winder safety	 470
82 Virtual Roll	 475
90 Feedback selection	 478
91 Encoder module settings	
92 Encoder 1 configuration	
93 Encoder 2 configuration	
94 LSU control	
95 HW configuration	
96 System	
97 Motor control	
98 User motor parameters	
99 Motor data	
200 Safety	
206 I/O bus configuration	
207 I/O bus service	
208 I/O bus diagnostics	
209 I/O bus fan identification	 532
9. Additional parameter data	
•	
What this chapter contains	
Terms and abbreviations	
Fieldbus addresses	
Parameter groups 19	
Parameter groups 1099	 541
10. Fault tracing	
What this chapter contains	502
Safety	
Indications	
Warnings and faults	
	 550



Pure events	594
Editable messages	594
Warning/fault history and analysis	594
Event logs	
Other data loggers	
Parameters containing warning/fault information	
QR code generation for mobile service application	
Firmware warning messages	
Application warning messages	
Firmware fault messages	
Application fault messages	
Auxiliary codes for line-side converter warnings	
Auxiliary codes for line-side converter faults	030
11. Fieldbus control through the embedded fieldbus interface (EFB)	
What this chapter contains	643
System overview	
Connecting the fieldbus to the drive	644
Setting up the embedded fieldbus interface	
Setting the drive control parameters	
Basics of the embedded fieldbus interface	
Control word and Status word	
References	
Actual values	
Data input/outputs	
Register addressing	
About the control profiles	
The ABB Drives profile	
Status Word	
State transition diagram	
References	
Actual values	
Modbus holding register addresses	
The Transparent profile	
Modbus function codes	
Exception codes	
Coils (0xxxx reference set)	
Discrete inputs (1xxxx reference set)	
Error code registers (holding registers 400090400100)	666
12. Fieldbus control through a fieldbus adapter	
What this chapter contains	667
System overview	
Basics of the fieldbus control interface	
Control word and Status word	
References	
Actual values	
Contents of the fieldbus Control word (ABB Drives profile)	

Contents of the fieldbus Status word (ABB Drives profile)	
The state diagram (ABB Drives profile)	
Setting up the drive for fieldbus control	
Parameter setting example: FPBA (PROFIBUS DP)	 6//
13. Control chain diagrams	
What this chapter contains	 679
Drive control diagrams	
Speed reference source selection I	 680
Speed reference source selection II	 681
Speed reference ramping and shaping	 682
Motor feedback configuration	
Load feedback and position counter configuration	
Speed error calculation	
Speed controller	
Torque reference source selection and modification	
Operating mode selection	
Reference selection for torque controller	
Torque limitation	
Torque controller	
Frequency reference selection	
Frequency reference modification	
Process PID setpoint and feedback source selection	
Process PID controller	
Master/Follower communication I (Master)	
Master/Follower communication II (Follower)	
Winder control diagrams	
Winder control word logic	
Diameter calculation	
Tension control	
Dancer control	
Friction compensation	
Inertia compensation	
Speed reference scaling	
Application PID controller	 705

## 14. Appendix A: Motor rotor inertia, IEC

## Further information







## Introduction to the manual

## What this chapter contains

This chapter describes the contents of the manual. It also contains information on the compatibility, safety and intended audience.

## **Applicability**

This manual applies to the ACS880 winder control program (option +N5000), winder application version 1.40 (loading package AWILx v1.40.0.0) or later, and primary control version 3.11.x or later.

You can see firmware and loading package versions in parameters.

#### Example:

Parameter	Loading package version
07.04 Firmware name	AINFB or AINFC
07.05 Firmware version	3.11.7.1
07.06 Loading package name	AWILB or AWILC
07.07 Loading package version	1.40.0.0

This winder application program is based on IEC standard 61131-3. It is an in-house application, therefore the application code is locked and cannot be modified by the user.

## Licensing

The winder control program (+N5000), version AWILx v1.30.0.0 or later comes with a license key on the ZMU-02 memory unit. The program activates only after recognizing the key and correspondingly registers itself with the winder software.

Device	License key
ZMU-02 memory unit license key	N8021 MU Interlock key – Winder
Winder software (loading package)	N8022 Licensed appl Winder

You can see the license information in the Drive Composer PC tool or in the ACS-AP-x control panel from **System info**  $\rightarrow$  **Licenses**.



If the program was loaded to a ZMU-02 memory unit without the license key, then the drive indicates a fault *64A5 Licensing fault*. See the auxiliary fault code in the Event logger to know the plus code of the missing license, in this case N8021. For further assistance, contact your local ABB representative.

## Safety instructions

Obey all safety instructions delivered with the drive.

- Read the complete safety instructions before you install, commission, or use
  the drive. The complete safety instructions are delivered with the drive as either
  part of the *Hardware manual*, or, in the case of ACS880 multidrives, as a separate
  document.
- Read the firmware function-specific warnings and notes before changing parameter values. These warnings and notes are included in the parameter descriptions presented in chapter *Parameters*.

## Target audience

This manual is intended for people who design, commission, or operate the drive system.

### Contents of the manual

This manual contains the following chapters:

- Introduction to the manual contains information on compatibility, safety and intended audience. It also includes a list of terms and abbreviations used in this manual.
- Start-up guide for ACS880 winder control program contains the basic start-up sequence of the drive and additional alternative checklists for starting up the drive with the control program.
- *Using the control panel* provides the basic instructions for using the control panel.
- Control locations and operating modes describes the control locations and operating modes of the drive.
- Winder program features contains descriptions of the features specific to the winder application.
- Standard program features contains descriptions of the control locations and operation modes, as well as the program features that are not specific to the winder application.
- Application macros contains a short description of each macro together with a connection diagram. Macros are pre-defined applications which saves the users time when configuring the drive.
- Parameters describes the parameters used to program the drive.
- Additional parameter data contains additional information of parameters.
- Fault tracing lists the warning and fault messages with possible causes and remedies.
- Fieldbus control through the embedded fieldbus interface (EFB) describes the communication to and from a fieldbus network using the embedded fieldbus interface of the drive.
- Fieldbus control through a fieldbus adapter describes the communication to and from a fieldbus network using an optional fieldbus adapter module.
- Control chain diagrams shows the parameter structure within the drive.
- Appendix A: Motor rotor inertia, IEC includes reference data of motor rotor inertia.

## Related documents

A list of related manuals is printed on the inside of the front cover.

## Terms and abbreviations

Term/abbreviation	Definition
AC 800M	Type of programmable controller manufactured by ABB.
ACS800	A product family of ABB drives
ACS-AP-I	Type of control panel used with ACS880 drives
Al	Analog input; interface for analog input signals
AO	Analog output; interface for analog output signals
BCU	Type of control unit used in ACS880 drive systems, primarily those with parallel-connected inverter or supply modules.
DC link	DC circuit between rectifier and inverter
DDCS	Distributed drives communication system; a protocol used in communication between ABB drive equipment
DI	Digital input; interface for digital input signals
DIO	Digital input/output; interface that can be used as a digital input or output
DO	Digital output; interface for digital output signals
Drive	Frequency converter for controlling AC motors. The drive consists of a rectifier and an inverter connected together by the DC link. In drives up to approximately 500 kW, these are integrated into a single module (drive module). Larger drives typically consist of separate supply and inverter units.
	The ACS880 winder control program is used to control the inverter part of the drive.
DriveBus	A communication link used by, for example, ABB controllers. ACS880 drives can be connected to the DriveBus link of the controller. See page <i>81</i> .
DTC	Direct torque control. See page 84.
FAIO-01	Optional analog I/O extension module
FBA	Fieldbus adapter
FCAN-01	Optional CANopen adapter
FCNA-01	Optional ControlNet adapter
FDCO-0x	Optional DDCS communication module
FDIO-01	Optional digital I/O extension module
FDNA-01	Optional DeviceNet™ adapter
FEA-03	Optional I/O extension adapter
FECA-01	Optional EtherCAT® adapter
FEN-01	Optional TTL encoder interface module
FEN-11	Optional absolute encoder interface module
FEN-21	Optional resolver interface module
FEN-31	Optional HTL encoder interface module
FENA-11	Optional Ethernet/IP, Modbus/TCP and PROFINET IO adapter

Term/abbreviation	Definition
FENA-21	Optional dual-port Ethernet/IP, Modbus/TCP and PROFINET IO adapter
FEPL-02	Optional POWERLINK adapter
FIO-01	Optional digital I/O extension module
FIO-11	Optional analog I/O extension module
FPBA-01	Optional PROFIBUS DP adapter
FPTC-01	Optional temperature measurement module. Not released for sales at the time of publication.
FPTC-02	Optional temperature measurement module for potentially explosive atmospheres. Not released for sales at the time of publication.
FSCA-01	Optional Modbus/RTU adapter
FSO-xx	Optional safety functions module
HTL	High-threshold logic
ID run	Motor identification run. During the identification run, the drive will identify the characteristics of the motor for optimum motor control.
IGBT	Insulated gate bipolar transistor; a voltage-controlled semiconductor type widely used in inverters and IGBT supply units due to their easy controllability and high switching frequency
INU-LSU	Type of optical <i>DDCS</i> communication link between two converters, for example the <i>supply unit</i> and the <i>inverter unit</i> of a drive system.
Inverter unit	The part of the drive that converts DC to AC for the motor.
I/O	Input/Output
ISU	An IGBT supply unit; type of supply unit implemented using IGBT switching components, used in regenerative and low-harmonic drives.
Line-side converter	See supply unit.
LSU	See supply unit.
ModuleBus	A communication link used by, for example, ABB controllers. ACS880 drives can be connected to the optical ModuleBus link of the controller.
Motor-side converter	See inverter unit.
Network control	With fieldbus protocols based on the Common Industrial Protocol (CIP <sup>TM</sup> ), such as DeviceNet and Ethernet/IP, denotes the control of the drive using the Net Ctrl and Net Ref objects of the ODVA AC/DC Drive Profile. For more information, see <a href="https://www.odva.org">www.odva.org</a> , and the following manuals:  • FDNA-01 DeviceNet adapter module User's manual (3AFE68573360 [English]), and
	FENA-01/-11 Ethernet adapter module User's manual (3AUA0000093568 [English]).
Parameter	User-adjustable operation instruction to the drive, or signal measured or calculated by the drive
PID controller	Proportional–integral–derivative controller. Drive speed control is based on PID algorithm.

Term/abbreviation	Definition
PLC	Programmable logic controller
Power unit	Contains the power electronics and power connections of the drive (or inverter module). The drive control unit is connected to the power unit.
PSL2	Protocol used in communication between the drive control unit and the
	Power unit.
PTC	Positive temperature coefficient
PU	See power unit.
RDCO-0x	Optional DDCS communication module
RFG	Ramp function generator.
RO	Relay output; interface for a digital output signal. Implemented with a relay.
SSI	Synchronous serial interface
STO	Safe torque off
Supply unit	The part of the drive that converts AC to DC. An IGBT supply unit ( <i>ISU</i> ) is also capable of feeding regenerative energy back into the supply network.
TTL	Transistor-transistor logic
UPS	Uninterrupted power supply; power supply equipment with battery to maintain output voltage during power failure
ZCU	Type of control unit used in ACS880 drives (primarily in drive modules, or inverter/supply units consisting of a single power module). Consists of an I/O board built into a plastic housing.  Depending on the type of hardware, the control unit may be integrated
	into or fitted onto the drive/inverter module, or installed separately.

## Cybersecurity disclaimer

This product is designed to be connected to and to communicate information and data via a network interface. It is Customer's sole responsibility to provide and continuously ensure a secure connection between the product and Customer network or any other network (as the case may be). Customer shall establish and maintain any appropriate measures (such as but not limited to the installation of firewalls, application of authentication measures, encryption of data, installation of anti-virus programs, etc) to protect the product, the network, its system and the interface against any kind of security breaches, unauthorized access, interference, intrusion, leakage and/or theft of data or information. ABB and its affiliates are not liable for damages and/or losses related to such security breaches, any unauthorized access, interference, intrusion, leakage and/or theft of data or information.

3

# Start-up guide for ACS880 winder control program

## What this chapter contains

This guide describes the basic start-up sequence of an ACS880 drive equipped with winder control program:



- Drive start-up (page 20)
- Winder control program start-up (page 27).

The drive can be set up using the ACS-AP-I control panel or by using the Drive composer PC tool.

## **Drive start-up**

### Before you start

Make sure that the drive has been mechanically and electrically installed as described in the appropriate Quick installation guide and/or Hardware manual.


## Safety



WARNING! All electrical installation and maintenance work on the drive should be carried out by qualified electricians only.


Never work on the drive, the braking copper circuit, the motor cable or the motor when power is applied to the drive. Always ensure by measuring that no voltage is actually present.

## Start-up



	1 (1 11 · · · · · · · · )	1		
	In the <b>Home</b> view, press ( <b>Menu</b> ).	Remote (*		0.0 rpm
	The main <b>Menu</b> (right) appears.	Menu —		
		Paramete	rs	<b>&gt;</b>
		Assistant	'S	<b>•</b>
		Energy ef	fficiency	•
		Evant lan		0 1 1
		Exit	12:34	Select
	Highlight <b>Settings</b> on the menu using (Select)	Remote C		0.0 rpm
	and <b>▼</b> and press <b>◯</b> ( <b>Select</b> ).	Settings —		
		Language		<b>&gt;</b>
		Date & time		<b>&gt;</b>
		Edit texts		•
		Display setting	<b>js</b>	•
		Back	12:34	Soloot
		Dack	12.34	Select
	In the <b>Settings</b> menu, highlight <b>Date &amp; time</b>	Remote C		0.0 rpm
	(if not already highlighted) and press (Select).	Date & time —		
	(Gelect).	Date	01	.01.1980
		Time		12:34:56
		Show date as	day.m	onth.year
		Show time as		24-hour
		Daylight saving		EU
		Pook	12:35	Edit
		Back	12.33	Euit
	In the <b>Date &amp; time</b> menu, highlight <b>Date</b> (if	Remote (*		0.0 rpm
	not already highlighted) and press	Date		0.0 ipini
	(Select).			
		Day M	onth Yea	r
		<u> </u>	01.198	טע
		Т	uesday	
		Cancel	12:35	Save
<u> </u>		<u> </u>		








Highlight <b>Parameters</b> and press (Select).	Parameters Favorites By function Complete list Modified	0.0 rpm
Highlight <b>Complete list</b> using ▲ and ▼ and press  ( <b>Select</b> ).  A listing of parameter groups is displayed.	Local Complete list O1 Actual values 03 Input references 04 Warnings and faults 05 Diagnostics 06 Control and status wor	0.0 rpm
Highlight parameter group 95 HW configuration and press (Select).  Note that the list wraps around in either direction between groups 99 and 01. In this case, it is quicker to use to locate group 95 on the list.  After selecting a group, a listing of parameters within the group is displayed.	Local 95 HW configuration — 95.01 Supply voltage 95.02 Adaptive voltage lim 95.04 Control board supply	0.0 rpm  Not given its Disable Internal 24V
Highlight parameter <i>95.01 Supply voltage</i> (if not already highlighted) and press (Edit).  The available parameter settings are listed.	Local	0.0 rpm







Refer to the motor nameplate for the following parameter settings. Whenever possible, enter

Example of a nameplate of an induction (asynchronous) motor:

the values exactly as shown on the motor nameplate.



Example of a nameplate of a permanent magnet motor:



#### 99.06 Motor nominal current

The allowable range is

- in DTC mode:  $1/6 \times I_{Hd} \dots 2 \times I_{Hd}$  of the drive
- in Scalar mode: 0 ... 2 × I<sub>Hd</sub>

Note: With numerical parameter values:

- Use (▲) and (▼) to change the value of a digit.
- Press (Save) to enter the value.



Mak	Make the following parameter settings in the same manner.			
	99.07 Motor nominal voltage			
Ш	The allowable range is $1/6 \times U_N \dots 2 \times U_N$ of the drive.			
	With permanent magnet motors, the nominal voltage is the BackEMF voltage at nominal speed. If the voltage is given in volt/rpm (e.g. 60 V per 1000 rpm), the voltage at a nominal speed of 3000 rpm is 3 × 60 V = 180 V. Note that nominal voltage is not the same as equivalent DC motor voltage (EDCM) given by some manufacturers. The nominal voltage can be calculated by dividing the EDCM voltage by 1.7 (or square root of 3).			
П	99.08 Motor nominal frequency			
	With permanent magnet motors, if the nomina it can be calculated using the following formula $f = n \times p / 60$			
	where $n =$ nominal motor speed, $p =$ number of	of note naire		
	· · · · · · · · · · · · · · · · · · ·	pole pairs.		
	99.09 Motor nominal speed			
	99.10 Motor nominal power			
	99.11 Motor nominal cos Φ 99.12 Motor nominal torque			
	These values are not required, but can be entered to improve control accuracy. If not known, leave at 0.			
	99.13 ID run requested			
	This parameter selects the mode of the identification run (DTC motor control mode only).			
	Note: The drive must be in local control for the identification run.			
	<b>WARNING!</b> The identification run modes marked thus * will run the motor in the forward direction (see below for details). Make sure it is safe to run the motor before choosing any of these modes.			
	*Normal mode should be selected whenever possible. The driven machinery must be decoupled from the motor if			
	<ul> <li>the load torque is higher than 20%, or</li> <li>the machinery is not able to withstand the nidentification run.</li> </ul>	ominal torque transient during the		
	*Reduced mode should be selected if the mec load cannot be de-coupled, or full flux is require conical motors).	•		
	The <i>Standstill</i> mode should be selected if neitl	ner the * <i>Normal</i> or * <i>Reduced</i> mode can be		
	used. <b>Notes</b> :	in the months of most of the second the second of the seco		
	This mode cannot be used with a permanent magnet motor if the load torque is higher than 20% of nominal.			
	Mechanical brake is not opened by the logic	c for the identification run.		
	Ensure that the Safe torque off and emergence	y stop circuits (if present) are closed.		
	Start the identification run by pressing the Start) button.	A warning will indicate that the identification run is in progress.		



Check that the motor runs in the correct direction (forward direction shown below).



The identification run has completed when the drive stops and the value of parameter 99.13 reverts to None.

If the motor ran in the wrong direction, correct the motor cabling or adjust parameter 99.16 Motor phase order.



## Winder control program start-up

## Before you start

Note that the application start-up is possible only after the drive basic start-up procedure is completed successfully, that is all the basic parameter configurations made and the motor ID-run is performed. For drive basic start-up procedure, see page 20.


## Fault tracing

If a warning or fault is generated during commissioning, see chapter Fault tracing, for warnings (page 615) and faults (page 635) generated by winder control program.

## Start-up

	Application Safety		
	It is recommended to assess the general physical boundaries for the machine so that the drive could prevent any accidental damages to the mechanics.		
	Make sure the following parameters comply with control and safety limits of the driven machinery:  motor speed limits are set automatically. However user can set custom values in group 81 Winder safety.  maximum output current  motor torque limits	30.17 Maximum current 30.19 Minimum torque 1 30.20 Maximum torque 1	
	Control signal settings		
To manage primary settings, the drive can be controlled either through digital and analog I/O interface or from a PLC through fieldbus interface. <b>Note</b> : By default, the application is configured to be controlled through digital and analog I/Os.			
Configure the following drive essential control settings according to the active electrical set up:			
	Choose the drive control interface.	20.01 Ext1 commands	
	Verify the drive start command source.	20.03 Ext1 in1 source	
	Verify the run enable command.	20.12 Run enable 1 source	
	Set the fault reset signal source.	31.11 Fault reset selection	
	Select the analog input type (voltage or current).	12.15 Al1 unit selection 12.25 Al2 unit selection	
	<b>Note</b> : Changing default settings of Al type requires altering the position of jumper on the ZCON board.		







	Winder control program settings			
General settings				
	Basic mechanical set up describing machine operating mode, direction of motor rotation and gearing.			
	Select the winding mode:  Winder - if the machine has to wind material on a roll  Unwinder - if the machine has to unwind material off the roll	74.05 Winding mode		
	Select the motor direction: <b>Positive</b> (onwind) or <b>Negative</b> (under-wind) depending on the motor rotation direction. <b>Note</b> : Resulting motor speed reference sign is generated based on this parameter setting.	74.06 Motor direction		
	Select the unit system (metric or imperial).	74.91 Unit system		
	Define gear ratio between the motor and winding object. <b>Example:</b> Set this parameter value to 2 if it takes two motor revolutions to make one rotation of a spindle.	74.11 Gear ratio 1		
	Using the fieldbus adapter and winder control word: If you need to control the application program functions from fieldbus, you can turn the important program functions on/off with a 16-bit data word in parameter 74.49 Winder control word.  Note: These bits are not connected to any function by default. The bit names are	74.49 Winder control word		
	existing, for which you need to make connections separately.			
	Material properti	es settings		
The	following material properties settings are requ	ired to achieve better control accuracy.		
	Define the thickness of the material (web or wire).  Note: For wire winding application, enter a value equivalent to the wire diameter divided by the number of turns needed to cover one	74.21 Material Thickness		
	full-width row on a spool.  Define the roll lay-down width (mm).	74.22 Material Width		
	Define the density of the used material (kg/m³).	74.23 Material Density		



	Select the source for length.	74.29 Length source
	Note: The selection Measured from	
	Encoder requires set-up of the virtual roll	
	counter settings in parameter group 82	
	Virtual Roll.	
	Diameter calculat	tion settings
is the esting production Actu	diameter calculation function delivers roll diameter used in motor speed and torque reference mation. The function also provides a means of cess. The list of important settings is given below all diameter acquisition methods are: stimated aken from a feedback device stimated diameter updated from a feedback decimated	calculations, as well as roll weight control over the diameter calculation ow.
	Set the diameter of the empty core (mm).	76.08 Core diameter
	Set the diameter of the full roll (mm).	76.09 Full roll diameter
	Estimated mode When no diameter feedback sensor is available based on ratio of motor actual speed to the a	
	Set parameter 76.01 Diameter calculation mode to Estimated.	76.01 Diameter calculation mode
	Define the filter time for diameter calculation.	76.03 Actual diameter filter time
	Define the conditions when diameter count	76.05 Count up enable
	up or count down conditions are enabled (diameter estimation active) or disabled (diameter estimation stopped).	76.06 Count down enable
	Select the signal source to reset the roll diameter.	76.11 Reset estimated diameter
	If you need to preset the roll diameter to a certain value, specify the value in parameter 76.26 Estimation preset value.	76.26 Estimation preset value
	Select the source for the preset command of roll diameter.	76.25 Preset estimated diameter
	External feedback device mode In this mode the information about roll diamet	er is available from an external signal.
	Set parameter 76.01 Diameter calculation mode to External feedback.	76.01 Diameter calculation mode
	Define the source for the diameter feedback signal.  Note: Scale the feedback source according to minimum/maximum diameter in mm. For more information, see parameter description on page 445.	76.02 Diameter feedback Src



	External feedback device at stop mode  The external feedback sensor value is used as the source of actual diameter when the		
	internal diameter estimation is frozen. Otherwise the estimated diameter is used. The rate of change of actual diameter is limited according to web thickness.		
	Note: Diameter estimation is frozen when diameter hold is active.		
	Set parameter 76.01 Diameter calculation mode to External feedback at stop.	76.01 Diameter calculation mode	
	Define the source for the diameter feedback signal.	76.02 Diameter feedback Src	
	<b>Note:</b> Scale the feedback source according to minimum/maximum diameter in mm. For more information, see parameter description on page <i>445</i> .		
	Set the rest of the parameters as in the case of Estimated mode.	See section <i>Estimated mode</i> on page 30.	
	After all diameter calculation settings are complete, it is recommend to set the	76.11 Reset estimated diameter	
	parameter 76.11 Reset estimated diameter.	o cottings	
Sol	Speed reference ect the source for speed reference and scaling		
	Set parameter 75.01 Max line speed. Based	75.01 Max line speed	
	on this value. The application program calculates the maximum motor speed (signal 75.61 Max motor speed at core).	73.01 Max line speed	
	<b>Note:</b> Make sure these settings do not exceed the maximum/minimum motor speed limits in group <i>30 Limits</i> .		
	Select the source for line speed reference.	75.02 Line speed reference src	
	Set the line speed reference input scaling	75.03 Line reference scaling	
	range. The target speed reference is defined as:	75.01 Max line speed	
	75.51 Line reference In = (75.02 Line speed reference src/ 75.03 Line reference scaling) * 75.01 Max line speed.		
	<b>Note:</b> Reference scaling could be set to 0, then the input from parameter <i>75.02</i> is interpreted directly as m/min (of ft/min) without any scaling.		
	If line speed reference is fed through fieldbus, then set the correct PLC program execution cycle time or communication cycle time whichever is longer.	75.05 Line ref source cycle time	
	The control program will use this information to synchronize the incoming speed reference with other functions, e.g., when Inertia compensation function is active.		




Set the speed reference additive parameters:				
Set parameter 75.31 Overspeed ref offset, that is speed reference additive defined in percent of maximum line speed (parameter 75.01 Max line speed).	75.31 Overspeed ref offset			
For example, 35% is usually enough.				
Define the line speed reference ramp settings	:			
Set parameter 75.11 Acceleration ramp time in seconds. It defines how fast the line speed reference increases from 0 to maximum line speed (parameter 75.01 Max line speed).	75.11 Acceleration ramp time			
Set parameter 75.12 Deceleration ramp time in seconds. It defines how fast the line speed reference decreases from maximum line speed (parameter 75.01 Max line speed) to zero.  Note: In case of drive stop command, define	75.12 Deceleration ramp time 75.13 Stop ramp time			
a separate deceleration ramp time with parameter 75.13 Stop ramp time.				
Tension control settings				
e parameter settings for each tension control maision control is enabled with parameter 77.01 E	•			
Open loop In this mode feedback from the web is not receive by calculating the torque reference for the motension reference and the actual roll radius. Tonfigure the following settings.	tor, which is the product of the user-given			
Set the tension control mode to <i>Open loop</i> (used when feedback devices for tension control are not available).	77.02 Tension control mode			
Select the source for tension reference. Tension reference scaling is then done with parameter 77.06 Tension reference scaling. The target tension reference is then defined as: 77.51 Tension reference In = (77.03 Tension reference Src/ 77.06 Tension reference scaling) * 77.05 Max tension.  Note: Reference scaling could be set to 0, then input from parameter 77.03 is	77.03 Tension reference Src 77.06 Tension reference scaling			
interpreted directly in Tension units without any scaling.  Define the maximum tension to exert on the material.	77.05 Max tension			



Tension torque trim In this mode load cell feedback is required. The tension of the web is controlled by calculating the torque reference of the motor, which is the product of the user-given tension reference and the actual roll radius. In addition, the tension control PI modifies the final motor torque reference based on the tension feedback from the load cell. Configure the following settings:		
Set the tension control mode to <i>Tension</i> torque trim.	77.02 Tension control mode	
Select the source for tension reference. Tension reference scaling is then done with parameter 77.06 Tension reference scaling. The target tension reference is then defined as:	77.03 Tension reference Src	
77.51 Tension reference In = (77.03 Tension reference Src/ 77.06 Tension reference scaling) * 77.05 Max tension.		
<b>Note</b> : Reference scaling could be set to 0, then input from parameter 77.03 is interpreted directly in tension units without any scaling.		
Select the source for the tension feedback signal.	77.04 Load cell feedback Src	
With load cell feedback device the incoming signal is interpreted directly in force units without any scaling. Value read by the drive could be seen in signal 77.70 Load cell measurement.		
Define the maximum tension to exert on the material.	77.05 Max tension	
Define the amount of allowed correction to the torque reference by the PID controller output.	78.09 PID output range	
Define the tension controller P-gain.	78.11 P-gain 1	
Define the tension controller integration time.	78.12 <i>I-time</i> 1	
Tension speed trim In this mode load cell feedback is required. The tension of the web is controlled by calculating the torque reference of the motor, which is the product of the user-given tension reference and the actual roll radius. In addition, the tension control PI modifies the final motor speed reference based on the tension feedback from the load cell. Configure the following settings:		
Enable tension control.	77.01 Enable tension control	
Set the tension control mode to <i>Tension</i> speed trim.	77.02 Tension control mode	







### Safety function settings

In case the material breaks, normal operation is no longer possible or it can be dangerous to proceed. The drive is able to detect such an occurrence with the web loss function.

**Open loop tension control mode**: In this mode the web loss is detected when the difference between the actual line speed and the final speed reference added with overspeed reference goes below the defined level.

Tension torque trim or Tension/Dancer speed trim mode: In this mode a material loss is detected when the tension feedback from the web is less than the web loss limit set by the user.

Select the required action for the web loss condition:  • Disable - no action or function is disabled  • Warning  • Fault	81.01 Web-loss function
If available, select the source for the web loss sensor feedback signal. Usually, it is a digital signal notifying about tension loss on the web.	81.02 Web-loss sensor src
Define the tripping level. When the observed signal value drops below this level, the drive assumes that the material is broken.	81.04 Speed error low %
Define the tripping delay timer. For the drive to trip, the web loss condition stays valid as long as set with this timer.	81.09 Open-loop trip delay 81.19 Closed-loop trip delay

### Friction compensation settings

The Friction compensation function improves the accuracy of tension control when no tension feedback device is available, that is running in Open loop tension control mode.

- Static friction means the forces of mechanical friction between the construction parts that interlock and prevent any relative motion until the limit where the motion occurs.
- Dynamic (linear) friction means an additional friction loss component as a function of roll speed.

For information on Friction measurement procedure and parameter settings, see parameter description in group 79 Mechanical losses compensation (page 463).

Set the values of static and dynamic friction	79.12 Static friction torque
in group 79 Mechanical losses compensation. For more information, see page 463.	79.13 Friction torque at 5% speed
	79.14 Friction torque at 10% speed
	79.15 Friction torque at 20% speed
	79.16 Friction torque at 40% speed
	79.17 Friction torque at 60% speed
	79.18 Friction torque at 80% speed
	79.19 Friction torque at 100% speed



Inertia compensation settings		
The Inertia compensation function is used to assist the acceleration and deceleration parts of the process. For more information on Inertial compensation and parameter settings, see parameter description in group 80 Turreting assistance (page 467).		
	Set parameter 79.31 Inertia compensation enable to TRUE for using the Inertia compensation function.	79.31 Inertia compensation enable
	<b>Note</b> : If fieldbus is used as line speed reference source in parameter 75.02 Line speed reference src, then set correct value in parameter 75.05 Line ref source cycle time for the function to work properly.	
	Select the method for calculating weight.  Based on estimated weight - in this method weight is calculated based on material properties	79.32 Inertia calculation method 79.34 Full roll weight
	Proportional to full roll and actual diameter.  Note: The letter method requires setting of	
	<b>Note</b> : The latter method requires setting of parameter 79.34 Full roll weight.	
	Define the value for fixed inertia.	79.33 Fixed inertia
	Fixed inertia includes sum of the inertia of the motor shaft, couplings, gear-box and inertia of an empty roll.	
	For correct values, see technical description documentation of these components.	
	For more information, see <i>Appendix A: Motor rotor inertia, IEC</i> (page 707).	





# Using the control panel

Refer to ACX-AP-x assistant control panels user's manual (3AUA0000085685 [English]).




# **Control locations and** operating modes

# What this chapter contains

This chapter describes the control locations and operating modes supported by the control program.

## Local control vs. external control

The ACS880 has two main control locations: external and local. The control location is selected with the Loc/Rem key on the control panel or in the PC tool.



- 1) Extra inputs/outputs can be added by installing optional I/O extension modules (FIO-xx) in drive slots.
- 2) Encoder or resolver interface module(s) (FEN-xx) installed in drive slots.

#### Local control

The control commands are given from the control panel keypad or from a PC equipped with Drive composer when the drive is set to local control. Speed and torque control modes are available for local control; frequency mode is available when scalar motor control mode is used (see parameter 19.16 Local control mode).

Local control is mainly used during commissioning and maintenance. The control panel always overrides the external control signal sources when used in local control. Changing the control location to local can be prevented by parameter 19.17 Local control disable.

The user can select by a parameter (49.05 Communication loss action) how the drive reacts to a control panel or PC tool communication break. (The parameter has no effect in external control.)

#### External control

When the drive is in external control, control commands are given through

- the I/O terminals (digital and analog inputs), or optional I/O extension modules
- the embedded fieldbus interface or an optional fieldbus adapter module
- the external (DDCS) controller interface
- the master/follower link, and/or
- the control panel.

Two external control locations, EXT1 and EXT2, are available. The user can select the sources of the start and stop commands separately for each location by parameters 20.01...20.10. The operating mode can be selected separately for each location (in parameter group 19 Operation mode), which enables guick switching between different operating modes, for example speed and torque control. Selection between EXT1 and EXT2 is done through any binary source such as a digital input or fieldbus control word (see parameter 19.11 Ext1/Ext2 selection). The source of reference is selectable for each operating mode separately.

The control location selection is checked on a 2 ms time level

### Using the control panel as an external control source

The control panel can also be used as a source of start/stop commands and/or reference in external control. Selections for the control panel are available in the start/stop command source and reference source selection parameters.

Reference source selection parameters (except PID setpoint selectors) have two selections for the control panel. The difference between the two selections is in the initial reference value after the reference source switches to the control panel.

The panel reference is saved whenever another reference source is selected. If the reference source selection parameter is set to Control panel (ref saved), the saved value is used as the initial reference when control switches back to the panel. Note that only one type of reference can be saved at a time: for example, attempting to use the same saved reference with different operating modes (speed, torque, etc.) causes the drive to trip on 7083 Panel reference conflict. The panel reference can be separately limited by parameters in group 49 Panel port communication.


With the reference source selection parameter set to Control panel (ref copied), the initial panel reference value depends on whether the operating mode changes with the reference source. If the source switches to the panel and the operating mode does not change, the last reference from the previous source is adopted. If the operating mode changes, the drive actual value corresponding to the new mode is adopted as the initial value.

The process PID setpoint selectors in parameter groups 40 Process PID set 1 and 41 Process PID set 2 only have one setting for the control panel. Whenever the control panel is selected as the setpoint source, operation resumes using the previous setpoint.						

# Operating modes of the drive

The drive can operate in several operating modes with different types of reference. The mode is selectable for each control location (Local, EXT1 and EXT2) in parameter group 19 Operation mode.

The following is a general representation of the reference types and control chains. The page numbers refer to detailed diagrams in chapter Control chain diagrams.



## Speed control mode

The motor follows a speed reference given to the drive. This mode can be used either with estimated speed as feedback, or with an encoder or resolver for better speed control accuracy.

Speed control mode is available in both local and external control. It is also available both in DTC (Direct Torque Control) and scalar motor control modes.

## Torque control mode

Motor torque follows a torque reference given to the drive. Torque control is possible without feedback, but is much more dynamic and accurate when used in conjunction with a feedback device such as an encoder or a resolver. It is recommended that a feedback device is used in crane, winch or lift control situations.

Torque control mode is available in DTC motor control mode for both local and external control locations.

## Frequency control mode

The motor follows a frequency reference given to the drive. Frequency control is only available in scalar motor control mode.

## Special control modes

In addition to the control modes mentioned above, the following special control modes are available:

- Process PID control. For more information, see section Process PID control (page 108).
- Emergency stop modes Off1 and Off3: Drive stops along the defined deceleration ramp and drive modulation stops.
- Jogging mode: Drive starts and accelerates to the defined speed when the jogging signal is activated. For more information, see section *Jogging* (page 97).


# Winder program features

# What this chapter contains

This chapter describes some of the important functions within the winder control program, how to use them and how to program them to operate.

## Winder overview


The figure below shows an example of a process with winders.



#### Winder/Unwinder

A winding machine or winder is used for wrapping a string, twine, cord, thread, yarn, rope, wire, ribbon, tape, etc. onto a spool, bobbin, reel, etc. The opposite process that is getting the material off any type of core is called unwinding.

The Winder control program is used to calculate the diameter of the roll and to control web tension and motor speed according to user given references. The diagram below gives an overview of the winder control. The sections below explain each tension control mode in detail with the help of control diagrams.



#### **Settings**

74.05 Winding mode

74.06 Motor direction

# Infeeder (main drive)

The Winder control program can also be used in infeeder applications. Infeeder (e.g., NIP or pinch roll) is a process control section used for transporting material in the process line. An infeeder can be tension controlled or purely speed controlled. For tension controlled feeder, the Tension control function must be enabled and Winding mode must be set as either Winder (if section has to push the material) or Unwinder (if material has to be pulled).

Note: Infeeder application uses a fixed roll diameter. For this purpose, ABB recommends to disable the diameter calculation using parameters in group 76 Diameter calculation.

## Settings

76.08 Core diameter

76.05 Count up enable

76.06 Count down enable

# **Material properties**

Settings based on material properties (thickness, width, density etc.) are required to achieve better control accuracy in the control program.

#### **Settings**

Parameter group 74 Application setup (page 433)

# Line speed

Line speed is the operational speed of the controlled process, given in meters per minute (or ft/min). Because the roll radius of winders and unwinders keeps changing, the speed reference to the motor is automatically corrected according to the actual radius of the driven roll.

See also the *Virtual roll control chain diagram* on page 62.

#### Settings

Parameter groups 75 Winder speed settings (page 438), 22 Speed reference selection (page 260)

# **Threading**

Threading function works similar to Jog function. The difference is that in Threading mode, reference is given in surface speed units (m/min or ft/min). The program considers the actual roll diameter for determining the target motor speed reference.

Unlike the original Jog mode, Threading function also requires the drive start command to be given after the threading forward or reverse command is set On. The transition between threading and normal production modes is done automatically. As soon as line speed reference goes greater than the threading speed reference, the control program automatically switches to tension control mode, that the application is configured to run in. This function is useful when it is needed to pick up a slack in the material and then immediately switch to production.

If tension control is On, then tension reference signal is considered and applied to the motor torque limit to prevent the material from breaking at the moment when slack is removed and it gets tense.

Note: Because surface to motor speed and tension to torque calculation depends on the actual diameter reading, the accuracy of the final used motor speed and torque limit highly depends on the accuracy of actual diameter calculation.

#### Settings

Parameter group 75 Winder speed settings

## Diameter calculation

This function provides the means of control over the roll diameter calculation process. There are several options on how the diameter value can be acquired:

- The diameter sensor feedback signal can be wired either directly to the drive analog input or sent remotely through a fieldbus.
- When no sensor is available, the control program can estimate the actual roll diameter using the ratio between line surface speed feedback and the actual motor speed. To stabilize the calculation, the actual diameter rate of change is limited according to the web thickness setting.
- Alternatively, actual diameter can also be derived from the number of revolutions by an encoder installed either on the motor/roll shaft or on the line pulley. For more details, see Virtual roll function on page 61.

The program uses actual diameter signal for calculating motor speed and torque reference, as well as estimating the roll weight. The diameter value can be reset to its core diameter value or to the full roll diameter value, depending on the selected winding mode (winder or unwinder) and also can be preset to a user-defined value.

See control chain diagram for *Diameter calculation* on page 699.

#### Diameter hold

Diameter hold function observes the cases when diameter should not be calculated. Diameter hold status is shown when the following hold conditions are met:

- drive is stopped
- both count up and count down are disabled
- when PID control is disabled
- when torque memory is active
- actual speed and actual tension is less than the minimum
- jogging mode is active
- full roll diameter is reached
- diameter reset or preset is active
- web thickness is less than the minimum
- parameter 76.07 Hold diameter count input is active.

**Note**: For NIP or pinch roll (infeeder) the diameter of the driven roll does not change, so diameter calculation must be disabled by setting the core and maximum diameter to same value (empty roll diameter).

#### Settings

Parameter group 76 Diameter calculation (page 445)

## **Tension control**

The Tension control function provides control over tension on a material surface. If there is a load cell or a dancer available in a control section, then stable tension control is maintained with the embedded PID-controller.

Due to complexity of process a number of tuning tools are used to make the control adaptive and suitable in possible situations. The Stall function helps starting the machine smoothly and avoids over-regulation at slow speeds. The adaptive P-gain and integration time in combination with the adjustable trimming options helps tuning the controller to remain stable with a constantly changing roll diameter.

When no feedback device is available, the drive is still capable of estimating essential process parameters and produce stable tension control in open loop. Features such as Friction compensation, Inertia compensation and precise material property settings enable achieving best possible result.

The objective of the tension control is to maintain the tension of the web, that is the force applied to the web. The motor speed and torque must change as a function of the web speed and roll diameter.

Motor torque = Tension reference × Roll radius

See chain diagram for *Tension control* on page 700.

## Settings

Parameter groups 77 Tension/Dancer control (page 449) and 78 Winder PID controller (page 457)


# Open loop

In this mode, feedback from the web is not required. The tension of the web is controlled by calculating the torque reference of the motor, which is the product of the user-given tension reference and the actual roll radius. The tension control PI is disabled. Inertia and friction compensation can be used to improve the tension control accuracy.

The drive is running as speed controlled; the torque limits of the speed controller are controlled by the tension control. To ensure that the drive is always running against the calculated speed controller torque limits, the application adds an overspeed reference to the final speed reference. The amount of overspeed reference is adaptable with parameters.

Since tension feedback from the web is not available, accurate web data is a prerequisite for successful tension control. Therefore, the friction and inertia compensation should be set up carefully when the Open loop tension control is used. The Open loop tension control is suitable especially for non-stretchy materials which do not set extremely high requirements for the tension.

## Open loop tension control chain diagram



## **Tension torque trim**


Load cell feedback is required. Tension of the web is controlled by calculating the torque reference of the motor, which is the product of the user-given tension reference and the actual roll radius. In addition, the tension control PI modifies the final motor torque reference based on the tension feedback from the load cell. Inertia and friction compensation can be used to improve the tension control accuracy.

The drive is running as speed controlled; the torque limits of the speed controller are controlled by the tension control. To ensure that the drive is always running against the calculated speed controller torque limits, the application adds an overspeed reference to the final speed reference. The amount of overspeed reference is adaptable with parameters. Accurate web material information is required.

The Tension torque trim tension control may result in a stable steady-state performance, but on the other hand it is less adaptable to a wide variety of web materials than the Tension speed trim tension control. The Tension torque trim tension control is suitable especially for non-stretchy materials and when high dynamic accuracy is needed.

See the below tension torque trim control chain diagram.

## Tension torque trim control chain diagram




## **Tension speed trim**

Load cell feedback is required. The tension control PI modifies the final motor speed reference based on the tension feedback from the load cell. Inertia compensation can be used to improve the tension control accuracy. The drive is running as speed controlled.

When running in the Tension speed trim control mode, the tension controller is very adaptable to a large variety of web material characteristics. The Tension speed trim tension control is suitable especially for stretchy materials demanding smooth control of the tension.

See the below tension speed trim control chain diagram.


## Tension speed trim control chain diagram



TENSION SPEED TRIM CONTROL

## **Dancer speed trim**

Dancer feedback signal is required. The purpose of the dancer regulation is to control the web tension by regulating the dancer (mechanical roll/wheel) position. The dancer is loaded from either an external source controlled by the user or by the output of the dancer PID controller of the drive. The dancer absorbs the changes of the web tension, which cause the dancer position to change. The dancer PID controller corrects the position error of the dancer by means of speed trimming. Inertia compensation can be used to improve the tension control accuracy. The drive is running as speed controlled.



An advantage of a dancer is the web storage, which acts like an accumulator to absorb and isolate tension disturbances.

The Dancer speed trim tension control is suitable especially for stretchy materials demanding smooth control of the tension.


See the below dancer speed trim control chain diagram.

## **Settings**

Parameter groups 77 Tension/Dancer control (page 449), 79 Mechanical losses compensation (page 463) and 80 Turreting assistance (page 467)

## Dancer speed trim control chain diagram

DANCER SPEED TRIM CONTROL



# **Taper function**

The taper function allows to reduce or increase the tension of the web as the material builds (diameter increases). You can use it to control roll hardness and to prevent the roll starring or crushing the core.

#### **Settings**

Parameters 77.11 Taper mode...77.15 Max taper tension trim % (page 453)

# Friction compensation

Friction compensation calculates the linear friction compensation term based on a predefined friction curve. The curve is defined by static friction and dynamic friction values at 5%, 10%, 20%, 40%, 60%, 80% and 100% of the maximum speed (maximum speed for the winder with an empty roll).

Static friction: It is force of mechanical friction between construction parts that interlock and prevent any relative motion until the limit where the motion occurs.

Dynamic (linear) friction: It is an additional friction loss component as a function of the roll speed. Proper friction compensation is essential especially in the open loop tension control to improve accuracy of the tension control.

See chain diagram for *Friction compensation* on page 702.

#### **Settings**

Parameter group 79 Mechanical losses compensation (page 463)

# **Inertia compensation**

Inertia compensation function calculates the inertia based on the roll diameter and material data. The function also calculates the additional torque needed to support acceleration and deceleration of the roll considering its current inertia and speed reference change dynamics.

See chain diagram for *Inertia compensation* on page 703.

### **Settings**

Parameter group 80 Turreting assistance (page 467)

## Winder stall function

In winder stall function, roll speed is at or near zero speed. When using the winder stall function, the stall values (speed reference, PID controller parameters) are used instead of normal ones. Stall is used, for example, when threading web material through a machine (low speed and tension reference) and for a machinery standstill.

Note: There is also a fault function called motor stall function (in group 31 Fault functions) and they should not be mixed.

### **Settings**

Parameter groups 77 Tension/Dancer control (page 449) and 78 Winder PID controller (page 457)

# **Torque memory**

Torque memory stores the used torque at the moment of a request and calculates the boosted torque from the stored torque.


This function is used in continuous process lines with the automated winder roll change. The torque is memorized before the finished roll is removed from the winding position. When the finishing roll is isolated from the tension feedback, the torque memory is enabled to maintain the tension in the finishing roll section. Block diagram of torque memory function is presented on page 700.

## **Settings**

Parameter group 80 Turreting assistance (page 467)

# Automatic roll change

Turret winders are used to perform an automatic roll change. In the turret winder two center winders are located on a rotating axis, whose position is changed so that a new roll can be started on the fly.



During the roll change, the web material is cut with a flying knife. To facilitate slicing of the material, torque boost defined by the user can be applied to temporarily increase the tension of the web. When the material is cut, the load cell or dancer is disconnected from the web and cannot therefore be used for the tension control. To finish the roll after cutting, the torque memorized before cutting can be used as the torque reference for the motor.

The pivot control of the automatic roll change machine is not part of the winder control program but has to be controlled by the user.

#### **Settings**

Parameter group 80 Turreting assistance (page 467)

#### Web loss

The Web loss detection function enables the drive to detect an occurrence of web loss (web break, wire break or cable breakdown) in the tension control modes from the following conditions:

- In the Open loop tension control mode, the drive detects web loss when the difference between the actual line speed and final speed reference together with overspeed reference goes below the defined level. This happens because, in case of a web loss, the motor speed rushes from the line speed to overspeed reference and the speed difference decreases to zero.
- In the other tension control modes, the drive detects web loss when the tension feedback from the web (tension or dancer position) is less than the web loss limit set by the user.

The user can also define a time delay for the web-loss function to trigger a drive warning or fault.

#### **Settings**

Parameter group 81 Winder safety (page 470)

#### Virtual roll

Virtual roll function offers an additional method for diameter estimation. It allows to use an encoder feedback to count how much material is delivered on a roll, and to assume the actual diameter and the roll driven speed. The encoder can be placed either on a pulley connected to the line surface, or directly on the motor driving the roll.


See the below virtual roll control chain diagram.

#### **Settings**

Parameter group 82 Virtual Roll (page 475)

62

## Virtual roll control chain diagram



# **Speed control torque limitation**

Speed control torque limitation selects the torque limit for the speed controller. The actual torque limit is selected according to the tension control mode and direction of rotation. By forcing input, torque limit 2 can be applied regardless of the control mode (used, for example, for the torque memory). The block diagrams of speed control torque limitation are presented on pages 689 and 701.

## Tension to torque conversion

This function converts the percent scaled tension reference to the motor torque.

It also calculates the torque limit of the speed controller (tension reference + friction compensation term). Block diagrams of tension to torque conversion are presented on pages 701.

# Winder control word logic

Winder control word logic controls selections through winder control word or/and parameters. Winder features can be selected either through Control word or by parameters. Block diagram of winder control word logic is presented on page 701.

## Settings


Parameter group 74 Application setup (page 433)

## Winder status

The current status of application can be obtained through specific status words.

## **Settings**

Parameters 09.01 Winder status word, 76.88 Diameter hold status (pages 191, 449).



# Standard program features

# What this chapter contains

The chapter describes


- the control locations and operating modes supported by the control program
- some of the important functions in the control program that are not specific to winder application.

# **Drive configuration and programming**

The drive control program is divided into two parts:

- firmware program
- application program.

#### **Drive control program**



The firmware program performs the main control functions, including speed and torque control, drive logic (start/stop), I/O, feedback, communication and protection functions. Firmware functions are configured and programmed with parameters, and can be extended by application programming.

## **Programming via parameters**

Parameters configure all of the standard drive operations and can be set via

- the control panel, as described in chapter *Using the control panel*
- the Drive composer PC tool, as described in Drive composer user's manual (3AUA0000094606 [English]), or
- the fieldbus interface, as described in chapters Fieldbus control through the embedded fieldbus interface (EFB) and Fieldbus control through a fieldbus adapter.

All parameter settings are stored automatically to the permanent memory of the drive. However, if an external +24 V DC power supply is used for the drive control unit, it is highly recommended to force a save by using parameter 96.07 Parameter save manually before powering down the control unit after any parameter changes have been made.

If necessary, the default parameter values can be restored by parameter 96.06 Parameter restore.

## Adaptive programming

Conventionally, the user can control the operation of the drive by parameters. However, the standard parameters have a fixed set of choices or a setting range. To further customize the operation of the drive, an adaptive program can be constructed out of a set of function blocks.

The Drive composer PC tool has an Adaptive programming feature with a graphical user interface for building the custom program. The function blocks include the usual arithmetic and logical functions, as well as e.g., selection, comparison and timer blocks. The program can contain a maximum of 50 blocks. The adaptive program is executed on a 10 ms time level.

The physical inputs, drive status information, actual values, constants and data storage parameters can be used as the input for the program. The output of the program can be used e.g. as a start signal, external event or reference, or connected to the drive outputs. See below for a listing of the available inputs and outputs. Note that connecting the output of the adaptive program to a selection parameter will writeprotect the parameter.

The status of the adaptive program is shown by parameter 07.30 Adaptive program status. The adaptive program can be disabled by 96.70 Disable adaptive program.

Please note that sequential programming is not supported.

For more information, see the Adaptive programming application guide (3AXD50000028574 [English]).

Inputs available to the adaptive program				
Input	Source			
1/0				
DI1	10.02 DI delayed status, bit 0			
DI2	10.02 DI delayed status, bit 1			
DI3	10.02 DI delayed status, bit 2			
DI4	10.02 DI delayed status, bit 3			
DI5	10.02 DI delayed status, bit 4			
DI6	10.02 DI delayed status, bit 5			
DIIL	10.02 DI delayed status, bit 15			
Al1	12.11 Al1 actual value			
Al2	12.21 Al2 scaled value			
DIO1	11.02 DIO delayed status, bit 0			
DIO2	11.02 DIO delayed status, bit 1			
Actual signals				
Motor speed	01.01 Motor speed used			
Output frequency	01.06 Output frequency			
Motor current	01.07 Motor current			
Motor torque	01.10 Motor torque			
Motor shaft power	01.17 Motor shaft power			

Inputs available to the adaptive program				
Input	Source			
Status				
Enabled	06.16 Drive status word 1, bit 0			
Inhibited	06.16 Drive status word 1, bit 1			
Ready to start	06.16 Drive status word 1, bit 3			
Tripped	06.11 Main status word, bit 3			
At setpoint	06.11 Main status word, bit 8			
Limiting	06.16 Drive status word 1, bit 7			
Ext1 active	06.16 Drive status word 1, bit 10			
Ext2 active	06.16 Drive status word 1, bit 11			
Data storage				
Data storage 1 real32	47.01 Data storage 1 real32			
Data storage 2 real32	47.02 Data storage 2 real32			
Data storage 3 real32	47.03 Data storage 3 real32			
Data storage 4 real32	47.04 Data storage 4 real32			
Data storage 5 real32	47.05 Data storage 5 real32			
Data storage 6 real32	47.06 Data storage 6 real32			
Data storage 7 real32	47.07 Data storage 7 real32			
Data storage 8 real32	47.08 Data storage 8 real32			

Outputs available to the adaptive program			
Output	Target		
I/O			
RO1	10.24 RO1 source		
RO2	10.27 RO2 source		
RO3	10.30 RO3 source		
AO1	13.12 AO1 source		
AO2	13.22 AO2 source		
DIO1	11.06 DIO1 output source		
DIO2	11.10 DIO2 output source		
Start control			
Ext1/Ext2 selection	19.11 Ext1/Ext2 selection		
Run enable 1	20.12 Run enable 1 source		
Ext1 in1 cmd	20.03 Ext1 in1 source		
Ext1 in2 cmd	20.04 Ext1 in2 source		
Ext1 in3 cmd	20.05 Ext1 in3 source		
Ext2 in1 cmd	20.08 Ext2 in1 source		
Ext2 in2 cmd	20.09 Ext2 in2 source		
Ext2 in3 cmd	20.10 Ext2 in3 source		
Fault reset	31.11 Fault reset selection		
Speed control	·		

Outputs available to the adaptive program					
Output	Target				
Speed ref1	22.11 Speed ref1 source				
Speed ref2	22.12 Speed ref2 source				
Speed additive 1	22.15 Speed additive 1 source				
Speed (controller) proportional gain	25.02 Speed proportional gain				
Speed (controller) integration time	25.03 Speed integration time				
Acceleration time 1	23.12 Acceleration time 1				
Deceleration time 1	23.12 Deceleration time 1				
Frequency control					
Frequency ref1	28.11 Frequency ref1 source				
Frequency ref2	28.12 Frequency ref2 source				
Torque control					
Torque ref1	26.11 Torque ref1 source				
Torque ref2	26.12 Torque ref2 source				
Torque additive 2	26.25 Torque additive 2 source				
Limitations					
Minimum torque 2	30.21 Minimum torque 2 source				
Maximum torque 2	30.22 Maximum torque 2 source				
Events					
External event 1	31.01 External event 1 source				
External event 2	31.03 External event 2 source				
External event 3	31.05 External event 3 source				
External event 4	31.07 External event 4 source				
External event 5	31.09 External event 5 source				
Data storage					
Data storage 1 real 32	47.01 Data storage 1 real32				
• • •					
Data storage 8 real 32	47.08 Data storage 8 real32				
Process PID					
Set 1 setpoint 1	40.16 Set 1 setpoint 1 source				
Set 1 setpoint 2	40.17 Set 1 setpoint 2 source				
Set 1 feedback 1	40.08 Set 1 feedback 1 source				
Set 1 feedback 2	40.09 Set 1 feedback 2 source				
Set 1 (PID controller) gain	40.32 Set 1 gain				
Set 1 (PID controller) integration time	40.33 Set 1 integration time				
Set 1 tracking mode	40.49 Set 1 tracking mode				
Set 1 track reference	40.50 Set 1 tracking ref selection				

# Application programming

The winder application control program is based on the IEC 61131-3 standard. The program is an in-house application and is locked to the user to avoid any changes to the program.

## **Control interfaces**

## Programmable analog inputs

The control unit has two programmable analog inputs. Each of the inputs can be independently set as a voltage (0/2...10 V or -10...10 V) or current (0/4...20 mA) input by a jumper or switch on the control unit. Each input can be filtered, inverted and scaled. The analog inputs on the control unit are read on a 0.5 ms time level.

The number of analog inputs can be increased by installing FIO-11 or FAIO-01 I/O extensions (see *Programmable I/O extensions* below). The analog inputs on the extension modules are read on a 2 ms time level.

The drive can be set to perform an action (for example, to generate a warning or fault) if the value of an analog input goes beyond the predefined range.

### **Settings**

Parameter group 12 Standard AI (page 205).

## Programmable analog outputs

The control unit has two current (0...20 mA) analog outputs. Each output can be filtered, inverted and scaled. The analog outputs on the control unit are updated on a 0.5 ms time level.

The number of analog outputs can be increased by installing FIO-11 or FAIO-01 I/O extensions (see Programmable I/O extensions below). The analog outputs on extension modules are updated on a 2 ms time level.

#### Settings

Parameter group 13 Standard AO (page 209).

# Programmable digital inputs and outputs

The control unit has six digital inputs, a digital start interlock input, and two digital input/outputs (I/O that can be set as either an input or an output). The digital inputs on the control unit are read on a 0.5 ms time level.

One digital input (DI6) doubles as a PTC thermistor input. See section *Motor thermal* protection (page 122).

Digital input/output DIO1 can be used as a frequency input, DIO2 as a frequency output.

The number of digital inputs/outputs can be increased by installing FIO-01, FIO-11 or FDIO-01 I/O extensions (see *Programmable I/O extensions* below). The digital inputs on extension modules are read on a 2 ms time level.

#### **Settings**

Parameter groups 10 Standard DI, RO (page 193) and 11 Standard DIO, FI, FO (page 200).

## Programmable relay outputs

The control unit has three relay outputs. The signal to be indicated by the outputs can be selected by parameters. The relay outputs on the control unit are updated on a 0.5 ms time level.

Relay outputs can be added by installing FIO-01 or FDIO-01 I/O extensions. The relay outputs on extension modules are updated on a 2 ms time level.

#### **Settings**

Parameter group 10 Standard DI, RO (page 193).

## Programmable I/O extensions

You can add inputs and outputs using I/O extension modules. The control unit includes slots to mount one to three modules. You can add slots by connecting an FEA-03 I/O extension adapter.

The table below shows the number of I/O on the control unit as well as optional I/O extension modules.

Location	Digital inputs (DI)	Digital I/Os (DIO)	Analog inputs (Al)	Analog outputs (AO)	Relay outputs (RO)
Control unit	6 + DIIL	2	2	2	3
FIO-01	-	4	-	-	2
FIO-11	-	2	3	1	-
FAIO-01	-	-	2	2	-
FDIO-01	3	ı	-	-	2

Three I/O extension modules can be activated and configured using parameter groups 14...16.

**Note:** Each configuration parameter group contains parameters that display the values of the inputs on that particular extension module. These parameters are the only way of utilizing the inputs on I/O extension modules as signal sources. To connect to an input, choose the setting *Other* in the source selector parameter, then specify the appropriate value parameter (and bit, for digital signals) in group 14, 15 or 16.

#### Settings

Parameter groups 14 I/O extension module 1 (page 213), 15 I/O extension module 2 (page 233) and 16 I/O extension module 3 (page 237). Parameter 60.41 (page 416).

#### Fieldbus control

The drive can be connected to several different automation systems through its fieldbus interfaces. See chapters Fieldbus control through the embedded fieldbus interface (EFB) (page 643) and Fieldbus control through a fieldbus adapter (page 667).

### **Settings**


Parameter groups 50 Fieldbus adapter (FBA) (page 388), 51 FBA A settings (page 396), 52 FBA A data in (page 398), and 53 FBA A data out (page 399), 54 FBA B settings (page 399), 55 FBA B data in (page 400), 56 FBA B data out (page 401) and 58 Embedded fieldbus (page 401).

# Master/follower functionality

#### General

The master/follower functionality can be used to link several drives together so that the load can be evenly distributed between the drives. This is ideal in applications where the motors are coupled to each other through gearing, chain, belt, etc.

The external control signals are typically connected to one drive only which acts as the master. The master controls up to 10 followers by sending broadcast messages over an electric cable or fiber optic link. The master can read feedback signals from up to 3 selected followers.



The master drive is typically speed-controlled and the other drives follow its torque or speed reference. In general, a follower should be

- torque-controlled when the motor shafts of the master and the follower are rigidly coupled by gearing, chain etc. so that no speed difference between the drives is possible
- speed-controlled when the motor shafts of the master and the follower are flexibly coupled so that a slight speed difference is possible. When both the master and the follower are speed-controlled, drooping is also typically used (see parameter 25.08 Drooping rate). The distribution of load between the master and follower can alternatively be adjusted as described under Load share function with a speed-controlled follower below.

**Note:** With a speed-controlled follower (without load sharing), pay attention to the acceleration and deceleration ramp times of the follower. If the ramp times are set longer than in the master, the follower will follow its own acceleration/deceleration ramp times rather than those from the master. In general, it is recommended to set identical ramp times in both the master and the follower(s). Any ramp shape settings (see parameters 23.16...23.19) should only be applied in the master.

In some applications, both speed control and torque control of the follower are required. In those cases, the operating mode can be switched by parameter (19.12 Ext1 control mode or 19.14 Ext2 control mode). Another method is to set one external control location to speed control mode, the other to torque control mode. Then, a digital input of the follower can be used to switch between the control locations. See chapter Control locations and operating modes (page 39).

With torque control, follower parameter 26.15 Load share can be used to scale the incoming torque reference for optimal load sharing between the master and the follower. Some torque-controlled follower applications, e.g. where the torque is very low, or very low speed operation is required, may require encoder feedback.

If a drive needs to quickly switch between master and follower statuses, one user parameter set (see page 133) can be saved with the master settings, another with the follower settings. The suitable settings can then be activated using e.g. digital inputs.

### Load share function with a speed-controlled follower

Load sharing between the master and a speed-controlled follower can be used in various applications. The load share function is implemented by fine-tuning the follower speed reference with an additional trim signal based on a torque reference. The torque reference is selected by parameter 23.42 Follower speed corr torq source (by default, reference 2 received from the master). Load share is adjusted by parameter 26.15 Load share and activated by the source selected by 23.40 Follower speed correction enable. Parameter 23.41 Follower speed correction gain provides a gain adjustment for the speed correction. The final correction signal added to the speed reference is shown by 23.39 Follower speed correction out. See the block diagram on page 684.

#### Notes:

- The function can be enabled only when the drive is a speed-controlled follower in remote control mode.
- Drooping (25.08 Drooping rate) is ignored when the load share function is active.
- The master and follower should have the same speed control tuning values.
- The speed correction term is limited by the speed error window parameters 24.44 Speed error window low and 24.43 Speed error window high. An active limitation is indicated by 06.19 Speed control status word.

#### Communication

You can build a master/follower link by connecting the drives together with fiber optic cables (may required additional equipment depending on the existing drive hardware), or by wiring together the XD2D connectors of the drives. The medium is selected by parameter 60.01 M/F communication port.

Parameter 60.03 M/F mode defines whether the drive is the master or a follower on the communication link. Typically, the speed-controlled process master drive is also configured as the master in the communication.

The communication on the master/follower link is based on the DDCS protocol, which employs data sets (specifically, data set 41). One data set contains three 16-bit words. The contents of the data set are freely configurable using parameters 61.01...61.03. The data set broadcast by the master typically contains the control word, speed reference and torque reference, while the followers return a status word with two actual values.

The default setting of parameter 61.01 M/F data 1 selection is Follower CW. With this setting in the master, a word consisting of bits 0...11 of 06.01 Main control word and four bits selected by parameters 06.45...06.48 is broadcast to the followers. However, bit 3 of the follower control word is modified so that it remains on as long as the master is modulating, and its switching to 0 causes the follower to coast to a stop. This is to synchronize the stopping of both master and follower.

**Note:** When the master is ramping down to a stop, the follower observes the decreasing reference but receives no stop command until the master stops modulating and clears bit 3 of the follower control word. Because of this, the maximum and minimum speed limits on the follower drive should not have the same sign – otherwise the follower would be pushing against the limit until the master finally stops.

Three words of additional data can optionally be read from each follower. The followers from which data is read are selected by parameter 60.14 M/F follower selection in the master. In each follower drive, the data to be sent is selected by parameters 61.01...61.03. The data is transferred in integer format over the link, and displayed by parameters 62.28...62.36 in the master. The data can then be forwarded to other parameters using 62.04...62.12.

To indicate faults in the followers, each follower must be configured to transmit its status word as one of the above-mentioned data words. In the master, the corresponding target parameter must be set to *Follower SW*. The action to be taken when a follower is faulted is selected by 60.17 Follower fault action. External events (see parameter group 31 Fault functions) can be used to indicate the status of other bits of the status word.

Block diagrams of the master/follower communication are presented on pages 696 and 697.


#### Construction of the master/follower link

The master/follower link is formed by connecting the drives together using either

- shielded twisted-pair cable between the XD2D terminals of the drives\*, or
- fiber optic cables. Drives with a ZCU control unit require an additional FDCO DDCS communication module; drives with a BCU control unit require an RDCO module.

Connection examples are shown below. Note that a star configuration using fiber optic cables requires an NDBU-95C DDCS branching unit.


#### Master/follower wiring with electrical cable



See the hardware manual of the drive for wiring and termination details.


<sup>\*</sup>This connection cannot co-exist with, and is not to be confused with, drive to drive (D2D) communication implemented by application programming (detailed in *Drive application* programming manual (IEC 61131-3), 3AUA0000127808 [English]).


# Ring configuration with fiber optic cables



T = Transmitter; R = Receiver

# Star configuration with fiber optic cables (1)





### Star configuration with fiber optic cables (2)

#### **Example parameter settings**

The following is a checklist of parameters that need to be set when configuring the master/follower link. In this example, the master broadcasts the Follower control word, a speed reference and a torque reference. The follower returns a status word and two actual values (this is not compulsory but is shown for clarity).

#### Master settings:

- Master/follower link activation
  - 60.01 M/F communication port (fiber optic channel or XD2D selection)
  - (60.02 M/F node address = 1)
  - 60.03 M/F mode = DDCS master
  - 60.05 M/F HW connection (Ring or Star for fiber optic, Star for wire)
- Data to be broadcast to the followers
  - 61.01 M/F data 1 selection = Follower CW (Follower control word)
  - 61.02 M/F data 2 selection = Used speed reference
  - 61.03 M/F data 3 selection = Torque reference act 5
- Data to be read from the followers (optional)
  - 60.14 M/F follower selection (selection of followers that data is read from)
  - 62.04 Follower node 2 data 1 sel ... 62.12 Follower node 4 data 3 sel (mapping of data received from followers)

## Follower settings:

- Master/follower link activation
  - 60.01 M/F communication port (fiber optic channel or XD2D selection)
  - 60.02 M/F node address = 2...60
  - 60.03 M/F mode = DDCS follower
  - 60.05 M/F HW connection (Ring or Star for fiber optic, Star for electrical cable)
- Mapping of data received from master
  - 62.01 M/F data 1 selection = CW 16bit
  - 62.02 M/F data 2 selection = Ref1 16bit
  - 62.03 M/F data 3 selection = Ref2 16bit
- Selection of operating mode and control location
  - 19.12 Ext1 control mode = Speed or Torque
  - 20.01 Ext1 commands = M/F link
  - 20.02 Ext1 start trigger type = Level
- Selection of reference sources
  - 22.11 Speed ref1 source = M/F reference 1
  - 26.11 Torque ref1 source = M/F reference 2
- Selection of data to be sent to master (optional)
  - 61.01 M/F data 1 selection = SW 16bit
  - 61.02 M/F data 2 selection = Act1 16bit
  - 61.03 M/F data 3 selection = Act2 16bit

### Specifications of the fiber optic master/follower link

- Maximum fiber optic cable length:
  - FDCO-01/02 or RDCO-04 with POF (Plastic Optic Fiber): 30 m
  - FDCO-01/02 or RDCO-04 with HCS (Hard-clad Silica Fiber): 200 m
  - For distances up to 1000 m, use two NOCR-01 optical converter/repeaters with glass optic cable (GOF, 62.5 micrometers, Multi-Mode)
- Maximum shielded twisted-pair cable length: 50 m
- Transmission rate: 4 Mbit/s
- Total performance of the link: < 5 ms to transfer references between the master and followers.
- Protocol: DDCS (Distributed Drives Communication System)

### **Settings and diagnostics**

Parameter groups 60 DDCS communication (page 409), 61 D2D and DDCS transmit data (page 421) and 62 D2D and DDCS receive data (page 426).

#### External controller interface

#### General


The drive can be connected to an external controller (such as the ABB AC 800M) using fiber optic cables or twisted-pair cable. The ACS880 is compatible with both the ModuleBus and DriveBus connections.

Note: Some features of DriveBus (such as BusManager) are not supported.

### **Topology**

An example connection with either a ZCU-based or BCU-based drive using fiber optic cables is shown below.

Drives with a **ZCU** control unit require an additional FDCO DDCS communication module; drives with a BCU control unit require an RDCO or FDCO module. The BCU has a dedicated slot for the RDCO – an FDCO module can also be used with a BCU control unit but it will reserve one of the three universal option module slots. Ring and star configurations are also possible much in the same way as with the master/follower link (see section Master/follower functionality on page 74); the notable difference is that the external controller connects to channel CH0 on the RDCO board instead of CH2. The channel on the FDCO communication module can be freely selected.



T = Transmitter; R = Receiver

The external controller can also be wired to the D2D (RS-485) connector using shielded, twisted-pair cable. The selection of the connection is made by parameter 60.51 DDCS controller comm port.

The transfer rate can be selected by parameter 60.56 DDCS controller baud rate.


#### Communication

The communication between the controller and the drive consists of data sets of three 16-bit words each. The controller sends a data set to the drive, which returns the next data set to the controller.

The communication uses data sets 10...33. The contents of the data sets are freely configurable, but data set 10 typically contains the control word and one or two references, while data set 11 returns the status word and selected actual values. For ModuleBus communication, the ACS880 can be set up as a "standard drive" or an "engineered drive" by parameter 60.50 DDCS controller drive type. ModuleBus communication uses data sets 1...4 with a "standard drive" and data sets 10...33 with an "engineered drive".

The word that is defined as the control word is internally connected to the drive logic; the coding of the bits is as presented in section Contents of the fieldbus Control word (ABB Drives profile) (page 673). Likewise, the coding of the status word is as shown in section Contents of the fieldbus Status word (ABB Drives profile) (page 674).

By default, data sets 32 and 33 are dedicated for the mailbox service, which enables the setting or inquiry of parameter values as follows:



<sup>\*19.01 -&</sup>gt; 13h.01h -> 1301h = 4865

By parameter 60.64 Mailbox dataset selection, data sets 24 and 25 can be selected instead of data sets 32 and 33

The update intervals of the data sets are as follows:

- Data sets 10...11: 2 ms
- Data sets 12...13: 4 ms
- Data sets 14...17: 10 ms
- Data sets 18...25, 32, 33: 100 ms.

#### Settings

Parameter groups 60 DDCS communication (page 409), 61 D2D and DDCS transmit data (page 421) and 62 D2D and DDCS receive data (page 426).

<sup>\*\*24.03 -&</sup>gt; 18h.03h -> 1803h = 6147

# Control of a supply unit (LSU)

#### General

If the drive has separately-controlled supply and inverter units (also known as lineside and motor-side converters), the supply unit can be controlled through the inverter unit. For example, the inverter unit can send a control word and references to the supply unit, enabling the control of both units from the interfaces of one control program.

With ACS880 single drives, the two control units are connected at the factory. In ACS880 multidrives (drive systems with one supply unit and multiple inverter units), the feature is not typically used.

#### Communication

The communication between the converters and the drive consists of data sets of three 16-bit words each. The inverter unit sends a data set to the supply unit, which returns the next data set to the inverter unit.

The communication uses data sets 10 and 11, updated at 2 ms intervals. Data sets 10 is sent by the inverter unit to the supply unit, while data set 11 is sent by the supply unit to the inverter unit. The contents of the data sets are freely configurable, but data set 10 typically contains the control word, while data set 11 returns the status word.

The basic communication is initialized by parameter 95.20 HW options word 1. This will make several parameters visible (see below).

If the supply unit is regenerative (such as an IGBT supply unit), it is possible to send a DC voltage and/or reactive power reference to it from inverter parameter group 94 LSU control. A regenerative supply unit will also send actual signals to the inverter unit which are visible in parameter group 01 Actual values.

### Settings

- Parameters 01.102...01.164 (page 164), 05.111...05.121 (page 174), 06.36...06.43 (page 182), 06.116...06.118 (page 188), 07.106...07.107 (page 191), 30.101...30.149 (page 315), 31.120...31.121 (page 325), 95.20 HW options word 1 (page 505) and 96.08 LSU control board boot (page 518).
- Parameter groups 60 DDCS communication (page 409), 61 D2D and DDCS transmit data (page 421), 62 D2D and DDCS receive data (page 426) and 94 LSU control (page 498).

## Motor control

# **Direct torque control (DTC)**

The motor control of the ACS880 is based on direct torque control (DTC), the ABB premium motor control platform. The switching of the output semiconductors is controlled to achieve the required stator flux and motor torque. The switching frequency is changed only if the actual torque and stator flux values differ from their reference values by more than the allowed hysteresis. The reference value for the torque controller comes from the speed controller or directly from an external torque reference source.

Motor control requires measurement of the DC voltage and two motor phase currents. Stator flux is calculated by integrating the motor voltage in vector space. Motor torque is calculated as a cross product of the stator flux and the rotor current. By utilizing the identified motor model, the stator flux estimate is improved. Actual motor shaft speed is not needed for the motor control.

The main difference between traditional control and DTC is that torque control operates on the same time level as the power switch control. There is no separate voltage and frequency controlled PWM modulator; the output stage switching is wholly based on the electromagnetic state of the motor.

The best motor control accuracy is achieved by activating a separate motor identification run (ID run).

See also section Scalar motor control (page 100).

#### **Settings**

Parameters 99.04 Motor control mode (page 526) and 99.13 ID run requested (page 528).

# Reference ramping

Acceleration and deceleration ramping times can be set individually for speed, torque and frequency reference.

With a speed or frequency reference, the ramps are defined as the time it takes for the drive to accelerate or decelerate between zero speed or frequency and the value defined by parameter 46.01 Speed scaling or 46.02 Frequency scaling. The user can switch between two preset ramp sets using a binary source such as a digital input. For speed reference, also the shape of the ramp can be controlled.

With a torque reference, the ramps are defined as the time it takes for the reference to change between zero and nominal motor torque (parameter 01.30 Nominal torque scale).

## Special acceleration/deceleration ramps

The acceleration/deceleration times for the jogging function can be defined separately; see section Jogging (page 97).

The change rate of the motor potentiometer function (page 100) is adjustable. The same rate applies in both directions.

A deceleration ramp can be defined for emergency stop ("Off3" mode).

### **Settings**

- Speed reference ramping: Parameters 23.11...23.19 and 46.01 (pages 268 and 379).
- Torque reference ramping: Parameters 01.30, 26.18 and 26.19 (pages 162 and 293).
- Frequency reference ramping: Parameters 28.71...28.75 and 46.02 (pages 303 and 379).
- Jogging: Parameters 23.20 and 23.21 (page 271).
- Motor potentiometer: Parameter 22.75 (page 266).
- Emergency stop ("Off3" mode): Parameter 23.23 Emergency stop time (page 271).

# **Constant speeds/frequencies**

Constant speeds and frequencies are predefined references that can be quickly activated, for example, through digital inputs. It is possible to define up to 7 constant speeds for speed control and 7 constant frequencies for frequency control.



**WARNING:** Constant speeds and frequencies override the normal reference irrespective of where the reference is coming from.

The constant speeds/frequencies function operates on a 2 ms time level.

## Settings

Parameter groups 22 Speed reference selection (page 260) and 28 Frequency reference chain (page 298).

# Critical speeds/frequencies

Critical speeds (sometimes called "skip speeds") can be predefined for applications where it is necessary to avoid certain motor speeds or speed ranges because of, for example, mechanical resonance problems.


The critical speeds function prevents the reference from dwelling within a critical band for extended times. When a changing reference (22.87 Speed reference act 7) enters a critical range, the output of the function (22.01 Speed ref unlimited) freezes until the reference exits the range. Any instant change in the output is smoothed out by the ramping function further in the reference chain.

The function is also available for scalar motor control with a frequency reference. The input of the function is shown by 28.96 Frequency ref act 7, the output by 28.97 Frequency ref unlimited.

### **Example**

A fan has vibrations in the range of 540 to 690 rpm and 1380 to 1560 rpm. To make the drive avoid these speed ranges,

- enable the critical speeds function by turning on bit 0 of parameter 22.51 Critical speed function, and
- set the critical speed ranges as in the figure below.



# **Settings**

Critical speeds: parameters 22.51...22.57 (page 265)

3 2

4

Critical frequencies: parameters 28.51...28.57 (page 302).

# Speed controller autotune

The speed controller of the drive can be automatically adjusted using the autotune function. Autotuning is based on an estimation of the mechanical time constant (inertia) of the motor and machine.


22.87 Speed reference act 7 (rpm)

(input of function)

The autotune routine runs the motor through a series of acceleration/deceleration cycles, the number of which can be adjusted with parameter 25.40 Autotune repeat times. Higher values produce more accurate results, especially if the difference between initial and maximum speeds is small.

The maximum torque reference used during autotuning will be the initial torque (i.e. torque when the routine is activated) plus 25.38 Autotune torque step, unless limited by the maximum torque limit (parameter group 30 Limits) or the nominal motor torque (99 Motor data). The calculated maximum speed during the routine is the initial speed (i.e. speed when the routine is activated) + 25.39 Autotune speed step, unless limited by 30.12 Maximum speed or 99.09 Motor nominal speed.

The diagram below shows the behavior of speed and torque during the autotune routine. In this example, 25.40 Autotune repeat times is set to 2.



#### Notes:

- If the drive cannot produce the requested braking power during the routine, the results will be based on the acceleration stages only, and not as accurate as with full braking power.
- The motor exceeds the calculated maximum speed slightly at the end of each acceleration stage.

### Before activating the autotune routine

The prerequisites for performing the autotune routine are:

- The motor identification run (ID run) has been successfully completed
- Speed and torque limits (parameter group 30 Limits) have been set
- The speed feedback has been monitored for noise, vibrations and other disturbances caused by the mechanics of the system, and
  - speed feedback filtering (parameter group 90 Feedback selection)
  - speed error filtering (24 Speed reference conditioning) and
  - zero speed (21.06 and 21.07)


have been set to eliminate these disturbances.

The drive has been started and is running in speed control mode.

After these conditions have been fulfilled, autotuning can be activated by parameter 25.33 Speed controller autotune (or the signal source selected by it).

#### Autotune modes

Autotuning can be performed in three different ways depending on the setting of parameter 25.34 Speed controller autotune mode. The selections Smooth, Normal and *Tight* define how the drive torque reference should react to a speed reference step after tuning. The selection Smooth produces a slow but robust response; Tight produces a fast response but possibly too high gain values for some applications. The figure below shows speed responses at a speed reference step (typically 1...20%).



- A: Under compensated
- B: Normally tuned (autotuning)
- C: Normally tuned (manually). Better dynamic performance than with B
- D: Over compensated speed controller


#### Autotune results

At the end of a successful autotune routine, its results are automatically transferred into parameters

- 25.02 Speed proportional gain (proportional gain of the speed controller)
- 25.03 Speed integration time (integration time of the speed controller)
- 25.37 Mechanical time constant (mechanical time constant of the motor and machine).

Nevertheless, it is still possible to manually adjust the controller gain, integration time and derivation time.

The figure below is a simplified block diagram of the speed controller. The controller output is the reference for the torque controller.



### Warning indications

A warning message, AF90 Speed controller autotuning, is generated if the autotune routine does not complete successfully. See chapter Fault tracing (page 593) for further information.

### **Settings**

Parameters 25.33...25.40 (page 288).

# **Oscillation damping**

The oscillation damping function can be used to cancel out oscillations caused by mechanics or an oscillating DC voltage. The input – a signal reflecting the oscillation - is selected by parameter 26.53 Oscillation compensation input. The oscillation damping function outputs a sine wave (26.58 Oscillation damping output) which can be summed with the torque reference with a suitable gain (26.57 Oscillation damping gain) and phase shift (26.56 Oscillation damping phase).

The oscillation damping algorithm can be activated without connecting the output to the reference chain, which makes it possible to compare the input and output of the function and make further adjustments before applying the result.

## Tuning procedure for oscillation damping

Select the input by 26.53 Oscillation compensation input Activate algorithm by 26.51 Oscillation damping Set 26.57 Oscillation damping gain to 0 Calculate the oscillation frequency from the signal (use the Drive composer PC tool) and set 26.55 Oscillation damping frequency Set 26.56 Oscillation damping phase\* Increase 26.57 Oscillation damping gain gradually so that the algorithm starts to take effect. oscillation amplitude decreases oscillation amplitude increases Increase 26.57 Oscillation damping gain Try other values for 26.56 Oscillation and adjust 26.56 Oscillation damping damping phase phase if necessary \*If the phasing of a DC oscillation cannot be determined by measuring, the value of 0 Increase 26.57 Oscillation damping gain to

**Note:** Changing the speed error low-pass filter time constant or the integration time of the speed controller can affect the tuning of the oscillation damping algorithm. It is recommended to tune the speed controller before the oscillation damping algorithm. (The speed controller gain can be adjusted after the tuning of this algorithm.)

degrees is usually a suitable initial value.


#### **Settings**

Parameters 26.51...26.58 (page 295).

suppress the oscillation totally.

### Rush control

In torque control, the motor could potentially rush if the load were suddenly lost. The control program has a rush control function that decreases the torque reference whenever the motor speed exceeds 30.11 Minimum speed or 30.12 Maximum speed.



The function is based on a PID controller. The proportional gain and integration time can be defined by parameters. Setting these to zero disables rush control.

## **Settings**

Parameters 26.81 Rush control gain and 26.82 Rush control integration time (page 297).

# **Encoder support**

The program supports two single-turn or multi-turn encoders (or resolvers). The following optional interface modules are available:

- TTL encoder interface FEN-01: two TTL inputs, TTL output (for encoder emulation and echo) and two digital inputs
- Absolute encoder interface FEN-11: absolute encoder input, TTL input, TTL output (for encoder emulation and echo) and two digital inputs
- Resolver interface FEN-21: resolver input, TTL input, TTL output (for encoder emulation echo) and two digital inputs
- HTL encoder interface FEN-31: HTL encoder input, TTL output (for encoder emulation and echo) and two digital inputs.
- HTL/TTL encoder interface FSE-31 (for use with an FSO-xx safety functions module): Two HTL/TTL encoder inputs (one HTL input supported at the time of publication).

You must install the interface module onto one of the option slots of the drive control unit. The module (except the FSE-31) can also be installed onto an FEA-03 extension adapter.

#### **Encoder echo and emulation**

Both encoder echo and emulation are supported by the above-mentioned FEN-xx interfaces.

Encoder echo is available with TTL, TTL+ and HTL encoders. The signal received from the encoder is relayed to the TTL output unchanged. This enables the connection of one encoder to several drives.


Encoder emulation also relays the encoder signal to the output, but the signal is either scaled, or position data converted to pulses. Emulation can be used when absolute encoder or resolver position needs to be converted to TTL pulses, or when the signal must be converted to a different pulse number than the original.

#### Load and motor feedback

Three different sources can be used as speed and position feedback: encoder 1, encoder 2, or motor position estimate. Any of these can be used for load position calculation or motor control. The load position calculation makes it possible, for example, to determine the position of a conveyor belt or the height of the load on a crane. The feedback sources are selected by parameters 90.41 Motor feedback selection and 90.51 Load feedback selection.

For detailed parameter connections of the motor and load feedback functions, see the block diagrams Motor feedback configuration (page 683) and Load feedback and position counter configuration (page 684). For more information on load position calculation, see section *Position counter* (page 93).

Any mechanical gear ratios between the components (motor, motor encoder, load, load encoder) are specified using the gear parameters shown in the diagram below.



Any gear ratio between the load encoder and the load is defined by 90.53 Load gear numerator and 90.54 Load gear denominator. Similarly, any gear ratio between the motor encoder and the motor is defined by 90.43 Motor gear numerator and 90.44 Motor gear denominator. In case the internal estimated position is chosen as load feedback, the gear ratio between the motor and load can be defined by 90.61 Gear numerator and 90.62 Gear denominator.


By default, all the ratios mentioned above are 1:1. The ratios can only be changed with the drive stopped. The new settings require validation by 91.10 Encoder parameter refresh.

#### Position counter

The control program contains a position counter feature that can be used to indicate the position of the load. The output of the counter function, parameter 90.07 Load position scaled int, indicates the scaled number of revolutions read from the selected source (see section Load and motor feedback on page 92).

The relation between revolutions of the motor shaft and the translatory movement of the load (in any given unit of distance) is defined by parameters 90.63 Feed constant numerator and 90.64 Feed constant denominator. This gear function can be changed without the need of a parameter refresh or position counter reinitialization – however, the counter output is only updated after the new position input data is received.

For detailed parameter connections of the load feedback function, see the block diagram on page 684.



The position counter is initialized by setting a known physical position of the load into the control program. The initial position (for example, the home/zero position, or the distance from it) can be entered manually in a parameter (90.58 Pos counter init value int), or taken from another parameter. This position is set as the value of the position counter (90.07 Load position scaled int) when the source selected by 90.67 Pos counter init cmd source, such as a proximity switch connected to a digital input, is activated. A successful initialization is indicated by bit 4 of 90.35 Pos counter status.

Any subsequent initialization of the counter must first be enabled by 90.69 Reset pos counter init ready. To define a time window for initializations, 90.68 Disable pos counter initialization can be used to inhibit the signal from the proximity switch. An active fault in the drive will also prevent counter initialization.

## **Encoder error handling**

When an encoder is used for load feedback, the action taken in case of an encoder error is specified by 90.55 Load feedback fault. If the parameter is set to Warning, the calculation will continue smoothly using estimated motor position. If the encoder recovers from the error, the calculation will smoothly switch back to encoder feedback. The load position signals (90.04, 90.05 and 90.07) will continue to be updated all the time, but bit 6 of 90.35 Pos counter status will be set to indicate potentially inaccurate position data. In addition, bit 4 of 90.35 will be cleared upon the next stop as a recommendation to reinitialize the position counter.

Parameter 90.60 Pos counter error and boot action defines whether position calculation resumes from the previous value over an encoder error or control unit reboot. By default, bit 4 of 90.35 Pos counter status is cleared after an error, indicating that reinitialization is needed. With 90.60 set to Continue from previous value, the position values are retained over an error or reboot; bit 6 of 90.35 Pos counter status is set however to indicate that an error occurred.

**Note:** With a multiturn absolute encoder, bit 6 of 90.35 is cleared at the next stop of the drive if the encoder has recovered from the error; bit 4 is not cleared. The status of the position counter is retained over a control unit reboot, after which position calculation resumes from the absolute position given by the encoder, taking into account the initial position specified by 90.58.

**WARNING!** If the drive is in stopped state when an encoder error occurs, or if the drive is not powered, parameters 90.04, 90.05, 90.07 and 90.35 are not updated because no movement of the load can be detected. When using previous position values (90.60 Pos counter error and boot action is set to Continue from previous value), be aware that the position data is unreliable if the load is able to move.

#### Reading/writing position counter values through fieldbus

You can access the parameters of the position counter function, such as 90.05 Load position scaled and 90.65 Pos counter init value from an upper-level control system in the following formats:

- 16-bit integer (if 16 bits are sufficient for the application)
- 32-bit integer (can be accessed as two consequent 16-bit words).

For example, to read parameter 90.05 Load position scaled through fieldbus, set the selection parameter of the desired dataset (in group 52) to Other – 90.07, and select the format. If you select a 32-bit format, the subsequent data word is also automatically reserved.

## Configuration of HTL encoder motor feedback

- 1. Specify the type of the encoder interface module (parameter 91.11 Module 1 type = FEN-31) and the slot the module is installed into (91.12 Module 1 location).
- 2. Specify the type of the encoder (92.01 Encoder 1 type = HTL). The parameter listing will be re-read from the drive after the value is changed.
- 3. Specify the interface module that the encoder is connected to (92.02 Encoder 1 source = Module 1).
- 4. Set the number of pulses according to encoder nameplate (92.10 Pulses/revolution).
- 5. If the encoder rotates at a different speed to the motor (i.e. is not mounted directly on the motor shaft), enter the gear ratio in 90.43 Motor gear numerator and 90.44 Motor gear denominator.
- 6. Set parameter 91.10 Encoder parameter refresh to Refresh to apply the new parameter settings. The parameter automatically reverts to *Done*.
- 7. Check that 91.02 Module 1 status is showing the correct interface module type (FEN-31). Also check the status of the module; both LEDs should be glowing green.
- 8. Start the motor with a reference of e.g. 400 rpm.
- 9. Compare the estimated speed (01.02 Motor speed estimated) with the measured speed (01.04 Encoder 1 speed filtered). If the values are the same, set the encoder as the feedback source (90.41 Motor feedback selection = Encoder 1).
- 10. Specify the action taken in case the feedback signal is lost (90.45 Motor feedback fault).

# Example 1: Using the same encoder for both load and motor feedback

The drive controls a motor used for lifting a load in a crane. An encoder attached to the motor shaft is used as feedback for motor control. The same encoder is also used for calculating the height of the load in the desired unit. A gear exists between the motor shaft and the cable drum. The encoder is configured as Encoder 1 as shown in Configuration of HTL encoder motor feedback above. In addition, the following settings are made:

- parameter 90.43 Motor gear numerator = 1
- parameter 90.44 Motor gear denominator = 1

(No gear is needed as the encoder is mounted directly on the motor shaft.)

- parameter 90.51 Load feedback selection = Encoder 1
- parameter 90.53 Load gear numerator = 1
- parameter 90.54 Load gear denominator = 50

The cable drum turns one revolution per 50 revolutions of the motor shaft.

parameter 90.61 Gear numerator = 1

- parameter 90.62 Gear denominator = 1 (These parameters need not be changed as position estimate is not being used for feedback.)
- parameter 90.63 Feed constant numerator = 7
- parameter 90.64 Feed constant denominator = 10

The load moves 70 centimeters, i.e. 7/10 of a meter, per one revolution of the cable drum.

The load height in meters can be read from 90.07 Load position scaled int, while 90.03 Load speed displays the rotational speed of the cable drum.

### **Example 2: Using two encoders**

One encoder (encoder 1) is used for motor feedback. The encoder is connected to the motor shaft through a gear. Another encoder (encoder 2) measures the line speed elsewhere in the machine. Each encoder is configured as shown in Configuration of HTL encoder motor feedback above. In addition, the following settings are made:

- parameter 90.41 Motor feedback selection = Encoder 1
- parameter 90.43 Motor gear numerator = 1
- parameter 90.44 Motor gear denominator = 3

The encoder turns three revolutions per one revolution of the motor shaft.

parameter 90.51 Load feedback selection = Encoder 2

The line speed measured by encoder 2 can be read from 90.03 Load speed. This value is given in rpm which can be converted into another unit by using 90.53 Load gear numerator and 90.54 Load gear denominator. Note that the feed constant gear cannot be used in this conversion because it does not affect 90.03 Load speed.

### Example 3: ACS 600 / ACS800 compatibility

With ACS 600 and ACS800 drives, both the rising and falling edges from encoder channels A and B are typically counted to achieve best possible accuracy. Thus the received pulse number per revolution equals four times the nominal pulse number of the encoder.

In this example, an HTL-type 2048-pulse encoder is fitted directly on the motor shaft. The desired initial position to correspond the proximity switch is 66770.

In the ACS880, the following settings are made:

- parameter 92.01 Encoder 1 type = HTL
- parameter 92.02 Encoder 1 source = Module 1
- parameter 92.10 Pulses/revolution = 2048
- parameter 92.13 Position estimation enable = Enable
- parameter 90.51 Load feedback selection = Encoder 1
- parameter 90.63 Feed constant numerator = 8192 (i.e. 4 × value of 92.10, as the received number of pulses is 4 times nominal. See also parameter 92.12 Resolver polepairs)
- The desired "data out" parameter is set to Other 90.58 Pos counter init value int (32-bit format). Only the high word needs to be specified – the subsequent data word is reserved for the low word automatically.
- The desired sources (such as digital inputs or user bits of the control word) are selected in 90.67 Pos counter init cmd source and 90.69 Reset pos counter init ready.

In the PLC, if the initial value is set in 32-bit format using low and high words (corresponding to ACS800 parameters POS COUNT INIT LO and POS COUNT INIT HI), enter the value 66770 into these words as follows:

E.g., PROFIBUS:

- FBA data out x = POS COUNT INIT HI = 1 (as bit 16 equals 66536)
- FBA data out (x + 1) = POS COUNT INIT LO = 1234.

ABB Automation using DDCS communication, e.g.:

- Data set 12.1 = POS COUNT INIT HI
- Data set 12.2 = POS COUNT INIT LO

To test the configuration of the PLC, initialize the position counter with the encoder connected. The initial value sent from the PLC should immediately be reflected by 90.07 Load position scaled int in the drive. The same value should then appear in the PLC after having been read from the drive.

#### **Settings**

Parameter groups 90 Feedback selection (page 478), 91 Encoder module settings (page 487), 92 Encoder 1 configuration (page 490) and 93 Encoder 2 configuration (page 496).

# Jogging

The jogging function enables the use of a momentary switch to briefly rotate the motor. The jogging function is typically used during servicing or commissioning to control the machinery locally.


Two jogging functions (1 and 2) are available, each with their own activation sources and references. The signal sources are selected by parameters 20.26 Jogging 1 start source and 20.27 Jogging 2 start source. When jogging is activated, the drive starts

and accelerates to the defined jogging speed (22.42 Jogging 1 ref or 22.43 Jogging 2 ref) along the defined jogging acceleration ramp (23.20 Acc time jogging). After the activation signal switches off, the drive decelerates to a stop along the defined jogging deceleration ramp (23.21 Dec time jogging).

The figure and table below provide an example of how the drive operates during jogging. In the example, the ramp stop mode is used (see parameter 21.03 Stop mode).

Jog cmd = State of source set by 20.26 Jogging 1 start source or 20.27 Jogging 2 start source

Jog enable = State of source set by 20.25 Jogging enable Start cmd = State of drive start command.



Phase	Jog cmd	Jog enable	Start cmd	Description
1-2	1	1	0	Drive accelerates to the jogging speed along the acceleration ramp of the jogging function.
2-3	1	1	0	Drive follows the jog reference.
3-4	0	1	0	Drive decelerates to zero speed along the deceleration ramp of the jogging function.
4-5	0	1	0	Drive is stopped.
5-6	1	1	0	Drive accelerates to the jogging speed along the acceleration ramp of the jogging function.
6-7	1	1	0	Drive follows the jog reference.
7-8	0	1	0	Drive decelerates to zero speed along the deceleration ramp of the jogging function.
8-9	0	1->0	0	Drive is stopped. As long as the jog enable signal is on, start commands are ignored. After jog enable switches off, a fresh start command is required.

Phase	Jog cmd	Jog enable	Start cmd	Description
9-10	х	0	1	Drive accelerates to the speed reference along the selected acceleration ramp (parameters 23.1123.19).
10-11	х	0	1	Drive follows the speed reference.
11-12	х	0	0	Drive decelerates to zero speed along the selected deceleration ramp (parameters 23.1123.19).
12-13	х	0	0	Drive is stopped.
13-14	х	0	1	Drive accelerates to the speed reference along the selected acceleration ramp (parameters 23.1123.19).
14-15	х	0->1	1	Drive follows the speed reference. As long as the start command is on, the jog enable signal is ignored. If the jog enable signal is on when the start command switches off, jogging is enabled immediately.
15-16	0->1	1	0	Start command switches off. The drive starts to decelerate along the selected deceleration ramp (parameters 23.1123.19).
				When the jog command switches on, the decelerating drive adopts the deceleration ramp of the jogging function.
16-17	1	1	0	Drive follows the jog reference.
17-18	0	1→0	0	Drive decelerates along the deceleration ramp of the jogging function.
18-19	0	0	0	Drive decelerates to zero speed along the selected deceleration ramp (parameters 23.1123.19).

See also the block diagram on page 682.

The jogging function operates on a 2 ms time level.

#### Notes:

- Jogging is not available when the drive is in local control.
- Jogging cannot be enabled when the drive start command is on, or the drive started when jogging is enabled. Starting the drive after the jog enable switches off requires a fresh start command.



**WARNING!** If jogging is enabled and activated while the start command is on, jogging activates as soon as the start command switches off.

- If both jogging functions are activated, the one that was activated first has priority.
- Jogging uses the speed control mode.
- Ramp shape times (parameters 23.16...23.19) do not apply to jogging acceleration/deceleration ramps.
- The inching functions activated through fieldbus (see 06.01 Main control word, bits 8...9) use the references and ramp times defined for jogging, but do not require the jog enable signal.

### **Settings**

Parameters 20.25 Jogging enable (page 251), 20.26 Jogging 1 start source (page 251), 20.27 Jogging 2 start source (page 252), 22.42 Jogging 1 ref (page 264), 22.43 Jogging 2 ref (page 264), 23.20 Acc time jogging (page 271) and 23.21 Dec time jogging (page 271).

#### Scalar motor control

It is possible to select scalar control as the motor control method instead of DTC (Direct Torque Control). In scalar control mode, the drive is controlled with a speed or frequency reference. However, the outstanding performance of DTC is not achieved in scalar control.

It is recommended to activate scalar motor control mode


- if the nominal current of the motor is less than 1/6 of the nominal output current of the drive
- if the drive is used without a motor connected (for example, for test purposes)
- if the drive runs a medium-voltage motor through a step-up transformer, or
- in multimotor drives, if
  - the load is not equally shared between the motors,
  - the motors are of different sizes, or
  - the motors are going to be changed after motor identification (ID run)

In scalar control, some standard features are not available.

See also section *Operating modes of the drive* (page 43).

## IR compensation for scalar motor control

IR compensation (also known as voltage boost) is available only when the motor control mode is scalar. When IR compensation is activated, the drive gives an extra voltage boost to the motor at low speeds. IR compensation is useful in applications that require a high break-away torque. In step-up applications, voltage cannot be fed through the transformer at 0 Hz, so an additional breakpoint is available for



defining the compensation near zero frequency.

In Direct Torque Control (DTC), no IR compensation is possible or needed as it is applied automatically.

### Settings

- Parameters 19.20 Scalar control reference unit (page 243), 97.12 IR comp stepup frequency (page 521), 97.13 IR compensation (page 522) and 99.04 Motor control mode (page 526)
- Parameter group 28 Frequency reference chain (page 298).

# Autophasing


Autophasing is an automatic measurement routine to determine the angular position of the magnetic flux of a permanent magnet synchronous motor or the magnetic axis of a synchronous reluctance motor. The motor control requires the absolute position of the rotor flux to control motor torque accurately.

Sensors like absolute encoders and resolvers indicate the rotor position at all times after the offset between the zero angle of rotor and that of the sensor has been established. On the other hand, a standard pulse encoder determines the rotor position when it rotates but the initial position is not known. However, a pulse encoder can be used as an absolute encoder if it is equipped with Hall sensors, albeit with coarse initial position accuracy. Hall sensors generate the so-called commutation pulses that change their state six times during one revolution, so it is only known within which 60° sector of a complete revolution the initial position is.

Many encoders give a zero pulse (also called Z-pulse) once during each rotation. The position of the zero pulse is fixed. If this position is known with respect to zero position used by motor control, the rotor position at the instant of the zero pulse is also known.

Using zero pulse improves the robustness of the rotor position measurement. You must determine the rotor position in the starting, because the encoder gives the initial value as zero. The autophasing routine determines the position, but there is a risk of

some position error. If the zero pulse position is already known, you can correct the position found by autophasing as soon the zero pulse is detected for the first time after starting.



The autophasing routine is performed with permanent magnet synchronous motors and synchronous reluctance motors in the following cases:

- 1. One-time measurement of the rotor and encoder position difference when an absolute encoder, a resolver, or an encoder with commutation signals is used
- 2. At every power-up when an incremental encoder is used
- 3. With open-loop motor control, repetitive measurement of the rotor position at every start.
- 4. When the position of the zero pulse must be measured before the first start after the power-up.

**Note**: In closed-loop control, autophasing is performed automatically after the motor identification run (ID run). Autophasing is also performed automatically before starting when necessary.

In open-loop control, the zero angle of the rotor is determined before starting. In closed-loop control, the actual angle of the rotor is determined with autophasing when the sensor indicates zero angle. The offset of the angle must be determined because the actual zero angles of the sensor and the rotor do not usually match. The autophasing mode determines how this operation is done both in open-loop and closed-loop control.

The rotor position offset used in motor control can also be given by the user – see parameter *98.15 Position offset user*. Note that the autophasing routine also writes its result into this parameter. The results are updated even if user settings are not enabled by *98.01 User motor model mode*.

**Note**: In open-loop control, the motor always turns when it is started as the shaft is turned towards the remanence flux.

### **Autophasing modes**

Several autophasing modes are available (see parameter 21.13 Autophasing mode).

- The *Turning* mode is recommended especially with case 1 (see the list above) as it is the most robust and accurate method. The rotor position is determined by turning the motor shaft back and forward (±360/pole pair)°. In case 3 (open-loop control), the shaft is turned only in one direction at smaller angles.
- The Turning with Z-pulse mode can be used when there is a problem using the normal turning mode, for example, in case of significant friction. You must turn the motor slowly until the encoder detects a zero pulse. When the zero pulse is detected for the first time, its position is stored into parameter 98.15 Position offset user, which you can edit for fine-tuning. Note that it is not mandatory to use this mode with a zero pulse encoder. In open-loop control, the two turning modes are identical.
- The Standstill 1 and Standstill 2 modes can be used if the motor cannot be turned (for example, when the load is connected). As the characteristics of motors and loads differ, you must test to know the most suitable standstill mode.

The drive determines the rotor position when started into a running motor in either open-loop control or closed-loop control. In this situation, the setting of 21.13 Autophasing mode has no effect.

The autophasing routine can fail and therefore it is recommended to perform the routine several times and check the value of parameter 98.15 Position offset user.

An autophasing fault (3385 Autophasing) can occur with a running motor if the estimated angle of the motor differs too much from the measured angle. This could be caused by, for example, in the following cases:


- The encoder is slipping on the motor shaft
- An incorrect value has been entered into 98.15 Position offset user
- The motor is already turning before the autophasing routine is started
- Turning mode is selected in 21.13 Autophasing mode but the motor shaft is locked
- Turning with Z-pulse mode is selected in 21.13 Autophasing mode, but no zero pulse is detected within a revolution of the motor
- The wrong motor type is selected in 99.03 Motor type
- Motor ID run has failed.

### **Settings**

Parameters 21.13 Autophasing mode (page 257), 98.15 Position offset user (page 525) and 99.13 ID run requested (page 528).

# Flux braking

The drive can provide greater deceleration by raising the level of magnetization in the motor. By increasing the motor flux, the energy generated by the motor during braking can be converted to motor thermal energy.



The drive monitors the motor status continuously, also during flux braking. Therefore, flux braking can be used both for stopping the motor and for changing the speed. The other benefits of flux braking are:

- The braking starts immediately after a stop command is given. The function does not need to wait for the flux reduction before it can start the braking.
- The cooling of the induction motor is efficient. The stator current of the motor increases during flux braking, not the rotor current. The stator cools much more efficiently than the rotor.
- Flux braking can be used with induction motors and permanent magnet synchronous motors.

Two braking power levels are available:

- Moderate braking provides faster deceleration compared to a situation where flux braking is disabled. The flux level of the motor is limited to prevent excessive heating of the motor.
- Full braking exploits almost all available current to convert the mechanical braking energy to motor thermal energy. Braking time is shorter compared to moderate braking. In cyclic use, motor heating may be significant.



**WARNING:** The motor needs to be rated to absorb the thermal energy generated by flux braking.

## **Settings**

Parameter 97.05 Flux braking (page 519).

## DC magnetization

DC magnetization can be applied to the motor to

- heat the motor to remove or prevent condensation, or
- lock the rotor at or near zero speed.

### **Pre-heating**

A motor pre-heating function is available to prevent condensation in a stopped motor, or to remove condensation from the motor before start. Pre-heating involves feeding a DC current into the motor to heat up the windings.

Pre-heating is deactivated at start, or when one of the other DC magnetization functions is activated. With the drive stopped, pre-heating is disabled by the safe torque off function, a drive fault state, or the process PID sleep function. Pre-heating can only start after one minute has elapsed from stopping the drive.


A digital source to control pre-heating is selected by parameter 21.14 Pre-heating input source. The heating current is set by 21.16 Pre-heating current.

#### **Pre-magnetization**

Pre-magnetization refers to DC magnetization of the motor before start. Depending on the selected start mode (21.01 Start mode or 21.09 Scalar start mode), premagnetization can be applied to guarantee the highest possible breakaway torque, up to 200% of the nominal torque of the motor. By adjusting the pre-magnetization time (21.02 Magnetization time), it is possible to synchronize the motor start and, for example, the release of a mechanical brake.

#### DC hold

The function makes it possible to lock the rotor at (near) zero speed in the middle of normal operation. DC hold is activated by parameter 21.08 DC current control. When both the reference and motor speed drop below a certain level (parameter 21.09 DC hold speed), the drive will stop generating sinusoidal current and start to inject DC into the motor. The current is set by parameter 21.10 DC current reference. When the reference exceeds parameter 21.09 DC hold speed, normal drive operation continues.



#### Note:

- DC hold is only available in speed control in DTC motor control mode (see page 43).
- The function applies the DC current to one phase only, depending on the position of the rotor. The return current is shared between the other phases.

## Post-magnetization

This feature keeps the motor magnetized for a certain period (parameter 21.11 Post magnetization time) after stopping. This is to prevent the machinery from moving under load, for example before a mechanical brake can be applied. Post-magnetization is activated by parameter 21.08 DC current control. The magnetization current is set by parameter 21.10 DC current reference.

**Note:** Post-magnetization is only available when ramping is the selected stop mode (see parameter *21.03 Stop mode*).

#### **Continuous magnetization**

The Continuous magnetization feature is active by selecting a digital signal such as a user bit in the fieldbus control word. This can be useful in processes that require motors to be stopped (for example, to stand by until new material is processed), then quickly started without magnetizing them first.

### Note:

Continuous magnetization is only available in speed control in DTC motor control
mode (see page 43). If parameter 21.12 Continuous magnetization command is
on, the motor will be kept magnetized after a ramp stop. To enable continuous
magnetization after a coast stop, the command (21.12) must be cycled (on, off,

- on). Furthermore, if the Run enable signal has been off, a new rising edge is required before continuous magnetization starts.
- Continuous magnetization should not be enabled while the motor is rotating.



**WARNING:** The motor must be designed to absorb or dissipate the thermal energy generated by continuous magnetization, for example by forced ventilation.

# **Settings**

Parameters 06.21 Drive status word 3 (page 179), 21.01 Start mode, 21.02 Magnetization time, 21.08...21.12, 21.14 Pre-heating input source and 21.16 Preheating current (page 258).

## Hexagonal motor flux pattern

**Note:** This feature is only available in scalar motor control mode (see page 43).

Typically, the drive controls the motor flux so that the rotating flux vector follows a circular pattern. This is ideal for most applications. However, when operating above the field weakening point (FWP), it is not possible to reach 100% of the output voltage. This reduces the peak load capacity of the drive.

Using a hexagonal motor flux vector pattern, the maximum output voltage can be reached above the field weakening point. This increases the peak load capacity compared to the circular pattern, but the continuous load capacity in the range of FWP ... 1.6 × FWP is reduced because of increasing losses. With hexagonal motor flux active, the pattern changes from circular to hexagonal gradually as the frequency rises from 100% to 120% of the FWP.

### **Settings**

Parameters 97.18 Hexagonal field weakening and 97.19 Hexagonal field weakening *point* (page 522).

# **Application control**

## **Application macros**

Application macros are predefined application parameter edits and I/O configurations. See chapter *Application macros* (page 139).


#### **Process PID control**

There is a built-in process PID controller in the drive. The controller can be used to control process variables such as pressure, flow or fluid level.

In process PID control, a process reference (setpoint) is connected to the drive instead of a speed reference. An actual value (process feedback) is also brought back to the drive. The process PID control adjusts the drive speed in order to keep the measured process quantity (actual value) at the desired level (setpoint).

Process PID control operates on a 2 ms time level.

The simplified block diagram below illustrates the process PID control. For a more detailed block diagram, see page 694.



The control program contains two complete sets of process PID controller settings that can be alternated whenever necessary; see parameter 40.57 PID set1/set2 selection

Note: Process PID control is only available in external control; see section Local control vs. external control (page 40).

#### Quick configuration of the process PID controller


- 1. Activate the process PID controller (parameter 40.07 Set 1 PID operation mode).
- 2. Select a feedback source (parameters 40.08...40.11).
- 3. Select a setpoint source (parameters 40.16...40.25).
- 4. Set the gain, integration time, derivation time, and the PID output levels (40.32) Set 1 gain, 40.33 Set 1 integration time, 40.34 Set 1 derivation time, 40.36 Set 1 output min and 40.37 Set 1 output max).
- 5. The PID controller output is shown by parameter 40.01 Process PID output actual. Select it as the source of, for example, 22.11 Speed ref1 source.

#### Sleep function for process PID control

The sleep function can be used in PID control applications that involve relatively long periods of low demand (for example, a tank is at level), During such periods, the sleep function saves energy by stopping the motor completely, instead of running the motor slowly below the efficient operating range of the system. When the feedback changes, the PID controller wakes the drive up.

**Note**: The sleep function is disabled when mechanical brake control (see page 112) is active.

**Example:** The drive controls a pressure boost pump. The water consumption falls at night. As a consequence, the process PID controller decreases the motor speed. However, due to natural losses in the pipes and the low efficiency of the centrifugal pump at low speeds, the motor would never stop rotating. The sleep function detects the slow rotation and stops unnecessary pumping after the sleep delay has passed. The drive shifts into sleep mode, still monitoring the pressure. The pumping resumes when the pressure falls under the wake-up level (setpoint - wake-up deviation) and the wake-up delay has passed.



#### **Tracking**

In tracking mode, the PID block output is set directly to the value of parameter 40.50 (or 41.50) Set 1 tracking ref selection. The internal I term of the PID controller is set so that no transient is allowed to pass on to the output, so when the tracking mode is left, normal process control operation can be resumed without a significant bump.

#### **Settings**

- Parameter 96.04 Macro select (macro selection)
- Parameter groups 40 Process PID set 1 (page 355) and 41 Process PID set 2 (page 368).

# Motor potentiometer


The motor potentiometer is, in effect, a counter whose value can be adjusted up and down using two digital signals selected by parameters 22.73 Motor potentiometer up source and 22.74 Motor potentiometer down source. Note that these signals have no effect when the drive in stopped.

When enabled by 22.71 Motor potentiometer function, the motor potentiometer assumes the value set by 22.72 Motor potentiometer initial value. Depending on the mode selected in 22.71, the motor potentiometer value is either retained or reset over a power cycle.

The change rate is defined in 22.75 Motor potentiometer ramp time as the time it would take for the value to change from the minimum (22.76 Motor potentiometer min value) to the maximum (22.77 Motor potentiometer max value) or vice versa. If the up and down signals are simultaneously on, the motor potentiometer value does not change.

The output of the function is shown by 22.80 Motor potentiometer ref act, which can directly be set as the source of any selector parameter such as 22.11 Speed ref1 source.

The following example shows the behavior of the motor potentiometer value.



#### **Settings**

Parameters 22.71...22.80 (page 265).

#### Mechanical brake control

A mechanical brake can be used for holding the motor and driven machinery at zero speed when the drive is stopped, or not powered. The brake control logic observes the settings of parameter group 44 Mechanical brake control as well as several external signals, and moves between the states presented in the diagram on page 113. The tables below the state diagram detail the states and transitions. The timing diagram on page 115 shows an example of a close-open-close sequence.

The mechanical brake control logic operates on a 10 ms time level.

# Inputs of the brake control logic

The start command of the drive (bit 5 of 06.16 Drive status word 1) is the main control source of the brake control logic. An optional external open/close signal can be selected by 44.12 Brake close request. The two signals interact as follows:

- Start command = 1 AND signal selected by 44.12 Brake close request = 0
   → Request brake to open
- Start command = 0 **OR** signal selected by 44.12 Brake close request = 1
   → Request brake to close

Another external signal – for example, from a higher-level control system – can be connected via parameter *44.11 Keep brake closed* to prevent the brake from opening.

Other signals that affect the state of the control logic are

- brake status acknowledgment (optional, defined by 44.07 Brake acknowledge selection),
- bit 2 of *06.11 Main status word* (indicates whether the drive is ready to follow the given reference or not),
- bit 6 of 06.16 Drive status word 1 (indicates whether the drive is modulating or not),
- optional FSO-xx safety functions module.

#### Outputs of the brake control logic


The mechanical brake is to be controlled by bit 0 of parameter *44.01 Brake control status*. This bit should be selected as the source of a relay output (or a digital input/output in output mode) which is then wired to the brake actuator through a relay. See the wiring example on page *116*.

The brake control logic, in various states, will request the drive control logic to hold the motor, increase the torque, or ramp down the speed. These requests are visible in parameter *44.01 Brake control status*.

#### **Settings**

Parameter group 44 Mechanical brake control (page 372).

# **Brake state diagram**



# State descriptions

State name	Description
BRAKE DISABLED	Brake control is disabled (parameter 44.06 Brake control enable = 0, and 44.01 Brake control status b4 = 0). The brake is closed (44.01 Brake control status b0 = 1).
BRAKE OPENING:	
BRAKE OPENING WAIT	Brake has been requested to open. The drive logic is requested to increase the torque up to opening torque to hold the load in place (44.01 Brake control status b1 = 1 and b2 = 1). The state of 44.11 Keep brake closed is checked; if it is not 0 within a reasonable time, the drive trips on a 71A5 Mechanical brake opening not allowed fault*.
BRAKE OPENING DELAY	Opening conditions have been met and open signal activated (44.01 Brake control status b0 is set). The opening torque request is removed (44.01 Brake control status b1 → 0). The load is held in place by the speed control of the drive until 44.08 Brake open delay elapses.  At this point, if 44.07 Brake acknowledge selection is set to No acknowledge, the logic proceeds to BRAKE OPEN state. If an acknowledgment signal source has been selected, its state is checked; if the state is not "brake open", the drive trips on a 71A3 Mechanical brake opening failed fault*.
BRAKE OPEN	The brake is open ( $44.01$ Brake control status b0 = 1). Hold request is removed ( $44.01$ Brake control status b2 = 0), and the drive is allowed to follow the reference.


State name	Description			
BRAKE CLOSING:				
BRAKE CLOSING WAIT	Brake has been requested to close. The drive logic is requested to ramp down the speed to a stop (44.01 Brake control status b3 = 1). The open signal is kept active (44.01 Brake control status b0 = 1). The brake logic will remain in this state until the motor speed has remained below 44.14 Brake close level for the time defined by 44.15 Brake close level delay.			
BRAKE CLOSING DELAY	Closing conditions have been met. The open signal is deactivated (44.01 Brake control status b0 → 0) and the closing torque written into 44.02 Brake torque memory. The ramp-down request is maintained (44.01 Brake control status b3 = 1). The brake logic will remain in this state until 44.13 Brake close delay has elapsed.  At this point, if 44.07 Brake acknowledge selection is set to No acknowledge, the logic proceeds to BRAKE CLOSED state. If an acknowledgment signal source has been selected, its state is checked; if the state is not "brake closed", the drive generates an A7A1 Mechanical brake closing failed warning. If 44.17 Brake fault function = Fault, the drive will trip on a 71A2 Mechanical brake closing failed fault after 44.18 Brake fault delay.			
BRAKE CLOSED	The brake is closed (44.01 Brake control status b0 = 0). The drive is not necessarily modulating.			
	<b>Note concerning open-loop (encoder-less) applications:</b> If the brake is kept closed by a brake close request (either from parameter <i>44.12</i> or an FSO-xx safety functions module) against a modulating drive for longer than 5 seconds, the brake is forced to closed state and the drive trips on a fault, <i>71A5 Mechanical brake opening not allowed.</i>			
*A warning can alternatively be selected by 44.17 Brake fault function; if so, the drive will keep modulating and remain in this state.				

# State change conditions ( (n))

- 1 Brake control disabled (parameter 44.06 Brake control enable  $\rightarrow$  0).
- 2 *06.11 Main status word*, bit 2 = 0 or brake is forced to close by optional FSO-xx safety functions module.
- 3 Brake has been requested to open and 44.16 Brake reopen delay has expired.
- 4 Brake open conditions (such as 44.10 Brake open torque) fulfilled and 44.11 Keep brake closed = 0.
- 5 44.08 Brake open delay has elapsed and brake open acknowledgement (if chosen by 44.07 Brake acknowledge selection) has been received.
- 6 Brake has been requested to close.
- 7 Motor speed has remained below closing speed 44.14 Brake close level for the duration of 44.15 Brake close level delay.
- 8 44.13 Brake close delay has elapsed and brake close acknowledgment (if chosen by 44.07 Brake acknowledge selection) has been received.
- 9 Brake has been requested to open.
- 10 Brake control enabled (parameter 44.06 Brake control enable → 1).

#### **Timing diagram**

The simplified timing diagram below illustrates the operation of the brake control function. Refer to the state diagram above.



 $T_{\rm s}$ Start torque at brake open (parameter 44.03 Brake open torque reference) Stored torque value at brake close (44.02 Brake torque memory)  $T_{\text{mem}}$ Motor magnetization delay  $t_{\sf md}$ Brake open delay (parameter 44.08 Brake open delay)  $t_{od}$ Brake close speed (parameter 44.14 Brake close level)  $n_{cs}$ Brake close command delay (parameter 44.15 Brake close level delay)  $t_{\rm ccd}$ Brake close delay (parameter 44.13 Brake close delay)  $t_{cd}$ Brake close fault delay (parameter 44.18 Brake fault delay)  $t_{\rm cfd}$ Brake reopen delay (parameter 44.16 Brake reopen delay)  $t_{\rm rod}$ BOW BRAKE OPENING WAIT BOD **BRAKE OPENING DELAY BCW** BRAKE CLOSING WAIT BCD BRAKE CLOSING DELAY


# Wiring example

The figure below shows a brake control wiring example. The brake control hardware and wiring is to be sourced and installed by the customer.

WARNING! Make sure that the machinery into which the drive with brake control function is integrated fulfills the personnel safety regulations. Note that the frequency converter (a Complete Drive Module or a Basic Drive Module, as defined in IEC 61800-2), is not considered as a safety device mentioned in the European Machinery Directive and related harmonized standards. Thus, the personnel safety of the complete machinery must not be based on a specific frequency converter feature (such as the brake control function), but it has to be implemented as defined in the application specific regulations.

The brake is controlled by bit 0 of parameter 44.01 Brake control status. The source of brake acknowledge (status supervision) is selected by parameter 44.07 Brake acknowledge selection. In this example,

- parameter 10.24 RO1 source is set to Open brake command (i.e. bit 0 of 44.01 Brake control status), and
- parameter 44.07 Brake acknowledge selection is set to DI5.



# DC voltage control


# Overvoltage control

Overvoltage control of the intermediate DC link is typically needed when the motor is in generating mode. The motor can generate when it decelerates or when the load overhauls the motor shaft, causing the shaft to turn faster than the applied speed or frequency. To prevent the DC voltage from exceeding the overvoltage control limit, the overvoltage controller automatically decreases the generating torque when the limit is reached. The overvoltage controller also increases any programmed deceleration times if the limit is reached; to achieve shorter deceleration times, a brake chopper and resistor may be required.

# **Undervoltage control (power loss ride-through)**

If the incoming supply voltage is cut off, the drive will continue to operate by utilizing the kinetic energy of the rotating motor. The drive will be fully operational as long as the motor rotates and generates energy to the drive. The drive can continue operation after the break if the main contactor (if present) remained closed.

**Note:** Units equipped with a main contactor must be equipped with a hold circuit (e.g. UPS) to keep the contactor control circuit closed during a short supply break.



 $U_{\mathrm{DC}}$ = intermediate circuit voltage of the drive,  $f_{\mathrm{out}}$  = output frequency of the drive,  $T_{\mathrm{M}}$  = motor torque Loss of supply voltage at nominal load ( $f_{out}$  = 40 Hz). The intermediate circuit DC voltage drops to the minimum limit. The controller keeps the voltage steady as long as the mains is switched off. The drive runs the motor in generator mode. The motor speed falls but the drive is operational as long as the motor has enough kinetic energy.

#### **Automatic restart**

It is possible to restart the drive automatically after a short (max. 5 seconds) power supply failure by using the Automatic restart function provided that the drive is allowed to run for 5 seconds without the cooling fans operating.

When enabled, the function takes the following actions upon a supply failure to enable a successful restart:

- The undervoltage fault is suppressed (but a warning is generated)
- Modulation and cooling is stopped to conserve any remaining energy
- DC circuit pre-charging is enabled.

If the DC voltage is restored before the expiration of the period defined by parameter 21.18 Auto restart time and the start signal is still on, normal operation will continue. However, if the DC voltage remains too low at that point, the drive trips on a fault, 3280 Standby timeout.

**WARNING!** Before you activate the function, make sure that no dangerous situations can occur. The function restarts the drive automatically and continues operation after a supply break.

# Voltage control and trip limits

The control and trip limits of the intermediate DC voltage regulator are relative to the supply voltage as well as drive/inverter type. The DC voltage is approximately 1.35 times the line-to-line supply voltage, and is displayed by parameter 01.11 DC voltage.

The following diagram shows the values of selected DC voltage levels in volts. All voltages are relative to the supply voltage range selected in parameter 95.01 Supply voltage.

	Supply voltage range [V] (see 95.01 Supply voltage)				ge)	
Level	208240	380415	440480	500	525600	660690
Overvoltage fault limit	489/440*	800	878	880	1113	1218
Overvoltage control limit	389	700	778	810	1013	1118
Internal brake chopper at 100% pulse width	403	697	806	806	1008	1159
Internal brake chopper at 0% pulse width	375	648	749	780	936	1077
Overvoltage warning limit	373	644	745	776	932	1071
DC voltage at upper bound of supply voltage range ( $U_{\rm DCmax}$ )	324	560	648	675	810	932
DC voltage at lower bound of supply voltage range	281	513	594	675	709	891
Undervoltage control and warning limit	239	436	505	574	602	757
Charging activation/standby limit	225	410	475	540	567	713
Undervoltage fault limit	168	308	356	405	425	535

<sup>\*489</sup> V with frames R1...R3, 440 V with frames R4...R8.

# **Settings**

Parameters 01.11 DC voltage (page 160), 30.30 Overvoltage control (page 313), 30.31 Undervoltage control (page 313), 95.01 Supply voltage (page 501) and 95.02 Adaptive voltage limits (page 501).

# Brake chopper

A brake chopper can be used to handle the energy generated by a decelerating motor. When the DC voltage rises high enough, the chopper connects the DC circuit to an external brake resistor. The chopper operates on the pulse width modulation principle.

Some ACS880 drives have an internal brake chopper as standard, some have a brake chopper available as an internal or external option. See the appropriate hardware manual or sales catalog.

The internal brake choppers of ACS880 drives start conducting when the DC link voltage reaches approximately  $1.15 \times U_{\rm DCmax}$ . 100% pulse width is reached at approximately  $1.2 \times U_{\rm DCmax}$ . ( $U_{\rm DCmax}$  is the DC voltage corresponding to the maximum of the AC supply voltage range.) For information on external brake choppers, refer to their documentation.

**Note:** For runtime braking, you must disable overvoltage control (parameter *30.30 Overvoltage control*) to operate the chopper.

#### **Settings**

Parameter 01.11 DC voltage (page 160) and 30.30 Overvoltage control (page 313); parameter group 43 Brake chopper (page 370).

# Safety and protections

# Emergency stop

The emergency stop signal is connected to the input selected by parameter 21.05 Emergency stop source. An emergency stop can also be generated through fieldbus (parameter 06.01 Main control word, bits 0...2).

The mode of the emergency stop is selected by parameter 21.04 Emergency stop *mode*. The following modes are available:

- Off1: Stop along the standard deceleration ramp defined for the particular reference type in use
- Off2: Stop by coasting
- Off3: Stop by the emergency stop ramp defined by parameter 23.23 Emergency stop time.

With Off1 or Off3 emergency stop modes, the ramp-down of the motor speed can be supervised by parameters 31.32 Emergency ramp supervision and 31.33 Emergency ramp supervision delay.

#### Notes:

- For SIL 3 / PL e-level emergency stop functions, the drive can be fitted with a TÜV-certified FSO-xx safety options module. The module can then be incorporated into certified safety systems.
- The installer of the equipment is responsible for installing the emergency stop devices and all additional devices needed for the emergency stop function to fulfill the required emergency stop categories. For more information, contact your local ABB representative.
- After an emergency stop signal is detected, the emergency stop function cannot be canceled even though the signal is canceled.
- If the minimum (or maximum) torque limit is set to 0%, the emergency stop function may not be able to stop the drive.
- Speed and torque reference additives (parameters 22.15, 22.17, 26.16, 26.25 and 26.41) and reference ramp shapes (23.16...23.19) are ignored in case of emergency ramp stops.

#### **Settings**

Parameters 06.17 Drive status word 2 (page 176), 06.18 Start inhibit status word (page 177), 21.04 Emergency stop mode (page 254), 21.05 Emergency stop source (page 254), 23.23 Emergency stop time (page 271), 25.13 Min torg sp ctrl em stop (page 285), 25.14 Max torg sp ctrl em stop (page 285), 25.15 Proportional gain em stop (page 285), 31.32 Emergency ramp supervision (page 323) and 31.33 Emergency ramp supervision delay (page 324).

# Motor thermal protection

The control program features two separate motor temperature monitoring functions. The temperature data sources and warning/trip limits can be set up independently for each function.

The motor temperature can be monitored using

- the motor thermal protection model (estimated temperature derived internally inside the drive), or
- sensors installed in the windings. This will result in a more accurate motor model.

In addition to temperature monitoring, a protection function is available for 'Ex' motors installed in a potentially explosive atmosphere.

#### Motor thermal protection model

The drive calculates the temperature of the motor on the basis of the following assumptions:


- When power is applied to the drive for the first time, the motor is assumed to be at ambient temperature (defined by parameter 35.50 Motor ambient temperature).
   After this, when power is applied to the drive, the motor is assumed to be at the estimated temperature.
- Motor temperature is calculated using the user-adjustable motor thermal time and motor load curve. The load curve should be adjusted in case the ambient temperature exceeds 30 °C.

The motor thermal protection model fulfills standard IEC/EN 61800-5-1 ed. 2.1 requirements for thermal memory retention and speed sensitivity. The estimated temperature is retained over power down. Speed dependency is set by parameters 35.51 Motor load curve, 35.52 Zero speed load and 35.53 Break point.

**Note:** The motor thermal model can be used when only one motor is connected to the drive.

#### Temperature monitoring using PTC sensors

One PTC sensor can be connected to digital input DI6.




The resistance of the PTC sensor increases when its temperature rises. The increasing resistance of the sensor decreases the voltage at the input, and eventually its state switches from 1 to 0, indicating overtemperature.

1...3 PTC sensors can also be connected in series to an analog input and an analog output. The analog output feeds a constant excitation current of 1.6 mA through the sensor. The sensor resistance increases as the motor temperature rises, as does the voltage over the sensor. The temperature measurement function calculates the resistance of the sensor and generates an indication if overtemperature is detected.

For wiring of the sensor, refer to the *Hardware Manual* of the drive.

The figure below shows typical PTC sensor resistance values as a function of temperature.



In addition to the above, optional FEN-XX encoder interfaces, and FPTC-xx modules have connections for PTC sensors. For more information, refer the module-specific documentation.

#### Temperature monitoring using Pt100 or Pt1000 sensors

1...3 Pt100 or Pt1000 sensors can be connected in series to an analog input and an analog output.

The analog output feeds a constant excitation current of 9.1 mA (Pt100) or 1 mA (Pt1000) through the sensor. The sensor resistance increases as the motor temperature rises, as does the voltage over the sensor. The temperature measurement function reads the voltage through the analog input and converts it into degrees Celsius.

The warning and fault limits can be adjusted by parameters.

For the wiring of the sensor, refer to the *Hardware Manual* of the drive.


#### Temperature monitoring using KTY84 sensors


One KTY84 sensor can be connected to an analog input and an analog output on the control unit.

The analog output feeds a constant excitation current of 2.0 mA through the sensor. The sensor resistance increases as the motor temperature rises, as does the voltage over the sensor. The temperature measurement function reads the voltage through the analog input and converts it into degrees Celsius.

FEN-xx encoder interfaces (optional) also have a connection for one KTY84 sensor.

The figure and table below show typical KTY84 sensor resistance values as a function of the motor operating temperature.





The warning and fault limits can be adjusted by parameters.

For the wiring of the sensor, refer to the *Hardware Manual* of the drive.

#### Motor fan control logic (parameters 35.100...35.106)

If the motor has an external cooling fan, it is possible to use a drive signal (for example, running/stopped) to control the starter of the fan via a relay or digital output. A digital input can be selected for fan feedback. A loss of the feedback signal will optionally cause a warning or a fault.

Start and stop delays can be defined for the fan. In addition, a feedback delay can be set to define the time within which feedback must be received after the fan starts.

#### Ex motor support (parameter 95.15, bit 0)

The control program has a temperature protection function for Ex motors located in a potentially explosive atmosphere. The protection is enabled by setting bit 0 of parameter *95.15 Special HW settings*.

#### **Settings**

Parameter group 35 Motor thermal protection (page 337) and 91 Encoder module settings (page 487); parameter 95.15 Special HW settings (page 503).

# Motor overload protection

This section describes motor overload protection without using motor thermal protection model, either with estimated or measured temperature. For protection with the motor thermal protection model, see section *Motor thermal protection* (page 122).

Motor overload protection is required and specified by multiple standards including the US National Electric Code (NEC), UL 508C and the common UL\IEC 61800-5-1 standard in conjunction with IEC 60947-4-1. The standards allow for motor overload protection without external temperature sensors.

The Motor overload protection fulfills standard IEC/EN 61800-5-1 ed. 2.1 requirements for thermal memory retention and speed sensitivity. The estimated temperature is retained over power down. Speed dependency is set by parameters.

The protection feature allows the user to specify the class of operation in the same manner as the overload relays are specified in standards IEC 60947-4-1 and NEMA ICS 2.

Motor overload protection requires that you specify a motor current tripping level. This is defined by a curve using parameters 35.51, 35.52 and 35.53. The tripping level is the motor current at which the overload protection will ultimately trip if the motor current remains at this level continuously.

The motor overload class (class of operation), parameter 35.57 Motor overload class, is given as the time required for the overload relay to trip when operating at 7.2 times the tripping level in the case of IEC 60947-4-1 and 6 times the tripping level in the case of NEMA ICS 2. The standards also specify the time to trip for current levels between the tripping level and the 6 times tripping level. The drive satisfies the IEC standard and NEMA standard trip times.

Using class 20 satisfies the UL 508C requirements.

The motor overload algorithm monitors the squared ratio (motor current / tripping level)2 and accumulates this over time. This is sometimes referred to as I2t protection. The accumulated value is shown in parameter 35.05.

You can define with parameter 35.56 that when 35.05 reaches 88%, a motor overload warning will be generated, and when it reaches 100%, the drive will trip on the motor overload fault. The rate at which this internal value is increased depends on the actual current, tripping level current and overload class selected.

Parameters 35.51, 35.52 and 35.53 serve a dual purpose. They determine the load curve for temperature estimate as well as specify the overload tripping level.

# **Settings and diagnostics**

Parameters common to motor thermal protection and motor overload protection: 35.51 Motor load curve ... 35.53 Break point (page 344).

Parameters specific to motor overload protection: 35.05 Motor overload level (page 338), 35.56 Motor overload action ... 35.57 Motor overload class (page 345).

# Thermal protection of motor cable

The control program contains a thermal protection function for the motor cable. This function should be used, for example, when the nominal current of the drive exceeds the current-carrying capacity of the motor cable.

The program calculates the temperature of the cable on the basis of the following data:

- Measured output current (parameter 01.07 Motor current)
- Nominal continuous current rating of the cable, specified by 35.61 Cable nominal current, and
- Thermal time constant of the cable, specified by 35.62 Cable thermal rise time.

When the calculated temperature of the cable reaches 102% of the rated maximum, a warning (A480 Motor cable overload) is given. The drive trips on a fault (4000 Motor cable overload) when 106% is reached.

#### **Settings**


Parameters 35.60...35.62 (page 346).

#### User load curve

The user load curve provides a function that monitors an input signal (e.g. motor torque or motor current) as a function of drive output speed or frequency. The function includes both high limit (overload) and low limit (underload) monitoring. Overload monitoring can, for example, be used to detect a pump becoming clogged or a saw blade hitting a knot. Underload monitoring can detect the load being lost, for example because of the snapping of a transmission belt.

The monitoring is effective within a motor speed and/or frequency range. The frequency range is used with a frequency reference in scalar motor control mode; otherwise, the speed range is used. The range is defined by five speed (parameters 37.11...37.15) or frequency (37.16...37.20) values. The values are positive, but the monitoring is symmetrically active in the negative direction as the sign of the monitored signal is ignored. Outside the speed/frequency range, the monitoring is disabled.

An underload (37.21...37.25) and overload (37.31...37.35) limit is set for each of the five speed or frequency points. Between these points, the limits are interpolated linearly to form overload and underload curves.



The action (none, warning or fault) taken when the signal exits the allowed operation area can be selected separately for overload and underload conditions (parameters 31.03 and 31.04 respectively). Each condition also has an optional timer to delay the selected action (37.41 and 31.42).

#### **Settings**

Parameter group 37 User load curve (page 352).

# Other programmable protection functions

# External events (parameters 31.01...31.10)

Five different event signals from the process can be connected to selectable inputs to generate trips and warnings for the driven equipment. When the signal is lost, an external event (fault, warning, or a mere log entry) is generated. The contents of the messages can be edited on the control panel by selecting Menu - Settings - Edit texts.

## Motor phase loss detection (parameter 31.19)

The parameter selects how the drive reacts whenever a motor phase loss is detected.

#### Earth (Ground) fault detection (parameter 31.20)

The earth fault detection function is based on sum current measurement. Note that

- an earth fault in the supply cable does not activate the protection
- in a grounded supply, the protection activates within 2 milliseconds
- in an ungrounded supply, the supply capacitance must be 1 micro farad or more
- the capacitive currents caused by shielded motor cables up to 300 meters will not activate the protection
- the protection is deactivated when the drive is stopped.

## Safe torque off detection (parameter 31.22)

The drive monitors the status of the Safe torque off input, and this parameter selects which indications are given when the signals are lost. (The parameter does not affect the operation of the Safe torque off function itself). For more information on the Safe torque off function, see the Hardware manual.

#### Swapped supply and motor cabling (parameter 31.23)

The drive can detect if the supply and motor cables have accidentally been swapped (for example, if the supply is connected to the motor connection of the drive). The parameter selects if a fault is generated or not. Note that the protection should be disabled in drive/inverter hardware supplied from a common DC bus.

#### Stall protection (parameters 31.24...31.28)

The drive protects the motor in a stall situation. It is possible to adjust the supervision limits (current, frequency and time) and choose how the drive reacts to a motor stall condition.

#### Overspeed protection (parameter 31.30)

The user can set overspeed limits by specifying a margin that is added to the currently-used maximum and minimum speed limits.

#### Ramp stop supervision (parameters 31.32, 31.33, 31.37 and 31.38)

The control program has a supervision function for both the normal and emergency stop ramps. The user can either define a maximum time for stopping, or a maximum deviation from the expected deceleration rate. If the drive fails to stop in the expected manner, a fault is generated and the drive coasts to a stop.

#### Custom motor current fault limit (parameter 31.42)

The control program sets a motor current limit based on drive hardware. In most cases, the default value is appropriate. However, a lower limit can be manually set by the user, for example, to protect a permanent magnet motor from demagnetization.

#### Local control loss detection (parameter 49.05)

The parameter selects how the drive reacts to a control panel or PC tool communication break.

#### **Automatic fault resets**

The drive can automatically reset itself after overcurrent, overvoltage, undervoltage and external faults. The user can also specify a fault (excluding Safe torque off related faults) to be reset automatically.

By default, automatic resets are off and must be specifically activated by the user.

WARNING! Before you activate the function, make sure that no dangerous situations can occur. The function restarts the drive automatically and continues operation after a supply break.

## **Settings**

Parameters 31.12...31.16 (page 318).

# **Diagnostics**

# Fault and warning messages, data logging

See chapter *Fault tracing* (page 593).

# Signal supervision

Three signals can be selected to be supervised by this function. Whenever a supervised signal exceeds or falls below predefined limits, a bit in 32.01 Supervision status is activated, and a warning or fault generated. The contents of the message can be edited on the control panel by selecting Menu - Settings - Edit texts.

The supervised signal is low-pass filtered. The supervision operates on a 2 ms time level. The configuration parameters are scanned for changes on a 10 ms time level.

## **Settings**

Parameter group 32 Supervision (page 326).

#### Maintenance timers and counters

The program has six different maintenance timers or counters that can be configured to generate a warning when a pre-defined limit is reached. The contents of the message can be edited on the control panel by selecting Menu - Settings - Edit texts.

The timer/counter can be set to monitor any parameter. This feature is especially useful as a service reminder.

There are three types of counters:

- On-time timers. Measures the time a binary source (for example, a bit in a status word) is on.
- Signal edge counters. The counter is incremented whenever the monitored binary source changes state.
- Value counters. The counter measures, by integration, the monitored parameter. A warning is given when the calculated area below the signal peak exceeds a user-defined limit.

#### Settings

Parameter group 33 Generic timer & counter (page 329).

# Energy saving calculators

This feature consists of the following functionalities:

- An energy optimizer that adjusts the motor flux in such a way that the total system efficiency is maximized
- A counter that monitors used and saved energy by the motor and displays them in kWh, currency or volume of CO<sub>2</sub> emissions, and
- A load analyzer showing the load profile of the drive (see separate section on page 131).

Note: The accuracy of the energy savings calculation is directly dependent on the accuracy of the reference motor power given in parameter 45.19 Comparison power.

# **Settings**

Parameter group 45 Energy efficiency (page 376).

# Load analyzer

## Peak value logger


The user can select a signal to be monitored by a peak value logger. The logger records the peak value of the signal along with the time the peak occurred, as well as motor current, DC voltage and motor speed at the time of the peak. The peak value is sampled at 2 ms intervals.

#### **Amplitude loggers**

The control program has two amplitude loggers. loggers. Depending on the setting of parameter 36.08 Reset loggers, the loggers are active continuously or only when the drive is modulating.

For amplitude logger 2, the user can select a signal to be sampled at 200 ms intervals, and specify a value that corresponds to 100%. The collected samples are sorted into 10 read-only parameters according to their amplitude. Each parameter represents an amplitude range 10 percentage points wide, and displays the percentage of the collected samples that have fallen within that range.

**Note:** The lowest range also contains negative values (if any), while the highest range also contains values above 100%.



Amplitude ranges (parameters 36.40...36.49)

Amplitude logger 1 is fixed to monitor motor current, and cannot be reset. With amplitude logger 1, 100% corresponds to the maximum output current of the drive  $(I_{\text{max}}, \text{ as given in the hardware manual})$ . The distribution of samples is shown by parameters 36.20...36.29.

#### **Settings**

Parameter group 36 Load analyzer (page 348).

# **Miscellaneous**

# User parameter sets

The drive supports four user parameter sets that can be saved to the permanent memory and recalled using drive parameters. It is also possible to use digital inputs to switch between user parameter sets.

A user parameter set contains all editable values in parameter groups 10...99 except

- forced I/O values such as parameters 10.03 DI force selection and 10.04 DI force data
- I/O extension module settings (groups 14...16)
- fieldbus communication enable parameters (50.01 FBA A enable and 50.31 FBA B enable)
- other fieldbus communication settings (groups 51...56 and 58)
- encoder configuration settings (groups 92...93)
- some hardware settings in parameter group 95 HW configuration, and
- user set selection parameters 96.11...96.13.

As the motor settings are included in the user parameter sets, make sure the settings correspond to the motor used in the application before recalling a user set. In an application where different motors are used with the drive, the motor ID run needs to be performed with each motor and the results saved to different user sets. The appropriate set can then be recalled when the motor is switched.

If no parameter sets have been saved, attempting to load a set will create all sets from the currently active parameter settings.

Switching between user parameter sets is only possible with the drive stopped.

#### Settings

Parameters 96.10...96.13 (page 510).

#### Parameter checksum calculation

A parameter checksum can be calculated from a user-definable set of parameters to monitor changes in the drive configuration. The calculated checksum is compared to 1...4 reference checksums; in case of a mismatch, an event (a pure event, warning or fault) is generated.

By default, the set of parameters included in the calculation contain most parameters with the exception of

- actual signals
- parameter group 47 Data storage
- parameters that are activated to validate new settings (such as 51.27 and 96.07)
- parameters that are not saved to the flash memory (such as 96.24...96.26)
- parameters that are internally calculated from others (such as 98.09...98.14).
- dynamic parameters (e.g. parameters that vary according to hardware), and
- application program parameters.

The default set can be edited using the Drive customizer PC tool.

#### Settings

Parameters 96.53...96.59 (page 514).

#### **User lock**

For better cybersecurity, ABB highly recommends that you set a master pass code to prevent, for example, the changing of parameter values and/or the loading of firmware and other files.



**WARNING!** ABB will not be liable for damages or losses caused by the failure to activate the user lock using a new pass code. See Cybersecurity disclaimer (page 18).

To activate the user lock for the first time,

- 1. Type the default pass code, 10000000, into 96.02 Pass code. This will make parameters 96.100...96.102 visible.
- 2. Type a new pass code into 96.100 Change user pass code. Always use eight digits; if using Drive composer, finish by pressing Enter.
- 3. Confirm the new pass code in 96.101 Confirm user pass code.



**WARNING!** Store the pass code in a safe place – the user lock cannot be opened even by ABB if the pass code is lost.

- 4. In 96.102 User lock functionality, define the actions that you want to prevent (we recommend you select all the actions unless otherwise required by the application).
- 5. Type an invalid (random) pass code into 96.02 Pass code.
- 6. Activate 96.08 Control board boot, or cycle the power to the control unit.
- 7. Check that parameters 96.100...96.102 are hidden. If they are not, type another random pass code into 96.02.

To reopen the lock, type your pass code into 96.02 Pass code. This will again make parameters 96.100...96.102 visible.

#### Settings

Parameters 96.02 (page 508) and 96.100...96.102 (page 517).

# Data storage parameters

Twenty-four (sixteen 32-bit, eight 16-bit) parameters are reserved for data storage. These parameters are unconnected by default and can be used, for example, linking, testing and commissioning purposes. They can be written to and read from using other parameters' source or target selections.

Note that only 32-bit floating point (type *real32*) parameters can be selected as the source of another parameter value. In other words, parameters 47.01...47.08can be used as value sources of other parameters while 47.11...47.28 cannot.

To use a 16-bit integer (received in DDCS data sets) as the source of another parameter, write the value into one of the *real32* type storage parameters (47.01...47.08). Select the storage parameter as the source, and define a suitable scaling method between the 16-bit and 32-bit values in parameters 47.31...47.38.

#### Settings

Parameter group 47 Data storage (page 383).

# du/dt filter support

With an external du/dt filter connected to the output of the drive, bit 13 of 95.20 HW options word 1 must be switched on. The setting limits the output switching frequency. With frame size R5i...R7i inverter modules, the setting also forces the drive/inverter module fan to full speed. Note that the setting is not to be activated with inverter modules with internal du/dt filters.

## Settings

Parameter 95.20 HW options word 1 (page 505).

# Sine filter support

The control program has a setting that enables the use of sine filters (available separately from ABB and others).

With an ABB sine filter connected to the output of the drive, bit 1 of 95.15 Special HW settings must be switched on. The setting limits the switching and output frequencies to

- prevent the drive from operating at filter resonance frequencies, and
- protect the filter from overheating.

With a custom sine filter, bit 3 of 95.15 Special HW settings must be switched on. (The setting does not limit the output frequency.) Additional parameters must be set according to the properties of the filter as listed below.

#### **Settings**

For both ABB and custom filters: Parameter 95.15 Special HW settings (page 503).

For custom filters: Parameters 97.01 Switching frequency reference, 97.02 Minimum switching frequency (page 519), 99.18 Sine filter inductance and 99.19 Sine filter capacitance (page 532).

#### Router mode for BCU control unit


The BCU control unit of an inverter unit can be set to a "router mode" to allow the control of locally-connected power units (for example, inverter modules) by another BCU. Using the router mode and some hardware switching, it is possible to have the same modules alternate between inverter and, for example, IGBT supply use.


The router mode involves connecting the two BCUs together by their PSL2 channels. When router mode is active, the channels coming from the other BCU are forwarded to the local modules.

The diagrams below show how the control of four converter modules can be switched between two BCUs.

**Note**: For an example of how to switch converter modules between inverter and IGBT supply use, see the ACS880 IGBT supply control program firmware manual (3AUA0000131562 [English]).

BCU 1 controlling all modules, BCU 2 in router mode





#### BCU 2 controlling all modules, BCU 1 in router mode

#### Notes:

- The local modules must be connected to successive channels starting from CH1. The immediately following channels are connected to the other BCU and routed to the local modules. There must be at least as many local modules as there are routed channels.
- In PLC control, any switch-overs must be done in stopped state, and so that at least one BCU is in router mode at any given time.
- Additional rules or restrictions may apply when using the router mode with other control programs. See the appropriate firmware manual.

## **Settings**

Parameters 95.16 Router mode and 95.17 Router channel config (page 504).



# Application macros

# What this chapter contains

This chapter describes the intended use, operation and default control connections of the application macros.

More information on the connectivity of the control unit is given in the *Hardware* manual of the drive.

# General

Application macros are sets of default parameter values suitable for the application in question. When starting up the drive, the user typically selects the best-suited application macro as a starting point, then makes any necessary changes to tailor the settings to the application. This usually results in a much lower number of user edits compared to the traditional way of programming a drive.

Application macros can be selected by parameter 96.04 Macro select. User parameter sets are managed by the parameters in group 96 System.

# **Factory macro**

The Factory macro is suited to relatively straightforward speed control applications such as conveyors, pumps and fans, and test benches.

The drive is speed-controlled with the reference signal connected to analog input AI1. The start/stop commands are given through digital input DI1; running direction is determined by DI2. This macro uses control location EXT1.

Faults are reset through digital input DI3.


DI4 switches between acceleration/deceleration time sets 1 and 2. The acceleration and deceleration times, as well as ramp shapes, are defined by parameters 23.12...23.19.

DI5 activates constant speed 1.

# Default parameter settings for the Factory macro

The default parameter settings for the Factory macro are listed under *Parameter listing* (page *160*).

# **Default control connections for the Factory macro**



# Hand/Auto macro

The Hand/Auto macro is suited to speed control applications where two external control devices are used.

The drive is speed-controlled from the external control locations EXT1 (Hand control) and EXT2 (Auto control). The selection between the control locations is done through digital input DI3.

The start/stop signal for EXT1 is connected to DI1 while running direction is determined by DI2. For EXT2, start/stop commands are given through DI6, the direction through DI5.

The reference signals for EXT1 and EXT2 are connected to analog inputs Al1 and Al2 respectively.


A constant speed (by default, 300 rpm) can be activated through DI4.

# Default parameter settings for the Hand/Auto macro

Below is a listing of default parameter values that differ from those listed for the Factory macro in *Parameter listing* (page 160).

Parameter		Hand/Auto magra default			
No.	Name	Hand/Auto macro default			
12.30	AI2 scaled at AI2 max	1500.000			
19.11	Ext1/Ext2 selection	DI3			
20.06	Ext2 commands	In1 Start; In2 Dir			
20.08	Ext2 in1 source	DI6			
20.09	Ext2 in2 source	DI5			
20.12	Run enable 1 source	DIIL			
22.12	Speed ref2 source	Al2 scaled			
22.14	Speed ref1/2 selection	Follow Ext1/Ext2 selection			
22.22	Constant speed sel1	DI4			
23.11	Ramp set selection	Acc/Dec time 1			
31.11	Fault reset selection	Not selected			

#### Default control connections for the Hand/Auto macro



# PID control macro

The PID control macro is suitable for process control applications, for example closed-loop pressure, level or flow control systems such as

- pressure boost pumps of municipal water supply systems
- · level-controlling pumps of water reservoirs
- · pressure boost pumps of district heating systems
- material flow control on a conveyor line.

The process reference signal is connected to analog input Al1 and the process feedback signal to Al2. Alternatively, a direct speed reference can be given to the drive through Al1. Then the PID controller is bypassed and the drive no longer controls the process variable.

Selection between direct speed control (control location EXT1) and process variable control (EXT2) is done through digital input DI3.

The stop/start signals for EXT1 and EXT2 are connected to DI1 and DI6 respectively.

A constant speed (by default, 300 rpm) can be activated through DI4.

**Note:** When commissioning the PID loop, it is useful to run the motor in speed control first using EXT1; this allows testing of the PID feedback polarity and scaling. Once the feedback has been proven, the PID loop can be "closed" by switching to EXT2.

#### Default parameter settings for the PID control macro

Below is a listing of default parameter values that differ from those listed for the Factory macro in *Parameter listing* (page 160).

Param	eter	PID control macro default	
No.	Name	FID CONTION MACIO GENAUIT	
12.27	AI2 min	4.000	
19.11	Ext1/Ext2 selection	DI3	
20.01	Ext1 commands	In1 Start	
20.04	Ext1 in2 source	Not selected	
20.06	Ext2 commands	In1 Start	
20.08	Ext2 in1 source	DI6	
20.12	Run enable 1 source	DI5	
22.12	Speed ref2 source	PID	
22.22	Constant speed sel1	DI4	
23.11	Ramp set selection	Acc/Dec time 1	
31.11	Fault reset selection	Not selected	
40.07	Set 1 PID operation mode	On when drive running	
40.08	Set 1 feedback 1 source	Al2 scaled	
40.11	Set 1 feedback filter time	0.040 s	
40.35	Set 1 derivation filter time	1.0 s	
40.60	Set 1 PID activation source	Follow Ext1/Ext2 selection	


Note: The macro selection does not affect parameter group 41 Process PID set 2.

#### Default control connections for the PID control macro


		XPOW External power input			
		1	+24VI 24 V DC, 2 A		
		2	GND	124 V DC, 2 A	
	<u></u>	XAI	Reference	voltage and analog inputs	
	/	1	+VREF	10 V DC, R <sub>I</sub> 110 kohm	
ᄕ	<u> </u>	2	-VREF	-10 V DC, R <sub>L</sub> 110 kohm	
	<b>▲</b>   *	3	AGND	Ground	
	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	4	Al1+	Speed reference	
		5	Al1-	0(2)10 V, R <sub>in</sub> > 200 kohm	
F	7 -	6	Al2+	Process feedback*	
'	/ı	7	Al2-	0(4)20 mA, R <sub>in</sub> > 100 ohm	
		XAO	Analog out		
(	\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	1	AO1	Motor speed rpm	
(	<u> </u>	2	AGND	020 mA, R <sub>I</sub> < 500 ohm	
	~ <u> </u>	3	AO2	Motor current	
	<i>)</i> / ¦   ¦	4	AGND	020 mA, R <sub>I</sub> < 500 ohm	
	_ ,	XD2D	Drive-to-dr		
	<del>=</del>	1	B		
		2	A	Drive-to-drive link	
		3	BGND	Brive-to-drive link	
				3 Relay outputs	
		1	NC	Ready run	
		2	COM	250 V AC / 30 V DC	
	<u> </u>	3	NO	230 V AC / 30 V BC	
		1	NC		
		2	COM	Running 250 V AC / 30 V DC	
	<b>/</b>			250 V AC / 30 V DC	
	Fault Fault	3	NO		
	N	1	NC	Fault (-1)	
		2	COM	250 V AC / 30 V DC	
		3	NO Distribution		
		XD24	Digital inte		
		1	DIIL	Digital interlock. By default, not in use.	
		2	+24VD	+24 V DC 200 mA	
		3	DICOM	Digital input ground	
		4	+24VD	+24 V DC 200 mA	
-		5	DIOGND	Digital input/output ground	
		XDIO	Digital inpu		
		1	DIO1	Output: Ready run	
		2	DIO2	Output: Running	
		XDI	Digital inpu		
		1	DI1	Stop (0) / Start (1) – Speed control	
		2	DI2	By default, not in use.	
		3	DI3	Speed control (0) / Process control (1)	
		4	DI4	Constant speed 1 (1 = On)	
		5	DI5	Run enable (1 = On)	
ļ		6	DI6	Stop (0) / Start (1) – Process control	
		XSTO		e off circuits must be closed for the drive to start. See <i>manual</i> of drive.	
		X12		ions connection	
		X12 X13		nel connection	
	X205 Memory unit connection				

<sup>\*</sup>For sensor connection examples, see page 147.

#### Sensor connection examples for the PID control macro



Note: The sensor must be powered externally.



Al2-

-20...20 mA.  $R_{in}$  = 100 ohm

#### **Torque control macro**

This macro is used in applications in which torque control of the motor is required. These are typically tension applications, where a particular tension needs to be maintained in the mechanical system.

Torque reference is given through analog input AI2, typically as a current signal in the range of 0...20 mA (corresponding to 0...100% of rated motor torque).

The start/stop signal is connected to digital input DI1. The direction is determined by DI2. Through digital input DI3, it is possible to select speed control (EXT1) instead of torque control (EXT2). As with the PID control macro, speed control can be used for commissioning the system and checking the motor direction.

It is also possible to change the control to local (control panel or PC tool) by pressing the Loc/Rem key. By default, the local reference is speed; if a torque reference is required, the value of parameter 19.16 Local control mode should be changed to Torque.


A constant speed (by default, 300 rpm) can be activated through DI4. DI5 switches between acceleration/deceleration time sets 1 and 2. The acceleration and deceleration times, as well as ramp shapes, are defined by parameters 23.12...23.19.

#### Default parameter settings for the Torque control macro

Below is a listing of default parameter values that differ from those listed for the Factory macro in *Parameter listing* (page 160).

Param	eter	Torque control macro
No.	Name	default
19.11	Ext1/Ext2 selection	DI3
19.14	Ext2 control mode	Torque
20.02	Ext1 start trigger type	Level
20.06	Ext2 commands	In1 Start; In2 Dir
20.07	Ext2 start trigger type	Level
20.08	Ext2 in1 source	DI1
20.09	Ext2 in2 source	DI2
20.12	Run enable 1 source	DI6
22.22	Constant speed sel1	DI4
23.11	Ramp set selection	DI5
26.11	Torque ref1 source	Al2 scaled
31.11	Fault reset selection	Not selected

#### Default control connections for the Torque control macro



#### Sequential control macro

The Sequential control macro is suited for speed control applications in which a speed reference, multiple constant speeds, and two acceleration and deceleration ramps can be used.

Only EXT1 is used in this macro.


The macro offers seven preset constant speeds which can be activated by digital inputs DI4...DI6 (see parameter 22.21 Constant speed function). An external speed reference can be given through analog input AI1. The reference is active only when no constant speed is activated (digital inputs DI4...DI6 are all off). Operational commands can also be given from the control panel.

The start/stop commands are given through digital input DI1; running direction is determined by DI2.

Two acceleration/deceleration ramps are selectable through DI3. The acceleration and deceleration times, as well as ramp shapes, are defined by parameters 23.12...23.19.

#### Operation diagram

The figure below shows an example of the use of the macro.



#### **Selection of constant speeds**

By default, constant speeds 1...7 are selected using digital inputs DI4...DI6 as follows:

DI4	DI5	DI6	Constant speed active	
0	0	None (External speed reference used)		
1	0	0	Constant speed 1	
0	1	0	Constant speed 2	
1	1	0	0 Constant speed 3	
0	0	1 Constant speed 4		
1	0	1	Constant speed 5	
0	1	1	Constant speed 6	
1	1	1	Constant speed 7	

#### Default parameter settings for the Sequential control macro

Below is a listing of default parameter values that differ from those listed for the Factory macro in *Parameter listing* (page 160).

Param	eter	Sequential control macro
No.	Name	default
20.12	Run enable 1 source	DIIL
21.03	Stop mode	Ramp
22.21	Constant speed function	01b (Bit 0 = Packed)
22.22	Constant speed sel1	DI4
22.23	Constant speed sel2	DI5
22.24	Constant speed sel3	DI6
22.27	Constant speed 2	600.00 rpm
22.28	Constant speed 3	900.00 rpm
22.29	Constant speed 4	1200.00 rpm
22.30	Constant speed 5	1500.00 rpm
22.31	Constant speed 6	2400.00 rpm
22.32	Constant speed 7	3000.00 rpm
23.11	Ramp set selection	DI3
25.06	Acc comp derivation time	0.12 s
31.11	Fault reset selection	Not selected

## Default control connections for the Sequential control macro

		XPOW External power input			
		1	+24VI	24 V DC, 2 A	
2			GND	24 V DC, 2 A	
	<del>=</del>	XAI	Reference	voltage and analog inputs	
	//	1	+VREF	10 V DC, R <sub>L</sub> 110 kohm	
$\vdash$	⋥ <del>ा</del> ∕¬ '¦':	2	-VREF	-10 V DC, R <sub>L</sub> 110 kohm	
	<b>♣</b>	3	AGND	Ground	
	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	4	Al1+	Speed reference	
	<del></del>	5	Al1-	0(2)10 V, R <sub>in</sub> > 200 kohm	
		6	Al2+	By default, not in use.	
		7	Al2-	0(4)20 mA, R <sub>in</sub> > 100 ohm	
	~ ^ ·	XAO	Analog out		
(		1	AO1	Motor speed rpm	
	√	2	AGND	020 mA, R <sub>L</sub> < 500 ohm	
(	) / '; ;;	3	AO2	Motor current	
`	~ <del></del>	4	AGND	020 mA, R <sub>L</sub> < 500 ohm	
	- +	XD2D	Drive-to-dr	ive link	
		2	B A	Drive-to-drive link	
		3	BGND	Drive-to-drive link	
				I J 3 Relay outputs	
		1	NC	Ready run	
		2	COM	250 V AC / 30 V DC	
		3	NO	250 V AG / 50 V BG	
		1	NC	Running	
	4	2	COM	250 V AC / 30 V DC	
		3	NO	2 A 2 A	
	Fault	1	NC	Fault (-1)	
	, <u> </u>	2	COM	250 V AC / 30 V DC	
		3	NO	2A	
		XD24	Digital inte	rlock	
		1	DIIL	Run enable	
		2	+24VD	+24 V DC 200 mA	
		3	DICOM	Digital input ground	
		4	+24VD	+24 V DC 200 mA	
<u> </u>		5	DIOGND	0 1 0	
		XDIO	Digital inpu		
		1	DIO1	Output: Ready run	
		2	DIO2	Output: Running	
		XDI	Digital inpu		
		1	DI1	Stop (0) / Start (1)	
		2	DI2	Forward (0) / Reverse (1)	
		3	DI3	Acc/Dec time set 1 (0) / set 2 (1)	
		4	DI4	Constant anged colection (see negre 454)	
		5	DI5	Constant speed selection (see page 151)	
		6	DI6	o off circuits must be closed for the drive to start. See	
		XSTO	Safe torque off circuits must be closed for the drive to start. See		
		X12	Hardware manual of drive.  X12 Safety options connection		
		X12 X13		nel connection	
		X205		nit connection	
			orriory di	in commoduli	

## Fieldbus control macro

	macro is no			

# **Parameters**

## What this chapter contains

The chapter describes the parameters, including actual signals, of the control program.

## Terms and abbreviations

Term	Definition
Actual signal	Type of <i>parameter</i> that is the result of a measurement or calculation by the drive, or contains status information. Most actual signals are read-only, but some (especially counter-type actual signals) can be reset.
Def	(In the following table, shown on the same row as the parameter name)  The default value of a <i>parameter</i> when used in the Factory macro. For information on other macro-specific parameter values, see chapter <i>Application macros</i> (page <i>139</i> ). <b>Note:</b> Certain configurations or optional equipment may require specific default values. These are labeled as follows:  (95.20 bx) = Default changed or write-protected by parameter 95.20, bit x.
FbEq16	(In the following table, shown on the same row as the parameter range, or for each selection) 16-bit fieldbus equivalent: The scaling between the integer used in communication and the value shown on the panel when a 16-bit value is selected for transmission to an external system.  A dash (-) indicates that the parameter is not accessible in 16-bit format. The corresponding 32-bit scalings are listed in chapter <i>Additional parameter data</i> (page 533).
Other	The value is taken from another parameter.  Choosing "Other" displays a parameter list in which the user can specify the source parameter.  Note: The source parameter must be of the <i>real32</i> (32-bit floating point) type. To use a 16-bit integer (for example, received from an external device in data sets) as the source, data storage parameters 47.0147.08 (page 383) can be used. The parameter types are listed in chapter Additional parameter data (page 437).  Note: The source parameter must be a 32-bit real (floating point) number. To use a 16-bit integer (for example, received from an external device in data sets) as the source, data storage parameter 47.0147.08 (page 383) can be used.
Other [bit]	The value is taken from a specific bit in another parameter. Choosing "Other" displays a parameter list in which the user can specify the source parameter and bit.
Parameter	Either a user-adjustable operating instruction for the drive, or an actual signal.
p.u.	Per unit

## **Summary of parameter groups**

Group	Contents	Page
01 Actual values	Basic signals for monitoring the drive.	160
03 Input references	Values of references received from various sources.	165
04 Warnings and faults	Information on warnings and faults that occurred last.	166
05 Diagnostics	Various run-time-type counters and measurements related to drive maintenance.	173
06 Control and status words	Drive control and status words.	174
07 System info	Drive hardware and firmware information.	188
09 Winder actual signals	Actual signals of the winder control program.	191
10 Standard DI, RO	Configuration of digital inputs and relay outputs.	193
11 Standard DIO, FI, FO	Configuration of digital input/outputs and frequency inputs/outputs.	200
12 Standard AI	Configuration of standard analog inputs.	205
13 Standard AO	Configuration of standard analog outputs.	209
14 I/O extension module 1	Configuration of I/O extension module 1.	213
15 I/O extension module 2	Configuration of I/O extension module 2.	233
16 I/O extension module 3	Configuration of I/O extension module 3.	237
19 Operation mode	Selection of local and external control location sources and operating modes.	241
20 Start/stop/direction	Start/stop/direction and run/start/jog enable signal source selection; positive/negative reference enable signal source selection.	243
21 Start/stop mode	Start and stop modes; emergency stop mode and signal source selection; DC magnetization settings; autophasing mode selection.	252
22 Speed reference selection	Speed reference selection; motor potentiometer settings.	260
23 Speed reference ramp	Speed reference ramp settings (programming of the acceleration and deceleration rates for the drive).	268
24 Speed reference conditioning	Speed error calculation; speed error window control configuration; speed error step.	274
25 Speed control	Speed controller settings.	279
26 Torque reference chain	Settings for the torque reference chain.	290
28 Frequency reference chain	Settings for the frequency reference chain.	298
30 Limits	Drive operation limits.	307
31 Fault functions	Settings that define the behavior of the drive upon fault situations.	316
32 Supervision	Configuration of signal supervision functions 13.	326
33 Generic timer & counter	Configuration of maintenance timers/counters.	329
35 Motor thermal protection	Motor thermal protection settings such as temperature measurement configuration, load curve definition and motor fan control configuration.	337
36 Load analyzer	Peak value and amplitude logger settings.	348
37 User load curve	Settings for user load curve.	348
40 Process PID set 1	Parameter values for process PID control.	355
41 Process PID set 2	A second set of parameter values for process PID control.	368
43 Brake chopper	Settings for the internal brake chopper.	370
44 Mechanical brake control	Configuration of mechanical brake control.	372

Group	Contents	Page
45 Energy efficiency	Settings for the energy saving calculators.	376
46 Monitoring/scaling settings	Speed supervision settings; actual signal filtering; general scaling settings.	379
47 Data storage	Data storage parameters that can be written to and read from using other parameters' source and target settings.	383
49 Panel port communication	Communication settings for the control panel port on the drive.	385
50 Fieldbus adapter (FBA)	Fieldbus communication configuration.	388
51 FBA A settings	Fieldbus adapter A configuration.	396
52 FBA A data in	Selection of data to be transferred from drive to fieldbus controller through fieldbus adapter A.	398
53 FBA A data out	Selection of data to be transferred from fieldbus controller to drive through fieldbus adapter A.	399
54 FBA B settings	Fieldbus adapter B configuration.	399
55 FBA B data in	Selection of data to be transferred from drive to fieldbus controller through fieldbus adapter B.	400
56 FBA B data out	Selection of data to be transferred from fieldbus controller to drive through fieldbus adapter B.	401
58 Embedded fieldbus	Configuration of the embedded fieldbus (EFB) interface.	401
60 DDCS communication	DDCS communication configuration.	409
61 D2D and DDCS transmit data	Defines the data sent to the DDCS link.	421
62 D2D and DDCS receive data	Mapping of data received through the DDCS link.	426
74 Application setup	Winder control and setup.	433
75 Winder speed settings	Ramping time adjustments and winder-related speed reference adaptation setup.	438
76 Diameter calculation	Diameter calculation control and setup.	445
77 Tension/Dancer control	Tension control and setup.	449
78 Winder PID controller	PID controller settings.	457
79 Mechanical losses compensation	Friction compensation control and setup.	463
80 Turreting assistance	Torque memory control and setup.	467
81 Winder safety	Settings for web loss.	470
82 Virtual Roll	Settings for the virtual roll function.	475
90 Feedback selection	Motor and load feedback configuration.	478
91 Encoder module settings	Configuration of encoder interface modules.	487
92 Encoder 1 configuration	Settings for encoder 1.	490
93 Encoder 2 configuration	Settings for encoder 2.	496
94 LSU control	Control of the supply unit of the drive, such as DC voltage and reactive power reference.	496
95 HW configuration	Various hardware-related settings.	501
96 System	Language selection; access levels; macro selection; parameter save and restore; control unit reboot; user parameter sets; unit selection; data logger triggering; parameter checksum calculation; user lock.	507

Group	Contents	Page
97 Motor control	Motor model settings.	519
98 User motor parameters	Motor values supplied by the user that are used in the motor model.	523
99 Motor data	Motor configuration settings.	525
200 Safety	FSO-xx settings.	532

## **Parameter listing**

No.	Name/Value	Description	Def/FbEq16
01 Ac	tual values	Basic signals for monitoring the drive. All parameters in this group are read-only unless otherwise noted.	
01.01 Motor speed used		Measured or estimated motor speed depending on which type of feedback is used (see parameter 90.41 Motor feedback selection). A filter time constant for this signal can be defined by parameter 46.11 Filter time motor speed.	-
	-30000.00 30000.00 rpm	Measured or estimated motor speed.	See par. 46.01
01.02	Motor speed estimated	Estimated motor speed in rpm. A filter time constant for this signal can be defined by parameter 46.11 Filter time motor speed.	-
	-30000.00 30000.00 rpm	Estimated motor speed.	See par. 46.01
01.03	Motor speed %	Shows the value of <i>01.01 Motor speed used</i> in percent of the synchronous speed of the motor.	10 = 1%
	-1000.00 1000.00%	Measured or estimated motor speed.	See par. 46.01
01.04	Encoder 1 speed filtered	Speed of encoder 1 in rpm. A filter time constant for this signal can be defined by parameter 46.11 Filter time motor speed.	-
	-30000.00 30000.00 rpm	Encoder 1 speed.	See par. 46.01
01.05	Encoder 2 speed filtered	Speed of encoder 2 in rpm.A filter time constant for this signal can be defined by parameter 46.11 Filter time motor speed.	-
	-30000.00 30000.00 rpm	Encoder 2 speed.	See par. 46.01
01.06	Output frequency	Estimated drive output frequency in Hz. A filter time constant for this signal can be defined by parameter 46.12 Filter time output frequency.	-
	-500.00 500.00 Hz	Estimated output frequency.	See par. 46.02
01.07	Motor current	Measured (absolute) motor current in A.	-
	0.00 30000.00 A	Motor current.	See par. 46.05
01.08	Motor current % of motor nom	Motor current (drive output current) in percent of the nominal motor current.	-
	0.0 1000.0%	Motor current.	1 = 1%
01.10	Motor torque	Motor torque in percent of the nominal motor torque. See also parameter <i>01.30 Nominal torque scale</i> .  A filter time constant for this signal can be defined by parameter <i>46.13 Filter time motor torque</i> .	-
	-1600.0 1600.0%	Motor torque.	See par. 46.03
01.11	DC voltage	Measured DC link voltage.	-
	0.00 2000.00 V	DC link voltage.	10 = 1 V

No.	Name/Value	Description	Def/FbEq16
01.13	Output voltage	Calculated motor voltage in V AC.	-
	0 2000 V	Motor voltage.	10 = 1 V
01.14	Output power	Drive output power. The unit is selected by parameter 96.16 Unit selection. A filter time constant for this signal can be defined by parameter 46.14 Filter time power out.	-
	-32768.00 32767.00 kW or hp	Output power.	1 = 1 unit
01.15	Output power % of motor nom	Shows the value of <i>01.14 Output power</i> in percent of the nominal power of the motor.	-
	-300.00 300.00%	Output power.	10 = 1%
01.17	Motor shaft power	Estimated mechanical power at motor shaft. The unit is selected by parameter 96.16 Unit selection. A filter time constant for this signal can be defined by parameter 46.14 Filter time power out.	-
	-32768.00 32767.00 kW or hp	Motor shaft power.	1 = 1 unit
01.18	Inverter GWh motoring	Amount of energy that has passed through the drive (towards the motor) in full gigawatt-hours. The minimum value is zero.	-
	032767 GWh	Motoring energy in GWh.	1 = 1 GWh
01.19	Inverter MWh motoring	Amount of energy that has passed through the drive (towards the motor) in full megawatt-hours. Whenever the counter rolls over, 01.18 Inverter GWh motoring is incremented. The minimum value is zero.	-
	0999 MWh	Motoring energy in MWh.	1 = 1 MWh
01.20	Inverter kWh motoring	Amount of energy that has passed through the drive (towards the motor) in full kilowatt-hours. Whenever the counter rolls over, 01.19 Inverter MWh motoring is incremented. The minimum value is zero.	-
	0999 kWh	Motoring energy in kWh.	10 = 1 kWh
01.21	U-phase current	Measured U-phase current.	-
	-30000.00 30000.00 A	U-phase current.	See par. 46.05
01.22	V-phase current	Measured V-phase current.	-
	-30000.00 30000.00 A	V-phase current.	See par. 46.05
01.23	W-phase current	Measured W-phase current.	-
	-30000.00 30000.00 A	W-phase current.	See par. 46.05
01.24	Flux actual %	Used flux reference in percent of nominal flux of motor.	-
	0200%	Flux reference.	1 = 1%
01.25	INU momentary cos fii	Momentary cosphi of the drive.	-
	-1.00 1.00	Cosphi.	100 = a

No.	Name/Value	Description	Def/FbEq16
01.29	Speed change rate	Rate of speed reference change after the speed ramp generator.  See also parameters 31.32 Emergency ramp supervision, 31.33 Emergency ramp supervision delay, 31.37 Ramp stop supervision and 31.38 Ramp stop supervision delay.	-
	-15000 15000 rpm/s	Rate of speed change.	1 = 1 rpm/s
01.30	Nominal torque scale	Torque that corresponds to 100% of nominal motor torque. The unit is selected by parameter 96.16 Unit selection  Note: This value is copied from parameter 99.12 Motor nominal torque if entered. Otherwise the value is calculated from other motor data.	-
	0.000 N·m or lb·ft	Nominal torque.	1 = 100 unit
01.31	Ambient temperature	Measured temperature of incoming cooling air. The unit is selected by parameter 96.16 Unit selection.	-
	-40.0 200.0 °C or °F	Cooling air temperature.	1 = 1°
01.32	Inverter GWh regenerating	Amount of energy that has passed through the drive (towards the supply) in full gigawatt-hours. The minimum value is zero.	-
	032767 GWh	Regenerative energy in GWh.	1 = 1 GWh
01.33	Amount of energy that has passed through the drive (towards the supply) in full megawatt-hours. Whenever the counter rolls over, 01.32 Inverter GWh regenerating is incremented. The minimum value is zero.		-
	0999 MWh	Regenerative energy in MWh.	1 = 1 MWh
01.34	Inverter kWh regenerating	Amount of energy that has passed through the drive (towards the supply) in full kilowatt-hours. Whenever the counter rolls over, 01.33 Inverter MWh regenerating is incremented. The minimum value is zero.	-
	0999 kWh	Regenerative energy in kWh.	10 = 1 kWh
01.35	Mot - regen energy GWh	Amount of net energy (motoring energy - regenerating energy) that has passed through the drive in full gigawatthours.	-
	-3276832767 GWh	Energy balance in GWh.	1 = 1 GWh
01.36	Mot - regen energy MWh	Amount of net energy (motoring energy - regenerating energy) that has passed through the drive in full megawatthours. Whenever the counter rolls over, 01.35 Mot - regenenergy GWh is incremented or decremented.	-
	-999999 MWh	Energy balance in MWh.	1 = 1 MWh
01.37	Mot - regen energy kWh	Amount of energy (motoring energy - regenerating energy) that has passed through the drive in full kilowatt-hours. Whenever the counter rolls over, 01.36 Mot - regen energy MWh is incremented or decremented.	
	-999999 kWh	Energy balance in kWh.	10 = 1 kWh
01.61	Abs motor speed used	Absolute value of 01.01 Motor speed used.	-
	0.00 30000.00 rpm	Measured or estimated motor speed.	See par. 46.01

No.	Name/Value	Description	Def/FbEq16
01.62	Abs motor speed %	Absolute value of 01.03 Motor speed %.	-
	0.00 1000.00%	Measured or estimated motor speed.	See par. 46.01
01.63	Abs output frequency	Absolute value of 01.06 Output frequency.	-
	0.00 500.00 Hz	Estimated output frequency.	See par. 46.02
01.64	Abs motor torque	Absolute value of 01.10 Motor torque.	-
	0.0 1600.0%	Motor torque.	See par. 46.03
01.65	Abs output power	Absolute value of 01.14 Output power.	-
	0.00 32767.00 kW or hp	Output power.	1 = 1 unit
01.66	· · · · · · · · · · · · · · · · · · ·		-
	0.00 300.00%	Output power.	1 = 1%
01.68	Abs motor shaft power	Absolute value of 01.17 Motor shaft power.	-
	0.00 32767.00 kW or hp	<b>'</b>	
01.70 Ambient temperature %		Measured temperature of incoming cooling air. The amplitude range of 0100% corresponds to 060 °C or 32140 °F. See also 01.31 Ambient temperature.	-
	-200.00 200.00%	Cooling air temperature.	1 = 1%
01.71	Step-up motor current	Estimated motor current in A when a step-up transformer is in use. The value is calculated from parameter 01.07 Motor current using the step-up transformer ratio (par. 95.40) and sine filter values (parameters 99.18 and 99.19).	-
	0.00 30000.00 A	Estimated motor current.	See par. 46.05
01.72	U-phase RMS current	U-phase rms current.	-
	0.00 30000.00 A	U-phase rms current.	See par. 46.05
01.73	V-phase RMS current	V-phase rms current.	-
	0.00 32767.00 kW or hp	V-phase rms current.	See par. 46.05
01.74	W-phase RMS current	W-phase rms current.	-
	0.00 32767.00 kW or hp	W-phase rms current.	See par. 46.05
01.102	Line current	(Visible only when IGBT supply unit control is activated by 95.20) Estimated line current flowing through the supply unit.	-
	0.00 30000.00 A	Estimated line current.	See par 46.05

No.	Name/Value	Description	Def/FbEq16
01.104	Active current	(Visible only when IGBT supply unit control is activated by 95.20)	-
		Estimated active current flowing through the supply unit.	
	0.00 30000.00 A	Estimated active current.	See par 46.05
01.106	Reactive current	(Visible only when IGBT supply unit control is activated by 95.20) Estimated reactive current flowing through the supply unit.	-
	0.00 30000.00 A	Estimated reactive current.	See par 46.05
01.108	Grid frequency	(Visible only when IGBT supply unit control is activated by 95.20) Estimated frequency of the power supply network.	-
	0.00 100.00 Hz	Estimated supply frequency.	See par 46.02
01.109	Grid voltage	(Visible only when IGBT supply unit control is activated by 95.20) Estimated voltage of the power supply network.	-
	0.00 2000.00 V	Estimated supply voltage.	10 = 1 V
01.110 Grid apparent power		(Visible only when IGBT supply unit control is activated by 95.20) Estimated apparent power transferred through the supply unit.	-
	-30000.00 30000.00 kVA	Estimated apparent power.	See par 46.04
01.112	Grid power	(Visible only when IGBT supply unit control is activated by 95.20) Estimated power transferred through the supply unit.	-
	-30000.00 30000.00 kW	Estimated supply power.	See par 46.04
01.114	Grid reactive power	(Visible only when IGBT supply unit control is activated by 95.20) Estimated reactive power transferred through the supply unit.	-
	-30000.00 30000.00 kvar	Estimated reactive power.	10 = 1 kvar
01.116	LSU cos Φ	(Visible only when IGBT supply unit control is activated by 95.20) Power factor of the supply unit.	-
	-1.00 1.00	Power factor.	100 = 1
01.164		(Visible only when IGBT supply unit control is activated by 95.20) Nominal power of the supply unit.	-
	0 30000 kW	Nominal power.	1 = 1 kW

No.	Name/Value	Description	Def/FbEq16
03 Inp	ut references	Values of references received from various sources. All parameters in this group are read-only unless otherwise noted.	
03.01	Panel reference	Local reference given from the control panel or PC tool.	-
	-100000.00 100000.00	Control panel or PC tool reference.	1 = 10
03.02	Panel reference 2	Remote reference given from the control panel or PC tool.	-
	-30000.00 30000.00	Remote control panel or PC tool reference.	1 = 10
03.05	FB A reference 1	Reference 1 received through fieldbus adapter A. See also chapter <i>Fieldbus control through a fieldbus adapter</i> (page 667).	-
	-100000.00 100000.00	Reference 1 from fieldbus adapter A.	1 = 10
03.06	76 FB A reference 2 Reference 2 received through fieldbus adapter A.		-
	-100000.00 100000.00	Reference 2 from fieldbus adapter A.	1 = 10
03.07	FB B reference 1	Reference 1 received through fieldbus adapter B.	-
	-100000.00 100000.00	Reference 1 from fieldbus adapter B.	1 = 10
03.08	FB B reference 2	Reference 2 received through fieldbus adapter B.	-
	-100000.00 100000.00	Reference 2 from fieldbus adapter B.	1 = 10
03.09	EFB reference 1	Scaled reference 1 received through the embedded fieldbus interface. The scaling is defined by 58.26 EFB ref1 type.	1 = 10
	-30000.00 30000.00	Reference 1 received through the embedded fieldbus interface.	1 = 10
03.10	EFB reference 2	Scaled reference 2 received through the embedded fieldbus interface. The scaling is defined by 58.27 EFB ref2 type.	1 = 10
	-30000.00 30000.00	Reference 2 received through the embedded fieldbus interface.	1 = 10
03.11	DDCS controller ref	Reference 1 received from the external (DDCS) controller. The value has been scaled according to parameter 60.60 DDCS controller ref1 type.  See also section External controller interface (page 81).	1 = 10
	-30000.00 30000.00	Scaled reference 1 received from external controller.	1 = 10
03.12	DDCS controller ref 2	Reference 2 received from the external (DDCS) controller. The value has been scaled according to parameter 60.61 DDCS controller ref2 type.	1 = 10
	-30000.00 30000.00	Scaled reference 2 received from external controller.	1 = 10
03.13	M/F or D2D ref1	Master/follower reference 1 received from the master. The value has been scaled according to parameter 60.10 M/F ref1 type.  See also section Master/follower functionality (page 74).	1 = 10
	-30000.00 30000.00	Scaled reference 1 received from master.	1 = 10

No.	Name/Value	Description	Def/FbEq16
03.14	M/F or D2D ref2	Master/follower reference 2 received from the master. The value has been scaled according to parameter 60.11 M/F ref2 type.	1 = 10
	-30000.00 30000.00	Scaled reference 2 received from master.	1 = 10
03.30	FB A reference 1 int32	Reference1receivedthroughfieldbusadapterAasa32-bit integer.	-
	-2147483648 2147483647	Reference 1 from fieldbus adapter A.	-
03.31	FB A reference 2 int32	Reference 2 received through fieldbus adapter A as a 32-bit integer.	-
	-2147483648 2147483647	Reference 2 from fieldbus adapter A.	-
03.51	IEC application panel	Panel reference defined in the application program.	-
	100000.0	Panel reference in the application program.	1 = 1

04 Wa	rnings and faults	Information on warnings and faults that occurred last. For explanations of individual warning and fault codes, see chapter <i>Fault tracing</i> . All parameters in this group are read-only unless otherwise noted.	
04.01	Tripping fault	Code of the 1st active fault (the fault that caused the current trip).	-
	0000hFFFFh	1st active fault.	1 = 1
04.02	Active fault 2	Code of the 2nd active fault.	-
	0000hFFFFh	2nd active fault.	1 = 1
04.03	Active fault 3	Code of the 3rd active fault.	-
	0000hFFFFh	3rd active fault.	1 = 1
04.04	Active fault 4	Code of the 4th active fault.	-
	0000hFFFFh	4th active fault.	1 = 1
04.05	Active fault 5	Code of the 5th active fault.	-
	0000hFFFFh	5th active fault.	1 = 1
04.06	Active warning 1	Code of the 1st active warning.	-
	0000hFFFFh	1st active warning.	1 = 1
04.07	Active warning 2	Code of the 2nd active warning.	-
	0000hFFFFh	2nd active warning.	1 = 1
04.08	Active warning 3	Code of the 3rd active warning.	-
	0000hFFFFh	3rd active warning.	1 = 1
04.09	Active warning 4	Code of the 4th active warning.	-
	0000hFFFFh	4th active warning.	1 = 1
04.10	Active warning 5	Code of the 5th active warning.	-
	0000hFFFFh	5th active warning.	1 = 1
04.11	Latest fault	Code of the 1st stored (non-active) fault.	-
	0000hFFFFh	1st stored fault.	1 = 1

No.	Name/Value	Description	Def/FbEq16
04.12	2nd latest fault	Code of the 2nd stored (non-active) fault.	-
	0000hFFFFh	2nd stored fault.	1 = 1
04.13	3rd latest fault	Code of the 3rd stored (non-active) fault.	-
	0000hFFFFh	3rd stored fault.	1 = 1
04.14	4th latest fault	Code of the 4th stored (non-active) fault.	-
	0000hFFFFh	4th stored fault.	1 = 1
04.15	5th latest fault	Code of the 5th stored (non-active) fault.	-
	0000hFFFFh	5th stored fault.	1 = 1
04.16	Latest warning	Code of the 1st stored (non-active) warning.	-
	0000hFFFFh	1st stored warning.	1 = 1
04.17	2nd latest warning	Code of the 2nd stored (non-active) warning.	-
	0000hFFFFh	2nd stored warning.	1 = 1
04.18	3rd latest warning	Code of the 3rd stored (non-active) warning.	-
	0000hFFFFh	3rd stored warning.	1 = 1
04.19	4th latest warning	Code of the 4th stored (non-active) warning.	-
	0000hFFFFh	4th stored warning.	1 = 1
04.20	5th latest warning	Code of the 5th stored (non-active) warning.	-
	0000hFFFFh	5th stored warning.	1 = 1

0000h...FFFFh

No.	Name/V	alue Descri	ption		Def/FbEq16
04.21	Fault wo	The bit WORD word co are acc control	assignments of this was 1 in the ACS800. Parampatibility determines tording to the ACS800 program.	ndicate several ACS880 events as listed below.	
		ACS800	fault name		
	Bit	(04.120 = ACS800 Standard ctrl program)	(04.120 = ACS800 System ctrl program)	ACS880 events indicated by (see Fault tracing, page 593)	this bit
	0	SHORT CIRC	SHORT CIRC	2340	
	1	OVERCURRENT	OVERCURRENT	2310	
	2	DC OVERVOLT	DC OVERVOLT	3210	
	3	ACS800 TEMP	ACS800 TEMP	2381, 4210, 4290, 42F1, 4310	4380
	4	EARTH FAULT	EARTH FAULT	2330, 2392, 3181	
	5	THERMISTOR	MOTOR TEMP M	4981, 4991, 4992, 4993	
	6	MOTOR TEMP	MOTOR TEMP	4982	
	7	SYSTEM_FAULT	SYSTEM_FAULT	6481, 6487, 64A1, 64A2, 64A3 6881, 6882, 6883, 6885	, 64B1, 64E1,
	8	UNDERLOAD	UNDERLOAD	-	
	9	OVERFREQ	OVERFREQ	7310	
	10	Reserved	MPROT SWITCH	9081	
	11	Reserved	CH2 COMM LOSS	7582	
	12	Reserved	SC (INU1)	2340 (XXYY YY01)	
	13	Reserved	SC (INU2)	2340 (XXYY YY02)	
	14	Reserved	SC (INU3)	2340 (XXYY YY03)	
	15	Reserved	SC (INU4)	2340 (XXYY YY04)	

ACS800-compatible fault word 1.

1 = 1

1 = 1

No.	Name/V	alue	Descri	otion		Def/FbEq1
04.22	Fault wo	rd 2	The bit WORD word co are accontrol Each bibelow.	2 in the ACS800. Pa impatibility determine ording to the ACS800 program.	word correspond to FAULT rameter 04.120 Fault/Warning es whether the bit assignments 0 Standard or ACS800 System	-
			CS800 :	fault name		
	Bit (04.120 = 7 Standard of program)		CS800	(04.120 = ACS800 System ctrl program)	ACS880 events indicated by (see Fault tracing, page 593)	this bit
	0	SUPPLY PI	HASE	SUPPLY PHASE	3130	
	1	NO MOT D	ATA	NO MOTOR DATA	-	
	2	DC UNDEF	RVOLT	DC UNDERVOLT	3220	
	3	Reserved		CABLE TEMP	4000	
	4	RUN ENABLE		RUN DISABLE	AFEB	
	5	ENCODER ERR		ENCODER ERR	7301, 7380, 7381, 73A0, 73A1	
	6	I/O COMM CTRL B TEMP		IO COMM ERR	7080, 7082	
	7			CTRL B TEMP	-	
	8	EXTERNAL FLT		SELECTABLE	9082	
	9	OVER SWFREQ		OVER SWFREQ	-	
	10	AI < MIN FUNC		AI <min func<="" td=""><td>80A0</td><td></td></min>	80A0	
	11	PPCC LINK	(	PPCC LINK	5681, 5682, 5690, 5691, 5692, 5695	, 5693, 5694,
	12	COMM MODULE		COMM MODULE	6681, 7510, 7520, 7581	
	13	PANEL LOS	SS	PANEL LOSS	7081	
	14	MOTOR ST		MOTOR STALL	7121	
	15	MOTOR PH	HASE	MOTOR PHASE	3381	
	0000h	FFFFh	ACS80	0-compatible fault wo	ord 2.	1 = 1
04.25	Indica The bi reset.		Indicate The bits reset.	visible with a BCU control unit) ses which parallel-connected modules have faulted. ts of this word are cleared when all faults have been arameter is read-only.		-
	Bit	Name		Description		
	0	Module 1		1 = Module 1 faulted		
	1	Module 2		1 = Module 2 faul		
	11	Module 12		1 = Module 12 fau	ulted	
	1215	Module 12 Reserved		1		

Faulted modules indication.

0000h...FFFFh

No.	Name/V	alue	Descri	otion		Def/FbEq16	
04.31	The bit WORD word co accordi control Each m below.			00-compatible warning (alarm) word 1. assignments of this word correspond to ALARM 10 1 in the ACS800. Parameter 04.120 Fault/Warning 11 in the ACS800 Standard or ACS800 System 12 ing to the ACS800 Standard or ACS800 System 13 program. 14 indicate several ACS880 warnings as listed 15 arameter is read-only.		-	
		A	CS800 a	larm name			
	Bit	(04.120 = A Standard ct. program)		(04.120 = ACS800 System ctrl program)	ACS880 events indicated by (see Fault tracing, page 593)	this bit	
	0	START INHIBIT		START INHIBI	A5A0		
	1	Reserved		EM STOP	AFE1, AFE2		
	2	THERMISTOR		MOTOR TEMP M	A491, 4991, 4992, 4993		
	3	MOTOR TEMP		MOTOR TEMP	A492		
	4	ACS800 TEMP		ACS800 TEMP	A2BA, A4A9, A4B0, A4B1, A4F	-6	
	5	ENCODER ERR		ENCODER ERR	A797, A7B0, A7B1, A7E1		
	6	T MEAS ALM		T MEAS CIRC	A490, A5EA, A782, A8A0		
	7	Reserved		DIGITAL IO	-		
	8	Reserved		ANALOG IO	-		
	9	Reserved		EXT DIGITAL IO	-		
	10	Reserved		EXT ANALOG IO	A6E5, A7AA, A7AB		
	11	Reserved		CH2 COMM LOSS	A7CB, AF80		
	12	COMM MOI	DULE	MPROT SWITCH	A981		
	13	Reserved		EM STOP DEC	-		
	14	EARTH FAL	JLT	EARTH FAULT	A2B3		
	15	Reserved		SAFETY SWITC	A983		

0000h...FFFFh ACS800-compatible warning (alarm) word 1. 1 = 1

No.	Name/Value	Name/Value Description			
04.32	Warning word 2	ACS800-compatible warning (alarm) word 2.  The bit assignments of this word correspond to ALARM WORD 2 in the ACS800. Parameter 04.120 Fault/Warning word compatibility determines whether the bit assignments are according to the ACS800 Standard or ACS800 System control program.  Each may indicate several ACS880 warnings as listed below.  This parameter is read-only.	-		

	ACS800 a	larm name	
Bit	(04.120 = ACS800 Standard ctrl program)	(04.120 = ACS800 System ctrl program)	ACS880 events indicated by this bit (see Fault tracing, page 593)
0	Reserved	MOTOR FAN	A781
1	UNDERLOAD	UNDERLOAD	-
2	Reserved	INV OVERLOAD	-
3	Reserved	CABLE TEMP	A480
4	ENCODER	ENCODER A<>B	-
5	Reserved	FAN OVERTEMP	A984
6	Reserved	Reserved	-
7	POWFAIL FILE	POWFAIL FILE	-
8	ALM (OS_17)	POWDOWN FILE	-
9	MOTOR STALL	MOTOR STALL	A780
10	AI < MIN FUNC	AI <min func<="" td=""><td>A8A0</td></min>	A8A0
11	Reserved	COMM MODULE	A6D1, A6D2, A7C1, A7C2, A7CA, A7CE
12	Reserved	BATT FAILURE	-
13	PANEL LOSS	PANEL LOSS	A7EE
14	Reserved	DC UNDERVOLT	A3A2
15	Reserved	RESTARTED	-

0000hFFFFh	ACS800-compatible warning (alarm) word 2.	1 = 1
04.40 Event word 1	User-defined event word. This word collects the status of the events (warnings, faults or pure events) selected by parameters 04.4104.72.  For each event, an auxiliary code can optionally be specified for filtering.  This parameter is read-only.	-

Bit	Name	Description
0	User bit 0	1 = Event selected by parameters <i>04.41</i> (and <i>04.42</i> ) is active
1	User bit 1	1 = Event selected by parameters <i>04.43</i> (and <i>04.44</i> ) is active
15	User bit 15	1 = Event selected by parameters <i>04.71</i> (and <i>04.72</i> ) is active

	0000hFFFFh	User-defined event word.	1 = 1
--	------------	--------------------------	-------

No.	Name/Value	Description	Def/FbEq16
04.41	Event word 1 bit 0 code	Selects the hexadecimal code of an event (warning, fault or pure event) whose status is shown as bit 0 of <i>04.40 Event word 1</i> . The event codes are listed in chapter <i>Fault tracing</i> (page <i>593</i> ).	0000h
	0000hFFFFh	Code of event.	1 = 1
04.42	Event word 1 bit 0 aux code	Specifies an auxiliary code for the event selected by the previous parameter. The selected event is indicated by the event word only if its auxiliary code matches the value of this parameter.  With a value of 0000 0000h, the event word will indicate the event regardless of the auxiliary code.	0000 0000h
	0000 0000h FFFF FFFFh	Code of warning, fault or pure event.	1 = 1
04.43	Event word 1 bit 1 code	Selects the hexadecimal code of an event (warning, fault or pure event) whose status is shown as bit 1 of <i>04.40 Event word 1</i> . The event codes are listed in chapter <i>Fault tracing</i> (page <i>593</i> ).	0000h
	0000hFFFFh	Code of event.	1 = 1
04.44	Event word 1 bit 1 aux code	Specifies an auxiliary code for the event selected by the previous parameter. The selected event is indicated by the event word only if its auxiliary code matches the value of this parameter.  With a value of 0000 0000h, the event word will indicate the event regardless of the auxiliary code.	0000 0000h
	0000 0000h FFFF FFFFh	Code of warning, fault or pure event.	1 = 1
04.71	Event word 1 bit 15 code	Selects the hexadecimal code of an event (warning, fault or pure event) whose status is shown as bit 15 of 04.40 Event word 1. The event codes are listed in chapter Fault tracing (page 593).	0000h
	0000hFFFFh	Code of event.	1 = 1
04.72	Event word 1 bit 15 aux code	Specifies an auxiliary code for the event selected by the previous parameter. The selected event is indicated by the event word only if its auxiliary code matches the value of this parameter.  With a value of 0000 0000h, the event word will indicate the event regardless of the auxiliary code.	0000 0000h
	0000 0000h FFFF FFFFh	Code of warning, fault or pure event.	1 = 1
04.120	Fault/Warning word compatibility	Selects whether the bit assignments of parameters 04.2104.32 correspond to the ACS800 Standard control program or the ACS800 System control program.	False
	ACS800 Standard ctrl program	The bit assignments of parameters 04.2104.32 correspond to the ACS800 Standard control program as follows:  04.21 Fault word 1: 03.05 FAULT WORD 1  04.22 Fault word 2: 03.06 FAULT WORD 2  04.31 Warning word 1: 03.08 ALARM WORD 1  04.32 Warning word 2: 03.09 ALARM WORD 2	0

1 = 1%

O5.04       Fan on-time counter       Running time of the drive cooling fan. Can be reset from the control panel by keeping Reset depressed for over 3 seconds.       -         065535 d       Cooling fan run-time counter.       1 = 1 d         05.09       Time from power-up       500-microsecond ticks elapsed since the last boot of the control unit.       -         04294967295       500-microsecond ticks since last boot.       1 = 1         05.11       Inverter temperature       Estimated drive temperature in percent of fault limit. The actual trip temperature varies according to the type of the drive.       -         0.0% = 0 °C (32 °F)       94% approx. = Warning limit 100.0% = Fault limit       -	No.	Name/Value	Description	Def/FbEq16
to drive maintenance. All parameters in this group are read-only unless otherwise noted.  05.01 On-time counter  On-time counter: The counter runs when the drive is powered.  065535 d  On-time counter: The counter runs when the inverter modulates.  065535 d  Motor run-time counter.  Running time of the drive cooling fan. Can be reset from the control panel by keeping Reset depressed for over 3 seconds.  065535 d  Cooling fan run-time counter.  1 = 1 d  05.09 Time from power-up 500-microsecond ticks elapsed since the last boot of the control unit.  04294967295 500-microsecond ticks since last boot.  1 = 1  Estimated drive temperature in percent of fault limit. The actual trip temperature varies according to the type of the drive.  0.0% = 0 °C (32 °F) 94% approx. = Warning limit 100.0% = Fault limit  -40.0 160.0% Drive temperature in percent.  1 = 1%  Diagnostic word 3  Diagnostic word 3.		-	correspond to the ACS800 System control program as follows:  04.21 Fault word 1: 09.01 FAULT WORD 1  04.22 Fault word 2: 09.02 FAULT WORD 2  04.31 Warning word 1: 09.04 ALARM WORD 1	1
to drive maintenance. All parameters in this group are read-only unless otherwise noted.  05.01 On-time counter On-time counter. The counter runs when the drive is powered.  065535 d On-time counter. The counter runs when the inverter modulates.  065535 d Motor run-time counter.  Running time of the drive cooling fan. Can be reset from the control panel by keeping Reset depressed for over 3 seconds.  065535 d Cooling fan run-time counter.  1 = 1 d 05.09 Time from power-up 500-microsecond ticks elapsed since the last boot of the control unit.  04294967295 500-microsecond ticks since last boot.  1 = 1	05 Dia	anostics	Various run-time-type counters and measurements related	
powered.  065535 d On-time counter. 1 = 1 d  05.02 Run-time counter Motor run-time counter. The counter runs when the inverter modulates.  065535 d Motor run-time counter. 1 = 1 d  05.04 Fan on-time counter Control panel by keeping Reset depressed for over 3 seconds.  065535 d Cooling fan run-time counter. 1 = 1 d  05.09 Time from power-up 500-microsecond ticks elapsed since the last boot of the control unit. 500-microsecond ticks since last boot. 1 = 1  05.11 Inverter temperature	00 270	gnocus	to drive maintenance. All parameters in this group are read-only unless otherwise	
Motor run-time counter modulates.   1 = 1 d	05.01	On-time counter		-
modulates.  065535 d Motor run-time counter. 1 = 1 d  05.04 Fan on-time counter Running time of the drive cooling fan. Can be reset from the control panel by keeping Reset depressed for over 3 seconds.  065535 d Cooling fan run-time counter. 1 = 1 d  05.09 Time from power-up 500-microsecond ticks elapsed since the last boot of the control unit. 1 = 1  05.11 Inverter Estimated drive temperature in percent of fault limit. The actual trip temperature varies according to the type of the drive. 1 = 0.0% = 0 °C (32 °F) 94% approx. = Warning limit 100.0% = Fault limit 10		065535 d	On-time counter.	1 = 1 d
Running time of the drive cooling fan. Can be reset from the control panel by keeping Reset depressed for over 3 seconds.   065535 d   Cooling fan run-time counter.   1 = 1 d	05.02	Run-time counter		-
control panel by keeping Reset depressed for over 3 seconds.  065535 d Cooling fan run-time counter. 1 = 1 d  05.09 Time from power-up 500-microsecond ticks elapsed since the last boot of the control unit  04294967295 500-microsecond ticks since last boot. 1 = 1  05.11 Inverter Estimated drive temperature in percent of fault limit. The actual trip temperature varies according to the type of the drive. 0.0% = 0 °C (32 °F) 94% approx. = Warning limit 100.0% = Fault limit - 40.0 160.0% Drive temperature in percent. 1 = 1%  05.22 Diagnostic word 3 Diagnostic word 3    Bit   Name   Value		065535 d	Motor run-time counter.	1 = 1 d
Displays the age of the main cooling fan as a percentage of its estimated lifetime. The estimated since word 3.   Displays the age of the main cooling fan as a percentage of its estimated lifetime. The estimate is based on the duty, operating conditions and other operating (A8CO Fan service counter) is generated.   Can be reset from the control panel by keeping Reset	05.04	Fan on-time counter	control panel by keeping Reset depressed for over 3	-
control unit.  04294967295 500-microsecond ticks since last boot. 1 = 1  05.11 Inverter temperature  Estimated drive temperature in percent of fault limit. The actual trip temperature varies according to the type of the drive.  0.0% = 0 °C (32 °F)  94% approx. = Warning limit 100.0% = Fault limit  -40.0 160.0% Drive temperature in percent. 1 = 1%  05.22 Diagnostic word 3 Diagnostic word 3    Bit   Name   Value		065535 d	Cooling fan run-time counter.	1 = 1 d
Displays the age of the main cooling fan as a percentage of its estimated lifetime. The setunder of the main cooling fan as a percentage of its estimated lifetime. The eactual trip temperature in percent of fault limit. The actual trip temperature varies according to the type of the drive.     0.0% = 0 °C (32 °F)     94% approx. = Warning limit	05.09	Time from power-up		-
temperature  actual trip temperature varies according to the type of the drive.  0.0% = 0 °C (32 °F) 94% approx. = Warning limit 100.0% = Fault limit  -40.0 160.0% Drive temperature in percent.  1 = 1%  Diagnostic word 3 Diagnostic word 3.    This is is notating above idle speed   1215   Reserved		04294967295	500-microsecond ticks since last boot.	1 = 1
Diagnostic word 3   Diagnostic word 3.   -	05.11		actual trip temperature varies according to the type of the drive.  0.0% = 0 °C (32 °F)  94% approx. = Warning limit	-
Bit Name		-40.0 160.0%	Drive temperature in percent.	1 = 1%
010 Reserved  11 Fan command 1 = Drive fan is rotating above idle speed  1215 Reserved  0000hFFFh Diagnostic word 3. 1 = 1  05.41 Main fan service counter  Displays the age of the main cooling fan as a percentage of its estimated lifetime. The estimate is based on the duty, operating conditions and other operating parameters of the fan. When the counter reaches 100%, a warning (A8C0 Fan service counter) is generated.  Can be reset from the control panel by keeping Reset	05.22	Diagnostic word 3	Diagnostic word 3.	-
11 Fan command 1 = Drive fan is rotating above idle speed 1215 Reserved  0000hFFFFh Diagnostic word 3. 1 = 1  05.41 Main fan service counter  Displays the age of the main cooling fan as a percentage of its estimated lifetime. The estimate is based on the duty, operating conditions and other operating parameters of the fan. When the counter reaches 100%, a warning (A8C0 Fan service counter) is generated.  Can be reset from the control panel by keeping Reset		Bit Name	Value	
1215 Reserved  0000hFFFh  Diagnostic word 3.  1 = 1  05.41 Main fan service counter  Displays the age of the main cooling fan as a percentage of its estimated lifetime. The estimate is based on the duty, operating conditions and other operating parameters of the fan. When the counter reaches 100%, a warning (A8C0 Fan service counter) is generated.  Can be reset from the control panel by keeping Reset		010 Reserved		
0000hFFFh Diagnostic word 3. 1 = 1  05.41 Main fan service counter  Displays the age of the main cooling fan as a percentage of its estimated lifetime. The estimate is based on the duty, operating conditions and other operating parameters of the fan. When the counter reaches 100%, a warning (A8C0 Fan service counter) is generated.  Can be reset from the control panel by keeping Reset		11 Fan comma	and 1 = Drive fan is rotating above idle speed	
Displays the age of the main cooling fan as a percentage of its estimated lifetime. The estimate is based on the duty, operating conditions and other operating parameters of the fan. When the counter reaches 100%, a warning (A8C0 Fan service counter) is generated.  Can be reset from the control panel by keeping Reset		1215 Reserved		
its estimated lifetime. The estimate is based on the duty, operating conditions and other operating parameters of the fan. When the counter reaches 100%, a warning (A8C0 Fan service counter) is generated.  Can be reset from the control panel by keeping Reset		0000hFFFFh	Diagnostic word 3.	1 = 1
ı ·	05.41		its estimated lifetime. The estimate is based on the duty, operating conditions and other operating parameters of the fan. When the counter reaches 100%, a warning (A8C0 Fan service counter) is generated.  Can be reset from the control panel by keeping Reset	-

Main cooling fan age.

0...150%

No.	Name/Value	Description	Def/FbEq16
05.42	Aux. fan service counter	Displays the age of the auxiliary cooling fan as a percentage of its estimated lifetime. The estimate is based on the duty, operating conditions and other operating parameters of the fan. When the counter reaches 100%, a warning (A8C0 Fan service counter) is generated.  Can be reset from the control panel by keeping Reset	-
	0150%	depressed for over 3 seconds.  Auxiliary cooling fan age.	1 = 1%
05.111	Line converter	(Visible only when IGBT supply unit control is activated by	-
00.777	temperature	95.20) Estimated supply unit temperature in percent of fault limit. 0.0% = 0 °C (32 °F) 94% approx. = Warning limit 100.0% = Fault limit	
	-40.0 160.0%	Supply unit temperature in percent.	1 = 1%
05.121	MCB closing counter	(Visible only when IGBT supply unit control is activated by 95.20) Counts the closures of the main circuit breaker of the supply unit.	-
	0 4294967295	Count of closures of main circuit breaker.	1 = 1
	· · · · · · · · · · · · · · · · · · ·	Count of discussion of main should should.	' '
06 Cor words	ntrol and status	Drive control and status words.	
06.01	Main control word	The main control word of the drive. This parameter shows the control signals as received from the selected sources (such as digital inputs, the fieldbus interface and the application program).  The bit assignments of the word are as described on page 673. The related status word and state diagram are presented on pages 674 and 675 respectively.  Notes:  Bits 1215 can be used to carry additional control data, and used as a signal source by any binary-source selector parameter. Bit 10 must be active for bits 1215 to update.  In fieldbus control, this parameter value is not exactly the same as the control word that the drive receives from the PLC. See parameter 50.12 FBA A debug mode.  This parameter is read-only.	-
	0000hFFFFh	Main control word.	1 = 1
06.02	Application control word	The drive control word received from the application program (if any). The bit assignments are described on page 673. This parameter is read-only.	-
	0000hFFFFh	Application program control word.	1 = 1
06.03	FBA A transparent control word	Displays the unaltered control word received from the PLC through fieldbus adapter A when a transparent communication profile is selected e.g. by parameter group 51 FBA A settings. See section Control word and Status word (page 670).  This parameter is read-only.	-
	00000000h FFFFFFFh	Control word received through fieldbus adapter A.	-

No.	Name/Value	Description	Def/FbEq16
06.04	FBA B transparent control word	Displays the unaltered control word received from the PLC through fieldbus adapter B when a transparent communication profile is selected e.g. by parameter group 54 FBA B settings. See section Control word and Status word (page 670).  This parameter is read-only.	-
	00000000h FFFFFFFh	Control word received through fieldbus adapter B.	1 = 1
06.05	EFB transparent control word	Displays the unaltered control word received from the PLC through the embedded fieldbus interface when a transparent communication profile is selected in parameter 58.25 Control profile. See section The Transparent profile (page 660).  This parameter is read-only.	-
	00000000h FFFFFFFh	Control word received through the embedded fieldbus interface.	1 = 1
06.11	Main status word	Main status word of the drive. The bit assignments are described on page 674. The related control word and state diagram are presented on pages 673 and 675 respectively.  Note: In fieldbus control, this parameter value is not exactly the same as the control word that the drive receives from the PLC. See parameter 50.12 FBA A debug mode. This parameter is read-only.	-
	0000hFFFFh	Main status word.	1 = 1
06.16	Drive status word 1	Drive status word 1. This parameter is read-only.	-

Bit	Name	Description	
0	Enabled	1 = Both run enable (see par. 20.12) and start enable (20.19) signals are present. <b>Note:</b> This bit is not affected by the presence of a fault.	
1	Inhibited	1 = Start inhibited. See parameters <i>06.18</i> and <i>06.25</i> for the source of the inhibiting signal.	
2	DC charged	1 = DC circuit has been charged	
3	Ready to start	1 = Drive is ready to receive a start command	
4	Following reference	1 = Drive is ready to follow given reference	
5	Started	1 = Drive has been started	
6	Modulating	1 = Drive is modulating (output stage is being controlled)	
7	Limiting	= Any operating limit (speed, torque, etc.) is active	
8	Local control	ocal control 1 = Drive is in local control	
9	Network ctrl	1 = Drive is in <i>network control</i> (see page 17)	
10	Ext1 active	1 = Control location EXT1 active	
11	Ext2 active	1 = Control location EXT2 active	
12	Reserved		
13	Start request	1 = Start requested	
		<b>Note</b> : At the time of publishing, a start request from the control panel does not activate this bit if any start-inhibiting condition (see bit 1) is present.	
0000hFFFFh Drive sta		Drive status word 1. 1 = 1	

No.	Name/Value	Description	Def/FbEq16
06.17	Drive status word 2	Drive status word 2.	-
		This parameter is read-only.	

Bit	Name	Description	
0	Identification run done	1 = Motor identification (ID) run has been performed	
1	Magnetized	1 = The motor has been magnetized	
2	Torque control	1 = Torque control mode active	
3	Speed control	1 = Speed control mode active	
4	Power control	Reserved	
5	Safe reference active	1 = A "safe" reference is being applied by functions s parameters 49.05 and 50.02	uch as
6	Last speed active	1 = A "last speed" reference is being applied by funct parameters 49.05 and 50.02	ions such as
7	Loss of reference	1 = Reference signal lost	
8	Emergency stop failed 1 = Emergency stop failed (see parameters		d 31.33)
9	Jogging active 1 = Jogging enable signal is on		
10	Above limit 1 = Actual speed, frequency or torque equals or exceeds limit (defined by parameters 46.3146.33). Valid in both directions of rotation.		
11	Emergency stop active	1 = An emergency stop command signal is active, or stopping after receiving an emergency stop comman	
12	Reduced run	1 = Reduced run active (see section <i>du/dt filter suppol</i> 135)	ort on page
13	,		
14	Stop failed	1 = Stopping failed (see parameters 31.37 and 31.38	3)
15	Reserved	•	
•			
00001	hFFFFh Drive st	atus word 2.	1 = 1

06.18	Start			/FbEq1
06.18			Start inhibit status word. This word specifies the source of the inhibiting condition that prevents the drive from starting.  After the condition is removed, the start command must be cycled. See bit-specific notes.  See also parameter 06.25 Drive inhibit status word 2, and 06.16 Drive status word 1, bit 1.  This parameter is read-only.	
	Bit	Name	Description	Note
	0	Not ready run	1 = DC voltage is missing or drive has not been parametrized correctly. Check the parameters in groups 95 and 99.	l a
	1	Ctrl location changed	1 = Control location has changed	a,c
	2	SSW inhibit	1 = Control program is keeping itself in inhibited state	а
	3	Fault reset	1 = A fault has been reset	a,c
	4	Lost start enable	1 = Start enable signal missing	а
	5	Lost run enable	1 = Run enable signal missing	а
	6	FSO inhibit	1 = Operation prevented by FSO-xx safety functions module	b
	7	STO	1 = Safe torque off is active	b
	8	Current calibrati ended	on 1 = Current calibration routine has finished	b,c
	9	ID run ended	1 = Motor identification run has finished	b,c
	10	Auto phase end	ed 1 = Autophasing routine has finished	b,c
	11	Em Off1	1 = Emergency stop signal (mode off1)	b
	12	Em Off2	1 = Emergency stop signal (mode off2)	b
	13	Em Off3	1 = Emergency stop signal (mode off3)	b
	14	Auto reset inhibi	t 1 = The autoreset function is inhibiting operation	
	15	Jogging active	1 = The jogging enable signal is inhibiting operation	b
	Not	, DC.		

- If bit 1 of 06.16 Drive status word 1 is still set after the removal of the inhibiting condition, and edge triggering is selected for the active external control location, a fresh rising-edge start signal is required. See parameters 20.02, 20.07 and 20.19.
- If bit 1 of 06.16 Drive status word 1 is still set after the removal of the inhibiting condition, a fresh rising-edge start signal is required.
- Informative bit. The inhibiting condition need not be removed by the user.

0000h...FFFFh Start inhibit status word. 1 = 1

No.	Name/Value		Description		Def/FbEq16		
06.19	Speed control status word		Speed contro	ol status word.	-		
			This parameter is read-only.				
	Bit	Bit Name		Description			
	0	Zero speed		1 = Drive is running at zero speed			
	1	Forward		1 = Drive is running in forward direction above zero speed limit (par. 21.06)			
	2	Reverse		1 = Drive is running in reverse direction above zero speed limit (par. 21.06)			
	3	Out of window		1 = Speed error window control active (see	1 = Speed error window control active (see par. 24.41)		
	4	Internal speed feedback		1 = Estimated speed feedback used in motor control, i.e. estimated speed is selected by par. 90.41 or 90.46, or selected encoder has faulted (par. 90.45)			
				0 = Encoder 1 or 2 is used for speed feedback.			
	5	Encoder 1 feedback		1 = Encoder 1 used for speed feedback in motor control 0 = Encoder 1 faulted or not selected as source of speed feedback (see par. 90.41 and 90.46)			
				1 = Encoder 2 used for speed feedback in motor control			
	6	Encoder 2 feedback		0 = Encoder 2 faulted or not selected as source of speed feedback (see par. 90.41 and 90.46)			
	7	Any constant speed request		1 = A constant speed or frequency has been selected; see par. 06.20.			
	8	Follower speed corr min lim		1 = Minimum limit of speed correction (in a speed-controlled follower) has been reached (see par. 23.3923.41).			
	9	Follower speed corr max lim		1 = Maximum limit of speed correction (in a speed-controlled follower) has been reached (see par. 23.3923.41).			
	1015	Reserved		· · · · · · · · · · · · · · · · · · ·			
	0000hFFFFh		Speed control status word.		1 = 1		
06.20	Constant speed status word		Constant speed/frequency status word. Indicates which constant speed or frequency is active (if any). See also parameter 06.19 Speed control status word, bit 7, and section Constant speeds/frequencies (page 85).  This parameter is read-only.		-		
			Description				
	0	Constant s		1 = Constant speed or frequency 1 selected			
	1		•	= Constant speed or frequency 1 selected  = Constant speed or frequency 2 selected			
	2	·		1 = Constant speed or frequency 3 selected			
		•					
	3	·		= Constant speed or frequency 4 selected			
	4	' '		= Constant speed or frequency 5 selected			
	5	-		= Constant speed or frequency 6 selected			
	6	· ·		= Constant speed or frequency 7 selected			
	715	Reserved					
	00006		Constant speed/frequency status word.		1 - 1		
	0000h	rrrn	Constant spe	eed/frequency status word.	1 = 1		

No.	Name	<b>Value</b>	Description		Def/FbEq
06.21	p s		constant spe parameter 0 section Cons	eed/frequency status word. Indicates which eed or frequency is active (if any). See also 6.19 Speed control status word, bit 7, and stant speeds/frequencies (page 85). eter is read-only.	-
	Bit	Name		Description	
	0	DC hold ac	tive	1 = DC hold is active (see par. 21.08)	
	1	Post-magnetizing active		1 = Post-magnetizing is active (see par. 21.08)	
	2	Motor pre-heating active		1 = Motor pre-heating is active (see par 21.08)	
	3	PM smooth start active		Reserved.	
	4	Rotor position known		1 = Rotor position has been determined (autophasing n needed). See section <i>Autophasing</i> (page 101).	
	415	5 Reserved		, , , ,	
	0000hFFFFh		Constant speed/frequency status word. 1 = 1		1 = 1
06.25	word 2		Drive inhibit status word 2. This word specifies the source of the inhibiting signal that is preventing the drive from starting.  After the con bit specific notes.		-
	(		See also parameters 06.18 Start inhibit status word and 06.16 Drive status word 1, bit 1.		
			ı nıs parame	eter is read-only.	
	Bit	Name	Description	on	No
	0	Follower drive	1 = A follow	wer drive is preventing the master from starting.	а
	1 Application		1 = The ap	1 = The application program is preventing the drive from starting.	
	2	Reserved	•		
			A The second of a dhead configuration is present to the		

Bit	Name	Description	Note
0	Follower drive	1 = A follower drive is preventing the master from starting.	а
1	Application	1 = The application program is preventing the drive from starting.	b
2	Reserved		
3	Encoder feedback	1 = The encoder feedback configuration is preventing the drive from starting.	а
4	Ref source parametrization	1 = A reference source parametrization conflict is preventing the drive from starting. See warning <i>A6DA Reference source</i> parametrization (page <i>603</i> ).	b
515	Reserved		

Notes	Notes:			
а	If bit 1 of 06.16 Drive status word 1 is still set after the removal of the inhibiting condition, and edge triggering is selected for the active external control location, a fresh rising-edge start signal is required. See parameters 20.02, 20.07 and 20.19.			
	If bit 1 of 06.16 Drive status word 1 is still set after the removal of the inhibiting condition, a fresh rising-edge start signal is required.			

	0000hFFFFh	Start inhibit status word 2.	1 = 1
06.29	MSW bit 10 sel	Selects a binary source whose status is transmitted as bit 10 of 06.11 Main status word.	Above limit
	False	0.	0
	True	1.	1
	Above limit	Bit 10 of 06.17 Drive status word 2 (see page 176).	2
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 156).	-

No. Name/Value		Description	Def/FbEq16	
06.30	MSW bit 11 sel	Selects a binary source whose status is transmitted as bit 11 of 06.11 Main status word.	Ext ctrl loc	
	False	0.	0	
	True	1.	1	
	Ext ctrl loc	Bit 11 of 06.01 Main control word (see page 174).	2	
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-	
06.31	MSW bit 12 sel	Selects a binary source whose status is transmitted as bit 12 of 06.11 Main status word.	Ext run enable	
	False	0.	0	
	True	1.	1	
	Ext run enable	Inverted bit 5 of 06.18 Start inhibit status word (see page 177).	2	
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-	
06.32	MSW bit 13 sel	Selects a binary source whose status is transmitted as bit 13 of 06.11 Main status word.	False	
	False	0.	0	
	True	1.	1	
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-	
06.33	MSW bit 14 sel	Selects a binary source whose status is transmitted as bit 14 of 06.11 Main status word.	False	
	False	0.	0	
	True	1.	1	
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-	

36	Name/\	/alue	Description	Def/FbEq16				
	LSU Status Word		(Visible only when supply unit control is activated by 95.20) Shows the status of the supply unit. See also section Control of a supply unit (LSU) on page 83), and parameter group 60 DDCS communication. This parameter is read-only.	-				
	Bit Name Description							
	0	Ready on	1 = Ready to switch on					
	1	Ready run	1 = Ready to operate, DC link charged					
	2	Ready ref	1 = Operation enabled					
	3	Tripped	1 = A fault is active					
	46	Reserved						
	7	Alarm	1 = A warning is active					
	8	Modulating	1 = The supply unit is modulating					
	9	Remote	1 = Remote control (EXT1 or EXT2) 0 = Local control					
	10	Net ok	1 = Supply network voltage OK					
	1112	Reserved	•					
	13	Charging or ready run	1 = Bit 1 or bit 14 active					
	14	Charging	1 = Charging contactor closed 0 = Charging contactor open					
	15							
	0000h	.FFFFh	Supply unit status word.	1 = 1				
			Shows the control word sent to the supply unit from the INU-LSU (inverter unit/supply unit) state machine.  This parameter is read-only.					
	Bit	Name	Description					
	0	ON/OFF	1 = Start charging					
		014/011	0 = Open main contactor (switch power off)					
	1	OFF 2						
	2		0 = Open main contactor (switch power off)  0 = Emergency stop (Off2)  0 = Emergency stop (Off3)					
		OFF 2	0 = Open main contactor (switch power off) 0 = Emergency stop (Off2)					
	2	OFF 2 OFF 3	0 = Open main contactor (switch power off)  0 = Emergency stop (Off2)  0 = Emergency stop (Off3)  1 = Start modulating					
	2	OFF 2 OFF 3 START	0 = Open main contactor (switch power off)  0 = Emergency stop (Off2)  0 = Emergency stop (Off3)  1 = Start modulating	uired after				
	2 3 46	OFF 2 OFF 3 START Reserved	0 = Open main contactor (switch power off)  0 = Emergency stop (Off2)  0 = Emergency stop (Off3)  1 = Start modulating  0 = Stop modulating  0 -> 1 = Reset an active fault. A fresh start command is requ	uired after				
	2 3 46 7	OFF 2 OFF 3 START  Reserved RESET	0 = Open main contactor (switch power off)  0 = Emergency stop (Off2)  0 = Emergency stop (Off3)  1 = Start modulating  0 = Stop modulating  0 -> 1 = Reset an active fault. A fresh start command is requireset.	iired after				
	2 3 46 7 811	OFF 2 OFF 3 START Reserved RESET Reserved	0 = Open main contactor (switch power off)  0 = Emergency stop (Off2)  0 = Emergency stop (Off3)  1 = Start modulating  0 = Stop modulating  0 -> 1 = Reset an active fault. A fresh start command is requireset.  See parameter .	uired after				
	2 3 46 7 811	OFF 2 OFF 3 START  Reserved RESET  Reserved USER BIT 0	0 = Open main contactor (switch power off)  0 = Emergency stop (Off2)  0 = Emergency stop (Off3)  1 = Start modulating  0 = Stop modulating  0 -> 1 = Reset an active fault. A fresh start command is requreset.  See parameter .  See parameter .	uired after				
	2 3 46 7 811 12	OFF 2 OFF 3 START  Reserved RESET  Reserved USER BIT 0 USER BIT 1 USER BIT 2	0 = Open main contactor (switch power off)  0 = Emergency stop (Off2)  0 = Emergency stop (Off3)  1 = Start modulating  0 = Stop modulating  0 -> 1 = Reset an active fault. A fresh start command is requreset.  See parameter .  See parameter .	uired after				
	2 3 46 7 811 12 13 14	OFF 2 OFF 3 START  Reserved RESET  Reserved USER BIT 0 USER BIT 1 USER BIT 2 USER BIT 3	0 = Open main contactor (switch power off)  0 = Emergency stop (Off2)  0 = Emergency stop (Off3)  1 = Start modulating  0 = Stop modulating  0 -> 1 = Reset an active fault. A fresh start command is requreset.  See parameter .  See parameter .  See parameter .	uired after				
40	2 3 46 7 811 12 13 14 15	OFF 2 OFF 3 START  Reserved RESET  Reserved USER BIT 0 USER BIT 1 USER BIT 2 USER BIT 3	0 = Open main contactor (switch power off)  0 = Emergency stop (Off2)  0 = Emergency stop (Off3)  1 = Start modulating  0 = Stop modulating  0 -> 1 = Reset an active fault. A fresh start command is requreset.  See parameter .  See parameter .  See parameter .  See parameter .  See parameter .					

No.	Name/Value	Description	Def/FbEq16
	True	1.	1
	MCW user bit 0	Bit 12 of 06.01 Main control word (see page 174).	2
	MCW user bit 1	Bit 13 of 06.01 Main control word (see page 174).	3
	MCW user bit 2	Bit 14 of 06.01 Main control word (see page 174).	4
	MCW user bit 3	Bit 15 of 06.01 Main control word (see page 174).	5
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
06.41	LSU CW user bit 1 selection	(Visible only when supply unit control is activated by 95.20) Selects a binary source whose status is transmitted as bit 13 of 06.39 Internal state machine LSU CW to the supply unit.	MCW user bit 1
	False	0.	0
	True	1.	1
	MCW user bit 0	Bit 12 of 06.01 Main control word (see page 174).	2
	MCW user bit 1	Bit 13 of 06.01 Main control word (see page 174).	3
	MCW user bit 2	Bit 14 of 06.01 Main control word (see page 174).	4
	MCW user bit 3	Bit 15 of 06.01 Main control word (see page 174).	5
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
06.42	LSU CW user bit 2 selection	(Visible only when supply unit control is activated by 95.20) Selects a binary source whose status is transmitted as bit 14 of 06.39 Internal state machine LSU CW to the supply unit.	MCW user bit 2
	False	0.	0
	True	1.	1
	MCW user bit 0	Bit 12 of 06.01 Main control word (see page 174).	2
	MCW user bit 1	Bit 13 of 06.01 Main control word (see page 174).	3
	MCW user bit 2	Bit 14 of 06.01 Main control word (see page 174).	4
	MCW user bit 3	Bit 15 of 06.01 Main control word (see page 174).	5
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
06.43	LSU CW user bit 3 selection	(Visible only when supply unit control is activated by 95.20) Selects a binary source whose status is transmitted as bit 15 of 06.39 Internal state machine LSU CW to the supply unit.	MCW user bit 3
	False	0.	0
	True	1.	1
	MCW user bit 0	Bit 12 of 06.01 Main control word (see page 174).	2
	MCW user bit 1	Bit 13 of 06.01 Main control word (see page 174).	3
	MCW user bit 2	Bit 14 of 06.01 Main control word (see page 174).	4
	MCW user bit 3	Bit 15 of 06.01 Main control word (see page 174).	5
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-

No.	Name/Value	Description	Def/FbEq16		
06.45	Follower CW user bit 0 selection	Selects a binary source whose status is transmitted as bit 12 of the Follower control word to follower drives. (Bits 011 of the Follower control word are taken from 06.01 Main control word.)	MCW user bit 0		
		See also section Master/follower functionality (page 74).			
	False	0.	0		
	True	1.	1		
	MCW user bit 0	Bit 12 of 06.01 Main control word (see page 174).	2		
	MCW user bit 1	Bit 13 of 06.01 Main control word (see page 174).	3		
	MCW user bit 2	Bit 14 of 06.01 Main control word (see page 174).	4		
	MCW user bit 3	Bit 15 of 06.01 Main control word (see page 174).	5		
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-		
06.46	Follower CW user bit 1 selection				
	False	0.	0		
	True	1.			
	MCW user bit 0	er bit 0 Bit 12 of 06.01 Main control word (see page 174).			
	MCW user bit 1	Bit 13 of 06.01 Main control word (see page 174).	3		
	MCW user bit 2	Bit 14 of 06.01 Main control word (see page 174).	4		
	MCW user bit 3	Bit 15 of 06.01 Main control word (see page 174).	5		
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-		
06.47	Follower CW user bit 2 selection	Selects a binary source whose status is transmitted as bit 14 of the Follower control word to follower drives. (Bits 011 of the Follower control word are taken from 06.01 Main control word.)	MCW user bit 2		
	False	0.	0		
	True	1.	1		
	MCW user bit 0	Bit 12 of 06.01 Main control word (see page 174).	2		
	MCW user bit 1	Bit 13 of 06.01 Main control word (see page 174).	3		
	MCW user bit 2	Bit 14 of 06.01 Main control word (see page 174).	4		
	MCW user bit 3	Bit 15 of 06.01 Main control word (see page 174).	5		
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 156).	-		
06.48	Follower CW user bit 3 selection	Selects a binary source whose status is transmitted as bit 15 of the Follower control word to follower drives. (Bits 011 of the Follower control word are taken from 06.01 Main control word.)	MCW user bit 3		
	False	0.	0		
	True	1.	1		
	MCW user bit 0	Bit 12 of 06.01 Main control word (see page 174).	2		
	MCW user bit 1	Bit 13 of 06.01 Main control word (see page 174).	3		
	MCW user bit 2	Bit 14 of 06.01 Main control word (see page 174).	4		

True

1.

No.	Name/Value		Descripti	Description	
	MCW user bit 3		Bit 15 of (	Bit 15 of 06.01 Main control word (see page 174).	
	Other [	bit]	Source se 156).	election (see Terms and abbreviations on page	-
06.50	Users	tatus word 1	binary so	ned status word. This word shows the status of the urces selected by parameters 06.6006.75. meter is read-only.	-
	Bit	Name		Description	
	0 User statu		s bit 0	Status of source selected by parameter <i>06.60</i>	
	1	User statu	s bit 1	Status of source selected by parameter <i>06.61</i>	
	15	User statu	s bit 15	Status of source selected by parameter <i>06.75</i>	
	0000h	FFFFh	User-defi	ned status word.	1 = 1
06.60		tatus word 1			False
00.00	bit 0 se			binary source whose status is shown as bit 0 of er status word 1.	raise
	False		0.	0.	
	True		1.		1
	Other [bit] Source selection (see Terms and abbreviations on page 156).			-	
06.61	User status word 1 bit 1 sel			binary source whose status is shown as bit 1 of er status word 1.	Out of window
	False		0.		0
	True		1.		1
	Out of window		Bit 3 of 06	6.19 Speed control status word (see page 178).	2
	Other [bit]		Source selection (see <i>Terms and abbreviations</i> on page 156).		-
06.62	User status word 1 bit 2 sel			binary source whose status is shown as bit 2 of er status word 1.	Emergency stop failed
	False		0.		0
	True		1.		1
	Emergency stop		Bit 8 of 06	6.17 Drive status word 2 (see page 176).	2
	Other [	bit]	Source se page 156	election (see <i>Terms and abbreviations</i> on ).	-
06.63	User st	tatus word 1	Selects a binary source whose status is shown as bit 3 of 06.50 User status word 1.		Magnetized
	False		0.		0
	True		1.		1
	Magnetized		Bit 1 of 00	6.17 Drive status word 2 (see page 176).	2
	Other [			election (see <i>Terms and abbreviations</i> on	-
06.64	User st	tatus word 1		binary source whose status is shown as bit 4 of er status word 1.	Run disable
	False		0.		0
					<del> </del>

1

No.	Name/Value	Description	Def/FbEq16
	Run disable	Bit 5 of 06.18 Start inhibit status word (see page 177).	2
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
06.65	User status word 1 bit 5 sel	Selects a binary source whose status is shown as bit 5 of 06.50 User status word 1.	False
	False	0.	0
	True	1.	1
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
06.66	User status word 1 bit 6 sel	Selects a binary source whose status is shown as bit 6 of 06.50 User status word 1.	False
	False	0.	0
	True	1.	1
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
06.67	User status word 1 bit 7 sel	Selects a binary source whose status is shown as bit 7 of 06.50 User status word 1.	Identification run done
	False	0.	0
	True	1.	1
	Identification run done	Bit 0 of 06.17 Drive status word 2 (see page 176).	2
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
06.68	User status word 1 bit 8 sel	Selects a binary source whose status is shown as bit 8 of 06.50 User status word 1.	Start inhibition
	False	0.	0
	True	1.	1
	Start inhibition	Bit 7 of 06.18 Start inhibit status word (see page 177).	2
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
06.69	User status word 1 bit 9 sel	Selects a binary source whose status is shown as bit 9 of 06.50 User status word 1.	Limiting
	False	0.	0
	True	1.	1
	Limiting	Bit 7 of 06.16 Drive status word 1 (see page 175).	2
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
06.70	User status word 1 bit 10 sel	Selects a binary source whose status is shown as bit 10 of 06.50 User status word 1.	Torque control
	False	0.	0
	True	1.	1
	Torque control	Bit 2 of 06.17 Drive status word 2 (see page 176).	2
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-

No.	Name/Value	Description	Def/FbEq16	
06.71	User status word 1 bit 11 sel	Selects a binary source whose status is shown as bit 11 of 06.50 User status word 1.	Zero speed	
	False	0.	0	
	True	1.	1	
	Zero speed	Bit 0 of 06.19 Speed control status word (see page 178).	2	
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-	
06.72	User status word 1 bit 12 sel	Selects a binary source whose status is shown as bit 12 of 06.50 User status word 1.	Internal speed feedback	
	False	0.	0	
	True	1.	1	
	Internal speed feedback	Bit 4 of 06.19 Speed control status word (see page 178).	2	
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-	
06.73	User status word 1 bit 13 sel	Selects a binary source whose status is shown as bit 13 of 06.50 User status word 1.	False	
	False	0.	0	
	True	1.	1	
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-	
06.74	User status word 1 bit 14 sel	Selects a binary source whose status is shown as bit 14 of 06.50 User status word 1.	False	
	False	0.	0	
	True	1.	1	
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-	
06.75	User status word 1 bit 15 sel	Selects a binary source whose status is shown as bit 15 of 06.50 User status word 1.	False	
	False	0.	0	
	True	1.	1	
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-	
06.100	User control word 1	User-defined control word 1.	-	
	Bit Name	Description		

Bit	Name	Description		
0	User control word 1 bit 0	User-defined bit.		
1	User control word 1 bit 1	User-defined bit.		
15	User control word 1 bit 15	User-defined bit.		

0000hFFFFh	User-defined control word 1.	1 = 1

1 = 1

No.	Name/V	'alue	Description			Def/FbEq16
06.101	User co	ntrol word 2	User-defined	User-defined control word 2.		-
	Bit	Name			Description	
	0	User contro	ol word 2 bit 0		User-defined bit.	
	1	User contro	ol word 2 bit 1		User-defined bit.	
	15	User contro	ol word 2 bit 1	5	User-defined bit.	
	0000h	.FFFFh	User-defined	d control word 2.		1 = 1
06.116	LSU drive status word 1		(Visible only when IGBT supply unit control is activated by 95.20) Drive status word 1 received from the supply unit. See also section <i>Control of a supply unit (LSU)</i> (page 83), and parameter group 60 DDCS communication. This parameter is read-only.		-	
	Bit	Name		Description		
	0	Enabled		1 = Run enable	and start enable signals are pre	esent
	1	Inhibited		1 = Start inhibited		
	2	Operation a	allowed	1 = Drive is ready to operate		
	3	Ready to s	tart	1 = Drive is ready to receive a start command		
	4	Running		1 = Drive is ready to follow given reference 1 = Drive has been started		
	5	Started				
	6	Modulating			dulating (output stage is being o	ontrolled)
	7	Limiting	_		ng limit is active	
	8	Local contr	<del>-</del> .	1 = Drive is in local control		
	9	Network co		1 = Drive is in network control		
	10	Ext1 active		1 = Control location Ext1 active 1 = Control location Ext2 active		
	11 12	Ext2 active		_		
	13	Charging re	tiay	1 = Charging re		
	1415	MCB relay Reserved		1 = MCB relay	is ciused	
	1415	Reserved				

Drive status word 1.

0000h...FFFFh

No.	Name/Value	Descriptio	n	Def/FbEq16			
06.118	LSU start inhibit status word	95.20) This word so is preventing See also so and param	y when IGBT supply unit control is activated by specifies the source of the inhibiting condition that any the supply unit from starting. ection Control of a supply unit (LSU) (page 83), eter group 60 DDCS communication. eter is read-only.	-			
	Bit Name						
		0	0 Not ready run				
		1					
		2	SSW inhibit				
		3	Fault reset				
		4	Lost start enable				
		5	Lost run enable				
		68	Reserved				
		9	Charging overload				
		1011	Reserved				
		12	Em Off2				
		13	Em Off3				
		14	Auto reset inhibit				
		15	Reserved				
	0000hFFFFh	Start inhibit	t status word of supply unit.	1 = 1			

07 Sys	stem info	Drive hardware and firmware information. All parameters in this group are read-only.	
07.03	Drive rating id	Type of the drive/inverter unit.	-
07.04	Firmware name Firmware identification. The format is AINFX, where X denotes the control unit type (2 or B = BCU-x2, 6 or C = ZCU-12/14).		-
07.05	Firmware version	Version number of the firmware.  The format is A.BB.C.D, where A = major version, B = minor version, C = patch (ie. firmware variant code), D = 0.	-
07.06	Loading package name	Name of the firmware loading package. The format is AINLX, where X denotes the control unit type (2 or B = BCU-x2, 6 or C = ZCU-12/14).	-
07.07	Loading package version	Version number of the firmware loading package.	-
07.08	Bootloader version	Version number of the firmware bootloader.	-
07.11	Cpu usage	Microprocessor load in percent.	-
	0100%	Microprocessor load.	1 = 1%
07.13	PU logic version number	Version number of the power unit logic.	-
07.15	FPGA logic version number	Version number of the FPGA logic of the control unit.	-

No.	Name/V	Name/Value		on		Def/FbE	q16
07.21	Applicat environi status 1	ment	programm Shows wh See the Di	ability]) ich tasks of rive (IEC 61	the application the application program are running.  131-3) application programming  7808 [English])	-	
	Bit	Name			Description		
	0	Pre task			1 = Pre-task running.		
	1	Appl task	<b>c</b> 1		1 = Task 1 running.		
	2	Appl task			1 = Task 2 running.		
	3	Appl task			1 = Task 3 running.		
	414	Reserve					
	15	Task mo	nitoring		1 = Task monitoring enabled.		
	0000h	FFFFh	Application	n program ta	ack etatue	1 = 1	
07.22	Applicat environi status 2	ment	programm Shows the See the Di	ability]) status of the rive (IEC 61	en +N8010 [application] e openings in the application program. 131-3) application programming 7808 [English]).	-	
	Bit Name			Description			
	0	Opening1		Status of opening 1 in the application program.			
	1	Opening2		Status of opening 2 in the application program.			
	15	Opening16	Status of opening 16 in the application program.				
	0000h	.FFFFh	Application	Application program opening status.			
07.23	Application name (Visible or programm First five A program is			ability])  SCII letters the programmer info on the PC tool.	on +N8010 [application  of the name given to the application mming tool. The full name is visible the control panel or the Drive	-	
07.24	programmability]) Application program program in the program			<i>ability])</i> n program ven the prograr	ersion number given to the application mming tool. Also visible under System lel or the Drive composer PC tool.	-	
07.25	Customization package name  First five customiz System it tool.		customiza System inf	tion package o on the cor	of the name given to the e. The full name is visible under ntrol panel or the Drive composer PC	-	
07.26	Custom package	ization e version			e version number. Also visible under ntrol panel or the Drive composer PC	-	

No.	Name/Va	alue	Descript	ion	Def/FbEq16	
07.30	07.30 Adaptive program status			e status of the adaptive program. on <i>Adaptive programming</i> (page 67).	-	
	Bit	Name		Description		
	0	Initialized		1 = Adaptive program initialized		
	1	Editing		1 = Adaptive program is being edited		
	2 Edit done			1 = Editing of adaptive program finished		
	3	Running		1 = Adaptive program running		
	413	Reserved				
	14	State chang	ging	Reserved		
	15	Faulted		1 = Error in adaptive program		
	0000h	FFFFh	Adaptive	program status.	1 = 1	
07.40	IFC appl	ication Cnu		nly with option +N8010 [application	_	
	IEC application Cpu usage peak		programn Displays the applic be used t functiona internal q The value	nability]) the peak loading of the microprocessor caused by cation program. This parameter can, for example, o check the effect of a given application program lity on the CPU load. The value is in percent of an		
	0.0 100	0.0%	Peak mic program.	Peak microprocessor loading caused by application program.		
07.41	IEC application Cpu load average		programn Displays	the average loading of the microprocessor caused plication program. The value is in percent of an	-	
	0.0 100	0.0%	Average program.	microprocessor loading caused by application	10 = 1%	
07.51	Slot 1 op module	otion	Displays control ur	the type of module detected in slot 1 of the drive nit.	No option	
	No optio	n	No modu	le detected.	0	
	[module	type]	Type of m	nodule detected.	-	
07.52	Slot 2 op module	otion	Displays control ur	the type of module detected in slot 2 of the drive nit.	No option	
	No optio	n	No modu	le detected.	0	
	[module	type]	Type of m	nodule detected.	-	
07.53	Slot 3 op	otion	Displays control ur	the type of module detected in slot 3 of the drive nit.	No option	
	No optio	n	No modu	le detected.	0	
	[module		Type of m	nodule detected.	-	
07.106			(Visible o 95.20)	nly when IGBT supply unit control is activated by the loading package of the supply unit firmware.	-	

No.	Name/Value	Description	Def/FbEq16
07.107	LSU loading package version	((Visible only when IGBT supply unit control is activated by 95.20)  Version number of the loading package of the supply unit firmware.	-

	9 Winder actual ignals	Actual signals of the winder control program.	
0	9.01 Winder status word	Winder status word	0b0000

Bit	Name	Description
0	Roll end	0 = Partial roll 1 = Roll diameter equals full roll
1	Unwinding	0 = Wind mode is activated 1 = Unwind mode is activated
2	Motor direction negative	0 = Speed reference is not reversed 1 = Speed reference is reversed
3	Torque reference negative	0 = Torque reference positive 1 = Torque reference negative
4	Torque memory active	0 = Torque memory is not active 1 = Torque memory is activated
5	Winder stall active	0 = Stall tension is not active 1 = Stall tension is activated
6	PID controller is ON	0 = PID controller off 1 = PID controller on
7	Web loss detected	0 = No web loss detected 1 = Web loss detected
8	Diameter hold active	0 = Diameter hold is not active 1 = Diameter hold is activated
9	Threading now	0 = Threading line speed reference is not active 1 = Threading line speed reference is activated
10	Tension is ON	0 = Tension control is not active 1 = Tension control is activated
1114	Reserved	
15	Simulation mode active	0 = Simulation mode is not active 1 = Simulation mode is activated


	0b0000 0b111111	Winder status word	1 = 1
09.02	Drive control state	Displays drive operation status.	DRIVE_NOT _ READY
	DRIVE_NOT_ READY	Drive is not ready for operation.	0
	ID_RUN_UNDONE	Motor identification (ID) run has not been performed.	1
	DRIVE_STOPPED	Drive is stopped.	2
	FAULT_ACTIVE	A fault is active.	3
	LOCAL_CONTROL	Drive is in Local control.	4


No.	Name/Value	Description	Def/FbEq16	
	JOG_MODE	Jogging enable signal is On.	5	
	EXT1_RUNNING	Control location EXT1 is active.	6	
	EXT2_RUNNING	Control location EXT2 is active.	7	
	STOPPING	Drive is stopping.	8	
	EM_STOP_ACTIVE	An emergency stop command signal is active, or the drive is stopping after receiving an emergency stop command.	9	
09.03	Actual tension ctrl mode	Displays the active tension control mode.	Open loop	
	Open loop	Open loop tension control is active.	0	
	Tension torque trim	Tension control with torque trim is active.	1	
	Tension speed trim	Tension control with speed trim is active.	2	
	Dancer speed trim	Dancer control with speed trim is active.	3	
	Line speed control	Line speed control is active.	4	
	Threading	Threading is active.	8	
	Torque memory	Torque memory is active.	9	
	Not active	None of the tension control modes are active.	10	
09.11	Actual diameter	Displays the actual filtered diameter.	0.0 mm	
	0.032767.0 mm	Actual filtered diameter.	10 = 1 mm	
09.12	Actual diameter %	Displays the actual diameter in percent of the full roll.	0.00%	
	0.00100.00%	Actual diameter in percent of the full roll.	100 = 1%	
09.13	Diameter ratio	Displays ratio of the core to the actual diameter.	0.0000	
	0.0000 1.00000	Ratio of core to actual diameter.	10000 = 1	
09.14	Diameter ratio inversed	Displays the diameter ratio inversed.	0.00	
	1.00 100.00	Inversed ratio of the actual diameter to the core.	100 = 1	
09.21	Estimated length	Displays total length of the material wound on the roll estimated from the actual diameter with regard to the defined material properties (in parameter group 74 Application setup).	0.0 m	
	0.0 100000.0 m	Estimated length.	10 = 1 m	
09.25	Roll estimated weight	Displays total weight of the material wound on the roll estimated from the actual diameter with regard to the defined material properties (in parameter group 74 Application setup).	0.0 kg	
	0.0 32767.0 kg	Estimated roll weight.	10 = 1 kg	
09.31	Actual tension	Displays the actual tension based on the unit selected in parameter 77.91 Tension measure selection.	0.0 N	
	0.032767.0 N	Actual tension.	10 = 1 N	
09.36	Torque trim	Displays torque reference correction term used in Torque- trim tension control mode (parameter 77.02 Tension control mode = Tension torque trim). The reference sign is chosen automatically based on settings in parameters 74.05 Winding mode and 74.06 Motor direction.	0.00%	
	-100.00 100.00%	Torque trim from the tension control.	100 = 1%	

No.	Name/Value	Description	Def/FbEq16
09.37	Speed trim	Displays speed reference correction term used for Tension speed trim and Dancer speed trim control modes set in parameter 77.02 Tension control mode. The control program interprets the trimmed PI control output as motor speed correction factor in rpm. The reference sign is chosen automatically based on settings in parameters 74.05 Winding mode and 74.06 Motor direction.	0.0 rpm
	-1000.0 1000.0 rpm	Speed reference correction term.	10 = 1 rpm
09.41	Load model torque ref	Displays cumulative torque reference generated by the application load model based on tension reference, effect of estimated inertia and friction.	0.000 Nm
	-32767.000 32767.000 Nm		1000 = 1 Nm
09.42	Tension torque demand	Displays torque reference component coming from currently used tension reference.	0.000 Nm
	-32767.000 32767.000 Nm		1000 = 1 Nm
09.43	Friction compensation torque	Displays frictional compensation torque (static + dynamic).	0.000 Nm
	-32767.000 32767.000 Nm	Frictional compensation torque.	1000 = 1 Nm
09.44	Inertia compensation torque	Displays additional torque reference generated by the inertia compensation function.	0.000 Nm
	-32767.000 32767.000 Nm	Additional torque reference.	1000 = 1 Nm

10 Standard DI, RO	Configuration of digital inputs and relay outputs.	
10.01 DI status	Displays electrical status of digital inputs DIIL and DI6DI1. The activation/deactivation delays of the inputs (if any are specified) are ignored.  Bits 05 reflect the status of DI1DI6; bit 15 reflects the status of the DIIL input. <b>Example:</b> 100000000010011b = DIIL, DI5, DI2 and DI1 are on, DI3, DI4 and DI6 are off. This parameter is read-only.	-
0000hFFFFh	Status of digital inputs.	1 = 1
10.02 DI delayed status	Displays status of digital inputs DIIL and DI6DI1. This word is updated only after activation/deactivation delays (if any are specified). A filtering time can be defined by parameter 10.51 DI filter time.  Bits 05 reflect the delayed status of DI1DI6; bit 15 reflects the delayed status of the DIIL input.  This parameter is read-only.	-
0000hFFFFh	Delayed status of digital inputs.	1 = 1

No.	Name/Value		P/Value Description	
10.03	DI force	selection	The electrical statuses of the digital inputs can be overridden for e.g., testing purposes. A bit in parameter 10.04 DI force data is provided for each digital input, and its value is applied whenever the corresponding bit in this parameter is 1.	0000h
	Bit	Value		
	0	1 = Force [	DI1 to value of bit 0 of parameter 10.04 DI force data.	
	1	1 = Force D	DI2 to value of bit 1 of parameter 10.04 DI force data.	
	2	1 = Force [	DI3 to value of bit 2 of parameter 10.04 DI force data.	
	3	1 = Force [	DI4 to value of bit 3 of parameter 10.04 DI force data.	
	4		DI5 to value of bit 4 of parameter 10.04 DI force data.	
	5	1 = Force [	DI6 to value of bit 5 of parameter 10.04 DI force data.	
	614	Reserved		
	15	1 = Force [	OIL to value of bit 15 of parameter 10.04 DI force data.	
	00001			4 4
	0000h		Override selection for digital inputs.	1 = 1
10.04 DI force data		data	Contains the values that the digital inputs are forced to when selected by 10.03 DI force selection.  Bit 0 is the forced value for DI1; bit 15 is the forced value for the DIIL input.	0000h
	0000h	FFFFh	Forced values of digital inputs.	1 = 1
10.05	DI1 ON	delay	Defines activation delay for digital input DI1.	0.0 s
	**Delaye	*DI status — ed DI status —		1
	$t_{\rm Off} = 10.0$	5 DI1 ON dela 6 DI1 OFF del status of digita		
	**Indicated by 10.02 DI			
	0.0 30	000.0 s	Activation delay for DI1.	10 = 1 s
10.06 DI1 OFF delay 0.0 3000.0 s		delay	Defines deactivation delay for digital input DI1. See parameter 10.05 DI1 ON delay.	0.0 s





No.	Name/Value	ame/Value Description	
10.15	DI6 ON delay	Defines the activation delay for digital input DI6.	0.0 s
	*DI status —		1 0
	**Delayed DI status — —	$t_{\mathrm{On}}$ $t_{\mathrm{Off}}$ $t_{\mathrm{On}}$ $t_{\mathrm{Off}}$	1 0 Time
	$t_{\rm On}$ = 10.15 DI6 ON delated to the total status of digitation and the total status of the the total status of the total	lay al input. Indicated by 10.01 DI status.	
	0.0 3000.0 s	Activation delay for DI6.	10 = 1 s
10.16	DI6 OFF delay	Defines the deactivation delay for digital input DI6. See parameter 10.15 DI6 ON delay.	0.0 s
	0.0 3000.0 s	Deactivation delay for DI6.	10 = 1 s
10.21	RO status	Status of relay outputs RO8RO1. <b>Example:</b> 00000001b = RO1 is energized, RO2RO8 are de-energized.	-
	0000hFFFFh	Status of relay outputs.	1 = 1
10.24	RO1 source	Selects a drive signal to be connected to relay output RO1.	Ready run
	Not energized	Output is not energized.	0
	Energized	Output is energized.	1
	Ready run	Bit 1 of 06.11 Main status word (see page 175).	2
	Enabled	Bit 0 of 06.16 Drive status word 1 (see page 175).	4
	Started	Bit 5 of 06.16 Drive status word 1 (see page 175).	5
	Magnetized	Bit 1 of 06.17 Drive status word 2 (see page 176).	6
	Running	Bit 6 of 06.16 Drive status word 1 (see page 175).	7
	Ready ref	Bit 2 of 06.11 Main status word (see page 175).	8
	At setpoint	Bit 8 of 06.11 Main status word (see page 175).	9
	Reverse	Bit 2 of 06.19 Speed control status word (see page 178).	10
	Zero speed	Bit 0 of 06.19 Speed control status word (see page 178).	11
	Above limit	Bit 10 of 06.11 Main status word (see page 175).	12
	Warning	Bit 7 of 06.11 Main status word (see page 175).	13
	Fault	Bit 3 of 06.11 Main status word (see page 175).	14
	Fault (-1)	Inverted bit 3 of 06.11 Main status word (see page 175).	15
	Start request	Bit 13 of 06.16 Drive status word 1 (see page 175).	16
	Open brake command	Bit 0 of 44.01 Brake control status (see page 372).	22
	Ext2 active	Bit 11 of 06.16 Drive status word 1 (see page 175).	23
	Remote control	Bit 9 of 06.11 Main status word (see page 175).	24
	Supervision 1	Bit 0 of 32.01 Supervision status (see page 326).	33
	Supervision 2	Bit 1 of 32.01 Supervision status (see page 326).	34

No.	Name/Value	Description	Def/FbEq16
	Supervision 3	Bit 2 of 32.01 Supervision status (see page 326).	35
	RO/DIO control word bit0	Bit 0 of 10.99 RO/DIO control word (see page 199).	40
	RO/DIO control word bit1	Bit 1 of 10.99 RO/DIO control word (see page 199).	41
	RO/DIO control word bit2	Bit 2 of 10.99 RO/DIO control word (see page 199).	42
	RO/DIO control word bit8	Bit 8 of 10.99 RO/DIO control word (see page 199).	43
	RO/DIO control word bit9	Bit 9 of 10.99 RO/DIO control word (see page 199).	44
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
10.25	RO1 ON delay	Defines the activation delay for relay output RO1.	0.0 s
	Status of selected source		1 0
	RO status		1 0
	- 10.25 BO1 ON do	$\langle \cdot \rangle$ $\langle \cdot $	Time
	$t_{\text{On}} = 10.25 \text{ RO1 ON de} $ $t_{\text{Off}} = 10.26 \text{ RO1 OFF de}$	elay	
	0.0 3000.0 s	Activation delay for RO1.	10 = 1 s
10.26	RO1 OFF delay	Defines the deactivation delay for relay output RO1. See parameter 10.25 RO1 ON delay.	0.0 s
	0.0 3000.0 s	Deactivation delay for RO1.	10 = 1 s
10.27	RO2 source	Selects a drive signal to be connected to relay output RO2. For the available selections, see parameter 10.24 RO1 source.	Running
10.28	RO2 ON delay	Defines the activation delay for relay output RO2.	0.0 s
	Status of selected source		0
	RO status —		1 0
		$t_{\text{On}}$ $t_{\text{Off}}$ $t_{\text{On}}$ $t_{\text{Off}}$	Time
	$t_{\text{On}}$ = 10.28 RO2 ON de $t_{\text{Off}}$ = 10.29 RO2 OFF d	lay elay	
	0.0 3000.0 s	Activation delay for RO2.	10 = 1 s
10.29	RO2 OFF delay	Defines the deactivation delay for relay output RO2. See parameter 10.28 RO2 ON delay.	0.0 s
		parameter 10.201102 off delay.	

No.	Name/Va	lue	Description	Def/FbEq16
10.30	RO3 soul	rce	Selects a drive signal to be connected to relay output RO3. For the available selections, see parameter 10.24 RO1 source.	Fault (-1)
10.31	RO3 ON	delay	Defines the activation delay for relay output RO3.	0.0 s
	Status	of selected source		1 0
		RO status		1 ──── 0 ──────────────────────────────
	$t_{\rm On} = 10.33$ $t_{\rm Off} = 10.32$	1 RO3 ON del 2 RO3 OFF de	$t_{ m On}$ $t_{ m Off}$ $t_{ m On}$ $t_{ m Off}$ ay elay	
	0.0 30	00.0 s	Activation delay for RO3.	10 = 1 s
10.32	RO3 OFF	delay	Defines the deactivation delay for relay output RO3. See parameter 10.31 RO3 ON delay.	0.0 s
	0.0 30	00.0 s	Deactivation delay for RO3.	10 = 1 s
10.51	DI filter ti	me	Defines a filtering time for parameter 10.01 DI status.	10.0 ms
	0.3 10	0.0 ms	Filtering time for 10.01.	10 = 1 ms
10.99			Storage parameter for controlling the relay outputs and digital input/outputs e.g. through the embedded fieldbus interface.  To control the relay outputs (RO) and the digital input/outputs (DIO) of the drive, send a control word with the bit assignments shown below as Modbus I/O data. Set the target selection parameter of that particular data (58.10158.124) to RO/DIO control word. In the source selection parameter of the desired output, select the appropriate bit of this word.	0000h
	Bit	Name	Description	
	0	RO1	Source bits for relay outputs RO1RO3 (see parameters 1	0.24, 10.27
	1	RO2	and <i>10.30</i> ).	
	2	RO3		
	37	Reserved		
	8	DIO1	Source bits for digital input/outputs DIO1DIO3 (see paran and 11.10).	neters 11.06
	9	DIO2	and 11.10J.	
	1015	Reserved		1
	0000hF	FFFFh	RO/DIO control word.	1 = 1

No.	Name/Value	Description	Def/FbEq16
11 Sta	andard DIO, FI, FO	Configuration of digital input/outputs and frequency inputs/outputs.	
11.01	DIO status	Displays status of digital input/outputs DIO1 and DIO2. The activation/deactivation delays (if any are specified) are ignored. A filtering time (for input mode) can be defined by parameter 11.81 DIO filter time.  Example: 0010 = DIO2 is on, DIO1 is off. This parameter is read-only.	-
	0000b0011b	Status of digital input/outputs.	1 = 1
11.02	DIO delayed status	Displays delayed status of digital input/outputs DIO1 and DIO2. This word is updated only after activation/deactivation delays (if any are specified). A filtering time (for input mode) can be defined by parameter 11.81 DIO filter time.  Example: 0010 = DIO2 is on, DIO1 is off. This parameter is read-only.	-
	0000b0011b	Delayed status of digital input/outputs.	1 = 1
11.05	DIO1 function	Selects whether DIO1 is used as a digital output or input, or a frequency input.	Output
	Output	DIO1 is used as a digital output.	0
	Input	DIO1 is used as a digital input.	1
	Frequency	DIO1 is used as a frequency input.	2
11.06	DIO1 output source	Selects a drive signal to be connected to digital input/output DIO1 when parameter 11.05 DIO1 function is set to Output.	Ready run
	Not energized	Output is off.	0
	Energized	Output is on.	1
	Ready run	Bit 1 of 06.11 Main status word (see page 175).	2
	Enabled	Bit 0 of 06.16 Drive status word 1 (see page 175).	4
	Started	Bit 5 of 06.16 Drive status word 1 (see page 175).	5
	Magnetized	Bit 1 of 06.17 Drive status word 2 (see page 176).	6
	Running	Bit 6 of 06.16 Drive status word 1 (see page 175).	7
	Ready ref	Bit 2 of 06.11 Main status word (see page 175).	8
	At setpoint	Bit 8 of 06.11 Main status word (see page 175).	9
	Reverse	Bit 2 of 06.19 Speed control status word (see page 178).	10
	Zero speed	Bit 0 of 06.19 Speed control status word (see page 178).	11
	Above limit	Bit 10 of 06.11 Main status word (see page 175).	12
	Warning	Bit 7 of 06.11 Main status word (see page 175).	13
	Fault	Bit 3 of 06.11 Main status word (see page 175).	14
	Fault (-1)	Inverted bit 3 of 06.11 Main status word (see page 175).	15
	Start request	Bit 13 of 06.16 Drive status word 1 (see page 175).	16
	Open brake command	Bit 0 of 44.01 Brake control status (see page 372).	22
	Ext2 active	Bit 11 of 06.16 Drive status word 1 (see page 175).	23
	Remote control	Bit 9 of 06.11 Main status word (see page 175).	24
	Supervision 1	Bit 0 of 32.01 Supervision status (see page 326).	33
	Supervision 2	Bit 1 of 32.01 Supervision status (see page 326).	34

No.	Name/Value	Description	Def/FbEq16
	Supervision 3	Bit 2 of 32.01 Supervision status (see page 326).	35
	RO/DIO control word bit0	Bit 0 of 10.99 RO/DIO control word (see page 199).	40
	RO/DIO control word bit1	Bit 1 of 10.99 RO/DIO control word (see page 199).	41
	RO/DIO control word bit2	Bit 2 of 10.99 RO/DIO control word (see page 199).	42
	RO/DIO control word bit8	Bit 8 of 10.99 RO/DIO control word (see page 199).	43
	RO/DIO control word bit9	Bit 9 of 10.99 RO/DIO control word (see page 199).	44
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
11.07	DIO1 ON delay	Defines the activation delay for digital input/output DIO1 (when used as a digital output or digital input).	0.0 s
	*DIO status —  **Delayed DIO status		1 — 0 1
	t <sub>On</sub> = 11.07 DIO1 ON de	$ \cdot $	0 Time
	$t_{\rm Off} = 11.08  DIO1  OFF  de$	elay (in input mode) or status of selected source (in output mode). Indicated b	y 11.01 DIO
	0.0 3000.0 s	Activation delay for DIO1.	10 = 1 s
11.08	DIO1 OFF delay	Defines the deactivation delay for digital input/output DIO1 (when used as a digital output or digital input). See parameter 11.07 DIO1 ON delay.	0.0 s
	0.0 3000.0 s	Deactivation delay for DIO1.	10 = 1 s
11.09	DIO2 function	Selects whether DIO2 is used as a digital output or input, or a frequency output.	Output
	Output	DIO2 is used as a digital output.	0
	Input	DIO2 is used as a digital input.	1
	Frequency	DIO2 is used as a frequency output.	2
11.10	DIO2 output source	Selects a drive signal to be connected to digital input/output DIO2 when parameter 11.09 DIO2 function is set to Output. For the available selections, see parameter 11.06 DIO1 output source.	Running

No.	Name/Value	Description	Def/FbEq16
11.11	DIO2 ON delay	Defines the activation delay for digital input/output DIO2 (when used as a digital output or digital input).	0.0 s
	*DIO status —		1 0
	**Delayed DIO status — —	++++++++++++++++++++++++++++++++++++	$ \begin{array}{c} 1 \\ \hline  & 0 \\ \hline  & Time \end{array} $
	t <sub>On</sub> = 11.11 DIO2 ON de t <sub>Off</sub> = 11.12 DIO2 OFF of *Electrical status of DIO status. **Indicated by 11.02 DIO	oy 11.01 DIO	
	0.0 3000.0 s	Activation delay for DIO2.	10 = 1 s
11.12	DIO2 OFF delay	Defines the deactivation delay for digital input/output DIO2 (when used as a digital output or digital input). See parameter 11.11 DIO2 ON delay.	0.0 s
	0.0 3000.0 s	Deactivation delay for DIO2.	10 = 1 s
11.38	Freq in 1 actual value	Displays value of frequency input 1 (via DIO1 when it is used as a frequency input) before scaling. See parameter 11.42 Freq in 1 min. This parameter is read-only.	-
	0 16000 Hz	Unscaled value of frequency input 1.	1 = 1 Hz
11.39	Freq in 1 scaled	Displays value of frequency input 1 (via DIO1 when it is used as a frequency input) after scaling. See parameter 11.42 Freq in 1 min. This parameter is read-only.	-
	-32768.000 32767.000	Scaled value of frequency input 1.	1 = 1

No.	Name/Value	Description	Def/FbEq16
11.42	Freq in 1 min	Defines the minimum for the frequency actually arriving at frequency input 1 (DIO1 when it is used as a frequency input).  The incoming frequency signal (11.38 Freq in 1 actual value) is scaled into an internal signal (11.39 Freq in 1 scaled) by parameters 11.4211.45 as follows:  11.45  11.44  11.44  11.45  11.48	0 Hz
	0 16000 Hz	Minimum frequency of frequency input 1 (DIO1).	1 = 1 Hz
11.43	Freq in 1 max	Defines the maximum for the frequency actually arriving at frequency input 1 (DIO1 when it is used as a frequency input). See parameter 11.42 Freq in 1 min.	16000 Hz
	0 16000 Hz	Maximum frequency for frequency input 1 (DIO1).	1 = 1 Hz
11.44	Freq in 1 at scaled min	Defines the value that is required to correspond internally to the minimum input frequency defined by parameter 11.42 Freq in 1 min. See diagram at parameter 11.42 Freq in 1 min.	0.000
	-32768.000 32767.000	Value corresponding to minimum of frequency input 1.	1 = 1
11.45	Freq in 1 at scaled max	Defines the value that is required to correspond internally to the maximum input frequency defined by parameter 11.43  Freq in 1 max. See diagram at parameter 11.42 Freq in 1 min.	1500.000
	-32768.000 32767.000	Value corresponding to maximum of frequency input 1.	1 = 1
11.54	Freq out 1 actual value	Displays value of frequency output 1 after scaling. See parameter 11.58 Freq out 1 src min. This parameter is read-only.	-
	0 16000 Hz	Value of frequency output 1.	1 = 1
11.55	Freq out 1 source	Selects a signal to be connected to frequency output 1.	Motor speed used
	Zero	None.	0
	Motor speed used	01.01 Motor speed used (page 160).	1
	Output frequency	01.06 Output frequency (page 160).	3
	Motor current	01.07 Motor current (page 160).	4
	Motor torque	01.10 Motor torque (page 160).	6

No.	Name/Value	Description	Def/FbEq16
	DC voltage	01.11 DC voltage (page 160).	7
	Power inu out	01.14 Output power (page 161).	8
	Speed ref ramp in	23.01 Speed ref ramp input (page 268).	10
	Speed ref ramped	23.02 Speed ref ramp output (page 268).	11
	Speed ref used	24.01 Used speed reference (page 274).	12
	Torq ref used	26.02 Torque reference used (page 290).	13
	Freq ref used	28.02 Frequency ref ramp output (page 298).	14
	Process PID out	40.01 Process PID output actual (page 355).	16
	Process PID fbk	40.02 Process PID feedback actual (page 355).	17
	Process PID act	40.03 Process PID setpoint actual (page 355).	18
	Process PID dev	40.04 Process PID deviation actual (page 356).	19
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
11.58	Freq out 1 src min	Defines the real value of the signal (selected by parameter 11.55 Freq out 1 source and shown by parameter 11.54 Freq out 1 actual value) that corresponds to the minimum value of frequency output 1 (defined by parameter 11.60 Freq out 1 at src min.  11.54  11.58  11.59  Signal (real) selected by par. 11.55  11.60  11.60	0.000
		11.59 11.58 Signal (real) selected by par. 11.55	
	-32768.000 32767.000	Real signal value corresponding to minimum value of frequency output 1.	1 = 1

No.	Name/Value	Description	Def/FbEq16
11.59	Freq out 1 src max	Defines the real value of the signal (selected by parameter 11.55 Freq out 1 source and shown by parameter 11.54 Freq out 1 actual value) that corresponds to the maximum value of frequency output 1 (defined by parameter 11.61 Freq out 1 at src max). See parameter 11.58 Freq out 1 src min.	1500.000
	-32768.000 32767.000	Real signal value corresponding to maximum value of frequency output 1.	1 = 1
11.60	Freq out 1 at src min	Defines the minimum value of frequency output 1. See diagrams at parameter 11.58 Freq out 1 src min.	0 Hz
	016000 Hz	Minimum value of frequency output 1.	1 = 1 Hz
11.61	Freq out 1 at src max	Defines the maximum value of frequency output 1. See diagrams at parameter 11.58 Freq out 1 src min.	16000 Hz
	016000 Hz	Maximum value of frequency output 1.	1 = 1 Hz
11.81	DIO filter time	Defines a filtering time for parameter 11.01 DIO status and 11.02 DIO delayed status. The filtering time affects only the DIOs that are in input mode.	10.0 ms
	0.3100.0 ms	Filtering time for 11.01.	10 = 1 ms
12 Sta	andard Al	Configuration of standard analog inputs.	
12.01	Al tune	Triggers the analog input tuning function.	

12 Standard AI		Configuration of standard analog inputs.	
12.01	AI tune	Triggers the analog input tuning function. Connect the signal to the input and select the appropriate tuning function.	
	No action	Al tune is not activated.	0
	Al1 min tune	Current analog input Al1 signal value is set as minimum value of Al1 into parameter 12.17 Al1 min. The value reverts back to No action automatically.	1
	Al1 max tune	Current analog input AI1 signal value is set as maximum value of AI1 into parameter 12.18 AI1 max. The value reverts back to No action automatically.	2
	Al2 min tune	Current analog input Al2 signal value is set as minimum value of Al2 into parameter 12.27 Al2 min. The value reverts back to No action automatically.	3
	Al2 max tune	Current analog input Al2 signal value is set as maximum value of Al2 into parameter 12.28 Al2 max. The value reverts back to No action automatically.	4
12.03	AI supervision function	Selects how the drive reacts when an analog input signal moves out of the minimum and/or maximum limits specified for the input.  The supervision applies a margin of 0.5 V or 1.0 mA to the limits. For example, if the maximum limit for the input is 7.000 V, the maximum limit supervision activates at 7.500 V. The inputs and the limits to be observed are selected by parameter 12.04 Al supervision selection.  Note: Analog input signal supervision is only active when  • the analog input is set as the source (using the Al1 scaled or Al2 scaled selection) in parameter 22.11, 22.12, 22.15, 22.17, 23.42, 26.11, 26.12, 26.16, 26.25, 28.11, 28.12, 30.21, 30.22, 40.16, 40.17, 40.50, 41.16, 41.17, 41.50 or 44.09, and  • is being used as the active source.	No action
	No action	No action taken.	0
	Fault	Drive trips on 80A0 AI supervision.	1

lo.	Name/	Value	Description	Def/FbEq16
	Warnin	g	Drive generates an A8A0 AI supervision warning.	2
	Last speed  Speed ref safe		Drive generates a warning (A8A0 AI supervision) and freezes the speed (or frequency) to the level the drive was operating at. The speed/frequency is determined on the basis of actual speed using 850 ms low-pass filtering.  WARNING! Make sure that it is safe to continue operation in case of a communication break.	3
			Drive generates a warning (A8A0 AI supervision) and sets the speed to the speed defined by parameter 22.41 Speed ref safe (or 28.41 Frequency ref safe when frequency reference is being used).  WARNING! Make sure that it is safe to continue operation in case of a communication break.	
2.04	Al supe selection		Specifies the analog input limits to be supervised. See parameter 12.03 Al supervision function.	0000b
	Bit	Name	Description	
	0	AI1 < MIN	1 = Minimum limit supervision of Al1 active.	
	1	AI1 > MAX	•	
	2	Al2 < MIN	1 = Minimum limit supervision of Al2 active.	
	3	Al2 > MAX	1 = Maximum limit supervision of Al2 active.	
	415	Reserved		
	0000b.	1111b	Activation of analog input supervision.	1 = 1
2.05	7 ii dape	ervision force	Activates analog input supervision separately for each control location (see section <i>Local control vs. external control</i> on page <i>40</i> ).  The parameter is primarily intended for analog input supervision when the input is connected to the application program and not selected as a control source by drive parameters.	0000 0000b
	Bit	Name	Description	
	0	Al1 Ext1	1 = Al1 supervision is active when EXT1 is used.	
	1	Al1 Ext2	1 = Al1 supervision is active when EXT2 is used.	
	2	Al1 Local	1 = Al1 supervision is active when local control is used	
	3	Reserved		
	4	Al2 Ext1	1 = Al2 supervision is active when EXT1 is used.	
	5	Al2 Ext2	1 = Al2 supervision is active when EXT2 is used.	
	6	Al2 Local	1 = Al2 supervision is active when local control is used	
	715	Reserved		
	0000 0 0111 0	000b 111b	Analog input supervision selection.	1 = 1
2.11	AI1 act	ual value	Displays value of analog input Al1 in mA or V (depending on whether the input is set to current or voltage by a hardware setting).  This parameter is read-only.	-
	-22.000 22 mA or V		Value of analog input Al1.	1000 = 1 mA or V

No.	Name/Value	Description	Def/FbEq16
12.12	Al1 scaled value	Displays value of analog input Al1 after scaling. See parameters 12.19 Al1 scaled at Al1 min and 12.20 Al1 scaled at Al1 max.  This parameter is read-only.	-
	-32768.000 32767.000	Scaled value of analog input AI1.	1 = 1
12.15	Al1 unit selection	Selects the unit for readings and settings related to analog input Al1. <b>Note:</b> This setting must match the corresponding hardware setting on the drive control unit (see the hardware manual of the drive). Control board reboot (either by cycling the power or through parameter 96.08 Control board boot) is required to validate any changes in the hardware settings.	V
L	V	Volts.	2
	mA	Milliamperes.	10
12.16	All filter time	Defines the filter time constant for analog input Al1.  "Unfiltered signal  100  63  Filtered signal   O = I × (1 - e <sup>-t/T</sup> )  I = filter input (step) O = filter output t = time T = filter time constant  Note: The signal is also filtered due to the signal interface hardware (approximately 0.25 ms time constant). This cannot be changed by any parameter.	0.100 s
12.17	0.000 30.000 s	Filter time constant.  Defines the minimum site value for analog input Al1.  Set the value actually sent to the drive when the analog signal from plant is wound to its minimum setting.	1000 = 1 s 0.000 mA or V
		See also parameter 12.01 Al tune.	
	-22.000 22.000 mA or V	Minimum value of Al1.	1000 = 1 mA or V
12.18	Al1 max	Defines the maximum site value for analog input AI1. Set the value actually sent to the drive when the analog signal from plant is wound to its maximum setting. See also parameter 12.01 AI tune.	20.000 mA or 10.000 V
	-22.000 22.000 mA or V	Maximum value of Al1.	1000 = 1 mA or V

No.	Name/Value	Description	Def/FbEq16
12.19	Al1 scaled at Al1 min	Defines the real internal value that corresponds to the minimum analog input Al1 value defined by parameter 12.17 Al1 min. (Changing the polarity settings of 12.19 and 12.20 can effectively invert the analog input.)  Al <sub>scaled</sub> (12.12)  12.17  Al <sub>in</sub> (12.11)	0.000
	-32768.000 32767.000	Real value corresponding to minimum Al1 value.	1 = 1
12.20	Al1 scaled at Al1 max	Defines the real internal value that corresponds to the maximum analog input Al1 value defined by parameter 12.18 Al1 max. See the drawing at parameter 12.19 Al1 scaled at Al1 min.	1500.000; 1800.000 (95.20 b0)
	-32768.000 32767.000	Real value corresponding to maximum Al1 value.	1 = 1
12.21	AI2 actual value	Displays value of analog input Al2 in mA or V (depending on whether the input is set to current or voltage by a hardware setting).  This parameter is read-only.	-
	-22.000 22.000 mA or V	Value of analog input Al2.	1000 = 1 mA or V
12.22	AI2 scaled value	Displays value of analog input Al2 after scaling. See parameters 12.29 Al2 scaled at Al2 min and 12.30 Al2 scaled at Al2 max.  This parameter is read-only.	-
	-32768.000 32767.000	Scaled value of analog input Al2.	1 = 1
12.25	Al2 unit selection	Selects the unit for readings and settings related to analog input AI2.  Note: This setting must match the corresponding hardware setting on the drive control unit (see the hardware manual of the drive). Control board reboot (either by cycling the power or through parameter 96.08 Control board boot) is required to validate any changes in the hardware settings.	mA
	V	Volts.	2
	mA	Milliamperes.	10
12.26	Al2 filter time	Defines the filter time constant for analog input Al2. See parameter 12.16 Al1 filter time.	0.100 s
	0.000 30.000 s	Filter time constant.	1000 = 1 s

0

1

3

4

Name/Value	Description	Def/FbEq16
AI2 min	Defines the minimum site value for analog input Al2. Set the value actually sent to the drive when the analog signal from plant is wound to its minimum setting. See also parameter 12.01 Al tune.	0.000 mA or V
-22.000 22.000 mA or V	Minimum value of AI2.	1000 = 1 mA or V
Al2 max	Defines the maximum site value for analog input Al2. Set the value actually sent to the drive when the analog signal from plant is wound to its maximum setting. See also parameter 12.01 Al tune.	20.000 mA or 10.000 V
-22.000 22.000 mA or V	Maximum value of Al2.	1000 = 1 mA or V
Al2 scaled at Al2 min	Defines the real value that corresponds to the minimum analog input Al2 value defined by parameter 12.27 Al2 min. (Changing the polarity settings of 12.29 and 12.30 can effectively invert the analog input.)  Al <sub>scaled</sub> (12.22)  12.27  Al <sub>in</sub> (12.21)	0.000
-32768.000 32767.000	Real value corresponding to minimum Al2 value.	1 = 1
Al2 scaled at Al2 max	Defines the real value that corresponds to the maximum analog input Al2 value defined by parameter 12.28 Al2 max. See the drawing at parameter 12.29 Al2 scaled at Al2 min.	100.000
-32768.000 32767.000	Real value corresponding to maximum Al2 value.	1 = 1
ndard AO	Configuration of standard analog outputs.	
AO1 actual value	Displays value of AO1 in mA. This parameter is read-only.	-
0.000 22.000 mA	Value of AO1.	1000 = 1 mA
AO1 source	Selects a signal to be connected to analog output AO1. Alternatively, sets the output to excitation mode to feed a constant current to a temperature sensor.	Motor speed used
	-22.000 22.000 mA or V  Al2 max  -22.000 22.000 mA or V  Al2 scaled at Al2 min  -32768.000 32767.000  Al2 scaled at Al2 max  -32768.000 32767.000  AO1 actual value  0.000 22.000 mA	Defines the minimum site value for analog input Al2. Set the value actually sent to the drive when the analog signal from plant is wound to its minimum setting. See also parameter 12.01 Al tune.  -22.000 22.000 Minimum value of Al2.  Defines the maximum site value for analog input Al2. Set the value actually sent to the drive when the analog signal from plant is wound to its maximum setting. See also parameter 12.01 Al tune.  Maximum value of Al2.  Defines the real value that corresponds to the minimum analog input Al2 value defined by parameter 12.27 Al2 min. (Changing the polarity settings of 12.29 and 12.30 can effectively invert the analog input.)  Al <sub>scaled</sub> (12.22)  12.30  Al <sub>scaled</sub> (12.22)  12.30  Al <sub>scaled</sub> (12.22)  12.30  Al <sub>scaled</sub> (12.22)  12.30  Real value corresponding to minimum Al2 value.  32767.000  Real value corresponding to maximum analog input Al2 value defined by parameter 12.28 Al2 max. See the drawing at parameter 12.29 Al2 scaled at Al2 min.  Real value corresponding to maximum Al2 value.  32767.000  Real value corresponding to maximum Al2 value.  Displays value of AO1 in mA. This parameter is read-only.  O.000 22.000 mA  Value of AO1.  AO1 source  Selects a signal to be connected to analog output AO1. Alternatively, sets the output to excitation mode to feed a

Zero

Motor speed used

Output frequency

Motor current

None.

01.01 Motor speed used (page 160).

01.06 Output frequency (page 160).

01.07 Motor current (page 160).

No.	Name/Value	Description	Def/FbEq16
	Motor torque	01.10 Motor torque (page 160).	6
	DC voltage	01.11 DC voltage (page 160).	7
	Power inu out	01.14 Output power (page 161).	8
	Speed ref ramp in	23.01 Speed ref ramp input (page 268).	10
	Speed ref ramp out	23.02 Speed ref ramp output (page 268).	11
	Speed ref used	24.01 Used speed reference (page 274).	12
	Torq ref used	26.02 Torque reference used (page 290).	13
	Freq ref used	28.02 Frequency ref ramp output (page 298).	14
	Process PID out	40.01 Process PID output actual (page 355).	16
	Process PID fbk	40.02 Process PID feedback actual (page 355).	17
	Process PID act	40.03 Process PID setpoint actual (page 355).	18
	Process PID dev	40.04 Process PID deviation actual (page 356).	19
	Force PT100 excitation	The output is used to feed an excitation current to 13 Pt100 sensors. See section <i>Motor thermal protection</i> (page 122).	20
	Force KTY84 excitation	The output is used to feed an excitation current to a KTY84 sensor. See section <i>Motor thermal protection</i> (page 122).	21
	Force PTC excitation	The output is used to feed an excitation current to 13 PTC sensors. See section <i>Motor thermal protection</i> (page 122).	22
	Force Pt1000 excitation	The output is used to feed an excitation current to 13 Pt1000 sensors. See section <i>Motor thermal protection</i> (page 122).	23
	AO1 data storage	13.91 AO1 data storage (page 213).	37
	AO2 data storage	13.92 AO2 data storage (page 213).	38
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
13.16	AO1 filter time	Defines the filtering time constant for analog output AO1.  "Unfiltered signal  Filtered signal  T  O = I × (1 - e <sup>-t/T</sup> )  I = filter input (step) O = filter output t = time T = filter time constant	0.100 s
	0.000 30.000 s	Filter time constant.	1000 = 1 s

No.	Name/Value	Description	Def/FbEq16
13.17	AO1 source min	Defines the real minimum value of the signal (selected by parameter 13.12 AO1 source) that corresponds to the minimum required AO1 output value (defined by parameter 13.19 AO1 out at AO1 src min).  IAO1 (mA)  13.19  13.17  13.18  Signal (real) selected by 13.12  Programming 13.17 as the maximum value and 13.18 as the minimum value inverts the output.  IAO1 (mA)  13.20  13.19  3.17  Signal (real) selected by 13.12	0.0
	-32768.0 32767.0	Real signal value corresponding to minimum AO1 output value.	1 = 1
13.18	AO1 source max	Defines the real maximum value of the signal (selected by parameter 13.12 AO1 source) that corresponds to the maximum required AO1 output value (defined by parameter 13.20 AO1 out at AO1 src max). See parameter 13.17 AO1 source min.	1500.0; 1800.0 (95.20 b0)
	-32768.0 32767.0	Real signal value corresponding to maximum AO1 output value.	1 = 1
13.19	AO1 out at AO1 src min	Defines the minimum output value for analog output AO1. See also drawing at parameter 13.17 AO1 source min.	0.000 mA
	0.000 22.000 mA	Minimum AO1 output value.	1000 = 1 mA
13.20	AO1 out at AO1 src max	Defines the maximum output value for analog output AO1. See also drawing at parameter 13.17 AO1 source min.	20.000 mA
	0.000 22.000 mA	Maximum AO1 output value.	1000 = 1 mA

No.	Name/Value	Description	Def/FbEq16
13.21	AO2 actual value	Displays value of AO2 in mA. This parameter is read-only.	-
	0.000 22.000 mA	Value of AO2.	1000 = 1 mA
13.22	AO2 source	Selects a signal to be connected to analog output AO2. Alternatively, sets the output to excitation mode to feed a constant current to a temperature sensor. For the selections, see parameter 13.12 AO1 source.	Motor current
13.26	AO2 filter time	Defines the filtering time constant for analog output AO2. See parameter 13.16 AO1 filter time.	0.100 s
	0.000 30.000 s	Filter time constant.	1000 = 1 s
13.27	AO2 source min	Defines the real minimum value of the signal (selected by parameter 13.22 AO2 source) that corresponds to the minimum required AO2 output value (defined by parameter 13.29 AO2 out at AO2 src min).  I <sub>AO2</sub> (mA)  13.27  13.28  Signal (real) selected by 13.22  Programming 13.27 as the maximum value and 13.28 as the minimum value inverts the output.  I <sub>AO2</sub> (mA)  13.30	0.0
		13.28 13.27 Signal (real) selected by 13.22	
	-32768.0 32767.0	Real signal value corresponding to minimum AO2 output value.	1 = 1

13.28 AO2 so		·	Def/FbEq16
70.20	urce max	Defines the real maximum value of the signal (selected by parameter 13.22 AO2 source) that corresponds to the maximum required AO2 output value (defined by parameter 13.30 AO2 out at AO2 src max). See parameter 13.27 AO2 source min.	100.0
-32768. 32767.0		Real signal value corresponding to maximum AO2 output value.	1 = 1
13.29 AO2 ou min	t at AO2 src	Defines the minimum output value for analog output AO2. See also drawing at parameter 13.27 AO2 source min.	0.000 mA
0.000	. 22.000 mA	Minimum AO2 output value.	1000 = 1 mA
13.30 AO2 ou max	t at AO2 src	Defines the maximum output value for analog output AO2. See also drawing at parameter 13.27 AO2 source min.	20.000 mA
0.000	. 22.000 mA	Maximum AO2 output value.	1000 = 1 mA
13.91 AO1 da	ta storage	Storage parameter for controlling analog output AO1 e.g. through fieldbus.  In 13.12 AO1 source, select AO1 data storage. Then set this parameter as the target of the incoming value data.  With the embedded fieldbus interface, simply set the target selection parameter of that particular data (58.10158.124) to AO1 data storage.	0.00
-327.68	327.67	Storage parameter for AO1.	100 = 1
13.92 AO2 da	ta storage	Storage parameter for controlling analog output AO2 e.g. through fieldbus.  In 13.22 AO2 source, select AO2 data storage. Then set this parameter as the target of the incoming value data.  With the embedded fieldbus interface, simply set the target selection parameter of that particular data (58.10158.124) to AO2 data storage.	0.00
-327.68	327.67	Storage parameter for AO2.	100 = 1
14 I/O extension	on module	Configuration of I/O extension module 1. See also section <i>Programmable I/O extensions</i> (page 72). <b>Note:</b> The contents of the parameter group vary according to the selected I/O extension module type.	
14.01 Module	1 type	Activates (and specifies the type of) I/O extension module 1. <b>Note:</b> This parameter cannot be changed while the drive is running.	None
None		Inactive.	0
FIO-01		FIO-01.	1
FIO-11		FIO-11.	2
FDIO-0	1	FDIO-01.	3
FAIO-0	1	FAIO-01.	4
14.02 Module	1 location	Specifies slots (13) on the control unit of the drive into which the I/O extension module is installed. Also specifies the node ID of the slot on the FEA-03 extension adapter.  Note: This parameter cannot be changed while the drive is running.	Slot 1
Slot 1		Slot 1.	1
Slot 2		Slot 2.	2
Slot 3		Slot 3.	3

No.	Name/Value	Description	Def/FbEq16
	4254	Node ID of the slot on the FEA-03 extension adapter.	1 = 1
14.03	Module 1 status	Displays status of I/O extension module 1.	No option
	No option	No module detected in the specified slot.	0
	No communication	A module has been detected but cannot be communicated with.	1
	Unknown	The module type is unknown.	2
	FIO-01	An FIO-01 module has been detected and is active.	15
	FIO-11	An FIO-11 module has been detected and is active.	20
	FAIO-01	An FAIO-01 module has been detected and is active.	24
14.05	DI status	(Visible when 14.01 Module 1 type = FDIO-01) Displays status of the digital inputs on the extension module. The activation/deactivation delays (if any are specified) are ignored. A filtering time (for input mode) can be defined by parameter 14.08 DI filter time. Bit 0 indicates the status of DI1.  Note: The number of active bits in this parameter depends on the number of digital input/outputs on the extension module.  Example: 0101b = DI1 and DI3 are on, remainder are off. This parameter is read-only.	-
	0000b1111b	Status of digital inputs.	1 = 1
14.05	DIO status	(Visible when 14.01 Module 1 type = FIO-01 or FIO-11) Displays status of the digital input/outputs on the extension module. The activation/deactivation delays (if any are specified) are ignored. A filtering time (for input mode) can be defined by parameter 14.08 DIO filter time.  Bit 0 indicates the status of DIO1.  Note: The number of active bits in this parameter depends on the number of digital input/outputs on the extension module.  Example: 1001b = DIO1 and DIO4 are on, remainder are off.  This parameter is read-only.	-
	0000b1111b	Status of digital input/outputs.	1 = 1
14.06	DI delayed status	(Visible when 14.01 Module 1 type = FDIO-01) Displays delayed status of the digital inputs on the extension module. The word is updated only after activation/deactivation delays (if any are specified). Bit 0 indicates the status of DI1.  Note: The number of active bits in this parameter depends on the number of digital inputs on the extension module.  Example: 0101b = DI1 and DI3 are on, remainder are off. This parameter is read-only.	-
		1	1

No.	Name/Value	Description	Def/FbEq16
14.06	DIO delayed status	(Visible when 14.01 Module 1 type = FIO-01 or FIO-11) Displays status of the digital input/outputs on the extension module. This word is updated only after activation/deactivation delays (if any are specified). Bit 0 indicates the status of DIO1.  Note: The number of active bits in this parameter depends on the number of digital input/outputs on the extension module.  Example: 1001b = DIO1 and DIO4 are on, remainder are off. This parameter is read-only.	-
	0000b1111b	Delayed status of digital input/outputs.	1 = 1
14.08	DI filter time	(Visible when 14.01 Module 1 type = FDIO-01) Defines a filtering time for parameter 14.05 DI status and 14.06 DI delayed status	10.0 ms
	0.8 100.0 ms	Filtering time for 14.05.	10 = 1 ms
14.08	DIO filter time	(Visible when 14.01 Module 1 type = FIO-01 or FIO-11)  Defines a filtering time for parameter 14.05 DIO status and 14.06 DIO delayed status. The filtering time will only affect the DIOs that are in input mode.	10.0 ms
	0.8 100.0 ms	Filtering time for 14.05.	10 = 1 ms
14.09	DIO1 function	(Visible when 14.01 Module 1 type = FIO-01 or FIO-11) Selects whether DIO1 of the extension module is used as a digital input or output.	Input
	Output	DIO1 is used as a digital output.	0
	Input	DIO1 is used as a digital input.	1
14.11	DIO1 output source	(Visible when 14.01 Module 1 type = FIO-01 or FIO-11) Selects a drive signal to be connected to digital input/output DIO1 of the extension module when parameter 14.09 DIO1 function is set to Output.	Not energized
	Not energized	Output is not energized.	0
	Energized	Output is energized.	1
	Ready run	Bit 1 of 06.11 Main status word (see page 175).	2
	Enabled	Bit 0 of 06.16 Drive status word 1 (see page 175).	4
	Started	Bit 5 of 06.16 Drive status word 1 (see page 175).	5
	Magnetized	Bit 1 of 06.17 Drive status word 2 (see page 176).	6
	Running	Bit 6 of 06.16 Drive status word 1 (see page 175).	7
	Ready ref	Bit 2 of 06.11 Main status word (see page 175).	8
	At setpoint	Bit 8 of 06.11 Main status word (see page 175).	9
	Reverse	Bit 2 of 06.19 Speed control status word (see page 178).	10
	Zero speed	Bit 0 of 06.19 Speed control status word (see page 178).	11
	Above limit	Bit 10 of 06.11 Main status word (see page 175).	12
	Warning	Bit 7 of 06.11 Main status word (see page 175).	13
	Fault	Bit 3 of 06.11 Main status word (see page 175).	14
	Fault (-1)	Inverted bit 3 of 06.11 Main status word (see page 175).	15
	Start request	Bit 13 of 06.16 Drive status word 1 (see page 175).	16

No.	Name/Value	Description	Def/FbEq16
	Open brake command	Bit 0 of 44.01 Brake control status (see page 372).	22
	Ext2 active	Bit 11 of 06.16 Drive status word 1 (see page 175).	23
	Remote control	Bit 9 of 06.11 Main status word (see page 175).	24
	Supervision 1	Bit 0 of 32.01 Supervision status (see page 326).	33
	Supervision 2	Bit 1 of 32.01 Supervision status (see page 326).	34
	Supervision 3	Bit 2 of 32.01 Supervision status (see page 326).	35
	RO/DIO control word bit0	Bit 0 of 10.99 RO/DIO control word (see page 199).	40
	RO/DIO control word bit1	Bit 1 of 10.99 RO/DIO control word (see page 199).	41
	RO/DIO control word bit2	Bit 2 of 10.99 RO/DIO control word (see page 199).	42
	RO/DIO control word bit8	Bit 8 of 10.99 RO/DIO control word (see page 199).	43
	RO/DIO control word bit9	Bit 9 of 10.99 RO/DIO control word (see page 199).	44
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
14.12	DI1 ON delay	(Visible when 14.01 Module 1 type = FDIO-01) Defines the activation delay for digital input DI1.	0.00 s
	*DI status —		0
	**Delayed DI status —		0
	_	$t_{\text{On}}$ $t_{\text{Off}}$ $t_{\text{On}}$ $t_{\text{Off}}$	Time
	$t_{\rm On}$ = 14.12 DI1 ON dela $t_{\rm Off}$ = 14.13 DI1 OFF de *Electrical status of DI c **Indicated by 14.06 DI	<i>lay</i> or status of selected source (in output mode). Indicated by <i>14.05 DI statu</i>	us.
	0.00 3000.00 s	Activation delay for DI1.	10 = 1 s

No.	Name/Value	Description	Def/FbEq16
14.12	DIO1 ON delay	(Visible when 14.01 Module 1 type = FIO-01 or FIO-11) Defines the activation delay for digital input/output DIO1.	0.00 s
	*DIO status —		1 0 1
	**Delayed DIO status	$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	0 > <sub>Time</sub>
	$t_{\rm On}$ = 14.12 DIO1 ON de $t_{\rm Off}$ = 14.13 DIO1 OFF de *Electrical status of DIO status. **Indicated by 14.06 DIO	elay (in input mode) or status of selected source (in output mode). Indicated b	oy 14.05 DIO
	0.00 3000.00 s	Activation delay for DIO1.	100 = 1 s
14.13	DI1 OFF delay	(Visible when 14.01 Module 1 type = FDIO-01) Defines the deactivation delay for digital input DI1. See parameter 14.12 DI1 ON delay.	0.00 s
	0.00 3000.00 s	Deactivation delay for DI1.	10 = 1 s
14.13	DIO1 OFF delay	(Visible when 14.01 Module 1 type = FIO-01 or FIO-11) Defines the deactivation delay for digital input/output DIO1. See parameter 14.12 DIO1 ON delay.	0.00 s
	0.00 3000.00 s	Deactivation delay for DIO1.	100 = 1 s
14.14	DIO2 function	(Visible when 14.01 Module 1 type = FIO-01 or FIO-11) Selects whether DIO2 of the extension module is used as a digital input or output.	Input
	Output	DIO2 is used as a digital output.	0
	Input	DIO2 is used as a digital input.	1
14.16	DIO2 output source	(Visible when 14.01 Module 1 type = FIO-01 or FIO-11) Selects a drive signal to be connected to digital input/output DIO2 when parameter 14.14 DIO2 function is set to Output. For the available selections, see parameter 14.11 DIO1 output source.	Not energized
14.17	DI2 ON delay	(Visible when 14.01 Module 1 type = FDIO-01) Defines the activation delay for digital input DI2. See parameter 14.12 DI1 ON delay.	0.00 s
	0.00 3000.00 s	Activation delay for DI2.	10 = 1 s
14.17	DIO2 ON delay	(Visible when 14.01 Module 1 type = FIO-01 or FIO-11) Defines the activation delay for digital input/output DIO2. See parameter 14.12 DIO1 ON delay.	0.00 s
	0.00 3000.00 s	Activation delay for DIO2.	100 = 1 s
14.18	DI2 OFF delay	(Visible when 14.01 Module 1 type = FDIO-01) Defines the deactivation delay for digital input DI2. See parameter 14.12 DI1 ON delay.	0.00 s
	0.00 3000.00 s	Deactivation delay for DI2.	10 = 1 s

No.	Name/V	alue	Description	Def/FbEq16
14.18	DIO2 O	FF delay	(Visible when 14.01 Module 1 type = FIO-01 or FIO-11) Defines the deactivation delay for digital input/output DIO2. See parameter 14.17 DIO2 ON delay.	0.00 s
	0.00	3000.00 s	Deactivation delay for DIO2.	100 = 1 s
14.19	DIO3 fu	nction	(Visible when 14.01 Module 1 type = FIO-01) Selects whether DIO3 of the extension module is used as a digital input or output.	Input
	Output		DIO3 is used as a digital output.	0
	Input		DIO3 is used as a digital input.	1
14.19	AI super function		(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Selects how the drive reacts when an analog input signal moves out of the minimum and/or maximum limits specified for the input.  The inputs and the limits to be observed are selected by parameter 14.20 Al supervision selection.	No action
	No actio	nn	No action taken.	0
	Fault	•••	Drive trips on 80A0 AI supervision.	1
	Warning	1	Drive generates an A8A0 AI supervision warning.	2
	Last spe		Drive generates a warning (A8A0 Al supervision) and freezes the speed (or frequency) to the level the drive was	3
			operating at. The speed/frequency is determined on the basis of actual speed using 850 ms low-pass filtering.  WARNING! Make sure that it is safe to continue operation in case of a communication break.	
	Speed r	ef safe	Drive generates a warning (A8A0 AI supervision) and sets the speed to the speed defined by parameter 22.41 Speed ref safe (or 28.41 Frequency ref safe when frequency reference is being used).  WARNING! Make sure that it is safe to continue operation in case of a communication break.	4
14.20	Al supervision selection		(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Specifies the analog input limits to be supervised. See parameter 14.19 AI supervision function.  Note: The number of active bits in this parameter depends on the number of inputs on the extension module.	0000 0000ь
	Bit	Name	Description	
	0	Al1 < MIN	1 = Minimum limit supervision of Al1 active.	
	1	Al1 > MAX	1 = Maximum limit supervision of Al1 active.	
	2	Al2 < MIN	1 = Minimum limit supervision of Al2 active.	
	3	Al2 > MAX	1 = Maximum limit supervision of Al2 active.	
	4	Al3 < MIN	•	
	5	Al3 > MAX		
	615	Reserved		
	0000 00 1111b	00b 0011	Activation of analog input supervision.	1 = 1

No.	Name/Va	alue	Description	Def/FbEq16
14.21	DIO3 output source		(Visible when 14.01 Module 1 type = FIO-01) Selects a drive signal to be connected to digital input/output DIO3 when parameter 14.19 DIO3 function is set to Output. For the available selections, see parameter 14.11 DIO1 output source.	Not energized
14.21	Al tune		(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Triggers the analog input tuning function, which enables the use of actual measurements as the minimum and maximum input values instead of potentially inaccurate estimates.  Apply the minimum or maximum signal to the input and select the appropriate tuning function.  See also the drawing at parameter 14.35 AI1 scaled at AI1 min.	No action
	No action	n	Tuning action completed or no action has been requested. The parameter automatically reverts to this value after any tuning action.	0
	Al1 min t	tune	The measured value of Al1 is set as the minimum value of Al1 into parameter 14.33 Al1 min.	1
	Al1 max	tune	The measured value of Al1 is set as the maximum value of Al1 into parameter 14.34 Al1 max.	2
	Al2 min t	tune	The measured value of Al2 is set as the minimum value of Al2 into parameter 14.48 Al2 min.	3
	Al2 max	tune	The measured value of Al2 is set as the maximum value of Al2 into parameter 14.49 Al2 max.	4
	Al3 min tune		(Visible when 14.01 Module 1 type = FIO-11) The measured value of Al3 is set as the minimum value of Al3 into parameter 14.63 Al3 min.	5
	Al3 max	tune	(Visible when 14.01 Module 1 type = FIO-11) The measured value of Al3 is set as the maximum value of Al3 into parameter 14.64 Al3 max.	6
14.22	DI3 ON (	delay	(Visible when 14.01 Module 1 type = FDIO-01) Defines the activation delay for digital input DI3. See parameter 14.12 DI1 ON delay.	0.00 s
	0.00 3	3000.00 s	Activation delay for DI3.	10 = 1 s
14.22	DIO3 ON	l delay	(Visible when 14.01 Module 1 type = FIO-01 or FIO-11) Defines the activation delay for digital input/output DIO3. See parameter 14.12 DIO1 ON delay.	0.00 s
	0.00 3	3000.00 s	Activation delay for DIO3.	100 = 1 s
14.22	Al force	selection	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) The true readings of the analog inputs can be overridden for e.g. testing purposes. A forced value parameter is provided for each analog input, and its value is applied whenever the corresponding bit in this parameter is 1.	0000b
	Bit	Name	Description	
	0	Al1	1 = Force mode: Force Al1 to value of parameter 14.28 Al1	force data.
	1	Al2	1 = Force mode: Force Al2 to value of parameter 14.43 Al2	
	2	Al3	1 = Force mode: Force Al3 to value of parameter 14.58 Al3	
			(FIO-11 only).	

No.	Name/Value	Description	Def/FbEq16
	0000b0111b	Forced values selector for analog inputs.	1 = 1
14.23	DI3 OFF delay	(Visible when 14.01 Module 1 type = FDIO-01) Defines the deactivation delay for digital input DI3. See parameter 14.12 DI1 ON delay.	0.00 s
	0.00 3000.00 s	Deactivation delay for DI3.	10 = 1 s
14.23	DIO3 OFF delay	(Visible when 14.01 Module 1 type = FIO-01) Defines the deactivation delay for digital input/output DIO3. See parameter 14.12 DIO1 ON delay.	0.00 s
	0.00 3000.00 s	Deactivation delay for DIO3.	100 = 1 s
14.24	DIO4 function	(Visible when 14.01 Module 1 type = FIO-01) Selects whether DIO4 of the extension module is used as a digital input or output.	Input
	Output	DIO4 is used as a digital output.	0
	Input	DIO4 is used as a digital input.	1
14.26	DIO4 output source	(Visible when 14.01 Module 1 type = FIO-01) Selects a drive signal to be connected to digital input/output DIO4 when parameter 14.24 DIO4 function is set to Output. For the available selections, see parameter 14.11 DIO1 output source.	Not energized
14.26	Al1 actual value	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Displays value of analog input Al1 in mA or V (depending on whether the input is set to current or voltage). This parameter is read-only.	-
	-22.000 22.000 mA or V	Value of analog input AI1.	1000 = 1 mA or V
14.27	DIO4 ON delay	(Visible when 14.01 Module 1 type = FIO-01 or FIO-11) Defines the activation delay for digital input/output DIO4. See parameter 14.12 DIO1 ON delay.	0.00 s
	0.00 3000.00 s	Activation delay for DIO4.	100 = 1 s
14.27	Al1 scaled value	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Displays value of analog input Al1 after scaling. See parameter 14.35 Al1 scaled at Al1 min. This parameter is read-only.	-
	-32768.000 32767.000	Scaled value of analog input AI1.	1 = 1
14.28	DIO4 OFF delay	(Visible when 14.01 Module 1 type = FIO-01) Defines the deactivation delay for digital input/output DIO4. See parameter 14.12 DIO1 ON delay.	0.00 s
	0.00 3000.00 s	Deactivation delay for DIO4.	100 = 1 s
14.28	Al1 force data	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Forced value that can be used instead of the true reading of the input. See parameter 14.22 Al force selection.	0.000 mA
	-22.000 22.000 mA or V	Forced value of analog input Al1.	1000 = 1 mA or V

No.	Name/Value	Description	Def/FbEq16
14.29	AI1 HW switch position	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Shows the position of the hardware current/voltage selector on the I/O extension module.  Note: The setting of the current/voltage selector must match the unit selection made in parameter 14.30 AI1 unit selection. I/O module reboot either by cycling the power or through parameter 96.08 Control board boot is required to validate any changes in the hardware settings.	-
	V	Volts.	2
	mA	Milliamperes.	10
14.30	Al1 unit selection	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Selects the unit for readings and settings related to analog input AI1.  Note: This setting must match the corresponding hardware setting on the I/O extension module (see the manual of the I/O extension module). The hardware setting is shown by parameter 14.29 AI1 HW switch position. I/O module reboot either by cycling the power or through parameter 96.08  Control board boot is required to validate any changes in the hardware settings.	mA
	V	Volts.	2
	mA	Milliamperes.	10
14.31	RO status	(Visible when 14.01 Module 1 type = FIO-01 or FDIO-01) Status of relay outputs on the I/O extension module.  Example: 0001b = RO1 is energized, RO2 is de-energized.	-
	0000b1111b	Status of relay outputs.	1 = 1
14.31	Al1 filter gain	(Visible when 14.01 Module 1 type = FIO-11or FAIO-01) Selects a hardware filtering time for AI1. See also parameter 14.32 AI1 filter time.	1 ms
	No filtering	No filtering.	0
	125 us	125 microseconds.	1
_	250 us	250 microseconds.	2
	500 us	500 microseconds.	3
	1 ms	1 millisecond.	4
	2 ms	2 milliseconds.	5
	4 ms	4 milliseconds.	6
	7.9375 ms	7.9375 milliseconds.	7

No.	Name/Value	Description	Def/FbEq16
14.32	Al1 filter time	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01)  Defines the filter time constant for analog input AI1.   "Unfiltered signal  100  63  Filtered signal	0.100 s
	0.000 30.000 s	Filter time constant.	1000 = 1 s
14.33	Al1 min	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Defines the minimum value for analog input Al1. See also parameter 14.21 Al tune.	0.000 mA or V
	-22.000 22.000 mA or V	Minimum value of Al1.	1000 = 1 mA or V
14.34	RO1 source	(Visible when 14.01 Module 1 type = FIO-01 or FDIO-01) Selects a drive signal to be connected to relay output RO1. For the available selections, see parameter 14.11 DIO1 output source.	Not energized
14.34	Al1 max	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Defines the maximum value for analog input AI1. See also parameter 14.21 AI tune.	10.000 mA or V
	-22.000 22.000 mA or V	Maximum value of Al1.	1000 = 1 mA or V

No.	Name/Value	Description	Def/FbEq16
14.35	RO1 ON delay	(Visible when 14.01 Module 1 type = FIO-01 or FDIO-01) Defines the activation delay for relay output RO1.	0.00 s
	Status of selected source		1 0 1
	RO status	$\langle \cdot \rangle$ $\langle \cdot $	──── 0 ────────────────────────────────
	$t_{\rm On}$ = 14.35 RO1 ON del $t_{\rm Off}$ = 14.36 RO1 OFF de		
	0.00 3000.00 s	Activation delay for RO1.	100 = 1 s
14.35	Al1 scaled at Al1 min	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Defines the real value that corresponds to the minimum analog input Al1 value defined by parameter 14.33 Al1 min.	0.000
		AI <sub>scaled</sub> (14.27)	
		14.36	
	-32768.000	Real value corresponding to minimum Al1 value.	1 = 1
	32767.000	·	
14.36	RO1 OFF delay	(Visible when 14.01 Module 1 type = FIO-01 or FDIO-01) Defines the deactivation delay for relay output RO1. See parameter 14.35 RO1 ON delay.	0.00 s
	0.00 3000.00 s	Deactivation delay for RO1.	100 = 1 s
14.36	Al1 scaled at Al1 max	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Defines the real value that corresponds to the maximum analog input AI1 value defined by parameter 14.34 AI1 max. See the drawing at parameter 14.35 AI1 scaled at AI1 min.	100.000
	-32768.000 32767.000	Real value corresponding to maximum Al1 value.	1 = 1
14.37	RO2 source	(Visible when 14.01 Module 1 type = FIO-01 or FDIO-01) Selects a drive signal to be connected to relay output RO2. For the available selections, see parameter 14.11 DIO1 output source.	Not energized

No.	Name/Value	Description	Def/FbEq16
14.38	RO2 ON delay	(Visible when 14.01 Module 1 type = FIO-01 or FDIO-01) Defines the activation delay for relay output RO2. See parameter 14.35 RO1 ON delay.	0.00 s
	0.00 3000.00 s	Activation delay for RO2.	100 = 1 s
14.39	RO2 OFF delay	(Visible when 14.01 Module 1 type = FIO-01 or FDIO-01) Defines the deactivation delay for relay output RO2. See parameter 14.35 RO1 ON delay.	0.00 s
	0.00 3000.00 s	Deactivation delay for RO2.	100 = 1 s
14.41	Al2 actual value	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Displays value of analog input AI2 in mA or V (depending on whether the input is set to current or voltage). This parameter is read-only.	-
	-22.000 22.000 mA or V	Value of analog input Al2.	1000 = 1 mA or V
14.42	Al2 scaled value	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Displays value of analog input Al2 after scaling. See parameter 14.50 Al2 scaled at Al2 min. This parameter is read-only.	-
	-32768.000 32767.000	Scaled value of analog input Al2.	1 = 1
14.43	Al2 force data	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Forced value that can be used instead of the true reading of the input. See parameter 14.22 AI force selection.	0.000 mA
	-22.000 22.000 mA or V	Forced value of analog input Al2.	1000 = 1 mA or V
14.44	AI2 HW switch position	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Shows the position of the hardware current/voltage selector on the I/O extension module.  Note: The setting of the current/voltage selector must match the unit selection made in parameter 14.45 AI2 unit selection. I/O module reboot either by cycling the power or through parameter 96.08 Control board boot is required to validate any changes in the hardware settings.	-
	V	Volts.	2
	mA	Milliamperes.	10
14.45	AI2 unit selection	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Selects the unit for readings and settings related to analog input Al2.  Note: This setting must match the corresponding hardware setting on the I/O extension module (see the manual of the I/O extension module). The hardware setting is shown by parameter 14.44 AI2 HW switch position. I/O module reboot either by cycling the power or through parameter 96.08  Control board boot is required to validate any changes in the hardware settings.	mA
	V	Volts.	2
	mA	Milliamperes.	10
14.46	Al2 filter gain	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Selects a hardware filtering time for Al2. See also parameter 14.47 Al2 filter time.	1 ms
	No filtering	No filtering.	0

No.	Name/Value	Description	Def/FbEq16
	125 us	125 microseconds.	1
	250 us	250 microseconds.	2
	500 us	500 microseconds.	3
	1 ms	1 millisecond.	4
	2 ms	2 milliseconds.	5
	4 ms	4 milliseconds.	6
	7.9375 ms	7.9375 milliseconds.	7
14.47	Al2 filter time	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01)  Defines the filter time constant for analog input AI2.   "Unfiltered signal  100  63  Filtered signal   O = I × (1 - e <sup>-t/T</sup> )  I = filter input (step) O = filter output t = time T = filter time constant  Note: The signal is also filtered due to the signal interface hardware. See parameter 14.46 AI2 filter gain.	0.100 s
	0.000 30.000 s	Filter time constant.	1000 = 1 s
14.48	AI2 min	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Defines the minimum value for analog input AI2. See also parameter 14.21 AI tune.	0.000 mA or V
	-22.000 22.000 mA or V	Minimum value of Al2.	1000 = 1 mA or V
14.49	AI2 max	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Defines the maximum value for analog input Al2. See also parameter 14.21 Al tune.	10.000 mA or V
	-22.000 22.000 mA or V	Maximum value of AI2.	1000 = 1 mA or V

No.	Name/Value	Description	Def/FbEq16
14.50	Al2 scaled at Al2 min	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Defines the real value that corresponds to the minimum analog input Al2 value defined by parameter 14.48 Al2 min.  Al <sub>scaled</sub> (14.42)  14.48  Al <sub>in</sub> (14.41)	0.000
	-32768.000 32767.000	Real value corresponding to minimum Al2 value.	1 = 1
14.51	AI2 scaled at AI2 max	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Defines the real value that corresponds to the maximum analog input AI2 value defined by parameter 14.49 AI2 max. See the drawing at parameter 14.50 AI2 scaled at AI2 min.	100.000
	-32768.000 32767.000	Real value corresponding to maximum Al2 value.	1 = 1
14.56	Al3 actual value	(Visible when 14.01 Module 1 type = FIO-11) Displays value of analog input Al3 in mA or V (depending on whether the input is set to current or voltage). This parameter is read-only.	-
	-22.000 22.000 mA or V	Value of analog input Al3.	1000 = 1 mA or V
14.57	Al3 scaled value	(Visible when 14.01 Module 1 type = FIO-11) Displays value of analog input Al3 after scaling. See parameter 14.65 Al3 scaled at Al3 min. This parameter is read-only.	-
	-32768.000 32767.000	Scaled value of analog input Al3.	1 = 1
14.58	Al3 force data	(Visible when 14.01 Module 1 type = FIO-11) Forced value that can be used instead of the true reading of the input. See parameter 14.22 Al force selection.	0.000 mA
	-22.000 22.000 mA or V	Forced value of analog input Al3.	1000 = 1 mA or V
14.59	AI3 HW switch position	(Visible when 14.01 Module 1 type = FIO-11) Shows the position of the hardware current/voltage selector on the I/O extension module.  Note: The setting of the current/voltage selector must match the unit selection made in parameter 14.60 AI3 unit selection. I/O module reboot either by cycling the power or through parameter 96.08 Control board boot is required to validate any changes in the hardware settings.	-
	V	Volts.	2

No.	Name/Value	Description	Def/FbEq16
	mA	Milliamperes.	10
14.60	Al3 unit selection	(Visible when 14.01 Module 1 type = FIO-11) Selects the unit for readings and settings related to analog input AI3.  Note: This setting must match the corresponding hardware setting on the I/O extension module (see the manual of the I/O extension module). The hardware setting is shown by parameter 14.59 AI3 HW switch position. I/O module reboot either by cycling the power or through parameter 96.08  Control board boot is required to validate any changes in the hardware settings.	mA
	V	Volts.	2
	mA	Milliamperes.	10
14.61	Al3 filter gain	(Visible when 14.01 Module 1 type = FIO-11) Selects a hardware filtering time for Al3. See also parameter 14.62 Al3 filter time.	1 ms
	No filtering	No filtering.	0
	125 us	125 microseconds.	1
	250 us	250 microseconds.	2
	500 us	500 microseconds.	3
	1 ms	1 millisecond.	4
	2 ms	2 milliseconds.	5
	4 ms	4 milliseconds.	6
	7.9375 ms	7.9375 milliseconds.	7
14.62	Al3 filter time	(Visible when 14.01 Module 1 type = FIO-11)  Defines the filter time constant for analog input AI3.   "Unfiltered signal  100 63  Filtered signal   O = I × (1 - e <sup>-t/T</sup> )  I = filter input (step) O = filter output t = time T = filter time constant  Note: The signal is also filtered due to the signal interface hardware. See parameter 14.61 AI3 filter gain.	0.100 s
	0.000 30.000 s	Filter time constant.	1000 = 1 s

No.	Name/Va	lue	Description	Def/FbEq16
14.63	AI3 min		(Visible when 14.01 Module 1 type = FIO-11) Defines the minimum value for analog input Al3. See also parameter 14.21 Al tune.	0.000 mA or V
	-22.000 . mA or V	22.000	Minimum value of Al3.	1000 = 1 mA or V
14.64	AI3 max		(Visible when 14.01 Module 1 type = FIO-11) Defines the maximum value for analog input Al3. See also parameter 14.21 Al tune.	10.000 mA or V
	-22.000 . mA or V	22.000	Maximum value of Al3.	1000 = 1 mA or V
14.65	AI3 scale	ed at AI3	(Visible when 14.01 Module 1 type = FIO-11)  Defines the real value that corresponds to the minimum analog input Al3 value defined by parameter 14.63 Al3 min.  Al <sub>scaled</sub> (14.57)  14.63  Al <sub>in</sub> (14.56)  14.64	0.000
	-32768.0 32767.00		Real value corresponding to minimum Al3 value.	1 = 1
14.66	AI3 scale max		(Visible when 14.01 Module 1 type = FIO-11)  Defines the real value that corresponds to the maximum analog input Al3 value defined by parameter 14.64 Al3 max. See the drawing at parameter 14.65 Al3 scaled at Al3 min.	100.000
	-32768.0 32767.00		Real value corresponding to maximum Al3 value.	1 = 1
14.71	AO force	selection	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) The value of the analog output can be overridden for e.g. testing purposes. A forced value parameter (14.78 AO1 force data) is provided for the analog output, and its value is applied whenever the corresponding bit in this parameter is 1.	00b
		Name	Description	
	Bit	Name		
	Bit 0		-	force data
		AO1 AO2	1 = Force mode: Force AO1 to value of parameter 14.78 AO1 1 = Force mode: Force AO2 to value of parameter 14.88 AO2 (FAIO-01 only).	
	0	AO1	1 = Force mode: Force AO1 to value of parameter 14.78 AO1 1 = Force mode: Force AO2 to value of parameter 14.88 AO2	

No.	Name/Value	Description	Def/FbEq16
14.76	AO1 actual value	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Displays value of AO1 in mA. This parameter is read-only.	-
	0.000 22.000 mA	Value of AO1.	1000 = 1 mA
14.77	AO1 source	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Selects a signal to be connected to analog output AO1. Alternatively, sets the output to excitation mode to feed a constant current to a temperature sensor.	Zero
	Zero	None.	0
	Motor speed used	01.01 Motor speed used (page 160).	1
	Output frequency	01.06 Output frequency (page 160).	3
	Motor current	01.07 Motor current (page 160).	4
	Motor torque	01.10 Motor torque (page 160).	6
	DC voltage	01.11 DC voltage (page 160).	7
	Power inu out	01.14 Output power (page 161).	8
	Speed ref ramp in	23.01 Speed ref ramp input (page 268).	10
	Speed ref ramp out	23.02 Speed ref ramp output (page 268).	11
	Speed ref used	24.01 Used speed reference (page 274).	12
	Torq ref used	26.02 Torque reference used (page 290).	13
	Freq ref used	28.02 Frequency ref ramp output (page 298).	14
	Process PID out	40.01 Process PID output actual (page 355).	16
	Process PID fbk	40.02 Process PID feedback actual (page 355).	17
	Process PID act	40.03 Process PID setpoint actual (page 355).	18
	Process PID dev	40.04 Process PID deviation actual (page 356).	19
	Force PT100 excitation	The output is used to feed an excitation current to 13 Pt100 sensors. See section <i>Motor thermal protection</i> (page 122).	20
	Force KTY84 excitation	The output is used to feed an excitation current to a KTY84 sensor. See section <i>Motor thermal protection</i> (page 122).	21
	Force PTC excitation	The output is used to feed an excitation current to 13 PTC sensors. See section <i>Motor thermal protection</i> (page 122).	22
	Force Pt1000 excitation	The output is used to feed an excitation current to 13 Pt1000 sensors. See section <i>Motor thermal protection</i> (page 122).	23
	AO1 data storage	13.91 AO1 data storage (page 213).	37
	AO2 data storage	13.92 AO2 data storage (page 213).	38
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
14.78	AO1 force data	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Forced value that can be used instead of the selected output signal. See parameter 14.71 AO force selection.	0.000 mA
	0.000 22.000 mA	Forced value of analog output AO1.	1000 = 1 mA

No.	Name/Value	Description	Def/FbEq16
14.79	AO1 filter time	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Defines the filtering time constant for analog output AO1.  Which is a signal for a signal fo	0.100 s
	0.000 30.000 s	Filter time constant.	1000 = 1 s

No.	Name/Value	Description	Def/FbEq16
14.80	AO1 source min	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Defines the real value of the signal (selected by parameter 14.77 AO1 source) that corresponds to the minimum AO1 output value (defined by parameter 14.82 AO1 out at AO1 src min).  IAO1 (mA)  14.83  14.82  14.81  Signal (real) selected by par. 14.77  Signal (real) selected by par. 14.77	0.0
	-32768.0 32767.0	Real signal value corresponding to minimum AO1 output value.	1 = 1
14.81	AO1 source max	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01)  Defines the real value of the signal (selected by parameter 14.77 AO1 source) that corresponds to the maximum AO1 output value (defined by parameter 14.83 AO1 out at AO1 src max). See parameter 14.80 AO1 source min.	100.0
	-32768.0 32767.0	Real signal value corresponding to maximum AO1 output value.	1 = 1
14.82	AO1 out at AO1 src min	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Defines the minimum output value for analog output AO1. See also drawing at parameter 14.80 AO1 source min.	0.000 mA
	0.000 22.000 mA	Minimum AO1 output value.	1000 = 1 mA
14.83	AO1 out at AO1 src max	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Defines the maximum output value for analog output AO1. See also drawing at parameter 14.80 AO1 source min.	10.000 mA
	0.000 22.000 mA	Maximum AO1 output value.	1000 = 1 mA

No.	Name/Value	Description	Def/FbEq16
14.86	AO2 actual value	(Visible when 14.01 Module 1 type = FAIO-01) Displays value of AO2 in mA. This parameter is read-only.	-
	0.000 22.000 mA	Value of AO2.	1000 = 1 mA
14.87	AO2 source	(Visible when 14.01 Module 1 type = FAIO-01) Selects a signal to be connected to analog output AO2. Alternatively, sets the output to excitation mode to feed a constant current to a temperature sensor. For the selections, see parameter 14.77 AO1 source.	Zero
14.88	AO2 force data	(Visible when 14.01 Module 1 type = FAIO-01) Forced value that can be used instead of the selected output signal. See parameter 14.71 AO force selection.	0.000 mA
	0.000 22.000 mA	Forced value of analog output AO2.	1000 = 1 mA
14.89	AO2 filter time	(Visible when 14.01 Module 1 type = FAIO-01) Defines the filtering time constant for analog output AO2. See parameter 14.79 AO1 filter time.	0.100 s
	0.000 30.000 s	Filter time constant.	1000 = 1 s
14.90	AO2 source min	Defines the real value of the signal (selected by parameter 14.87 AO2 source) that corresponds to the minimum AO2 output value (defined by parameter 14.92 AO2 out at AO2 src min).  IAO1 (mA)  Signal (real) selected by parameter 14.93  IAO1 (mA)  14.93	0.0
		14.92	
	-32768.0 32767.0	Real signal value corresponding to minimum AO2 output value.	1 = 1

No.	Name/Value	Description	Def/FbEq16
14.91	AO2 source max	(Visible when 14.01 Module 1 type = FAIO-01)  Defines the real value of the signal (selected by parameter 14.87 AO2 source) that corresponds to the maximum AO2 output value (defined by parameter 14.93 AO2 out at AO2 src max). See parameter 14.90 AO2 source min.	100.0
	-32768.0 32767.0	Real signal value corresponding to maximum AO2 output value.	1 = 1
14.92	AO2 out at AO2 src min	(Visible when 14.01 Module 1 type = FAIO-01) Defines the minimum output value for analog output AO2. See also drawing at parameter 14.90 AO2 source min.	0.000 mA
	0.000 22.000 mA	Minimum AO2 output value.	1000 = 1 mA
14.93	AO2 out at AO2 src max	(Visible when 14.01 Module 1 type = FAIO-01) Defines the maximum output value for analog output AO2. See also drawing at parameter 14.90 AO2 source min.	10.000 mA
	0.000 22.000 mA	Maximum AO2 output value.	1000 = 1 mA

15 I/O 2	extension module	Configuration of I/O extension module 2. See also section <i>Programmable I/O extensions</i> (page 72). <b>Note:</b> The contents of the parameter group vary according to the selected I/O extension module type.	
15.01	Module 2 type	See parameter 14.01 Module 1 type.	None
15.02	Module 2 location	See parameter 14.02 Module 1 location.	Slot 1
15.03	Module 2 status	See parameter 14.03 Module 1 status.	No option
15.05	DI status	(Visible when 15.01 Module 2 type = FDIO-01) See parameter 14.05 DI status.	-
15.05	DIO status	(Visible when 15.01 Module 2 type = FIO-01 or FIO-11) See parameter 14.05 DIO status.	-
15.06	DI delayed status	(Visible when 15.01 Module 2 type = FDIO-01) See parameter 14.06 DI delayed status.	-
15.06	DIO delayed status	(Visible when 15.01 Module 2 type = FIO-01 or FIO-11) See parameter 14.06 DIO delayed status.	-
15.08	DI filter time	(Visible when 15.01 Module 2 type = FDIO-01) See parameter 14.08 DI filter time.	10.0 ms
15.08	DIO filter time	(Visible when 15.01 Module 2 type = FIO-01 or FIO-11) See parameter 14.08 DIO filter time.	10.0 ms
15.09	DIO1 function	(Visible when 15.01 Module 2 type = FIO-01 or FIO-11) See parameter 14.09 DIO1 function.	Input
15.11	DIO1 output source	(Visible when 15.01 Module 2 type = FIO-01 or FIO-11) See parameter 14.11 DIO1 output source.	Not energized
15.12	DI1 ON delay	(Visible when 15.01 Module 2 type = FDIO-01) See parameter 14.12 DI1 ON delay.	0.00 s
15.12	DIO1 ON delay	(Visible when 15.01 Module 2 type = FIO-01 or FIO-11) See parameter 14.12 DIO1 ON delay.	0.00 s
15.13	DI1 OFF delay	(Visible when 15.01 Module 2 type = FDIO-01) See parameter 14.13 DI1 OFF delay.	0.00 s
15.13	DIO1 OFF delay	(Visible when 15.01 Module 2 type = FIO-01 or FIO-11) See parameter 14.13 DIO1 OFF delay.	0.00 s

No.	Name/Value	Description	Def/FbEq16
15.14	DIO2 function	(Visible when 15.01 Module 2 type = FIO-01 or FIO-11) See parameter 14.14 DIO2 function.	Input
15.16	DIO2 output source	(Visible when 15.01 Module 2 type = FIO-01 or FIO-11) See parameter 14.16 DIO2 output source.	Not energized
15.17	DI2 ON delay	(Visible when 15.01 Module 2 type = FDIO-01) See parameter 14.17 DI2 ON delay.	0.00 s
15.17	DIO2 ON delay	(Visible when 15.01 Module 2 type = FIO-01 or FIO-11) See parameter 14.17 DIO2 ON delay.	0.00 s
15.18	DI2 OFF delay	(Visible when 15.01 Module 2 type = FDIO-01) See parameter 14.18 DI2 OFF delay.	0.00 s
15.18	DIO2 OFF delay	(Visible when 15.01 Module 2 type = FIO-01 or FIO-11) See parameter 14.18 DIO2 OFF delay.	0.00 s
15.19	DIO3 function	(Visible when 15.01 Module 2 type = FIO-01) See parameter 14.19 DIO3 function.	Input
15.19	Al supervision function	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.19 AI supervision function.	No action
15.20	AI supervision selection	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.20 AI supervision selection.	0000 0000Ь
15.21	DIO3 output source	(Visible when 15.01 Module 2 type = FIO-01) See parameter 14.21 DIO3 output source.	Not energized
15.21	Al tune	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.21 AI tune.	No action
15.22	DI3 ON delay	(Visible when 15.01 Module 2 type = FDIO-01) See parameter 14.22 DI3 ON delay.	0.00 s
15.22	DIO3 ON delay	(Visible when 15.01 Module 2 type = FIO-01) See parameter 14.22 DIO3 ON delay.	0.00 s
15.22	Al force selection	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.22 AI force selection.	0000b
15.23	DI3 OFF delay	(Visible when 15.01 Module 2 type = FDIO-01) See parameter 14.23 DI3 OFF delay.	0.00 s
15.23	DIO3 OFF delay	(Visible when 15.01 Module 2 type = FIO-01) See parameter 14.23 DIO3 OFF delay.	0.00 s
15.24	DIO4 function	(Visible when 15.01 Module 2 type = FIO-01) See parameter 14.24 DIO4 function.	Input
15.26	DIO4 output source	(Visible when 15.01 Module 2 type = FIO-01) See parameter 14.26 DIO4 output source.	Not energized
15.26	Al1 actual value	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.26 AI1 actual value.	-
15.27	DIO4 ON delay	(Visible when 15.01 Module 2 type = FIO-01) See parameter 14.27 DIO4 ON delay.	0.00 s
15.27	Al1 scaled value	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.27 AI1 scaled value.	-
15.28	DIO4 OFF delay	(Visible when 15.01 Module 2 type = FIO-01) See parameter 14.28 DIO4 OFF delay.	0.00 s
15.28	Al1 force data	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.28 Al1 force data.	0.000 mA

No.	Name/Value	Description	Def/FbEq16
15.49	Al2 max	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.49 AI2 max.	10.000 mA or V
15.50	AI2 scaled at AI2 min	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.50 AI2 scaled at AI2 min.	0.000
15.51	Al2 scaled at Al2 max	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.51 AI2 scaled at AI2 max.	100.000
15.56	Al3 actual value	(Visible when 15.01 Module 2 type = FIO-11) See parameter 14.56 AI3 actual value.	-
15.57	Al3 scaled value	(Visible when 15.01 Module 2 type = FIO-11) See parameter 14.57 AI3 scaled value.	-
15.58	Al3 force data	(Visible when 15.01 Module 2 type = FIO-11) See parameter 14.58 AI3 force data.	0.000 mA
15.59	AI3 HW switch position	(Visible when 15.01 Module 2 type = FIO-11) See parameter 14.59 AI3 HW switch position.	-
15.60	Al3 unit selection	(Visible when 15.01 Module 2 type = FIO-11) See parameter 14.60 AI3 unit selection.	mA
15.61	Al3 filter gain	(Visible when 15.01 Module 2 type = FIO-11) See parameter 14.61 AI3 filter gain.	1 ms
15.62	Al3 filter time	(Visible when 15.01 Module 2 type = FIO-11) See parameter 14.62 AI3 filter time.	0.100 s
15.63	Al3 min	(Visible when 15.01 Module 2 type = FIO-11) See parameter 14.63 AI3 min.	0.000 mA or V
15.64	AI3 max	(Visible when 15.01 Module 2 type = FIO-11) See parameter 14.64 AI3 max.	10.000 mA or V
15.65	AI3 scaled at AI3 min	(Visible when 15.01 Module 2 type = FIO-11) See parameter 14.65 AI3 scaled at AI3 min.	0.000
15.66	AI3 scaled at AI3 max	(Visible when 15.01 Module 2 type = FIO-11) See parameter 14.66 AI3 scaled at AI3 max.	100.000
15.71	AO force selection	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.71 AO force selection.	00b
15.76	AO1 actual value	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.76 AO1 actual value.	-
15.77	AO1 source	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.77 AO1 source.	Zero
15.78	AO1 force data	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.78 AO1 force data.	0.000 mA
15.79	AO1 filter time	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.79 AO1 filter time.	0.100 s
15.80	AO1 source min	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.80 AO1 source min.	0.0
15.81	AO1 source max	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.81 AO1 source max.	100.0
15.82	AO1 out at AO1 src min	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.82 AO1 out at AO1 src min.	0.000 mA
15.83	AO1 out at AO1 src max	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.83 AO1 out at AO1 src max.	10.000 mA

energized

0.00 s

 $0.00 \, s$ 

0.00 s

See parameter 14.11 DIO1 output source.

See parameter 14.12 DI1 ON delay.

See parameter 14.12 DIO1 ON delay.

See parameter 14.13 DI1 OFF delay.

(Visible when 16.01 Module 3 type = FDIO-01)

(Visible when 16.01 Module 3 type = FDIO-01)

(Visible when 16.01 Module 3 type = FIO-01 or FIO-11)

16.12

16.12

16.13

DI1 ON delay

DIO1 ON delay

DI1 OFF delay

No.	Name/Value	Description	Def/FbEq16
16.13	DIO1 OFF delay	(Visible when 16.01 Module 3 type = FIO-01 or FIO-11) See parameter 14.13 DIO1 OFF delay.	0.00 s
16.14	DIO2 function	(Visible when 16.01 Module 3 type = FIO-01 or FIO-11) See parameter 14.14 DIO2 function.	Input
16.16	DIO2 output source	(Visible when 16.01 Module 3 type = FIO-01 or FIO-11) See parameter 14.16 DIO2 output source.	Not energized
16.17	DI2 ON delay	(Visible when 16.01 Module 3 type = FDIO-01) See parameter 14.17 DI2 ON delay.	0.00 s
16.17	DIO2 ON delay	(Visible when 16.01 Module 3 type = FIO-01 or FIO-11) See parameter 14.17 DIO2 ON delay.	0.00 s
16.18	DI2 OFF delay	(Visible when 16.01 Module 3 type = FDIO-01) See parameter 14.18 DI2 OFF delay.	0.00 s
16.18	DIO2 OFF delay	(Visible when 16.01 Module 3 type = FIO-01 or FIO-11) See parameter 14.18 DIO2 OFF delay.	0.00 s
16.19	DIO3 function	(Visible when 16.01 Module 3 type = FIO-01) See parameter 14.19 DIO3 function.	Input
16.19	AI supervision function	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.19 AI supervision function.	No action
16.20	Al supervision selection	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.20 AI supervision selection.	0000 0000b
16.21	DIO3 output source	(Visible when 16.01 Module 3 type = FIO-01) See parameter 14.21 DIO3 output source.	Not energized
16.21	Al tune	(Visible when 16.01 Module 3 type = FIO-11) See parameter 14.21 Al tune.	No action
16.22	DI3 ON delay	(Visible when 16.01 Module 3 type = FDIO-01) See parameter 14.22 DI3 ON delay.	0.00 s
16.22	DIO3 ON delay	(Visible when 16.01 Module 3 type = FIO-01) See parameter 14.22 DIO3 ON delay.	0.00 s
16.22	Al force selection	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.22 AI force selection.	0000b
16.23	DI3 OFF delay	(Visible when 16.01 Module 3 type = FDIO-01) See parameter 14.23 DI3 OFF delay.	0.00 s
16.23	DIO3 OFF delay	(Visible when 16.01 Module 3 type = FIO-01) See parameter 14.23 DIO3 OFF delay.	0.00 s
16.24	DIO4 function	(Visible when 16.01 Module 3 type = FIO-01) See parameter 14.24 DIO4 function.	Input
16.26	DIO4 output source	(Visible when 16.01 Module 3 type = FIO-01) See parameter 14.26 DIO4 output source.	Not energized
16.26	Al1 actual value	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.26 AI1 actual value.	-
16.27	DIO4 ON delay	(Visible when 16.01 Module 3 type = FIO-01) See parameter 14.27 DIO4 ON delay.	0.00 s
16.27	Al1 scaled value	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.27 Al1 scaled value.	-
16.28	DIO4 OFF delay	(Visible when 16.01 Module 3 type = FIO-01) See parameter 14.28 DIO4 OFF delay.	0.00 s

No.	Name/Value	Description	Def/FbEq16
16.48	Al2 min	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.48 AI2 min.	0.000 mA or V
16.49	Al2 max	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.49 Al2 max.	10.000 mA or V
16.50	AI2 scaled at AI2 min	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.50 Al2 scaled at Al2 min.	0.000
16.51	Al2 scaled at Al2 max	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.51 Al2 scaled at Al2 max.	100.000
16.56	Al3 actual value	(Visible when 16.01 Module 3 type = FIO-11) See parameter 14.56 AI3 actual value.	-
16.57	Al3 scaled value	(Visible when 16.01 Module 3 type = FIO-11) See parameter 14.57 Al3 scaled value.	-
16.58	Al3 force data	(Visible when 16.01 Module 3 type = FIO-11) See parameter 14.58 Al3 force data.	0.000 mA
16.59	AI3 HW switch position	(Visible when 16.01 Module 3 type = FIO-11) See parameter 14.59 AI3 HW switch position.	-
16.60	Al3 unit selection	(Visible when 16.01 Module 3 type = FIO-11) See parameter 14.60 AI3 unit selection.	mA
16.61	AI3 filter gain	(Visible when 16.01 Module 3 type = FIO-11) See parameter 14.61 Al3 filter gain.	1 ms
16.62	AI3 filter time	(Visible when 16.01 Module 3 type = FIO-11) See parameter 14.62 AI3 filter time.	0.100 s
16.63	AI3 min	(Visible when 16.01 Module 3 type = FIO-11) See parameter 14.63 AI3 min.	0.000 mA or V
16.64	AI3 max	(Visible when 16.01 Module 3 type = FIO-11) See parameter 14.64 AI3 max.	10.000 mA or V
16.65	Al3 scaled at Al3 min	(Visible when 16.01 Module 3 type = FIO-11) See parameter 14.65 AI3 scaled at AI3 min.	0.000
16.66	Al3 scaled at Al3 max	(Visible when 16.01 Module 3 type = FIO-11) See parameter 14.66 AI3 scaled at AI3 max.	100.000
16.71	AO force selection	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.71 AO force selection.	00b
16.76	AO1 actual value	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.76 AO1 actual value.	-
16.77	AO1 source	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.77 AO1 source.	Zero
16.78	AO1 force data	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.78 AO1 force data.	0.000 mA
16.79	AO1 filter time	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.79 AO1 filter time.	0.100 s
16.80	AO1 source min	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.80 AO1 source min.	0.0
16.81	AO1 source max	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.81 AO1 source max.	100.0
16.82	AO1 out at AO1 src min	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.82 AO1 out at AO1 src min.	0.000 mA

No.	Name/Value	Description	Def/FbEq16
16.83	AO1 out at AO1 src max	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.83 AO1 out at AO1 src max.	10.000 mA
16.86	AO2 actual value	(Visible when 16.01 Module 3 type = FAIO-01) See parameter 14.86 AO2 actual value.	-
16.87	AO2 source	(Visible when 16.01 Module 3 type = FAIO-01) See parameter 14.87 AO2 source.	Zero
16.88	AO2 force data	(Visible when 16.01 Module 3 type = FAIO-01) See parameter 14.88 AO2 force data.	0.000 mA
16.89	AO2 filter time	(Visible when 16.01 Module 3 type = FAIO-01) See parameter 14.89 AO2 filter time.	0.100 s
16.90	AO2 source min	(Visible when 16.01 Module 3 type = FAIO-01) See parameter 14.90 AO2 source min.	0.0
16.91	AO2 source max	(Visible when 16.01 Module 3 type = FAIO-01) See parameter 14.91 AO2 source max.	100.0
16.92	AO2 out at AO2 src min	(Visible when 16.01 Module 3 type = FAIO-01) See parameter 14.92 AO2 out at AO2 src min.	0.000 mA
16.93	AO2 out at AO2 src max	(Visible when 16.01 Module 3 type = FAIO-01) See parameter 14.93 AO2 out at AO2 src max.	10.000 mA

19 Operation mode		Selection of local and external control location sources and operating modes.  See also section <i>Operating modes of the drive</i> (page <i>43</i> ).	
19.01	Actual operation mode	Displays operating mode currently used. See parameters 19.1119.14. This parameter is read-only.	-
	Zero	None.	1
	Speed	Speed control (in DTC motor control mode).	2
	Torque	Torque control (in DTC motor control mode).	3
	Min	The torque selector is comparing the output of the speed controller (25.01 Torque reference speed control) and torque reference (26.74 Torque ref ramp out) and the smaller of the two is used.	4
	Max	The torque selector is comparing the output of the speed controller (25.01 Torque reference speed control) and torque reference (26.74 Torque ref ramp out) and the greater of the two is used.	5
	Add	The speed controller output is added to the torque reference.	6
	Scalar (Hz)	Frequency control in scalar motor control mode.	10
	Scalar (rpm)	Speed control in scalar motor control mode.	11
	Forced magn.	Motor is in magnetizing mode.	20
19.11	Ext1/Ext2 selection	Selects the source for external control location EXT1/EXT2 selection.  0 = EXT1 1 = EXT2  Note: Winder feature is valid only in Ext 1 control location.	EXT1
	EXT1	EXT1 (permanently selected).	0
	EXT2	EXT2 (permanently selected).	1

No.	Name/Value	Description	Def/FbEq16
	FBA A MCW bit 11	Control word bit 11 received through fieldbus interface A.	2
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	3
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	4
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	5
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	6
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	7
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	8
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	11
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	12
	EFB MCW bit 11	Control word bit 11 received through the embedded fieldbus interface.	32
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
19.12	Ext1 control mode	Selects the operating mode for external control location EXT1.	Speed
	Zero	None.	1
	Speed	Speed control. The torque reference used is 25.01 Torque reference speed control (output of the speed reference chain).	2
	Torque	Torque control. The torque reference used is 26.74 Torque ref ramp out (output of the torque reference chain).	3
	Minimum	Combination of selections <i>Speed</i> and <i>Torque</i> : the torque selector compares the speed controller output (25.01 Torque reference speed control) and the torque reference (26.74 Torque ref ramp out) and selects the smaller of the two. If speed error becomes negative, the drive follows the speed controller output until speed error becomes positive again. This prevents the drive from accelerating uncontrollably if the load is lost in torque control.	4
	Maximum	Combination of selections <i>Speed</i> and <i>Torque</i> : the torque selector compares the speed controller output (25.01 Torque reference speed control) and the torque reference (26.74 Torque ref ramp out) and selects the greater of the two. If speed error becomes positive, the drive follows the speed controller output until speed error becomes negative again. This prevents the drive from accelerating uncontrollably if the load is lost in torque control.	5
	Add	Combination of selections <i>Speed</i> and <i>Torque</i> : Torque selector adds the speed reference chain output to the torque reference chain output.	6
19.14	Ext2 control mode	Selects the operating mode for external control location EXT2. For the selections, see parameter 19.12 Ext1 control mode.	Speed
19.16	Local control mode	Selects the operating mode for local control.	Speed
	Speed	Speed control. The torque reference used is 25.01 Torque reference speed control (output of the speed reference chain).	0
	Torque	Torque control. The torque reference used is 26.74 Torque ref ramp out (output of the torque reference chain).	1

No.	Name/Value	Description					Def/FbEq16
19.17	Local control disable	Enables/disables local control (start and stop buttons on the control panel, and the local controls on the PC tool).  WARNING! Before disabling local control, ensure that the control panel is not needed for stopping the drive.				No	
	No	Local control enabled.					0
	Yes	Local control disabled.	Local control disabled.				
19.20	Scalar control reference unit	Selects the reference type for scalar motor control mode.  See also section <i>Operating modes of the drive</i> (page 43), and parameter 99.04 Motor control mode.			Rpm		
	Hz	Hz. The reference is taken from parameter 28.02 Frequency ref ramp output (output of the frequency control chain).					0
	Rpm		Rpm. The reference is taken from parameter 23.02 Speed ref ramp output (speed reference after ramping and shaping).				
20 Sta	rt/stop/direction	Start/stop/direction and run/start/jog enable signal source selection; positive/negative reference enable signal source selection.  For information on control locations, see section <i>Local control vs. external control</i> (page 40).					
20.01	Ext1 commands	Selects the source of start, stop and direction commands for external control location 1 (EXT1).  See also parameters 20.0220.05.				In1 Start	
	Not selected	No start or stop commar	nd sc	ources selecte	d.		0
	0 -> 1 (20.02 = Edge) 1 (20.02 = Level)			<i>irce</i> . The state			1
In1 Start; In2 Dir  The source selected by 20.03 Ext1 in1 source is the start signal; the source selected by 20.04 Ext1 in2 source determines the direction. The state transitions of the source bits are interpreted as follows:						2	
		State of source 1 (20.03)	St	ate of source (20.04)	Comma		
		0		Any	Stop Start form		
		0 -> 1 (20.02 = Edge) 1 (20.02 = Level)		0	Start forv		
		1 (23.02 2000)		1	Jantieve	5136	

No.	Name/Value	Description				Def/FbEq16
	In1 Start fwd; In2 Start rev	The source selecte start signal; the souther reverse start significant bits are interpreted	urce selecte gnal. The st	d by 20.04 Ext	1 in2 source is	3
		State of source (20.03)	1 State	e of source 2 (20.04)	Command	
		0		0	Stop	
		0 -> 1 (20.02 = Ed 1 (20.02 = Leve		0	Start forward	
		0		(20.02 = Edge) 0.02 Level)	Start reverse	
		1		1	Stop	
	In1P Start; In2 Stop	The sources of the parameters 20.03 is source. The state to interpreted as follows:  State of source.	Ext1 in1 sour ransitions of ws:	irce and 20.04 I	Ext1 in2 s are	4
		(20.03)		(20.04)	Command	
		0 -> 1		1	Start	
		Any		0	Stop	
		<b>Note:</b> The start sig				
	In1P Start; In2 Stop; In3 Dir	The sources of the parameters 20.03 is source. The source determines the dire bits are interpreted	5			
			State of source 2 (20.04)	State of source 3 (20.05)	Command	
		0 -> 1	1	0	Start forward	
		0 -> 1	1	1	Start reverse	
		Any	0	Any	Stop	
		Note: The start sig setting regardless				
	In1P Start fwd; In2P Start rev; In3 Stop	The sources of the parameters 20.03 and 20.05 Ext1 in3 source bits are interested.	in2 source	6		
			State of source 2 (20.04)	State of source 3 (20.05)	Command	
		0 -> 1	Any	1	Start forward	
		Any	0 -> 1	1	Start reverse	
		Any	Any	0	Stop	
		The start signal regardless of pa				

No.	Name/Value	Description	Def/FbEq16
	Control panel	The start and stop commands are taken from the control panel.	11
	Fieldbus A	The start and stop commands are taken from fieldbus adapter A.  Note: The start signal is always level-triggered with this setting regardless of parameter 20.02 Ext1 start trigger type.	12
	Embedded fieldbus	The start and stop commands are taken from the embedded fieldbus interface.  Note: The start signal is always level-triggered with this setting regardless of parameter 20.02 Ext1 start trigger type.	14
	M/F link	The start and stop commands are taken from another drive through the master/follower link.  Note: The start signal is always level-triggered with this setting regardless of parameter 20.02 Ext1 start trigger type.	15
	DDCS controller	The start and stop commands are taken from an external (DDCS) controller.  Note: The start signal is always level-triggered with this setting regardless of parameter 20.02 Ext1 start trigger type.	16
	Application Program	The start and stop commands are taken from the application program control word (parameter <i>06.02 Application control word</i> ). <b>Note:</b> The start signal is always level-triggered with this setting regardless of parameter <i>20.02 Ext1 start trigger type</i> .	21
	ATF	Reserved.	22
20.02	Ext1 start trigger type	Defines whether the start signal for external control location EXT1 is edge-triggered or level-triggered.  Note: This parameter is only effective when parameter 20.01 Ext1 commands is set to In1 Start, In1 Start; In2 Dir, In1 Start fwd; In2 Start rev or Control panel.	Edge
	Edge	The start signal is edge-triggered.	0
	Level	The start signal is level-triggered.	1
20.03	Ext1 in1 source	Selects source 1 for parameter 20.01 Ext1 commands.	DI1
	Not selected	0 (always off).	0
	Selected	1 (always on).	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
20.04	Ext1 in2 source	Selects source 2 for parameter 20.01 Ext1 commands. For the available selections, see parameter 20.03 Ext1 in1 source.	Not selected

No.	Name/Value	Description	Def/FbEq16				
20.05	Ext1 in3 source	Selects source 3 for par For the available selecti source.			Not selected		
20.06	Ext2 commands	Selects the source of state external control location. See also parameters 20	n 2 (EXT2).	commands for	Not selected		
	Not selected	*	No start or stop command sources selected.				
	In1 Start	The source of the start a parameter 20.08 Ext2 in source bits are interpret	1				
		0 -> 1 (20.07 = Edge 1 (20.07 = Level)					
	In1 Start; In2 Dir	The source selected by signal; the source selected determines the direction bits are interpreted as for the source of source o	2				
		State of source 1 (20.08)	State of source 2 (20.09)	Command			
		0	Any	Stop			
		0 -> 1 (20.07 = Edge)	0	Start forward			
		1 (20.07 = Level)	1	Start reverse			
	In1 Start fwd; In2 Start rev  The source selected by 20.08 Ext2 in1 source is the forward start signal; the source selected by 20.09 Ext2 in2 source the reverse start signal. The state transitions of the source bits are interpreted as follows:						
		State of source 1 (20.08)	State of source 2 (20.09)	Command			
		0	0	Stop			
		0 -> 1 (20.07 = Edge) 1 (20.07 = Level)	0	Start forward			
		0	0 -> 1 (20.07 = Edge 1 (20.07 = Level)	Start reverse			
		1	1	Stop			
	In1P Start; In2 Stop  The sources of the start and stop commands are selected by parameters 20.08 Ext2 in1 source and 20.09 Ext2 in2 source. The state transitions of the source bits are interpreted as follows:						
		State of source 1 (20.08)	State of source 2 (20.09)	Command			
		0 -> 1	1	Start			
		Any  Note: The start signal is	0	Stop			
		<b>Note:</b> The start signal is setting regardless of pa					

No.	Name/Value	Description				Def/FbEq16		
In1P Start; In2 Stop; In3 Dir  The sources of the start and stop commands are selected by parameters 20.08 Ext2 in1 source and 20.09 Ext2 in2 source. The source selected by 20.10 Ext2 in3 source determines the direction. The state transitions of the source bits are interpreted as follows:					5			
		State of source 1 (20.08)	State of source 2 (20.09)	State of source 3 (20.10)	Command			
		0 -> 1						
		0 -> 1	1	1	Start reverse			
		Any	0	Any	Stop			
		Note: The star setting regardle			ered with this start trigger type.			
	In1P Start fwd; In2P Start rev; In3 Stop	The sources of parameters 20, and 20.10 Ext2 source bits are	.08 Ext2 in1 sc 2 in3 source. TI	ource, 20.09 Ex ne state transit		6		
		State of source 1 (20.08)	State of source 2 (20.09)	State of source 3 (20.10)	Command			
		0 -> 1	Any	1	Start forward			
		Any	0 -> 1	1	Start reverse			
		Note: The star setting regardle			start trigger type.			
	Control panel	The start and spanel.	stop commands	s are taken fro	m the control	11		
	Fieldbus A	The start and s adapter A. <b>Note:</b> The star setting regardle	t signal is alwa	ys level-trigge		12		
	Embedded fieldbus	fieldbus interfa <b>Note:</b> The star	ce. t signal is alwa	ys level-trigge	n the embedded red with this start trigger type.	14		
	M/F link	through the dri	The start and stop commands are taken from another drive through the drive-to-drive link or the master/follower link.  Note: Set also 20.07 Ext2 start trigger type to Level.					
	DDCS controller	The start and s (DDCS) contro <b>Note:</b> The start setting regardle	16					
	Application Program	The start and s program contro word). <b>Note:</b> The star setting regardle	21					
	ATF	Reserved.				22		
		<b>.</b>						

No.	Name/Value	Description	Def/FbEq16
20.07	Ext2 start trigger type	Defines whether the start signal for external control location EXT2 is edge-triggered or level-triggered.  Note: This parameter is only effective when parameter 20.06 Ext2 commands is set to In1 Start, In1 Start; In2 Dir, In1 Start fwd; In2 Start rev or Control panel.	Edge
	Edge	The start signal is edge-triggered.	0
	Level	The start signal is level-triggered.	1
20.08	Ext2 in1 source	Selects source 1 for parameter 20.06 Ext2 commands. For the available selections, see parameter 20.03 Ext1 in1 source.	Not selected
20.09	Ext2 in2 source	Selects source 2 for parameter 20.06 Ext2 commands. For the available selections, see parameter 20.03 Ext1 in1 source.	Not selected
20.10	Ext2 in3 source	Selects source 3 for parameter 20.06 Ext2 commands. For the available selections, see parameter 20.03 Ext1 in1 source.	Not selected
20.11	Run enable stop mode	Selects the way the motor is stopped when the run enable signal switches off.  The source of the run enable signal is selected by parameter 20.12 Run enable 1 source.	Coast (95.20 b10)
	Coast	Stop by switching off the output semiconductors of the drive. The motor coasts to a stop.  WARNING! If a mechanical brake is used, ensure it is safe to stop the drive by coasting.	0
	Ramp	Stop along the active deceleration ramp. See parameter group 23 Speed reference ramp on page 268.	1
	Torque limit	Stop according to torque limits (parameters 30.19 and 30.20).	2
20.12	Run enable 1 source	Selects the source of external run enable signal. If the run enable signal is switched off, the drive does not start. If already running, the drive stops according to the setting in parameter 20.11 Run enable stop mode.  1 = Run enable signal on.  Note: You can suppress the warning that indicates a missing signal using parameter 20.30 Enable signals warning function.  See also parameter 20.19 Enable start command.	DIIL (95.20 b10); Selected (95.20 b5); DI5 (95.20 b10)
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	FBAAMCW bit 3	Control word bit 3 received through fieldbus interface A.	30

No.	Name/Value	Description	Def/FbEq16
	EFB MCW bit 3	Control word bit 3 received through the embedded fieldbus interface.	32
	DIIL	DIIL input (10.02 DI delayed status, bit 15).	33
	Active control source MCW bit 3	Control word bit 3 received from the active control source. In case the active source is the control panel, PC tool or drive I/O, the run enable signal is always on.  Note: If the drive is running, switching bit 3 off effectively removes both the start and run enable signals. In this case, the stop mode is determined by either 20.11 Run enable stop mode or 21.03 Stop mode, whichever mode has higher priority. The order of stop modes from highest to lowest priority is Coast – Torque limit – Ramp.	34
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
20.19	Enable start command	Selects the source for the start enable signal.  1 = Start enable.  With the signal switched off, any drive start command is inhibited. (Switching the signal off while the drive is running will not stop the drive.)  Notes:  • If a level-triggered start command is on when the start enable signal switches on, the drive will start. (An edge-triggered start signal must be cycled for the drive to start.) See parameters 20.02 Ext1 start trigger type, 20.07 Ext2 start trigger type and 20.29 Local start trigger type.  • The warning that indicates a missing signal can be suppressed using parameter 20.30 Enable signals warning function.  See also parameter 20.12 Run enable 1 source.	Selected
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	DIIL	DIIL input (10.02 DI delayed status, bit 15).	30
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-

No.	Name/Value	Description	Def/FbEq16
20.23	Positive speed enable	Selects the source of the positive speed enable command.  1 = Positive speed enabled.  0 = Positive speed interpreted as zero speed reference. In the figure below, 23.01 Speed ref ramp input is set to zero after the positive speed enable signal has cleared.  Actions in different control modes:  Speed control: Speed reference is set to zero and the motor ramps down along the currently active deceleration ramp. The drive keeps modulating. The rush controller prevents additional torque terms from running the motor in the positive direction.  Torque control: The rush controller monitors the rotation direction of the motor.	Selected
	20.23 Positive speed	d enable	-
	20.24 Negative spee	d enable	
	23.01 Speed ref ra	mp input	-
	01.01 Motor spe	eed used	
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
			11 -

No.	Name/Value	Description	Def/FbEq16
20.25	Jogging enable	Selects the source for a jog enable signal.  (The sources for jogging activation signals are selected by parameters 20.26 Jogging 1 start source and 20.27 Jogging 2 start source.)  1 = Jogging is enabled.  0 = Jogging is disabled.  Note: Jogging can be enabled only when no start command from an external control location is active. On the other hand, if jogging is already enabled, the drive cannot be started from an external control location (apart from inching commands through fieldbus).  See section Jogging (page 97).	Not selected
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
20.26	Jogging 1 start source	If enabled by parameter 20.25 Jogging enable, selects the source for the activation of jogging function 1. (Jogging function 1 can also be activated through fieldbus regardless of parameter 20.25.)  1 = Jogging 1 active.  Note: If both jogging 1 and 2 are activated, the one that was activated first has priority.	Not selected
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-

No.	Name/Va	alue	Description	on	Def/FbEq16	
20.27	Jogging source	2 start	If enabled source for function 2 of parametric 1 = Joggin For the set source.  Note: If boactivated f	Not selected		
20.29	Local sta type	art trigger		Defines whether the start signal for local control (for example, control panel or PC tool) is edge-triggered or level-triggered.		
	Edge		The start s	signal is edge-triggered.	0	
	Level		The start s	signal is level-triggered.	1	
20.30 Enable signals warning function		warnings t prevent the Whenever correspond generated	able signal (e.g., run enable, start enable) o be suppressed. This parameter can be used to ese warnings from flooding the event log. a bit of this parameter is set to 1, the ding warning is suppressed, i.e. no warning is even if the signal is switched off. f this binary number correspond to the following	00b		
	Bit	Name		Warning		
	0	Enable Sta	rt	AFEA Enable start signal missing		
	1	Run enable	:1	AFEB Run enable missing		
	215 Reserved					
00b11b Supp		Suppressi	uppression of "enable signal missing" warnings.			
source			stop modes; emergency stop mode and signal ection; DC magnetization settings; autophasing ction.			

21 Start/stop mode	Start and stop modes; emergency stop mode and signal source selection; DC magnetization settings; autophasing mode selection.	
21.01 Start mode	<ul> <li>Selects the motor start function for the DTC motor control mode, i.e. when 99.04 Motor control mode is set to DTC.</li> <li>Notes:</li> <li>The start function for the scalar motor control mode is selected by parameter 21.19 Scalar start mode.</li> <li>Starting into a rotating motor is not possible when DC magnetizing is selected (Fast or Constant time).</li> <li>With permanent magnet motors and synchronous reluctance motors, Automatic start mode must be used.</li> <li>This parameter cannot be changed while the drive is running.</li> <li>See also section DC magnetization (page 105).</li> </ul>	Automatic
Fast	The drive pre-magnetizes the motor before start. The pre-magnetizing time is determined automatically, being typically 200 ms to 2 s depending on motor size. This mode should be selected if a high break-away torque is required.	0

No.	Name/Value	Description		Def/FbEq16
	Constant time	magnetizing time is defined Magnetization time. This mo constant pre-magnetizing tim start must be synchronized where brake). This setting also guabreak-away torque when the long enough.  WARNING! The drive magnetizing time has magnetization is not all magnetization.	de should be selected if the is required (e.g. if the motor with the release of a mechanical rantees the highest possible a pre-magnetizing time is set a will start after the set is passed even if motor completed. In applications we is essential, ensure that the along enough to allow	1
	Automatic	Automatic start guarantees of cases. It includes the flying strotating motor) and the autor motor can be restarted immer motor flux to die away). The identifies the flux as well as motor and starts the motor in	start function (starting into a matic restart function (a stopped ediately without waiting the drive motor control program the mechanical state of the	2
	Flying start	This method is intended for a is optimized for applications into a rotating motor at high	3	
21.02	Magnetization time			
		Motor rated power	Constant magnetizing time	
		< 1 kW	≥ 50 to 100 ms	
		1 to 10 kW	≥ 100 to 200 ms	
		10 to 200 kW	≥ 200 to 1000 ms	
		200 to 1000 kW	≥ 1000 to 2000 ms	
		<b>Note:</b> This parameter canno running.	t be changed while the drive is	
	0 10000 ms	Constant DC magnetizing tir	ne.	1 = 1 ms
21.03	Stop mode	Selects the way the motor is is received. Additional braking is possible parameter 97.05 Flux braking. Note: This parameter has no master/follower configuration.	Coast	
	Coast	The motor coasts to a stop.	out semiconductors of the drive.  nanical brake is used, ensure it ve by coasting.	0

No.	Name/Value	Description	Def/FbEq16
	Ramp	Stop along the active deceleration ramp. See parameter group 23 Speed reference ramp on page 268.	1
	Torque limit	Stop according to torque limits (parameters 30.19 and 30.20).	2
21.04	Emergency stop mode	Selects the way the motor is stopped when an emergency stop command is received.  The source of the emergency stop signal is selected by parameter 21.05 Emergency stop source.	Ramp stop (Off1); Coast stop (Off2) (95.20 b1); Eme ramp stop (Off3) (95.20 b1)
	Ramp stop (Off1)	<ul> <li>With the drive running:</li> <li>1 = Normal operation.</li> <li>0 = Normal stop along the standard deceleration ramp defined for the particular reference type (see section <i>Reference ramping</i> [page <i>84</i>]). After the drive has stopped, it can be restarted by removing the emergency stop signal and switching the start signal from 0 to 1.</li> <li>With the drive stopped:</li> <li>1 = Starting allowed.</li> <li>0 = Starting not allowed.</li> </ul>	0
	Coast stop (Off2)	<ul> <li>With the drive running:</li> <li>1 = Normal operation.</li> <li>0 = Stop by coasting. The drive can be restarted by restoring the start interlock signal and switching the start signal from 0 to 1.</li> <li>With the drive stopped:</li> <li>1 = Starting allowed.</li> <li>0 = Starting not allowed.</li> </ul>	1
	Eme ramp stop (Off3)	<ul> <li>With the drive running:</li> <li>1 = Normal operation</li> <li>0 = Stop by ramping along emergency stop ramp defined by parameter 23.23 Emergency stop time. After the drive has stopped, it can be restarted by removing the emergency stop signal and switching the start signal from 0 to 1.</li> <li>With the drive stopped:</li> <li>1 = Starting allowed</li> <li>0 = Starting not allowed</li> </ul>	2
21.05	Emergency stop source	Selects the source of the emergency stop signal. The stop mode is selected by parameter 21.04 Emergency stop mode.  0 = Emergency stop active 1 = Normal operation  Note: This parameter cannot be changed while the drive is running.	Inactive (true); DI4 (95.20 b1), (95.20 b2)
	Active (false)	0.	0
	Inactive (true)	1.	1
	DIIL	DIIL input (10.02 DI delayed status, bit 15).	2
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	3
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	4
	DIZ	, ,	
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	5

No.	Name/Value	Description	Def/FbEq16
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	7
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	8
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	11
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	12
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
21.06	Zero speed limit	Defines the zero speed limit. The motor is stopped along a speed ramp (when ramped stop is selected) until the defined zero speed limit is reached. After the zero speed delay, the motor coasts to a stop.  Note: If you use a value below the default, make sure the drive is able to stop.	30.00 rpm
	0.00 30000.00 rpm	Zero speed limit.	See par. 46.01
21.07	Zero speed delay	Defines the delay for the zero speed delay function. The function is useful in applications where a smooth and quick restarting is essential. During the delay, the drive knows the rotor position accurately.  Without zero speed delay: The drive receives a stop command and decelerates along a ramp. When actual motor speed falls below the value of parameter 21.06 Zero speed limit, inverter modulation is stopped and the motor coasts to a standstill.  Speed  Speed controller switched off: Motor coasts to a stop.	0 ms
		Time	

No.	Name/Value	Description	Def/FbEq16
		With zero speed delay: The drive receives a stop command and decelerates along a ramp. When actual motor speed falls below the value of parameter 21.06 Zero speed limit, the zero speed delay function activates. During the delay the function keeps the speed controller live: the inverter modulates, motor is magnetized and the drive is ready for a quick restart. Zero speed delay can be used e.g. with the jogging function.	
		Speed Speed controller remains active. Motor is decelerated to true zero speed.  Time	
	0 30000 ms	Zero speed delay.	1 = 1 ms
21.08	DC current control	<ul> <li>Activates/deactivates the DC hold and post-magnetization functions. See section <i>DC magnetization</i> (page 105).</li> <li>Notes:</li> <li>DC hold is only available with speed control in DTC motor control mode (see page 43).</li> <li>DC magnetization causes the motor to heat up. In applications where long DC magnetization times are required, externally ventilated motors should be used. If the DC magnetization period is long, DC magnetization cannot prevent the motor shaft from rotating if a constant load is applied to the motor.</li> </ul>	0000b
	Bit Value		
	0 1 = Enab	e DC hold. See section DC hold (page 105).	
	1 1 = Enabl Note: Po:	e DC hold function has no effect if the start signal is switched of e post-magnetization. See section <i>Post-magnetization</i> (page 10 st-magnetization is only available when ramping is the selected	<del>96</del> ).
	1 1 = Enabl Note: Po:	e DC hold function has no effect if the start signal is switched of e post-magnetization. See section <i>Post-magnetization</i> (page 10 st-magnetization is only available when ramping is the selected meter 21.03 Stop mode).	<del>96</del> ).
	1 1 = Enable Note: Post (see paral 215   Reserved	e DC hold function has no effect if the start signal is switched of e post-magnetization. See section <i>Post-magnetization</i> (page 10 st-magnetization is only available when ramping is the selected meter 21.03 Stop mode).	of). stop mode
21.09	Note: The 1 = Enable Note: Post (see para	e DC hold function has no effect if the start signal is switched of e post-magnetization. See section <i>Post-magnetization</i> (page 10 st-magnetization is only available when ramping is the selected meter 21.03 Stop mode).	<del>76</del> ).
21.09	Note: The 1 = Enable Note: Positive (see para 215   Reserved 0000b0011b	e DC hold function has no effect if the start signal is switched of the post-magnetization. See section Post-magnetization (page 10 st-magnetization is only available when ramping is the selected meter 21.03 Stop mode).  DC magnetization selection.  Defines the DC hold speed. See parameter 21.08 DC	06). stop mode
21.09	Note: The 1 = Enable Note: Post (see para 215   Reserved	e DC hold function has no effect if the start signal is switched of e post-magnetization. See section <i>Post-magnetization</i> (page 10 st-magnetization is only available when ramping is the selected meter 21.03 Stop mode).  DC magnetization selection.  Defines the DC hold speed. See parameter 21.08 DC current control, and section DC hold (page 105).	1 = 1 5.00 rpm See par.

No.	Name/Value	Description	Def/FbEq16
21.11	Post magnetization time	Defines the length of time for which post-magnetization is active after stopping the motor. The magnetization current is defined by parameter 21.10 DC current reference.  See parameter 21.08 DC current control.	0 s
	03000 s	Post-magnetization time.	1 = 1 s
21.12	Continuous magnetization command	Activates/deactivates (or selects a source that activates/deactivates) continuous magnetization. See section <i>Continuous magnetization</i> (page 106).  The magnetization current is calculated on the basis of flux reference (see parameter group 97 <i>Motor control</i> ).  Note:  • This function is available only in DTC motor control mode.  • Continuous magnetization causes the motor to heat up. In applications where long magnetization times are required, externally ventilated motors should be used.  • Continuous magnetization may not prevent the motor shaft from rotating for a long period if a constant load is applied to the motor.  0 = Normal operating  1 = Magnetization is active	Off
	Off	0.	0
	On	1.	1
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
21.13	Autophasing mode	Selects the way autophasing is performed. See section <i>Autophasing</i> on page <i>101</i> . <b>Note:</b> This parameter cannot be changed while the drive is running.	Turning
	Turning	This mode gives the most accurate autophasing result. This mode can be used, and is recommended, if the motor is allowed to rotate during the ID run and the start-up is not time-critical.  Note: This mode will cause the motor to rotate. The load torque must be less than 5%.	0
	Standstill 1	Faster than the <i>Turning</i> mode, but not as accurate. The motor will not rotate.	1
	Standstill 2	An alternative standstill autophasing mode that can be used if the <i>Turning</i> mode cannot be used, and the <i>Standstill 1</i> mode gives erratic results. However, this mode is considerably slower than <i>Standstill 1</i> .	2
	Turning with Z-pulse	This mode is used to observe the zero pulse signal of the pulse encoder and when other modes do not give a result. The motor turns until a zero pulse is detected.	3

No.	Name/Value	Description	Def/FbEq16
21.14	Pre-heating input source	Selects the source of the motor pre-heat on/off command. See section <i>Pre-heating</i> (page 105).  Note: The pre-heating function does not activate if  the Safe torque off function is active,  a fault is active,  less than one minute has elapsed after stopping, or  PID sleep function is active.  Pre-heating is deactivated when the drive is started, and overridden by pre-magnetization, post-magnetization or continuous magnetization.  Pre-heating is inactive  1 = Pre-heating is active	Off
	Off	O. Pre-heating is always deactivated.	0
	On	Pre-heating is always activated when the drive is stopped (apart from conditions stated above).	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	Supervision 1	Supervision 1 active (32.01 Supervision status, bit 0).	8
	Supervision 2	Supervision 2 active (32.01 Supervision status, bit 1).	9
	Supervision 3	Supervision 3 active (32.01 Supervision status, bit 2).	10
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
21.16	Pre-heating current	Defines the motor pre-heating current that is fed into the motor when the source selected by 21.14 Pre-heating input source is on. The value is in percent of the nominal motor current.	0.0%
	0.0 30.0%	Pre-heating current.	1 = 1%
21.18	Auto restart time	The motor can be automatically started after a short supply power failure using the automatic restart function. See section <i>Automatic restart</i> (page 118).  When this parameter is set to 0.0 seconds, automatic restarting is disabled. Otherwise, the parameter defines the maximum duration of the power failure after which restarting is attempted. Note that this time also includes the DC precharging delay.  WARNING! The function restarts the drive automatically and continues operation after a supply break. Make sure that no dangerous situations can occur.	5.0 s
	0.0 s	Automatic restarting disabled.	0
	0.1 5.0 s	Maximum power failure duration.	1 = 1 s
		+	

No.	Name/Value	Description	Def/FbEq16
21.19	Scalar start mode	Selects the motor start function for the scalar motor control mode, i.e. when 99.04 Motor control mode is set to Scalar.  Notes:  • The start function for the DTC motor control mode is selected by parameter 21.01 Start mode.  • With permanent magnet motors, Automatic start mode must be used.  See also section DC magnetization (page 105).	Normal
	Normal	Immediate start from zero speed.	0
	Const time	The drive pre-magnetizes the motor before start. The pre-magnetizing time is defined by parameter 21.02  Magnetization time. This mode should be selected if constant pre-magnetizing time is required (e.g. if the motor start must be synchronized with the release of a mechanical brake). This setting also guarantees the highest possible break-away torque when the pre-magnetizing time is set long enough.  Note: This mode cannot be used to start into a rotating motor.  WARNING! The drive will start after the set magnetizing time has passed even if motor magnetization is not completed. In applications where a full break-away torque is essential, ensure that the constant magnetizing time is long enough to allow generation of full magnetization and torque.	1
	Automatic	<ul> <li>This setting should be used</li> <li>in applications where flying starts (i.e. starting into a rotating motor) are required, and</li> <li>with permanent magnet motors.</li> </ul>	2
21.20	Follower force ramp stop	In a torque-controlled follower drive, forces (or selects a source that forces) the drive to switch to speed control upon a ramp stop command.  See also section <i>Master/follower functionality</i> (page 74).  1 = Ramp stop forces speed control	Not selected
	Not selected	0.	0
	Selected	1.	1
	DIIL	DIIL input (10.02 DI delayed status, bit 15).	2
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	3
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	4
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	5
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	6
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	7
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	8
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	11
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	12
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-

No. Name/Value	Description	Def/FbEq16
22 Speed reference selection	Speed reference selection; motor potentiometer settings. See the control chain diagrams on pages 680682.	
22.01 Speed ref unlimited	Displays output of the speed reference selection block. See the control chain diagram on page <i>681</i> . This parameter is read-only.	-
-30000.00 30000.00 rpm	Value of the selected speed reference.	See par. 46.01
22.11 Speed ref1 source	Selects speed reference source 1. Two signal sources can be defined by this parameter and 22.12 Speed ref2 source. A digital source selected by 22.14 Speed ref1/2 selection can be used to switch between the two sources, or a mathematical function (22.13 Speed ref1 function) applied to the two signals to create the reference.	Al1 scaled
0 — AI — FB —  Other —	22.11  22.11  Ref1  SUB  MIN  MAX  22.12  22.82	22.83
Zero	None.	0
Al1 scaled	12.12 Al1 scaled value (see page 207).	1
Al2 scaled	12.22 AI2 scaled value (see page 208).	2
FB A ref1	03.05 FB A reference 1 (see page 165).	4
FB A ref2	03.06 FB A reference 2 (see page 165).	5
EFB ref1	03.09 EFB reference 1 (see page 165).	8
EFB ref2	03.10 EFB reference 2 (see page 165).	9
DDCS ctrl ref1	03.11 DDCS controller ref 1 (see page 165).	10
DDCS ctrl ref2	03.12 DDCS controller ref 2 (see page 165).	11
M/F reference 1	03.13 M/F or D2D ref1 (see page 165).	12
M/F reference 2	03.14 M/F or D2D ref2 (see page 166).	13
Motor potentiometer	22.80 Motor potentiometer ref act (output of the motor potentiometer).	15
PID	40.01 Process PID output actual (output of the process PID controller).	16
Control panel (ref saved)	Control panel reference, with initial value from last-used panel reference. See section <i>Using the control panel as an external control source</i> (page 41).	18

No.	Name/Value	Description	Def/FbEq16
	Control panel (ref copied)	Control panel reference, with initial value from previous source or actual value. See section <i>Using the control panel as an external control source</i> (page 41).	19
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
22.12	Speed ref2 source	Selects speed reference source 2. For the selections, and a diagram of reference source selection, see parameter 22.11 Speed ref1 source.	Zero
22.13	Speed ref1 function	Selects a mathematical function between the reference sources selected by parameters 22.11 Speed ref1 source and 22.12 Speed ref2 source. See diagram at 22.11 Speed ref1 source.	Ref1
	Ref1	Signal selected by 22.11 Speed ref1 source is used as speed reference 1 as such (no function applied).	0
	Add (ref1 + ref2)	The sum of the reference sources is used as speed reference 1.	1
	Sub (ref1 - ref2)	The subtraction ([22.11 Speed ref1 source] - [22.12 Speed ref2 source]) of the reference sources is used as speed reference 1.	2
	Mul (ref1 × ref2)	The multiplication of the reference sources is used as speed reference 1.	3
	Min (ref1, ref2)	The smaller of the reference sources is used as speed reference 1.	4
	Max (ref1, ref2)	The greater of the reference sources is used as speed reference 1.	5
22.14	Speed ref1/2 selection	Configures the selection between speed references 1 and 2. See diagram at 22.11 Speed ref1 source.  0 = Speed reference 1 1 = Speed reference 2	Follow Ext1/Ext2 selection
	Speed reference 1	0.	0
	Speed reference 2	1.	1
	Follow Ext1/Ext2 selection	Speed reference 1 is used when external control location EXT1 is active. Speed reference 2 is used when external control location EXT2 is active.  See also parameter 19.11 Ext1/Ext2 selection.	2
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	3
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	4
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	5
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	6
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	7
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	8
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	11
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	12
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 156).	-

No.	Name/Va	alue	Description Def/FbE		
22.15	Speed ac source	dditive 1	Defines a reference to be added to the speed reference after reference selection (see page 680).  For the selections, see parameter 22.11 Speed ref1 source.  Note: For safety reasons, the additive is not applied when any of the stop functions are active.	Zero	
22.16	Speed si	hare	Defines a scaling factor for the selected speed reference (speed reference 1 or 2, multiplied by the defined value). Speed reference 1 or 2 is selected by parameter 22.14 Speed ref1/2 selection.	1.000	
	-8.000	.8.000	Speed reference scaling factor.	1000 = 1	
22.17	Speed additive 2 source		Defines a reference to be added to the speed reference after the speed share function (see page 680).  For the selections, see parameter 22.11 Speed ref1 source.  Note: For safety reasons, the additive is not applied when any of the stop functions are active.	Zero	
22.21	Constant function	t speed	Determines how constant speeds are selected, and whether the rotation direction signal is considered or not when applying a constant speed.	0000b	
	Bit	Name	Information		
	0	Constant speed mode	1 = Packed: 7 constant speeds are selectable using the t defined by parameters 22.22, 22.23 and 22.24.	hree sources	
			0 = Separate: Constant speeds 1, 2 and 3 are separately the sources defined by parameters 22.22, 22.23 and 22.2 In case of conflict, the constant speed with the smaller nu priority.	4 respectively.	
	1	Direction enable	1 = Start dir: To determine running direction for a constant sign of the constant speed setting (parameters 22.2622 multiplied by the direction signal (forward: +1, reverse: -1 effectively allows the drive to have 14 (7 forward, 7 reversed speeds if all values in 22.2622.32 are positive.  WARNING: If the direction signal is reverse and the constant speed is negative, the drive will run in the direction.	2.32) is ). This se) constant ne active e forward	
			0 = Accord Par: The running direction for the constant sped determined by the sign of the constant speed setting (par 22.2622.32).		
	215	Reserved			
	0000b	0011b	Constant speed configuration word.	1 = 1	

No.	Name/	Value	Description			Def/FbEq16
22.22	When bit 0 of parameter 22.21 Constant speed function is 0 (Separate), selects a source that activates constant speed 1 When bit 0 of parameter 22.21 Constant speed function is 1 (Packed), this parameter and parameters 22.23 Constant speed sel2 and 22.24 Constant speed sel3 select three sources whose states activate constant speeds as follows:					Not selected
		Source defin by par. 22.2		Source defined by par. 22.24	Constant speed ac	ctive
		0	0	0	None	
		1	0	0	Constant speed	
		0	1	0	Constant speed	
		1	1	0	Constant speed	
		0	0 0	1	Constant speed Constant speed	
		0	1	1	Constant speed	
		1	1	1	Constant speed	
	Not sel	ected	0 (always off).			0
	Selecte	ed	1 (always on).			1
	DI1		Digital input DI1 (10.	02 DI delayed statı	us, bit 0).	2
	DI2		Digital input DI2 (10.	02 DI delayed statu	us, bit 1).	3
	DI3		Digital input DI3 (10.	02 DI delayed statu	us, bit 2).	4
	DI4		Digital input DI4 (10.	02 DI delayed statu	us, bit 3).	5
	DI5		Digital input DI5 (10.	02 DI delayed statı	<i>is</i> , bit 4).	6
	DI6		Digital input DI6 (10.	02 DI delayed statı	<i>us</i> , bit 5).	7
	DIO1		Digital input/output D	IO1 (11.02 DIO de	layed status, bit 0).	10
	DIO2		Digital input/output D	IO2 (11.02 DIO de	layed status, bit 1).	11
	Other [	bit]	Source selection (see page 156).	e Terms and abbre	viations on	-
22.23	Constant speed sel2		When bit 0 of parame (Separate), selects a When bit 0 of parame (Packed), this param speed sel1 and 22.2 sources that are used at parameter 22.22 C For the selections, sesel1.	source that activate ter 22.21 Constant eter and paramete 4 Constant speed 5 to activate constant speed sel	tes constant speed 2.  t speed function is 1 rs 22.22 Constant sel3 select three nt speeds. See table 1.	Not selected
22.24	Consta sel3	nt speed	When bit 0 of parame (Separate), selects a When bit 0 of parame (Packed), this param speed sel1 and 22.2 sources that are used at parameter 22.22 CF or the selections, sesel1.	source that activate ter 22.21 Constant eter and paramete 3 Constant speed 5 to activate constant speed selfonstant speed selfons speed selfonstant speed se	tes constant speed 3.  t speed function is 1 rs 22.22 Constant sel2 select three nt speeds. See table 1.	Not selected

No.	Name/Value	Description	Def/FbEq16
22.26	Constant speed 1	Defines constant speed 1 (the speed the motor will turn when constant speed 1 is selected).	300.00 rpm
	-30000.00 30000.00 rpm	Constant speed 1.	See par. 46.01
22.27	Constant speed 2	Defines constant speed 2.	0.00 rpm
	-30000.00 30000.00 rpm	Constant speed 2.	See par. 46.01
22.28	Constant speed 3	Defines constant speed 3.	0.00 rpm
	-30000.00 30000.00 rpm	Constant speed 3.	See par. 46.01
22.29	Constant speed 4	Defines constant speed 4.	0.00 rpm
	-30000.00 30000.00 rpm	Constant speed 4.	See par. 46.01
22.30	Constant speed 5	Defines constant speed 5.	0.00 rpm
	-30000.00 30000.00 rpm	Constant speed 5.	See par. 46.01
22.31	Constant speed 6	Defines constant speed 6.	0.00 rpm
	-30000.00 30000.00 rpm	Constant speed 6.	See par. 46.01
22.32	Constant speed 7	Defines constant speed 7.	0.00 rpm
	-30000.00 30000.00 rpm	Constant speed 7.	See par. 46.01
22.41	Speed ref safe	Defines a safe speed reference value that is used with supervision functions such as  12.03 AI supervision function  49.05 Communication loss action  50.02 FBA A comm loss func  50.32 FBA B comm loss func  58.14 Communication loss action.	0.00 rpm
	-30000.00 30000.00 rpm	Safe speed reference.	See par. 46.01
22.42	Jogging 1 ref	Defines the speed reference for jogging function 1. For more information on jogging, see page 97.	0.00 rpm
	-30000.00 30000.00 rpm	Speed reference for jogging function 1.	See par. 46.01
22.43	Jogging 2 ref	Defines the speed reference for jogging function 2. For more information on jogging, see page 97.	0.00 rpm
	-30000.00 30000.00 rpm	Speed reference for jogging function 2.	See par. 46.01

No.	Name/V	alue alue	Description	Def/FbEq16
22.51	Critical speed function		Enables/disables the critical speeds function. Also determines whether the specified ranges are effective in both rotating directions or not.  See also section <i>Critical speeds/frequencies</i> (page 85).	0000ь
	Bit	Name	Information	
	0	Enable	1 = Enable: Critical speeds enabled.	
			0 = Disable: Critical speeds disabled.	
	1	Sign mode	1 = Signed: The signs of parameters 22.5222.57 are taken account.	into
			0 = Absolute: Parameters 22.5222.57 are handled as absolutes. Each range is effective in both directions of rotation.	lute
	215	Reserved	•	
	0000b	.0011b	Critical speeds configuration word.	1 = 1
22.52	Critical	speed 1 low	Defines the low limit for critical speed range 1. <b>Note:</b> This value must be less than or equal to the value of 22.53 Critical speed 1 high.	0.00 rpm
	-30000.0 30000.0		Low limit for critical speed 1.	See par. 46.01
22.53	Critical	speed 1 high	Defines the high limit for critical speed range 1. <b>Note:</b> This value must be greater than or equal to the value of 22.52 Critical speed 1 low.	0.00 rpm
	-30000.0 30000.0		High limit for critical speed 1.	See par. 46.01
22.54	Critical	speed 2 low	Defines the low limit for critical speed range 2. <b>Note:</b> This value must be less than or equal to the value of 22.55 Critical speed 2 high.	0.00 rpm
	-30000.0 30000.0		Low limit for critical speed 2.	See par. 46.01
22.55	Critical	speed 2 high	Defines the high limit for critical speed range 2. <b>Note:</b> This value must be greater than or equal to the value of 22.54 Critical speed 2 low.	0.00 rpm
	-30000.0 30000.0		High limit for critical speed 2.	See par. 46.01
22.56	Critical	speed 3 low	Defines the low limit for critical speed range 3. <b>Note:</b> This value must be less than or equal to the value of 22.57 Critical speed 3 high.	0.00 rpm
	-30000.0 30000.0		Low limit for critical speed 3.	See par. 46.01
22.57	Critical	speed 3 high	Defines the high limit for critical speed range 3. <b>Note:</b> This value must be greater than or equal to the value of 22.56 Critical speed 3 low.	0.00 rpm
	-30000.0 30000.0		High limit for critical speed 3.	See par. 46.01
22.71	Motor po	otentiometer	Activates and selects the mode of the motor potentiometer. See section Scalar motor control (page 100).	Disabled
	Disable	<b>-</b>	Motor potentiometer is disabled and its value set to 0.	0

No.	Name/Value	Description	Def/FbEq16
	Enabled (init at stop/power-up)	When enabled, the motor potentiometer first adopts the value defined by parameter 22.72 Motor potentiometer initial value. When the drive is operating, the value can be adjusted from the up and down sources defined by parameters 22.73 Motor potentiometer up source and 22.74 Motor potentiometer down source.  A stop or a power cycle resets the motor potentiometer to the initial value (22.72).	1
	Enabled (resume always)	Functions as in <i>Enabled (init at stop/power-up)</i> , but retains the motor potentiometer value over a stop or a power cycle.	2
22.72	Motor potentiometer initial value	Defines an initial value (starting point) for the motor potentiometer. See the selections of parameter 22.71 Motor potentiometer function.	0.00
	-32768.00 32767.00	Initial value for motor potentiometer.	1 = 1
22.73	Motor potentiometer up source	Selects the source of motor potentiometer up signal.  0 = No change  1 = Increase motor potentiometer value. (If both the up and down sources are on, the potentiometer value will not change.)	Not selected
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
22.74	Motor potentiometer down source	Selects the source of motor potentiometer down signal.  0 = No change  1 = Decrease motor potentiometer value. (If both the up and down sources are on, the potentiometer value will not change.)  For the selections, see parameter 22.73 Motor potentiometer up source.	Not selected
22.75	Motor potentiometer ramp time	Defines the change rate of the motor potentiometer. This parameter specifies the time required for the motor potentiometer to change from minimum (22.76) to maximum (22.77). The same change rate applies in both directions.	60.0 s
	0.0 3600.0 s	Motor potentiometer change time.	10 = 1 s
22.76	Motor potentiometer min value	Defines the minimum value of the motor potentiometer.	-1500.00
	-32768.00 32767.00	Motor potentiometer minimum.	1 = 1

No.	Name/Value	Description	Def/FbEq16
22.77	Motor potentiometer max value	Defines the maximum value of the motor potentiometer.	1500.00
	-32768.00 32767.00	Motor potentiometer maximum.	1 = 1
22.80	Motor potentiometer ref act	Displays output of the motor potentiometer function. (The motor potentiometer is configured using parameters 22.7122.74.)	-
	00700.00	This parameter is read-only.	
	-32768.00 32767.00	Value of motor potentiometer.	1 = 1
22.81	Speed reference act 1	Displays value of speed reference source 1 (selected by parameter 22.11 Speed ref1 source). See the control chain diagram on page 680.  This parameter is read-only.	-
	-30000.00 30000.00 rpm	Value of reference source 1.	See par. 46.01
22.82	Speed reference act 2	Displays value of speed reference source 2 (selected by parameter 22.12 Speed ref2 source). See the control chain diagram on page 680.  This parameter is read-only.	-
	-30000.00 30000.00 rpm	Value of reference source 2.	See par. 46.01
22.83	Speed reference act 3	Displays value of speed reference after the mathematical function applied by parameter 22.13 Speed ref1 function and reference 1/2 selection (22.14 Speed ref1/2 selection). See the control chain diagram on page 680. This parameter is read-only.	-
	-30000.00 30000.00 rpm	Speed reference after source selection.	See par. 46.01
22.84	Speed reference act 4	Displays value of speed reference after application of 1st speed additive (22.15 Speed additive 1 source). See the control chain diagram on page 680.  This parameter is read-only.	-
	-30000.00 30000.00 rpm	Speed reference after additive 1.	See par. 46.01
22.85	Speed reference act 5	Displays value of speed reference after the application of the speed share scaling factor (22.16 Speed share). See the control chain diagram on page 680.  This parameter is read-only.	-
	-30000.00 30000.00 rpm	Speed reference after speed share scaling.	See par. 46.01
22.86	Speed reference act 6	Displays value of speed reference after application of 2nd speed additive (22.17 Speed additive 2 source). See the control chain diagram on page 680.  This parameter is read-only.	-
	-30000.00 30000.00 rpm	Speed reference after additive 2.	See par. 46.01

No.	Name/Value	Description	Def/FbEq16
22.87	Speed reference act 7	Displays value of speed reference before application of critical speeds. See the control chain diagram on page 681. The value is received from 22.86 Speed reference act 6 unless overridden by  • any constant speed  • a jogging reference  • Network control reference  • control panel reference  • safe speed reference.  This parameter is read-only.	-
	-30000.00 30000.00 rpm	Speed reference before application of critical speeds.	See par. 46.01

23 Speramp	eed reference	Speed reference ramp settings (programming of the acceleration and deceleration rates for the drive).  See the control chain diagram on page 682.	
23.01	Speed ref ramp input	Displays used speed reference (in rpm) before it enters the ramping and shaping functions. See the control chain diagram on page 682.  This parameter is read-only.	-
	-30000.00 30000.00 rpm	Speed reference before ramping and shaping.	See par. 46.01
23.02	Speed ref ramp output	Displays ramped and shaped speed reference in rpm. See the control chain diagram on page 682. This parameter is read-only.	-
	-30000.00 30000.00 rpm	Speed reference after ramping and shaping.	See par. 46.01
23.11	Ramp set selection	Selects the source that switches between the two sets of acceleration/deceleration ramp times defined by parameters 23.1223.15.  0 = Acceleration time 1 and deceleration time 1 are active 1 = Acceleration time 2 and deceleration time 2 are active	Acc/Dec time 1
	Acc/Dec time 1	0.	0
	Acc/Dec time 2	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 156).	-

No.	Name/Value	Description	Def/FbEq16
23.12	Acceleration time 1	Defines acceleration time 1 as the time required for the speed to change from zero to the speed defined by parameter 46.01 Speed scaling (not to parameter 30.12 Maximum speed).  If the speed reference increases faster than the set acceleration rate, the motor speed will follow the acceleration rate.  If the speed reference increases slower than the set acceleration rate, the motor speed will follow the reference. If the acceleration time is set too short, the drive will automatically prolong the acceleration in order not to exceed the drive torque limits.	20.000 s
	0.0001800.000 s	Acceleration time 1.	10 = 1 s
23.13	Deceleration time 1	Defines deceleration time 1 as the time required for the speed to change from the speed defined by parameter 46.01 Speed scaling (not from parameter 30.12 Maximum speed) to zero.  If the speed reference decreases slower than the set deceleration rate, the motor speed will follow the reference. If the reference changes faster than the set deceleration rate, the motor speed will follow the deceleration rate. If the deceleration rate is set too short, the drive will automatically prolong the deceleration in order not to exceed drive torque limits (or not to exceed a safe DC link voltage). If there is any doubt about the deceleration time being too short, ensure that DC overvoltage control is on (parameter 30.30 Overvoltage control).  Note: If a short deceleration time is needed for a high inertia application, the drive should be equipped with braking equipment such as a brake chopper and brake resistor.	20.000 s
	0.0001800.000 s	Deceleration time 1.	10 = 1 s
23.14	Acceleration time 2	Defines acceleration time 2. See parameter 23.12  Acceleration time 1. Acceleration time 2 changes according to the roll diameter.	60.000 s
	0.0001800.000 s	Acceleration time 2.	10 = 1 s
23.15	Deceleration time 2	Defines deceleration time 2. See parameter 23.13  Deceleration time 1. Deceleration time 2 changes according to the roll diameter.	60.000 s
	0.0001800.000 s	Deceleration time 2.	10 = 1 s

No.	Name/Value	Description	Def/FbEq16
23.16	Shape time acc 1	Defines the shape of the acceleration ramp at the beginning of the acceleration.  0.000 s: Linear ramp. Suitable for steady acceleration or deceleration and for slow ramps.  0.0011000.000 s: S-curve ramp. S-curve ramps are ideal for lifting applications. The S-curve consists of symmetrical curves at both ends of the ramp and a linear part in between.  Note: For safety reason, shape times are not applied to emergency stop ramps.  Acceleration:  Linear ramp:  23.17 = 0 s  S-curve ramp:  23.17 > 0 s  Time	0.000 s
		Deceleration:  Speed  S-curve ramp:  23.18 > 0 s  Linear ramp:  23.19 > 0 s  Linear ramp:  23.19 = 0 s  Time	
	0.0001800.000 s	Ramp shape at start of acceleration.	10 = 1 s
23.17	Shape time acc 2	Defines the shape of the acceleration ramp at the end of the acceleration. See parameter 23.16 Shape time acc 1.	0.000 s
	0.0001800.000 s	Ramp shape at end of acceleration.	10 = 1 s
23.18	Shape time dec 1	Defines the shape of the deceleration ramp at the beginning of the deceleration. See parameter 23.16 Shape time acc 1.	0.000 s
		and the second s	

No.	Name/Value	Description	Def/FbEq16
23.19	Shape time dec 2	Defines the shape of the deceleration ramp at the end of the deceleration. See parameter 23.16 Shape time acc 1.	0.000 s
	0.0001800.000 s	Ramp shape at end of deceleration.	10 = 1 s
23.20	Acc time jogging	Defines the acceleration time for the jogging function i.e. the time required for the speed to change from zero to the speed value defined by parameter 46.01 Speed scaling.  See section Jogging (page 97).	60.000 s
	0.0001800.000 s	Acceleration time for jogging.	10 = 1 s
23.21	Dec time jogging	Defines the deceleration time for the jogging function i.e. the time required for the speed to change from the speed value defined by parameter 46.01 Speed scaling to zero.  See section Jogging (page 97).	60.000 s
	0.0001800.000 s	Deceleration time for jogging.	10 = 1 s
23.23	Emergency stop time	In speed control mode, this parameter defines the deceleration rate for emergency stop Off3 as the time it would take for the speed to decrease from the value of parameter 46.01 Speed scaling to zero. This also applies to torque control because the drive switches to speed control on receiving an emergency stop Off3 command. In frequency control mode, this parameter specifies the time it would take for the frequency to decrease from the value of 46.02 Frequency scaling to zero.  The emergency stop mode and activation source are selected by parameters 21.04 Emergency stop mode and 21.05 Emergency stop source respectively. Emergency stop can also be activated through fieldbus.  Note: Emergency stop Off1 uses the standard deceleration ramp as defined by parameters 23.1123.19 (speed and torque control) or 28.7128.75 (frequency control).	3.000 s
	0.0001800.000 s	Emergency stop Off3 deceleration time.	10 = 1 s
23.24	Speed ramp in zero source	Selects a source that forces the speed reference to zero just before it enters the ramp function.  0 = Force speed reference to zero before the ramp function 1 = Speed reference continues towards the ramp function as normal	Inactive
	Active	0.	0
	Inactive	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-

No.	Name/Value	Description	Def/FbEq16
23.26	Ramp out balancing enable	Selects the source for enabling/disabling speed reference ramp balancing.  This function is used to generate a smooth transfer from a torque- or tension-controlled motor back to being speed-controlled. The balancing output would be tracking the present "line" speed of the application and when transfer is required, the speed reference can then be quickly "seeded" to the correct line speed. Balancing is also possible in the speed controller, see parameter 25.09 Speed ctrl balancing enable.  See also parameter 23.27 Ramp out balancing ref.  0 = Disabled  1 = Enabled	Not selected
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
23.27	Ramp out balancing ref	Defines the reference for speed ramp balancing. The output of the ramp generator is forced to this value when balancing is enabled by parameter 23.26 Ramp out balancing enable.	0.00 rpm
	-30000.00 30000.00 rpm	Speed ramp balancing reference.	See par. 46.01

No.	Name/Value	Description	Def/FbEq16
23.28	Variable slope enable	Activates the variable slope function, which controls the slope of the speed ramp during a speed reference change. This allows for a constantly variable ramp rate to be generated, instead of just the standard two ramps normally available.  If the update interval of the signal from an external control system and the variable slope rate (23.29 Variable slope rate) are equal, the resulting speed reference (23.02 Speed ref ramp output) is a straight line.	Off
		Speed reference  Speed reference  23.02 Speed ref ramp output  Time  t = update interval of signal from external control system A = speed reference change during t	
		This function is only active in remote control.	
	Off	Variable slope disabled.	0
	On	Variable slope enabled (not available in local control).	1
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
23.29	Variable slope rate	Defines the rate of the speed reference change when variable slope is enabled by parameter 23.28 Variable slope enable.  For the best result, enter the reference update interval into this parameter.	50 ms
	230000 ms	Variable slope rate.	1 = 1 ms
23.39	Follower speed correction out	Displays speed correction term for the load share function with a speed-controlled follower drive.  See section Load share function with a speed-controlled follower (page 75).  This parameter is read-only.	-
	-30000.00 30000.00 rpm	Speed correction term.	See par. 46.01
23.40	Follower speed correction enable	With a speed-controlled follower, selects the source for enabling/disabling the load share function.  See section Load share function with a speed-controlled follower (page 75).  0 = Disabled 1 = Enabled	Not selected
	Not selected	0.	0
	Selected	1.	1

No.	Name/Value	Description	Def/FbEq16
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
23.41	Follower speed correction gain	Adjusts the gain of the speed correction term in a speed-controlled follower. In effect, defines how accurately the follower follows the master torque. A greater value results in a more accurate performance.  See section Load share function with a speed-controlled follower (page 75).	1.00%
	0.00 100.00%	Speed correction term adjustment.	1 = 1%
23.42	Follower speed corr torq source	Selects the source of the torque reference for the load share function. See section <i>Load share function with a speed-controlled follower</i> (page 75).	MF ref 2
	NULL	None.	0
	MF ref 2	03.14 M/F or D2D ref2 (page 166).	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-

24 Speed reference conditioning		Speed error calculation; speed error window control configuration; speed error step. See the control chain diagrams on pages <i>684</i> and <i>685</i> .	
24.01	Used speed reference	Displays ramped and corrected speed reference (before speed error calculation). See the control chain diagram on page <i>684</i> .  This parameter is read-only.	-
	-30000.00 30000.00 rpm	Speed reference used for speed error calculation.	See par. 46.01
24.02	Used speed feedback	Displays speed feedback used for speed error calculation. See the control chain diagram on page 684. This parameter is read-only.	-
	-30000.00 30000.00 rpm	Speed feedback used for speed error calculation.	See par. 46.01
24.03	Speed error filtered	Displays filtered speed error. See the control chain diagram on page 684. This parameter is read-only.	-
	-30000.0 30000.0 rpm	Filtered speed error.	See par. 46.01
24.04	Speed error inverted	Displays the inverted (unfiltered) speed error. See the control chain diagram on page 684. This parameter is read-only.	-
	-30000.0 30000.0 rpm	Inverted speed error.	See par. 46.01

No.	Name/Value	Description	Def/FbEq16
24.11	Speed correction	Defines a speed reference correction, i.e. a value added to the existing reference between ramping and limitation. This is useful to trim the speed if necessary, for example to adjust draw between sections of a paper machine.  Note: For safety reasons, the correction is not applied when an emergency stop is active.  WARNING! If the speed reference correction exceeds 21.06 Zero speed limit, a ramp stop may be impossible. Make sure the correction is reduced or removed when a ramp stop is required.  See the control chain diagram on page 684.	0.00 rpm
	-10000.00 10000.00 rpm	Speed reference correction.	See par. 46.01
24.12	Speed error filter time	Defines the time constant of the speed error low-pass filter. If the used speed reference changes rapidly, the possible interferences in the speed measurement can be filtered with the speed error filter. Reducing the ripple with this filter may cause speed controller tuning problems. A long filter time constant and fast acceleration time contradict one another. A very long filter time results in unstable control.	0 ms
	010000 ms	Speed error filtering time constant. 0 = filtering disabled.	1 = 1 ms
24.13	RFE speed filter	Enables/disables resonance frequency filtering. The filtering is configured by parameters 24.1324.17.  The speed error value coming to the speed controller is filtered by a common 2nd order band-elimination filter to eliminate the amplification of mechanical resonance frequencies.  Note: Tuning the resonance frequency filter requires a basic understanding of frequency filters. Incorrect tuning can amplify mechanical oscillations and damage the drive hardware. To ensure the stability of the speed controller, stop the drive or disable the filtering before changing the parameter settings.  0 = Resonance frequency filtering disabled.  1 = Resonance frequency filtering enabled.	Off
	Off	0.	0
	On	1.	1

No.	Name/Value	Description	Def/FbEq16
24.14	Frequency of zero	Defines the zero frequency of the resonance frequency filter. The value must be set near the resonance frequency, which is filtered out before the speed controller. The drawing shows the frequency response.	45.00 Hz
		$20\log_{10} H(\omega) $	
		20 -20 -40 -60 0 50 100 150	
		f (Hz)	
24.15	0.50 500.00 Hz  Damping of zero	Zero frequency.  Defines the damping coefficient for parameter <i>24.14</i> . The	1 = 1 Hz 0.000
		value of 0 corresponds to the maximum elimination of the resonance frequency. $20\log_{10} H(\omega) $ $20$ $f_{zero} = 45 \text{ Hz}$ $\xi_{zero} = 0.250$ $\xi_{pole} = 1$ $f_{zero} = 45 \text{ Hz}$ $\xi_{zero} = 0$ $\xi_{pole} = 1$ $f_{zero} = 45 \text{ Hz}$ $\xi_{zero} = 0$ $\xi_{pole} = 1$ Note: To ensure that the resonance frequency band is filtered (rather than amplified), the value of $24.15$ must be	
	1,000 1,000	smaller than 24.17.	100 – 1
	-1.000 1.000	Damping coefficient.	100 = 1

No.	Name/Value	Description	Def/FbEq16
24.16	Frequency of pole	Defines the frequency of pole of the resonance frequency filter.	40.00 Hz
		$20\log_{10} H(\omega) $	
		$f_{zero} = 45 \text{ Hz}$ $f_{pole} = 50 \text{ Hz}$ $f_{pole} = 50 \text{ Hz}$ $f_{zero} = 0$ $f_{zero} = 45 \text{ Hz}$ $f_{pole} = 0.250$ $f_{zero} = 45 \text{ Hz}$ $f_{pole} = 40 \text{ Hz}$ $f_{pole} = 40 \text{ Hz}$ $f_{pole} = 40 \text{ Hz}$ $f_{pole} = 0.250$	
	0.50 500.00 Hz	which can damage the driven machine.  Frequency of pole.	1 = 1 Hz
24.17	Damping of pole	Defines the damping coefficient for parameter $24.16$ . The coefficient shapes the frequency response of the resonance frequency filter. A narrower bandwidth results in better dynamic properties. By setting this parameter to 1, the effect of the pole is eliminated. $20\log_{10} H(\omega) $ $40$ $20$ $40$ $40$ $5_{zero} = 45 \text{ Hz}$ $f_{pole} = 40 \text{ Hz}$ $5_{zero} = 0$ $5_{pole} = 40 \text{ Hz}$ $5_{zero} = 0$ $5_{pole} = 40 \text{ Hz}$ $5_{zero} = 0$ $5_{pole} = 0.250$ $60$ $60$ $100$ $f \text{ (Hz)}$ Note: To ensure that the resonance frequency band is	0.250
		filtered (rather than amplified), the value of 24.15 must be smaller than 24.17.	
	-1.000 1.000	Damping coefficient.	100 = 1

No.	Name/Value	Description	Def/FbEq16
No. 24.41	Speed error window control enable	Enables/disables speed error window control, sometimes also referred to as deadband control or strip break protection. It forms a speed supervision function for a torque-controlled drive, preventing the motor from running away if the material that is being held under tension breaks.  Note: Speed error window control is only effective when the Add operating mode is active (see parameters 19.12 and 19.14), or when the drive is a speed-controlled follower (see page 75).  In normal operation, window control keeps the speed controller input at zero so the drive stays in torque control. If the motor load is lost, then the motor speed will rise as the torque controller tries to maintain torque. The speed error (speed reference - actual speed) will increase until it exits the speed error window. When this is detected, the exceeding part of the error value is connected to the speed controller. The speed controller produces a reference term relative to the input and gain (25.02 Speed proportional gain) which the torque selector adds to the torque reference. The result is used as the internal torque reference for the drive.  The activation of speed error window control is indicated by bit 3 of 06.19 Speed control status word.  The window boundaries are defined by 24.43 Speed error window high and 24.44 Speed error window low as follows:  Speed (rpm)  Reference  Reference + [24.44] rpm  Reference  Reference - [24.44] rpm  Reference - [24.44] rpm  Reference or row indow control is indicated by bit 3 of 06.19 Speed error window high and 24.44 Speed error window low as follows:  Speed error window control disabled error (which is negative in case of overspeed, positive in case of underspeed).  0 = Speed error window control disabled  1 = Speed error window control disabled	Disable Disable
	Disable	0.	0
	Enable	1.	1
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 156).	-

No.	Name/Value	Description	Def/FbEq16
24.42	Speed error window high	When speed error window control (see parameter 24.41 Speed error window control enable) is enabled, this parameter determines whether the speed controller only observes the proportional term instead of all three (P, I and D) terms.	Normal speed control
	Normal speed control	All three terms (parameters 25.02, 25.03 and 25.04) are observed by the speed controller.	0
	P-control	Only the proportional term (25.02) is observed by the speed controller. The integral and derivative terms are internally forced to zero.	1
24.43	Speed error window high	Defines the upper boundary of the speed error window. See parameter 24.41 Speed error window control enable.	0.00 rpm
	0.00 3000.00 rpm	Upper boundary of speed error window.	See par. 46.01
24.44	Speed error window low	Defines the lower boundary of the speed error window. See parameter 24.41 Speed error window control enable.	0.00 rpm
	0.00 3000.00 rpm	Lower boundary of speed error window.	See par. 46.01
24.46	Speed error step	WARNING! Make sure the error step value is removed when a stop command is given.  Defines an additional speed error step given to the input of the speed controller (and added to the speed error value). This can be used in large drive systems for dynamic speed normalizing.	0.00 rpm
	-3000.00 3000.00 rpm	Speed error step.	See par. 46.01

25 Speed control		Speed controller settings. See the control chain diagrams on pages 684 and 685.	
25.01	Torque reference speed control	Displays the speed controller output that is transferred to the torque controller. See the control chain diagram on page 685.  This parameter is read-only.	-
	-1600.0 1600.0%	Limited speed controller output torque.	See par. 46.03

No.	Name/Value	Description	Def/FbEq16
25.02	Speed proportional gain	Defines the proportional gain $(K_p)$ of the speed controller. Too high a gain may cause speed oscillation. The figure below shows the speed controller output after an error step when the error remains constant.	10.00; 5.00 (95.21 b1)
	%	Gain = $K_p = 1$ $T_l = \text{Integration time} = 0$ $T_D = \text{Derivation time} = 0$	
	Controller output = K <sub>p</sub> × e		: Error value me
		If gain is set to 1.00, a 10% error (reference - actual value) in the motor synchronous speed produces a proportional term of 10%.  Note: This parameter is automatically set by the speed controller autotune function. See section Speed controller autotune (page 86).	
	0.00250.00	Proportional gain for speed controller.	100 = 1

No.	Name/Value	Description	Def/FbEq16
25.03	Speed integration time	Defines the integration time of the speed controller. The integration time defines the rate at which the controller output changes when the error value is constant and the proportional gain of the speed controller is 1. The shorter the integration time, the faster the continuous error value is corrected.  Setting the integration time to zero disables the I-part of the controller. This is useful when tuning the proportional gain. Adjust the proportional gain first and then return the integration time.  The integrator has anti-windup control for operation at a torque or current limit.  The figure below shows the speed controller output after an error step when the error remains constant.	2.50 s; 5.00 (95.21 b1)
	% ▲	Controller output  Gain = $K_p = 1$ $T_l = Integration time > T_D = Derivation time = T_D$	
	K <sub>p</sub> × e	e = Error value	е
		Time Time	
		<b>Note</b> : This parameter is automatically set by the speed controller autotune function. See section <i>Speed controller autotune</i> (page 86).	
	0.00 1000.00 s	Integration time for speed controller.	10 = 1 s

No.	Name/Value	Description	Def/FbEq16	
25.04	Speed derivation time	Defines the derivation time of the speed controller. Derivative action boosts the controller output if the error value changes. The longer the derivation time, the more the speed controller output is boosted during the change. If the derivation time is set to zero, the controller works as a PI controller, otherwise as a PID controller. The derivation makes the control more responsive for disturbances. For simple applications (especially those without an encoder), derivative time is not normally required and should be left at zero.  The figure below shows the speed controller output after an error step when the error remains constant. The speed error derivative must be filtered with a low pass filter to eliminate external disturbances.	0.000 s	
	$K_{p} \times T_{D} \times \frac{\Delta e}{T_{s}} \begin{cases} K_{p} & K_{p} \end{cases}$	Controller output  Error value  e = Error	value	
		Time		
	$egin{array}{c} T_{I} & & & & & & & & & & & & & & & & & & $	ain = K <sub>p</sub> = 1 = Integration time > 0 = Derivation time > 0 = Sample time period = 500 µs = Error value change between two samples		
	0.000 10.000 s	Derivation time for speed controller.	1000 = 1 s	
25.05	Derivation filter time	Defines the derivation filter time constant. See parameter 25.04 Speed derivation time.	8 ms	
·	010000 ms Derivation filter time constant.			

No.	Name/Value	Description	Def/FbEq16
25.06	Acc comp derivation time	Defines the derivation time for acceleration(/deceleration) compensation. In order to compensate for a high inertia load during acceleration, a derivative of the reference is added to the output of the speed controller. The principle of a derivative action is described under parameter 25.04 Speed derivation time.  Note: As a general rule, set this parameter to the value between 50 and 100% of the sum of the mechanical time constants of the motor and the driven machine.  The figure below shows the speed responses when a high inertia load is accelerated along a ramp.  In winder control, signal 09.44 Inertia compensation torque is used as acceleration compensation value. This parameter cannot be changed manually.  No acceleration compensation:  **Acceleration compensation:**  - Speed reference  - Actual speed  Time  Acceleration compensation:  **Time*	0.00 s
	0.00 1000.00 s	Acceleration compensation derivation time.	10 = 1 s
25.07	Acc comp filter time	Defines the acceleration (or deceleration) compensation filter time constant. See parameters 25.04 Speed derivation time and 25.06 Acc comp derivation time.	8.0 ms
	0.0 1000.0 ms	Acceleration/deceleration compensation filter time.	1 = 1 ms

No.	Name/Value	Description	Def/FbEq16
25.08	Drooping rate	Defines the droop rate in percent of the nominal motor speed. Drooping decreases the drive speed slightly as the drive load increases. The actual speed decrease at a certain operating point depends on the droop rate setting and the drive load (= torque reference / speed controller output). At 100% speed controller output, drooping is at its nominal level, i.e. equal to the value of this parameter. The drooping effect decreases linearly to zero along with the decreasing load.  The droop rate can be used e.g. to adjust the load sharing in a Master/Follower application run by several drives. In a Master/Follower application the motor shafts are coupled to each other.  The correct droop rate for a process must be found out case by case in practice.	0.00%
	<b>Example:</b> Speed co 1500 rpm.	Speed controller output × Drooping × Nominal speed ntroller output is 50%, droop rate is 1%, nominal speed of the .50 × 0.01 × 1500 rpm = 7.5 rpm.	drive is
	Motor speed in % of nominal		
	100%	No drooping  Drooping  25.08 Drooping rate	
		Speed controller output / %	load
	0.00 100.00%	Droop rate.	100 = 1%
25.09	Speed ctrl balancing enable	Selects the source for enabling/disabling speed controller output balancing.  This function is used to generate a smooth transfer from a torque- or tension-controlled motor back to being speed-controlled. The balancing output would be tracking the present "line" speed of the application and when transfer is required, the speed reference can then be quickly "seeded" to the correct line speed. Balancing is also possible in the ramp generator, see parameter 23.26 Ramp out balancing enable.  See also parameter 25.10 Speed ctrl balancing ref.  0 = Disabled  1 = Enabled	Not selected
	Not selected	0.	1
	Selected	1.	2
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4

No.	Name/Value	Description	Def/FbEq16
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
25.10	Speed ctrl balancing ref	Defines the reference used in speed controller output balancing. The output of the speed controller is forced to this value when balancing is enabled by parameter 25.09 Speed ctrl balancing enable.	0.0%
	-300.0 300.0%	Speed control output balancing reference.	1 = 1%
25.11	Speed control min torque	Defines the minimum speed controller output torque. In Open loop tension and Tension torque trim modes this value is changed according to tension control. See the control diagrams on page 52 and 54. This parameter cannot be changed manually.	-300.0%
	-1600.0 0.0%	Minimum speed controller output torque.	See par. 46.03
25.12	Speed control max torque	Defines the maximum speed controller output torque. In Open loop tension and Tension torque trim modes this value is changed according to tension control. See the control diagrams on page 52 and 54. This parameter cannot be changed manually.	300.0%
	0.0 1600.0%	Maximum speed controller output torque.	See par. 46.03
25.13	Min torq sp ctrl em stop	Defines the minimum speed controller output torque during a ramped emergency stop (Off1 or Off3).	-400.0%
	-1600.0 0.0%	Minimum speed controller output torque for ramped emergency stop.	See par. 46.03
25.14	Max torq sp ctrl em stop	Defines the maximum speed controller output torque during a ramped emergency stop (Off1 or Off3).	400.0%
	0.0 1600.0%	Maximum speed controller output torque for ramped emergency stop.	See par. 46.03
25.15	Proportional gain em stop	Defines the proportional gain for the speed controller when an emergency stop is active. See parameter 25.02 Speed proportional gain.	10.00; 5.00 (95.21 b1)
	1.00 250.00	Proportional gain upon an emergency stop.	100 = 1

No.	Name/Value	Description	Def/FbEq16
25.18	Speed adapt min limit	Minimum actual speed for speed controller adaptation. Speed controller gain and integration time can be adapted according to actual speed (90.01 Motor speed for control). This is done by multiplying the gain (25.02 Speed proportional gain) and integration time (25.03 Speed integration time) by coefficients at certain speeds. The coefficients are defined individually for both gain and integration time.  When actual speed is below or equal to 25.18 Speed adapt min limit, the gain is multiplied by 225.21 Kp adapt coef at min speed, and the integration time divided by 25.22 Ti adapt coef at min speed.  When actual speed is equal to or above 25.19 Speed adapt max limit, no adaptation takes place (the coefficient is 1).  When actual speed is between 25.18 Speed adapt min limit and 25.19 Speed adapt max limit, the coefficients for the gain and integration time are calculated linearly on the basis of the breakpoints.  See also the block diagram on page 685.  Coefficient for K <sub>p</sub> or T <sub>1</sub> K <sub>p</sub> = Proportional gain T <sub>1</sub> = Integration time	Orpm  Orpm
	25.21 Kp adapt coef a 25.22 Ti adapt coe		Actual speed (90.01) (rpm)
	030000 rpm	Minimum actual speed for speed controller adaptation.	1 = 1 rpm
25.19	030000 rpm  Speed adapt max limit	Minimum actual speed for speed controller adaptation.  Maximum actual speed for speed controller adaptation.  See parameter 25.18 Speed adapt min limit.	1 = 1 rpm 0 rpm
25.19	Speed adapt max	Maximum actual speed for speed controller adaptation.	
25.19	Speed adapt max limit	Maximum actual speed for speed controller adaptation. See parameter 25.18 Speed adapt min limit.	0 rpm
	Speed adapt max limit  030000 rpm  Kp adapt coef at	Maximum actual speed for speed controller adaptation. See parameter 25.18 Speed adapt min limit.  Maximum actual speed for speed controller adaptation.  Proportional gain coefficient at minimum actual speed.	0 rpm  1 = 1 rpm
	Speed adapt max limit  030000 rpm  Kp adapt coef at min speed	Maximum actual speed for speed controller adaptation. See parameter 25.18 Speed adapt min limit.  Maximum actual speed for speed controller adaptation.  Proportional gain coefficient at minimum actual speed. See parameter 25.18 Speed adapt min limit.	0 rpm  1 = 1 rpm  1.000

No.	Name/Value	Description	Def/FbEq16
No. 25.25	Torque adapt max limit	Maximum torque reference for speed controller adaptation. Speed controller gain can be adapted according to the final unlimited torque reference (26.01 Torque reference to TC). This can be used to smooth out disturbances caused by a small load and backlashes.  The functionality involves multiplying the gain (25.02 Speed proportional gain) by a coefficient within a certain torque range.  When the torque reference is 0%, the gain is multiplied by the value of parameter 25.27 Kp adapt coef at min torque. When the torque reference is equal to or above 25.25 Torque adapt max limit, no adaptation takes place (the coefficient is 1).  Between 0% and 25.25 Torque adapt max limit, the coefficient for the gain is calculated linearly on the basis of the breakpoints.  Filtering can be applied on the torque reference using parameter 25.26 Torque adapt filt time.  See also the block diagram on page 685.	0.0%
	1.000		rque reference (26.01) (rpm)
	0.0 1600.0%		10 = 1%
25.26	0.0 1600.0%  Torque adapt filt time	adapt max limit	10 = 1% 0.000 s
25.26	Torque adapt filt	Adapt max limit  Maximum torque reference for speed controller adaptation.  Defines a filter time constant for the adaptation, in effect adjusting the rate of change of the gain.	
25.26	Torque adapt filt time	Adapt max limit  Maximum torque reference for speed controller adaptation.  Defines a filter time constant for the adaptation, in effect adjusting the rate of change of the gain.  See parameter 25.25 Torque adapt max limit.	0.000 s

No.	Name/Value	Description	Def/FbEq16
25.30	Flux adaption enable	Enables/disables speed controller adaptation based on motor flux reference (01.24 Flux actual %).  The proportional gain of the speed controller is multiplied by a coefficient of 01 between 0100% flux reference respectively.  See also the block diagram on page 685.	Enable
	Coef	ficient for K <sub>p</sub> (proportional gain)	
	1.000Flux		reference 01.24) (%)
		0 100	,
	Disable	Speed controller adaptation based on flux reference disabled.	0
	Enable	Speed controller adaptation based on flux reference enabled.	1
25.33	Speed controller autotune	Activates (or selects a source that activates) the speed controller autotune function. See section Speed controller autotune (page 86).  The autotune will automatically set parameters 25.02 Speed proportional gain, 25.03 Speed integration time and 25.37 Mechanical time constant.  The prerequisites for performing the autotune routine are:  • the motor identification run (ID run) has been successfully completed  • the speed and torque limits (parameter group 30 Limits) have been set  • speed feedback filtering (parameter group 90 Feedback selection), speed error filtering (24 Speed reference conditioning) and zero speed (21 Start/stop mode) have been set, and  • the drive has been started and is running in speed control mode.  MARNING! The motor and machinery will run against the torque and speed limits during the autotune routine. MAKE SURE IT IS SAFE TO ACTIVATE THE AUTOTUNE FUNCTION!  The autotune routine can be aborted by stopping the drive.  0 -> 1 = Activate speed controller autotune  Note: The value does not revert to 0 automatically.	Off
	Off	0.	0
	On	1.	1
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-

No.	Name/Value	Description	Def/FbEq16	
25.34	Speed controller autotune mode	Defines a control preset for the speed controller autotune function. The setting affects the way the torque reference will respond to a speed reference step.	Normal	
	Smooth	Slow but robust response.	0	
	Normal	Medium setting.	1	
	Tight	Fast response. May produce too high a gain value for some applications.	2	
25.37	Mechanical time constant	Mechanical time constant of the drive and the machinery as determined by the speed controller autotune function. The value can be adjusted manually.	-	
	0.00 1000.00 s	Mechanical time constant.	10 = 1 s	
25.38	Autotune torque step	Defines an added torque value used by the autotune function. This value is scaled to motor nominal torque. Note that the torque used by the autotune function can also be limited by the torque limits (in parameter group 30 Limits) and nominal motor torque.	10.00%	
	0.00 100.00%	Autotune torque step.	100 = 1%	
25.39	Autotune speed step	Defines a speed value added to the initial speed for the autotune routine. The initial speed (used when autotune is activated) plus the value of this parameter is the calculated maximum speed used by the autotune routine. The maximum speed can also be limited by the speed limits (in parameter group 30 Limits) and nominal motor speed. The value is scaled to motor nominal speed.  Note: The motor will exceed the calculated maximum speed slightly at the end of each acceleration stage.	10.00%	
	0.00 100.00%	Autotune speed step.	100 = 1%	
25.40	Autotune repeat times	Determines how many acceleration/deceleration cycles are performed during the autotune routine. Increasing the value will improve the accuracy of the autotune function, and allow the use of smaller torque or speed step values.	10	
	110	Number of cycles during autotune routine.	1 = 1	
25.41	Torque reference Autotune2	Reserved	-	
25.42	Integral term enable	Selects a source that enables/disables the integral (I) part of the speed controller.  0 = I-part disabled  1 = I-part enabled	Selected	
	Not selected	0.	0	
	Selected	1.	1	
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2	
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3	
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4	
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5	
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6	
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7	
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10	
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11	

No.	Name/Value	Description	Def/FbEq16
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
25.53	Torque prop reference	Displays the output of the proportional (P) part of the speed controller. See the control chain diagram on page 685.  This parameter is read-only.	-
	-30000.0 30000.0%	P-part output of speed controller.	See par. 46.03
25.54	Torque integral reference	Displays the output of the integral (I) part of the speed controller. See the control chain diagram on page 685. This parameter is read-only.	-
	-30000.0 30000.0%	I-part output of speed controller.	See par. 46.03
25.55	Torque deriv reference	Displays the output of the derivative (D) part of the speed controller. See the control chain diagram on page 685.  This parameter is read-only.	-
	-30000.0 30000.0%	D-part output of speed controller.	See par. 46.03
25.56	Torque acc compensation	Displays the output of the acceleration compensation function. See the control chain diagram on page 685.  This parameter is read-only.	-
	-30000.0 30000.0%	Output of acceleration compensation function.	See par. 46.03
25.57	Torque reference unbalanced	Displays the acceleration-compensated output of the speed controller. See the control chain diagram on page 685.  This parameter is read-only.	-
	-30000.0 30000.0%	Acceleration-compensated output of speed controller.	See par. 46.03
26 Tor chain	que reference	Settings for the torque reference chain. See the control chain diagrams on pages 686 and 688.	
26.01	Torque reference to TC	Displays the final torque reference given to the torque controller in percent. This reference is then acted upon by various final limiters, like power, torque, load etc.  See the control chain diagrams on pages 688 and 689.  This parameter is read-only.	-
	-1600.0 1600.0%	Torque reference for torque control.	See par. 46.03
26.02	Torque reference used	Displays the final torque reference (in percent of motor nominal torque) given to the DTC core, and comes after frequency, voltage and torque limitation.  See the control chain diagram on page 689.  This parameter is read-only.	-
	-1600.0 1600.0%	Torque reference for torque control.	See par. 46.03
26.08	Minimum torque ref	Defines the minimum torque reference. Allows for local limiting of the torque reference before it is passed on to the torque ramp controller. For absolute torque limiting, refer to parameter 30.19 Minimum torque 1.	-300.0%
	-1000.0 0.0%	Minimum torque reference.	See par. 46.03

No.	Name/Value	Description	Def/FbEq16			
26.09	Defines the maximum torque reference. Allows for local limiting of the torque reference before it is passed on to the torque ramp controller. For absolute torque limiting, refer to parameter 30.20 Maximum torque 1.					
	0.0 1000.0%	0.0 1000.0% Maximum torque reference.				
26.11	Torque ref1 source  26.1	Selects torque reference source 1.  Two signal sources can be defined by this parameter and 26.12 Torque ref2 source. A digital source selected by 26.14 Torque ref1/2 selection can be used to switch between the two sources, or a mathematical function (26.13 Torque ref1 function) applied to the two signals to create the reference.	Zero			
	Other — 26.1		3.72			
	Zero	None.	0			
	Al1 scaled	12.12 Al1 scaled value (see page 207).	1			
	Al2 scaled	12.22 Al2 scaled value (see page 208).	2			
	FB A ref1	03.05 FB A reference 1 (see page 165).	4			
	FB A ref2	03.06 FB A reference 2 (see page 165).	5			
	EFB ref1	03.09 EFB reference 1 (see page 165).	8			
	EFB ref2	03.10 EFB reference 2 (see page 165).	9			
	DDCS ctrl ref1	03.11 DDCS controller ref 1 (see page 165).	10			
	DDCS ctrl ref2	03.12 DDCS controller ref 2 (see page 165).	11			
	M/F reference 1	03.13 M/F or D2D ref1 (see page 165).	12			
	M/F reference 2	03.14 M/F or D2D ref2 (see page 166).	13			
_	Motor potentiometer	22.80 Motor potentiometer ref act (output of the motor potentiometer).	15			
	PID	40.01 Process PID output actual (output of the process PID controller).	16			
	Control panel (ref saved)	Control panel reference, with initial value from last-used panel reference. See section <i>Using the control panel as an external control source</i> (page 41).	18			
	Control panel (ref copied)	Control panel reference, with initial value from previous source or actual value. See section <i>Using the control panel as an external control source</i> (page 41).	19			

No.	Name/Value	Description	Def/FbEq16			
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-			
26.12	Torque ref2 source	Selects torque reference source 2. For the selections, and a diagram of reference source selection, see parameter 26.11 Torque ref1 source.	Zero			
26.13	Torque ref1 function	Selects a mathematical function between the reference sources selected by parameters 26.11 Torque ref1 source and 26.12 Torque ref2 source. See diagram at 26.11 Torque ref1 source.	Ref1			
	Ref1	reference 1.  The subtraction ([26.11 Torque ref1 source] - [26.12 Torque ref2 source]) of the reference sources is used as torque reference 1.  The multiplication of the reference sources is used as torque reference 1.  The smaller of the reference sources is used as torque reference 1.  The greater of the reference sources is used as torque reference 1.  The greater of the reference sources is used as torque reference 1.				
	Add (ref1 + ref2)		1			
	Sub (ref1 - ref2)	1	2			
	Mul (ref1 × ref2)	3				
	Min (ref1, ref2)	·	4			
	Max (ref1, ref2)		5			
26.14	Torque ref1/2 selection	Configures the selection between torque references 1 and 2. See diagram at 26.11 Torque ref1 source.  0 = Torque reference 1 1 = Torque reference 2	Torque reference 1			
	Torque reference 1	0.	0			
	Torque reference 2	1.	1			
	Follow Ext1/Ext2 selection	Torque reference 1 is used when external control location EXT1 is active. Torque reference 2 is used when external control location EXT2 is active.  See also parameter 19.11 Ext1/Ext2 selection.	2			
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	3			
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	4			
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	5			
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	6			
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	7			
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	8			
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-			
26.15	Load share	Defines the scaling factor for the torque reference (the torque reference is multiplied by the value).  This allows drives sharing the load between two motors on the same mechanical plant to be tailored to share the correct amount each, yet use the same master torque reference.	1.000			
	-8.000 8.000	Torque reference scaling factor.	1000 = 1			

No.	Name/Value	Description	Def/FbEq16
26.16	Torque additive 1 source	Selects the source for torque reference additive 1. <b>Note:</b> For safety reasons, the additive is not applied when an emergency stop is active.  See the control chain diagram on page 686.  For the selections, see parameter 26.11 Torque ref1 source.	Zero
26.17	Torque ref filter time	Defines a low-pass filter time constant for the torque reference.	0.000 s
	0.000 30.000 s	Filter time constant for torque reference.	1000 = 1 s
26.18	Torque ramp up time	Defines the torque reference ramp-up time, i.e. the time for the reference to increase from zero to nominal motor torque.	0.000 s
	0.000 60.000 s	Torque reference ramp-up time.	100 = 1 s
26.19	Torque ramp down time	Defines the torque reference ramp-down time, i.e. the time for the reference to decrease from nominal motor torque to zero.	0.000 s
	0.000 60.000 s	Torque reference ramp-down time.	100 = 1 s
26.25	Force torque ref add 2 zero	Selects the source of torque reference additive 2.  The value received from the selected source is added to the torque reference after operating mode selection. Because of this, the additive can be used in speed and torque modes.  Note: For safety reasons, the additive is not applied when an emergency stop is active.  WARNING! If the additive exceeds the limits set by parameters 25.11 Speed control min torque and 25.12 Speed control max torque, a ramp stop may be impossible. Make sure the additive is reduced or removed when a ramp stop is required e.g. by using parameter 26.26 Force torque ref add 2 zero.  See the control chain diagram on page 688.  For the selections, see parameter 26.11 Torque ref1 source.  Selects a source that forces torque reference additive 2 (see parameter 26.25 Torque additive 2 source) to zero.	Zero  Not selected
	2 zero	0 = Normal operation 1 = Force torque reference additive 2 to zero.	
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	Other [bit]	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).  Source selection (see Terms and abbreviations on page 156).	-

No.	Name/Value	Description	Def/FbEq16
26.41	Torque step	When enabled by parameter 26.42 Torque step enable, adds an additional step to the torque reference.  A second torque step can be added using pointer	0.0%
		parameters 26.43 Torque step pointer enable and 26.44	
		Torque step source.  The two torque steps work independently of each other, and are summed up to calculate the total torque step.	
		Note: For safety reasons, the torque step is not applied	
		when an emergency stop is active.  WARNING! If the torque step exceeds the limits set by parameters 25.11 Speed control min torque and	
		25.12 Speed control max torque, a ramp stop may be impossible. Make sure the torque step is reduced or removed when a ramp stop is required e.g. by using parameter 26.42 Torque step enable.	
	-300.0 300.0%	Torque step.	See par. 46.03
26.42	Torque step enable	Enables/disables a torque step (defined by parameter 26.41 Torque step).	Disable
	Disable	Torque step disabled.	0
	Enable	Torque step enabled.	1
26.43	Torque step pointer enable	Selects a source that enables/disables the torque step defined by parameter 26.44 Torque step source.  See also parameter 26.41 Torque step.  1 = Torque step enabled.	Selected
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
26.44	Torque step source	Selects the source of the torque step enabled by 26.43  Torque step pointer enable.	Zero
	Zero	None.	0
	Al1 scaled	12.12 Al1 scaled value (see page 207).	1
	Al2 scaled	12.22 Al2 scaled value (see page 208).	2
	FB A ref1	03.05 FB A reference 1 (see page 165).	4
	FB A ref2	03.06 FB A reference 2 (see page 165).	5
	EFB ref1	03.09 EFB reference 1 (see page 165).	8
	EFB ref2	03.10 EFB reference 2 (see page 165).	9
	DDCS ctrl ref1	03.11 DDCS controller ref 1 (see page 165).	10
	DDCS ctrl ref2	03.12 DDCS controller ref 2 (see page 165).	11

No.	Name/Value	Description	Def/FbEq16
	M/F reference 1	03.13 M/F or D2D ref1 (see page 165).	12
	M/F reference 2	03.14 M/F or D2D ref2 (see page 166).	13
	Motor potentiometer	22.80 Motor potentiometer ref act (output of the motor potentiometer).	15
	PID	40.01 Process PID output actual (output of the process PID controller).	16
	Control panel (ref saved)	Control panel reference, with initial value from last-used panel reference. See section <i>Using the control panel as an external control source</i> (page 41).	18
	Control panel (ref copied)	Control panel reference, with initial value from previous source or actual value. See section <i>Using the control panel</i> as an external control source (page 41).	19
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
26.51	Oscillation damping	Parameters 26.5126.58 configure the oscillation damping function. See section Oscillation damping (page 89), and the block diagram on page 688.  This parameter enables (or selects a source that enables) the oscillation damping algorithm.  1 = Oscillation damping algorithm enabled	Not selected
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
26.52	Oscillation damping out enable	Determines (or selects a source that determines) whether the output of the oscillation damping function is added to the torque reference or not.  Note: Before enabling the oscillation damping output, adjust parameters 26.5326.57. Then monitor the input signal (selected by 26.53) and the output (26.58) to make sure that the correction is safe to apply.  1 = Apply oscillation damping output to torque reference	Not selected
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6

No.	Name/Value	Description	Def/FbEq16
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
26.53	Oscillation compensation input	Selects the input signal for the oscillation damping function. <b>Note:</b> Before changing this parameter run-time, disable the oscillation damping output using parameter 26.52. Monitor the behavior of 26.58 before re-enabling the output.	Speed error
	Speed error	24.01 Used speed reference - unfiltered motor speed.  Note: This setting is not supported in scalar motor control mode.	0
	DC voltage	01.11 DC voltage. (The value is internally filtered.)	1
26.55	Oscillation damping frequency	Defines the center frequency of the oscillation damping filter. Set the value according to the number of oscillation peaks in the monitored signal (selected by 26.53) per second.  Note: Before changing this parameter run-time, disable the oscillation damping output using parameter 26.52. Monitor the behavior of 26.58 before re-enabling the output.	31.0 Hz
	0.1 60.0 Hz	Center frequency for oscillation damping.	10 = 1 Hz
26.56	Oscillation damping phase	Defines a phase shift for the output of the filter. <b>Note:</b> Before changing this parameter run-time, disable the oscillation damping output using parameter 26.52. Monitor the behavior of 26.58 before re-enabling the output.	180 deg
	0360 deg	Phase shift for oscillation damping function output.	10 = 1 deg
26.57	Oscillation damping gain	Defines a gain for the output of the oscillation damping function, i.e. how much the output of the filter is amplified before it is added to the torque reference.  Oscillation gain is scaled according to the speed controller gain so that changing the gain will not disturb oscillation damping.  Note: Before changing this parameter run-time, disable the oscillation damping output using parameter 26.52. Monitor the behavior of 26.58 before re-enabling the output.	1.0%
	0.0 100.0%	Gain setting for oscillation damping output.	10 = 1%
26.58	Oscillation damping output	Displays the output of the oscillation damping function. This value is added to the torque reference (as allowed by parameter 26.52 Oscillation damping out enable). This parameter is read-only.	-
	-1600.000 1600.000%	Output of the oscillation damping function.	10 = 1%
26.70	Torque reference act 1	Displays the value of torque reference source 1 (selected by parameter 26.11 Torque ref1 source). See the control chain diagram on page 686. This parameter is read-only.	-
	-1600.0 1600.0%	Value of torque reference source 1.	See par. 46.03

No.	Name/Value	Description	Def/FbEq16
26.71	Torque reference act 2	Displays the value of torque reference source 2 (selected by parameter 26.12 Torque ref2 source). See the control chain diagram on page 686.  This parameter is read-only.	-
	-1600.0 1600.0%	Value of torque reference source 2.	See par. 46.03
26.72	Torque reference act 3	Displays the torque reference after the function applied by parameter 26.13 Torque ref1 function (if any), and after selection (26.14 Torque ref1/2 selection). See the control chain diagram on page 686. This parameter is read-only.	-
	-1600.0 1600.0%	Torque reference after selection.	See par. 46.03
26.73	Torque reference act 4	Displays the torque reference after application of reference additive 1. See the control chain diagram on page 686. This parameter is read-only.	-
	-1600.0 1600.0%	Torque reference after application of reference additive 1.	See par. 46.03
26.74	Torque ref ramp out	Displays the torque reference after limiting and ramping. See the control chain diagram on page 686. This parameter is read-only.	-
	-1600.0 1600.0%	Torque reference after limiting and ramping.	See par. 46.03
26.75	Torque reference act 5	Displays the torque reference after control mode selection. See the control chain diagram on page 688.  This parameter is read-only.	-
	-1600.0 1600.0%	Torque reference after control mode selection.	See par. 46.03
26.76	Torque reference act 6	Displays the torque reference after application of reference additive 2. See the control chain diagram on page 688. This parameter is read-only.	-
	-1600.0 1600.0%	Torque reference after application of reference additive 2.	See par. 46.03
26.77	Torque ref add A actual	Displays the value of the source of torque reference additive 2. See the control chain diagram on page 688.  This parameter is read-only.	-
	-1600.0 1600.0%	Torque reference additive 2.	See par. 46.03
26.78	Torque ref add B actual	Displays the value of torque reference additive 2 before it is added to torque reference. See the control chain diagram on page 688.  This parameter is read-only.	-
	-1600.0 1600.0%	Torque reference additive 2.	See par. 46.03
26.81	Rush control gain	Rush controller gain term. See section <i>Rush control</i> (page 91).	10.0
	0.010000.0	Rush controller gain (0.0 = disabled).	1 = 1
26.82	Rush control integration time	Rush controller integration time term.	2.0 s
	0.010.0 s	Rush controller integration time (0.0 = disabled).	1 = 1 s

No.	Name/Value	Description	Def/FbEq16
28 Frechain	quency reference	Settings for the frequency reference chain. See the control chain diagrams on pages 692 and 693.	
28.01	Frequency ref ramp input	Displays the used frequency reference before ramping. See the control chain diagram on page 693. This parameter is read-only.	-
	-500.00 500.00 Hz	Frequency reference before ramping.	See par. 46.02
28.02	Frequency ref ramp output	Displays the final frequency reference (after selection, limitation and ramping). See the control chain diagram on page 693. This parameter is read-only.	-
	-500.00 500.00 Hz	Final frequency reference.	See par. 46.02
28.11	Frequency ref1 source	Selects frequency reference source 1.  Two signal sources can be defined by this parameter and 28.12 Frequency ref2 source. A digital source selected by 28.14 Frequency ref1/2 selection can be used to switch between the two sources, or a mathematical function (28.13 Frequency ref1 function) applied to the two signals to create the reference.	Zero
	0 — Al — — — — — — — — — — — — — — — — —	28.13  Ref1  SUB  MUL  MIN  MIN  28.14  28.14	92
	Zero	None.	0
	Al1 scaled	12.12 Al1 scaled value (see page 207).	1
	Al2 scaled	12.22 Al2 scaled value (see page 208).	2
	FB A ref1	03.05 FB A reference 1 (see page 165).	4
	FB A ref2	03.06 FB A reference 2 (see page 165).	5
	EFB ref1	03.09 EFB reference 1 (see page 165).	8
	EFB ref2	03.10 EFB reference 2 (see page 165).	9
	DDCS ctrl ref1	03.11 DDCS controller ref 1 (see page 165).	10
	DDCS ctrl ref2	03.12 DDCS controller ref 2 (see page 165).	11
	M/F reference 1	03.13 M/F or D2D ref1 (see page 165).	12
	M/F reference 2	03.14 M/F or D2D ref2 (see page 166).	13
	Motor potentiometer	22.80 Motor potentiometer ref act (output of the motor potentiometer).	15

No.	Name/Value	Description	Def/FbEq16	
	PID	40.01 Process PID output actual (output of the process PID controller).	16	
	Control panel (ref saved)	Control panel reference, with initial value from last-used panel reference. See section <i>Using the control panel as an external control source</i> (page 41).	18	
	Control panel (ref copied)	Control panel reference, with initial value from previous source or actual value. See section <i>Using the control panel as an external control source</i> (page 41).	19	
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-	
28.12	Frequency ref2 source	Selects frequency reference source 2. For the selections, and a diagram of reference source selection, see parameter 28.11 Frequency ref1 source.	Zero	
28.13	Frequency ref1 function	Ref1		
	Ref1	0		
	Add (ref1 + ref2)	The sum of the reference sources is used as frequency reference 1.	1	
	Sub (ref1 - ref2)	The subtraction ([28.11 Frequency ref1 source] - [28.12 Frequency ref2 source]) of the reference sources is used as frequency reference 1.	2	
	Mul (ref1 × ref2)	The multiplication of the reference sources is used as frequency reference 1.	3	
	Min (ref1, ref2)	The smaller of the reference sources is used as frequency reference 1.	4	
	Max (ref1, ref2)	The greater of the reference sources is used as frequency reference 1.	5	
28.14	Frequency ref1/2 selection	Configures the selection between frequency references 1 and 2. See diagram at 28.11 Frequency ref1 source.  0 = Frequency reference 1 1 = Frequency reference 2		
	Frequency reference 1	0.	0	
	Frequency reference 2	1.	1	
	Follow Ext1/Ext2 selection	Frequency reference 1 is used when external control location EXT1 is active. Frequency reference 2 is used when external control location EXT2 is active.  See also parameter 19.11 Ext1/Ext2 selection.	2	
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	3	
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	4	
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	5	
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	6	
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	7	
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	8	
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-	

No.	Name/	Value	De	scription			Def/FbEq1
28.21	Consta functio	ant frequency n	wh		stant frequencies a direction signal is o stant frequency.		0000b
	Bit	Name		Information			
	0	Constant fr mode	eq			are selectable using to 28.23 and 28.24.	the three
				by the sources de	fined by parameter se of conflict, the c	1, 2 and 3 are separa is 28.22, 28.23 and 2 onstant frequency w	28.24
	1	Direction enable	1 = Start dir: To determine running direction for a constart the sign of the constant frequency setting (parameters 28 multiplied by the direction signal (forward: +1, reverse: -'effectively allows the drive to have 14 (7 forward, 7 reversequencies if all values in 28.2628.32 are positive.  WARNING: If the direction signal is reverse and to constant frequency is negative, the drive will rundirection.		etting (parameters 28 ward: +1, reverse: -1 4 (7 forward, 7 revers 3.32 are positive. gnal is reverse and the	.2628.32) is ). This se) constant ne active	
						ection for the constar nt speed setting (par	
	0000b0011b Constant frequency configuration word.					1 = 1	
	Source defii by par. 28.		fre Wh is ' Co sel	quency 1. nen bit 0 of parame 1 (Packed), this pa <i>nstant frequency</i> s	rameter and paran sel2 and 28.24 Con whose states activ	t frequency function neters 28.23 stant frequency sel3	
				Source defined by par. 28.23	Source defined by par. 28.24	Constant freque	ency
		0		0	0	None	
		1		0	0	Constant frequen	
		0		1	0	Constant frequen	•
		0		0	0	Constant frequen	-
		1		0	1	Constant frequen	-
		0		1	1	Constant frequen	•
		1		1	1	Constant frequen	•
	Not selected						
			0.				0
	Selecte	ea	1.	'' I' I DIA (40 A	00 DI dala adalah	- 1'' 0'	1
	DI1 DI2				02 DI delayed statu 02 DI delayed statu	-	3
	DI3		`	• • •	02 DI delayed stati 02 DI delayed stati	<u>,                                      </u>	4
	DI3 DI4		`	• • •	02 DI delayed stati 02 DI delayed stati	<u>,                                      </u>	5
	DI5		`		02 DI delayed statu	<u> </u>	6
	ם סום		ادر	J	- D. Goldy Cd Statt	· · · · · · · · · · · · · · · · · · ·	

No.	Name/Value	Description	Def/FbEq16
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
28.23	Constant frequency sel2	When bit 0 of parameter 28.21 Constant frequency function is 0 (Separate), selects a source that activates constant frequency 2.  When bit 0 of parameter 28.21 Constant frequency function is 1 (Packed), this parameter and parameters 28.22 Constant frequency sel1 and 28.24 Constant frequency sel3 select three sources that are used to activate constant frequencies. See table at parameter 28.22 Constant frequency sel1.  For the selections, see parameter 28.22 Constant frequency sel1.	Not selected
28.24	Constant frequency sel3	When bit 0 of parameter 28.21 Constant frequency function is 0 (Separate), selects a source that activates constant frequency 3.  When bit 0 of parameter 28.21 Constant frequency function is 1 (Packed), this parameter and parameters 28.22 Constant frequency sel1 and 28.23 Constant frequency sel2 select three sources that are used to activate constant frequencies. See table at parameter 28.22 Constant frequency sel1.  For the selections, see parameter 28.22 Constant frequency sel1.	Not selected
28.26	Constant frequency	Defines constant frequency 1 (the frequency the motor will turn when constant frequency 1 is selected).	0.00 Hz
	-500.00 500.00 Hz	Constant frequency 1.	See par. 46.02
28.27	Constant frequency 2	Defines constant frequency 2.	0.00 Hz
	-500.00 500.00 Hz	Constant frequency 2.	See par. 46.02
28.28	Constant frequency 3	Defines constant frequency 3.	0.00 Hz
	-500.00 500.00 Hz	Constant frequency 3.	See par. 46.02
28.29	Constant frequency 4	Defines constant frequency 4.	0.00 Hz
	-500.00 500.00 Hz	Constant frequency 4.	See par. 46.02
28.30	Constant frequency 5	Defines constant frequency 5.	0.00 Hz
	-500.00 500.00 Hz	Constant frequency 5.	See par. 46.02
28.31	Constant frequency	Defines constant frequency 6.	0.00 Hz
	-500.00 500.00 Hz	Constant frequency 6.	See par. 46.02

No.	Name/	Value	Description	Def/FbEq16
28.32	Consta 7	nt frequency	Defines constant frequency 7.	0.00 Hz
	-500.00 500.00		Constant frequency 7.	See par. 46.02
28.41	Freque	ncy ref safe	Defines a safe frequency reference value that is used with supervision functions such as  12.03 Al supervision function  49.05 Communication loss action  50.02 FBA A comm loss func	0.00 Hz
			<ul> <li>50.32 FBA B comm loss func</li> <li>58.14 Communication loss action.</li> </ul>	
	-500.00 500.00		Safe frequency reference.	See par. 46.02
28.51	Critical function	frequency 1	Enables/disables the critical frequencies function. Also determines whether the specified ranges are effective in both rotating directions or not.  See also section <i>Critical speeds/frequencies</i> (page 85).	0000b
	Bit	Name	Information	
	0	Enable	1 = Enable: Critical frequencies enabled.	
			0 = Disable: Critical frequencies disabled.	
	1	Sign mode	1 = According to par: The signs of parameters 28.5228.57 into account.	are taken
			0 = Absolute: Parameters 28.5228.57 are handled as absolutes. Each range is effective in both directions of rotation.	olute
	0000b.	0011b	Critical frequencies configuration word.	1 = 1
28.52	Critical frequency 1 low		Defines the low limit for critical frequency 1. <b>Note:</b> This value must be less than or equal to the value of 28.53 Critical frequency 1 high.	0.00 Hz
	-500.00 500.00		Low limit for critical frequency 1.	See par. 46.02
28.53	Critical high	frequency 1	Defines the high limit for critical frequency 1. <b>Note:</b> This value must be greater than or equal to the value of 28.52 Critical frequency 1 low.	0.00 Hz
	-500.00 500.00		High limit for critical frequency 1.	See par. 46.02
28.54	Critical low	frequency 2	Defines the low limit for critical frequency 2. <b>Note:</b> This value must be less than or equal to the value of 28.55 Critical frequency 2 high.	0.00 Hz
	-500.00 500.00 Hz		Low limit for critical frequency 2.	See par. 46.02
28.55	Critical high	frequency 2	Defines the high limit for critical frequency 2. <b>Note:</b> This value must be greater than or equal to the value of 28.54 Critical frequency 2 low.	0.00 Hz
	-500.00 500.00		High limit for critical frequency 2.	See par. 46.02

No.	Name/Value	Description	Def/FbEq16
28.56	Critical frequency 3 low	Defines the low limit for critical frequency 3. <b>Note:</b> This value must be less than or equal to the value of 28.57 Critical frequency 3 high.	0.00 Hz
	-500.00 500.00 Hz	Low limit for critical frequency 3.	See par. 46.02
28.57	Critical frequency 3 high	Defines the high limit for critical frequency 3. <b>Note:</b> This value must be greater than or equal to the value of 28.56 Critical frequency 3 low.	0.00 Hz
	-500.00 500.00 Hz	High limit for critical frequency 3.	See par. 46.02
28.71	Freq ramp set selection	Selects a source that switches between the two sets of acceleration/deceleration times defined by parameters 28.7228.75.  0 = Acceleration time 1 and deceleration time 1 are in force 1 = Acceleration time 2 and deceleration time 2 are in force	Acc/Dec time
	Acc/Dec time 1	0.	0
	Acc/Dec time 2	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
28.72	Freq acceleration time 1	Defines acceleration time 1 as the time required for the frequency to change from zero to the frequency defined by parameter 46.02 Frequency scaling not to parameter 30.14. Maximum frequency)  If the reference increases faster than the set acceleration rate, the motor will follow the acceleration rate.  If the reference increases slower than the set acceleration rate, the motor frequency will follow the reference.  If the acceleration time is set too short, the drive will automatically prolong the acceleration in order not to exceed the drive torque limits.	20.000 s
	0.000 1800.000 s	Acceleration time 1.	10 = 1 s

No.	Name/Value	Description	Def/FbEq16
28.73	Freq deceleration time 1	Defines deceleration time 1 as the time required for the frequency to change from the frequency defined by parameter 46.02 Frequency scaling (not from parameter 30.14 Maximum frequency) to zero.  If there is any doubt about the deceleration time being too short, ensure that DC overvoltage control (30.30 Overvoltage control) is on.  Note: If a short deceleration time is needed for a high inertia application, the drive should be equipped with braking equipment such as a brake chopper and brake resistor.	20.000 s
	0.000 1800.000 s	Deceleration time 1.	10 = 1 s
28.74	Freq acceleration time 2	Defines acceleration time 2. See parameter 28.72 Freq acceleration time 1.	60.000 s
	0.000 1800.000 s	Acceleration time 2.	10 = 1 s
28.75	Freq deceleration time 2	Defines deceleration time 2. See parameter 28.73 Freq deceleration time 1.	60.000 s
	0.000 1800.000 s	Deceleration time 2.	10 = 1 s
28.76	Freq ramp in zero source	Selects a source that forces the frequency reference to zero.  0 = Force frequency reference to zero.  1 = Normal operation	Inactive
	Active	0.	0
	Inactive	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
28.77	Freq ramp hold	Selects a source that forces the output of the frequency ramp generator to actual frequency value.  0 = Force ramp output to actual frequency 1 = Normal operation	Inactive
	Active	0.	0
	Inactive	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10

No.	Name/Value	Description	Def/FbEq16	
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11	
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-	
28.78	Freq ramp output balancing	Defines a reference for frequency ramp balancing. The output of the ramp generator is forced to this value when balancing is enabled by parameter 28.79 Freq ramp out balancing enable.	0.00 Hz	
	-500.00 500.00 Hz	Frequency ramp balancing reference.	See par. 46.02	
28.79	Freq ramp out balancing enable	Selects the source for enabling/disabling speed ramp balancing. See parameter 28.78 Freq ramp output balancing.  0 = Disabled 1 = Enabled	Not selected	
	Not selected	0.		
	Selected	1.		
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2	
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3	
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4	
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5	
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6	
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7	
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10	
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11	
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-	
28.90	Frequency ref act 1	Displays the value of frequency reference source 1 (selected by parameter 28.11 Frequency ref1 source). See the control chain diagram on page 692.  This parameter is read-only.	-	
	-500.00 500.00 Hz	Value of frequency reference source 1.	See par. 46.02	
28.91	Frequency ref act 2	Displays the value of frequency reference source 2 (selected by parameter 28.12 Frequency ref2 source). See the control chain diagram on page 692.  This parameter is read-only.	-	
	-500.00 500.00 Hz	Value of frequency reference source 2.	See par. 46.02	
28.92	Frequency ref act 3	Displays the frequency reference after the function applied by parameter 28.13 Frequency ref1 function (if any), and after selection (28.14 Frequency ref1/2 selection). See the control chain diagram on page 692. This parameter is read-only.	-	
	-500.00 500.00 Hz	Frequency reference after selection.	See par. 46.02	

No.	Name/Value	Description	Def/FbEq16
28.96	Frequency ref act 7	Displays the frequency reference after application of constant frequencies, control panel reference, etc. See the control chain diagram on page 692.  This parameter is read-only.	-
	-500.00 500.00 Hz	Frequency reference 7.	See par. 46.02
28.97	Frequency ref unlimited	Displays the frequency reference after application of critical frequencies, but before ramping and limiting. See the control chain diagram on page 693.  This parameter is read-only.	-
	-500.00 500.00 Hz	Frequency reference before ramping and limiting.	See par. 46.02

No.	Name/	Value Des	cription	Def/FbEq10	
30 Limits Drive		Driv	e operation limits.		
30.01	Limit w		olays limit word 1. s parameter is read-only.	-	
	Bit	Name	Description		
	0	Torq lim	1 = Drive torque is being limited by the motor control (control, current control, load angle control or pull-out of the torque limits defined by parameters.		
	1	Spd ctl tlim min	1 = Speed controller output is being limited by 25.11 S min torque	Speed control	
	2	Spd ctl tlim max	1 = Speed controller output is being limited by 25.12 s max torque	Speed control	
	3	Torq ref max	1 = Torque reference ramp input is being limited by 26.09 Maximum torque ref, source of 30.25 Maximum torque sel, 30.26 Power motoring limit or 30.27 Power generating limit. See diagram on page 690.  1 = Torque reference ramp input is being limited by 26.08 Minimum torque ref, source of 30.18 Minimum torque sel, 30.26 Power motoring limit or 30.27 Power generating limit. See diagram on page 690.		
	4	Torq ref min			
	5	Tlim max speed	1 = Torque reference is being limited by the rush contr maximum speed limit (30.12 Maximum speed)		
	6	Tlim min speed	1 = Torque reference is being limited by the rush contr minimum speed limit (30.11 Minimum speed)	ol because o	
	7	Max speed ref li	<ul> <li>1 = Speed reference is limited by value defined in para Maximum speed or maximum permanent magnet mot based on DC voltage</li> </ul>		
	8	Min speed ref lin	1 = Speed reference is limited by 30.11 Minimum speed maximum permanent magnet motor speed limit based voltage		
	9	Max freq ref lim	1 = Frequency reference is being limited by 30.14 Ma. frequency	ximum	
	10	Min freq ref lim	1 = Frequency reference is being limited by 30.13 Min	nimum	
	11	Reserved	1 - 3 3		
	12	Sw freq ref lim	1 = Requested output frequency cannot be reached d switching frequency limitation (because of output filter related protections)		
	13	Load angle lim	(With permanent magnet motors and synchronous rel motors, and externally-excited synchronous motors in 1 = Maximum load angle is being limited, ie. the motor produce any more torque  (With externally-excited synchronous motors in dynam 1 = Torque is being limited	steady state r cannot	

0000h...FFFFh Limit word 1. 1 = 1

14...15 Reserved

No.	Name/Va	alue	Desc	ription	Def/FbEq16	
30.02	Torque li	mit status		ays the torque controller limitation status word. parameter is read-only.	-	
	Bit	Name		Description		
	0	Undervolta	ge	*1 = Intermediate DC circuit undervoltage		
	1	Overvoltag	e	*1 = Intermediate DC circuit overvoltage		
	2	Maximum torque		*1 = Torque is being limited by 30.26 Power motoring limit, 30.27 Power generating limit or the source of 30.18 Minimum torque sel. See diagram on page 690.  *1 = Torque is being limited by 30.26 Power motoring limit, 30.27 Power generating limit or the source of 30.25 Maximum torque sel. See diagram on page 690.		
	3					
	4	Internal cur	rent	1 = An inverter current limit (identified by bits 811) is a	active	
	5	angle angle 1  Motor pullout (		(With permanent magnet motors, synchronous reluctance motors, and externally-excited synchronous motors only)  1 = Maximum load angle limit is active, ie. the motor is producing as much torque as possible  (With asynchronous motors only)  Motor pull-out limit is active, i.e. the motor cannot produce any more torque		
	6					
	7	Reserved				
	8	Thermal		1 = Input current is being limited by the main circuit thermal limit		
	9	Max current User current Thermal IGBT IGBT overtemperature		*1 = Maximum output current (I <sub>MAX</sub> ) is being limited  *1 = Output current is being limited by 30.17 Maximum current  *1 = Output current is being limited by a calculated thermal current value  *1 = Output current is being limited because of estimated IGBT temperature		
	10					
	11					
	12					
	13	IGBT overl	oad	*1 = Output current is being limited because of IGBT junction to case temperature		
	1415	Reserved				
				and one out of bits 9…11 can be on simultaneously. The ceeded first.	bit typically	
	0000h	FFFFh	Torqu	ue limitation status word.	1 = 1	
30.11	Minimun	n speed	Defir	warning! This value must not be higher than 30.12 Maximum speed.  Warning! In frequency control mode, this limit is not effective. Make sure the frequency limits (30.13 and 30.14) are set appropriately if frequency control is used.  Warning! In a master/follower configuration, do not set maximum and minimum speed limits with the same sign on a follower drive. See section Master/follower functionality (page 74).	-1500.00 rpm; - 1800.00 rpn (95.20 b0)	
	-30000.00 30000.00		Minir	num allowed speed.	See par. 46.01	

1 = 1 A

0.00 A

1 = 1 A

Defines a maximum start current when enabled by

parameter 30.15 Maximum start current enable.

Defines the maximum allowed motor current.

Maximum start current.

Maximum motor current.

30.16

30.17

Maximum start

0.00 ... 30000.00 A

Maximum current
0.00 ... 30000.00 A

current

No.	Name/Value	Description	Def/FbEq16
30.18	Minimum torque sel	Selects a source that switches between two different predefined minimum torque limits.  0 = Minimum torque limit defined by 30.19 is active  1 = Minimum torque limit selected by 30.21 is active  The user can define two sets of torque limits, and switch between the sets using a binary source such as a digital input. The minimum limit selection (30.18) is independent of the maximum limit selection (30.25).  The first set of limits is defined by parameters 30.19 and 30.20. The second set has selector parameters for both the minimum (30.21) and maximum (30.22) limits that allows the use of a selectable analog source (such as an analog input).  30.21  Al1  Al2  PID  30.24  Other  30.25  1  User-defined minimum torque limit  30.20  The limit selection parameters are updated on a 10 ms time level.  Note: In addition to the user-defined limits, torque may be limited for other reasons (such as power limitation). Refer to the block diagram on page 689.	Minimum torque 1
	Minimum torque 1	0 (minimum torque limit defined by 30.19 is active).	0
	Minimum torque 2 source	1 (minimum torque limit selected by 30.21 is active).	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-

No.	Name/Value	Description	Def/FbEq16
30.19	Minimum torque 1	Defines a minimum torque limit for the drive (in percent of nominal motor torque). See diagram at parameter 30.18 Minimum torque sel.  The limit is effective when  • the source selected by 30.18 Minimum torque sel is 0, or  • 30.18 is set to Minimum torque 1.  Note: Do not set this parameter to 0% in an attempt to prevent reverse rotation. In an open-loop application, that is likely to prevent the motor from stopping altogether. To prevent reverse rotation, use the speed/frequency limits in this parameter group, or parameters 20.23/20.24.	-300.0%
	-1600.0 0.0%	Minimum torque limit 1.	See par. 46.03
30.20	Maximum torque 1	Defines a maximum torque limit for the drive (in percent of nominal motor torque). See diagram at parameter 30.18  Minimum torque sel.  The limit is effective when  the source selected by 30.25 Maximum torque sel is 0, or  30.25 is set to Maximum torque 1.	300.0%
	0.0 1600.0%	Maximum torque 1.	See par. 46.03
30.21	Minimum torque 2 source	Defines the source of the minimum torque limit for the drive (in percent of nominal motor torque) when  • the source selected by parameter 30.18 Minimum torque sel is 1, or  • 30.18 is set to Minimum torque 2 source.  See diagram at 30.18 Minimum torque sel.  Note: Any positive values received from the selected source are inverted.	Minimum torque 2
	Zero	None.	0
	Al1 scaled	12.12 Al1 scaled value (see page 207).	1
	Al2 scaled	12.22 AI2 scaled value (see page 208).	2
	PID	40.01 Process PID output actual (output of the process PID controller).	5
	Minimum torque 2	30.23 Minimum torque 2.	6
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
30.22	Maximum torque 2 source	Defines the source of the maximum torque limit for the drive (in percent of nominal motor torque) when  • the source selected by parameter 30.25 Maximum torque sel is 1, or  • 30.25 is set to Maximum torque 2 source.  See diagram at 30.18 Minimum torque sel.  Note: Any negative values received from the selected source are inverted.	Maximum torque 2
	Zero	None.	0
	Al1 scaled	12.12 Al1 scaled value (see page 207).	1
	Al2 scaled	12.22 AI2 scaled value (see page 208).	2
	PID	40.01 Process PID output actual (output of the process PID controller).	5
	Maximum torque 2	30.24 Maximum torque 2.	6

No.	Name/Value	Description	Def/FbEq16
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
30.23	Minimum torque 2	Defines the minimum torque limit for the drive (in percent of nominal motor torque) when  • the source selected by parameter 30.18 Minimum torque sel is 1, and  • 30.21 is set to Minimum torque 2.  Note: Do not set this parameter to 0% in an attempt to prevent reverse rotation. In an open-loop application, that is likely to prevent the motor from stopping altogether. To prevent reverse rotation, use the speed/frequency limits in this parameter group, or parameters 20.23/20.24.  See diagram at 30.18 Minimum torque sel.	-300.0%
	-1600.0 0.0%	Minimum torque limit 2.	See par. 46.03
30.24	Maximum torque 2	Defines the maximum torque limit for the drive (in percent of nominal motor torque) when  • the source selected by parameter 30.25 Maximum torque sel is 1, and  • 30.22 is set to Maximum torque 2.  See diagram at 30.18 Minimum torque sel.	300.0%
	0.0 1600.0%	Maximum torque limit 2.	See par. 46.03
30.25	Maximum torque sel	Selects a source that switches between two different maximum torque limits.  0 = Maximum torque limit 1 defined by 30.20 is active 1 = Maximum torque limit selected by 30.22 is active See also parameter 30.18 Minimum torque sel.	Maximum torque 1
	Maximum torque 1	0.	0
	Maximum torque 2 source	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
30.26	Power motoring limit	Defines the maximum shaft power in motoring mode, i.e. when power is being transferred from the motor to the machinery. The value is given in percent of nominal motor power.	300.00%
	0.00 600.00%	Maximum shaft power in motoring mode.	1 = 1%

No.	Name/Value	Description	Def/FbEq16
30.27	Power generating limit	Defines the maximum shaft power in generating mode, i.e., when power is being transferred from the machinery to the motor. The value is given in percent of nominal motor power.  Note: Do not set this parameter to 0% in an attempt to prevent reverse rotation. In an open-loop application, that is likely to prevent the motor from stopping altogether. To prevent reverse rotation, use the speed/frequency limits in this parameter group, or parameters 20.23/20.24.	-300.00%
	-600.00 0.00%	Maximum shaft power in generating mode.	1 = 1%
30.30	Overvoltage control	Enables the overvoltage control of the intermediate DC link. Fast braking of a high inertia load causes the voltage to rise to the overvoltage control limit. To prevent the DC voltage from exceeding the limit, the overvoltage controller automatically decreases the braking torque.  Note: If the drive is equipped with a brake chopper and resistor, or a regenerative supply unit, the controller must be disabled.	Enable
	Disable	Overvoltage control disabled.	0
	Enable	Overvoltage control enabled.	1
30.31	Undervoltage control	Enables the undervoltage control of the intermediate DC link. If the DC voltage drops due to input power cut off, the undervoltage controller will automatically decrease the motor torque in order to keep the voltage above the lower limit. By decreasing the motor torque, the inertia of the load will cause regeneration back to the drive, keeping the DC link charged and preventing an undervoltage trip until the motor coasts to a stop. This will act as a power-loss ride-through functionality in systems with high inertia, such as a centrifuge or a fan.	Enable
	Disable	Undervoltage control disabled.	0
	Enable	Undervoltage control enabled.	1
30.35	Thermal current limitation	Enables/disables temperature-based output current limitation. The limitation should only be disabled if required by the application.	Enable
	Disable	Thermal current limitation disabled.	0
	Enable	Thermal current limitation enabled.	1

	Name/Value Descript			tion	Def/FbEq16	
0.101	LSU li	mit word 1	95.20) Displays	(Visible only when IGBT supply unit control is activated by		
	Bit	Name		Description		
	0	P user ref ma	х	1 = Power reference is limited by supply control pro	gram	
	1	P user ref mir	า	parameters		
	2	P user max		1 = Power is limited by parameter		
	3	P user min		1 = Power is limited by parameter		
	4	P cooling over	rtemp	1 = Power reference is limited because of coolant overtemperature		
	5	P power unit	overtemp			
	615	Reserved		·		
	0000hFFFFh Supply unit limit word 1.				1 = 1	
102	L30 II	IIIIL WOIG Z	95.20)	only when IGBT supply unit control is activated by	-	
				limit word 2 of the supply unit. ameter is read-only.		
	Bit	Name		ameter is read-only.		
	Bit 0	Name Q user ref ma	This para			
			This para	Description		
	0	Q user ref ma	This para	Description	coolant	
	0	Q user ref ma	This para	Description  1 = Reactive power reference is limited  1 = Reactive power reference is limited because of		
	0 1 2	Q user ref ma Q user ref mi Q cooling over	This para	Description  1 = Reactive power reference is limited  1 = Reactive power reference is limited because of overtemperature  1 = Reactive power reference is limited because of		
	0 1 2 3	Q user ref ma Q user ref mi Q cooling ove Q power unit	This para	Description  1 = Reactive power reference is limited  1 = Reactive power reference is limited because of overtemperature  1 = Reactive power reference is limited because of overtemperature		
	0 1 2 3 4	Q user ref ma Q user ref mi Q cooling ove Q power unit	This para	Description  1 = Reactive power reference is limited  1 = Reactive power reference is limited because of overtemperature  1 = Reactive power reference is limited because of overtemperature  1 = Reactive power reference is limited because of overtemperature  1 = AC overvoltage protection	supply unit	
	0 1 2 3 4 56	Q user ref ma Q user ref mi Q cooling ove Q power unit AC overvolta Reserved	This para	Description  1 = Reactive power reference is limited  1 = Reactive power reference is limited because of overtemperature  1 = Reactive power reference is limited because of overtemperature  1 = Reactive power reference is limited because of overtemperature  1 = AC overvoltage protection	supply unit	
	0 1 2 3 4 56 3	Q user ref ma Q user ref mi Q cooling ove Q power unit AC overvolta Reserved AC diff max AC diff min	This para	Description  1 = Reactive power reference is limited  1 = Reactive power reference is limited because of overtemperature  1 = Reactive power reference is limited because of overtemperature  1 = Reactive power reference is limited because of overtemperature  1 = AC overvoltage protection	supply unit	

1 = 1%

No.	Name/Va	alue	Descript	ion	Def/FbEq16			
30.103	LSU limi	t word 3	95.20) Displays	nly when IGBT supply unit control is activated by limit word 3 of the supply unit. meter is read-only.	-			
	Bit	Name		Description				
	0	Undervoltag	ge limit	1 = Power is limited by undervoltage controller				
	1	Overvoltage limit  Motoring power		1 = Power is limited by overvoltage controller				
	2			1 = Power is being limited by temperature or user p	ower limits			
	3	Generating	power	(see parameters and )				
	4	Active curre	ent limit	1 = Active current is limited. For details, see bits 61415.	.9 and			
	5	Reactive cu	ırrent limit	1 = Reactive current is limited. For details, see bits	1213.			
	6	Thermal lim	nit	1 = Active current is limited by internal main circuit	thermal limit			
	7	SOA limit		1 = Active current is limited by internal safe operation				
	8	User currer	nt limit	1 = Active current is limited by current limit set by supply control program parameters				
	9	Thermal IG	ВТ	1 = Active current is limited based on internal maximum therma IGBT stress limit				
	1011	Reserved						
	12	Q act neg		1 = Negative reactive current is limited by maximum total current				
	13	Q act pos		<ul> <li>1 = Positive reactive current is limited by maximum total current</li> <li>1 = Negative active current is limited by maximum total current</li> <li>1 = Positive active current is limited by maximum total current</li> </ul>				
	14	P act neg						
	15	P act pos						
	0000hFFFFh Supply		Supply u	y unit limit word 3.				
30.104	LSU limi	t word 4	95.20) Displays	nly when IGBT supply unit control is activated by limit word 4 of the supply unit. meter is read-only.	-			
	Bit	Name	De	scription				
	0	Udc ref max	x 1 =	DC reference is limited by supply control program parameters				
	1	Udc ref min	1					
	2	User I max		Current is limited by supply control program parameters				
	3	Temp I max	1 =	Current is limited based on temperature				
	415 Reserved							
	0000hFFFFh Supply to		Supply u	nit limit word 4.	1 = 1			
30.148	power limit 95.20) Defines Negative		95.20) Defines a Negative	nly when IGBT supply unit control is activated by a minimum power limit for the supply unit. values refer to regenerating, i.e. feeding power into y network.	-130.0%			
	-200.0	0.0%	Minimum	power limit for supply unit.	1 = 1%			
30.149	LSU maximum (Vis		95.20)	nly when IGBT supply unit control is activated by	130.0%			

Defines a maximum power limit for the supply unit.

Maximum power limit for supply unit.

0.0 ... 200.0%

No.	Name/Value	Description	Def/FbEq16
31 Fau	ult functions	Settings that define the behavior of the drive upon fault situations.	
31.01	External event 1 source	Defines the source of external event 1. See also parameter 31.02 External event 1 type.  0 = Trigger event 1 = Normal operation	Inactive (true); DI6 (95.20 b8)
	Active (false)	0.	0
	Inactive (true)	1.	1
	DIIL	DIIL input (10.02 DI delayed status, bit 15).	2
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	3
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	4
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	5
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	6
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	7
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	8
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	11
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	12
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
31.02	External event 1 type	Selects the type of external event 1.	Fault (95.20 b8)
	Fault	The external event generates a fault.	0
	Warning	The external event generates a warning.	1
	Warning/Fault	If the drive is modulating, the external event generates a fault. Otherwise, the event generates a warning.	3
31.03	External event 2 source	Defines the source of external event 2. See also parameter 31.04 External event 2 type. For the selections, see parameter 31.01 External event 1 source.	Inactive (true); DIIL (95.20 b5)
31.04	External event 2 type	Selects the type of external event 2.	-
	Fault	The external event generates a fault.	0
	Warning	The external event generates a warning.	1
	Warning/Fault	If the drive is modulating, the external event generates a fault. Otherwise, the event generates a warning.	3
31.05	External event 3 source	Defines the source of external event 3. See also parameter 31.06 External event 3 type. For the selections, see parameter 31.01 External event 1 source.	Inactive (true)
31.06	External event 3 type	Selects the type of external event 3.	
	Fault	The external event generates a fault.	0
	Warning	The external event generates a warning.	1
	Warning/Fault	If the drive is modulating, the external event generates a fault. Otherwise, the event generates a warning.	3

No.	Name/Value	ne/Value Description			
31.07	Defines the source of external event 4. See also parameter 31.08 External event 4 type.  For the selections, see parameter 31.01 External event 1 source.				
31.08	External event 4 type	Selects the type of external event 4.			
	Fault	The external event generates a fault.	0		
	Warning	The external event generates a warning.	1		
	Warning/Fault	If the drive is modulating, the external event generates a fault. Otherwise, the event generates a warning.	3		
31.09	External event 5 source	Defines the source of external event 5. See also parameter 31.10 External event 5 type. For the selections, see parameter 31.01 External event 1 source.	Inactive (true)		
31.10	External event 5 type	Selects the type of external event 5.	-		
	Fault	The external event generates a fault.	0		
	Warning	The external event generates a warning.	1		
	Warning/Fault	If the drive is modulating, the external event generates a fault. Otherwise, the event generates a warning.	3		
31.11	Fault reset selection	Selects the source of an external fault reset signal. The signal resets the drive after a fault trip if the cause of the fault no longer exists.  0 -> 1 = Reset  Note: A fault reset from the fieldbus interface is always observed regardless of this parameter.	DI3		
	Not selected	0.	0		
	Selected	1.	1		
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2		
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3		
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4		
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5		
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6		
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7		
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10		
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11		
	FBA A MCW bit 7	Control word bit 7 received through fieldbus interface A.	30		
	EFB MCW bit 7	Control word bit 7 received through the embedded fieldbus interface.	32		
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-		

No.	Name/Va	alue	Description Def/FbEq				
31.12	Autorese	t selection	Selects faults that are automatically reset. The parameter is a 16-bit word with each bit corresponding to a fault type. Whenever a bit is set to 1, the corresponding fault is automatically reset.  The number and interval of reset attempts are defined by parameters 31.1431.16.  WARNING! Before you activate the function, make sure that no dangerous situations can occur. The function resets the drive automatically and continues operation after a fault.  Notes:  The autoreset function is only available in external control; see section Local control vs. external control (page 40).  Faults related to the Safe torque off (STO) function cannot be automatically reset.  The bits of this binary number correspond to the following faults:	0000h			
	Bit	Fault					
	0	Overcurrent	t				
	1	Overvoltage	e				
	2	Undervoltage					
	3	Al supervision fault					
	4	Supply unit					
	57	Reserved					
	8	Application fault 1 (defined in the application program)					
	9	Application fault 2 (defined in the application program)					
	10	Selectable fault (see parameter 31.13 User selectable fault)					
	11	External fault 1 (from source selected by parameter 31.01 External event 1 source)					
	12	External fault 2 (from source selected by parameter 31.03 External event 2 source)					
	13	External fault 3 (from source selected by parameter 31.05 External event 3 source)					
	14	1	ult 4 (from source selected by parameter 31.07 External event				
	15	External fau	ult 5 (from source selected by parameter 31.09 External event	5 source)			
	0000h	FFFFh	Automatic reset configuration word.	1 = 1			
31.13	User sele	ectable fault	Defines the fault that can be automatically reset using parameter 31.12 Autoreset selection, bit 10.  The faults are listed in chapter Fault tracing (page 616).	0000h			
	0000h	FFFFh	Fault code.	10 = 1			
31.14 Number of trials  05			Defines the maximum number of automatic resets that the drive is allowed to attempt within the time specified by 31.15 Total trials time.  If the fault persists, subsequent reset attempts will be made at intervals defined by 31.16 Delay time.  The faults to be automatically reset are defined by 31.12 Autoreset selection.	0			
			<b>1</b>	ļ			

No.	Name/Value	Description	Def/FbEq16
31.15	Total trials time	Defines a time window for automatic fault resets. The maximum number of attempts made during any period of this length is defined by 31.14 Number of trials.  Note: If the fault condition remains and cannot be reset, each reset attempt will generate an event and start a new time window. In practice, if the specified number of resets (31.14) at specified intervals (31.16) take longer than the value of 31.15, the drive will continue to attempt resetting the fault until the cause is eventually removed.	
	1.0 600.0 s	Time for automatic resets.	10 = 1 s
31.16	Delay time	Defines the time that the drive will wait after a fault (or a previous reset attempt) before attempting an automatic reset. See parameter 31.12 Autoreset selection.	0.0 s
	0.0 120.0 s	Autoreset delay.	10 = 1 s
31.19	Motor phase loss	Selects how the drive reacts when a motor phase loss is detected.  Note: The drive may not be able to reliably detect a phase loss in a multimotor application: a separate protection method (eg. a motor protection switch) should be installed for each motor.	Fault
	No action	No action taken.	0
	Fault	The drive trips on fault 3381 Output phase loss.	1
31.20	Earth fault	Selects how the drive reacts when an earth fault or current unbalance is detected in the motor or the motor cable.	Fault
	No action	No action taken.	0
	Warning	The drive generates an A2B3 Earth leakage warning.	1
	Fault	The drive trips on fault 2330 Earth leakage.	2

No.	Name/Value	Descri	ption			Def/FbEq16
31.22	STO indication run/stop	Selects torque indicati stoppe The tal genera Notes:  This function the support start rese as it This runn For mo of the control of the contr	Fault/Fault			
	Fault/Fault	Of the C	arive.			0
		Inp IN1 0	in2 0	Fault 5091 Safe torque of	off torque off the off and FA81 Safe off 1 loss	
		1	0	Faults 5091 Safe torque of	ff 2 loss	
		1	1	(Normal o	peration)	
	Fault/Warning					1
			uts	Indica		
		IN1	IN2	Running	Stopped	
		0	0	Fault 5091 Safe torque off	torque off	
		0	1	Faults 5091 Safe torque off and FA81 Safe torque off 1 loss	Warning A5A0 Safe torque off and fault FA81 Safe torque off 1 loss	
		1	0	Faults 5091 Safe torque off and FA82 Safe torque off 2 loss	Warning A5A0 Safe torque off and fault FA82 Safe torque off 2 loss	
		1	1	(Normal o	peration)	

No.	Name/Value	Description	Def/FbEq16
31.24	Selects how the drive reacts to a motor stall condition.  A stall condition is defined as follows:  • The drive exceeds at stall current limit (31.25 Stall cu limit), and  • the output frequency is below the level set by parama 31.27 Stall frequency limit or the motor speed is below level set by parameter 31.26 Stall speed limit, and  • the conditions above have been true longer than the set by parameter 31.28 Stall time.		Fault
	No action	None (stall supervision disabled).	0
	Warning	The drive generates an A780 Motor stall warning.	1
	Fault	The drive trips on fault 7121 Motor stall.	2
31.25	Stall current limit	200.0%	
	0.0 1600.0%	Stall current limit.	10 = 1%
31.26	Stall speed limit	Stall speed limit in rpm. See parameter 31.24 Stall function.	150.00 rpm; 180.00 rpm (95.20 b0)
	0.00 10000.00 rpm	Stall speed limit.	See par. 46.01
31.27	Stall frequency limit	Stall frequency limit. See parameter 31.24 Stall function.  Note: Setting the limit below 10 Hz is not recommended.	15.00 Hz; 18.00 Hz (95.20 b0)
	0.00 500.00 Hz	Stall frequency limit.	See par. 46.02
31.28	Stall time	Stall time. See parameter 31.24 Stall function.	20 s
	0 3600 s	Stall time.	1 = 1 s

No.	Name/Value	Description	Def/FbEq16
No. Name/Value  31.30 Overspeed trip margin		Defines, together with 30.11 Minimum speed and 30.12  Maximum speed, the maximum allowed speed of the motor (overspeed protection). If actual speed (90.01 Motor speed for control) exceeds the speed limit defined by parameter 30.11 or 30.12 by more than the value of this parameter, the drive trips on the 7310 Overspeed fault.  WARNING! This function only supervises the speed in DTC motor control mode. The function is not effective in scalar motor control mode.  Example: If the maximum speed is 1420 rpm and speed trip margin is 300 rpm, the drive trips at 1720 rpm.  Speed (90.01)  Overspeed trip level  31.30  Overspeed trip level	500.00 rpm
	0.00 10000.00 rpm	Overspeed trip margin.	See par. 46.01
31.32	Parameters 31.32 Emergency ramp supervision and 31.33 Emergency ramp supervision delay, together with 01.29 Speed change rate, provide a supervision function for emergency stop modes Off1 and Off3. The supervision is based on either • observing the time within which the motor stops, or • comparing the actual and expected deceleration rates. If this parameter is set to 0%, the maximum stop time is directly set in parameter 31.33. Otherwise, 31.32 defines the maximum allowed deviation from the expected deceleration rate, which is calculated from parameters 23.1123.19 (Off1) or 23.23 Emergency stop time (Off3). If the actual deceleration rate (01.29) deviates too much from the expected rate, the drive trips on 73B0 Emergency ramp failed, sets bit 8 of 06.17 Drive status word 2, and coasts to a stop.  If 31.32 is set to 0% and 31.33 is set to 0 s, the emergency stop ramp supervision is disabled.  See also parameter 21.04 Emergency stop mode.		0%
	0300%	Maximum deviation from expected deceleration rate.	1 = 1%

No.	Name/Value	Description	Def/FbEq16
31.33	Emergency ramp supervision delay	If parameter 31.32 Emergency ramp supervision is set to 0%, this parameter defines the maximum time an emergency stop (mode Off1 or Off3) is allowed to take. If the motor has not stopped when the time elapses, the drive trips on 73B0 Emergency ramp failed, sets bit 8 of 06.17 Drive status word 2, and coasts to a stop.  If 31.32 is set to a value other than 0%, this parameter defines a delay between the receipt of the emergency stop command and the activation of the supervision. It is recommended to specify a short delay to allow the speed change rate to stabilize.	0 s
	032767 s	Maximum ramp-down time, or supervision activation delay.	1 = 1 s
31.35	Main fan fault function	Selects how the drive reacts when a main cooling fan fault is detected.	Fault
	Fault	The drive trips on fault 5080 Fan.	0
	Warning	The drive generates an A581 Fan warning.	1
	No action	No action taken.	2
31.36	Aux fan fault function	(Only visible with a ZCU control unit) Selects how the drive reacts when an auxiliary fan fault is detected.	Fault
	Fault	The drive trips on fault 5081 Auxiliary fan broken.  Note: The fault is suppressed for two minutes after power- up. During this time, the drive only generates a warning, A582 Auxiliary fan not running.	0
	Warning	The drive generates a warning, A582 Auxiliary fan not running.	1
31.37	Ramp stop supervision	Parameters 31.37 Ramp stop supervision and 31.38 Ramp stop supervision delay, together with 01.29 Speed change rate, provide a supervision function for normal (i.e. non-emergency) ramp stopping.  The supervision is based on either  • observing the time within which the motor stops, or  • comparing the actual and expected deceleration rates. If this parameter is set to 0%, the maximum stop time is directly set in parameter 31.38. Otherwise, 31.37 defines the maximum allowed deviation from the expected deceleration rate, which is calculated from parameters 23.1123.19. If the actual deceleration rate (01.29) deviates too much from the expected rate, the drive trips on 73B1 Stop failed, sets bit 14 of 06.17 Drive status word 2, and coasts to a stop. If 31.37 is set to 0% and 31.38 is set to 0 s, the ramp stop supervision is disabled.	0%
	0300%	Maximum deviation from expected deceleration rate.	1 = 1%
31.38	Ramp stop supervision delay	If parameter 31.37 Ramp stop supervision is set to 0%, this parameter defines the maximum time a ramp stop is allowed to take. If the motor has not stopped when the time elapses, the drive trips on 73B1 Stop failed, sets bit 14 of 06.17 Drive status word 2, and coasts to a stop.  If 31.37 is set to a value other than 0%, this parameter defines a delay between the receipt of the stop command and the activation of the supervision. It is recommended to specify a short delay to allow the speed change rate to stabilize.	0 s
	032767 s	Maximum ramp-down time, or supervision activation delay.	1 = 1 s

No.	Name/Va	alue	Description		Def/FbEq16
31.40 Disable warning		warnings	bit word with each	s to be suppressed. The parameter is a 16-ch bit corresponding to a warning. Whenever the corresponding warning is suppressed. Dinary number correspond to the following	0000b
	Bit	Name		Warning	
	0	Overvoltage	е	A3A1 DC link overvoltage	
	1	Reserved			
	2	Encoder 1		A7E1 Encoder (for encoder 1)	
	3	Encoder 2		A7E1 Encoder (for encoder 2)	
	4	CU (Contro	l unit) battery	A5F4 Control unit battery	
	5	Emergency	Stop Off2	AFE1 Emergency stop (off2)	
	6	Emergency	Stop Off1 Off3	AFE2 Emergency stop (off1 or off3)	
	715	Reserved			
	0000h	FFFFh	Warning suppres	ssion word.	1 = 1
31.42	Overcurrent fault limit		Sets a custom maccording to the appropriate to the appropriate in maceta a lower current magnet motor from the set a lower magnet motor from the set a lower current magnet magnet motor from the set a lower current magnet magnet magnet motor from the set a lower current magnet motor from the set a lower current magnet motor	notor current fault limit. Inatically sets an internal motor current limit drive hardware. The internal limit is ne drive hardware. The internal limit is ost cases, but this parameter can be used to ent limit, for example, to protect a permanent om demagnetization. Internal limit is in force.	-
	0.0300	00.0 A	Custom motor c	urrent fault limit.	See par. 46.05
31.54	Fault act	ion	Selects the stop	mode when a non-critical fault occurs.	Coast
	Coast		The drive coasts	s to a stop.	0
	Emerger	ncy ramp		s the ramp specified for an emergency stop .23 Emergency stop time.	1
31.55	Ext I/O c	omm loss	Selects how the I/O extension me	drive reacts when the communication to an odule fails.	Fault
	No action	า	No action taken.		0
	Warning		The drive genera	ates a warning, A799 Ext I/O comm loss.	1
	Fault		The drive trips o	n a fault, 7082 Ext I/O comm loss.	2
31.120	LSU ear	th fault	95.20)	en IGBT supply unit control is activated by supply unit reacts when an earth fault or ce is detected.	Fault
	No action	า	No action taken.		0
	Warning		The supply unit	generates an AE02 Earth leakage warning.	1
	Fault		The supply unit	trips on fault 2E01 Earth leakage.	2
31.121	LSU sup loss	ply phase	95.20)	en IGBT supply unit control is activated by supply unit reacts when a supply phase loss	Fault
	No action	า	No action taken.		0
			1		1

No.	Name/Value		Description		Def/FbEq16
	Fault		The supply un	nit trips on fault 3E00 Input phase loss.	1
32 Supervision			Configuration of signal supervision functions 13.  Three values can be chosen to be monitored; a warning or fault is generated whenever predefined limits are exceeded.  See also section Signal supervision (page 130).		
32.01	01 Supervision status		Indicates whe supervision fu limits.  Note: This wo	ision status word. ther the values monitored by the signal unctions are within or outside their respective ord is independent of the drive actions defined is 32.06, 32.16 and 32.26.	0000Ь
	Bit	Name		Description	
	0	Supervisio	n 1 active	1 = Signal selected by 32.07 is outside its lim	its.
	1	Supervisio		1 = Signal selected by 32.17 is outside its lim	
	2	Supervisio	n 3 active	1 = Signal selected by 32.27 is outside its lim	its.
	315	Reserved			
	00000	111b	Signal supervi	ision status word.	1 = 1
32.05	Supervision 1 function		Selects the modern Determines had is compared to respectively).	ode of signal supervision function 1. by the monitored signal (see parameter 32.07) o its lower and upper limits (32.09 and 32.10 The action to be taken when the condition is ected by 32.06.	Disabled
	Disabled		Signal supervi	ision 1 not in use.	0
	Low		Action is taker	n whenever the signal falls below its lower limit.	1
	High		Action is taker limit.	n whenever the signal rises above its upper	2
	Abs low			n whenever the absolute value of the signal (absolute) lower limit.	3
	Abs high			n whenever the absolute value of the signal s (absolute) upper limit.	4
	Both		Action is taker rises above its	n whenever the signal falls below its low limit or s high limit.	5
	Abs both	ı		n whenever the absolute value of the signal (absolute) low limit or rises above its h limit.	6
32.06	Supervis	ion 1 action	by signal supe	ction the drive takes when the value monitored ervision 1 exceeds its limits. rameter does not affect the status indicated by ision status.	No action
	No actio	n	No action take	en.	0
	Warning		A warning (A8	BB0 Signal supervision) is generated.	1
	Fault		The drive trips	s on 80B0 Signal supervision.	2
32.07	Supervis	ion 1 signal	-	gnal to be monitored by signal supervision	Zero
	Zero		None.		0
	Speed		01.01 Motor s	speed used (page 160).	1
	Opou				

No.	Name/Value	Description	Def/FbEq16	
	Current	01.07 Motor current (page 160).	4	
	Torque	01.10 Motor torque (page 160).	6	
	DC voltage	01.11 DC voltage (page 160).	7	
	Output power	01.14 Output power (page 161).	8	
	Al1	12.11 Al1 actual value (page 206).	9	
	Al2	12.21 Al2 actual value (page 208).	10	
	Speed ref ramp in	23.01 Speed ref ramp input (page 268).	18	
	Speed ref ramp out	23.02 Speed ref ramp output (page 268).	19	
	Speed ref used	24.01 Used speed reference (page 274).	20	
	Torque ref used	26.02 Torque reference used (page 290).	21	
	Freq ref used	28.02 Frequency ref ramp output (page 298).	22	
	Process PID output	40.01 Process PID output actual (page 355).	24	
	Process PID feedback	40.02 Process PID feedback actual (page 355).	25	
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-	
32.08	Supervision 1 filter time	Defines a filter time constant for the signal monitored by signal supervision 1.	0.000 s	
	0.000 30.000 s	Signal filter time.	1000 = 1 s	
32.09	Supervision 1 low	Defines the lower limit for signal supervision 1.	0.00	
	-21474830.00 21474830.00	Low limit.	-	
32.10	Supervision 1 high	Defines the upper limit for signal supervision 1.	0.00	
	-21474830.00 21474830.00	Upper limit.	-	
32.15	Supervision 2 function	Selects the mode of signal supervision function 2. Determines how the monitored signal (see parameter 32.17) is compared to its lower and upper limits (32.19 and 32.20 respectively). The action to be taken when the condition is fulfilled is selected by 32.16.	Disabled	
	Disabled	Signal supervision 2 not in use.	0	
	Low	Action is taken whenever the signal falls below its lower limit.	1	
	High	Action is taken whenever the signal rises above its upper limit.	2	
	Abs low	Action is taken whenever the absolute value of the signal falls below its (absolute) lower limit.	3	
	Abs high	Action is taken whenever the absolute value of the signal rises above its (absolute) upper limit.	4	
	Both	Action is taken whenever the signal falls below its low limit or rises above its high limit.	5	
	Abs both	Action is taken whenever the absolute value of the signal falls below its (absolute) low limit or rises above its (absolute) high limit.	6	

No.	Name/Value	Description	Def/FbEq16
32.16	Supervision 2 action	Selects the action the drive takes when the value monitored by signal supervision 2 exceeds its limits.  Note: This parameter does not affect the status indicated by 32.01 Supervision status.	No action
	No action	No action taken.	0
	Warning	A warning (A8B1 Signal supervision 2) is generated.	1
	Fault	The drive trips on 80B1 Signal supervision 2.	2
	Fault if running	If running, the drive trips on 80B1 Signal supervision 2.	3
32.17	Supervision 2 signal	Selects the signal to be monitored by signal supervision function 2. For the available selections, see parameter 32.07 Supervision 1 signal.	Zero
32.18	Supervision 2 filter time	Defines a filter time constant for the signal monitored by signal supervision 2.	0.000 s
	0.000 30.000 s	Signal filter time.	1000 = 1 s
32.19	Supervision 2 low	Defines the lower limit for signal supervision 2.	0.00
	-21474830.00 21474830.00	Low limit.	-
32.20	Supervision 2 high	Defines the upper limit for signal supervision 2.	0.00
	-21474830.00 21474830.00	Upper limit.	-
32.25	Supervision 3 function	Selects the mode of signal supervision function 3. Determines how the monitored signal (see parameter 32.27) is compared to its lower and upper limits (32.29 and 32.30 respectively). The action to be taken when the condition is fulfilled is selected by 32.26.	Disabled
	Disabled	Signal supervision 3 not in use.	0
	Low	Action is taken whenever the signal falls below its lower limit.	1
	High	Action is taken whenever the signal rises above its upper limit.	2
	Abs low	Action is taken whenever the absolute value of the signal falls below its (absolute) lower limit.	3
	Abs high	Action is taken whenever the absolute value of the signal rises above its (absolute) upper limit.	4
	Both	Action is taken whenever the signal falls below its low limit or rises above its high limit.	5
	Abs both	Action is taken whenever the absolute value of the signal falls below its (absolute) low limit or rises above its (absolute) high limit.	6
32.26	Supervision 3 action	Selects the action the drive takes when the value monitored by signal supervision 3 exceeds its limits.  Note: This parameter does not affect the status indicated by 32.01 Supervision status.	No action
	No action	No action taken.	0
	Warning	A warning (A8B2 Signal supervision 3) is generated.	1
	Fault	The drive trips on 80B2 Signal supervision 3.	2

No.	Name/V	alue alue	Description	Def/FbEq16
32.27	Supervision 3 signal		Selects the signal to be monitored by signal supervision function 3.  For the available selections, see parameter 32.07  Supervision 1 signal.	Zero
32.28	Supervision 3 filter time		Defines a filter time constant for the signal monitored by signal supervision 3.	0.000 s
	0.000	. 30.000 s	Signal filter time.	1000 = 1 s
32.29	Supervi	sion 3 low	Defines the lower limit for signal supervision 3.	0.00
	-214748 2147483	30.00 30.00	Low limit.	-
32.30	Supervis	sion 3 high	Defines the upper limit for signal supervision 3.	0.00
	-214748 2147483	30.00 30.00	Upper limit.	-
33 Gel count	neric tin er Counter		Configuration of maintenance timers/counters.  See also section <i>Maintenance timers and counters</i> (page 130).	
33.01	Counter	status	Displays the maintenance timer/counter status word, indicating which maintenance timers/counters have exceeded their limits.  This parameter is read-only.	-
	Bit	Name	Description	
	0	On-time1	1 = On-time timer 1 has reached its preset limit.	
	1	On-time2	1 = On-time timer 2 has reached its preset limit.	
	3	Edge 1 Edge 2	<ul><li>1 = Signal edge counter 1 has reached its preset limit.</li><li>1 = Signal edge counter 2 has reached its preset limit.</li></ul>	
	4	Value 1	1 = Value counter 1 has reached its preset limit.	
	5	Value 2	1 = Value counter 1 has reached its preset limit.	
	615	Reserved		
	0000 00 0011 11		Maintenance time/counter status word.	1 = 1
33.10	On-time	1 actual	Displays the actual present value of on-time timer 1. The timer runs whenever the signal selected by parameter 33.13 On-time 1 source is on.  When the timer exceeds the limit set by 33.11 On-time 1 warn limit, bit 0 of 33.01 Counter status is set to 1. The warning specified by 33.14 On-time 1 warn message is also given if enabled by 33.12 On-time 1 function.  The timer can be reset from the Drive composer PC tool, or from the control panel by keeping Reset depressed for over 3 seconds.	-
			I	
	04294	1967295 s	Actual present value of on-time timer 1.	-
33.11		1967295 s 1 warn limit	Actual present value of on-time timer 1.  Sets the warning limit for on-time timer 1.	- 0 s

No.	Name/Value		Description	Def/FbEq16		
33.12	On-time	1 function	Configures on-time timer 1.	0000b		
	Bit	Function				
	Counter mode 0 = Loop: When the limit is reached, the counter is reset. The counter state 33.01) switches to 1 for one second. The warning (if enabled) stays active 10 seconds. 1 = Saturate: When the limit is reached, the counter status (bit 0 of 33.01) 1, and remains so until 33.10 is reset. The warning (if enabled) also stays 33.10 is reset.					
	1		rable : No warning is given when the limit is reached : A warning (see <i>33.14</i> ) is given when the limit is reached			
	215	Reserved				
	0000b	0011h	On-time timer 1 configuration word.	1 = 1		
33.13			Selects the signal to be monitored by on-time timer 1.	False		
00.70	On-time 1 source False		Constant 0 (timer disabled).	0		
	True		Constant 1.	1		
	RO1		Bit 0 of 10.21 RO status (page 197).	2		
	Other [bit]		Source selection (see <i>Terms and abbreviations</i> on page 156).	-		
33.14	On-time 1 warn message		Selects the optional warning message for on-time timer 1.	On-time 1 exceeded		
	On-time 1 exceeded		A886 On-time 1. The message text can be edited on the control panel by choosing Menu – Settings – Edit texts.	0		
	Clean de	evice	A88C Device clean.	6		
	Maintain cooling f	additional an	A890 Additional cooling.	7		
	Maintain	cabinet fan	A88E Cabinet fan.	8		
	Maintain DC capacitors		A88D DC capacitor.	9		
	Maintain bearing	motor	A880 Motor bearing.	10		
33.20	On-time 2 actual		Displays the actual present value of on-time timer 2. The timer runs whenever the signal selected by parameter 33.23 On-time 2 source is on.  When the timer exceeds the limit set by 33.21 On-time 2 warn limit, bit 1 of 33.01 Counter status is set to 1. The warning specified by 33.24 On-time 2 warn message is also given if enabled by 33.22 On-time 2 function.  The timer can be reset from the Drive composer PC tool, or from the control panel by keeping Reset depressed for over 3 seconds.	-		
	04294	967295 s	Actual present value of on-time timer 2.	-		
33.21	On-time	2 warn limit	Sets the warning limit for on-time timer 2.	0 s		
	04294	967295 s	Warning limit for on-time timer 2.	-		

No.	Name/Va	alue	Description	Def/FbEq16	
33.22	On-time	2 function	Configures on-time timer 2.	0000b	
		1=			
	Bit	Function			
	0	33.01) swit 10 seconds	When the limit is reached, the counter is reset. The counter status (bit 1 of ches to 1 for one second. The warning (if enabled) stays active for at least s. e: When the limit is reached, the counter status (bit 1 of 33.01) switches to ains so until 33.20 is reset. The warning (if enabled) also stays active until set.		
		1, and remains 33.20 is res			
	1				
	215	Reserved			
	0000b	0011b	On-time timer 2 configuration word.	1 = 1	
33.23	On-time	2 source	Selects the signal to be monitored by on-time timer 2.	False	
	False		Constant 0 (timer disabled).	0	
	True		Constant 1.	1	
	RO1		Bit 0 of 10.21 RO status (page 197).	2	
	Other [bi	<i>t</i> ]	Source selection (see <i>Terms and abbreviations</i> on page 156).	-	
33.24	On-time 2 warn message		Selects the optional warning message for on-time timer 2.	On-time 2 exceeded	
	On-time 2 exceeded		A887 On-time 2. The message text can be edited on the control panel by choosing <b>Menu</b> – <b>Settings</b> – <b>Edit texts</b> .	1	
	Clean de	vice	A88C Device clean.	6	
	Maintain cool fan	additional	A890 Additional cooling.	7	
	Maintain	cabinet fan	A88E Cabinet fan.	8	
	Maintain capacitor		A88D DC capacitor.	9	
	Maintain bearing	motor	A880 Motor bearing.	10	
33.30	Edge cou actual	unter 1	Actual present value of signal edge counter 1.  The counter is incremented every time the signal selected by parameter 33.33 Edge counter 1 source switches on or off (or either, depending on the setting of 33.32 Edge counter 1 function). A divisor may be applied to the count (see 33.34 Edge counter 1 divider).  When the counter exceeds the limit set by 33.31 Edge counter 1 warn limit, bit 2 of 33.01 Counter status is set to 1. The warning specified by 33.35 Edge counter 1 warn message is also given if enabled by 33.32 Edge counter 1 function.  The counter can be reset from the Drive composer PC tool, or from the control panel by keeping Reset depressed for over 3 seconds.	-	
	04294	967295	Actual present value of signal edge counter 1.	-	

No.	Name/Va	alue	Description	Def/FbEq16				
33.31	Edge co		Sets the warning limit for signal edge counter 1.	0				
	04294	967295	Warning limit for signal edge counter 1.	-				
33.32	Edge counter 1 function		Configures signal edge counter 1.	0000b				
	Bit	Function						
	0	0 = Loop: V 33.01) swite warning (if 1 = Saturat	counter mode  = Loop: When the limit is reached, the counter is reset. The counter status (bit 2 of 0.01) switches to 1 and remains so until the counter is again incremented. The arning (if enabled) stays active for at least 10 seconds.  = Saturate: When the limit is reached, the counter status (bit 2 of 33.01) switches to and remains so until 33.30 is reset. The warning (if enabled) also stays active until					
	1							
	2	0 = Disable	unt rising edges Disable: Rising edges are not counted Enable: Rising edges are counted					
	3	0 = Disable	falling edges sable: Falling edges are not counted able: Falling edges are counted					
	415 Reserved							
	0000b	1111b	Edge counter 1 configuration word.	1 = 1				
33.33	Edge co	unter 1	Selects the signal to be monitored by signal edge counter 1.	False				
	False		Constant 0.	0				
	True		Constant 1.	1				
	RO1		Bit 0 of 10.21 RO status (page 197).	2				
	Other [bit]		Source selection (see <i>Terms and abbreviations</i> on page 156).	-				
33.34	Edge co	unter 1	Defines a divisor for signal edge counter 1. Determines how many signal edges increment the counter by 1.	1				
	14294	967295	Divisor for signal edge counter 1.	-				
33.35	Edge co		Selects the optional warning message for signal edge counter 1.	Edge counter 1 exceeded				
	Edge cor exceede		A888 Edge counter 1. The message text can be edited on the control panel by choosing <b>Menu</b> – <b>Settings</b> – <b>Edit texts</b> .	2				
	Counted contacto		A884 Main contactor.	11				
	Counted relay	output	A881 Output relay.	12				
	Counted starts	motor	A882 Motor starts.	13				
	Counted	power ups	A883 Power ups.	14				
	Counted charges	DC	A885 DC charge.	15				

No.	Name/V	aiue	Description	Def/FbEq16	
33.40	Edge counter 2 actual		Displays the actual present value of signal edge counter 2. The counter is incremented every time the signal selected by parameter 33.43 Edge counter 2 source switches on or off (or either, depending on the setting of 33.42 Edge counter 2 function). A divisor may be applied to the count (see 33.44 Edge counter 2 divider). When the counter exceeds the limit set by 33.41 Edge counter 2 warn limit, bit 3 of 33.01 Counter status is set to 1. The warning specified by 33.45 Edge counter 2 warn message is also given if enabled by 33.42 Edge counter 2 function.  The counter can be reset from the Drive composer PC tool, or from the control panel by keeping Reset depressed for over 3 seconds.	-	
	04294	1967295	Actual present value of signal edge counter 2.	-	
33.41	Edge co warn lim		Sets the warning limit for signal edge counter 2.	0	
	04294	1967295	Warning limit for signal edge counter 2.	-	
33.42	Edge co function		Configures signal edge counter 2.	0000b	
	Bit	Function			
	1	0 = Loop: When the limit is reached, the counter is reset. The counter st 33.01) remains 1 until the counter is again incremented. The warning (if a active for at least 10 seconds.  1 = Saturate: After the limit is reached, the counter status (bit 3 of 33.01 until 33.40 is reset. The warning (if enabled) also stays active until 33.40  Warning enable 0 = Disable: No warning is given when the limit is reached			
	2	0 = Disable: Rising edges are not counted			
		0 = Disable			
	3	0 = Disable 1 = Enable Count fallin 0 = Disable 1 = Enable	: Rising edges are counted		
	3 415	0 = Disable 1 = Enable Count fallin 0 = Disable	: Rising edges are counted g edges :: Falling edges are not counted		
		0 = Disable 1 = Enable Count fallin 0 = Disable 1 = Enable Reserved	: Rising edges are counted g edges :: Falling edges are not counted	1 = 1	
33.43	415	0 = Disable 1 = Enable Count fallin 0 = Disable 1 = Enable Reserved	Rising edges are counted g edges Falling edges are not counted Falling edges are counted	1 = 1  False	
33.43	415 0000b Edge co	0 = Disable 1 = Enable Count fallin 0 = Disable 1 = Enable Reserved	Rising edges are counted g edges Falling edges are not counted Falling edges are counted Falling edges are counted  Edge counter 2 configuration word.		
33.43	415  0000b  Edge cosource	0 = Disable 1 = Enable Count fallin 0 = Disable 1 = Enable Reserved	Exising edges are counted g edges Example Example Edges are not counted Edge counter 2 configuration word.  Selects the signal to be monitored by signal edge counter 2.	False	
33.43	415  0000b  Edge cosource False	0 = Disable 1 = Enable Count fallin 0 = Disable 1 = Enable Reserved	E Rising edges are counted g edges E Falling edges are not counted Falling edges are counted  Edge counter 2 configuration word.  Selects the signal to be monitored by signal edge counter 2.  0.	False	
33.43	415  0000b  Edge cosource  False  True	0 = Disable 1 = Enable Count fallin 0 = Disable 1 = Enable Reserved	Exising edges are counted g edges Existing edges are not counted Existing edges are counted  Edge counter 2 configuration word.  Selects the signal to be monitored by signal edge counter 2.  0. 1.	False 0 1	
33.43	415  0000b  Edge cosource  False  True  RO1	0 = Disable 1 = Enable Count fallin 0 = Disable 1 = Enable Reserved	Exising edges are counted  g edges Falling edges are not counted Falling edges are counted  Edge counter 2 configuration word.  Selects the signal to be monitored by signal edge counter 2.  0.  1.  Bit 0 of 10.21 RO status (page 197).  Source selection (see Terms and abbreviations on	False 0 1	

No.	Name/Value	Description	Def/FbEq16
33.45	Edge counter 2 warn message	Selects the optional warning message for signal edge counter 2.	Edge counter 2 exceeded
	Edge counter 2 exceeded	A889 Edge counter 2. The message text can be edited on the control panel by choosing Menu – Settings – Edit texts.	3
	Counted main contactor	A884 Main contactor.	11
	Counted output relay	A881 Output relay.	12
	Counted motor starts	A882 Motor starts.	13
	Counted power ups	A883 Power ups.	14
	Counted DC charges	A885 DC charge.	15
33.50	Value counter 1 actual	Displays the actual present value of value counter 1.  The value of the source selected by parameter 33.53 Value counter 1 source is read at one-second intervals and added to the counter. A divisor can be applied to the count (see 33.54 Value counter 1 divider).  When the counter exceeds the limit set by 33.51 Value counter 1 warn limit, bit 4 of 33.01 Counter status is set to 1. The warning specified by 33.55 Value counter 1 warn message is also given if enabled by 33.52 Value counter 1 function.  The counter can be reset from the Drive composer PC tool, or from the control panel by keeping Reset depressed for over 3 seconds.	-
	-2147483008 2147483008	Actual present value of value counter 1.	-
33.51	Value counter 1 warn limit	Sets the limit for value counter 1.  With a positive limit, bit 4 of 33.01 Counter status is set to 1 (and a warning optionally generated) when the counter is equal or greater than the limit.  With a negative limit, bit 4 of 33.01 Counter status is set to 1 (and a warning optionally generated) when the counter is equal or smaller than the limit.  0 = Counter disabled.	0
	-2147483008 2147483008	Limit for value counter 1.	-

No.	Name/Va	alue	Description	Def/FbEq16		
33.52	Value co function	unter 1	Configures value counter 1.	0000b		
	Bit	Function				
	Counter mode 0 = Loop: When the limit is reached, the counter is reset. The counter status (bit 33.01) switches to 1 for one second. The warning (if enabled) stays active for at 10 seconds. 1 = Saturate: When the limit is reached, the counter status (bit 4 of 33.01) switch 1, and remains so until 33.50 is reset. The warning (if enabled) also stays active 33.50 is reset.					
	1					
	215	Reserved				
	0000b	0011b	Value counter 1 configuration word.	1 = 1		
33.53	Value co source	unter 1	Selects the signal to be monitored by value counter 1.	Not selected		
	Not selec	cted	None (counter disabled).	0		
	Motor sp	eed	01.01 Motor speed used (see page 160).	1		
	Other		Source selection (see <i>Terms and abbreviations</i> on page 156).	-		
33.54	Value co divider	unter 1	Defines a divisor for value counter 1. The value of the monitored signal is divided by this value before integration.	1.000		
	0.001 2147483		Divisor for value counter 1.	-		
33.55	Value co warn me		Selects the optional warning message for value counter 1.	Value counter 1 exceeded		
	Value co exceede		A88A Value counter 1. The message text can be edited on the control panel by choosing Menu – Settings – Edit texts.	4		
	Maintain bearing	motor	A880 Motor bearing.	10		
33.60	Value co actual	unter 2	Displays the actual present value of value counter 2.  The value of the source selected by parameter 33.63 Value counter 2 source is read at one-second intervals and added to the counter. A divisor can be applied to the count (see 33.64 Value counter 2 divider).  When the counter exceeds the limit set by 33.61 Value	-		
			counter 2 warn limit, bit 5 of 33.01 Counter status is set to 1. The warning specified by 33.65 Value counter 2 warn message is also given if enabled by 33.62 Value counter 2 function.  The counter can be reset from the Drive composer PC tool, or from the control panel by keeping Reset depressed for over 3 seconds.			
	-2147483 2147483		Actual present value of value counter 2.	-		

No.	Name/Va	alue	Description	Def/FbEq16		
33.61	Value counter 2 warn limit		Sets the limit for value counter 2. With a positive limit, bit 5 of 33.01 Counter status is set to 1 (and a warning optionally generated) when the counter is equal or greater than the limit. With a negative limit, bit 5 of 33.01 Counter status is set to 1 (and a warning optionally generated) when the counter is equal or smaller than the limit. 0 = Counter disabled.	0		
	-214748 2147483		Limit for value counter 2.	-		
33.62	Value co function	ounter 2	Configures value counter 2.	0000b		
	Bit	Function				
	0	33.01) swit 10 seconds 1 = Saturat	When the limit is reached, the counter is reset. The counter status (bit 5 of ches to 1 for one second. The warning (if enabled) stays active for at least is. e: When the limit is reached, the counter status (bit 5 of 33.01) switches to ains so until 33.60 is reset. The warning (if enabled) also stays active until			
	1	Warning enable 0 = Disable: No warning is given when the limit is reached 1 = Enable: A warning (see 33.65) is given when the limit is reached				
	215 Reserved					
	0000b	0011b	Value counter 2 configuration word.	1 = 1		
33.63	Value counter 2 source		Selects the signal to be monitored by value counter 2.	Not selected		
	Not selected		None (counter disabled).	0		
	Motor sp	eed	01.01 Motor speed used (see page 160).	1		
	Other		Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-		
33.64	Value co divider	ounter 2	Defines a divisor for value counter 2. The value of the monitored signal is divided by this value before integration.	1.000		
	0.001 2147483.000		Divisor for value counter 2.	-		
33.65	Value co warn me		Selects the optional warning message for value counter 2.	Value counter 2 exceeded		
	Value co exceede		A88B Value counter 2. The message text can be edited on the control panel by choosing Menu – Settings – Edit texts.	5		
	Maintain bearing	motor	A880 Motor bearing.	10		

No.	Name/	Value	Description		Def/FbEq16
35 Motor thermal protection		measuremer fan control c	al protection settings such as temperature nt configuration, load curve definition and motor onfiguration.  ction <i>Motor thermal protection</i> (page <i>122</i> ).		
35.01	Motor e temper	estimated rature	motor therma 35.5035.5 selection	motor temperature as estimated by the internal al protection model (see parameters 5). The unit is selected by parameter 96.16 Unit ter is read-only.	-
	-60	1000 °C or °F	Estimated m	otor temperature.	1 = 1°
35.02	Measu temper	red ature 1	defined by pois selected boote: With a	temperature received through the source arameter 35.11 Temperature 1 source. The unit y parameter 96.16 Unit selection.  a PTC sensor, the unit is ohms. ter is read-only.	-
	-60 -761 0 ohm [35.12]	or	Measured te	mperature 1.	1 = 1 unit
35.03			Displays the temperature received through the source defined by parameter 35.21 Temperature 2 source. The unit is selected by parameter 96.16 Unit selection.  Note: With a PTC sensor, the unit is ohms.  This parameter is read-only.		
			Measured te	mperature 2.	1 = 1 unit
35.04	FPTC	status word	protection m e.g. external <b>Note:</b> The "r whether the the "fault act the module i parameter 3.	status of optional FPTC-xx thermistor odules. The word can be used as the source of events.  nodule found" bits are updated regardless of corresponding module is activated. However, ive" and "warning active" bits are not updated if s not activated. Modules are activated by 5.30 FPTC configuration word. ter is read-only.	-
	Bit	Name		Description	
	0	Module fou	nd in slot 1	1 = Yes: An FPTC-xx module has been detecte	d in slot 1.
	1	Fault active	in slot 1	1 = Yes: The module in slot 1 has an active fau	lt.
	2	Warning ac	tive in slot 1	1 = Yes: The module in slot 1 has an active wa	ning.
	3	Module fou	nd in slot 2	1 = Yes: An FPTC-xx module has been detecte	
	4	Fault active	in slot 2	1 = Yes: The module in slot 2 has an active fau	lt.
	5	Warning active in slot 2		1 = Yes: The module in slot 2 has an active warning.	
	6	Module fou	nd in slot 3		
	7	Fault active	in slot 3	1 = Yes: The module in slot 3 has an active fau	lt.
	8	Warning ac	tive in slot 3	1 = Yes: The module in slot 3 has an active wa	ning.
	915	Reserved		•	

No.	Name/Value	Description	Def/FbEq16
35.05	Motor overload level	Displays the motor overload level as a percent of the motor overload fault limit. See parameter 35.56 Motor overload action and section Motor overload protection (page 125).	-
	0.0 300.0%	Motor overload level. 0.0% No motor overloading 88.0% Motor overloaded to warning level 100.0% Motor overloaded to fault level	10 = 1%
35.11	Temperature 1 source	Selects the source from which measured temperature 1 is read.  Usually this source is from a sensor connected to the motor controlled by the drive, but it could be used to measure and monitor a temperature from other parts of the process as long as a suitable sensor is used as per the selection list.	Disabled
	Disabled	None. Temperature monitoring function 1 is disabled.	0
	Estimated temperature	Estimated motor temperature (see parameter 35.01 Motor estimated temperature).  The temperature is estimated from an internal drive calculation. It is important to set up the ambient temperature of the motor in 35.50 Motor ambient temperature.	1
	KTY84 analog I/O	<ul> <li>KTY84 sensor connected to the analog input selected by parameter 35.14 Temperature 1 AI source and an analog output. The analog input can be from the standard I/O or from an extension module.</li> <li>The following settings are required:</li> <li>Set the hardware jumper or switch related to the analog input to U (voltage). Any change must be validated by a control unit reboot.</li> <li>Set the unit selection parameter of the input to volt.</li> <li>Set the source selection parameter of the analog output to "Force KTY84 excitation".</li> <li>Select the analog input in parameter 35.14. In case the input is located on an I/O extension module, use the selection Other to point at the actual input value parameter (for example, 14.26 AI1 actual value).</li> <li>The analog output feeds a constant current through the sensor. As the resistance of the sensor increases along with its temperature, the voltage over the sensor increases. The voltage is read by the analog input and converted into degrees.</li> </ul>	2
	KTY84 encoder module 1	KTY84 sensor connected to encoder interface 1. See also parameters 91.21 Module 1 temp sensor type and 91.22 Module 1 temp filter time.	3
	KTY84 encoder module 2	KTY84 sensor connected to encoder interface 2. See also parameters 91.24 Module 2 temp sensor type and 91.25 Module 2 temp filter time.	4
	1 x Pt100 analog I/O	Pt100 sensor connected to a standard analog input selected by parameter 35.14 Temperature 1 Al source and an analog output. The input and output can be on the drive control unit or on an extension module.  The required settings are the same as with selection KTY84 analog I/O, except that the source selection parameter of the analog output must be set to Force PT100 excitation.	5
	2 x Pt100 analog I/O	As selection 1 x Pt100 analog I/O, but with two sensors connected in series. Using multiple sensors improves measurement accuracy significantly.	6

No.	Name/Value	Description	Def/FbEq16
	3 x Pt100 analog I/O	As selection 1 x Pt100 analog I/O, but with three sensors connected in series. Using multiple sensors improves measurement accuracy significantly.	7
	PTC DI6	PTC sensor connected to digital input DI6 (see the connection diagram on page 122).  Note: Either 0 ohm (normal temperature) or 4000 ohm (excessive temperature) will be shown by 35.02 Measured temperature 1.	8
	PTC encoder module 1	PTC sensor connected to encoder interface 1. See also parameters 91.21 Module 1 temp sensor type and 91.22 Module 1 temp filter time.	9
	PTC encoder module 2	PTC sensor connected to encoder interface 2. See also parameters 91.24 Module 2 temp sensor type and 91.25 Module 2 temp filter time.	10
	Direct temperature	The temperature is taken from the source selected by parameter 35.14 Temperature 1 Al source. The value of the source is assumed to be in the unit of temperature specified by 96.16 Unit selection.	11
	1 × Pt1000 analog I/O	Pt1000 sensor connected to a standard analog input selected by parameter 35.14 Temperature 1 Al source and an analog output. The input and output can be on the drive control unit or on an extension module.  The required settings are the same as with selection KTY84 analog I/O, except that the source selection parameter of the analog output must be set to Force PT100 excitation.	13
	2 × Pt1000 analog I/O	As selection 1 × Pt1000 analog I/O, but with two sensors connected in series. Using multiple sensors improves measurement accuracy significantly.	14
	3 × Pt1000 analog I/O	As selection 1 × Pt1000 analog I/O, but with three sensors connected in series. Using multiple sensors improves measurement accuracy significantly.	15
	PTC analog I/O	PTC sensor connected to a standard analog input selected by parameter 35.14 Temperature 1 AI source and an analog output. The input and output can be on the drive control unit or on an extension module.  The required settings are the same as with selection KTY84 analog I/O, except that the source selection parameter of the analog output must be set to Force PTC excitation.  Note: Either 0 ohm (normal temperature) or 4000 ohm (excessive temperature) will be shown by 35.02 Measured temperature 1.	20
35.12	Temperature 1 fault limit	Defines the fault limit for temperature monitoring function 1. When measured temperature 1 exceeds the limit, the drive trips on fault 4981 External temperature 1. The unit is selected by parameter 96.16 Unit selection.  Note: With a PTC sensor, the unit is ohms.	130 °C or 266 °F
	-60 1000 °C or ohm, or -761832 °F	Fault limit for temperature monitoring function 1.	1 = 1 unit

No.	Name/Value	Description	Def/FbEq16
35.13	Temperature 1 warning limit	Defines the warning limit for temperature monitoring function 1. When measured temperature 1 exceeds this limit, a warning (A491 External temperature 1) is generated. The unit is selected by parameter 96.16 Unit selection.  Note: With a PTC sensor, the unit is ohms.	110 °C or 230 °F
	-60 5000 °C or ohm, or -769032 °F	Warning limit for temperature monitoring function 1.	1 = 1 unit
35.14	Temperature 1 AI source	Specifies the analog input when the setting of 35.11  Temperature 1 source requires measurement through an analog input.  Note: If the input is located on an I/O extension module, use the selection Other to point to the AI actual value in group 14, 15 or 16, e.g. 14.26 AI1 actual value.	Not selected
	Not selected	None.	0
	Al1 actual value	Analog input Al1 on the control unit.	1
	Al2 actual value	Analog input Al2 on the control unit.	2
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
35.21	Temperature 2 source	Selects the source from which measured temperature 2 is read.  For wiring examples, see the hardware manual of the drive. Usually this source is from a sensor connected to the motor controlled by the drive, but it could be used to measure and monitor a temperature from other parts of the process as long as a suitable sensor is used as per the selection list.	Disabled
	Disabled	None. Temperature monitoring function 2 is disabled.	0
	Estimated temperature	Estimated motor temperature (see parameter 35.01 Motor estimated temperature).  The temperature is estimated from an internal drive calculation. It is important to set up the ambient temperature of the motor in 35.50 Motor ambient temperature.	1
	KTY84 analog I/O	<ul> <li>KTY84 sensor connected to the analog input selected by parameter 35.24 Temperature 2 AI source and an analog output. The input and output can be on the drive control unit or on an extension module.</li> <li>The following settings are required:</li> <li>Set the hardware jumper or switch related to the analog input to U (voltage). Any change must be validated by a control unit reboot.</li> <li>Set the unit selection parameter of the input to volt.</li> <li>Set the source selection parameter of the analog output to "Force KTY84 excitation".</li> <li>Select the analog input in parameter 35.24. In case the input is located on an I/O extension module, use the selection Other to point at the actual input value parameter (for example, 14.26 AI1 actual value).</li> <li>The analog output feeds a constant current through the sensor. As the resistance of the sensor increases along with its temperature, the voltage over the sensor increases. The voltage is read by the analog input and converted into degrees.</li> </ul>	2

No.	Name/Value	Description	Def/FbEq16
	KTY84 encoder module 1	KTY84 sensor connected to encoder interface 1. See also parameters 91.21 Module 1 temp sensor type and 91.22 Module 1 temp filter time.	3
	KTY84 encoder module 2	KTY84 sensor connected to encoder interface 2. See also parameters 91.24 Module 2 temp sensor type and 91.25 Module 2 temp filter time.	4
	1 x Pt100 analog I/O	Pt100 sensor connected to a standard analog input selected by parameter 35.24 Temperature 2 Al source and an analog output. The input and output can be on the drive control unit or on an extension module.  The required settings are the same as with selection KTY84 analog I/O, except that the source selection parameter of the analog output must be set to Force PT100 excitation.	5
	2 x Pt100 analog I/O	As selection 1 x Pt100 analog I/O, but with two sensors connected in series. Using multiple sensors improves measurement accuracy significantly.	6
	3 x Pt100 analog I/O	As selection 1 x Pt100 analog I/O, but with three sensors connected in series. Using multiple sensors improves measurement accuracy significantly.	7
	PTC DI6	PTC sensor connected to digital input DI6 (see the connection diagram on page 122).  Note: Either 0 ohm (normal temperature) or 4000 ohm (excessive temperature) will be shown by 35.03 Measured temperature 2.	8
	PTC encoder module 1	PTC sensor connected to encoder interface 1. See also parameters 91.21 Module 1 temp sensor type and 91.22 Module 1 temp filter time.	9
	PTC encoder module 2	PTC sensor connected to encoder interface 2. See also parameters 91.24 Module 2 temp sensor type and 91.25 Module 2 temp filter time.	10
	Direct temperature	The temperature is taken from the source selected by parameter 35.24 Temperature 2 Al source. The value of the source is assumed to be in the unit of temperature specified by 96.16 Unit selection.	11
	1 × Pt1000 analog I/O	Pt1000 sensor connected to a standard analog input selected by parameter 35.24 Temperature 2 AI source and an analog output. The input and output can be on the drive control unit or on an extension module.  The required settings are the same as with selection KTY84 analog I/O, except that the source selection parameter of the analog output must be set to Force PT100 excitation.	13
	2 × Pt1000 analog I/O	As selection 1 × Pt1000 analog I/O, but with two sensors connected in series. Using multiple sensors improves measurement accuracy significantly.	14
	3 × Pt1000 analog I/O	As selection 1 × Pt1000 analog I/O, but with three sensors connected in series. Using multiple sensors improves measurement accuracy significantly.	15

No.	Name/Va	alue	Description		Def/FbEq16
	PTC ana	alog I/O	by parameter output. The ir	connected to a standard analog input selected 35.24 Temperature 2 Al source and an analog input and output can be on the drive control unit insion module.	20
			analog I/O, ex analog outpu <b>Note:</b> Either	settings are the same as with selection KTY84 scept that the source selection parameter of the t must be set to Force PTC excitation.  O ohm (normal temperature) or 4000 ohm imperature) will be shown by 35.03 Measured 2.	
35.22	Tempera limit	ature 2 fault	When measu trips on fault The unit is se	ault limit for temperature monitoring function 2. Ired temperature 2 exceeds the limit, the drive 4982 External temperature 2. Elected by parameter 96.16 Unit selection.  PTC sensor, the unit is ohms.	130 °C or 266 °F
	-60 10 -76183	000 °C or 32 °F	Fault limit for	temperature monitoring function 2.	1 = 1 unit
35.23	Tempera warning		function 2. W a warning (A The unit is se	Defines the warning limit for temperature monitoring function 2. When measured temperature 2 exceeds the limit, a warning (A492 External temperature 2) is generated.  The unit is selected by parameter 96.16 Unit selection.	
			Note: With a		
		-60 5000 °C or -769032 °F		for temperature monitoring function 2.	1 = 1 unit
35.24	Tempera source	ature 2 AI	selections K7	put for parameter 35.21 Temperature 2 source, FY84 analog I/O, 1 x Pt100 analog I/O, 2 x I/O, 3 x Pt100 analog I/O and Direct	Not selected
	Not sele	Not selected None.			0
	Al1 actu	al value	Analog input Al1 on the control unit.  Analog input Al2 on the control unit.  Source selection (see <i>Terms and abbreviations</i> on page 156).		1
	Al2 actu	al value			2
	Other				-
35.30	5.30 FPTC configuration word		on the contro	TC-xx thermistor protection modules installed I unit of the drive. Using this word, it is also uppress the warnings (but not faults) from each	0000 0000b
	Bit	Name		Description	
	0	Module in s	lot 1	1 = Yes: Module installed in slot 1.	
	1	Disable slo	t 1 warning	1 = Yes: Warnings from the module in slot 1 su	ppressed.
	2	Module in s	lot 2	1 = Yes: Module installed in slot 2.	
	3	Disable slo	2 warning	1 = Yes: Warnings from the module in slot 2 su	ppressed.
	4	Module in s	lot 3	1 = Yes: Module installed in slot 3.	
	5	Disable slo	3 warning	1 = Yes: Warnings from the module in slot 3 su	ppressed.
	615	Reserved			
	0000 0000b 0011 1111b		FPTC-xx mod	dule configuration word.	1 = 1

No.	Name/Value	Description	Def/FbEq16
35.50	Motor ambient temperature	Defines the ambient temperature of the motor for the motor thermal protection model. The unit is selected by parameter 96.16 Unit selection.  The motor thermal protection model estimates the motor temperature on the basis of parameters 35.5035.55. The motor temperature increases if it operates in the region above the load curve, and decreases if it operates in the region below the load curve.  WARNING! The model cannot protect the motor if the motor does not cool properly because of dust, dirt, etc.	20 °C or 68 °F
	-60 100 °C or -75 212 °F	Ambient temperature.	1 = 1°
35.51	Motor load curve	Defines the motor load curve together with parameters 35.52 Zero speed load and 35.53 Break point. The load curve is used by the motor thermal protection model to estimate the motor temperature.  When the parameter is set to 100%, the maximum load is taken as the value of parameter 99.06 Motor nominal current (higher loads heat up the motor). The load curve level should be adjusted if the ambient temperature differs from the nominal value set in 35.50 Motor ambient temperature.	70%
	//I <sub>N</sub> (%) ^	<ul><li>I = Motor current</li><li>I<sub>N</sub> = Nominal motor current</li></ul>	
	150 —		
	100	35.51	
	50 – 35.52	35.53 Drive outp	out
		frequency	
	25 150%	Maximum load for the motor load curve.	1 = 1%
35.52	Zero speed load	Defines the motor load curve together with parameters 35.51 Motor load curve and 35.53 Break point. Defines the maximum motor load at zero speed of the load curve. A higher value can be used if the motor has an external motor fan to boost the cooling. See the motor manufacturer's recommendations.  See parameter 35.51 Motor load curve.	100%
	50 150%	Zero speed load for the motor load curve.	1 = 1%

No.	Name/Value	Description	Def/FbEq16
35.53	Break point	Defines the motor load curve together with parameters 35.51 Motor load curve and 35.52 Zero speed load. Defines the break point frequency of the load curve i.e. the point at which the motor load curve begins to decrease from the value of parameter 35.51 Motor load curve towards the value of parameter 35.52 Zero speed load.  See parameter 35.51 Motor load curve.	45.00 Hz
	1.00 500.00 Hz	Break point for the motor load curve.	See par. 46.02
35.54	Motor nominal temperature rise  Motor nom temperature	Ambient temperature	80 °C or 176 °F
	0300 °C or 32572 °F	Temperature rise.	1 = 1°

No.	Name/Value	Description	Def/FbEq16
35.55	Motor thermal time constant	Defines the thermal time constant for use with the motor thermal protection model, defined as the time to reach 63% of the nominal motor temperature. See the motor manufacturer's recommendations.	256 s
		Motor current	
		100% - Time	
	lei	100%	
	100 10000 s	Motor thermal time constant.	1 = 1 s
35.56	Motor overload action	Selects the action taken when motor overload is detected. See section <i>Motor overload protection</i> (page 125).	No action
	No action	No action taken	0
	Warning only	Drive generates warning A783 Motor overload when the motor is overloaded to the warning level, that is, parameter 35.05 Motor overload level reaches value 88.0%.	1
	Warning and fault	Drive generates warning A783 Motor overload when the motor is overloaded to the warning level, that is, parameter 35.05 Motor overload level reaches value 88.0%.  Drive trips on fault 7122 Motor overload when the motor is overloaded to the fault level, that is, parameter 35.05 Motor overload level reaches value 100.0%.	2
35.57	Motor overload class	Defines the motor overload class to be used. The class of protection is specified by the user as the time for tripping at 7.2 times (IEC 60947-4-1) or 6 times (NEMA ICS) the tripping level current.  See section <i>Motor overload protection</i> (page 125).	Class 20
	Class 5	Motor overload class 5.	0
	Class 10	Motor overload class 10.	1
	Class 20	Motor overload class 20.	2
	Class 30	Motor overload class 30.	3
	Class 40	Motor overload class 40.	4

No.	Name/Value	Description	Def/FbEq16
35.60	Cable temperature	Shows the calculated temperature of the motor cable. See section <i>Thermal protection of motor cable</i> (page 126). 102% = overtemperature warning (A480 Motor cable overload) 106% = overtemperature fault (4000 Motor cable overload) This parameter is read-only.	0.0%
	0.0 200.0%	Calculated temperature of motor cable.	1 = 1%
35.61	Cable nominal current	Specifies the continuous current of the motor cable for the thermal protection function in the control program.  WARNING! The value entered in this parameter must be limited according to all factors affecting the loadability of the cable, such as ambient temperature, cabling arrangement, and shrouding. Refer to the technical data from the cable manufacturer.	10000.00 A
	0.00 10000.00 A	Continuous current-carrying capacity of motor cable.	1 = 1 A
35.62	Cable thermal rise time	Specifies the thermal time of the motor cable for the thermal protection function in the control program. This value is defined as the time to reach 63% of the nominal cable temperature when the cable is loaded with nominal current (parameter 35.61 Cable nominal current).  O s = Thermal protection of motor cable disabled Refer to the technical data from the cable manufacturer.  Cable current	1 s
		Temperature rise  100%	
	0 s	Thermal protection of motor cable disabled.	1 = 1 s
	150000 s	Motor cable thermal time constant.	1 = 1 s
	150000 5 Wotor cable thermal time constant.		

No.	Name/Value	Description	Def/FbEq16
35.100	DOL starter control source	Parameters 35.10035.106 configure a monitored start/stop control logic for external equipment such as a contactor-controlled motor cooling fan.  This parameter selects the signal that starts and stops the fan.  0 = Stop  1 = Start  The output controlling the fan contactor is to be connected to parameter 35.105, bit 1. On and off delays can be set for the fan by 35.101 and 35.102 respectively. A feedback signal from the fan can be connected to an input selected by 35.103; the loss of the feedback will optionally trigger a warning or fault (see 35.104 and 35.106).	Off, 06.16 b6 (95.20 b6)
	Off	0 (function disabled).	0
	On	1.	1
	Running	Bit 6 of 06.16 Drive status word 1 (see page 175).	2
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
35.101	DOL starter on delay	Defines a start delay for the motor fan. The delay timer starts when the control source selected by parameter 35.100 switches on. After the delay, bit 1 of 35.105 switches on.	0 s
	042949673 s	Motor fan start delay.	1 = 1 s
35.102	DOL starter off delay	Defines a stop delay for the motor fan. The delay timer starts when the control source selected by parameter 35.100 switches off. After the delay, bit 1 of 35.105 switches off.	20 min
	0715828 min	Motor fan stop delay.	1 = 1 min
35.103	DOL starter feedback source	Selects the input for motor fan feedback signal.  0 = Stopped  1 = Running  After the fan is started (bit 1 of 35.105 switches on), feedback is expected within the time set by 35.104.	Not selected; DI5 (95.20 b6)
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 156).	-

Zero

Motor speed used

No.	Name/Va	alue	Desc	cription	Def/FbEq16	
35.104	DOL starter feedback delay		The offeeds action Note signs	nes a feedback delay for the motor fan. delay timer starts when bit 1 of 35.105 switches on. If no back is received from the fan until the delay elapses, the n selected by 35.106 is taken. This delay is only applied at start. If the feedback all is lost during run, the action selected by 35.106 is n immediately.	0 s; 5 s (95.20 b6)	
	04294	9673 s	Moto	r fan start delay.	1 = 1 s	
35.105	DOL starter status word		Bit 1 source The cand f	is of the motor fan control logic. is the control output for the fan, to be selected as the ce of, for example, a digital or relay output. other bits indicate the statuses of the selected control feedback sources, and the fault status. parameter is read-only.	-	
	Bit	Name		Description		
	0	Start comm	and	Status of fan control source selected by 35.100.  0 = Stop requested  1 = Start requested		
	1	Delayed sta command	art	Fan control bit (delays observed). Select this bit as the soutput controlling the fan.  0 = Stopped 1 = Started	source of the	
	2 DOL feedba		ack			
	3	DOL fault (-	-1)	Fault status.  0 = Fault (fan feedback missing). The action taken is se 35.106.  1 = No fault	elected by	
	415	Reserved				
			<del>.</del>			
	0000b	1111b	Statu	is of motor fan control logic.	1 = 1	
35.106	DOL star	rter event		cts the action taken when missing fan feedback is cted by the motor fan control logic.	Fault	
	No action	n	No a	ction taken.	0	
	Warning		The	drive generates a warning ( <i>A781 Motor fan</i> ).	1	
	Fault		Drive	e trips on <i>71B1 Motor fan</i> .	2	
36 Loa	ad analyzer			value and amplitude logger settings. also section <i>Load analyzer</i> (page <i>131</i> ).		
36.01	PVL signal source		The sparanter of the paranter of the sparanter of the sparant	cts the signal to be monitored by the peak value logger. signal is filtered using the filtering time specified by meter 36.02 PVL filter time.  peak value is stored, along with other pre-selected als at the time, into parameters 36.1036.15.  peak value logger can be reset using parameter 36.09 at loggers. The date and time of the last reset are stored parameters 36.16 and 36.17 respectively.	Power inu out	

None (peak value logger disabled).

01.01 Motor speed used (page 160).

0

1

No.	Name/Value	Description	Def/FbEq16
	Output frequency	01.06 Output frequency (page 160).	3
	Motor current	01.07 Motor current (page 160).	4
	Motor torque	01.10 Motor torque (page 160).	6
	DC voltage	01.11 DC voltage (page 160).	7
	Power inu out	01.14 Output power (page 161).	8
	Speed ref ramp in	23.01 Speed ref ramp input (page 268).	10
	Speed ref ramped	23.02 Speed ref ramp output (page 268).	11
	Speed ref used	24.01 Used speed reference (page 274).	12
	Torq ref used	26.02 Torque reference used (page 290).	13
	Freq ref used	28.02 Frequency ref ramp output (page 298).	14
	Process PID out	40.01 Process PID output actual (page 355).	16
	Process PID fbk	40.02 Process PID feedback actual (page 355).	17
	Process PID act	40.03 Process PID setpoint actual (page 355).	18
	Process PID dev	40.04 Process PID deviation actual (page 356).	19
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
36.02	PVL filter time	Defines a filtering time for the peak value logger. See parameter 36.01 PVL signal source.	2.00 s
	0.00 120.00 s	Peak value logger filtering time.	100 = 1 s
36.06	AL2 signal source	Selects the signal to be monitored by amplitude logger 2. The signal is sampled at 200 ms intervals, and can be scaled using parameter 36.07 AL2 signal scaling.  The results are displayed by parameters 36.4036.49. Each parameter represents an amplitude range, and shows what portion of the samples fall within that range.  Amplitude logger 2 can be reset using parameter 36.09 Reset loggers. The logger is also reset whenever the signal source or scaling is changed. The date and time of the last reset are stored into parameters 36.50 and 36.51 respectively.	Ambient temperature
	Zero	None (amplitude logger 2 disabled).	0
	Motor speed used	01.01 Motor speed used (page 160).	1
	Output frequency	01.06 Output frequency (page 160).	3
	Motor current	01.07 Motor current (page 160).	4
	Motor torque	01.10 Motor torque (page 160).	6
	DC voltage	01.11 DC voltage (page 160).	7
	Power inu out	01.14 Output power (page 161).	8
	Speed ref ramp in	23.01 Speed ref ramp input (page 268).	10
	Speed ref ramped	23.02 Speed ref ramp output (page 268).	11
	Speed ref used	24.01 Used speed reference (page 274).	12
	Torq ref used	26.02 Torque reference used (page 290).	13
	Freq ref used	28.02 Frequency ref ramp output (page 298).	14
	Process PID out	40.01 Process PID output actual (page 355).	16
	Process PID fbk	40.02 Process PID feedback actual (page 355).	17
	Process PID act	40.03 Process PID setpoint actual (page 355).	18

No.	o. Name/Value		Desc	cription	Def/FbEq16
	Process PID dev		40.04 Process PID deviation actual (page 356).		19
	Ambient			O Ambient temperature (page 163).	20
	temperature			amplitude range of 0100% corresponds to 060 °C or 140 °F.	
	Other		Soure 156).	ce selection (see <i>Terms and abbreviations</i> on page	-
36.07	AL2 sig	nal scaling		es the signal value that corresponds to 100% itude.	100.00
	0.00	32767.00	Signa	al value corresponding to 100%.	1 = 1
36.08	Logger	function		rmines whether amplitude loggers 1 and 2 are active nuously or only when the drive is modulating.	-
	Bit	Name		Description	
	0	AL1		0 = Amplitude logger 1 active continuously 1 = Amplitude logger 1 active only when the drive is mo	dulating
	1	AL2		0 = Amplitude logger 2 active continuously 1 = Amplitude logger 2 active only when the drive is mo	dulating
	215 Reserved				
	0000b.	.0011b	Ampl	itude logger activity selection.	1 = 1
36.09	Reset loggers		Resets the peak value logger and/or amplitude logger 2. (Amplitude logger 1 cannot be reset.)		Done
	Done		Rese	et completed or not requested (normal operation).	0
	All		Rese	t both the peak value logger and amplitude logger 2.	1
	PVL		Rese	t the peak value logger.	2
	AL2		Rese	et amplitude logger 2.	3
36.10	PVL peak value		Displ	ays the peak value recorded by the peak value logger.	0.00
	-32768. 32767.0		Peak	value.	1 = 1
36.11	PVL pe	ak date	Displ	ays the date on which the peak value was recorded.	-
	-		Peak	occurrence date.	-
36.12	PVL pe	ak time	Displ	ays the time at which the peak value was recorded.	-
	-		Peak	occurrence time.	-
36.13	PVL current at peak			ays the motor current at the moment the peak value recorded.	0.00 A
	-32768. 32767.0		Moto	r current at peak.	1 = 1 A
36.14	PVL DO	voltage at		ays the voltage in the intermediate DC circuit of the at the moment the peak value was recorded.	0.00 V
	0.00	2000.00 V	DC v	oltage at peak.	10 = 1 V
36.15	PVL sp	eed at peak	Displ recor	ays the motor speed at the moment the peak value was ded.	0.00 rpm
	-32768. 32767.0		Moto	r speed at peak.	See par. 46.01
36.16	PVL res	set date	Displ reset	ays the date on which the peak value logger was last	-

No.	Name/Value	Description	Def/FbEq16
	-	Last reset date of the peak value logger.	-
36.17	PVL reset time	Displays the time at which the peak value logger was last reset.	-
	-	Last reset time of the peak value logger.	-
36.20	AL1 below 10%	Displays the percentage of samples recorded by amplitude logger 1 that were below 10%.  Note: This percentage also includes samples with negative value.	0.00%
	0.00 100.00%	Amplitude logger 1 sample below 10%.	1 = 1%
36.21	AL1 10 to 20%	Displays the percentage of samples recorded by amplitude logger 1 that fall between 10 and 20%.	0.00%
	0.00 100.00%	Amplitude logger 1 samples between 10 and 20%.	1 = 1%
36.22	AL1 20 to 30%	Displays the percentage of samples recorded by amplitude logger 1 that fall between 20 and 30%.	0.00%
	0.00 100.00%	Amplitude logger 1 samples between 20 and 30%.	1 = 1%
36.23	AL1 30 to 40%	Displays the percentage of samples recorded by amplitude logger 1 that fall between 30 and 40%.	0.00%
	0.00 100.00%	Amplitude logger 1 samples between 30 and 40%.	1 = 1%
36.24	AL1 40 to 50%	Displays the percentage of samples recorded by amplitude logger 1 that fall between 40 and 50%.	0.00%
	0.00 100.00%	Amplitude logger 1 samples between 40 and 50%.	1 = 1%
36.25	AL1 50 to 60%	Displays the percentage of samples recorded by amplitude logger 1 that fall between 50 and 60%.	0.00%
	0.00 100.00%	Amplitude logger 1 samples between 50 and 60%.	1 = 1%
36.26	AL1 60 to 70%	Displays the percentage of samples recorded by amplitude logger 1 that fall between 60 and 70%.	0.00%
	0.00 100.00%	Amplitude logger 1 samples between 60 and 70%.	1 = 1%
36.27	AL1 70 to 80%	Displays the percentage of samples recorded by amplitude logger 1 that fall between 70 and 80%.	0.00%
	0.00 100.00%	Amplitude logger 1 samples between 70 and 80%.	1 = 1%
36.28	AL1 80 to 90%	Displays the percentage of samples recorded by amplitude logger 1 that fall between 80 and 90%.	0.00%
	0.00 100.00%	Amplitude logger 1 samples between 80 and 90%.	1 = 1%
36.29	AL1 over 90%	Displays the percentage of samples recorded by amplitude logger 1 that exceed 90%.	0.00%
	0.00 100.00%	Amplitude logger 1 samples over 90%.	1 = 1%
36.40	AL2 below 10%	Displays the percentage of samples recorded by amplitude logger 2 that were below 10%.  Note: This percentage also includes samples with negative value.	0.00%
	0.00 100.00%	Amplitude logger 2 samples below 10%.	1 = 1%
36.41	AL2 10 to 20%	Displays the percentage of samples recorded by amplitude logger 2 that fall between 10 and 20%.	0.00%
	0.00 100.00%	Amplitude logger 2 samples between 10 and 20%.	1 = 1%
36.42	AL2 20 to 30%	Displays the percentage of samples recorded by amplitude logger 2 that fall between 20 and 30%.	0.00%
	0.00 100.00%	Amplitude logger 2 samples between 20 and 30%.	1 = 1%

No.	Name/Value	Description	Def/FbEq16	
36.43	AL2 30 to 40%	Displays the percentage of samples recorded by amplitude logger 2 that fall between 30 and 40%.	0.00%	
	0.00 100.00%	Amplitude logger 2 samples between 30 and 40%.	1 = 1%	
36.44	AL2 40 to 50%	Displays the percentage of samples recorded by amplitude logger 2 that fall between 40 and 50%.	0.00%	
	0.00 100.00%	Amplitude logger 2 samples between 40 and 50%.	1 = 1%	
36.45	AL2 50 to 60%	Displays the percentage of samples recorded by amplitude logger 2 that fall between 50 and 60%.	0.00%	
	0.00 100.00%	Amplitude logger 2 samples between 50 and 60%.	1 = 1%	
36.46	AL2 60 to 70%	Displays the percentage of samples recorded by amplitude logger 2 that fall between 60 and 70%.	0.00%	
	0.00 100.00%	Amplitude logger 2 samples between 60 and 70%.	1 = 1%	
36.47	AL2 70 to 80%	Displays the percentage of samples recorded by amplitude logger 2 that fall between 70 and 80%.	0.00%	
	0.00 100.00%	Amplitude logger 2 samples between 70 and 80%.	1 = 1%	
36.48	AL2 80 to 90%	Displays the percentage of samples recorded by amplitude logger 2 that fall between 80 and 90%.	0.00%	
	0.00 100.00%	Amplitude logger 2 samples between 80 and 90%.	1 = 1%	
36.49	AL2 over 90%	Displays the percentage of samples recorded by amplitude logger 2 that exceed 90%.	0.00%	
	0.00 100.00%	Amplitude logger 2 samples over 90%.	1 = 1%	
36.50	AL2 reset date	Displays the date on which amplitude logger 2 was last reset.	-	
	-	Last reset date of amplitude logger 2.	-	
36.51	AL2 reset time	Displays the time at which amplitude logger 2 was last reset.	-	
	-	Last reset time of amplitude logger 2.	-	
37 Us	er load curve	Settings for user load curve. See also section <i>User load curve</i> (page 126).		
37.01	ULC output status	Displays the status of the monitored signal. (The status word	-	

37 User load curve	Settings for user load curve. See also section <i>User load curve</i> (page <i>126</i> ).	
37.01 ULC output status word	Displays the status of the monitored signal. (The status word is independent of the actions and delays selected by parameters 37.03, 37.04, 37.41 and 37.42.) This parameter is read-only.	-

Bit	Name	Information
0	Under load limit	1 = Monitored signal is below the underload curve
1	Reserved	
2	Over load limit	1 = Monitored signal is above the overload curve
315	Reserved	

	000b 101b	Status of the monitored signal.	1 = 1
37.02 ULC supervision signal		Selects the signal to be monitored. The function compares the absolute value of the signal against the load curve.	Not selected
	Not selected	No signal selected (monitoring disabled).	0
	Motor current %	01.07 Motor current (see page 160).	2
	Motor torque %	01.10 Motor torque (see page 160).	3

No.	Name/Value	Description	Def/FbEq16
	Output power % of motor nominal	01.15 Output power % of motor nom (see page 161).	4
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
37.03	ULC overload actions	Selects how the drive reacts if the absolute value of the monitored signal stays above the overload curve for longer than the value of 37.41 ULC overload timer.	Disabled
	Disabled	No action taken.	0
	Warning	The drive generates a warning (A8BE ULC overload warning).	1
	Fault	Drive trips on 8002 ULC overload fault.	2
	Warning/Fault	The drive generates a warning (A8BE ULC overload warning) if the signal stays continuously above the overload curve for half of the time defined by 37.41 ULC overload timer.  The drive trips on 8002 ULC overload fault if the signal stays continuously above the overload curve for the time defined by 37.41 ULC overload timer.	3
37.04	ULC underload actions	Selects how the drive reacts if the absolute value of the monitored signal stays below the underload curve for longer than the value of 37.42 ULC underload timer.	Disabled
	Disabled	No action taken.	0
	Warning	The drive generates a warning (A8BF ULC underload warning).	1
	Fault	Drive trips on 8001 ULC underload fault.	2
	Warning/Fault	The drive generates a warning (A8BF ULC underload warning) if the signal stays continuously below the underload curve for half of the time defined by 37.42 ULC underload timer.  The drive trips on 8001 ULC underload fault if the signal stays continuously below the underload curve for the time defined by 37.42 ULC underload timer.	3
37.11	ULC speed table point 1	Defines the 1st speed point on the X-axis of the user load curve.  The speed points are used in DTC motor control mode, and in scalar motor control mode when speed control is being used.  The five points must be in order from lowest to highest. The points are defined as positive values, but the range is symmetrically effective also in the negative direction. The monitoring is not active outside these two areas.	150.0 rpm
	0.0 30000.0 rpm	Speed.	1 = 1 rpm
37.12	ULC speed table point 2	Defines the 2nd speed point on the X-axis of the user load curve.	750.0 rpm
	0.0 30000.0 rpm	Speed.	1 = 1 rpm
37.13	ULC speed table point 3	Defines the 3rd speed point on the X-axis of the user load curve.	1290.0 rpm
	0.0 30000.0 rpm	Speed.	1 = 1 rpm
37.14	ULC speed table point 4	Defines the 4th speed point on the X-axis of the user load curve.	1500.0 rpm
	0.0 30000.0 rpm	Speed.	1 = 1 rpm

No. Name/Value		me/Value Description	
37.15	ULC speed table point 5	Defines the 5th speed point on the X-axis of the user load curve.	1800.0 rpm
	0.0 30000.0 rpm	Speed.	1 = 1 rpm
37.16	ULC frequency table point 1	Defines the 1st frequency point on the X-axis of the user load curve.  The frequency points are used in scalar motor control mode when frequency control is being used.  The five points must be in order from lowest to highest. The points are defined as positive values, but the range is symmetrically effective also in the negative direction. The monitoring is not active outside these two areas.	5.0 Hz
	0.0 500.0 Hz	Frequency.	1 = 1 Hz
37.17	ULC frequency table point 2	Defines the 2nd frequency point on the X-axis of the user load curve.	25.0 Hz
	0.0 500.0 Hz	Frequency.	1 = 1 Hz
37.18	ULC frequency table point 3	Defines the 3rd frequency point on the X-axis of the user load curve.	43.0 Hz
	0.0 500.0 Hz	Frequency.	1 = 1 Hz
37.19	ULC frequency table point 4	Defines the 4th frequency point on the X-axis of the user load curve.	50.0 Hz
	0.0 500.0 Hz	Frequency.	1 = 1 Hz
37.20	ULC frequency table point 5	Defines the 5th frequency point on the X-axis of the user load curve.	60.0 Hz
	0.0 500.0 Hz	Frequency.	1 = 1 Hz
37.21	ULC underload point 1	Defines the 1st point of the underload curve.  Each point of the underload curve must have a lower value than the corresponding overload point.	10.0%
	0.0 1600.0%	Underload point.	1 = 1%
37.22	ULC underload point 2	Defines the 2nd point of the underload curve.	15.0%
	0.0 1600.0%	Underload point.	1 = 1%
37.23	ULC underload point 3	Defines the 3rd point of the underload curve.	25.0%
	0.0 1600.0%	Underload point.	1 = 1%
37.24	ULC underload point 4	Defines the 4th point of the underload curve.	30.0%
	0.0 1600.0%	Underload point.	1 = 1%
37.25	ULC underload point 5	Defines the 5th point of the underload curve.	30.0%
	0.0 1600.0%	Underload point.	1 = 1%
37.31	ULC overload point 1	Defines the 1st point of the overload curve.  Each point of the overload curve must have a higher value than the corresponding underload point.	300.0%
	0.0 1600.0%	Overload point.	1 = 1%
37.32	ULC overload point 2	Defines the 2nd point of the overload curve.	300.0%
	0.0 1600.0%	Overload point.	1 = 1%

No.	Name/Value	Description	Def/FbEq16	
37.33	ULC overload point 3	Defines the 3rd point of the overload curve.	300.0%	
	0.0 1600.0%	Overload point.	1 = 1%	
37.34	ULC overload point 4	Defines the 4th point of the overload curve.	300.0%	
	0.0 1600.0%	Overload point.	1 = 1%	
37.35	ULC overload point 5	Defines the 5th point of the overload curve.	300.0%	
	0.0 1600.0%	Overload point.	1 = 1%	
37.41	ULC overload timer	Defines the time for which the monitored signal must continuously stay above the overload curve before the drive takes the action selected by 37.03 ULC overload actions.	20.0 s	
	0.0 10000.0 s	Overload timer.	1 = 1 s	
37.42	ULC underload timer	Defines the time for which the monitored signal must continuously stay below the underload curve before the drive takes the action selected by 37.04 ULC underload actions.	20.0 s	
	0.0 10000.0 s	Underload timer.	1 = 1 s	
		The drive contains a single active PID controller for process use, however two separate complete set-ups can be programmed and stored.  The first set is made up of parameters 40.0740.56*, the second set is defined by the parameters in group 41 Process PID set 2. The binary source that defines which set is used is selected by parameter 40.57 PID set1/set2 selection.  See section Process PID control (page 108) and the control chain diagrams on pages 694 and 695.  *The remaining parameters in this group are common for both sets.		
40.01	Process PID output actual	Displays the output of the process PID controller. See the control chain diagram on page 695.  This parameter is read-only. The unit is selected by parameter 40.12 Set 1 unit selection.	-	
	-32768.00 32767.00	Process PID controller output.	1 = 1 unit	
40.02	Process PID feedback actual	Displays the value of process feedback after source selection, mathematical function (parameter 40.10 Set 1 feedback function), and filtering. See the control chain diagram on page 694.  This parameter is read-only. The unit is selected by parameter 40.12 Set 1 unit selection.	-	
	-32768.00 32767.00	Process feedback.	1 = 1 unit	
40.03	Process PID setpoint actual	Displays the value of process PID setpoint after source selection, mathematical function (40.18 Set 1 setpoint function), limitation and ramping. See the control chain diagram on page 695.  This parameter is read-only. The unit is selected by parameter 40.12 Set 1 unit selection.	-	
	-32768.00 32767.00	Setpoint for process PID controller.	1 = 1 unit	

No.	Name/Va	alue	Descri	ption	Def/FbEq16	
40.04	Process PID deviation actual		equals parame chain of This pa	ys the process PID deviation. By default, this value setpoint - feedback, but deviation can be inverted by eter 40.31 Set 1 deviation inversion. See the control diagram on page 695.  arameter is read-only. The unit is selected by eter 40.12 Set 1 unit selection.	-	
	-32768.0 32767.00		PID de	viation.	1 = 1 unit	
40.05	Process output ad		chain d	ys the trimmed reference output. See the control diagram on page 695.  arameter is read-only. The unit is selected by eter 40.12 Set 1 unit selection.	-	
	-32768.0 32767.00		Trimme	ed reference.	1 = 1 unit	
40.06	Process word	PID status		ys status information on process PID control. arameter is read-only.	-	
	Bit	Name		Value		
	0	PID active		1 = Process PID control active.		
	1	Setpoint fro	zen	1 = Process PID setpoint frozen.		
	2	Output froz		1 = Process PID controller output frozen.		
	3	PID sleep r		1 = Sleep mode active.		
	4			1 = Sleep boost active.		
	5	Sleep boost		1 = Trim function active.		
	6	Trim mode		1 = Tracking function active.		
	7	Tracking mode		1 = PID output is being limited by par. <i>40.37</i> .		
	8	Output limit high		1 = PID output is being limited by par. 40.37.		
		Output limit low		1 = Deadband active (see par. 40.39)		
	9	Deadband active		0 = Parameter set 1 in use. 1 = Parameter set 2 in use.		
	10	PID set		0 - Parameter set 1 in use. 1 - Parameter set 2 in use.		
	11	Reserved		14 14 14 14 15 16 16 16 16 16 16 16 16 16 16 16 16 16		
	12	Internal set	point	1 = Internal setpoint active (see par. 40.1640.16)		
	1315	active Reserved				
	1515 Reserved					
	0000hFFFFh		Drocos	es PID control status word.	1 = 1	
40.07	Set 1 PID operation mode		paramone:	res/deactivates process PID control. See also eter 40.60 Set 1 PID activation source.  Process PID control is only available in external; see section Local control vs. external control 40).	Off	
	Off		Process PID control inactive.		0	
	On		Process PID control active.		1	
	On when drive running Proces		Proces	s PID control is active when the drive is running.	2	
40.08	Set 1 fee source	edback 1		s the first source of process feedback. See the control diagram on page 694.	Al1 scaled	
	Not selec	cted	None.		0	
	Al1 scale	ed	12.12	Al1 scaled value (see page 207).	1	
	Al2 scale		12 22	A/2 scaled value (see page 208).	2	

No.	Name/Value	Description	Def/FbEq16
	Freq in scaled	11.39 Freq in 1 scaled (see page 202).	3
	Motor current	01.07 Motor current (see page 160).	5
	Power inu out	01.14 Output power (see page 161).	6
	Motor torque	01.10 Motor torque (see page 160).	7
	Feedback data storage	40.91 Feedback data storage (see page 368).	10
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
40.09	Set 1 feedback 2 source	Selects the second source of process feedback. For the selections, see parameter 40.08 Set 1 feedback 1 source.	Not selected
40.10	Set 1 feedback function	Defines how process feedback is calculated from the two feedback sources selected by parameters 40.08 Set 1 feedback 1 source and 40.09 Set 1 feedback 2 source.	In1
	ln1	Source 1.	0
	ln1+ln2	Sum of sources 1 and 2.	1
	ln1-ln2	Source 2 subtracted from source 1.	2
	ln1*ln2	Source 1 multiplied by source 2.	3
	ln1/ln2	Source 1 divided by source 2.	4
	MIN(In1,In2)	Smaller of the two sources.	5
	MAX(In1,In2)	Greater of the two sources.	6
	AVE(In1,In2)	Average of the two sources.	7
	sqrt(In1)	Square root of source 1.	8
	sqrt(In1-In2)	Square root of (source 1 - source 2).	9
	sqrt(ln1+ln2)	Square root of (source 1 + source 2).	10
	sqrt(ln1)+sqrt(ln2)	Square root of source 1 + square root of source 2.	11
40.11	Set 1 feedback filter time	Defines the filter time constant for process feedback.	0.000 s
	0.000 30.000 s	Feedback filter time.	1 = 1 s
40.12	Set 1 unit selection	Defines the unit for parameters 40.0140.05, 40.2140.24 and 40.47.	%
	rpm	rpm.	7
	%	%.	4
	Hz	Hz.	3
	PID user unit 1	User-definable unit 1. The name of the unit can be edited on the control panel by choosing <b>Menu</b> - <b>Settings</b> - <b>Edit texts</b> .	250

No.	Name/Value	Description	Def/FbEq16
40.14	Set 1 setpoint scaling		
	-32768.00 32767.00	Process setpoint base.	1 = 1
40.15	Set 1 output scaling	See parameter 40.14 Set 1 setpoint scaling.	1500.00; 1800.00 (95.20 b0)
	-32768.00 32767.00	Process PID controller output base.	1 = 1
40.16	Set 1 setpoint 1 source	Selects the first source of process PID setpoint. This setpoint is available in parameter 40.25 Set 1 setpoint selection as setpoint 1. See the control chain diagram on page 694.	Internal setpoint
	Not selected	None.	0
	Control panel	03.01 Panel reference (see page 165). See section Using the control panel as an external control source (page 41).	1
	Internal setpoint	Internal setpoint. See parameter 40.19 Set 1 internal setpoint sel1.	2
	Al1 scaled	12.12 AI1 scaled value (see page 207).	3
	Al2 scaled	12.22 Al2 scaled value (see page 208).	4
	Motor potentiometer	22.80 Motor potentiometer ref act (output of the motor potentiometer).	8
	Freq in scaled	11.39 Freq in 1 scaled (see page 202).	10
	Setpoint data storage	40.92 Setpoint data storage (see page 368).	24
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
40.17	Set 1 setpoint 2 source	Selects the second source of process setpoint. This setpoint is available in parameter 40.25 Set 1 setpoint selection as setpoint 2.  For the selections, see parameter 40.16 Set 1 setpoint 1 source.	Not selected
40.18	Set 1 setpoint function	Selects a mathematical function between the setpoint sources selected by parameters 40.16 Set 1 setpoint 1 source and 40.17 Set 1 setpoint 2 source.	In1 or In2
	In1 or In2	No mathematical function applied. The source selected by parameter 40.25 Set 1 setpoint selection is used.	0
	ln1+ln2	Sum of sources 1 and 2.	1
	ln1-ln2	Source 2 subtracted from source 1.	2
	ln1*ln2	Source 1 multiplied by source 2.	3
	ln1/ln2	Source 1 divided by source 2.	4

No.	Name/Value	Description			Def/FbEq16
	MIN(In1,In2)	Smaller of the two	sources.		5
	MAX(In1,In2)	Greater of the two sources.			6
	AVE(In1,In2)	Average of the two sources.			7
	sqrt(In1)	Square root of source 1.			8
	sqrt(In1-In2)	Square root of (so	Square root of (source 1 - source 2).		
	sqrt(In1+In2)	Square root of (so	Square root of (source 1 + source 2).		
	sqrt(In1)+sqrt(In2)	Square root of source 1 + square root of source 2.			11
40.19	Set 1 internal setpoint sel1	Selects, together with 40.20 Set 1 internal setpoint sel2, the internal setpoint out of the presets defined by parameters 40.2140.24.			Not selected
		Source defined by par. 40.19	Source defined by par. 40.20	Setpoint preset active	
		0	0	1 (par. <b>40.21</b> )	
		1	0	2 (par. <b>40.22</b> )	
		0	1	3 (par. <b>40.23</b> )	
		1	1	4 (par. <b>40.24</b> )	
	Not selected	0			0
	Selected		0.		
	DI1		1.		
	DI2	Digital input DI1 (10.02 DI delayed status, bit 0).			3
	DI3	Digital input DI2 (10.02 DI delayed status, bit 1).			4
	DI4	Digital input DI3 (10.02 DI delayed status, bit 2).			5
	DI5	Digital input DI4 (10.02 DI delayed status, bit 3).  Digital input DI5 (10.02 DI delayed status, bit 4).			
		, ,	6 7		
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).  Digital input/output DIO1 (11.02 DIO delayed status bit 0)			
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).			10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).			11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).			-
40.20	Set 1 internal setpoint sel2	Selects, together with 40.19 Set 1 internal setpoint sel1, the internal setpoint out of the presets defined by parameters 40.2140.24. See table at 40.19 Set 1 internal setpoint sel1.			Not selected
	Not selected	0.	0		
	Selected	1.			1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).			2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).			3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).			4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).			5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).			6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).			7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).			10
	DIO2		`	delayed status, bit 1).	11

No.	Name/Value	Description	Def/FbEq16
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	
40.21	Set 1 internal setpoint 1	Defines process setpoint preset 1. See parameter 40.19 Set 1 internal setpoint sel1.	0.00
		The unit is selected by parameter 40.12 Set 1 unit selection.	
	-32768.00 32767.00	Process setpoint preset 1.	1 = 1 unit
40.22	Set 1 internal setpoint 2	Defines process setpoint preset 2. See parameter 40.19 Set 1 internal setpoint sel1.  The unit is selected by parameter 40.12 Set 1 unit selection.	0.00
	-32768.00 32767.00	Process setpoint preset 2.	1 = 1 unit
40.23	Set 1 internal setpoint 3	Defines process setpoint preset 3. See parameter 40.19 Set 1 internal setpoint sel1.  The unit is selected by parameter 40.12 Set 1 unit selection.	0.00
	-32768.00 32767.00	Process setpoint preset 3.	1 = 1 unit
40.24	Set 1 internal setpoint 4	Defines process setpoint preset 4. See parameter 40.19 Set 1 internal setpoint sel1.  The unit is selected by parameter 40.12 Set 1 unit selection.	0.00
	-32768.00 32767.00	Process setpoint preset 4.	1 = 1 unit
40.25	Set 1 setpoint selection	Configures the selection between setpoint sources 1 (40.16) and 2 (40.17).  This parameter is only effective when parameter 40.18 Set 1 setpoint function is set to In1 or In2.  0 = Setpoint source 1 1 = Setpoint source 2	Setpoint source 1
	Setpoint source 1	0.	0
	Setpoint source 2	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
40.26	Set 1 setpoint min	Defines a minimum limit for the process PID controller setpoint.	0.00
	-32768.00 32767.00	Minimum limit for process PID controller setpoint.	1 = 1
40.27	Set 1 setpoint max	Defines a maximum limit for the process PID controller setpoint.	32767.00
	-32768.00 32767.00	Maximum limit for process PID controller setpoint.	1 = 1

No.	Name/Value	Description	Def/FbEq16
40.28	Set 1 setpoint increase time	Defines the minimum time it takes for the setpoint to increase from 0% to 100%.	0.0 s
	0.0 1800.0 s	Setpoint increase time.	1 = 1
40.29	Set 1 setpoint decrease time	Defines the minimum time it takes for the setpoint to decrease from 100% to 0%.	0.0 s
	0.0 1800.0 s	Setpoint decrease time.	1 = 1
40.30	Set 1 setpoint freeze enable	Freezes, or defines a source that can be used to freeze, the setpoint of the process PID controller. This feature is useful when the reference is based on a process feedback connected to an analog input, and the sensor must be serviced without stopping the process.  1 = Process PID controller setpoint frozen See also parameter 40.38 Set 1 output freeze enable.	Not selected
	Not selected	Process PID controller setpoint not frozen.	0
	Selected	Process PID controller setpoint frozen.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
40.31	Set 1 deviation inversion	Inverts the input of the process PID controller.  0 = Deviation not inverted (Deviation = Setpoint - Feedback)  1 = Deviation inverted (Deviation = Feedback - Setpoint)  See also section Sleep function for process PID control (page 109).	Not inverted (Ref - Fbk)
	Not inverted (Ref - Fbk)	0.	0
	Inverted (Fbk - Ref)	1.	1
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
40.32	Set 1 gain	Defines the gain for the process PID controller. See parameter 40.33 Set 1 integration time.	1.00
	0.10 100.00	Gain for PID controller.	100 = 1

No.	Name/Value	Description	Def/FbEq16
40.33	Set 1 integration time  0.0 32767.0 s  Set 1 derivation time	Defines the integration time for the process PID controller. This time needs to be set to the same order of magnitude as the reaction time of the process being controlled, otherwise instability will result.  Error/Controller output  G × I  I = controller input (error) O = controller output G = gain Ti = integration time  Note: Setting this value to 0 disables the "I" part, turning the PID controller into a PD controller.  Integration time.  Defines the derivation time of the process PID controller. The derivative component at the controller output is calculated on basis of two consecutive error values (E <sub>K</sub> -1 and E <sub>K</sub> ) according to the following formula:  PID DERIV TIME × (E <sub>K</sub> - E <sub>K-1</sub> )/T <sub>S</sub> , in which T <sub>S</sub> = 2 ms sample time E = Error = Process reference - process feedback.	60.0 s  1 = 1 s  0.000 s
	0.000 10.000 s	Derivation time.	1000 = 1 s
40.35	Set 1 derivation filter time	Defines the time constant of the 1-pole filter used to smooth the derivative component of the process PID controller.   "Unfiltered signal  100 63  Filtered signal   O = I × (1 - e <sup>-t/T</sup> )  I = filter input (step) O = filter output t = time T = filter time constant	0.0 s
	0.0 10.0 s	Filter time constant.	10 = 1 s

No.	Name/Value	Description	Def/FbEq16
40.36	Set 1 output min	Defines the minimum limit for the process PID controller output. Using the minimum and maximum limits, it is possible to restrict the operation range.	0.0
	-32768.0 32767.0	Minimum limit for process PID controller output.	1 = 1
40.37	Set 1 output max	Defines the maximum limit for the process PID controller output. See parameter 40.36 Set 1 output min.	1500.0; 1800.0 (95.20 b0)
	-32768.0 32767.0	Maximum limit for process PID controller output.	1 = 1
40.38	Set 1 output freeze enable	Freezes (or defines a source that can be used to freeze) the output of the process PID controller, keeping the output at the value it was before freeze was enabled. This feature can be used when, for example, a sensor providing process feedback must to be serviced without stopping the process.  1 = Process PID controller output frozen See also parameter 40.30 Set 1 setpoint freeze enable.	Not selected
	Not selected	Process PID controller output not frozen.	0
	Selected	Process PID controller output frozen.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-

No.	Name/Value	Description	Def/FbEq16
40.39	Set 1 deadband range	Defines a deadband around the setpoint. Whenever process feedback enters the deadband, a delay timer starts. If the feedback remains within the deadband longer than the delay (40.40 Set 1 deadband delay), the PID controller output is frozen. Normal operation resumes after the feedback value leaves the deadband.	0.0
	40.39 Set 1		
	deadband range		
	Setpo	pint	
	Feedba		
	out	put PID co	ontroller t frozen
		40.40 Set 1 deadband delay	
			Time
	0.0 32767.0	Deadband range.	1 = 1
40.40	Set 1 deadband delay	Delay for the deadband. See parameter 40.39 Set 1 deadband range.	0.0 s
	0.0 3600.0 s	Delay for deadband area.	1 = 1 s
40.41	Set 1 sleep mode	Selects the mode of the sleep function. See also section Sleep function for process PID control (page 109).	Not selected
	Not selected	Sleep function disabled.	0
	Internal	The output of the PID controller is compared to the value of 40.43 Set 1 sleep level.  If the PID controller output remains below the sleep level longer than the sleep delay (40.44 Set 1 sleep delay), the drive enters sleep mode.  Parameters 40.4440.48 are in force.	1
	External	The sleep function is activated by the source selected by parameter 40.42 Set 1 sleep enable.  Parameters 40.4440.46 and 40.48 are in force.	2
40.42	Set 1 sleep enable	Defines a source that is used to activate the PID sleep function when parameter 40.41 Set 1 sleep mode is set to External.  0 = Sleep function disabled 1 = Sleep function activated	Not selected
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4

No.	Name/Value	Description	Def/FbEq16
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
40.43	Set 1 sleep level	Defines the start limit for the sleep function when parameter 40.41 Set 1 sleep mode is set to Internal.	0.0
	0.0 32767.0	Sleep start level.	1 = 1
40.44	Set 1 sleep delay	Defines a delay before the sleep function actually becomes enabled, to prevent nuisance sleeping.  The delay timer starts when the sleep condition selected by parameter 40.41 Set 1 sleep mode becomes true, and resets if the condition becomes false.	60.0 s
	0.0 3600.0 s	Sleep start delay.	1 = 1 s
40.45	Set 1 sleep boost time	Defines a boost time for the sleep boost step. See parameter 40.46 Set 1 sleep boost step.	0.0 s
	0.0 3600.0 s	Sleep boost time.	1 = 1 s
40.46	Set 1 sleep boost step	When the drive is entering sleep mode, the process setpoint is increased by this value for the time defined by parameter 40.45 Set 1 sleep boost time.  If active, sleep boost is aborted when the drive wakes up.	0.0
	0.0 32767.0	Sleep boost step.	1 = 1
40.47	Set 1 wake-up deviation	When 40.41 Set 1 sleep mode is set to Internal, this parameter defines the wake-up level as deviation between process setpoint and feedback. The unit is selected by parameter 40.12 Set 1 unit selection.  When the deviation exceeds the value of this parameter, and remains there for the duration of the wake-up delay (40.48 Set 1 wake-up delay), the drive wakes up.  See also parameter 40.31 Set 1 deviation inversion.	0.00 rpm, % or Hz
	-32768.00 32767.00 rpm, % or Hz	Wake-up level (as deviation between process setpoint and feedback).	1 = 1 unit
40.48	Set 1 wake-up delay	Defines a wake-up delay for the sleep function to prevent nuisance wake-ups. See parameter 40.47 Set 1 wake-up deviation.  The delay timer starts when the deviation exceeds the wake-up level (40.47 Set 1 wake-up deviation), and resets if the deviation falls below the wake-up level.	0.50 s
	0.00 60.00 s	Wake-up delay.	1 = 1 s
40.49	Set 1 tracking mode	Activates (or selects a source that activates) tracking mode. In tracking mode, the value selected by parameter 40.50 Set 1 tracking ref selection is substituted for the PID controller output. See also section Tracking (page 110).  1 = Tracking mode enabled	Not selected
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2

No.	Name/Value	Description	Def/FbEq16
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
40.50	Set 1 tracking ref selection	Selects the value source for tracking mode. See parameter 40.49 Set 1 tracking mode.	Not selected
	Not selected	None.	0
	Al1 scaled	12.12 Al1 scaled value (see page 207).	1
	Al2 scaled	12.22 Al2 scaled value (see page 208).	2
	FB A ref1	03.05 FB A reference 1 (see page 165).	3
	FB A ref2	03.06 FB A reference 2 (see page 165).	4
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
40.51	Set 1 trim mode	Activates the trim function and selects between direct and proportional trimming (or a combination of both). With trimming, it is possible to apply a corrective factor to the drive reference (setpoint). The output after trimming is available as parameter 40.05 Process PID trim output act. See the control chain diagram on page 695.	Off
	Off	The trim function is inactive.	0
	Direct	The trim function is active. The trimming factor is relative to the maximum speed, torque or frequency; the selection between these is made by parameter 40.52 Set 1 trim selection.	1
	Proportional	The trim function is active. The trimming factor is relative to the reference selected by parameter 40.53 Set 1 trimmed ref pointer.	2
	Combined	The trim function is active. The trimming factor is a combination of both <i>Direct</i> and <i>Proportional</i> modes; the proportions of each are defined by parameter 40.54 Set 1 trim mix.	3
40.52	Set 1 trim selection	Selects whether trimming is used for correcting the speed, torque or frequency reference.	Torque
	Torque	Torque reference trimming.	1
	Speed	Speed reference trimming.	2
	Frequency	Frequency reference trimming.	3
40.53	Set 1 trimmed ref pointer	Selects the signal source for the trim reference.	Not selected
	Not selected	None.	0
	Al1 scaled	12.12 Al1 scaled value (see page 207).	1
	Al2 scaled	12.22 Al2 scaled value (see page 208).	2
	FB A ref1	03.05 FB A reference 1 (see page 165).	3

No.	Name/Value	Description	Def/FbEq16
	FB A ref2	03.06 FB A reference 2 (see page 165).	4
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
40.54	Set 1 trim mix	When parameter 40.51 Set 1 trim mode is set to Combined, defines the effect of direct and proportional trim sources in the final trimming factor.  0.000 = 100% proportional  0.500 = 50% proportional, 50% direct  1.000 = 100% direct	0.000
	0.000 1.000	Trim mix.	1 = 1
40.55	Set 1 trim adjust	Defines a multiplier for the trimming factor. This value is multiplied by the result of parameter 40.51 Set 1 trim mode. Consequently, the result of the multiplication is used to multiply the result of parameter 40.56 Set 1 trim source.	1.000
	-100.000 100.000	Multiplier for trimming factor.	1 = 1
40.56	Set 1 trim source	Selects the reference to be trimmed.	PID ref
	PID ref	PID setpoint.	1
	PID output	PID controller output.	2
40.57	PID set1/set2 selection	Selects the source that determines whether process PID parameter set 1 (parameters 40.0740.56) or set 2 (group 41 Process PID set 2) is used.  0 = Process PID parameter set 1 in use	Not selected
		1 = Process PID parameter set 2 in use	
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
40.60	Set 1 PID activation source	Selects a source that enables/disables process PID control. See also parameter 40.07 Set 1 PID operation mode. 0 = Process PID control disabled. 1 = Process PID control enabled.	On
	Off	0.	0
	On	1.	1
	Follow Ext1/Ext2 selection	Process PID control is disabled when external control location EXT1 is active, and enabled when external control location EXT2 is active.  See also parameter 19.11 Ext1/Ext2 selection.	2
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	3
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	4

No.	Name/Value	Description	Def/FbEq16
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	5
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	6
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	7
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	8
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	11
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	12
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
40.91	Feedback data storage	Storage parameter for receiving a process feedback value e.g. through the embedded fieldbus interface.  The value can be sent to the drive as Modbus I/O data. Set the target selection parameter of that particular data (58.10158.124) to Feedback data storage. In 40.08 Set 1 feedback 1 source (or 40.09 Set 1 feedback 2 source), select Feedback data storage.	-
	-327.68 327.67	Storage parameter for process feedback.	100 = 1
40.92	Setpoint data storage	Storage parameter for receiving a process setpoint value e.g. through the embedded fieldbus interface.  The value can be sent to the drive as Modbus I/O data. Set the target selection parameter of that particular data (58.10158.124) to Setpoint data storage. In 40.16 Set 1 setpoint 1 source (or 40.17 Set 1 setpoint 2 source), select Setpoint data storage.	-
	-327.68 327.67	Storage parameter for process setpoint.	100 = 1

41 Pro	ocess PID set 2	A second set of parameter values for process PID control. The selection between this set and first set (parameter group 40 Process PID set 1) is made by parameter 40.57 PID set1/set2 selection.  See section Process PID control (page 108). See also parameters 40.0140.06, 40.91, 40.92, and the control chain diagrams on pages 694 and 695.	
41.07	Set 2 PID operation mode	See parameter 40.07 Set 1 PID operation mode.	Off
41.08	Set 2 feedback 1 source	See parameter 40.08 Set 1 feedback 1 source.	Al1 scaled
41.09	Set 2 feedback 2 source	See parameter 40.09 Set 1 feedback 2 source.	Not selected
41.10	Set 2 feedback function	See parameter 40.10 Set 1 feedback function.	In1
41.11	Set 1 feedback filter time	See parameter 40.11 Set 1 feedback filter time.	0.000 s
41.12	Set 1 unit selection	Defines the unit for parameter 41.2141.24 and 41.27.	%
	rpm	rpm.	7
	%	%.	4
	Hz	Hz.	3
	PID user unit 2	User-definable unit 2. The name of the unit can be edited on the control panel by choosing <b>Menu</b> – <b>Settings</b> – <b>Edit texts</b> .	249
41.14	Set 1 setpoint scaling	See parameter 40.14 Set 1 setpoint scaling.	100.00

41.40   Set 1 deadband   See parameter 40.40 Set 1 deadband delay   delay	No.	Name/Value	Description	Def/FbEq16
41.42         Set 1 sleep enable         See parameter 40.42 Set 1 sleep enable.         Not selected           41.43         Set 1 sleep level         See parameter 40.43 Set 1 sleep level.         0.0           41.44         Set 1 sleep delay         See parameter 40.44 Set 1 sleep boost time.         60.0 s           41.45         Set 1 sleep boost step.         See parameter 40.45 Set 1 sleep boost step.         0.0           41.46         Set 1 sleep boost step.         See parameter 40.46 Set 1 sleep boost step.         0.0           41.47         Set 1 wake-up delay         See parameter 40.47 Set 1 wake-up deviation.         0.00 rpm, % or Hz           41.48         Set 1 wake-up delay         See parameter 40.48 Set 1 wake-up delay.         0.50 s           41.49         Set 1 tracking mode         See parameter 40.49 Set 1 tracking mode.         Not selected           41.50         Set 1 trims mode         See parameter 40.50 Set 1 tracking ref selection.         Not selected           41.51         Set 1 trim mode         See parameter 40.52 Set 1 trim selection.         Torque           41.52         Set 1 trim mode         See parameter 40.53 Set 1 trim mix.         0.000           41.53         Set 1 trim adjust         See parameter 40.55 Set 1 trim source.         PID ref           41.54         Set 1 trim source         See parame	41.40		See parameter 40.40 Set 1 deadband delay.	0.0 s
41.43 Set 1 sleep level See parameter 40.43 Set 1 sleep level. 0.0 41.44 Set 1 sleep delay See parameter 40.44 Set 1 sleep delay. 60.0 s 41.45 Set 1 sleep boost time  41.46 Set 1 sleep boost step 41.47 Set 1 wake-up deviation  41.48 Set 1 wake-up delay 41.49 Set 1 wake-up delay 41.49 Set 1 tracking mode 41.40 Set 1 tracking mode 41.50 Set 1 tracking from delay 41.50 Set 1 tracking ref see parameter 40.49 Set 1 tracking mode. Not selected selection 41.51 Set 1 trim mode 41.52 Set 1 trim mode 41.53 Set 1 trim mode 41.54 Set 1 trim mode 55 See parameter 40.51 Set 1 trim mode. Off 41.55 Set 1 trim selection 41.56 Set 1 trim mix 41.57 Set 1 trim mix 41.58 Set 1 trim mix 41.59 Set 1 trim mix 41.50 Set 1 trim mix 41.50 Set 1 trim mix 41.51 Set 1 trim mix 55 See parameter 40.52 Set 1 trim selection. Torque 41.55 Set 1 trim selection 41.56 Set 1 trim source 41.57 Set 1 trim source 41.58 Set 1 trim source 56 See parameter 40.55 Set 1 trim mix. 57 On00 58 See parameter 40.55 Set 1 trim mix. 59 On00 50 On00 50 On000 50 On0000 50 On00000000000000000000000000000000000	41.41	Set 1 sleep mode	See parameter 40.41 Set 1 sleep mode.	Not selected
41.44 Set 1 sleep delay  See parameter 40.44 Set 1 sleep boost time  141.45 Set 1 sleep boost time  See parameter 40.45 Set 1 sleep boost time  32. Set 1 sleep boost step  41.46 Set 1 sleep boost step  41.47 Set 1 wake-up  41.48 Set 1 wake-up  41.49 Set 1 wake-up delay  See parameter 40.47 Set 1 wake-up deviation.  41.49 Set 1 tracking mode  41.50 Set 1 tracking mode  41.50 Set 1 tracking ref  52. See parameter 40.50 Set 1 tracking ref selection.  41.51 Set 1 trim mode  41.52 Set 1 trim selection  41.53 Set 1 trim mode  41.54 Set 1 trim mix  See parameter 40.53 Set 1 trim mix  See parameter 40.53 Set 1 trim mix  See parameter 40.53 Set 1 trim mix  See parameter 40.55 Set 1 trim mix  See parameter 40.55 Set 1 trim mix  O.000  41.55 Set 1 trim adjust  See parameter 40.56 Set 1 trim source.  PID ref  41.60 PID set 1/set2  52. See parameter 40.56 Set 1 trim source.  PID ref  41.60 PID set 1/set2  53. See parameter 40.56 Set 1 trim source.  Con  43.01 Braking resistor temperature  See parameter 40.56 Set 1 trim source.  Displays the estimated temperature of the brake resistor, or how close the brake resistor is hot.  The value is given in percent, where 100% is the eventual temperature that the resistor is hot.  The value is given in percent, where 100% is the eventual temperature that the resistor is lot.  The value is given in percent, where 100% is the eventual temperature that the resistor is hot.  The value is given in percent, where 100% is the eventual temperature that the resistor is hot.  The value is given in percent, where 100% is the eventual temperature that the resistor is hot.  The value is given in percent when loaded long enough with its rated maximum load capacity (43.09 Brake resistor Pmax cont).  Temperature calculation is based on the values defined in parameters 43.08, 43.09 and 43.10, and on the assumption that the resistor is read-only.  Disabled  Note: Before enabling brake chopper control, ensure that  a brake chopper  function  Final Pide Archapper  function  See parameter is read-only.  D	41.42	Set 1 sleep enable	See parameter 40.42 Set 1 sleep enable.	Not selected
41.45 Set 1 sleep boost time  41.46 Set 1 sleep boost step  See parameter 40.46 Set 1 sleep boost step.  41.47 Set 1 wake-up deviation  41.48 Set 1 wake-up delay  41.49 Set 1 tracking mode  41.50 Set 1 tracking mode  41.50 Set 1 tracking ref selection  41.51 Set 1 trim mode  41.52 Set 1 trim mode  41.53 Set 1 trim mode  41.54 Set 1 trim mix  41.55 Set 1 trim mix  41.56 Set 1 trim mix  41.57 See parameter 40.53 Set 1 trim mix  41.58 Set 1 trim mix  41.59 See parameter 40.53 Set 1 trim mix  41.50 Set 1 trim mix  41.51 See parameter 40.53 Set 1 trim selection.  41.52 Set 1 trim mix  41.53 Set 1 trim mix  41.54 Set 1 trim mix  41.55 Set 1 trim adjust  41.56 Set 1 trim adjust  41.57 See parameter 40.55 Set 1 trim mix.  41.58 Set 1 trim source  41.59 See parameter 40.56 Set 1 trim source.  41.50 PID set1/set2  41.50 See parameter 40.56 Set 1 trim source.  41.51 Set 1 trim source  41.52 Set 1 trim source  41.54 Set 1 trim source  41.55 Set 1 trim source  41.56 Set 1 trim source  41.57 See parameter 40.56 Set 1 trim source.  41.58 Set 1 trim source  41.59 See parameter 40.50 Set 1 trim source.  41.50 PID set1/set2  5ee parameter 40.56 Set 1 trim source.  5ee parameter 40.56 Set 1 trim source.  6e parameter 40.56 Set 1 trim source.  7e piD ref  41.50 PiD set1/set2  8ee parameter 40.56 Set 1 trim source.  8ee parameter 40.56 Set 1 trim source.  9e parameter 40.56 Set 1 trim source.  10 Set 1 trim source  11 Set 1 trim source  12 Set 1 selection  13 Set 1 trim source  14 Set 1 trim source  15 Set 1 trim source  16 Set 1 trim source  17 See parameter 40.56 Set 1 trim source.  18 See parameter 40.56 Set 1 trim source.  19 See parameter 40.56 Set 1 trim source.  10 See parameter 40.56 Set 1 trim source.  11 Set 1	41.43	Set 1 sleep level	See parameter 40.43 Set 1 sleep level.	0.0
### 41.46 Set 1 sleep boost step ### Set 1 sleep boost step ### Set 1 wake-up deviation ### Set 1 wake-up delay ### Set 1 wake-up delay ### Set 1 tracking mode ### Set 1 tracking ref selection. ### Not selected ### Set 1 trim mode ### See parameter 40.50 Set 1 tracking ref selection. ### Off ### Off ### Set 1 trim mode ### See parameter 40.51 Set 1 trim mode. ### Off ### Off ### Set 1 trim selection ### See parameter 40.52 Set 1 trim selection. ### Torque ### Set 1 trim mix ### See parameter 40.53 Set 1 trim mix. ### O.000 ### O.000 ### Set 1 trim mix ### See parameter 40.54 Set 1 trim mix. ### O.000 ### O.000 ### O.000 ### Set 1 trim source ### See parameter 40.55 Set 1 trim adjust. ### O.000 ### Set 1 trim source ### See parameter 40.56 Set 1 trim source. ### Ond ### Ond ### Death / Set 1 trim source. ### Ond ### Ond ### Death / Set 1 trim source. ### Ond	41.44	Set 1 sleep delay	See parameter 40.44 Set 1 sleep delay.	60.0 s
### 41.47 Set 1 wake-up deviation ### See parameter 40.47 Set 1 wake-up deviation ### O.00 rpm, % or Hz  ### 41.48 Set 1 wake-up delay	41.45	-	See parameter 40.45 Set 1 sleep boost time.	0.0 s
deviation       or Hz         41.48       Set 1 wake-up delay       See parameter 40.48 Set 1 wake-up delay.       0.50 s         41.49       Set 1 tracking mode       See parameter 40.49 Set 1 tracking mode.       Not selected         41.50       Set 1 tracking ref selection       See parameter 40.50 Set 1 trim wode.       Off         41.51       Set 1 trim mode       See parameter 40.51 Set 1 trim mode.       Off         41.52       Set 1 trim selection       See parameter 40.52 Set 1 trim selection.       Torque         41.53       Set 1 trim mix       See parameter 40.53 Set 1 trimmed ref pointer.       Not selected         41.54       Set 1 trim mix       See parameter 40.53 Set 1 trim mix.       0.000         41.55       Set 1 trim adjust       See parameter 40.55 Set 1 trim adjust.       1.000         41.60       PID set1/set2       See parameter 40.56 Set 1 trim source.       PID ref         41.60       PID set1/set2       See parameter 40.60 Set 1 PID activation source.       On         43.01       Braking resistor ten parameter 40.50 Set 1 resistor is hot.       The value is given in percent, where 100% is the eventual temperature that the resistor is hot.       The value is given in percent, where 100% is the eventual temperature that the resistor is hot.       The value is given in percent, where 100% is the eventual temperature that the resistor is hot.       The value	41.46		See parameter 40.46 Set 1 sleep boost step.	0.0
41.49 Set 1 tracking mode 41.50 Set 1 tracking ref selection See parameter 40.50 Set 1 tracking ref selection.  Not selected 41.51 Set 1 trim mode See parameter 40.51 Set 1 trim mode. Off 41.52 Set 1 trim selection See parameter 40.52 Set 1 trim selection. Torque 41.53 Set 1 trimmed ref pointer See parameter 40.53 Set 1 trimmed ref pointer. Not selected 41.54 Set 1 trim mix See parameter 40.55 Set 1 trim mix. 0.000 41.55 Set 1 trim adjust See parameter 40.55 Set 1 trim adjust. 1.000 41.56 Set 1 trim source See parameter 40.56 Set 1 trim source. PID ref 41.60 PID set1/set2 See parameter 40.60 Set 1 PID activation source. On  43 Brake chopper See also section Brake chopper (page 120).  43.01 Braking resistor temperature Displays the estimated temperature of the brake resistor, or how close the brake resistor is hot. The value is given in percent, where 100% is the eventual temperature that the resistor will reach when loaded long enough with its rated maximum load capacity (43.09 Brake resistor Pmax cont). Temperature calculation is based on the values defined in parameters 43.08, 43.09 and 43.10, and on the assumption that the resistor is installed as instructed by the manufacturer (i.e., it cools down as expected). This parameter is read-only.  Disabled  0.0 120.0% Estimated brake resistor temperature.  Enables brake resistor temperature.  1 = 1% Disabled This parameter is read-only.	41.47		See parameter 40.47 Set 1 wake-up deviation.	
41.50 Set 1 tracking ref selection  See parameter 40.50 Set 1 tracking ref selection.  Not selected  41.51 Set 1 trim mode  See parameter 40.51 Set 1 trim mode.  Off  41.52 Set 1 trim selection  See parameter 40.52 Set 1 trim selection.  Torque  41.53 Set 1 trimmed ref pointer  See parameter 40.53 Set 1 trimmed ref pointer.  Not selected pointer  41.54 Set 1 trim mix  See parameter 40.54 Set 1 trim mix.  See parameter 40.55 Set 1 trim adjust.  1.000  41.55 Set 1 trim source  See parameter 40.55 Set 1 trim source.  PID ref  41.60 PID sett/set2  See parameter 40.60 Set 1 PID activation source.  On  43 Brake chopper  See also section Brake chopper (page 120).  43.01 Braking resistor temperature  Displays the estimated temperature of the brake resistor, or how close the brake resistor is hot.  The value is given in percent, where 100% is the eventual temperature that the resistor will reach when loaded long enough with its rated maximum load capacity (43.09 Brake resistor Pmax cont).  Temperature calculation is based on the values defined in parameters 43.08, 43.09 and 43.10, and on the assumption that the resistor is installed as instructed by the manufacturer (i.e., it cools down as expected).  This parameter is read-only.  Disabled  1 = 1%  Note: Before enabling brake chopper control, ensure that  • a brake resistor is connected  • the supply voltage range (parameter 95.01 Supply voltage) has been selected correctly.	41.48	Set 1 wake-up delay	See parameter 40.48 Set 1 wake-up delay.	0.50 s
### selection  ### Set 1 trim mode  ### See parameter 40.51 Set 1 trim mode.  ### Set 1 trim selection  ### See parameter 40.52 Set 1 trim selection.  ### See parameter 40.53 Set 1 trim mix.  ### See parameter 40.53 Set 1 trimmed ref pointer.  ### Not selected pointer  ### See parameter 40.54 Set 1 trim mix.  ### O.000  ### See parameter 40.55 Set 1 trim adjust.  ### 1.000  ### Set 1 trim adjust  ### See parameter 40.55 Set 1 trim adjust.  ### 1.000  ### See parameter 40.56 Set 1 trim source.  ### PID set1/set2 See parameter 40.60 Set 1 PID activation source.  ### On  ### See parameter 40.60 Set 1 PID activation source.  ### On  ### See parameter 40.60 Set 1 PID activation source.  ### On  ### See also section Brake chopper (page 120).  ### Displays the estimated temperature of the brake resistor, or how close the brake resistor is hot.  ### The value is given in percent, where 100% is the eventual temperature that the resistor will reach when loaded long enough with its rated maximum load capacity (43.09 Brake resistor Pmax cont).  ### Temperature calculation is based on the values defined in parameters 43.08, 43.09 and 43.10, and on the assumption that the resistor is installed as instructed by the manufacturer (i.e., it cools down as expected).  ### This parameter is read-only.  ### On 120.0%  ### Enables brake chopper control.  ### Note: Before enabling brake chopper control, ensure that  ### In a brake resistor is connected  ### In a brake res	41.49	Set 1 tracking mode	See parameter 40.49 Set 1 tracking mode.	Not selected
41.52 Set 1 trim selection  See parameter 40.52 Set 1 trim selection.  Torque  41.53 Set 1 trimmed ref pointer  See parameter 40.53 Set 1 trimmed ref pointer.  Not selected pointer  41.54 Set 1 trim mix  See parameter 40.54 Set 1 trim mix.  0.000  41.55 Set 1 trim adjust  See parameter 40.55 Set 1 trim adjust.  1.000  41.56 Set 1 trim source  See parameter 40.56 Set 1 trim source.  PID ref  41.60 PID set1/set2 See parameter 40.60 Set 1 PID activation source.  On  43 Brake chopper  Settings for the internal brake chopper.  See also section Brake chopper (page 120).  Displays the estimated temperature of the brake resistor, or how close the brake resistor is hot.  The value is given in percent, where 100% is the eventual temperature that the resistor will reach when loaded long enough with its rated maximum load capacity (43.09 Brake resistor Pmax cont).  Temperature calculation is based on the values defined in parameters 43.08, 43.09 and 43.10, and on the assumption that the resistor is installed as instructed by the manufacturer (i.e., it cools down as expected).  This parameter is read-only.  Disabled  0.0 120.0%  Estimated brake resistor temperature.  1 = 1%  Note: Before enabling brake chopper control, ensure that  a brake resistor is connected  the supply voltage range (parameter 95.01 Supply voltage) has been selected correctly.	41.50		See parameter 40.50 Set 1 tracking ref selection.	Not selected
41.53 Set 1 trimmed ref pointer  See parameter 40.53 Set 1 trimmix.  0.000  41.54 Set 1 trim mix  See parameter 40.54 Set 1 trim mix.  0.000  41.55 Set 1 trim adjust  See parameter 40.55 Set 1 trim adjust.  1.000  41.56 Set 1 trim source  See parameter 40.56 Set 1 trim source.  PID ref  41.60 PID set1/set2 Selection  See parameter 40.60 Set 1 PID activation source.  On  43 Brake chopper  Settings for the internal brake chopper. See also section Brake chopper (page 120).  Displays the estimated temperature of the brake resistor, or how close the brake resistor is hot. The value is given in percent, where 100% is the eventual temperature that the resistor will reach when loaded long enough with its rated maximum load capacity (43.09 Brake resistor Pmax cont).  Temperature calculation is based on the values defined in parameters 43.08, 43.09 and 43.10, and on the assumption that the resistor is installed as instructed by the manufacturer (i.e., it cools down as expected). This parameter is read-only.  0.0 120.0%  Estimated brake resistor temperature.  1 = 1%  43.06 Brake chopper function  Note: Before enabling brake chopper control, ensure that  a brake resistor is connected  the supply voltage range (parameter 95.01 Supply voltage) has been selected correctly.	41.51	Set 1 trim mode	See parameter 40.51 Set 1 trim mode.	Off
### 41.54 Set 1 trim mix See parameter 40.54 Set 1 trim mix. 0.000  ### 41.55 Set 1 trim adjust See parameter 40.55 Set 1 trim adjust. 1.000  ### 41.56 Set 1 trim source See parameter 40.56 Set 1 trim source. PID ref  ### 41.60 PID set1/set2 See parameter 40.60 Set 1 PID activation source. On  ### 56 Set 1 trim source See parameter 40.60 Set 1 PID activation source. On  ### 57 See also section Brake chopper (page 120).  ### 58 Settings for the internal brake chopper. See also section Brake chopper (page 120).  ### 58 Braking resistor temperature  ### 58 Displays the estimated temperature of the brake resistor, or how close the brake resistor is hot. The value is given in percent, where 100% is the eventual temperature that the resistor will reach when loaded long enough with its rated maximum load capacity (43.09 Brake resistor Pmax cont). Temperature calculation is based on the values defined in parameters 43.08, 43.09 and 43.10, and on the assumption that the resistor is installed as instructed by the manufacturer (i.e., it cools down as expected). This parameter is read-only.  #### 50.0 120.0% Estimated brake resistor temperature.  #### 50.0 120.0% Estimated brake resistor temperature.  #### 50.0 120.0% Estimated brake chopper control.  ### Note: Before enabling brake chopper control, ensure that  ### 60.00 120.0% Estimated correctly.	41.52	Set 1 trim selection	See parameter 40.52 Set 1 trim selection.	Torque
41.55 Set 1 trim adjust  See parameter 40.55 Set 1 trim adjust.  1.000  41.56 Set 1 trim source  See parameter 40.56 Set 1 trim source.  PID ref  41.60 PID set1/set2 See parameter 40.60 Set 1 PID activation source.  See parameter 40.60 Set 1 PID activation source.  On  Settings for the internal brake chopper. See also section Brake chopper (page 120).  Displays the estimated temperature of the brake resistor, or how close the brake resistor is hot. The value is given in percent, where 100% is the eventual temperature that the resistor will reach when loaded long enough with its rated maximum load capacity (43.09 Brake resistor Pmax cont).  Temperature calculation is based on the values defined in parameters 43.08, 43.09 and 43.10, and on the assumption that the resistor is installed as instructed by the manufacturer (i.e., it cools down as expected).  This parameter is read-only.  O.0 120.0%  Estimated brake resistor temperature.  1 = 1%  43.06 Brake chopper function  Note: Before enabling brake chopper control, ensure that  • a brake resistor is connected  • the supply voltage range (parameter 95.01 Supply voltage) has been selected correctly.	41.53		See parameter 40.53 Set 1 trimmed ref pointer.	Not selected
41.56 Set 1 trim source See parameter 40.56 Set 1 trim source.  41.60 PID set1/set2 selection  See parameter 40.60 Set 1 PID activation source.  On  Settings for the internal brake chopper. See also section Brake chopper (page 120).  Displays the estimated temperature of the brake resistor, or how close the brake resistor is hot. The value is given in percent, where 100% is the eventual temperature that the resistor will reach when loaded long enough with its rated maximum load capacity (43.09 Brake resistor Pmax cont). Temperature calculation is based on the values defined in parameters 43.08, 43.09 and 43.10, and on the assumption that the resistor is installed as instructed by the manufacturer (i.e., it cools down as expected). This parameter is read-only.  O.0 120.0%  Estimated brake resistor temperature.  1 = 1%  43.06 Brake chopper function  Note: Before enabling brake chopper control, ensure that  • a brake resistor is connected  • the supply voltage range (parameter 95.01 Supply voltage) has been selected correctly.	41.54	Set 1 trim mix	See parameter 40.54 Set 1 trim mix.	0.000
41.60 PID set1/set2 selection  See parameter 40.60 Set 1 PID activation source.  On  43 Brake chopper  Settings for the internal brake chopper. See also section Brake chopper (page 120).  Displays the estimated temperature of the brake resistor, or how close the brake resistor is hot. The value is given in percent, where 100% is the eventual temperature that the resistor will reach when loaded long enough with its rated maximum load capacity (43.09 Brake resistor Pmax cont). Temperature calculation is based on the values defined in parameters 43.08, 43.09 and 43.10, and on the assumption that the resistor is installed as instructed by the manufacturer (i.e., it cools down as expected). This parameter is read-only.  O.0 120.0%  Estimated brake resistor temperature.  1 = 1%  Note: Before enabling brake chopper control, ensure that  a brake resistor is connected  the supply voltage range (parameter 95.01 Supply voltage) has been selected correctly.	41.55	Set 1 trim adjust	See parameter 40.55 Set 1 trim adjust.	1.000
### Selection    Settings for the internal brake chopper.   See also section *Brake chopper* (page 120).	41.56	Set 1 trim source	See parameter 40.56 Set 1 trim source.	PID ref
See also section Brake chopper (page 120).  Displays the estimated temperature of the brake resistor, or how close the brake resistor is hot.  The value is given in percent, where 100% is the eventual temperature that the resistor will reach when loaded long enough with its rated maximum load capacity (43.09 Brake resistor Pmax cont).  Temperature calculation is based on the values defined in parameters 43.08, 43.09 and 43.10, and on the assumption that the resistor is installed as instructed by the manufacturer (i.e., it cools down as expected).  This parameter is read-only.  Disabled  Seake chopper function  Brake chopper function  Note: Before enabling brake chopper control, ensure that  a brake resistor is connected  the supply voltage range (parameter 95.01 Supply voltage) has been selected correctly.	41.60		See parameter 40.60 Set 1 PID activation source.	On
how close the brake resistor is hot.  The value is given in percent, where 100% is the eventual temperature that the resistor will reach when loaded long enough with its rated maximum load capacity (43.09 Brake resistor Pmax cont).  Temperature calculation is based on the values defined in parameters 43.08, 43.09 and 43.10, and on the assumption that the resistor is installed as instructed by the manufacturer (i.e., it cools down as expected).  This parameter is read-only.  Disabled  Note: Before enabling brake chopper control, ensure that  a brake resistor is connected  the supply voltage range (parameter 95.01 Supply voltage) has been selected correctly.	43 Bra	ike chopper		
43.06 Brake chopper function  Enables brake chopper control.  Note: Before enabling brake chopper control, ensure that  a brake resistor is connected  the supply voltage range (parameter 95.01 Supply voltage) has been selected correctly.	43.01		how close the brake resistor is hot.  The value is given in percent, where 100% is the eventual temperature that the resistor will reach when loaded long enough with its rated maximum load capacity (43.09 Brake resistor Pmax cont).  Temperature calculation is based on the values defined in parameters 43.08, 43.09 and 43.10, and on the assumption that the resistor is installed as instructed by the manufacturer (i.e., it cools down as expected).	-
<ul> <li>Note: Before enabling brake chopper control, ensure that</li> <li>a brake resistor is connected</li> <li>the supply voltage range (parameter 95.01 Supply voltage) has been selected correctly.</li> </ul>		0.0 120.0%	Estimated brake resistor temperature.	1 = 1%
Disabled Brake chopper control disabled. 0	43.06		<ul> <li>Note: Before enabling brake chopper control, ensure that</li> <li>a brake resistor is connected</li> <li>the supply voltage range (parameter 95.01 Supply</li> </ul>	Disabled
		Disabled	Brake chopper control disabled.	0

No.	Name/Value	Description	Def/FbEq16
	Enabled with thermal model	Brake chopper control enabled with resistor overload protection.  Note: Before using this setting, ensure that overvoltage control is switched off (parameter 30.30 Overvoltage control).	1
	Enabled without thermal model	Brake chopper control enabled without resistor overload protection. This setting can be used, for example, if the resistor is equipped with a thermal circuit breaker that is wired to stop the drive if the resistor overheats.  Note: Before using this setting, ensure that overvoltage control is switched off (parameter 30.30 Overvoltage control).	2
	Overvoltage peak protection	Brake chopper starts to conduct at 100% pulse width whenever  • the DC voltage exceeds the overvoltage fault limit (a hysteresis applies), and  • the drive is not modulating (for example, during a coast stop).  The thermal model-based resistor overload protection is not active.  This setting is intended for situations where  • the braking chopper is not needed for runtime operation, that is to dissipate the inertial energy of the motor,  • the motor is able to store a considerable amount of magnetic energy in its windings, and  • the motor might, deliberately or inadvertently, be stopped by coasting.  In such a situation, the motor potentially discharges enough magnetic energy towards the drive to cause damage. To protect the drive, the brake chopper can be used with a small resistor dimensioned merely to handle the magnetic energy (not the inertial energy) of the motor.  With this setting, the brake chopper is activated only whenever the DC voltage exceeds the overvoltage limit. During normal use, the brake chopper is not operating.	3
43.07	Brake chopper run enable	Selects the source for quick brake chopper on/off control.  0 = Brake chopper IGBT pulses are cut off  1 = Normal brake chopper IGBT modulation.  This parameter can be used to program the chopper control to function only when the supply is missing from a drive with a regenerative supply unit.	On
	Off	0.	0
	On	1.	1
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
43.08	Brake resistor thermal tc	Defines the thermal time constant of the brake resistor for overload protection.	0 s
	0 10000 s	Brake resistor thermal time constant.	1 = 1 s
43.09	Brake resistor Pmax cont	Defines the maximum continuous braking power of the resistor (in kW) which will raise the resistor temperature to the maximum allowed value. The value is used in the overload protection.	0.00 kW
	0.00 10000.00 kW	Maximum continuous braking power.	1 = 1 kW

No.	Name/Value		Descri	ption	Def/FbEq1
43.10	Brake re	esistance		s the resistance value of the brake resistor. The value of the brake chopper protection.	0.0 ohm
	0.010	00.0 ohm	Brake	resistor resistance value.	1 = 1 ohm
43.11	Brake resistor fault limit		protect trips or The va reache	is the fault limit for the brake resistor temperature tion function. When the limit is exceeded, the drive in fault 7183 BR excess temperature.  Is given in percent of the temperature the resistor is when loaded with the power defined by parameter Brake resistor Pmax cont.	105%
	0 150	)%	Brake	resistor temperature fault limit.	1 = 1%
43.12		Brake resistor swarning limit p		is the warning limit for the brake resistor temperature tion function. When the limit is exceeded, the drive ates a <i>A793 BR excess temperature</i> warning. It is given in percent of the temperature the resistor as when loaded with the power defined by parameter <i>Brake resistor Pmax cont</i> .	95%
	0 150	)%	Brake	resistor temperature warning limit.	1 = 1%
<b>44 Me</b> <b>contro</b> <b>44</b> .01	chanical brake ol  Brake control status		See al	uration of mechanical brake control. so section <i>Mechanical brake control</i> (page 112).  ys the mechanical brake control status word. arameter is read-only.	-
	Bit	Name		Information	
	0	Open command		Close/open command to brake actuator (0 = close, 1 = open). Connect this bit to desired output.	
	1	Opening to request	rque	1 = Opening torque requested from drive logic	
	2 Hold stop			1 = Hold requested from drive logic	
		request	ea	1 - Hold requested from drive logic	
	3			1 = Ramping down to zero speed requested from driv	e logic
	4	request  Ramp to sto  Enabled		1 = Ramping down to zero speed requested from driv 1 = Brake control is enabled	e logic
	4 5	request  Ramp to sto  Enabled  Closed		1 = Ramping down to zero speed requested from driv 1 = Brake control is enabled 1 = Brake control logic in BRAKE CLOSED state	e logic
	4 5 6	request Ramp to sto Enabled Closed Opening		1 = Ramping down to zero speed requested from driv 1 = Brake control is enabled 1 = Brake control logic in BRAKE CLOSED state 1 = Brake control logic in BRAKE OPENING state	e logic
	4 5 6 7	request  Ramp to sto  Enabled  Closed  Opening  Open		1 = Ramping down to zero speed requested from driv 1 = Brake control is enabled 1 = Brake control logic in BRAKE CLOSED state 1 = Brake control logic in BRAKE OPENING state 1 = Brake control logic in BRAKE OPEN state	e logic
	4 5 6	request Ramp to sto Enabled Closed Opening		1 = Ramping down to zero speed requested from driv 1 = Brake control is enabled 1 = Brake control logic in BRAKE CLOSED state 1 = Brake control logic in BRAKE OPENING state	e logic
	4 5 6 7 8	request Ramp to sto Enabled Closed Opening Open Closing		1 = Ramping down to zero speed requested from driv 1 = Brake control is enabled 1 = Brake control logic in BRAKE CLOSED state 1 = Brake control logic in BRAKE OPENING state 1 = Brake control logic in BRAKE OPEN state	e logic
	4 5 6 7 8	request Ramp to sto Enabled Closed Opening Open Closing Reserved	opped	1 = Ramping down to zero speed requested from driv 1 = Brake control is enabled 1 = Brake control logic in BRAKE CLOSED state 1 = Brake control logic in BRAKE OPENING state 1 = Brake control logic in BRAKE OPEN state	e logic
44.02	4 5 6 7 8 915	request Ramp to sto Enabled Closed Opening Open Closing Reserved	Mecha Display brake of This vatorque and 44 A filteri	1 = Ramping down to zero speed requested from driv 1 = Brake control is enabled 1 = Brake control logic in BRAKE CLOSED state 1 = Brake control logic in BRAKE OPENING state 1 = Brake control logic in BRAKE OPEN state 1 = Brake control logic in BRAKE CLOSING state	

No. Name/Value Description		Description	Def/FbEq16
44.03	Brake open torque reference	Displays the currently active brake open torque. See parameters 44.09 Brake open torque source and 44.10 Brake open torque.	-
		This parameter is read-only.	
	-1600.0 1600.0%	Currently active brake open torque.	See par. 46.03
44.06	Brake control enable	Activates/deactivates (or selects a source that activates/deactivates) the mechanical brake control logic.  0 = Brake control inactive  1 = Brake control active  Note: This parameter cannot be changed while the drive is running.	Not selected
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
44.07	Brake acknowledge selection	Activates/deactivates (and selects the source for) brake open/close status (acknowledgment) supervision.  When a brake control error (unexpected state of the acknowledgment signal) is detected, the drive reacts as defined by parameter 44.17 Brake fault function.  0 = Brake closed 1 = Brake open	No acknowledge
	Off	0.	0
	On	1.	1
	No acknowledge	Brake open/closed supervision disabled.	2
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	3
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	4
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	5
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	6
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	7
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	8
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	11
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	12
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-

No.	Name/Value	Description	Def/FbEq16
44.08	Defines the brake open delay, i.e. the delay between the internal open brake command and the release of motor speed control. The delay timer starts when the drive has magnetized the motor and increased the motor torque to the level required for brake release (parameter 44.03 Brake open torque reference). Simultaneously with the timer start the brake control logic energizes the brake control output and the brake starts to open.  Set this parameter to the value of mechanical opening dela specified by the brake manufacturer.		0.00 s
	0.00 5.00 s	Brake open delay.	100 = 1 s
44.09	Brake open torque source	Defines a source that is used as a brake opening torque reference if  • its absolute value is greater than the setting of parameter 44.10 Brake open torque, and  • its sign is the same as the setting of 44.10 Brake open torque.  See parameter 44.10 Brake open torque.	Brake open torque
	Zero	Zero.	0
	Al1 scaled	12.12 Al1 scaled value (see page 207).	1
	Al2 scaled	12.22 Al2 scaled value (see page 208).	2
	FBA ref1	03.05 FB A reference 1 (see page 165).	3
	FBA ref2	03.06 FB A reference 2 (see page 165).	4
	Brake torque memory	Parameter 44.02 Brake torque memory.	7
	Brake open torque	Parameter 44.10 Brake open torque.	8
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
44.10	Brake open torque	Defines the sign (i.e. direction of rotation) and minimum absolute value of the brake open torque (motor torque requested at brake release in percent of motor nominal torque).  The value of the source selected by parameter 44.09 Brake open torque source is used as the brake open torque only if it has the same sign as this parameter and has a greater absolute value.  Note: This parameter is not effective in scalar motor control mode.	0.0%
	-1600.0 1600.0%	Minimum torque at brake release.	See par. 46.03
44.11	Keep brake closed	Selects a source that prevents the brake from opening.  0 = Normal brake operation  1 = Keep brake closed  Note: This parameter cannot be changed while the drive is running.	Not selected
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5

No.	Name/Value	Description	Def/FbEq16
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
44.12	<ul> <li>Brake close request</li> <li>Selects the source of an external brake close request signal When on, the signal overrides the internal logic and closes the brake.</li> <li>0 = Normal operation/No external close signal connected 1 = Close brake</li> <li>Notes:</li> <li>In an open-loop (encoder-less) application, if the brake is kept closed by a brake close request against a modulating drive for longer than 5 seconds, the brake is forced to close and the drive trips on a fault, 71A5 Mechanical brake opening not allowed.</li> <li>This parameter cannot be changed while the drive is running.</li> </ul>		Not selected
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
44.13	Brake close delay	Defines a delay between a close command (that is, when the brake control output is de-energized) and when the drive stops modulating. This is to keep the motor live and under control until the brake actually closes.  Set this parameter equal to the value specified by the brake manufacturer as the mechanical make-up time of the brake.	0.00 s
	0.00 60.00 s	Brake close delay.	100 = 1 s
44.14	Brake close level	Defines the brake close speed as an absolute value.  After motor speed remains below this level for the duration of the brake close level delay (44.15 Brake close level delay), a close command is given.  Note: Check the compatibility of this setting with 21.03 Stop mode (and the applicable deceleration time).	10.00 rpm
	0.00 1000.00 rpm	Brake close speed.	See par. 46.01
44.15	Brake close level delay	Defines a brake close level delay. See parameter 44.14 Brake close level.	0.00 s
	0.00 10.00 s	Brake close level delay.	100 = 1 s

No.	Name/Value	Description	Def/FbEq16
44.16	Brake reopen delay	Defines a minimum time between brake closure and a subsequent open command.	0.00 s
	0.00 10.00 s	Brake reopen delay.	100 = 1 s
44.17	Brake fault function	<ul> <li>Determines how the drive reacts upon a mechanical brake control error.</li> <li>Note: If parameter 44.07 Brake acknowledge selection is set to No acknowledge, acknowledgment status supervision is disabled altogether and will generate no warnings or faults. However, the brake open conditions are always supervised.</li> </ul>	
	Fault	The drive trips on a 71A2 Mechanical brake closing failed / 71A3 Mechanical brake opening failed fault if the status of the acknowledgment does not match the status presumed by the brake control logic.  The drive trips on a 71A5 Mechanical brake opening not allowed fault if the brake open conditions cannot be fulfilled (for example, the required motor starting torque is not achieved).	0
	Warning	The drive generates a A7A1 Mechanical brake closing failed / A7A2 Mechanical brake opening failed warning if the status of the acknowledgment does not match the status presumed by the brake control logic.  The drive generates a A7A5 Mechanical brake opening not allowed warning if the brake open conditions cannot be fulfilled (for example, the required motor starting torque is not achieved).	1
	Open fault	Upon closing the brake, the drive generates a A7A1  Mechanical brake closing failed warning if the status of the acknowledgment does not match the status presumed by the brake control logic.  Upon opening the brake, the drive trips on a 71A3  Mechanical brake opening failed fault if the status of the acknowledgment does not match the status presumed by the brake control logic.  The drive trips on a 71A5 Mechanical brake opening not allowed fault if the brake open conditions cannot be fulfilled (for example, the required motor starting torque is not achieved).	2
44.18	Brake fault delay	Defines a close fault delay, i.e. time between brake closure and brake close fault trip.	0.00 s
	0.00 60.00 s	Brake close fault delay.	100 = 1 s
44.21	Filter time brake torque memory	Defines a filtering time for parameter 44.02 Brake torque memory (actual torque value used as open torque reference).	100 ms
	0100 ms	Filtering time.	100 = 1 ms
45 En	ergy efficiency	Settings for the energy saving calculators. See also section <i>Energy saving calculators</i> (page <i>131</i> ).	
45.01	Saved GW hours	Displays the energy saved in GWh compared to direct-on-line motor connection. This parameter is incremented when 45.02 Saved MW hours rolls over.  This parameter is read-only (see parameter 45.21 Energy calculations reset).	-
	065535 GWh	Energy savings in GWh.	1 = 1 GWh

No.	Name/Value	Description	Def/FbEq16
45.02	Saved MW hours	Displays the energy saved in MWh compared to direct-on- line motor connection. This parameter is incremented when 45.03 Saved kW hours rolls over. When this parameter rolls over, parameter 45.01 Saved GW hours is incremented. This parameter is read-only (see parameter 45.21 Energy calculations reset).	-
	0999 MWh	Energy savings in MWh.	1 = 1 MWh
45.03	Saved kW hours	Displays the energy saved in kWh compared to direct-on-line motor connection.  If the internal brake chopper of the drive is enabled, all energy fed by the motor to the drive is assumed to be converted into heat, but the calculation still records savings made by controlling the speed. If the chopper is disabled, then regenerated energy from the motor is also recorded here.  When this parameter rolls over, parameter 45.02 Saved MW hours is incremented.  This parameter is read-only (see parameter 45.21 Energy calculations reset).	-
	0.0 999.9 kWh	Energy savings in kWh.	10 = 1 kWh
45.05	Saved money x1000	Displays the monetary savings in thousands compared to direct-on-line motor connection. This parameter is incremented when 45.06 Saved money rolls over.  The currency is defined by parameter 45.17 Tariff currency unit.  This parameter is read-only (see parameter 45.21 Energy calculations reset).	-
	04294967295 thousands	Monetary savings in thousands of units.	-
45.06	Saved money	Displays the monetary savings compared to direct-on-line motor connection. This value is a calculated by multiplying the saved energy in kWh by the currently active energy tariff (45.14 Tariff selection).  When this parameter rolls over, parameter 45.05 Saved money x1000 is incremented.  The currency is defined by parameter 45.17 Tariff currency unit.  This parameter is read-only (see parameter 45.21 Energy calculations reset).	-
	0.00 999.99 units	Monetary savings.	1 = 1 unit
45.08	CO2 reduction in kilotons	Displays the reduction in CO <sub>2</sub> emissions in metric kilotons compared to direct-on-line motor connection. This value is incremented when parameter <i>45.09 CO2 reduction in tons</i> rolls over.  This parameter is read-only (see parameter <i>45.21 Energy calculations reset</i> ).	-
	065535 metric kilotons	Reduction in CO <sub>2</sub> emissions in metric kilotons.	1 = 1 metric kiloton

No. Name/Value Description		Description	Def/FbEq16
45.09	CO2 reduction in tons	Displays the reduction in CO <sub>2</sub> emissions in metric tons compared to direct-on-line motor connection. This value is calculated by multiplying the saved energy in MWh by the value of parameter 45.18 CO <sub>2</sub> conversion factor (by default, 0.5 metric tons/MWh).	-
		When this parameter rolls over, parameter 45.08 CO2 reduction in kilotons is incremented.	
		This parameter is read-only (see parameter 45.21 Energy calculations reset).	
	0.0 999.9 metric tons	Reduction in CO <sub>2</sub> emissions in metric tons.	1 = 1 metric ton
45.11	Energy optimizer	Enables/disables the energy optimization function. The function optimizes the motor flux so that total energy consumption and motor noise level are reduced when the drive operates below the nominal load. The total efficiency (motor and drive) can be improved by 120% depending on load torque and speed.  Note: With a permanent magnet motor or a synchronous reluctance motor, energy optimization is always enabled regardless of this parameter.	
	Disable	Energy optimization disabled.	0
	Enable	Energy optimization enabled.	1
45.12	Energy tariff 1	Defines energy tariff 1 (price of energy per kWh). Depending on the setting of parameter 45.14 Tariff selection, either this value or 45.13 Energy tariff 2 is used for reference when monetary savings are calculated.  The currency is defined by parameter 45.17 Tariff currency unit.  Note: Tariffs are read only at the instant of selection, and are	1.000 units
	0.000	not applied retroactively.	
	0.000 4294967.295 units	Energy tariff 1.	-
45.13	Energy tariff 2	Defines energy tariff 2 (price of energy per kWh). See parameter 45.12 Energy tariff 1.	2.000 units
	0.000 4294967.295 units	Energy tariff 2.	-
45.14	Tariff selection	Selects (or defines a source that selects) which pre-defined energy tariff is used.  0 = 45.12 Energy tariff 1 1 = 45.13 Energy tariff 2	Energy tariff 1
	Energy tariff 1	0.	0
	Energy tariff 2	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11

No. Name/Value Description		Description	Def/FbEq16
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
45.17	Tariff currency unit	Specifies the currency used for the savings calculations.	EUR
	Local currency	Local currency. The name of the currency can be edited by choosing <b>Menu - Settings - Edit texts</b> on the control panel.	100
	EUR	Euro.	101
	USD	US dollar.	102
45.18	CO2 conversion factor	Defines a factor for conversion of saved energy into CO <sub>2</sub> emissions (kg/kWh or tn/MWh).	0.500 tn/MWh
	0.000 65.535 tn/MWh	Factor for conversion of saved energy into CO <sub>2</sub> emissions.	1 = 1 tn/MWh
45.19	Comparison power	Actual power that the motor absorbs when connected direct- on-line and operating the application. The value is used for reference when energy savings are calculated.  Note: The accuracy of the energy savings calculation is directly dependent on the accuracy of this value. If nothing is entered here, then the nominal motor power is used by the calculation, but that may inflate the energy savings reported as many motors do not absorb nameplate power.	0.0 kW
	0.0 100000.0 kW	Motor power.	See par. 46.04.
45.21	Energy calculations reset	Resets the savings counter parameters 45.0145.09.	Done
	Done	Reset not requested (normal operation), or reset complete.	0
	Reset	Reset the savings counter parameters. The value reverts automatically to <i>Done</i> .	1
46 Mo. setting	nitoring/scaling gs	Speed supervision settings; actual signal filtering; general scaling settings.  Note: The 16-bit scalings apply when parameter values are read or written directly. With protocol- and profile-specific read/write commands (eg. communication objects), the scaling depends on the protocol or profile. See the documentation of the adapter module.	
46.01	Speed scaling	Defines the maximum speed value used to define the acceleration ramp rate and the initial speed value used to define the deceleration ramp rate (see parameter group 23 Speed reference ramp). The speed acceleration and deceleration ramp times are therefore related to this value (not to parameter 30.12 Maximum speed).  Also defines the 16-bit scaling of speed-related parameters. The value of this parameter corresponds to 20000 in fieldbus, master/follower etc. communication.	
	0.10 30000.00 rpm	Acceleration/deceleration terminal/initial speed.	1 = 1 rpm
accele to defi  Freque and de value o Also d param		Defines the maximum frequency value used to define the acceleration ramp rate and the initial frequency value used to define deceleration ramp rate (see parameter group 28 Frequency reference chain). The frequency acceleration and deceleration ramp times are therefore related to this value (not to parameter 30.14 Maximum frequency). Also defines the 16-bit scaling of frequency-related parameters. The value of this parameter corresponds to 20000 in fieldbus, master/follower etc. communication.	50.00 Hz; 60.00 Hz (95.20 b0)

No. Name/Value Description		Def/FbEq16	
	0.10 1000.00 Hz	Acceleration/deceleration terminal/initial frequency.	10 = 1 Hz
46.03	Torque scaling	Defines the 16-bit scaling of torque parameters. The value of this parameter (in percent of nominal motor torque) corresponds to 10000 in fieldbus, master/follower etc. communication.	100.0%
	0.1 1000.0%	Torque corresponding to 10000 on fieldbus.	10 = 1%
		Defines the output power value that corresponds to 10000 in fieldbus, master/follower etc. communication. The unit is selected by parameter <i>96.16 Unit selection</i> .	1000.00 kW or hp
	0.10 30000.00 kW or 0.10 40214.48 hp	Power corresponding to 10000 on fieldbus.	1 = 1 unit
46.05	Current scaling	Defines the 16-bit scaling of current parameters. The value of this parameter corresponds to 10000 in fieldbus, master/follower etc. communication.	10000 A
	030000 A	Current corresponding to 10000 on fieldbus.	1 = 1 A
46.06	Speed ref zero scaling	Defines a speed corresponding to a zero reference received from fieldbus (either the embedded fieldbus interface, or interface FBAA or FBAB). For example, with a setting of 500, the fieldbus reference range of 020000 would correspond to a speed of 500[46.01] rpm.  Note: This parameter is effective only with the ABB Drives communication profile.	0.00 rpm
	0.00 30000.00 rpm	Speed corresponding to minimum fieldbus reference.	1 = 1 rpm
46.07	Frequency ref zero scaling	Defines a frequency corresponding to a zero reference received from fieldbus (either the embedded fieldbus interface, or interface FBAA or FBAB). For example, with a setting of 30, the fieldbus reference range of 020000 would correspond to a speed of 30[46.02] Hz.  Note: This parameter is effective only with the ABB Drives communication profile.	0.00 Hz
	0.00 1000.00 Hz	Frequency corresponding to minimum fieldbus reference.	10 = 1 Hz
46.11	Filter time motor speed	Defines a filter time for signals 01.01 Motor speed used, 01.02 Motor speed estimated, 01.04 Encoder 1 speed filtered and 01.05 Encoder 2 speed filtered.	500 ms
	220000 ms	Motor speed signal filter time.	1 = 1 ms
46.12	Filter time output frequency	Defines a filter time for signal 01.06 Output frequency.	500 ms
	220000 ms	Output frequency signal filter time.	1 = 1 ms
46.13	Filter time motor torque	Defines a filter time for signal 01.10 Motor torque.	100 ms
	220000 ms	Motor torque signal filter time.	1 = 1 ms
46.14	Filter time power out	Defines a filter time for signal 01.14 Output power.	100 ms
	220000 ms	Output power signal filter time.	1 = 1 ms

No.	Name/Value	Description	Def/FbEq16
46.21	At speed hysteresis	Defines the "at setpoint" limits for speed control of the drive.  When the absolute difference between reference (22.87  Speed reference act 7) and actual speed (90.01 Motor speed for control) becomes smaller than half this parameter value, the drive is considered to be "at setpoint". This is indicated by bit 8 of 06.11 Main status word.  The bit switches off when the absolute difference between reference and actual speed exceeds the value of 46.21 At speed hysteresis.  90.01 (rpm)  Hysteresis  90.01 (rpm)  22.87 + 46.21 (rpm)  22.87 - 0.5 × 46.21 (rpm)  Hysteresis  0 rpm	100.00 rpm
	0.00 30000.00 rpm	Limit for "at setpoint" indication in speed control.	See par. 46.01
46.22	At frequency hysteresis	Defines the "at setpoint" limits for frequency control of the drive. When the absolute difference between reference (28.96 Frequency ref ramp input) and actual frequency (01.06 Output frequency) is smaller than 46.22 At frequency hysteresis, the drive is considered to be "at setpoint". This is indicated by bit 8 of 06.11 Main status word.  O1.06 (Hz)  Drive at setpoint (06.11 bit 8 = 1)  Drive at setpoint (06.11 bit 8 = 1)  O Hz	10.00 Hz
	0.00 1000.00 Hz	Limit for "at setpoint" indication in frequency control.	See par. 46.02

No.	Name/Value	Description	Def/FbEq16
46.23	At torque hysteresis	Defines the "at setpoint" limits for torque control of the drive. When the absolute difference between reference (26.73 Torque reference act 4) and actual torque (01.10 Motor torque) is smaller than 46.23 At torque hysteresis, the drive is considered to be "at setpoint". This is indicated by bit 8 of 06.11 Main status word.  01.10 (%)	10.0%
		Drive at setpoint (06.11 bit 8 = 1)  Drive at setpoint (26.73 + 46.23 (%)  26.73 - 46.23 (%)  0%	
	0.0 300.0%	Limit for "at setpoint" indication in torque control.	See par. 46.03
46.31	Above speed limit	Defines the trigger level for "above limit" indication in speed control. When actual speed exceeds the limit, bit 10 of 06.17 Drive status word 2 is set.	1500.00 rpm
	0.00 30000.00 rpm	"Above limit" indication trigger level for speed control.	See par. 46.01
46.32	Above frequency limit	Defines the trigger level for "above limit" indication in frequency control. When actual frequency exceeds the limit, bit 10 of <i>06.17 Drive status word 2</i> is set.	50.00 Hz
	0.00 1000.00 Hz	"Above limit" indication trigger level for frequency control.	See par. 46.02
46.33	Above torque limit	Defines the trigger level for "above limit" indication in torque control. When actual torque exceeds the limit, bit 10 of 06.17 Drive status word 2 is set.	300.0%
	0.0 1600.0%	"Above limit" indication trigger level for torque control.	See par. 46.03
46.42	Torque decimals	Defines the number of decimal places of torque-related parameters.	1
	02	Number of decimal places of torque parameters.	1 = 1

No.	Name/Value	Description	Def/FbEq16
47 Dat	a storage	Data storage parameters that can be written to and read from using other parameters' source and target settings.  Note that there are different storage parameters for different data types. Integer-type storage parameters cannot be used as the source of other parameters.  See also section <i>Data storage parameters</i> (page 135).	
47.01	Data storage 1 real32	Data storage parameter 1.  Parameters 47.0147.08 are real 32-bit numbers that can be used as source values of other parameters.  Storage parameters 47.0147.08 can be used as the target of received 16-bit data (parameter group 62 D2D and DDCS receive data) or the source of transmitted 16-bit data (parameter group 61 D2D and DDCS transmit data). The scaling and range are defined by parameters 47.3147.38.	0.000
	See par. 47.31	32-bit real (floating point) number.	See par. 47.31
47.02	Data storage 2 real32	Data storage parameter 2. See also parameter 47.01 Data storage 1 real32.	0.000
	See par. 47.32	32-bit real (floating point) number.	See par. 47.32
47.03	Data storage 3 real32	Data storage parameter 3. See also parameter 47.01 Data storage 1 real32.	0.000
	See par. 47.33	32-bit real (floating point) number.	See par. 47.33
47.04	Data storage 4 real32	Data storage parameter 4. See also parameter 47.01 Data storage 1 real32.	0.000
	See par. 47.34	32-bit real (floating point) number.	See par. 47.34
47.05	Data storage 5 real32	Data storage parameter 5. See also parameter 47.01 Data storage 1 real32.	0.000
	See par. 47.35	32-bit real (floating point) number.	See par. 47.35
47.06	Data storage 6 real32	Data storage parameter 6. See also parameter 47.01 Data storage 1 real32.	0.000
	See par. 47.36	32-bit real (floating point) number.	See par. 47.36
47.07	Data storage 7 real32	Data storage parameter 7. See also parameter 47.01 Data storage 1 real32.	0.000
	See par. 47.37	32-bit real (floating point) number.	See par. 47.37
47.08	Data storage 8 real32	Data storage parameter 8. See also parameter 47.01 Data storage 1 real32.	0.000
	See par. 47.38	32-bit real (floating point) number.	See par. 47.38
47.11	Data storage 1 int32	Data storage parameter 9.	0
	-2147483648 2147483647	32-bit integer.	-

No.	Name/Value	Description	Def/FbEq16
47.12	Data storage 2 int32	Data storage parameter 10.	0
	-2147483648 2147483647	32-bit integer.	-
47.13	Data storage 3 int32	Data storage parameter 11.	0
	-2147483648 2147483647	32-bit integer.	-
47.14	Data storage 4 int32	Data storage parameter 12.	0
	-2147483648 2147483647	32-bit integer.	-
47.15	Data storage 5 int32	Data storage parameter 13.	0
	-2147483648 2147483647	32-bit integer.	-
47.16	Data storage 6 int32	Data storage parameter 14.	0
	-2147483648 2147483647	32-bit integer.	-
47.17	Data storage 7 int32	Data storage parameter 15.	0
	-2147483648 2147483647	32-bit integer.	-
47.18	Data storage 8 int32	Data storage parameter 16.	0
	-2147483648 2147483647	32-bit integer.	-
47.21	Data storage 1 int16	Data storage parameter 17.	0
	-32768 32767	16-bit integer.	1 = 1
47.22	Data storage 2 int16	Data storage parameter 18.	0
	-32768 32767	16-bit integer.	1 = 1
47.23	Data storage 3 int16	Data storage parameter 19.	0
	-32768 32767	16-bit integer.	1 = 1
47.24	Data storage 4 int16	Data storage parameter 20.	0
	-32768 32767	16-bit integer.	1 = 1
47.25	Data storage 5 int16	Data storage parameter 21.	0
	-32768 32767	16-bit integer.	1 = 1
47.26	Data storage 6 int16	Data storage parameter 22.	0
	-32768 32767	16-bit integer.	1 = 1
47.27	Data storage 7 int16	Data storage parameter 23.	0
	-32768 32767	16-bit integer.	1 = 1
47.28	Data storage 8 int16	Data storage parameter 24.	0
	-32768 32767	16-bit integer.	1 = 1

No.	Name/Value	Description	Def/FbEq16
47.31	Data storage 1 real32 type	Defines the scaling of parameter 47.01 Data storage 1 real32 to and from 16-bit integer format. This scaling is used when the data storage parameter is the target of received 16-bit data (defined in parameter group 62 D2D and DDCS receive data), or when the data storage parameter is the source of transmitted 16-bit data (defined in parameter group 61 D2D and DDCS transmit data).  The setting also defines the visible range of the storage parameter.	Unscaled
	Unscaled	Data storage only. Range: -2147483.264 2147473.264.	0
	Transparent	Scaling: 1 = 1. Range: -32768 32767.	1
	General	Scaling: 1 = 100. Range: -327.68 327.67.	2
	Torque	The scaling is defined by parameter <i>46.03 Torque scaling</i> . Range: -1600.0 1600.0.	3
	Speed	The scaling is defined by parameter <i>46.01 Speed scaling</i> . Range: -30000.00 30000.00.	4
	Frequency	The scaling is defined by parameter 46.02 Frequency scaling. Range: -600.00 600.00.	5
47.32	Data storage 2 real32 type	Defines the 16-bit scaling of parameter 47.02 Data storage 2 real32.  See parameter 47.31 Data storage 1 real32 type.	Unscaled
47.33	Data storage 3 real32 type	Defines the 16-bit scaling of parameter 47.03 Data storage 3 real32.  See parameter 47.31 Data storage 1 real32 type.	Unscaled
47.34	Data storage 4 real32 type	Defines the 16-bit scaling of parameter 47.04 Data storage 4 real32.  See parameter 47.31 Data storage 1 real32 type.	Unscaled
47.35	Data storage 5 real32 type	Defines the 16-bit scaling of parameter 47.05 Data storage 5 real32.  See parameter 47.31 Data storage 1 real32 type.	Unscaled
47.36	Data storage 6 real32 type	Defines the 16-bit scaling of parameter 47.06 Data storage 6 real32.  See parameter 47.31 Data storage 1 real32 type.	Unscaled
47.37	Data storage 7 real32 type	Defines the 16-bit scaling of parameter 47.07 Data storage 7 real32.  See parameter 47.31 Data storage 1 real32 type.	Unscaled
47.38	Data storage 8 real32 type	Defines the 16-bit scaling of parameter 47.08 Data storage 8 real32.  See parameter 47.31 Data storage 1 real32 type.	Unscaled
			1

	nel port unication	Communication settings for the control panel port on the drive.	
49.01	Node ID number	Defines the node ID of the drive. All devices connected to the network must have a unique node ID.  Note: For networked drives, it is advisable to reserve ID 1 for spare/replacement drives.	1
	132	Node ID.	1 = 1
49.03	Baud rate	Defines the transfer rate of the link.	230.4 kbps
	38.4 kbps	38.4 kbit/s.	1
	57.6 kbps	57.6 kbit/s.	2

No. Name/Value		Description	Def/FbEq16
	86.4 kbps	86.4 kbit/s.	3
	115.2 kbps	115.2 kbit/s.	4
	230.4 kbps	230.4 kbit/s.	5
49.04	Communication loss time	Sets a timeout for control panel (or PC tool) communication. If a communication break lasts longer than the timeout, the action specified by parameter 49.05 Communication loss action is taken.	10.0 s
	0.3 3000.0 s	Panel/PC tool communication timeout.	10 = 1 s
49.05	Communication loss action	Selects how the drive reacts to a control panel (or PC tool) communication break when the panel is the active control or reference source. See also parameter 49.08 Secondary comm. loss action.	Fault
	No action	No action taken.	0
	Fault	Drive trips on 7081 Control panel loss.	1
	Last speed	Drive generates an A7EE Control panel loss warning and freezes the speed to the level the drive was operating at. The speed is determined on the basis of actual speed using 850 ms low-pass filtering.  WARNING! Make sure that it is safe to continue operation in case of a communication break.	2
	Speed ref safe	Drive generates an A7EE Control panel loss warning and sets the speed to the speed defined by parameter 22.41 Speed ref safe (or 28.41 Frequency ref safe when frequency reference is used).  WARNING! Make sure that it is safe to continue operation in case of a communication break.	3
	Warning	Drive generates an A7EE Control panel loss warning. This occurs even though no control is expected from the panel (or PC tool).  WARNING! Make sure that it is safe to continue operation in case of a communication break.	5
49.06	Refresh settings	Applies the settings of parameters 49.0149.05. <b>Note:</b> Refreshing may cause a communication break, so reconnecting the drive may be required.	Done
	Done	Refresh done or not requested.	0
	Refresh	Refresh parameters 49.0149.05. The value reverts automatically to <i>Done</i> .	1

No.	Name/Value	Description	Def/FbEq16
49.18 Maximum ext frequency ref panel		Defines a maximum limit for control panel frequency reference in external control.  In local control, the limits in parameter group 30 Limits are in force. See section Local control vs. external control (page 40).	500.00 Hz
	-500.00 500.00 Hz	Maximum frequency reference.	See par. 46.02
49.24 Panel actual source		Selects an actual value to be displayed in the top right corner of the control panel. This parameter is only effective when the control panel is not an active reference source.	Automatic
	Automatic	The active reference is displayed.	0
	Process PID setpoint actual	See parameter 40.03 Process PID setpoint actual (see page 355).	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
50 Fie (FBA)	ldbus adapter	Fieldbus communication configuration. See also chapter <i>Fieldbus control through a fieldbus adapter</i> (page <i>667</i> ).	
50.01	FBA A enable	Enables/disables communication between the drive and fieldbus adapter A, and specifies the slot the adapter is installed into.  Note: This parameter cannot be changed while the drive is running.	Disable
	Disable	Communication between drive and fieldbus adapter A disabled.	0
	Option slot 1	Communication between drive and fieldbus adapter A enabled. The adapter is in slot 1.	1
	Option slot 2	Communication between drive and fieldbus adapter A enabled. The adapter is in slot 2.	2
	Option slot 3	Communication between drive and fieldbus adapter A enabled. The adapter is in slot 3.	3
50.02	FBA A comm loss func	Selects how the drive reacts upon a fieldbus communication break. The time delay is defined by parameter 50.03 FBA A comm loss t out.	No action
	No action	No action taken.	0
	Fault	Communication break detection active. Upon a communication break, the drive trips on a 7510 FBA A communication fault and coasts to a stop.	1
	Last speed	Communication break detection active. Upon a communication break, the drive generates a warning (A7C1 FBA A communication) and freezes the speed to the level the drive was operating at. The speed is determined on the basis of actual speed using 850 ms low-pass filtering.	2

**WARNING!** Make sure that it is safe to continue operation in case of a communication break.

No.	Name/Value	Description	Def/FbEq16
	Speed ref safe	Communication break detection active. Upon a communication break, the drive generates a warning (A7C1 FBA A communication) and sets the speed to the value defined by parameter 22.41 Speed ref safe (when speed reference is being used) or 28.41 Frequency ref safe (when frequency reference is being used).  WARNING! Make sure that it is safe to continue operation in case of a communication break.	3
	Fault always	Drive trips on 7510 FBA A communication. This occurs even though no control is expected from the fieldbus.	4
	Warning	Drive generates an A7C1 FBA A communication warning. This occurs even though no control is expected from the fieldbus.  WARNING! Make sure that it is safe to continue operation in case of a communication break.	5
50.03	FBA A comm loss t out	Defines the time delay before the action defined by parameter 50.02 FBA A comm loss func is taken. Time count starts when the communication link fails to update the message.  As a rule of thumb, this parameter should be set to at least 3 times the transmit interval of the master.  Note: There is a 60-second boot-up delay immediately after power-up. During the delay, communication break monitoring is disabled (but communication itself can be active).	0.3 s
	0.3 6553.5 s	Time delay.	1 = 1 s
50.04	FBA A ref1 type	Selects the type and scaling of reference 1 received from fieldbus adapter A.  Note: Fieldbus-specific communication profiles may use different scalings. For more information, see the manual of the fieldbus adapter.	General
	Auto	Type and scaling are chosen automatically according to which reference chain (see settings <i>Torque</i> , <i>Speed</i> , <i>Frequency</i> ) the incoming reference is connected to. if the reference is not connected to any chain, no scaling is applied (as with setting <i>Transparent</i> ).	0
	Transparent	No scaling is applied (the 16-bit scaling is 1 = 1 unit).	1
	General	Generic reference with a 16-bit scaling of 100 = 1 (i.e. integer and two decimals).	2
	Torque	The scaling is defined by parameter 46.03 Torque scaling.	3
	Speed	The scaling is defined by parameter 46.01 Speed scaling.	4
	Frequency	The scaling is defined by parameter 46.02 Frequency scaling.	5
50.05	FBA A ref2 type	Selects the type and scaling of reference 2 received from fieldbus adapter A. See parameter 50.04 FBA A ref1 type.	General
50.06	FBA A SW sel	Reserved.	-
50.07	FBA A actual 1 type	Selects the type/source and scaling of actual value 1 transmitted to the fieldbus network through fieldbus adapter A.  Note: Fieldbus-specific communication profiles may use different scalings. For more information, see the manual of the fieldbus adapter.	General

No.	Name/Value	Description	Def/FbEq16
	Auto	Type/source and scaling follow the type of reference 1 selected by parameter 50.04 FBA A ref1 type. See the individual settings below for the sources and scalings.	0
	Transparent	The value selected by parameter 50.10 FBA A act1 transparent source is sent as actual value 1. No scaling is applied (the 16-bit scaling is 1 = 1 unit).	1
	General	The value selected by parameter 50.10 FBA A act1 transparent source is sent as actual value 1 with a 16-bit scaling of 100 = 1 unit (i.e. integer and two decimals).	2
	Torque	01.10 Motor torque is sent as actual value 1. The scaling is defined by parameter 46.03 Torque scaling.	3
	Speed	01.01 Motor speed used is sent as actual value 1. The scaling is defined by parameter 46.01 Speed scaling.	4
	Frequency	01.06 Output frequency is sent as actual value 1. The scaling is defined by parameter 46.02 Frequency scaling.	5
	Position	Motor position is sent as actual value 1. See parameter 90.06 Motor position scaled.	6
50.08	FBA A actual 2 type	Selects the type/source and scaling of actual value 2 transmitted to the fieldbus network through fieldbus adapter A.  See parameter 50.07 FBA A actual 1 type.	General
50.09	FBA A SW transparent source	Selects the source of the fieldbus status word when the fieldbus adapter is set to a transparent communication profile, for example, by its configuration parameters in group 51 FBA A settings.	Not selected
	Not selected	No source selected.	-
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
50.10	FBA A act1 transparent source	When parameter 50.07 FBA A actual 1 type is set to Transparent or General, this parameter selects the source of actual value 1 transmitted to the fieldbus network through fieldbus adapter A.	Not selected
	Not selected	No source selected.	-
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
50.11	FBA A act2 transparent source	When parameter 50.08 FBA A actual 2 type is set to Transparent or General, this parameter selects the source of actual value 2 transmitted to the fieldbus network through fieldbus adapter A.	Not selected
	Not selected	No source selected.	-
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
50.12	FBA A debug mode	Enables the display of raw (unmodified) data received from and sent to fieldbus adapter A in parameters 50.1350.18. This functionality should only be used for debugging.  Note: This parameter cannot be changed while the drive is running.	Disable
·	Disable	Display of raw data from fieldbus adapter A disabled.	0
	Fast	Display of raw data from fieldbus adapter A enabled.	1

No.	Name/Value	Description	Def/FbEq16
50.13	FBA A control word	Displays the raw (unmodified) control word sent by the master (PLC) to fieldbus adapter A if debugging is enabled by parameter 50.12 FBA A debug mode.  This parameter is read-only.	-
	0.0.0.0 FF.FF.FF.FF	Control word sent by master to fieldbus adapter A.	-
50.14	FBA A reference 1	Displays raw (unmodified) reference REF1 sent by the master (PLC) to fieldbus adapter A if debugging is enabled by parameter 50.12 FBA A debug mode. This parameter is read-only.	-
	-2147483648 2147483647	Raw REF1 sent by master to fieldbus adapter A.	-
50.15	FBA A reference 2	Displays raw (unmodified) reference REF2 sent by the master (PLC) to fieldbus adapter A if debugging is enabled by parameter 50.12 FBA A debug mode.  This parameter is read-only.	-
	-2147483648 2147483647	Raw REF2 sent by master to fieldbus adapter A.	-
50.16	FBA A status word	Displays the raw (unmodified) status word sent by fieldbus adapter A to the master (PLC) if debugging is enabled by parameter 50.12 FBA A debug mode.  This parameter is read-only.	-
	0.0.0.0 FF.FF.FF.FF	Status word sent by fieldbus adapter A to master.	-
50.17	FBA A actual value 1	Displays raw (unmodified) actual value ACT1 sent by fieldbus adapter A to the master (PLC) if debugging is enabled by parameter 50.12 FBA A debug mode.  This parameter is read-only.	-
	-2147483648 2147483647	Raw ACT1 sent by fieldbus adapter A to master.	-
50.18	FBA A actual value 2	Displays raw (unmodified) actual value ACT2 sent by fieldbus adapter A to the master (PLC) if debugging is enabled by parameter 50.12 FBA A debug mode.  This parameter is read-only.	-
	-2147483648 2147483647	Raw ACT2 sent by fieldbus adapter A to master.	-

No.	Name/V	alue	Descrip	tion			Def/FbEq16
50.21	FBA A ti	melevel sel	In gener CPU loa	al, lower d. The ta te servic	munication time level time levels of read/vable below shows the es for cyclic high and setting.	vrite services reduce time levels of the	Normal
			Select	ion	Cyclic high *	Cyclic low **	
			Monito	ring	10 ms	10 ms	
			Norma	1	2 ms	10 ms	
			Fast		500 µs	2 ms	
			Very fa	ast	250 µs	2 ms	
			Act2.  ** Cyclic paramet and acyc Control vigenerate	low data er group clic data word, Re ed on red nis parar	a consists of the para es 52 FBA A data in a ef1 and Ref2 are hand ceipt of cyclic high me		
	Normal		Normal				0
	Fast Very fast		Fast spe				1
			Very fast speed.		2		
	Monitori			Low speed. Optimized for PC tool communication and monitoring usage.		3	
50.26	FBA A c supervis	omm sion force	each con control of The para commun	ntrol loca on page ameter is nication volumes on progr	ation (see section <i>Loc</i> 40). s primarily intended fo with FBAA when it is ram and not selected	nitoring separately for cal control vs. external or monitoring the connected to the as a control source by	0000b
	Bit	Name	\	/alue			
	0	Ext 1			munication monitorin	g active when Ext 1 is b	eing used.
	1	Ext 2				g active when Ext 2 is b	
	2	Local		1 = Com used.	munication monitorin	g active when local con	trol is being
	315	Reserved					
	0000b	.0111b	FBA A co	ommunio	cation monitoring sele	ection.	1 = 1
50.31		FBA B enable Enable fieldbu installe		/disables adapter into. nis parar	s communication beto B, and specifies the	ween the drive and	Disable
	Disable		Commun		between drive and fie	eldbus adapter B	0
	Option s	slot 1			between drive and ficapter is in slot 1.	eldbus adapter B	1

No. Name/Value		Description	Def/FbEq16
	Option slot 2	Communication between drive and fieldbus adapter B enabled. The adapter is in slot 2.	2
	Option slot 3	Communication between drive and fieldbus adapter B enabled. The adapter is in slot 3.	3
50.32	FBA B comm loss func	Selects how the drive reacts upon a fieldbus communication break. The time delay is defined by parameter 50.33 FBA B comm loss timeout.	No action
	No action	No action taken.	0
	Fault	Communication break detection active. Upon a communication break, the drive trips on a 7520 FBA B communication fault and coasts to a stop.	1
	Last speed	Communication break detection active. Upon a communication break, the drive generates a warning (A7C2 FBA B communication) and freezes the speed to the level the drive was operating at. The speed is determined on the basis of actual speed using 850 ms low-pass filtering.  WARNING! Make sure that it is safe to continue operation in case of a communication break.	2
	Speed ref safe	Communication break detection active. Upon a communication break, the drive generates a warning (A7C2 FBA B communication) and sets the speed to the value defined by parameter 22.41 Speed ref safe (or 28.41 Frequency ref safe when frequency reference is being used).  WARNING! Make sure that it is safe to continue	3
		∠!\ operation in case of a communication break.	
	Fault always	Drive trips on 7520 FBA B communication. This occurs even though no control is expected from the fieldbus.	4
	Warning	Drive generates an A7C2 FBA B communication warning. This occurs even though no control is expected from the fieldbus.  WARNING! Make sure that it is safe to continue operation in case of a communication break.	5
50.33	FBA B comm loss timeout	Defines the time delay before the action defined by parameter 50.32 FBA B comm loss func is taken. Time count starts when the communication link fails to update the message.  As a rule of thumb, this parameter should be set to at least 3 times the transmit interval of the master.  Note: There is a 60-second boot-up delay immediately after power-up. During the delay, communication break monitoring is disabled (but communication itself can be active).	0.3 s
	0.3 6553.5 s	Time delay.	1 = 1 s
50.34	FBA B ref1 type	Selects the type and scaling of reference 1 received from fieldbus adapter B.  See parameter 50.04 FBA A ref1 type.	Auto
50.35	FBA B ref2 type	Selects the type and scaling of reference 2 received from fieldbus adapter B.  See parameter 50.04 FBA A ref1 type.	Auto

No.	Name/Value	Description	Def/FbEq16
50.36	FBA B SW sel	Selects the type/source and scaling of actual value 1 transmitted to the fieldbus network through fieldbus adapter B.	
		See parameter 50.07 FBA A actual 1 type.	
50.37	FBA B actual 1 type	Selects the type/source and scaling of actual value 1 transmitted to the fieldbus network through fieldbus adapter B.  See parameter 50.07 FBA A actual 1 type.	Auto
50.38	FBA B actual 2 type	Selects the type/source and scaling of actual value 2 transmitted to the fieldbus network through fieldbus adapter B.  See parameter 50.08 FBA A actual 2 type.	Auto
50.39	FBA B SW transparent source	Selects the source of the fieldbus status word when the fieldbus adapter is set to a transparent communication profile e.g. by its configuration parameters (group 54 FBA B settings).	Not selected
	Not selected	No source selected.	-
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
50.40	FBA B act1 transparent source	When parameter 50.37 FBA B actual 1 type is set to Transparent or General, this parameter selects the source of actual value 1 transmitted to the fieldbus network through fieldbus adapter B.	Not selected
	Not selected	No source selected.	-
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
50.41	FBA B act2 transparent source	When parameter 50.38 FBA B actual 2 type is set to Transparent or General, this parameter selects the source of actual value 2 transmitted to the fieldbus network through fieldbus adapter B.	Not selected
	Not selected	No source selected.	-
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
50.42	FBA B debug mode	Enables the display of raw (unmodified) data received from and sent to fieldbus adapter B in parameters 50.4350.48. This functionality should only be used for debugging.  Note: This parameter cannot be changed while the drive is running.	Disable
	Disable	Display of raw data from fieldbus adapter B disabled.	0
	Fast	Display of raw data from fieldbus adapter B enabled.	1
50.43	FBA B control word	Displays the raw (unmodified) control word sent by the master (PLC) to fieldbus adapter B if debugging is enabled by parameter 50.42 FBA B debug mode.  This parameter is read-only.	-
	0.0.0.0 FF.FF.FF.FF	Control word sent by master to fieldbus adapter B.	-

No.	Name/Value	Description			Def/FbEq16	
50.44	FBA B reference 1	master (PLC) to	nmodified) reference In fieldbus adapter B if 0.42 FBA B debug mois read-only.	debugging is enabled	-	
	-2147483648 2147483647	<u> </u>	t by master to fieldbus	adapter B.	-	
50.45	FBA B reference 2	Displays raw (u master (PLC) to by parameter 50 This parameter	-			
	-2147483648 2147483647	Raw REF2 sent	t by master to fieldbus	adapter B.	-	
50.46	FBA B status word	adapter B to the	w (unmodified) status versions and the work of the wor	gging is enabled by	-	
	0.0.0.0 FF.FF.FF	Status word ser	nt by fieldbus adapter	B to master.	-	
50.47	FBA B actual value 1	Displays raw (u fieldbus adapted enabled by para This parameter	-			
	-2147483648 2147483647	Raw ACT1 sent	by fieldbus adapter B	to master.	-	
50.48	FBA B actual value 2	fieldbus adapte enabled by para	Displays raw (unmodified) actual value ACT2 sent by fieldbus adapter B to the master (PLC) if debugging is enabled by parameter 50.42 FBA B debug mode.  This parameter is read-only.			
	-2147483648 2147483647	Raw ACT2 sent	-			
50.51	FBA B timelevel sel	Selects the com In general, lowe CPU load. The read/write service each parameter	Normal			
		Selection	Cyclic high *	Cyclic low **		
		Monitoring	10 ms	10 ms		
		Normal	2 ms	10 ms		
		Fast	500 µs	2 ms		
		Very fast	250 µs	2 ms		
		* Cyclic high da and Act2. ** Cyclic low da parameter grou and acyclic data Control word, R				
			eceipt of cyclic high me nmeter cannot be char	essages. Iged while the drive is		
		+				
	Normal	Normal speed.			0	

/ery fast Monitorin	ng	Very fast speed.  Low speed. Optimized for PC tool communication and monitoring usage.	2 3	
BA B co		·	3	
		3 3		
supervisi	omm ion force	Activates fieldbus communication monitoring separately for each control location (see section <i>Local control vs. external control</i> on page <i>40</i> ).  The parameter is primarily intended for monitoring the communication with FBAB when it is connected to the application program and not selected as a control source by drive parameters.		
Bit	Name	Value		
0	Ext 1	1 = Communication monitoring active when Ext 1 is	being used.	
1	Ext 2	1 = Communication monitoring active when Ext 2 is	being used.	
2	Local	1 = Communication monitoring active when local coursed.	ntrol is being	
315	Reserved	1		
0	)	Ext 1 Ext 2 Local	The parameter is primarily intended for monitoring the communication with FBAB when it is connected to the application program and not selected as a control source by drive parameters.    Value	

51 FB/	A A settings	Fieldbus adapter A configuration.	
51.01	FBA A type	Displays the type of the connected fieldbus adapter module. <b>0</b> = Module is not found or is not properly connected, or is disabled by parameter 50.01 FBA A enable; <b>1</b> = FPBA; <b>32</b> = FCAN; <b>37</b> = FDNA; <b>101</b> = FCNA, <b>128</b> = FENA-11/21; <b>135</b> = FENA-11; <b>135</b> = FECA; <b>136</b> = FEPL; <b>485</b> = FSCA.  This parameter is read-only.	-
51.02	FBA A Par2	Parameters 51.0251.26 are adapter module-specific. For more information, see the documentation of the fieldbus adapter module. Note that not all of these parameters are necessarily in use.	-
	065535	Fieldbus adapter configuration parameter.	1 = 1
51.26	FBA A Par26	See parameter 51.02 FBA A Par2.	-
	065535	Fieldbus adapter configuration parameter.	1 = 1
51.27	FBA A par refresh	Validates any changed fieldbus adapter module configuration settings. After refreshing, the value reverts automatically to <i>Done</i> .  Note: This parameter cannot be changed while the drive is running.	Done
	Done	Refreshing done.	0
	Refresh	Refreshing.	1
51.28	FBA A par table ver	Displays the parameter table revision of the fieldbus adapter module mapping file (stored in the memory of the drive). In format axyz, where ax = major table revision number; yz = minor table revision number.  This parameter is read-only.	-
		Parameter table revision of adapter module.	-

No.	o. Name/Value Description		Def/FbEq16
51.29	FBA A drive type code	Displays the drive type code in the fieldbus adapter module mapping file (stored in the memory of the drive). This parameter is read-only.	-
	065535	Drive type code stored in the mapping file.	1 = 1
51.30	FBA A mapping file ver	Displays the fieldbus adapter module mapping file revision stored in the memory of the drive in decimal format. This parameter is read-only.	-
	065535	Mapping file revision.	1 = 1
51.31	D2FBA A comm status	Displays the status of the fieldbus adapter module communication.	-
	Idle	Adapter is not configured.	0
	Exec.init	Adapter is initializing.	1
	Time out	A timeout has occurred in the communication between the adapter and the drive.	2
	Conf.err	Adapter configuration error: mapping file not found in the file system of the drive, or mapping file upload has failed more than three times.	3
	Off-line	Fieldbus communication is off-line.	4
	On-line	Fieldbus communication is on-line, or fieldbus adapter has been configured not to detect a communication break. For more information, see the documentation of the fieldbus adapter.	5
	Reset	Adapter is performing a hardware reset.	6
51.32	FBA A comm SW ver	Displays the patch and build versions of the adapter module firmware in the format xxyy, where xx = patch version number and yy = build version number.  Example: C802 = 200.02 (patch version 200, build version 2).	
		Patch and build versions of adapter module firmware.	-
51.33	FBA A appl SW ver	Displays the major and minor versions of the adapter module firmware in format xyy, where x = major revision number and yy = minor revision number.  Example: 300 = 3.00 (major version 3, minor version 00).	
		Major and minor versions of adapter module firmware.	-

No.	Name/Value	Description	Def/FbEq16
52 FB.	A A data in	Selection of data to be transferred from drive to fieldbus controller through fieldbus adapter A.  Note: 32-bit values require two consecutive parameters.  Whenever a 32-bit value is selected in a data parameter, the next parameter is automatically reserved.	
52.01	FBA A data in1	Parameters 52.0152.12 select data to be transferred from the drive to the fieldbus controller through fieldbus adapter A.	None
	None	None.	0
	CW 16bit	Control Word (16 bits)	1
	Ref1 16bit	Reference REF1 (16 bits)	2
	Ref2 16bit	Reference REF2 (16 bits)	3
	SW 16bit	Status Word (16 bits)	4
	Act1 16bit	Actual value ACT1 (16 bits)	5
	Act2 16bit	Actual value ACT2 (16 bits)	6
	CW 32bit	Control Word (32 bits)	11
	Ref1 32bit	Reference REF1 (32 bits)	12
	Ref2 32bit	Reference REF2 (32 bits)	13
	SW 32bit	Status Word (32 bits)	14
	Act1 32bit	Actual value ACT1 (32 bits)	15
	Act2 32bit	Actual value ACT2 (32 bits)	16
	SW2 16bit	Status Word 2 (16 bits)	24
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
52.12	FBA A data in12	See parameter 52.01 FBA A data in1.	None

No.	Name/Value	Description	Def/FbEq16
53 FB.	A A data out	Selection of data to be transferred from fieldbus controller to drive through fieldbus adapter A.  Note: 32-bit values require two consecutive parameters.  Whenever a 32-bit value is selected in a data parameter, the next parameter is automatically reserved.	
53.01	FBA A data out1	Parameters 53.0153.12 select data to be transferred from the fieldbus controller to the drive through fieldbus adapter A.	None
	None	None.	0
	CW 16bit	Control Word (16 bits)	1
	Ref1 16bit	Reference REF1 (16 bits)	2
	Ref2 16bit	Reference REF2 (16 bits)	3
	CW 32bit	Control Word (32 bits)	11
	Ref1 32bit	Reference REF1 (32 bits)	12
	Ref2 32bit	Reference REF2 (32 bits)	13
	CW2 16bit	Control Word 2 (16 bits)	21
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
53.12	FBA A data out12	See parameter 53.01 FBA A data out1.	None
54 FB	A B settings	Fieldbus adapter B configuration.	
54.01	FBA B type	Displays the type of the connected fieldbus adapter module. <b>0</b> = Module is not found or is not properly connected, or is disabled by parameter 50.31 FBA B enable; <b>1</b> = FPBA; <b>32</b> = FCAN; <b>37</b> = FDNA; <b>101</b> = FCNA, <b>128</b> = FENA-11/21; <b>135</b> = FECA; <b>136</b> = FEPL; <b>485</b> = FSCA.  This parameter is read-only.	-
54.02	FBA B Par2	Parameters 54.0254.26 are adapter module-specific. For more information, see the documentation of the fieldbus adapter module. Note that not all of these parameters are necessarily in use.	-
	065535	Fieldbus adapter configuration parameter.	1 = 1
54.26	FBA B Par26	See parameter 54.02 FBA B Par2.	-
	065535	Fieldbus adapter configuration parameter.	1 = 1
54.27	FBA B par refresh	Validates any changed fieldbus adapter module configuration settings. After refreshing, the value reverts automatically to <i>Done</i> . <b>Note:</b> This parameter cannot be changed while the drive is running.	Done
	Done	Refreshing done.	0
	Refresh	Refreshing.	1
		I .	

No.	Name/Value	Description	Def/FbEq16
54.28 FBA B par table ver		Displays the parameter table revision of the fieldbus adapter module mapping file (stored in the memory of the drive). In format axyz, where ax = major table revision number; yz = minor table revision number. This parameter is read-only.	-
		Parameter table revision of adapter module.	-
54.29	FBA B drive type code	Displays the drive type code in the fieldbus adapter module mapping file (stored in the memory of the drive).  This parameter is read-only.	-
	065535	Drive type code stored in the mapping file.	1 = 1
54.30	FBA B mapping file ver	Displays the fieldbus adapter module mapping file revision stored in the memory of the drive in decimal format. This parameter is read-only.	-
	065535	Mapping file revision.	1 = 1
54.31	D2FBA B comm status	Displays the status of the fieldbus adapter module communication.	-
	Not configured	Adapter is not configured.	0
	Initializing	Adapter is initializing.	1
	Time out	A timeout has occurred in the communication between the adapter and the drive.	2
	Configuration error	Adapter configuration error: mapping file not found in the file system of the drive, or mapping file upload has failed more than three times.	3
	Off-line	Fieldbus communication is off-line.	4
	On-line	Fieldbus communication is on-line, or fieldbus adapter has been configured not to detect a communication break. For more information, see the documentation of the fieldbus adapter.	5
	Reset	Adapter is performing a hardware reset.	6
54.32	FBA B comm SW ver	Displays the patch and build versions of the adapter module firmware in the format xxyy, where xx = patch version number and yy = build version number.  Example: C802 = 200.02 (patch version 200, build version 2).	
		Patch and build versions of adapter module firmware.	-
54.33	FBA B appl SW ver	Displays the major and minor versions of the adapter module firmware in format xyy, where x = major revision number and yy = minor revision number.  Example: 300 = 3.00 (major version 3, minor version 00).	
		Major and minor versions of adapter module firmware.	-
55 FB/	A B data in	Selection of data to be transferred from drive to fieldbus controller through fieldbus adapter B.	
55.01	FBA B data in1	Parameters 55.0155.12 select data to be transferred from the drive to the fieldbus controller through fieldbus adapter B.	None
	None	None.	0
	CW 16bit	Control Word (16 bits)	1
	Ref1 16bit	Reference REF1 (16 bits)	2

No.	Name/Value	Description	Def/FbEq16
	Ref2 16bit	Reference REF2 (16 bits)	3
	SW 16bit	Status Word (16 bits)	4
	Act1 16bit	Actual value ACT1 (16 bits)	5
	Act2 16bit	Actual value ACT2 (16 bits)	6
	CW 32bit	Control Word (32 bits)	11
	Ref1 32bit	Reference REF1 (32 bits)	12
	Ref2 32bit	Reference REF2 (32 bits)	13
	SW 32bit	Status Word (32 bits)	14
	Act1 32bit	Actual value ACT1 (32 bits)	15
	Act2 32bit	Actual value ACT2 (32 bits)	16
	SW2 16bit	Status Word 2 (16 bits)	24
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
55.12	FBA B data in12	See parameter 55.01 FBA B data in1.	None

56 FBA B data out		Selection of data to be transferred from fieldbus controller to drive through fieldbus adapter B.	
56.01	FBA B data out1	Parameters 56.0156.12 select data to be transferred from the fieldbus controller to the drive through fieldbus adapter B.	None
	None	None.	0
	CW 16bit	Control Word (16 bits)	1
	Ref1 16bit	Reference REF1 (16 bits)	2
	Ref2 16bit	Reference REF2 (16 bits)	3
	CW 32bit	Control Word (32 bits)	11
	Ref1 32bit	Reference REF1 (32 bits)	12
	Ref2 32bit	Reference REF2 (32 bits)	13
	CW2 16bit	Control Word 2 (16 bits)	21
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
56.12	FBA B data out12	See parameter 56.01 FBA B data out1.	None

58 Embedded fieldbus	Configuration of the embedded fieldbus (EFB) interface. See also chapter <i>Fieldbus control through a fieldbus adapter</i> (page 667).	
58.01 Protocol enable	Enables/disables the embedded fieldbus interface and selects the protocol to use.  Notes:  When the embedded fieldbus interface is enabled, the drive-to-drive link functionality is automatically disabled.  This parameter cannot be changed while the drive is running.	None
None	None (communication disabled).	0

No.	Name/Value	Description	Def/FbEq16
	Modbus RTU	Embedded fieldbus interface is enabled and uses the Modbus RTU protocol.	1
58.02	Protocol ID	Displays the protocol ID and revision.  This parameter is read-only.	-
		Protocol ID and revision.	1 = 1
58.03	Node address	Defines the node address of the drive on the fieldbus link.  Values 1247 are allowable. Two devices with the same address are not allowed on-line.  Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06  Communication control.	1
	0255	Node address (values 1247 are allowable).	1 = 1
58.04	Baud rate	Selects the transfer rate of the fieldbus link. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control.	19.2 kbps
	9.6 kbps	9.6 kbit/s.	2
	19.2 kbps	19.2 kbit/s.	3
	38.4 kbps	38.4 kbit/s.	4
	57.6 kbps	57.6 kbit/s.	5
	76.8 kbps	76.8 kbit/s.	6
	115.2 kbps	115.2 kbit/s.	7
58.05	Parity	Selects the type of parity bit and the number of stop bits. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control.	8 EVEN 1
	8 NONE 1	Eight data bits, no parity bit, one stop bit.	0
	8 NONE 2	Eight data bits, no parity bit, two stop bits.	1
	8 EVEN 1	Eight data bits, even parity bit, one stop bit.	2
	8 ODD 1	Eight data bits, odd parity bit, one stop bit.	3
58.06	Communication control	Validates any changes in the EFB settings, or activates silent mode.	Enabled
	Enabled	Normal operation.	0
	Refresh settings	Validates any changed EFB configuration settings. Reverts automatically to <i>Enabled</i> .	1
	Silent mode	Activates silent mode (no messages are transmitted). Silent mode can be terminated by activating the <i>Refresh settings</i> selection of this parameter.	2

No.	Name/	Value	Description	on	Def/FbEq1	
58.07	Comm diagno	unication estics		ne status of the EFB communication. neter is read-only.	-	
	Bit	Name		Description		
	0	Init failed		1 = EFB initialization failed		
	1	Addr config	err	1 = Node address not allowed by protocol		
	2	Silent mode	9	1 = Drive not allowed to transmit		
				0 = Drive allowed to transmit		
	3	Autobauding Wiring error Parity error Baud rate error		Reserved		
	4			1 = Errors detected (A/B wires possibly swapped)		
	5			1 = Error detected: check parameters 58.04 and 5	58.05	
	6			1 = Error detected: check parameters 58.05 and 5	58.04	
	7	No bus acti	vity	1 = 0 bytes received during last 5 seconds		
	8	No packets		1 = 0 packets (addressed to any device) detected seconds	during last 5	
	9	Noise or ad	ldressing	1 = Errors detected (interference, or another device with the same address on line) 1 = 0 packets addressed to the drive received within timeo (58.16)		
	10	Comm loss				
	11	CW/Ref los	s	1 = No control word or references received within (58.16)	timeout	
	12	Not active		Reserved		
	13	Protocol 1		Reserved		
	14	Protocol 2		Reserved		
	15	Internal error		Reserved		
	0000h	FFFFh	EFB comm	nunication status.	1 = 1	
58.08	Receiv	ved packets	During nor Can be res	count of valid packets addressed to the drive. rmal operation, this number increases constantly. set from the control panel by keeping Reset I for over 3 seconds.	-	
	0429	94967295	Number of	freceived packets addressed to the drive.	1 = 1	
58.09	Transn	nitted packets	During nor Can be res	count of valid packets transmitted by the drive. rmal operation, this number increases constantly. set from the control panel by keeping Reset I for over 3 seconds.	-	
	04294967295		Number of	f transmitted packets.	1 = 1	
58.10	All pac	kets	on the bus constantly Can be res	count of valid packets addressed to any device b. During normal operation, this number increases set from the control panel by keeping Reset I for over 3 seconds.	-	
	04294967295		Number of	f all received packets.	1 = 1	
58.11	UART	errors	An increas bus. Can be res	count of character errors received by the drive. sing count indicates a configuration problem on the set from the control panel by keeping Reset for over 3 seconds.	-	
	0429	94967295	-	FUART errors.	1 = 1	
			l .		1	

No.	Name/Value	Description	Def/FbEq16
58.12	CRC errors	Displays a count of packets with a CRC error received by the drive. An increasing count indicates interference on the bus. Can be reset from the control panel by keeping Reset depressed for over 3 seconds.	-
	04294967295	Number of CRC errors.	1 = 1
58.14	Communication loss action	Selects how the drive reacts to an EFB communication break.  Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control.  See also parameters 58.15 Communication loss mode and 58.16 Communication loss time.	Fault
	No	No action taken (monitoring disabled).	0
	Fault	Drive trips on 6681 EFB comm loss. This only occurs if control is expected from the EFB (EFB selected as source of start/stop in the currently active location).	1
	Last speed	Drive generates an A7CE EFB comm loss warning and freezes the speed to the level the drive was operating at. This only occurs if control is expected from the EFB. The speed is determined on the basis of actual speed using 850 ms low-pass filtering.  WARNING! Make sure that it is safe to continue operation in case of a communication break.	2
	Speed ref safe	Drive generates an A7CE EFB comm loss warning and sets the speed to the speed defined by parameter 22.41 Speed ref safe (or 28.41 Frequency ref safe when frequency reference is being used). This only occurs if control is expected from the EFB.  WARNING! Make sure that it is safe to continue operation in case of a communication break.	3
	Fault always	Drive trips on 6681 EFB comm loss. This occurs even though no control is expected from the EFB.	4
	Warning	Drive generates an A7CE EFB comm loss warning. This occurs even though no control is expected from the EFB.  WARNING! Make sure that it is safe to continue operation in case of a communication break.	5
58.15	Communication loss mode	Defines which message types reset the timeout counter for detecting an EFB communication loss.  Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control.  See also parameters 58.14 Communication loss action and 58.16 Communication loss time.	Cw / Ref1 / Ref2
	Any message	Any message addressed to the drive resets the timeout.	1
	Cw / Ref1 / Ref2	A write of the control word or a reference from the fieldbus resets the timeout.	2

No.	Name/Value	me/Value Description			
58.16	Communication loss time	Sets a timeout for EFB communication. If a communication break lasts longer than the timeout, the action specified by parameter 58.14 Communication loss action is taken. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control.  Note: There is a 30-second boot-up delay immediately after power-up. During the delay, communication break monitoring is disabled (but communication itself can be active).  See also parameter 58.15 Communication loss mode.	3.0 s		
	0.0 6000.0 s	EFB communication timeout.	1 = 1		
58.17	Transmit delay	Defines a minimum response delay in addition to any fixed delay imposed by the protocol.  Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control.	0 ms		
	065535 ms	Minimum response delay.	1 = 1		
58.18	EFB control word	Displays the raw (unmodified) control word sent by the Modbus controller to the drive. For debugging purposes. This parameter is read-only.	-		
	0000hFFFFh	Control word sent by Modbus controller to the drive.	1 = 1		
58.19	EFB status word	Displays the raw (unmodified) status word sent by the drive to the Modbus controller. For debugging purposes. This parameter is read-only.	-		
	0000hFFFFh	Status word sent by the drive to the Modbus controller.	1 = 1		
58.25	Control profile	Defines the control profile used by the protocol.	ABB Drives		
	ABB Drives	ABB Drives profile (with a 16-bit control word) with registers in the classic format for backward compatibility.	0		
	Transparent	Transparent profile (16-bit or 32-bit control word) with registers in the classic format.	2		
58.26	EFB ref1 type	Selects the type and scaling of reference 1 received through the embedded fieldbus interface.  The scaled reference is displayed by 03.09 EFB reference 1.	Auto		
	Auto	Type and scaling are chosen automatically according to which reference chain (see settings <i>Torque</i> , <i>Speed</i> , <i>Frequency</i> ) the incoming reference is connected to. If the reference is not connected to any chain, no scaling is applied (as with setting <i>Transparent</i> ).	0		
	Transparent	No scaling is applied.	1		
	General	Generic reference with a scaling of 100 = 1 (i.e. integer and two decimals).	2		
	Torque	The scaling is defined by parameter 46.03 Torque scaling.	3		
	Speed	The scaling is defined by parameter 46.01 Speed scaling.	4		
	Frequency	The scaling is defined by parameter 46.02 Frequency scaling.	5		
58.27	EFB ref2 type	Selects the type and scaling of reference 2 received through the embedded fieldbus interface.  The scaled reference is displayed by 03.10 EFB reference 2.	Torque		
		For the selections, see parameter <i>58.26 EFB ref1 type</i> .			

No.	Name/Value	Description	Def/FbEq16
58.28	EFB act1 type	Selects the type/source and scaling of actual value 1 transmitted to the fieldbus network through the embedded fieldbus interface.	Auto
	Auto	Type/source and scaling follow the type of reference 1 selected by parameter 58.26 EFB ref1 type. See the individual settings below for the sources and scalings.	0
	Transparent	The value selected by parameter 58.31 EFB act1 transparent source is sent as actual value 1. No scaling is applied (the 16-bit scaling is 1 = 1 unit).	1
	General	The value selected by parameter 58.31 EFB act1 transparent source is sent as actual value 1 with a 16-bit scaling of 100 = 1 unit (i.e. integer and two decimals).	2
	Torque	01.10 Motor torque is sent as actual value 1. The scaling is defined by parameter 46.03 Torque scaling.	3
	Speed	01.01 Motor speed used is sent as actual value 1. The scaling is defined by parameter 46.01 Speed scaling.	4
	Frequency	01.06 Output frequency is sent as actual value 1. The scaling is defined by parameter 46.02 Frequency scaling.	5
	Position	Motor position is sent as actual value 1. See parameter 90.06 Motor position scaled.	6
58.29	EFB act2 type	Selects the type/source and scaling of actual value 2 transmitted to the fieldbus network through the embedded fieldbus interface.	Torque
	Auto Type/source and scaling follow the type of reference 1 selected by parameter 58.27 EFB ref2 type. See the individual settings below for the sources and scalings.		0
	Transparent	The value selected by parameter 58.32 EFB act2 transparent source is sent as actual value 2. No scaling is applied (the 16-bit scaling is 1 = 1 unit).	1
	General	The value selected by parameter 58.32 EFB act2 transparent source is sent as actual value 2 with a 16-bit scaling of 100 = 1 unit (i.e. integer and two decimals).	2
	Torque	01.10 Motor torque is sent as actual value 2. The scaling is defined by parameter 46.03 Torque scaling.	3
	Speed	01.01 Motor speed used is sent as actual value 2. The scaling is defined by parameter 46.01 Speed scaling.	4
	Frequency  01.06 Output frequency is sent as actual value 2. The scaling is defined by parameter 46.02 Frequency scaling.		5
	Position	Motor position is sent as actual value 2. See parameter 90.06 Motor position scaled.	6
58.30	EFB status word transparent source	Selects the source of the status word when 58.25 Control profile is set to Transparent.	Not selected
	Not selected	elected None.	
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
58.31	EFB act1 transparent source	Selects the source of actual value 1 when 58.28 EFB act1 type is set to Transparent or General.	Not selected
	Not selected	None.	0
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-

No.	Name/Va	lue	Description	Def/FbEq16	
58.32	EFB act2 transpare		Selects the source of actual value 1 when 58.29 EFB act2 type is set to Transparent or General.	Not selected	
	Not selec	ted	None.	0	
	Other		Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-	
58.33	Addressin	ng mode	Defines the mapping between parameters and holding registers in the 400101465535 Modbus register range. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control.	Mode 0	
	Mode 0		16-bit values (groups 199, indexes 199): Register address = 400000 + 100 × parameter group + parameter index. For example, parameter 22.80 would be mapped to register 400000 + 2200 + 80 = 402280.  32-bit values (groups 199, indexes 199): Register address = 420000 + 200 × parameter group + 2 × parameter index. For example, parameter 22.80 would be mapped to register 420000 + 4400 + 160 = 424560.	0	
	Mode 1		16-bit values (groups 1255, indexes 1255): Register address = 400000 + 256 × parameter group + parameter index. For example, parameter 22.80 would be mapped to register 400000 + 5632 + 80 = 405712.	1	
	Mode 2		32-bit values (groups 1127, indexes 1255): Register address = 400000 + 512 × parameter group + 2 × parameter index. For example, parameter 22.80 would be mapped to register 400000 + 11264 + 160 = 411424.	2	
58.34	Word order		Selects in which order 16-bit registers of 32-bit parameters are transferred.  For each register, the first byte contains the high order byte and the second byte contains the low order byte.  Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control.	LO-HI	
	HI-LO		The first register contains the high order word, the second contains the low order word.	0	
	LO-HI		The first register contains the low order word, the second contains the high order word.	1	
58.36	EFB comm supervision force		Activates fieldbus communication monitoring separately for each control location (see section <i>Local control vs. external control</i> on page <i>40</i> ).  The parameter is primarily intended for monitoring the communication with EFB when it is connected to the application program and not selected as a control source by drive parameters.	0000Ь	
	Bit	Name	Value		

Bit	Name	Value
0	Ext 1	1 = Communication monitoring active when Ext 1 is being used.
1	Ext 2	1 = Communication monitoring active when Ext 2 is being used.
2	Local	1 = Communication monitoring active when local control is being used.
315	Reserved	

0000b0111b	EFB communication monitoring selection.	1 = 1

No.	Name/Value	Description	Def/FbEq16
58.101	Data I/O 1	Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400001.	CW 16bit
		The master defines the type of the data (input or output). The value is transmitted in a Modbus frame consisting of two 16-bit words. If the value is 16-bit, it is transmitted in the LSW (least significant word). If the value is 32-bit, the subsequent parameter is also reserved for it and must be set to <i>None</i> .	
	None	None.	0
	CW 16bit	Control Word (16 bits).	1
	Ref1 16bit	Reference REF1 (16 bits).	2
	Ref2 16bit	Reference REF2 (16 bits).	3
	SW 16bit	Status Word (16 bits).	4
	Act1 16bit	Actual value ACT1 (16 bits).	5
	Act2 16bit	Actual value ACT2 (16 bits).	6
	CW 32bit	Control Word (32 bits).	11
	Ref1 32bit	Reference REF1 (32 bits).	12
	Ref2 32bit	Reference REF2 (32 bits).	13
	SW 32bit	Status Word (32 bits).	14
	Act1 32bit	Actual value ACT1 (32 bits).	15
	Act2 32bit	Actual value ACT2 (32 bits).	16
	CW2 16bit	Control Word 2 (16 bits). When a 32-bit control word is used, this setting means the most-significant 16 bits.	21
	SW2 16bit	Status Word 2 (16 bits). When a 32-bit control word is used, this setting means the most-significant 16 bits.	24
	RO/DIO control word	Parameter 10.99 RO/DIO control word.	31
	AO1 data storage	Parameter 13.91 AO1 data storage.	32
	AO2 data storage	Parameter 13.92 AO2 data storage.	33
	Feedback data storage	Parameter 40.91 Feedback data storage.	40
	Setpoint data storage	Parameter 40.92 Setpoint data storage.	41
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
58.102	Data I/O 2	Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400002.  For the selections, see parameter 58.101 Data I/O 1.	Ref1 16bit
58.103	Data I/O 3	Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400003.  For the selections, see parameter 58.101 Data I/O 1.	Ref2 16bit

7

12

No.	Name/Value	Description	Def/FbEq16
58.104	Data I/O 4	Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400004.  For the selections, see parameter 58.101 Data I/O 1.	SW 16bit
58.105	Data I/O 5	Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400005.  For the selections, see parameter 58.101 Data I/O 1.	Act1 16bit
58.106	Data I/O 6	Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400006.  For the selections, see parameter 58.101 Data I/O 1.	Act2 16bit
58.107	Data I/O 7	Parameter selector for Modbus register address 400007. For the selections, see parameter <i>58.101 Data I/O 1</i> .	None
58.124	Data I/O 24	Parameter selector for Modbus register address 400024. For the selections, see parameter 58.101 Data I/O 1.	None
60 DDG	unication	<ul> <li>DDCS communication configuration.</li> <li>The DDCS protocol is used in the communication between</li> <li>drives in a master/follower configuration (see page 74),</li> <li>the drive and an external controller such as the AC 800M (see page 81), or</li> <li>the drive (or more precisely, an inverter unit) and the supply unit of the drive system (see page 83).</li> <li>All of the above utilize a fiber optic link which also requires an FDCO module (with ZCU control units) or an RDCO module (with BCU control units). Master/follower and external controller communication can also be implemented through twisted-pair cable connected to the XD2D connector of the drive.</li> </ul>	
60.01	M/F communication port	Selects the connection used by the master/follower functionality.	Not in use
	Not in use	None (communication disabled).	0
	Slot 1A	Channel A on FDCO module in slot 1 (with ZCU control unit only).	1
	Slot 2A	Channel A on FDCO module in slot 2 (with ZCU control unit only).	2
	Slot 3A	Channel A on FDCO module in slot 3 (with ZCU control unit only).	3
	Slot 1B	Channel B on FDCO module in slot 1 (with ZCU control unit only).	4
	Slot 2B	Channel B on FDCO module in slot 2 (with ZCU control unit only).	5
	Slot 3B	Channel B on FDCO module in slot 3 (with ZCU control unit only).	6

Connector XD2D.

Channel 2 on RDCO module (with BCU control unit only).

XD2D

RDCO CH 2

No.	Name/Value	Description	Def/FbEq16
60.02	M/F node address	Selects the node address of the drive for master/follower communication. No two nodes on-line may have the same address.  Note: The allowable addresses for the master are 0 and 1. The allowable addresses for followers are 260.	1
	1254	Node address.	
60.03	M/F mode	Defines the role of the drive on the master/follower link.	Not in use
	Not in use	Master/follower functionality not active.	0
	DDCS master	The drive is the master on the master/follower (DDCS) link.	1
	DDCS follower	The drive is a follower on the master/follower (DDCS) link.	2
	D2D master	The drive is the master on the drive-to-drive (D2D) link. <b>Note:</b> Use the setting <i>DDCS master</i> if using the master/follower functionality (see page 74) through the XD2D connector.	3
	D2D follower	The drive is a follower on the drive-to-drive (D2D) link. <b>Note:</b> Use the setting <i>DDCS follower</i> if using the master/follower functionality (see page 74) through the XD2D connector.	4
	DDCS forcing	The role of the drive on the master/follower (DDCS) link is defined by parameters 60.15 Force master and 60.16 Force follower.	5
	D2D forcing	The role of the drive on the drive-to-drive (D2D) link is defined by parameters 60.15 Force master and 60.16 Force follower.  Note: Use the setting DDCS forcing if using the master/follower functionality (see page 74) through the XD2D connector.	6
60.05	M/F HW connection	Selects the topology of the master/follower link. <b>Note:</b> Use the setting <i>Star</i> if using the master/follower functionality (see page <i>74</i> ) through the XD2D connector (as opposed to a fiber optic link).	Ring
	Ring	The devices are connected in a ring topology. Forwarding of messages is enabled.	0
	Star	The devices are connected in a star topology (for example, through a branching unit). Forwarding of messages is disabled.	1
60.07	M/F link control	Defines the light intensity of the transmission LED of RDCO module channel CH2. (This parameter is effective only when parameter 60.01 M/F communication port is set to RDCO CH 2. FDCO modules have a hardware transmitter current selector.) In general, use higher values with longer fiber optic cables. The maximum setting is applicable to the maximum length of the fiber optic link. See Specifications of the fiber optic master/follower link (page 80).	10
	115	Light intensity.	

No.	Name/Value	Description	Def/FbEq16
60.08	M/F comm loss timeout	Sets a timeout for master/follower communication. If a communication break lasts longer than the timeout, the action specified by parameter 60.09 M/F comm loss function is taken.  As a rule of thumb, this parameter should be set to at least 3	100 ms
		times the transmit interval of the master. See also parameter 60.18 M/F comm loss function.	
	065535 ms	Master/follower communication timeout.	
60.09	M/F comm loss function	Selects how the drive reacts to a master/follower communication break.	Fault
	No action	No action taken.	0
	Warning	The drive generates a warning (A7CB MF comm loss).	1
	Fault	Drive trips on 7582 MF comm loss.	2
	Fault always	Drive trips on 7582 MF comm loss. This occurs even though no control is expected from the master/follower link.	3
60.10	M/F ref1 type	Selects the type and scaling of reference 1 received from the master/follower link. The resulting value is shown by 03.13 M/F or D2D ref1.	Auto
	Auto	Type and scaling are chosen automatically according to which reference chain (see settings <i>Torque</i> , <i>Speed</i> , <i>Frequency</i> ) the incoming reference is connected to. If the reference is not connected to any chain, no scaling is applied (as with setting <i>Transparent</i> ).	0
	Transparent	No scaling is applied.	1
	General	Generic reference without a specific unit.	2
	Torque	The scaling is defined by parameter 46.03 Torque scaling.	3
	Speed	The scaling is defined by parameter 46.01 Speed scaling.	4
	Frequency	The scaling is defined by parameter 46.02 Frequency scaling.	5
60.11	M/F ref2 type	Selects the type and scaling of reference 2 received from the master/follower link. The resulting value is shown by 03.14 M/F or D2D ref2.  For the selections, see parameter 60.10 M/F ref1 type.	Torque
60.12	M/F act1 type	Selects the type/source and scaling of actual value ACT1 transmitted to the master/follower link.	Auto
	Auto	Type/source and scaling follow the type of reference 1 selected by parameter 60.10 M/F ref1 type. See the individual settings below for the source and scalings.	0
	Transparent	Reserved.	1
	General	Reserved.	2
	Torque	01.10 Motor torque is sent as actual value 1. The scaling is defined by parameter 46.03 Torque scaling.	3
	Speed	01.01 Motor speed used is sent as actual value 1. The scaling is defined by parameter 46.01 Speed scaling.	4
	Frequency	01.06 Output frequency is sent as actual value 1. The scaling is defined by parameter 46.02 Frequency scaling.	5

No.	Name/Value	Description	Def/FbEq16
60.13	M/F act2 type	Selects the type/source and scaling of actual value ACT2 transmitted to the master/follower link.	Auto
	Auto	Type/source and scaling follow the type of reference 2 selected by parameter 60.11 M/F ref2 type. See the individual settings below for the sources and scalings.	0
	Transparent	Reserved.	1
	General	Reserved.	2
	Torque	01.10 Motor torque is sent as actual value 2. The scaling is defined by parameter 46.03 Torque scaling.	3
	Speed	01.01 Motor speed used is sent as actual value 2. The scaling is defined by parameter 46.01 Speed scaling.	4
	Frequency	01.06 Output frequency is sent as actual value 2. The scaling is defined by parameter 46.02 Frequency scaling.	5
60.14	M/F follower selection (Effective in the master only.) Defines the followers from which data is read. See also parameters 62.2862.33.  None None.  Follower node 2 Data is read from the follower with node address 2.  Follower node 3 Data is read from the follower with node address 3.		None
	None	None.	0
	Follower node 2	Data is read from the follower with node address 2.	2
	Follower node 3	Data is read from the follower with node address 3.	4
	Follower node 3 Data is read from the follower with node address 3.  Follower node 4 Data is read from the follower with node address 4.		8
	Follower nodes 2+3	Data is read from the followers with node addresses 2 and 3.	6
	Follower nodes 2+4 Data is read from the followers with node addresses 2 and 4.		10
	Follower nodes 3+4	Data is read from the followers with node addresses 3 and 4.	12
	Follower nodes 2+3+4	Data is read from the followers with node addresses 2, 3 and 4.	14
60.15	Force master	When parameter 60.03 M/F mode is set to DDCS forcing or D2D forcing, this parameter selects a source that forces the drive to be the master on the master/follower link.  1 = Drive is master on the master/follower link	FALSE
	FALSE	0.	0
	TRUE	1.	1
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
60.16	Force follower	When parameter 60.03 M/F mode is set to DDCS forcing or D2D forcing, this parameter selects a source that forces the drive to be a follower on the master/follower link.  1 = Drive is follower on the master/follower link	FALSE
	FALSE	0.	0
	TRUE	1.	1
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
60.17	Follower fault action	(Effective in the master only.) Selects how the drive reacts to a fault in a follower.  Note: Each follower must be configured to transmit its status word as one of the three data words in parameters 61.0161.03. In the master, the corresponding target parameter (62.0462.12) must be set to Follower SW.	Fault
	No action	No action taken. Unaffected drives on the master/follower link will continue running.	0

No.	Name/Va	ılue	Description	Def/FbEq16
	Warning		The drive generates a warning (AFE7 Follower).	1
	Fault		Drive trips on FF7E Follower. All followers will be stopped.	2
60.18	Follower	enable	Interlocks the starting of the master to the status of the followers.  Note: Each follower must be configured to transmit its status word as one of the three data words in parameters 61.0161.03. In the master, the corresponding target parameter (62.0462.12) must be set to Follower SW.	Always
	MSW bit	0	The master can only be started if all followers are ready to switch on (bit 0 of <i>06.11 Main status word</i> in each follower is on).	0
	MSW bit 1  MSW bits 0 + 1  Always		The master can only be started if all followers are ready to operate (bit 1 of <i>06.11 Main status word</i> in each follower is on).	1
	MSW bits	s 0 + 1	The master can only be started if all followers are ready to switch on and ready to operate (bits 0 and 1 of 06.11 Main status word in each follower are on).	2
	Always		The starting of the master is not interlocked to the status of the followers.	3
	MSW bit	12	The master can only be started if user-definable bit 12 of 06.11 Main status word in each follower is on. See parameter 06.31 MSW bit 12 sel.	4
	MSW bits	s 0 + 12	The master can only be started if both bit 0 and bit 12 of 06.11 Main status word in each follower is on.	5
	MSW bits	s 1 + 12	The master can only be started if both bit 1 and bit 12 of 06.11 Main status word in each follower is on.	6
60.19	M/F comm supervision sel 1 ma pa mo ln 1 a fol Th 1 po sp		(This parameter is only effective when the drive is the master on a drive-to-drive master/follower link. See parameters 60.01 M/F communication port and 60.03 M/F mode.)  In the master, parameters 60.19 M/F comm supervision sel 1 and 60.20 M/F comm supervision sel 2 specify the followers that are monitored for loss of communication. This parameter selects which followers (out of followers 116) are monitored. Each of the selected followers is polled by the master. If no reply is received, the action specified in 60.09 M/F comm loss function is taken. The status of communication is shown by 62.37 M/F communication status 1 and 62.38 M/F communication status 2.	-
	Bit	Name	Description	
	0	Follower 1	1 = Follower 1 is polled by the master.	

ollower 1	1 = Follower 1 is polled by the master.
ollower 2	1 = Follower 2 is polled by the master.
•	
ollower 16	1 = Follower 16 is polled by the master.
	ollower 2

0000hFFFFh	Selection of followers for communication supervision (1).	1 = 1

No.	Name/Value		De	scription	Def/FbEq16
60.20	M/F comm supervision sel 2		mo	lects which followers (out of followers 1732) are onitored for loss of communication. See parameter 60.19 F comm supervision sel 1.	-
	Bit	Name		Description	
	0	Follower 17	7	1 = Follower 17 is polled by the master.	
	1	Follower 18	3	1 = Follower 18 is polled by the master.	
	15	Follower 32	2	1 = Follower 32 is polled by the master.	
	0000h	FFFFh	Sel	lection of followers for communication supervision (2).	1 = 1
60.23				nis parameter is only effective when the drive is the	
00.23	supervision sel 1		ma par mo In t and who Thi who If a act and def Usi sta give The con	aster on a drive-to-drive master/follower link. See rameters 60.01 M/F communication port and 60.03 M/F ode.) the master, parameters 60.23 M/F status supervision sel 1 d 60.24 M/F status supervision sel 2 specify the followers lose status word is monitored by the master. is parameter selects the followers (out of followers 116) lose status words are monitored by the master. In follower reports a fault (bit 3 of the status word is on), the tion specified in 60.17 Follower fault action is taken. Bits 0 d 1 of the status word (ready states) are handled as fined by 60.18 Follower enable. Ining 60.27 M/F status supv mode sel 1 and 60.28 M/F attus supv mode sel 2, it is possible to define whether any ten follower is only monitored when it is stopped. The status of communication is shown by 62.37 M/F mmunication status 1 and 62.38 M/F communication in the status 2.	
	Bit	Name		Description	
	0	Follower 1		1 = Status of follower 1 is monitored.	
	1	Follower 2		1 = Status of follower 2 is monitored.	
	15	Follower 16	6	1 = Status of follower 16 is monitored.	
	0000h	FFFFh	M/F	F follower status supervision selection (followers 116).	1 = 1
60.24	M/F sta supervi	tus sion sel 2	wo	lects the followers (out of followers 1732) whose status ords are monitored by the master. e parameter 60.23 M/F status supervision sel 1.	-
	Bit	Name		Description	
	0	Follower 17	7	1 = Status of follower 17 is monitored.	
	1	Follower 18		1 = Status of follower 18 is monitored.	
	 15	Follower 32	2	1 = Status of follower 32 is monitored.	
	1.0	1. 5115 17 61 02	_		
	nnnnh	FFFFh	NA/F	F follower status supervision selection (followers 1732).	1 = 1

No.	Name/Value		Description	Def/FbEq16
60.27	mode sel 1		In the master, parameters 60.27 M/F status supv mode sel 1 and 60.28 M/F status supv mode sel 2 specify the mode of follower status word monitoring. Each follower can individually be set to be monitored continuously, or only when it is in stopped state.  This parameter selects the mode of status word monitoring of followers 116.	-
	Bit	Name	Description	
	0	Follower 1	0 = Status of follower 1 is monitored continuously. 1 = Status of follower 1 is monitored only when it is in stop	ped state.
	1	Follower 2	0 = Status of follower 2 is monitored continuously. 1 = Status of follower 2 is monitored only when it is in stop	ped state.
	15	Follower 16	0 = Status of follower 16 is monitored continuously. 1 = Status of follower 16 is monitored only when it is in sto	oped state.
	0000h	.FFFFh	M/F status supervision mode selection 1.	1 = 1
60.28	M/F state	tus supv el 2	Selects the mode of status word monitoring of followers 1732.	-
	Bit	Name	Description	
	0	Follower 17	0 = Status of follower 17 is monitored continuously. 1 = Status of follower 17 is monitored only when it is in sto	pped state.
	1	Follower 18	0 = Status of follower 18 is monitored continuously. 1 = Status of follower 18 is monitored only when it is in sto	pped state.
	15	Follower 32	0 = Status of follower 32 is monitored continuously. 1 = Status of follower 32 is monitored only when it is in sto	pped state.
	0000h	.FFFFh	M/F status supervision mode selection 2.	1 = 1
60.31	M/F wake up delay		Defines a wake-up delay during which no master/follower communication faults or warnings are generated. This is to allow all drives on the master/follower link to power up. The master cannot be started until the delay elapses or all monitored followers are found to be ready.	60.0 s
	0.0 180.0 s		Master/follower wake-up delay.	10 = 1 s

No.	Name/Va	alue	Description	Def/FbEq16
60.32	M/F comm supervision force		Activates master/follower communication monitoring separately for each control location (see section <i>Local control vs. external control</i> on page 40).  The parameter is primarily intended for monitoring the communication with master or follower when it is connected to the application program and not selected as a control source by drive parameters.	0000b
	Bit	Name	Value	
	0	Ext 1	1 = Communication monitoring active when Ext 1 is being	used.
	1	Ext 2	1 = Communication monitoring active when Ext 2 is being	used.
	2	Local	1 = Communication monitoring active when local control i used.	s being
	315	Reserved		
	0000b	0111b	Master/follower communication monitoring selection.	1 = 1
60.41	Extension adapter com port		Selects the channel used for connecting an optional FEA-xx extension adapter.	No connect
	No connect		None (communication disabled).	0
	Slot 1A		Channel A on FDCO module in slot 1.	1
	Slot 2A		Channel A on FDCO module in slot 2.	2
	Slot 3A		Channel A on FDCO module in slot 3.	3
	Slot 1B		Channel B on FDCO module in slot 1.	4
	Slot 2B		Channel B on FDCO module in slot 2.	5
	Slot 3B		Channel B on FDCO module in slot 3.	6
	RDCO C	H 3	Channel CH 3 on RDCO module (with BCU control unit only).	13
60.50	DDCS controller drive type		In ModuleBus communication, defines whether the drive is of the "engineered" or "standard" type.  Note: This parameter cannot be changed while the drive is running.	ABB engineered drive
	ABB eng drive	ineered	The drive is an "engineered drive" (data sets 1025 are used).	0
	ABB star	ndard drive	The drive is a "standard drive" (data sets 14 are used).	1
60.51	DDCS co		Selects the DDCS channel used for connecting an external controller (such as an AC 800M).	Not in use
	Not in us	se	None (communication disabled).	0
	Slot 1A		Channel A on FDCO module in slot 1.	1
	Slot 2A		Channel A on FDCO module in slot 2.	2
	Slot 3A		Channel A on FDCO module in slot 3.	3
	Slot 1B		Channel B on FDCO module in slot 1.	4
	Slot 2B		Channel B on FDCO module in slot 2.	5
	Slot 3B		Channel B on FDCO module in slot 3.	6
	XD2D		Connector XD2D.	7
	RDCO C	:H 0	Channel 0 on RDCO module (with BCU control unit only).	10

No.	Name/Value	Description	Def/FbEq16
60.52	DDCS controller node address	Selects the node address of the drive for communication with the external controller. No two nodes on-line may have the same address.  With an AC 800M (CI858) DriveBus connection, drives must be addressed 124.  With an AC 80 DriveBus connection, drives must be addressed 112.Note that the BusManager function must be disabled in the DriveBus controller.  With optical ModuleBus, the drive address is set according to the position value as follows:  1. Multiply the hundreds of the position value by 16.  2. Add the tens and ones of the position value to the result. For example, if the position value is 101, this parameter must be set to 1×16 + 1 = 17.	1
	1254	Node address.	-
60.55	DDCS controller HW connection	Selects the topology of the fiber optic link with an external controller.	Star
	Ring	The devices are connected in a ring topology. Forwarding of messages is enabled.	0
	Star	The devices are connected in a star topology (for example, through a branching unit). Forwarding of messages is disabled.	1
60.56	DDCS controller baud rate	Selects the communication speed of the channel selected by parameter 60.51 DDCS controller comm port.	4 mbps
	1 mbps	1 megabit/second.	1
	2 mbps	2 megabit/second.	2
	4 mbps	4 megabit/second.	4
	8 mbps	8 megabit/second.	8
60.57	DDCS controller link control	Defines the light intensity of the transmission LED of RDCO module channel CH0. (This parameter is effective only when parameter 60.51 DDCS controller comm port is set to RDCO CH 0. FDCO modules have a hardware transmitter current selector.)  In general, use higher values with longer fiber optic cables. The maximum setting is applicable to the maximum length of the fiber optic link. See Specifications of the fiber optic master/follower link (page 80).	10
	115	Light intensity.	

No.	Name/Value	Description	Def/FbEq16
60.58	DDCS controller comm loss time	Sets a timeout for communication with the external controller. If a communication break lasts longer than the timeout, the action specified by parameter 60.59 DDCS controller comm loss function is taken.  As a rule of thumb, this parameter should be set to at least 3 times the transmit interval of the controller.  Notes:  There is a 60-second boot-up delay immediately after power-up. During the delay, the communication break monitoring is disabled (but communication itself can be active).  With an AC800M controller, the controller detects a communication break immediately but re-establishing the communication is done at 9-second idle intervals. Also note that the sending interval of a data set is not the same as the execution interval of the application task. On ModuleBus, the sending interval is defined by controller parameter Scan Cycle Time (by default, 100 ms).	100 ms
	060000 ms	Timeout for communication with external controller.	-
60.59	DDCS controller comm loss function	Selects how the drive reacts to a communication break between the drive and the external controller.	Fault
	No action	No action taken (monitoring disabled).	0
	Fault	Drive trips on 7581 DDCS controller comm loss. This only occurs if control is expected from the external controller.	1
	Last speed	Drive generates an A7CA DDCS controller comm loss warning and freezes the speed to the level the drive was operating at. This only occurs if control is expected from the external controller.  The speed is determined on the basis of actual speed using 850 ms low-pass filtering.  WARNING! Make sure that it is safe to continue operation in case of a communication break.	2
	Speed ref safe	Drive generates an A7CA DDCS controller comm loss warning and sets the speed to the speed defined by parameter 22.41 Speed ref safe (or 28.41 Frequency ref safe when frequency reference is being used). This only occurs if control is expected from the external controller.  WARNING! Make sure that it is safe to continue operation in case of a communication break.	3
	Fault always	Drive trips on 7581 DDCS controller comm loss. This occurs even though no control is expected from the external controller.	4
	Warning	Drive generates an A7CA DDCS controller comm loss warning. This occurs only if control is expected from the external controller.  WARNING! Make sure that it is safe to continue operation in case of a communication break.	5

No.	Name/Value	Description	Def/FbEq16
60.60	DDCS controller ref1 type	Selects the type and scaling of reference 1 received from the external controller. The resulting value is shown by 03.11 DDCS controller ref 1.	Auto
	Auto	Type and scaling are chosen automatically according to which reference chain (see settings <i>Torque</i> , <i>Speed</i> , <i>Frequency</i> ) the incoming reference is connected to. If the reference is not connected to any chain, no scaling is applied (as with setting <i>Transparent</i> ).	0
	Transparent	No scaling is applied.	1
	General	Generic reference without a specific unit.	2
	Torque	The scaling is defined by parameter 46.03 Torque scaling.	3
	Speed	The scaling is defined by parameter 46.01 Speed scaling.	4
	Frequency	The scaling is defined by parameter 46.02 Frequency scaling.	5
60.61	DDCS controller ref2 type	Selects the type and scaling of reference 2 received from the external controller. The resulting value is shown by 03.12 DDCS controller ref 2.  For the selections, see parameter 60.60 DDCS controller ref1 type.	Auto
60.62	DDCS controller act1 type	Selects the type/source and scaling of actual value ACT1 transmitted to the external controller.	Auto
	Auto	Type/source and scaling follow the type of reference 1 selected by parameter 60.60 DDCS controller ref1 type. See the individual settings below for the sources and scalings.	0
	Transparent	Reserved.	1
	General	Reserved.	2
	Torque	01.10 Motor torque is sent as actual value 1. The scaling is defined by parameter 46.03 Torque scaling.	3
	Speed	01.01 Motor speed used is sent as actual value 1. The scaling is defined by parameter 46.01 Speed scaling.	4
	Frequency	01.06 Output frequency is sent as actual value 1. The scaling is defined by parameter 46.02 Frequency scaling.	5
60.63	DDCS controller act2 type	Selects the type/source and scaling of actual value ACT2 transmitted to the external controller.	Auto
	Auto	Type/source and scaling follow the type of reference 2 selected by parameter 60.61 DDCS controller ref2 type. See the individual settings below for the sources and scalings.	0
	Transparent	Reserved.	1
	General	Reserved.	2
	Torque	01.10 Motor torque is sent as actual value 2. The scaling is defined by parameter 46.03 Torque scaling.	3
	Speed	01.01 Motor speed used is sent as actual value 2. The scaling is defined by parameter 46.01 Speed scaling.	4
	Frequency	01.06 Output frequency is sent as actual value 2. The scaling is defined by parameter 46.02 Frequency scaling.	5
60.64	Mailbox dataset selection	Selects the pair of data sets used by the mailbox service in the drive/controller communication.  See section External controller interface (page 81).	Dataset 32/33
	Dataset 32/33	Data sets 32 and 33.	0

No.	Name/V	alue	Description	Def/FbEq16
	Dataset	24/25	Data sets 24 and 25.	1
60.65	DDCS controller comm supervision force		Activates DDCS controller communication monitoring separately for each control location (see section <i>Local control vs. external control</i> on page <i>40</i> ).  The parameter is primarily intended for monitoring the communication with the controller when it is connected to the application program and not selected as a control source by drive parameters.	0000b
	Bit	Name	Value	
	0	Ext 1	1 = Communication monitoring active when Ext 1 is bein	ig used.
	1	Ext 2	1 = Communication monitoring active when Ext 2 is being	_
	2	Local	1 = Communication monitoring active when local control	_
			used.	J
	315	Reserved		
	00001-	01115	DDCC controller communication manufacture and leading	1 - 4
	0000b		DDCS controller communication monitoring selection.	1 = 1
60.71	INU-LSU commur	J nication port	(Visible only when supply unit control is activated by 95.20) Selects the DDCS channel used for connecting to another converter (such as a supply unit). The selections available, as well as the default, depend on drive hardware. See also section Control of a supply unit (LSU) (page 83).	see text
	Not in us	se	None (communication disabled).	0
	RDCO C	CH 1	Channel 1 on RDCO module.	11
	DDCS v	ia BC	Connector X201.	15
60.77	INU-LSU	J link control	(Visible only when supply unit control is activated by 95.20) Defines the light intensity of the transmission LED of RDCO module channel CH1. (This parameter is effective only when parameter 60.71 INU-LSU communication port is set to RDCO CH 1. FDCO modules have a hardware transmitter current selector.) In general, use higher values with longer fiber optic cables.	10
			The maximum setting is applicable to the maximum length of the fiber optic link. See <i>Specifications of the fiber optic master/follower link</i> (page 80).	
	115		Light intensity.	
60.78	INU-LSU timeout	J comm loss	(Visible only when supply unit control is activated by 95.20) Sets a timeout for communication with another converter (such as the supply unit). If a communication break lasts longer than the timeout, the action specified by parameter 60.79 INU-LSU comm loss function is taken.	100 ms
	06553	35 ms	Timeout for communication between converters.	
60.79	INU-LSU function	J comm loss	(Visible only when supply unit control is activated by 95.20) Selects how the inverter unit reacts to a communication break between the inverter unit and the other converter (typically the supply unit).  WARNING! With settings other than Fault, the inverter unit continues operating based on the status information last received from the other converter.  Make sure this does not cause danger.	Fault
	No actio	n	No action taken.	0
	No actio	n	information last received from the other converter.  Make sure this does not cause danger.	0

No. Name/Value	Description	Def/FbEq16
Warning	The drive generates a warning (AF80 INU-LSU comm loss).	1
Fault	Drive trips on 7580 INU-LSU comm loss.	2

	D and DDCS nit data	Defines the data sent to the DDCS link. See also parameter group 60 DDCS communication.	
61.01	M/F data 1 selection	Preselects the data to be sent as word 1 onto the master/follower link.  See also parameter 61.25 M/F data 1 value, and section Master/follower functionality (page 74).	Follower CW
	None	None.	0
	CW 16bit	Control Word (16 bits)	1
	SW 16bit	Status Word (16 bits)	4
	Act1 16bit	Actual value ACT1 (16 bits)  Note: Using this setting to send a reference to the follower is not recommended as the source signal is filtered. Use the "reference" selections instead.	5
	Act2 16bit	Actual value ACT2 (16 bits)  Note: Using this setting to send a reference to the follower is not recommended as the source signal is filtered. Use the "reference" selections instead.	6
	Follower CW	A word consisting of bits 011 of 06.01 Main control word and the bits selected by parameters 06.4506.48.  Note: Bit 3 of the follower control word is kept on as long as the master is modulating, and when it switches to 0, the follower coasts to a stop.	27
	Used speed reference	24.01 Used speed reference (page 274).	6145
	Torque reference act 5	26.75 Torque reference act 5 (page 297).	6731
	Torque reference used	26.02 Torque reference used (page 290).	6658
	ACS800 System ctrl SW	A follower status word compatible with an ACS800 (System Control Program) master. With this setting, status word bit 0 is cleared whenever the run enable signal is missing.	28
	Follower CW B6 high	Otherwise identical to selection <i>Follower CW</i> , but bit 6 of the follower control word is also kept on as long as the master is modulating. This will allow the follower to stop along the stop ramp of the master.	29
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
61.02	M/F data 2 selection	Preselects the data to be sent as word 2 onto the master/follower link.  See also parameter 61.26 M/F data 2 value.  For the selections, see parameter 61.01 M/F data 1 selection.	Used speed reference
61.03	M/F data 3 selection	Preselects the data to be sent as word 3 onto the master/follower link.  See also parameter 61.27 M/F data 3 value.  For the selections, see parameter 61.01 M/F data 1 selection.	Torque reference act 5

No.	Name/Value	Description	Def/FbEq16
61.25	M/F data 1 value	Displays the data to be sent onto the master/follower link as word 1 as an integer.  If no data has been preselected by 61.01 M/F data 1 selection, the value to be sent can be written directly into this parameter.	0
	065535	Data to be sent as word 1 in master/follower communication.	
61.26	M/F data 2 value	Displays the data to be sent onto the master/follower link as word 2 as an integer.  If no data has been preselected by 61.02 M/F data 2 selection, the value to be sent can be written directly into this parameter.	0
	065535	Data to be sent as word 2 in master/follower communication.	
61.27	M/F data 3 value	Displays the data to be sent onto the master/follower link as word 3 as an integer.  If no data has been preselected by 61.03 M/F data 3 selection, the value to be sent can be written directly into this parameter.	0
	065535	Data to be sent as word 3 in master/follower communication.	
61.45	Data set 2 data 1 selection	Parameters 61.4561.50 preselect data to be sent in data sets 2 and 4 to the external controller. These data sets are used in ModuleBus communication with a "standard drive" (60.50 DDCS controller drive type = ABB standard drive). Parameters 61.9561.100 display the data to be sent to the external controller. If no data has been preselected, the value to be sent can be written directly into these parameters.  For example, this parameter preselects the data for word 1 of data set 2. Parameter 61.95 Data set 2 data 1 value displays the selected data in integer format. If no data is preselected, the value to be sent can be written directly into parameter 61.95.	None
	None	None.	0
	CW 16bit	Control Word (16 bits)	1
	SW 16bit	Status Word (16 bits)	4
	Act1 16bit	Actual value ACT1 (16 bits)	5
	Act2 16bit	Actual value ACT2 (16 bits)	6
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
61.46	Data set 2 data 2 selection	Preselects the data to be sent as word 2 of data set 2 to the external controller.  See also parameter 61.96 Data set 2 data 2 value.  For the selections, see parameter 61.45 Data set 2 data 1 selection.	None
61.47	Data set 2 data 3 selection	See parameter 61.45 Data set 2 data 1 selection.	None
61.50	Data set 4 data 3 selection	See parameter 61.45 Data set 2 data 1 selection.	None

No.	Name/Value	Description	Def/FbEq16
61.51	Data set 11 data 1 selection	Parameters 61.5161.74 preselect data to be sent in data sets 11, 13, 15, 17, 19, 21, 23 and 25 to the external controller.  Parameters 61.10161.124 display the data to be sent to	None
		the external controller. If no data has been preselected, the value to be sent can be written directly into these parameters.	
		For example, this parameter preselects the data for word 1 of data set 11. Parameter 61.101 Data set 11 data 1 value displays the selected data in integer format. If no data is preselected, the value to be sent can be written directly into parameter 61.101.	
	None	None.	0
	CW 16bit	Control Word (16 bits)	1
	SW 16bit	Status Word (16 bits)	4
	Act1 16bit	Actual value ACT1 (16 bits)	5
	Act2 16bit	Actual value ACT2 (16 bits)	6
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
61.52	Data set 11 data 2 selection	Preselects the data to be sent as word 2 of data set 11 to the external controller.	None
		See also parameter 61.102 Data set 11 data 2 value. For the selections, see parameter 61.51 Data set 11 data 1 selection.	
61.53	Data set 11 data 3 selection	Preselects the data to be sent as word 3 of data set 11 to the external controller.  See also parameter 61.103 Data set 11 data 3 value.  For the selections, see parameter 61.51 Data set 11 data 1 selection.	None
61.54	Data set 13 data 1 selection	See parameter 61.51 Data set 11 data 1 selection.	None
61.74	Data set 25 data 3 selection	See parameter 61.51 Data set 11 data 1 selection.	None
61.95	Data set 2 data 1 value	Displays (in integer format) the data to be sent to the external controller as word 1 of data set 2.	0
		If no data has been preselected by 61.45 Data set 2 data 1 selection, the value to be sent can be written directly into this parameter.	
	065535	Data to be sent as word 1 of data set 2.	
61.96	Data set 2 data 2 value	Displays (in integer format) the data to be sent to the external controller as word 2 of data set 2.  If no data has been preselected by 61.46 Data set 2 data 2 selection, the value to be sent can be written directly into this parameter.	0
	065535	Data to be sent as word 2 of data set 2.	
61.97	Data set 2 data 3 value	Displays (in integer format) the data to be sent to the external controller as word 3 of data set 2.  If no data has been preselected by 61.47 Data set 2 data 3 selection, the value to be sent can be written directly into this parameter.	0
	065535	Data to be sent as word 3 of data set 2.	

No.	Name/Value	Description	Def/FbEq16
61.100	Data set 4 data 3 value	Displays (in integer format) the data to be sent to the external controller as word 3 of data set 4.  If no data has been selected by 61.50 Data set 4 data 3 selection, the value to be sent can be written directly into this parameter.	0
	065535	Data to be sent as word 3 of data set 4.	
61.101	Data set 11 data 1 value	Displays (in integer format) the data to be sent to the external controller as word 1 of data set 11.  If no data has been preselected by 61.51 Data set 11 data 1 selection, the value to be sent can be written directly into this parameter.	0
	065535	Data to be sent as word 1 of data set 11.	
61.102	Data set 11 data 2 value	Displays (in integer format) the data to be sent to the external controller as word 2 of data set 11.  If no data has been preselected by 61.52 Data set 11 data 2 selection, the value to be sent can be written directly into this parameter.	0
	065535	Data to be sent as word 2 of data set 11.	
61.103	Data set 11 data 3 value	Displays (in integer format) the data to be sent to the external controller as word 3 of data set 11.  If no data has been selected by 61.53 Data set 11 data 3 selection, the value to be sent can be written directly into this parameter.	0
	065535	Data to be sent as word 3 of data set 11.	
61.104	Data set 13 data 1 value	Displays (in integer format) the data to be sent to the external controller as word 1 of data set 13. If no data has been selected by 61.54 Data set 13 data 1 selection, the value to be sent can be written directly into this parameter.	0
	065535	Data to be sent as word 1 of data set 13.	
61.124	Data set 25 data 3 value	Displays (in integer format) the data to be sent to the external controller as word 3 of data set 25.  If no data has been selected by 61.74 Data set 25 data 3 selection, the value to be sent can be written directly into this parameter.	0
	065535	Data to be sent as word 3 of data set 25.	

No.	Name/Value	Description	Def/FbEq16
61.151	INU-LSU Data set 10 data 1 sel	(Parameters 61.15161.203 are visible only when supply unit control is activated by 95.20)  Parameters 61.15161.153 preselect data to be sent in data sets 10, 12, 14, 16, 18, 20, 22, 24 and 32 to another converter. (Data set 32 is typically used by the mailbox function.)  Parameters 61.20161.203 display the data to be sent to the other converter. If no data has been preselected, the value to be sent can be written directly into these parameters.  For example, this parameter preselects the data for word 1 of data set 10. Parameter 61.201 INU-LSU Data set 10 data 1 value displays the selected data in integer format. If no data is preselected, the value to be sent can be written directly into parameter 61.201.	LSU CW
	None	None.	0
	LSU CW	Control word for the supply unit.	22
	DC voltage reference	94.20 DC voltage reference (page 499).	24084
	Reactive power reference	94.30 Reactive power reference (page ).	24094
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
61.152	INU-LSU Data set 10 data 2 sel	Preselects the data to be sent as word 2 of data set 10 to the other converter.  See also parameter 61.202 INU-LSU Data set 10 data 2 value.  For the selections, see parameter 61.151 INU-LSU Data set 10 data 1 sel.	DC voltage reference
61.153	INU-LSU Data set 10 data 3 sel	Preselects the data to be sent as word 3 of data set 10 to the other converter.  See also parameter 61.203 INU-LSU Data set 10 data 3 value.  For the selections, see parameter 61.151 INU-LSU Data set 10 data 1 sel.	Reactive power reference
61.201	INU-LSU Data set 10 data 1 value	Displays (in integer format) the data to be sent to the other converter as word 1 of data set 10.  If no data has been preselected by 61.151 INU-LSU Data set 10 data 1 sel, the value to be sent can be written directly into this parameter.	0
	065535	Data to be sent as word 1 of data set 10.	
61.202	INU-LSU Data set 10 data 2 value	Displays (in integer format) the data to be sent to the other converter as word 2 of data set 10.  If no data has been preselected by 61.152 INU-LSU Data set 10 data 2 sel, the value to be sent can be written directly into this parameter.	0
	065535	Data to be sent as word 2 of data set 10.	
61.203	INU-LSU Data set 10 data 3 value	Displays (in integer format) the data to be sent to the other converter as word 3 of data set 10.  If no data has been selected by 61.153 INU-LSU Data set 10 data 3 sel, the value to be sent can be written directly into this parameter.	0
	065535	Data to be sent as word 3 of data set 10.	
		1	l

No.	Name/Value	Description	Def/FbEq16
62 D2D	and DDCS data	Mapping of data received through the DDCS link. See also parameter group 60 DDCS communication.	
62.01	M/F data 1 selection	(Follower only) Defines a target for the data received as word 1 from the master through the master/follower link. See also parameter 62.25 MF data 1 value.	None
	None	None.	0
	CW 16bit	Control Word (16 bits)	1
	Ref1 16bit	Reference REF1 (16 bits)	2
	Ref2 16bit	Reference REF2 (16 bits)	3
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
62.02	M/F data 2 selection	(Follower only) Defines a target for the data received as word 2 from the master through the master/follower link. See also parameter 62.26 MF data 2 value. For the selections, see parameter 62.01 M/F data 1 selection.	None
62.03	M/F data 3 selection	(Follower only) Defines a target for the data received as word 3 from the master through the master/follower link. See also parameter 62.27 MF data 3 value. For the selections, see parameter 62.01 M/F data 1 selection.	None
62.04	Follower node 2 data 1 sel	Defines a target for the data received as word 1 from the first follower (i.e. the follower with node address 2) through the master/follower link.  See also parameter 62.28 Follower node 2 data 1 value.	None
	None	None.	0
	Follower SW	Status word of the follower. See also parameter 60.18 Follower enable.	26
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
62.05	Follower node 2 data 2 sel	Defines a target for the data received as word 2 from the first follower (i.e. the follower with node address 2) through the master/follower link.  See also parameter 62.29 Follower node 2 data 2 value.  For the selections, see parameter 62.04 Follower node 2 data 1 sel.	None
62.06	Follower node 2 data 3 sel	Defines a target for the data received as word 3 from the first follower (i.e. the follower with node address 2) through the master/follower link.  See also parameter 62.30 Follower node 2 data 3 value.  For the selections, see parameter 62.04 Follower node 2 data 1 sel.	None
62.07	Follower node 3 data 1 sel	Defines a target for the data received as word 1 from the second follower (i.e. the follower with node address 3) through the master/follower link.  See also parameter 62.31 Follower node 3 data 1 value.  For the selections, see parameter 62.04 Follower node 2 data 1 sel.	None

No.	Name/Value	Description	Def/FbEq16
62.08	Follower node 3 data 2 sel	Defines a target for the data received as word 2 from the second follower (i.e. the follower with node address 3) through the master/follower link.  See also parameter 62.32 Follower node 3 data 2 value.  For the selections, see parameter 62.04 Follower node 2 data 1 sel.	None
62.09	Follower node 3 data 3 sel	Defines a target for the data received as word 3 from the second follower (i.e. the follower with node address 3) through the master/follower link.  See also parameter 62.33 Follower node 3 data 3 value.  For the selections, see parameter 62.04 Follower node 2 data 1 sel.	None
62.10	Follower node 4 data 1 sel	Defines a target for the data received as word 1 from the third follower (i.e. the follower with node address 4) through the master/follower link.  See also parameter 62.34 Follower node 4 data 1 value.  For the selections, see parameter 62.04 Follower node 2 data 1 sel.	None
62.11	Follower node 4 data 2 sel	Defines a target for the data received as word 2 from the third follower (i.e. the follower with node address 4) through the master/follower link.  See also parameter 62.35 Follower node 4 data 2 value.  For the selections, see parameter 62.04 Follower node 2 data 1 sel.	None
62.12	Follower node 4 data 3 sel	Defines a target for the data received as word 3 from the third follower (i.e. the follower with node address 4) through the master/follower link.  See also parameter 62.36 Follower node 4 data 3 value.  For the selections, see parameter 62.04 Follower node 2 data 1 sel.	None
62.25	MF data 1 value	(Follower only) Displays, in integer format, the data received from the master as word 1.  Parameter 62.01 M/F data 1 selection can be used to select a target for the received data. This parameter can also be used as a signal source by other parameters.	0
	065535	Data received as word 1 in master/follower communication.	
62.26	MF data 2 value	(Follower only) Displays, in integer format, the data received from the master as word 2.  Parameter 62.02 M/F data 2 selection can be used to select a target for the received data. This parameter can also be used as a signal source by other parameters.	0
	065535	Data received as word 2 in master/follower communication.	
62.27	MF data 3 value	(Follower only) Displays, in integer format, the data received from the master as word 3.  Parameter 62.03 M/F data 3 selection can be used to select a target for the received data. This parameter can also be used as a signal source by other parameters.	0
	065535	Data received as word 3 in master/follower communication.	
62.28	Follower node 2 data 1 value	Displays, in integer format, the data received from the first follower (i.e. follower with node address 2) as word 1.  Parameter 62.04 Follower node 2 data 1 sel can be used to select a target for the received data. This parameter can also be used as a signal source by other parameters.	0
	065535	Data received as word 1 from follower with node address 2.	

No.	Name/Value	Description	Def/FbEq16
62.29	Follower node 2 data 2 value	Displays, in integer format, the data received from the first follower (i.e. follower with node address 2) as word 2.  Parameter 62.05 Follower node 2 data 2 sel can be used to select a target for the received data. This parameter can also be used as a signal source by other parameters.	0
	065535	Data received as word 2 from follower with node address 2.	
62.30	Follower node 2 data 3 value	Displays, in integer format, the data received from the first follower (i.e. follower with node address 2) as word 3.  Parameter 62.06 Follower node 2 data 3 sel can be used to select a target for the received data. This parameter can also be used as a signal source by other parameters.	0
	065535	Data received as word 3 from follower with node address 2.	
62.31	Follower node 3 data 1 value	Displays, in integer format, the data received from the second follower (i.e. follower with node address 3) as word 1.  Parameter 62.07 Follower node 3 data 1 sel can be used to select a target for the received data. This parameter can also be used as a signal source by other parameters.	0
	065535	Data received as word 1 from follower with node address 3.	
62.32	Follower node 3 data 2 value	Displays, in integer format, the data received from the second follower (i.e. follower with node address 3) as word 2.  Parameter 62.08 Follower node 3 data 2 sel can be used to select a target for the received data. This parameter can also be used as a signal source by other parameters.	0
	065535	Data received as word 2 from follower with node address 3.	
62.33	Follower node 3 data 3 value	Displays, in integer format, the data received from the second follower (i.e. follower with node address 3) as word 3.  Parameter 62.09 Follower node 3 data 3 sel can be used to select a target for the received data. This parameter can also be used as a signal source by other parameters.	0
	065535	Data received as word 3 from follower with node address 3.	
62.34	Follower node 4 data 1 value	Displays, in integer format, the data received from the third follower (i.e. follower with node address 4) as word 1.  Parameter 62.10 Follower node 4 data 1 sel can be used to select a target for the received data. This parameter can also be used as a signal source by other parameters.	0
	065535	Data received as word 1 from follower with node address 4.	
62.35	Follower node 4 data 2 value	Displays, in integer format, the data received from the third follower (i.e. follower with node address 4) as word 2.  Parameter 62.11 Follower node 4 data 2 sel can be used to select a target for the received data. This parameter can also be used as a signal source by other parameters.	0
	065535	Data received as word 2 from follower with node address 4.	
62.36	Follower node 4 data 3 value	Displays, in integer format, the data received from the third follower (i.e. follower with node address 4) as word 3.  Parameter 62.12 Follower node 4 data 3 sel can be used to select a target for the received data. This parameter can also be used as a signal source by other parameters.	0

lo.	Name/	Value	Description	Def/FbEq16
2.37	M/F communication status 1		In the master, displays the status of the communication with followers specified by parameter 60.19 M/F comm supervision sel 1. In a follower, bit 0 indicates the status of the communication with the master.	-
	Bit	Name	Description	
	0	Follower 1	1 (in the master) = Communication with follower 1 OK. 1 (in a follower) = Communication with master OK.	
	1	Follower 2	1 = Communication with follower 2 OK.	
	15	Follower 16	1 = Communication with follower 16 OK.	
	0000h.	FFFFh	M/F communication status (followers 116).	1 = 1
62.38	M/F co status	mmunication 2	In the master, displays the status of the communication with followers specified by parameter 60.20 M/F comm supervision sel 2.	-
	Bit	Name	Description	
	0	Follower 17	1 = Communication with follower 17 OK.	
	1	Follower 18	1 = Communication with follower 18 OK.	
	15	Follower 32	1 = Communication with follower 32 OK.	
	0000hFFFFh N		M/F communication status (followers 1732).	1 = 1
2.41	status 1		In the master, displays the ready status of the communication with followers specified by parameter 60.23 M/F status supervision sel 1.	
	Bit	Name	Description	
	0	Follower 1	1 = Follower 1 ready.	
	1	Follower 2	1 = Follower 2 ready.	
	15	Follower 16	1 = Follower 16 ready.	
	0000h.	FFFFh	Follower 116 ready status.	1 = 1
		lower ready	In the master, displays the ready status of the communication with followers specified by parameter 60.24	-
2.42	status .	2	M/F status supervision sel 2.	
2.42		2 Name	M/F status supervision sel 2.	
2.42	status		M/F status supervision sel 2.  Description	
2.42	status .	Name	M/F status supervision sel 2.  Description 1 = Follower 17 ready.	
2.42	Status .	Name Follower 17	M/F status supervision sel 2.  Description 1 = Follower 17 ready.	
2.42	Bit 0 1	Name Follower 17	Description 1 = Follower 17 ready. 1 = Follower 18 ready	
2.42	Bit 0 1	Name Follower 17 Follower 18	Description 1 = Follower 17 ready. 1 = Follower 18 ready	

No.	Name/Value	Description	Def/FbEq16
62.45	Data set 1 data 1 selection	Parameters 62.4562.50 define a target for the data received in data sets 1 and 3 from the external controller. These data sets are used in ModuleBus communication with a "standard drive" (60.50 DDCS controller drive type = ABB standard drive).  Parameters 62.9562.100 display the data received from the external controller in integer format, and can be used as sources by other parameters.  For example, this parameter selects a target for word 1 of data set 1. Parameter 62.95 Data set 1 data 1 value displays the received data in integer format, and can also be used as a source by other parameters.	None
	None	None.	0
	CW 16bit	Control Word (16 bits)	1
	Ref1 16bit	Reference REF1 (16 bits)	2
	Ref2 16bit	Reference REF2 (16 bits)	3
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
62.46	Data set 1 data 2 selection	Defines a target for the data received as word 2 of data set 1.  See also parameter 62.96 Data set 1 data 2 value. For the selections, see parameter 62.45 Data set 1 data 1 selection.	None
62.47	Data set 1 data 3 selection	See parameter 62.45 Data set 1 data 1 selection.	None
62.50	Data set 3 data 3 selection	See parameter 62.45 Data set 1 data 1 selection.	None
62.51	Data set 10 data 1 selection	Parameters 62.5162.74 define a target for the data received in data sets 10, 12, 14, 16, 18, 20, 22 and 24 from the external controller.  Parameters 62.10162.124 display the data received from the external controller in integer format, and can be used as sources by other parameters.  For example, this parameter selects a target for word 1 of data set 10. Parameter 62.101 Data set 10 data 1 value displays the received data in integer format, and can also be used as a source by other parameters.	None
	None	None.	0
	CW 16bit	Control Word (16 bits)	1
	Ref1 16bit	Reference REF1 (16 bits)	2
	Ref2 16bit	Reference REF2 (16 bits)	3
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
62.52	Data set 10 data 2 selection	Defines a target for the data received as word 2 of data set 10.  See also parameter 62.102 Data set 10 data 2 value.  For the selections, see parameter 62.51 Data set 10 data 1 selection.	None

No.	Name/Value	Description	Def/FbEq16
62.53	Data set 10 data 3 selection	Defines a target for the data received as word 3 of data set 10.  See also parameter 62.103 Data set 10 data 3 value.  For the selections, see parameter 62.51 Data set 10 data 1 selection.	None
62.54	Data set 12 data 1 selection	See parameter 62.51 Data set 10 data 1 selection.	None
62.74	Data set 24 data 3 selection	See parameter 62.51 Data set 10 data 1 selection.	None
62.95	Data set 1 data 1 value	Displays (in integer format) the data received from the external controller as word 1 of data set 1.  A target for this data can be selected by parameter 62.45  Data set 1 data 1 selection. The value can also be used as a source by another parameter.	0
	065535	Data received as word 1 of data set 1.	
62.96	Data set 1 data 2 value	Displays (in integer format) the data received from the external controller as word 2 of data set 1.  A target for this data can be selected by parameter 62.46  Data set 1 data 2 selection. The value can also be used as a source by another parameter.	0
	065535	Data received as word 2 of data set 1.	
62.97	Data set 1 data 3 value	Displays (in integer format) the data received from the external controller as word 3 of data set 1.  A target for this data can be selected by parameter 62.47  Data set 1 data 3 selection. The value can also be used as a source by another parameter.	0
	065535	Data received as word 3 of data set 1.	
62.100	Data set 3 data 3 value	Displays (in integer format) the data received from the external controller as word 3 of data set 3.  A target for this data can be selected by parameter 62.50  Data set 3 data 3 selection. The value can also be used as a source by another parameter.	0
	065535	Data received as word 3 of data set 3.	
62.101	Data set 10 data 1 value	Displays (in integer format) the data received from the external controller as word 1 of data set 10.  A target for this data can be selected by parameter 62.51  Data set 10 data 1 selection. The value can also be used as a source by another parameter.	0
	065535	Data received as word 1 of data set 10.	
62.102	Data set 10 data 2 value	Displays (in integer format) the data received from the external controller as word 2 of data set 10.  A target for this data can be selected by parameter 62.52  Data set 10 data 2 selection. The value can also be used as a source by another parameter.	0
	065535	Data received as word 2 of data set 10.	

No.	Name/Value	Description	Def/FbEq16
62.103	Data set 10 data 3 value	Displays (in integer format) the data received from the external controller as word 3 of data set 10.  A target for this data can be selected by parameter 62.53  Data set 10 data 3 selection. The value can also be used as a source by another parameter.	0
	065535	Data received as word 3 of data set 10.	
62.104	Data set 12 data 1 value	Displays (in integer format) the data received from the external controller as word 1 of data set 12.  A target for this data can be selected by parameter 62.54  Data set 12 data 1 selection. The value can also be used as a source by another parameter.	0
	065535	Data received as word 1 of data set 12.	
62.124	Data set 24 data 3 value	Displays (in integer format) the data received from the external controller as word 3 of data set 24.  A target for this data can be selected by parameter 62.74  Data set 24 data 3 selection. The value can also be used as a source by another parameter.	0
	065535	Data received as word 3 of data set 24.	
62.151	INU-LSU data set 11 data 1 sel	(Parameters 62.15162.203 are visible only when supply unit control is activated by 95.20)  Parameters 62.15162.153 define a target for the data received in data sets 11, 13, 15, 17, 19, 21, 23, 25 and 33 from another converter. (Data set 33 is typically used by the mailbox function.)  Parameters 62.20162.203 display the data received from the other converter in integer format, and can be used as sources by other parameters.  For example, this parameter selects a target for word 1 of data set 11. Parameter 62.201 INU-LSU data set 11 data 1 value displays the received data in integer format, and can also be used as a source by other parameters.	LSU SW
	None	None.	0
	LSU SW	Status word of the supply unit.	4
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
62.152	INU-LSU data set 11 data 2 sel	Defines a target for the data received as word 2 of data set 11.  See also parameter 62.202 INU-LSU data set 11 data 2 value.  For the selections, see parameter 62.151 INU-LSU data set 11 data 1 sel.	None
62.153	INU-LSU data set 11 data 3 sel	Defines a target for the data received as word 3 of data set 11.  See also parameter 62.203 INU-LSU data set 11 data 3 value.  For the selections, see parameter 62.151 INU-LSU data set 11 data 1 sel.	None

No.	Name/Value	Description	Def/FbEq16
62.201	INU-LSU data set 11 data 1 value	Displays (in integer format) the data received from the other converter as word 1 of data set 11.  A target for this data can be selected by parameter 62.151 INU-LSU data set 11 data 1 sel. The value can also be used as a source by another parameter.	0
	065535	Data received as word 1 of data set 11.	
62.202	INU-LSU data set 11 data 2 value	Displays (in integer format) the data received from the other converter as word 2 of data set 11.  A target for this data can be selected by parameter 62.152 INU-LSU data set 11 data 2 sel. The value can also be used as a source by another parameter.	0
	065535	Data received as word 2 of data set 11.	
62.203	INU-LSU data set 11 data 3 value	Displays (in integer format) the data received from the other converter as word 3 of data set 11.  A target for this data can be selected by parameter 62.153 INU-LSU data set 11 data 3 sel. The value can also be used as a source by another parameter.	0
	065535	Data received as word 3 of data set 11.	

74 Ap	plication setup	Winder control and setup.	
74.05	Winding mode	Selects whether the driven machine acts as a winder or unwinder.	Winder
	Winder	Material is wound to the core.	0
	Unwinder	Material is unwound from the roll.	1
	Winder cw bit 0	Driven machine acts as  • winder, if parameter 74.49 Winder control word, bit 0 = 0  • unwinder, if parameter 74.49 Winder control word, bit 0 = 1	2
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
74.06	Motor direction	Selects the direction of the motor rotation.	Positive
	Positive	Motor rotates clockwise. The speed reference goes positive.	0
	Negative	Motor rotates counterclockwise. The speed reference goes negative.	1
	Winder cw bit 1	<ul> <li>Motor rotates in</li> <li>positive direction, if parameter 74.49 Winder control word, bit 1 = 1</li> <li>negative direction, if parameter 74.49 Winder control word, bit 1 = 0</li> </ul>	2
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
74.11	Gear ratio 1	Defines the gear coefficient value 1 between the motor and driven load.  Example: You can set the value as 2 if the motor rotates two rounds for one round of spindle rotation (2:1).	1.000
	0.01032767.000	Gear coefficient value.	1000 = 1
74.12	Gear ratio 2	Defines the gear coefficient value 2 between the motor and driven load.  Example: You can set the value as 2 if the motor rotates two rounds for one round of spindle rotation (2:1).	1.000

No.	Name/Value	Description		Def/FbEq16
	0.01032767.000	Gear coefficient val	ue.	1000 = 1
74.13	Gear 1/2 selection	Selects the gear co program.	efficient 1 or 2 used by the control	Gear ratio 1
	Gear ratio 1	Uses value set in p	arameter 74.11 Gear ratio 1.	0
	Gear ratio 2	Uses value set in p	arameter 74.12 Gear ratio 2.	1
	Other	Source selection (s 156).	ee Terms and abbreviations on page	-
74.21	Material Thickness	winding application	al thickness in millimeters. For a wire- , enter a value equivalent to the wire the number of turns needed to complete e spool.	0.150 mm
	0.010 32767.000 mm	Material thickness.		1000 = 1 mm
74.22	Material Width	Defines the roll lay-	down width.	500.0 mm
	0.032767.0 mm	Roll lay-down width		10 = 1 mm
74.23	Material Density	gives examples of o winding application density of the mate	of the web material. The table below densities for some materials. In a wire, density values smaller than the actual rial can be used since the material is not evenly to the spool and the inertia will er.	100.0 kg/m <sup>3</sup>
		Material	Density (kg/m³)	
		Steel	7800	
		Aluminium	2700	
		Copper	8960	
		Paper	7001200	
		Rubber (soft)	9001100	
		Nylon	1100	
		Wool	1300	
	0.0 32767.0 kg/m <sup>3</sup>	Density of the web	material.	10 = 1 kg/m <sup>3</sup>
74.29	Length source	Selects the source	for material length.	Estimated from Diameter
	NULL	Zero.		0
	Estimated from Diameter		stimated from parameter <i>09.11 Actual</i> d length can be checked from parameter <i>ngth</i> .	1
	Calculated by Virtual Roll	coming to the drive <b>Note:</b> When using	neasured from an encoder feedback this selection, set the virtual roll counter er group 82 Virtual Roll.	2
	Other	Source selection (s 156).	ee Terms and abbreviations on page	-

0.	Name/Value	Description	Def/FbEq16
4.49	Winder control word	Winder control word. The resulting application control word is formed of individual function. Enables/disables the parameter settings and the status of bits.  For control word logic, see diagram <i>Winder control word logic</i> on page 698. <b>Note</b> : These bits are not connected to any function by default. The bit names are existing, for which you need to make connections separately.	0b0000
Bit	Name	Description	
0	Unwind mode	1 = Command to unwind, if parameter 74.05 Winding mode = bit 0 0 = Command to wind, if parameter 74.05 Winding mode = Wi	
1	Winding dir negative	1 = Winding direction negative, if parameter 74.06 Winding m Winder cw bit 1     0 = Winding direction positive, if parameter 74.06 Winding mo cw bit 1	ode =
2	Force open loop Tctrl	1 = Force open loop control, if parameter 78.01 Force open lo cw bit 2 0 = Normal operation	op = Winder
3	Reserved		
4	Reset diameter	1 = Reset diameter, if parameter 76.11 Reset estimated diame cw bit 4 0 = Normal operation	ter = Winder
5	Preset diameter	1 = Preset diameter, if parameter 76.25 Preset estimated diar Winder cw bit 5 0 = Normal operation	meter =
6	Hold diameter count-up	1 = Diameter count-up in hold, if parameter 76.05 Count up en Winder cw bit 6 0 = Normal operation	nable =
7	Hold diameter count-down	1 = Diameter count-down in hold, if parameter 76.06 Count do Winder cw bit 7 0 = Normal operation	wn enable =

sample = Winder cw bit 8

Torque memory enable = Winder cw bit 9

77.01 Enable tension control = Winder cw bit 10

0 = Normal operation

0 = Normal operation

cw bit 10

1 = Torque memory sampling is enabled, if parameter 80.01 Take torque

1 = Memorized torque as torque reference is enabled, if parameter 80.02

1 = Regulator control (forces pure speed control) is disabled, if parameter

0 = Normal operation, if parameter 77.01 Enable tension control = Winder

8

9

10

Torque memory

Enable torque

Disable tension

sample

memory

control

o. Name/Value		Name/Value Description		
Bit	Name	Description		
11	Stall mode enable	1 = Stall mode enabled, if parameter 77.21 Stall function en Winder cw bit 11 0 = Stall mode disabled, if parameter 77.21 Stall function en Winder cw bit 11		
12	Disable inertia compensation	1 = Inertia compensation is disabled, if parameter 79.31 Ine compensation enable = Winder cw bit 12 0 = Normal operation	rtia	
13	Disable friction compensation	1 = Friction compensation is disabled, if parameter 79.11 Friction compensation enable = Winder cw bit 13 0 = Normal operation		
14	Threading forward request	1 = Threading forward is enabled, if parameter 75.21 Thread command = Winder cw bit 14 0 = Threading forward is disabled, if parameter 75.21 Thread command = Winder cw bit 14		
15	Threading reverser request	1 = Threading reverse is enabled, if parameter 75.22 Thread command = Winder cw bit 15 0 = Threading reverse is disabled, if parameter 75.22 Thread command = Winder cw bit 15		
	0b0000 0b111111	Winder control word.	1 = 1	

No.	Name/Value	Description		Def/FbEq1
74.51 Winder control status		application.	showing active control settings of the ter is read-only.	0x0000
Bit	Name		Description	
0	Winding mode unv	winder	1 = Unwinding mode active 0 = Winding mode active	
1	Winding direction	is negative	1 = Winding direction negative 0 = Winding direction positive	
2	Open loop Tctrl for	rced	1 = Force open loop control 0 = Normal operation	
3	Reserved			
4	Diameter Reset co	ommand	1 = Reset diameter 0 = Normal operation	
5	Diameter Preset of	command	1 = Preset diameter 0 = Normal operation	
6	Count up enabled		1 = Count up is enabled 0 = Count up is disabled	
7	Count down enabl	led	1 = Count down is enabled 0 = Count down is disabled	
8	Torq memory sam	ple	1 = Torque memory sampling is enabled 0 = Normal operation	
9	Torq memory enal	bled	1 = Torque memory is enabled 0 = Normal operation	
10	Tension control en	nabled	1 = Regulator control is enabled 0 = Normal operation (pure speed control)	
11	Stall function enab	oled	1 = Stall mode is enabled 0 = Stall mode is disabled	
12	Inertia compensat	ion enabled	1 = Inertia compensation is enabled 0 = Normal operation	
13	Friction compensa	ation enabled	1 = Friction compensation is enabled 0 = Normal operation	
14	Threading forward	l command	1 = Threading forward mode active 0 = Normal operation	
15	Threading reverse	command	1 = Threading reverse mode active 0 = Normal operation	
	0x0000 0xffff	Winder contr	rol status.	1 = 1
74.61	Used length	calculations.	material length used in software internal ter is read-only.	0.0 m
	0.0 100000.0 m	Material leng	th used.	10 = 1 m
74.91	Unit system	Selects the u	ısed unit system.	Metric
	Metric	Uses the Me	tric unit system.	0
	Imperial	Uses the Imp	perial unit system.	1

No.	Name/Value	Description	Def/FbEq16
75 Wir	nder speed gs	Ramping time adjustments and winder-related speed reference adaptation setup.  See section <i>Line speed</i> on page 48.	
75.01	Max line speed	Defines the maximum linear speed the production line is intended to run at.	700.0 m/min
	0.0 32767.0 m/min	Maximum speed of the machinery.	10 = 1 m/min
75.02	Line speed reference src	Selects the source for the line speed reference. The target line speed reference is defined as:  75.51 Line reference In = (75.02 Line speed reference srcl 75.03 Line reference scaling) * 75.01 Max line speed	AI1_SCALE D
	NULL	Zero.	0
	AI1_SCALED	12.12 Al1 scaled value (see page 207).	1
	AI2_SCALED	12.22 AI2 scaled value (see page 208).	2
	FBA Reference 1	03.05 FB A reference 1 (see page 165).	3
	FBA Reference 2	03.06 FB A reference 2 (see page 165).	4
	M/F or D2D Reference 1	03.13 M/F or D2D ref1 (see page 165).	5
	M/F or D2D Reference 2	03.14 M/F or D2D ref2 (see page 166).	6
	Motor Potentiometer Ref	Motor potentiometer reference. See parameter 22.80 Motor potentiometer ref act on page 267.	7
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
75.03	Line reference scaling	Defines the custom scaling factor for line speed reference. For example, if line speed reference from the fieldbus is scaled from 0 to ± 20000 (INT), then set this value to 200.00 (REAL).  Note: Reference scaling can be set to 0, then input from parameter 75.02 is interpreted directly as m/min (or ft/min) without any scaling.	200.00
	0.0032767.00	Scaling factor.	100 = 1

No.	Name/Value	Description	Def/FbEq16
75.05	Line ref source cycle time	Defines the remote control system cycle time, meaning how often the line speed reference is updated. This helps absorbing the speed reference steps (see diagram below) that occurs due to acyclic communication delays.  This value should be the longest period of time taken for the control system to transmit speed reference data to the drive.  Note: This value is required to be accurate for Inertia compensation and to avoid torque reference spikes.  Speed reference  Speed reference cycle time	6 ms
		Time	
	032767 ms	Cycle time.	1 = 1 ms
75.11	Acceleration ramp time	Defines the time for the line speed reference to increase from zero to the value defined with parameter 75.01 Max line speed.	60.00 s
	0.0032767.00 s	Ramp time for acceleration.	100 = 1 s
75.12	Deceleration ramp time	Defines the time for the line speed reference to decrease from the value defined with parameter 75.01 Max line speed to zero. This setting is active while the drive start command is TRUE.	60.00 s
	0.0032767.00 s	Ramp time for deceleration.	100 = 1 s
75.13	Stop ramp time	Defines the time within which line speed reference decelerates to zero from the value defined with parameter 75.01 Max line speed in case of stop command. This setting is active while the drive start command is FALSE.  Note: This setting is valid only when parameter 21.03 Stop mode = Ramp.	60.00 s
	0.0032767.00 s	Stop ramp time.	100 = 1 s
75.21	Thread forward command	Defines the source for the command to generate line speed reference in positive direction. Speed reference used in that instance is set in parameter 75.23 Threading forward line ref.  See also Threading on page 48.	Not selected
	Not selected	Line speed reference is not activated.	0
	Selected	Line speed reference is activated.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5

No.	Name/Value	Description	Def/FbEq16
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	8
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	9
	Winder cw bit 14	Line speed reference in positive direction activated if parameter 74.29 Winder control word, bit 14 = 1.	
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
75.22	Thread reverse command	Defines the source for the command to generate line speed reference in negative direction. Speed reference used in that instance is set in parameter 75.24 Threading reverse line ref.  See also Threading on page 48.	Not selected
	Not selected	Line speed reference is not activated.	0
	Selected	Line speed reference is activated.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	8
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	9
	Winder cw bit 15	Line speed reference in positive direction activated if parameter 74.29 Winder control word, bit 15 = 1.	
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
75.23	Threading forward line ref	Defines the line speed reference for threading in forward direction.	5.0 m/min
	0.032767.0 m/min	Line speed reference	10 = 1 m/min
75.24	Threading reverse line ref	Defines the line speed reference for threading in reverse direction.	-5.0 m/min
	-32767.0 0.0 m/min	Line speed reference	10 = 1 m/min
75.25	Threading acceleration time	Defines the line speed acceleration time used when threading is active.	60.00 s
	0.0032767.00 s	Acceleration time.	100 = 1 s
75.26	Threading deceleration time	Defines the line speed deceleration time used when threading is active.	10.00 s
	0.0032767.00 s	Deceleration time.	100 = 1 s
75.31	Overspeed ref offset	Defines the motor speed reference additive defined in percent of signal 75.61 Max motor speed at core.	2.00%
	0.00100.00%	Additional over-speed reference.	100 = 1%

No.	Name/Value	Description	Def/FbEq16
75.32	Dynamic offset trim	Defines the dynamic motor speed additive term in percent of actual overspeed reference offset and is also proportional to the line speed reference.	00.00%
	-100.00 1000.00%	Multiplier of the ramped speed reference.	100 = 1%
75.35	Speed matching enable	Enables speed matching when dancer or tension control is active or selects the source for the activation signal.	OFF TEN/DAN
	Not selected	Speed matching is disabled	0
	Selected	Speed matching is enabled	1
	OFF TEN/DAN	Disabled when tension control is On.	2
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
75.36	Speed match trim Src	Selects the signal source for the reference value for the speed match trim amount. Incoming value must be scaled between -100 and +100 [%]. Resulting trim amount depends on parameter 75.37 Speed match range.	NULL
	NULL	Zero.	0
	AI1_SCALED	12.12 Al1 scaled value (see page 207).	1
	Al2_SCALED	12.22 Al2 scaled value (see page 208).	2
	FBA Reference 1	03.05 FB A reference 1 (see page 165).	3
	FBA Reference 2	03.06 FB A reference 2 (see page 165).	4
	M/F or D2D Reference 1	03.13 M/F or D2D ref1 (see page 165).	5
	M/F or D2D Reference 2	03.14 M/F or D2D ref2 (see page 166).	6
	Motor Potentiometer Ref	Motor potentiometer reference. See parameter 22.80 Motor potentiometer ref act on page 267.	7
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
75.37	Speed match range	Defines the maximum trim allowed.  Example: If 10% is entered, a minimum input (0 V DC / 0 mA) yields a -10% trim value. A maximum input (10 V DC / 20 mA) yields a +10% trim value.	10.00%
	-500.00500.00%	Maximum trim allowed.	100 = 1%
75.41	Line speed feedback src	Selects the source for line speed feedback.	Same as line reference
	Same as line reference	Same as 75.52 Line reference ramped.	0
	Encoder1 speed scaled	Encoder1 speed scaled.	1
	Encoder2 speed scaled	Encoder2 speed scaled.	2
	Load encoder speed	Load encoder speed.	3
	Virtual Roll line speed	Virtual roll line speed reading (82.54 Detected line speed).	4

No.	Name/Value	Description	Def/FbEq16
	M/F or D2D Reference 1	03.13 M/F or D2D ref1 (see page 165).	5
	M/F or D2D Reference 2	03.14 M/F or D2D ref2 (see page 166).	6
75.42	Line feedback filter time	Defines the time for the actual line speed filtering.	0 ms
	032767 ms	Line speed filtering time.	1 = 1 ms
75.43	Line feedback feed constant	Defines the circumference of the wheel where line speed encoder is placed.	1.00000 unit/rev
	0.00000 32767.00000 unit/rev	Circumference of wheel	100000 = 1 unit/rev
75.51	Line reference In	Displays the target line speed reference value coming from the line reference source (parameter 75.02 Line speed reference src) and scaled according to the scaling parameter setting (parameters 75.03 Line reference scaling).  This parameter is read-only.	0.0 m/min
	-2147483648.0 2147483648.0 m/min	Target line speed reference.	10 = 1 m/min
75.52	Line reference ramped	Displays the line speed reference used in application reference chain at the moment considering the target line speed reference and ramp times (set with parameters 75.11 Acceleration ramp time75.13 Stop ramp time). This parameter is read-only.	0.0 m/min
	-32767.0 32767.0 m/min	Line speed reference.	10 = 1 m/min
75.58	Line act speed scaled	Displays actual line speed scaled according to parameter 75.03 Line reference scaling. This parameter is read-only.	0.00
	-32767.00 32767.00	Scaled line speed value.	100 = 1
75.59	Line speed actual	Displays the actual line speed. This parameter is read-only.	0.0 m/min
	-32767.0 32767.0 m/min	Actual line speed.	10 = 1 m/min
75.60	Roll speed actual	Displays the actual roll speed. This parameter is read-only.	0.0 rpm
	-32767.0 32767.0 rpm	Actual roll speed.	10 =1 rpm
75.61	Max motor speed at core	Displays the maximum line speed reference (given in parameter 75.01 Max line speed) converted to motor rotational speed which is the highest at diameter of an empty core (set in parameter 76.08 Core diameter). This parameter is read-only.	0.0 rpm
	-32767.0 32767.0 rpm	Maximum line speed reference converted to motor rotational speed.	10 = 1 rpm
		•	•

No.	Name/Value	Description	Def/FbEq16
75.62	Motor speed from line ref	Displays the ramped line speed reference (parameter 75.52 Line reference ramped) converted to motor rotational speed assuming the diameter of the core.  This parameter is read-only.	0.0 rpm
	-32767.0 32767.0 rpm	Ramped line speed reference converted to motor rotational speed.	10 = 1 rpm
75.63	Motor ref diameter scaled	Displays the ramped line speed reference converted to motor rotational speed considering the actual diameter (parameter 09.11 Actual diameter) of the roll.  This parameter is read-only.	0.0 rpm
	32767.0 32767.0 rpm	Ramped line speed reference converted to motor rotational speed.	10 = 1 rpm
75.66	Speed ref additive	Displays the additional speed reference for the motor. The value is calculated based on overspeed reference parameter settings (parameters 75.32 Dynamic offset trim and 75.31 Overspeed ref offset). This signal is connected to firmware parameter 24.11 Speed correction.  This parameter is read-only.	0.0 rpm
	-32767.0 32767.0 rpm	Additional speed reference for the motor.	10 = 1 rpm
75.67	Speed match trim	Displays the motor speed additive term, i.e the product of speed matching parameter settings (parameters 75.36 75.37).  This parameter is read-only.	0.0 rpm
	-32767.0 32767.0 rpm	Motor speed additive term.	10 = 1 rpm

No.	Name/Value	Description	Def/FbEq16
75.89	Speed reference status	Displays status of the winder speed settings group functions.	0b0000

Bit	Name		Description	
0	Line speed ne	gative	<ul><li>1 = Line speed reference is negative.</li><li>0 = Line speed reference is positive or stopped.</li></ul>	
1	Accelerating		1 = Accelerating now. 0 = Not accelerating.	
2	Decelerating		1 = Decelerating now. 0 = Not decelerating.	
3	Ref on target		1 = Line reference ramped is on target. 0 = Line reference ramped has not reached the target.	arget
4	Stopping		1 = Drive is performing a ramped stop. 0 = Drive is not performing a ramped stop.	
5	Speed ref bala	ancing	1 = Ramp output is preset to actual speed. 0 = Normal ramping operation.	
6	f source interp	olation		
7	Stop-ramp act	ive	1 = Stop-ramp is activated. 0 = Stop-ramp is not activated.	
8	Speed additive	e ON	1 = Tension control mode required speed additive 0 = Speed additive is not used.	<del>)</del> .
9	Speed matchin	ng ON	<ul><li>1 = Speed matching is enabled.</li><li>0 = Speed matching is disabled.</li></ul>	
10	Ready to threa	ad		
11	Threading forv	vard	1 = Threading forward now. 0 = Not threading forward.	
12	Threading rev	erse	1 = Threading reverse now. 0 = Not threading reverse.	
13	Reserved			
14	Motor speed negative		<ul><li>1 = Motor speed reference is negative.</li><li>0 = Motor speed reference is positive or stopped.</li></ul>	
15	Unwinding		1 = Speed reference sign is for Unwinding. 0 = Speed reference sign is for Winding.	
	000b1111	I		1

Diameter calculation   Diameter calculation control and setup. In winder/unwinder applications, set the parameters of this group to define the conditions and slope of the diameter calculation. In an infeeder application, set the roll diameter to parameter 76.08 Core diameter and disable diameter calculation by setting parameters 76.08 Core diameter and disable diameter calculation by setting parameters 76.07 Count up enable and 76.08 Count down enable to Not selected. The rest of the parameters in this group can be left at their default values. See section Diameter calculation on page 49.    Selects the mode for calculating the actual diameter of the roll.	No.	Name/Value	Description	Def/FbEq16
Estimated  Diameter is calculated internally as the ratio of the actual speed and the line speed reference. The rate of change of the actual diameter is limited according to the web thickness (parameter 74.21 Material Thickness) and slope estimation gain (76.35 Estimation slope gain)  External feedback  External feedback sensor value is used as the source of actual diameter.  External feedback at stop  External feedback sensor value is used as the source of actual diameter is equal to the Estimated diameter. The rate of change of the actual diameter is limited according to the web thickness.  Virtual roll  Diameter is based on wrap count by Virtual roll function (see settings in group 82 Virtual Roll)  Total Diameter feedback Src  Selects the source for actual diameter feedback.  Note: Scale the feedback signal source so that it matches accurately with the measuring range of the used diameter sensor. The control program interprets the incoming signal as defined in parameter 74.91 Unit system (in millimeters or inches).  NULL  No source selected.  Al1 SCALED  Al1 scaled is the diameter feedback source.  1 Al2 SCALED  Al2 scaled is the diameter feedback source.  Virtual Roll  Diameter  FBA Reference 1  2 3.05 FBA reference 1 (see page 165).  FBA Reference 2  3.13 M/F or D2D  Reference 2  3.13 M/F or D2D ref1 (see page 165).  M/F or D2D  Reference 2  Other  Source selection (see Terms and abbreviations on page 156).  Tother  Source selection (see Terms and abbreviations on page 156).  Defines the time for diameter filtering (1st order low pass filter). Setting this parameter helps to get rid of possible oscillations in estimated diameter (parameter 76.51 Estimated diameter filtered) when the actual speed is unstable.	76 Dia	meter calculation	In winder/unwinder applications, set the parameters of this group to define the conditions and slope of the diameter calculation.  In an infeeder application, set the roll diameter to parameter 76.08 Core diameter and disable diameter calculation by setting parameters 76.05 Count up enable and 76.06 Count down enable to Not selected. The rest of the parameters in this group can be left at their default values.	
speed and the line speed reference. The rate of change of the actual diameter is limited according to the web thickness (parameter 74.21 Material Thickness) and slope estimation gain (76.35 Estimation slope gain)  External feedback  External feedback actual diameter.  External feedback sensor value is used as the source of actual diameter.  External feedback sensor value is used as the source of actual diameter when the drive is stopped. Otherwise the actual diameter when the drive is stopped. Otherwise the actual diameter is equal to the Estimated diameter. The rate of change of the actual diameter is limited according to the web thickness.  Virtual roll  Diameter is based on wrap count by Virtual roll function (see settings in group 82 Virtual Roll)  Selects the source for actual diameter feedback.  Note: Scale the feedback signal source so that it matches accurately with the measuring range of the used diameter sensor. The control program interprets the incoming signal as defined in parameter 74.91 Unit system (in millimeters or inches).  NULL  No source selected.  Al1 SCALED  Al2 scaled is the diameter feedback source.  1 Al2 SCALED  Al2 scaled is the diameter feedback source.  2 Virtual Roll  Diameter  feedback source.  FBA Reference 1  03.05 FBA reference 1 (see page 165).  FBA Reference 2  03.06 FBA reference 2 (see page 165).  MF or D2D  Reference 2  03.14 MF or D2D ref1 (see page 166).  MF or D2D  Reference 2  Other  Source selection (see Terms and abbreviations on page 166).  Testimated diameter filtering (1st order low pass filter). Setting this parameter helps to get rid of possible oscillations in estimated diameter (parameter 76.51 Estimated diameter (parameter 76.51 Estimated diameter filtered) when the actual speed is unstable.	76.01		l	Estimated
External feedback at stop  External feedback sensor value is used as the source of actual diameter when the drive is stopped. Otherwise the actual diameter is equal to the Estimated diameter. The rate of change of the actual diameter is limited according to the web thickness.  Virtual roll  Diameter is based on wrap count by Virtual roll function (see settings in group 82 Virtual Roll)  Selects the source for actual diameter feedback.  Note: Scale the feedback signal source so that it matches accurately with the measuring range of the used diameter sensor. The control program interprets the incoming signal as defined in parameter 74.91 Unit system (in millimeters or inches).  NULL  No source selected.  Al1 SCALED  Al2 scaled is the diameter feedback source.  1 Al2 SCALED  Al2 scaled is the diameter feedback source.  2 Virtual Roll  Diameter  feedback source.  FBA Reference 1  03.05 FBA reference 1 (see page 165).  FBA Reference 2  03.06 FBA reference 2 (see page 165).  M/F or D2D  Reference 1  03.13 M/F or D2D ref1 (see page 165).  M/F or D2D  Reference 2  Other  Source selection (see Terms and abbreviations on page 156).  Defines the time for diameter filtering (1st order low pass filter). Setting this parameter helps to get rid of possible oscillations in estimated diameter (parameter 76.51). Estimated diameter filtered) when the actual speed is unstable.		Estimated	speed and the line speed reference. The rate of change of the actual diameter is limited according to the web thickness (parameter 74.21 Material Thickness) and slope estimation	0
actual diameter when the drive is stopped. Otherwise the actual diameter is equal to the Estimated diameter. The rate of change of the actual diameter is limited according to the web thickness.  Virtual roll  Diameter is based on wrap count by Virtual roll function (see settings in group 82 Virtual Roll)  Selects the source for actual diameter feedback.  Note: Scale the feedback signal source so that it matches accurately with the measuring range of the used diameter sensor. The control program interprets the incoming signal as defined in parameter 74.91 Unit system (in millimeters or inches).  NULL  No source selected.  Al1 SCALED  Al2 scaled is the diameter feedback source.  1 Al2 SCALED  Al2 scaled is the diameter feedback source.  2 Virtual Roll  Diameter  Parameter 82.61 Virtual roll diameter is the diameter feedback source.  FBA Reference 1  03.05 FBA reference 1 (see page 165).  FBA Reference 2  03.13 M/F or D2D ref1 (see page 165).  M/F or D2D  Reference 2  03.14 M/F or D2D ref2 (see page 166).  7 Reference 2  Other  Source selection (see Terms and abbreviations on page 156).  Defines the time for diameter filtering (1st order low pass filter). Setting this parameter helps to get rid of possible oscillations in estimated diameter (parameter 76.51  Estimated diameter filtered) when the actual speed is unstable.		External feedback		1
Settings in group 82 Virtual Roll   Selects the source for actual diameter feedback.   Note: Scale the feedback signal source so that it matches accurately with the measuring range of the used diameter sensor. The control program interprets the incoming signal as defined in parameter 74.91 Unit system (in millimeters or inches).   NULL   No source selected.   0			actual diameter when the drive is stopped. Otherwise the actual diameter is equal to the Estimated diameter. The rate of change of the actual diameter is limited according to the	2
Note: Scale the feedback signal source so that it matches accurately with the measuring range of the used diameter sensor. The control program interprets the incoming signal as defined in parameter 74.91 Unit system (in millimeters or inches).    NULL		Virtual roll		3
Al1 SCALED Al2 scaled is the diameter feedback source.  Al2 SCALED Al2 scaled is the diameter feedback source.  Virtual Roll Diameter Parameter 82.61 Virtual roll diameter is the diameter feedback source.  FBA Reference 1  03.05 FB A reference 1 (see page 165).  4  FBA Reference 2  03.06 FB A reference 2 (see page 165).  5  M/F or D2D Reference 1  03.13 M/F or D2D ref1 (see page 165).  6  M/F or D2D Reference 2  03.14 M/F or D2D ref2 (see page 166).  7  Cother Source selection (see Terms and abbreviations on page 156).  76.03 Actual diameter filter time Defines the time for diameter filtering (1st order low pass filter). Setting this parameter helps to get rid of possible oscillations in estimated diameter (parameter 76.51 Estimated diameter filtered) when the actual speed is unstable.	76.02		<b>Note:</b> Scale the feedback signal source so that it matches accurately with the measuring range of the used diameter sensor. The control program interprets the incoming signal as defined in parameter 74.91 Unit system (in millimeters or	NULL
Al2 SCALED  Al2 scaled is the diameter feedback source.  Virtual Roll Diameter  Parameter 82.61 Virtual roll diameter is the diameter feedback source.  FBA Reference 1  03.05 FB A reference 1 (see page 165).  FBA Reference 2  03.06 FB A reference 2 (see page 165).  M/F or D2D Reference 1  03.13 M/F or D2D ref1 (see page 165).  6  M/F or D2D Reference 2  03.14 M/F or D2D ref2 (see page 166).  7  Cother  Source selection (see Terms and abbreviations on page 156).  76.03 Actual diameter filter time  Defines the time for diameter filtering (1st order low pass filter). Setting this parameter helps to get rid of possible oscillations in estimated diameter (parameter 76.51 Estimated diameter filtered) when the actual speed is unstable.		NULL	No source selected.	0
Virtual Roll Diameter Parameter 82.61 Virtual roll diameter is the diameter feedback source.  FBA Reference 1 03.05 FB A reference 1 (see page 165).  FBA Reference 2 03.06 FB A reference 2 (see page 165).  M/F or D2D Reference 1  M/F or D2D Reference 2  03.13 M/F or D2D ref1 (see page 165).  6  M/F or D2D Reference 2  Other  Source selection (see Terms and abbreviations on page 156).  7  76.03 Actual diameter filter time  Defines the time for diameter filtering (1st order low pass filter). Setting this parameter helps to get rid of possible oscillations in estimated diameter (parameter 76.51 Estimated diameter filtered) when the actual speed is unstable.		Al1 SCALED	Al1 scaled is the diameter feedback source.	1
Diameter feedback source.  FBA Reference 1 03.05 FB A reference 1 (see page 165). 4  FBA Reference 2 03.06 FB A reference 2 (see page 165). 5  M/F or D2D Reference 1 03.13 M/F or D2D ref1 (see page 165). 6  M/F or D2D Reference 2 03.14 M/F or D2D ref2 (see page 166). 7  Other Source selection (see Terms and abbreviations on page 156). 0  76.03 Actual diameter filter time for diameter filtering (1st order low pass filter). Setting this parameter helps to get rid of possible oscillations in estimated diameter (parameter 76.51 Estimated diameter filtered) when the actual speed is unstable.		Al2 SCALED	Al2 scaled is the diameter feedback source.	2
FBA Reference 2  03.06 FB A reference 2 (see page 165).  M/F or D2D Reference 1  03.13 M/F or D2D ref1 (see page 165).  6  M/F or D2D Reference 2  03.14 M/F or D2D ref2 (see page 166).  7  Source selection (see Terms and abbreviations on page 156).  76.03 Actual diameter filter time  Defines the time for diameter filtering (1st order low pass filter). Setting this parameter helps to get rid of possible oscillations in estimated diameter (parameter 76.51 Estimated diameter filtered) when the actual speed is unstable.				3
M/F or D2D Reference 1  M/F or D2D Reference 2  Other  Source selection (see Terms and abbreviations on page 156).  7  7  7  7  7  7  7  7  7  7  7  7  7		FBA Reference 1	03.05 FB A reference 1 (see page 165).	4
Reference 1  M/F or D2D Reference 2  Other  Source selection (see Terms and abbreviations on page 156).  7  7  7  7  7  7  7  7  7  7  7  7  7		FBA Reference 2	03.06 FB A reference 2 (see page 165).	5
Reference 2   Source selection (see <i>Terms and abbreviations</i> on page 156).   -			03.13 M/F or D2D ref1 (see page 165).	6
page 156).  76.03 Actual diameter filter time  Defines the time for diameter filtering (1st order low pass filter). Setting this parameter helps to get rid of possible oscillations in estimated diameter (parameter 76.51  Estimated diameter filtered) when the actual speed is unstable.			03.14 M/F or D2D ref2 (see page 166).	7
filter time filter). Setting this parameter helps to get rid of possible oscillations in estimated diameter (parameter 76.51 Estimated diameter filtered) when the actual speed is unstable.		Other		-
0 32767 ms Filter time. 1 = 1 ms	76.03		filter). Setting this parameter helps to get rid of possible oscillations in estimated diameter (parameter 76.51 Estimated diameter filtered) when the actual speed is	12 ms
		0 32767 ms	Filter time.	1 = 1 ms

No.	Name/Value	Description	Def/FbEq16
76.05	Count up enable	Activates/deactivates the diameter up-count. In feeder applications, disable the count by setting the parameter to <i>Not selected</i> .	Selected
	Not selected	Diameter up-count not activated.	0
	Selected	Diameter up-count activated.	1
	Roll is not Full Yet	Inverted status of bit 0 (Roll end) of 09.01 Winder status word. Estimated diameter stops counting up when 09.11 Actual diameter gets to the extremes: either greater than full roll diameter (set with parameter 76.09 Full roll diameter) or less than empty core (set with parameter 76.08 Core diameter).	2
	Winder cw bit 6	Diameter up-count  • activated if parameter 74.49 Winder control word, bit 6 = 1  • deactivated if parameter 74.49 Winder control word, bit 6 = 0	3
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
76.06	Count down enable	Activates/deactivates the diameter down-count. In feeder applications, disable the count by setting the parameter to <i>Not selected</i> .	Selected
	Not selected	Diameter down-count not activated.	0
	Selected	Diameter down-count activated.	1
	Roll is not Full Yet	Inverted status of bit 0 (Roll end) of 09.01 Winder status word. Estimated diameter stops counting down when 09.11 Actual diameter gets to the extremes: either greater than full roll diameter (set with parameter 76.09 Full roll diameter) or less than empty core (set with parameter 76.08 Core diameter).	2
	Winder cw bit 7	Diameter down-count  • activated if parameter 74.49 Winder control word, bit 7 = 1  • deactivated if parameter 74.49 Winder control word, bit 7 = 0	3
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
76.07	Hold diameter count	Selects the digital signal source to hold actual diameter counter.  See also section <i>Diameter hold</i> on page <i>49</i> .	Not selected
	Not selected	Hold diameter counter is not activated.	0
	Selected	Hold diameter counter is activated.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
76.08	Core diameter	Defines the core diameter (minimum actual diameter value).	150.0 mm
	0.032767.0 mm	Core diameter.	10 = 1 mm
76.09	Full roll diameter	Defines the full roll diameter (maximum actual diameter value).	500.0 mm
	0.032767.0 mm	Full roll diameter.	10 = 1 mm

No.	Name/Value	Description	Def/FbEq16
76.11	Reset estimated diameter	Selects the source to reset the <i>Estimated</i> diameter.  If parameter 74.05 Winding mode is set to:  • Winder, the diameter value is reset to the core diameter  • Unwinder, the diameter value is reset to the full roll diameter.  Note: If parameter 76.01 Diameter calculation mode is not set to <i>Estimated</i> , and if you use this diameter reset signal, the control program forces the actual diameter signal to 76.61 Measured diameter, ignoring any applied filter and/or diameter hold settings.	Not selected
	Not selected	No diameter reset.	0
	Selected	Reset diameter is activated.	1
	DI5	Source for diameter reset is DI5.	2
	DI6	Source for diameter reset is DI6.	3
	Torque Memory Active	Torque memory is active.	4
	Winder cw bit 4	Estimated diameter resets if parameter 74.49 Winder control word, bit 4 = 1	5
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
76.25	Preset estimated diameter	Presets the diameter, or selects the source for preset signal. See also parameter 76.26 Estimation preset value.	Not selected
	Not selected	Diameter preset Off.	0
	Selected	Diameter preset On.	1
	DI5	Source for diameter preset is DI5.	2
	DI6	Source for diameter preset is DI6.	3
	Torque Memory Active	Torque memory active.	4
	Winder cw bit 5	Estimated diameter preset is On, if parameter 74.49 Winder control word, bit 5 = 1	5
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
76.26	Estimation preset value	Defines the value to which the diameter is preset.	100.0 mm
	0.032767.0 mm	Diameter preset value.	10 = 1 mm
76.29	Reset/Preset while running	Defines the source for a flag allowing the calculated diameter value to be reset while the machine is running.	Not selected
	Not selected	Diameter reset/preset while machine running is Off.	0
	Selected	Diameter reset/preset while machine running is On.	1
	DI5	Source for diameter preset is DI5.	2
	DI6	Source for diameter preset is DI6.	3
	Torque Memory Active	Torque memory active.	4

No.	Name/Value	Description	Def/FbEq16
	Winder cw bit 4	Calculated diameter value resets while machine is running. Parameter 74.51 Winder control status shows the reset status. to do: check functionality	5
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
76.31	Min speed for diameter calc	Defines the speed below which the diameter calculation is frozen. Given in percent of 75.01 Max line speed.	2.00%
	0.00100.00%	Minimum speed for diameter to be calculated.	100 = 1%
76.32	Min tension for diameter calc	Defines the tension or dancer position below which the diameter calculation is frozen. Given as percentage of parameter  • 77.05 Max tension, if 77.02 Tension control mode is set to Tension torque trim or Tension speed trim, or  • 77.32 Dancer position max, if 77.02 Tension control mode is set to Dancer speed trim.	2.00%
	0.00100.00%	Minimum tension for diameter to be calculated.	100 = 1%
76.35	Estimation slope gain	Defines the multiplier to boost the diameter estimation responsiveness to a change. Normally the estimated diameter change step depends on actual motor speed. If it does not give enough agility for necessary corrections, set the value of this parameter greater than 1.0. If estimated diameter is changing too rapidly, set the value of this parameter less than 1.0 (in this case check the settings of parameter group 74 Application setup).	2.000
	0.000100.000	Multiplier.	1000 = 1
76.36	Estimation boost time	Defines the delay after which the multiplication defined by parameter 76.37 Estimation boost multiplier is no longer effective. The delay counter is started by the rising edge of the diameter change.	3.00 s
	0.0032767.00 s	Time delay.	100 = 1 s
76.37	Estimation boost multiplier	Defines the multiplier for widening the range of the allowed change rate of the actual diameter at start. Setting this parameter to 2 doubles the allowed rate of the actual diameter change. Widening can be used at start with partial rolls to correct the possible error between the actual and estimated diameter of the roll.	1.000
	0.000100.000	Multiplier.	1000 = 1
76.49	Raw estimate filter time	Defines filter time for the motor speed component in the estimation routine.	12 ms
	065536 ms	Filter time.	1 = 1 ms
76.50	Raw diameter estimation	Displays diameter estimation based solely on the load/line speed ratio without any ramping or filtering. This parameter is read-only.	0.0 mm
	0.0 32767.0 mm	Raw diameter estimation	10 = 1 mm
76.51	Estimated diameter filtered	Displays the actual diameter calculated based on line-to- motor speed ratio. This parameter is read-only.	0.0 mm
	0.032767.0 mm	Calculated diameter.	10 = 1 mm
		!	

No.	Name/Value	Description	Def/FbEq16
76.61	Measured diameter	Displays the scaled actual diameter value coming from diameter feedback source (parameter 76.02 Diameter feedback Src).  This parameter is read-only.	0.0 mm
	0.032767.0 mm	Scaled actual diameter.	10 = 1 mm
76.88	Diameter hold status	Diameter hold status word	0b0000

Bit	Name	Description	
0	Drive's not running	1 = Drive is not running	
1	Slope gain is too low	1 = Diameter not counting due to too low setting in parameter 76.35 Estimation slope gain	
2	Count up/down disabled	1 = Both diameter count up and diameter count down disabled.	
3	Speed below min threshold	1 = Actual speed is less than minimum speed for diameter calculation	
4	Tension below min threshold	1 = Tension or dancer position (according to tension mode) is less than minimum allowed value	
5	Tension control disabled	1 = Tension control disabled	
6	Torque memory active	1 = Torque memory activated	
7	Inching active	1 = Inching mode activated	
8	Preset diameter command	1 = Diameter preset activated	
9	Reset diameter command	1 = Diameter reset activated	
10	Web loss active	1 = Web loss detected	
11	Threading active	1 = Threading activated	
1214	Reserved		
15	Hold count forced (p76.7)	1 = Diameter hold count is forced by parameter 76.07 Hold diameter count.	

0b0000 0b111111	Diameter hold status word	1 = 1

77 Ter	nsion/Dancer ol	Tension control and setup. See section <i>Taper function</i> on page 58, and the diagrams on pages 5258.	
77.01	Enable tension control	Activates/deactivates the tension controller, or selects the source for the activation signal.	Selected
	Not selected	Tension controller not activated.	0
	Selected	Tension controller activated.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	8
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	9

No.	Name/Value	Description	Def/FbEq16
	Winder cw bit 10	<ul> <li>Tension controller</li> <li>activated if parameter 74.49 Winder control word, bit 10 = 1</li> <li>deactivated if parameter 74.49 Winder control word, bit 10 = 0</li> </ul>	10
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
77.02	Tension control mode	Selects the used tension control mode.	Open loop
	Open loop	Open loop tension control without any feedback device.	0
	Tension torque trim	Tension control with torque reference trim based on load cell feedback.  The control program controls the web tension by calculating the torque reference of the motor, which is the product of user-given tension reference and actual roll radius. In addition, the tension control PID modifies the final motor torque reference based on the tension feedback from the load cell.	1
	Tension speed trim	Tension control with speed reference trim based on load cell feedback. In addition, the tension control PID modifies the final motor speed reference based on the tension feedback from the load cell.	2
	Dancer speed trim	Dancer control with speed reference trim based on Dancer position feedback. The dancer absorbs the changes of the web tension, which causes the dancer position to change.	3
	Line speed master	Line surface speed control mode with motor speed reference trim based on the line speed feedback from an encoder.	4
77.03	Tension reference Src	Selects the source of the tension reference. Tension reference scaling is then done with parameter 77.06 Tension reference scaling. Target tension reference is then defined as: 77.51 Tension reference In = (77.03 Tension reference Src / 77.06 Tension reference scaling) x 77.05 Max tension.	AI2_SCALE D
	NULL	Zero.	0
	AI1_SCALED	12.12 Al1 scaled value (see page 207).	1
	AI2_SCALED	12.22 Al2 scaled value (see page 208).	2
	FBA Reference 1	03.05 FB A reference 1 (see page 165).	3
	FBA Reference 2	03.06 FB A reference 2 (see page 165).	4
	M/F or D2D Reference 1	03.13 M/F or D2D ref1 (see page 165).	5
	M/F or D2D Reference 2	03.14 M/F or D2D ref2 (see page 166).	6
	EFB Reference 1	03.09 EFB reference 1 (see page 165).	7
	EFB Reference 2	03.10 EFB reference 2 (see page 165).	8
	Motor Potentiometer Ref	Motor potentiometer reference. See parameter 22.80 Motor potentiometer ref act on page 267.	9

No.	Name/Value	Description	Def/FbEq16
	77.05 Maximum Tension	Value from parameter 77.05 Max tension is interpreted directly without scaling, when parameter 77.06 Tension reference scaling = 0	10
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
77.04	Load cell feedback Src	Selects source for the tension feedback signal. The input is interpreted directly in force units without any scaling. Value read by the drive could be seen in signal 77.70 Load cell measurement.	NULL
	NULL	Zero.	0
	AI1_SCALED	12.12 Al1 scaled value (see page 207).	1
	AI2_SCALED	12.22 Al2 scaled value (see page 208).	2
	FBA Reference 1	03.05 FB A reference 1 (see page 165).	3
	FBA Reference 2	03.06 FB A reference 2 (see page 165).	4
	M/F or D2D Reference 1	03.13 M/F or D2D ref1 (see page 165).	5
	M/F or D2D Reference 2	03.14 M/F or D2D ref2 (see page 166).	6
	Virtual Roll Estimation	Estimated virtual roll.	7
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
77.05	Max tension	Defines the maximum tension to be exerted on the material.  Note: If load cell feedback is available, you must set the maximum tension to be equal to the device measuring range.	5.0 N
	0.065535.0 N	Maximum tension.	10 = 1 N
77.06	Tension reference scaling	Defines tension reference scaling factor. <b>Note</b> : Reference scaling could be set to 0, then input from parameter 77.03 is interpreted directly in Tension units without any scaling.	100.00
	0.0032767.00	Maximum tension.	100 = 1
77.09	Tension ref change rate	Defines the ramping step for the tension reference. Rate of change per second is set in percent of 77.05 Max tension. Ramped and tapered value of tension reference could be seen in signal 77.52 Tension reference Used.	25.0%/s
	0.032767.0%/s	Maximum tension.	10 = 1%/s

No.	Name/Value	Description	Def/FbEq16
77.11	Taper mode	Selects the used taper mode. The taper function allows altering the web tension as roll diameter changes. Taper mode can be used to control the roll hardness and prevent defects as roll starring and core deformation.  The picture below shows different tension reference profile shapes associated with a certain taper mode selection.  Tension reference    77.11 Taper mode = No tapering   77.15 Max taper   77.16 Max taper   77.17 Max taper   77.18 Max taper   77.18 Max taper   77.19 Max taper   77.19 Max taper   77.10 Max taper   77.10 Max taper   77.11 Max taper   77.11 Max taper   77.11 Max taper   77.12 Max taper   77.13 Max taper   77.13 Max taper   77.13 Max taper   77.14 Max taper   77.15 Max taper   77	No tapering
	No tapering	Taper function is disabled. Tension reference stays the same	0
	Linear	all along the production cycle.  Tension reference changes linearly in direct proportion to the diameter change in the defined tapering range (from parameter 77.13 Taper starting point up to 76.09 Full roll diameter).	1
	Arc	Tension reference changes slowly at start and gets more rapid as actual diameter grows. For the visual representation of the arc shape profile, see the picture above.	2
	Slide	Tension reference changes rapidly at start and gets slower as actual diameter grows. For the visual representation of the slide shape profile, see the picture above.	3
77.12	Tapering reference signal	Defines the source for the axis signal that tension tapering function refers to. The active tapering range on this axis is then defined with parameters 77.13 Taper starting point and 77.14 Taper end point.	9.12 Actual diameter %
	NULL	Zero	0
	9.12 Actual diameter %	Actual diameter displayed in parameter 09.12 Actual diameter %.	1
	9.11 Actual diameter	Actual diameter displayed in parameter 09.11 Actual diameter.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-

No.	Name/Value	Description	Def/FbEq16
77.13	Taper starting point	Defines the taper function starting point at the reference axis defined with parameter 77.12 Tapering reference signal.  When parameter 09.12 Actual diameter % reaches the value defined with this parameter, tapering starts according to parameter 77.11 Taper mode.	0.00
	-32767.00 32767.00	Diameter.	100 = 1
77.14	Taper end point	Defines the taper function end point at the reference axis defined with parameter 77.12 Tapering reference signal.  When parameter 09.12 Actual diameter % reaches the value defined with this parameter, tapering ends according to parameter 77.11 Taper mode.	100.00
	-32767.00 32767.00	Diameter.	100 = 1
77.15	Max taper tension trim %	Defines the magnitude of tension reference change in percent of the target tension reference (parameter 77.51 Tension reference In). Resulting tension reference changes according to the chosen taper profile (parameter 77.11 Taper mode).  Note: When this parameter is positive, the tension reference gets lower as the diameter increases. To make the tension reference increase when the roll diameter builds up, set this parameter to negative value.	0.00%
	-100.00100.00%	Maximum allowed taper.	100 = 1%
77.21	Stall function enable	Enables Stall function or selects the source for the activation signal.	Not selected
	Not selected	Stall function is disabled.	0
	Selected	Stall function is enabled.	1
	Winder cw bit 11	<ul> <li>Stall function</li> <li>enabled if parameter 74.49 Winder control word, bit 11 = 1</li> <li>deactivated if parameter 74.49 Winder control word, bit 11 = 0</li> </ul>	10
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-

No.	Name/Value	Description	Def/FbEq16
77.22	Stall speed threshold %	Defines the line speed reference in percent of 75.01 Max line speed. When the stall function is enabled and the line speed reference is below the value set with this parameter, tension controller takes the tension reference set in parameter 77.23 Stall tension set point %. As the line speed reference approaches the value defined with this parameter, the tension reference linearly changes towards the reference value given in parameter 77.03 Tension reference Src as shown in the diagram below:	5.00%
	77.03 Tension refere		
	77.23 Stall tension so	et point %  75.51 Line reference In  77.22 Stall speed threshold %	
	0.00100.00%	Stall speed level.	100 = 1%
77.23	Stall tension set point %	Defines the stall tension set point.	25.00%
	0.0032767.00%	Stall tension set point.	100 = 1%
77.31	Dancer feedback Src	Defines the source for Dancer actual position feedback. The incoming signal is interpreted directly as is without any internal scaling.	NULL
	NULL	Zero.	0
	AI1_SCALED	12.12 Al1 scaled value (see page 207).	1
	AI2_SCALED	12.22 Al2 scaled value (see page 208).	2
	FBA Reference 1	03.05 FB A reference 1 (see page 165).	3
	FBA Reference 2	03.06 FB A reference 2 (see page 165).	4
	M/F or D2D Reference 1	03.13 M/F or D2D ref1 (see page 165).	5
	M/F or D2D Reference 2	03.14 M/F or D2D ref2 (see page 166).	6
	EFB Reference 1	03.09 EFB reference 1 (see page 165).	7
	EFB Reference 2	03.10 EFB reference 2 (see page 165).	8
	Motor Potentiometer Ref	Motor potentiometer reference. See parameter 22.80 Motor potentiometer ref act on page 267.	9
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-

No. Name/Value		Name/Value Description	
77.32	Dancer position max	Defines the maximum position value in dancer travel range. The parameter is used only if parameter 77.02 Tension control mode is set to Dancer speed trim.  Note: When defining dancer travel range, assume the axis minimum point is 0.	100.00
	-32767.00 32767.00	Maximum dancer travel.	100 = 1
77.33	Dancer position min	Defines the minimum position value in dancer travel range. The parameter is used only if parameter 77.02 Tension control mode is set to Dancer speed trim.  Note: When defining dancer travel range, assume the axis minimum point is 0.	0.00
	-32767.00 32767.00	Minimum dancer travel.	100 = 1
77.34	Dancer position set- point 1	Defines dancer position reference set point 1.	50.00
	-32767.00 32767.00	Set point 1.	100 = 1
77.35	Dancer position set- point 2	Defines dancer position reference set point 2.	50.00
	-32767.00 32767.00	Set point 2.	100 = 1
77.36	Dancer set-point 1/2 selection	Selects dancer reference set point 1 or 2 to be used by the control loop.	Not selected
	Not selected	Dancer set point 1 is selected.	0
	Selected	Dancer set point 2 is selected.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
77.39	Dancer ref change rate	Defines the ramping step for the dancer reference. Rate of change per second is set in percent of 77.32 Dancer position max.  The ramped value of dancer reference can be seen in signal 77.82 Dancer set point used.	20.0%/s
	0.0 32767.0%/s	Ramping step	10 = 1%/s
77.51	Tension reference In	Displays target tension reference coming from the reference source (parameter 77.03 Tension reference Src). The unit is selected in parameter 77.91 Tension measure selection. This parameter is read-only.	0.0 N
	0.0 32767.0 N	Target tension reference.	10 = 1 N
77.52	Tension reference Used	Displays resulting tension reference after selected ramping and tapering. The unit is selected in parameter 77.91  Tension measure selection.  This parameter is read-only.	0.0 N
	0.0 32767.0 N	Resulting tension reference.	10 = 1 N
77.53	Force reference Used	Displays resulting tension reference after selected ramping and tapering. This parameter is read-only.	0.0 N
	0.0 32767.0 N	Resulting tension reference.	10 = 1 N

No.	Name/Value	Description	Def/FbEq16
77.56	Tension torque ref %	Displays torque reference, which is the product of active tension reference and actual diameter. Used in tension torque trim and open loop tension control modes.  This parameter is read-only.	0.00%
	-1600.00 1600.00%	Torque reference.	100 = 1%
77.60	Tension set-point tapered	Displays tension reference set-point modified by taper function. The unit is selected in parameter 77.91 Tension measure selection.  This parameter is read-only.	0.0 N
	0.0 32767.0 N	Tension set-point	10 = 1 N
77.61	Tapering progress	Displays actual progress of tension reference tapering. This parameter is read-only.	0.00%
	0.00 100.00%	Tension reference.	100 = 1%
77.62	Taper trim share	Displays actual trimming of tension reference tapering. This parameter is read-only.	0.00%
	0.00 100.00%	Tension reference.	100 = 1%
77.70	Load cell measurement	Displays the value coming from parameter 77.04 Load cell feedback Src. This parameter is read-only.	0.0 N
	0.0 32767.0 N	Load cell feedback.	10 = 1 N
77.71	Measured tension	Displays tension acquired from the load cell. The unit is selected in parameter 77.91 Tension measure selection. This parameter is read-only.	0.0 N
	0.0 32767.0 N/m	Measured tension.	10 = 1 N
77.72	Estimated tension	Displays actual tension estimated by the Virtual roll function. The unit is selected in parameter 77.91 Tension measure selection. This parameter is read-only.	0.0 N
	0.0 32767.0 N/m	Estimated tension.	10 = 1 N
77.80	Dancer position measured	Displays the position of the dancer arm. This parameter is read-only.	0.00
	0.0032767.00	Dancer arm position.	100 = 1
77.81	Dancer set-point In	Displays target position reference for dancer. This parameter is read-only.	0.00
	0.0032767.00	Target dancer position set point.	100 = 1
77.82	Dancer set point used	Displays dancer position reference currently in use with regard to actual control mode and ramp settings. This parameter is read-only.	0.00
	0.0032767.00	Current dancer position set point.	100 = 1
77.91	Tension measure selection	Selects the unit for tension measurement.	Force
	Force	Tension measurement in Newton or lbf (if 74.91 Unit system = Imperial).	0
	Force/width	Tension measurement in Newton/meter or lbf/inch (if 74.91 Unit system = Imperial).	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-

No.	Name/Value	Description	Def/FbEq16
78 Wil	nder PID oller	PID controller settings. See section <i>Process PID control</i> on page <i>108</i> .	
78.01	Force open loop	Enables tension control mode (parameter 77.02 Tension control mode) to Open loop.	Not selected
	Not selected	Tension control in open loop mode is disabled.	0
	Selected	Tension control in open loop mode is enabled.	1
	Winder cw bit 2	<ul> <li>Open loop tension control</li> <li>activated if parameter 74.49 Winder control word, bit 2 = 1</li> <li>deactivated if parameter 74.49 Winder control word, bit 2 = 0</li> </ul>	2
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
78.02	Force P-control only	Enables only P control.	Not selected
	Not selected	Normal PID control is active.	0
	Selected	Forces the controller to use only P-term for regulation. I-term and D-term are inactive.	1
	Winder cw bit 2	to do: confirm if this descp is correct. selection is same as prev param.  P-control  • activated if parameter 74.49 Winder control word, bit 2 = 1  • deactivated if parameter 74.49 Winder control word, bit 2 = 0	2
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
78.09	PID output range	Defines absolute boundaries for the PID controller output before trimming.	100.00
	0.0032767.00	PID controller output.	100 = 1%
78.11	P-gain 1	Defines proportional gain setting for the PID controller. If parameter 78.14 PID adaptation is enabled, then the value in this parameter is interpreted as P-gain, effective when actual diameter is equal to parameter 76.08 Core diameter.	1.00
	0.0032767.00	Proportional gain.	100 = 1
78.12	I-time 1	Defines integration time setting for the PID controller. If parameter 78.14 PID adaptation is enabled, then the value in this parameter is interpreted as I-time, effective when actual diameter is equal to parameter 76.08 Core diameter.	10.000 s
	0.000 32767.000 s	Integration time.	1000 = 1 s
78.13	D-time 1	Defines derivation time setting for the PID controller. If parameter 78.14 PID adaptation is enabled, then the value in this parameter is interpreted as D-time, effective when actual diameter is equal to parameter 76.08 Core diameter.	0.0 ms
	0.032767.0 ms	Deviation time.	10 = 1 ms

No.	Name/Value	Description	Def/FbEq16
78.14	PID adaptation	Selects the source for activating PID adaptation function.	Not selected
	Not selected	PID adaptation is disabled.	0
	Selected	PID adaptation is enabled.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
78.15	Adaptation mode	Selects the PID input settings adaptation style.	Linear - diameter %
	P,I,D set 1/2 selection	In this mode, parameter 78.14 PID adaptation switches between set 1 and set 2 P, I, D inputs.  • set 1 settings are defined with parameters 78.1178.13  • set 2 settings are defined with parameters 78.1678.18.	0
	Linear - diameter %	In this mode, the PID adaptation function makes P-gain and I-time used by the PID controller to be proportional with actual diameter (parameter 09.12 Actual diameter %). The diagram below depicts the principle of PI adaptation function. The used PID controller settings are displayed in parameters 78.56 Used P-gain and 78.58 Used D-time.	1
		78.16 P-gain 2 78.17 I-time 2 78.18 D-time 2	
		78.11 P-gain 1 78.12 I-time 1 78.13 D-time 1  09.12 Actual diameter %  76.08 Core diameter  76.09 Full roll diameter	
78.16	P-gain 2	Defines the maximum P-gain value used by PID controller as actual diameter progresses towards full roll diameter (par. 76.09).  Note: This parameter is active only when parameter 78.14 PID adaptation is enabled.	1.00
	0.0032767.00	P-gain value.	100 = 1
78.17	I-time 2	Defines the maximum integration time used by PID controller as actual diameter progresses towards the full roll diameter (par. 76.09).  Note: This parameter is active only when parameter 78.14 PID adaptation is enabled.	10.000 s
	0.000 32767.000 s	Integration time.	1000 = 1 s
78.18	D-time 2	Defines the maximum derivation time used by PID controller as actual diameter progresses towards the full roll diameter (par. 76.09).  Note: This parameter is active only when parameter 78.14  PID adaptation is enabled	0.0 ms
	0.032767.0 ms	Derivation time.	10 = 1 ms

No.	Name/Value	Description	Def/FbEq16
78.21	Stall P-gain	Defines the tension controller gain in stall mode.	0.25
	0.0032767.00	Tension controller gain.	100 = 1
78.22	Stall I-time	Defines the tension controller integration time in stall mode.	10.000 s
	0.000 32767.000 s	Integration time.	1000 = 1 s
78.25	Invert PID error sign	Enables invert signal 78.60 Controller error sign.  Note: Activating this function results in inverting the controller output sign as well.	Not selected
	Not selected	Invert PID error sign is disabled.	0
	Selected	Invert PID error sign is enabled.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
78.26	Negative error response	Defines the controller response magnitude in instance when 78.60 Controller error is negative.	100.00%
	0.00100.00%	Controller negative error response	100 = 1%
78.27	Positive error response	Defines the controller response magnitude when parameter 78.60 Controller error is positive.  Response balancing can be used if the feedback signal is more sensitive in one direction, e.g. dancer weight naturally helps it go lower so negative error response could be more delicate.	100.00%
	0.00100.00%	Controller positive error response	100 = 1%

No.	Name/Value	Description	Def/FbEq16
78.31	Trim mode control	Defines specific trimming settings used by the PID controller. The resulting trim value displayed in parameter 78.75 Trim factor used is the product of all currently enabled trims. The product of this value and value in parameter 78.69 PID output limited forms the final control signal produced by the PID controller (parameter 78.79 PID output trimmed) which is then used to trim either torque (par. 09.36) or speed (par. 09.37) depending on the active tension control mode (parameter 09.03 Actual tension ctrl mode).	0b0110

Bit	Name	Description
0	Automatic	1 = Diameter related output trim is set automatically based on parameter 77.02 Tension control mode. 0 = Diameter related output trim is defined manually with bit 2 and 3.
1	Trim multiplier 78.32	1 = Take Trim multiplier in use (can be used in combination with other trims)     0 = Trim constant multiplier is not in use
2	Diameter ratio boost	1 = Trim grows with actual diameter growing 0 = Diameter ratio not in use
3	Diameter ratio fade	1 = Trim fades with actual diameter growing 0 = Diameter ratio not in use
4	Line speed % proportional	1 = Trim is proportional to line speed reference 0 = Line speed ratio not in use
5	Line speed % inverse	1 = Trim is inversely proportional to line speed reference 0 = Inversed line speed ratio is not in use
6	Motor speed % proportional	1 = Trim is proportional to motor speed actual 0 = Motor speed ratio is not in use
7	Motor speed % inverse	1 = Trim is inversely proportional to motor speed actual 0 = Inversed motor speed ratio is not in use
89	Reserved	
10	Proportional to 78.16 User trim source	1 = Trim is defined with parameter 78.33 User trim source 0 = User trim source is not in use
11	Reserved	
1215	Not used	

	0b0000 0b111111	Trim mode control word.	1 = 1
78.32	78.32 Trim multiplier  Defines a constant multiplier used to trim PI output.  Note: This parameter is active only if parameter 78.31 T mode control, mask bit 1 = True.		1.0000
	-32767.0000 32767.0000	Trim multiplier.	10000 = 1
78.33	User trim source	Defines the source for a custom trim input.  Note: This parameter is active only if parameter 78.31 Trim mode control, mask bit 10 = True.	NULL
	NULL	Zero.	0
	AI1_SCALED	12.12 Al1 scaled value (see page 207).	1
	AI2_SCALED	12.22 Al2 scaled value (see page 208).	2

No.	Name/Value	Description	Def/FbEq16
	FBA Reference 1	03.05 FB A reference 1 (see page 165).	3
	FBA Reference 2	03.06 FB A reference 2 (see page 165).	4
	M/F or D2D Reference 1	03.13 M/F or D2D ref1 (see page 165).	5
	M/F or D2D Reference 2	03.14 M/F or D2D ref2 (see page 166).	6
	EFB Reference 1	03.09 EFB reference 1 (see page 165).	7
	EFB Reference 2	03.10 EFB reference 2 (see page 165).	8
	Motor Potentiometer Ref	Motor potentiometer reference. See parameter 22.80 Motor potentiometer ref act on page 267.	9
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
78.34	Speed trim min	Defines the minimum value for trim multiplier term generated by the speed-trim modes.  The speed trim factor changes between this value and 1. At least one speed-trim mode should be enabled in parameter 78.31 Trim mode control, bits 47.	0.00
	0.001.00	Minimum speed trim factor.	100 = 1
78.38	Minimum trim factor	Defines the minimum value for parameter 78.75 Trim factor used.	-100.00
	-32767.00 32767.00	Trim value	100 = 1
78.39	Maximum trim factor	Defines the maximum value for parameter 78.75 Trim factor used.	100.00
	-32767.00 32767.00	Trim value	100 = 1
78.49	PID feedback filter time	Defines filter time for the feedback signal used in the control loop.	0 ms
	032767 ms	Filter time	1 = 1 ms
78.51	PID feedback used %	Displays the current value of actual feedback signal used in process control.  This parameter is read-only.	0.00%
	-32767.00 32767.00 %	Feedback signal.	100 = 1%
78.52	PID reference used %	Displays the currently used set point reference. This parameter is read-only.	0.00%
	-32767.00 32767.00 %	Set point reference signal.	100 = 1%
78.56	Used P-gain	Displays proportional gain setting currently used for process control.  This parameter is read-only.	0.00
	0.0032767.00	Gain value	100 = 1
78.57	Used I-time	Displays integration time setting currently used for process control.  This parameter is read-only.	0.000 s
	0.00032767.000 s	Integration time.	1000 = 1 s

No.	Name/Value	Description	Def/FbEq16
78.58	Used D-time	Displays derivation time setting currently used for process control.  This parameter is read-only.	0.0 ms
	0.032767.0 ms	Derivation time.	10 = 1 ms
78.60	Controller error	Displays actual control error which is the difference between set point (parameter 78.52 PID reference used % and 78.51 PID feedback used %). This parameter is read-only.	0.00
	-32767.00 32767.00	PID controller error in percentage.	100 = 1%
78.61	P term actual	Displays controller error response produced by proportional term. This parameter is read-only.	0.000
	-32767.000 32767.000	Proportional term	1000 = 1
78.62	I-term actual	Displays controller error response produced by integration term. This parameter is read-only.	0.000
	-32767.000 32767.000	Integration term	1000 = 1
78.63	D-term actual	Displays controller error response produced by derivation term. This parameter is read-only.	0.000
	-32767.000 32767.000	Derivation term	1000 = 1
78.69	PID output limited	Displays the controller sum effect of P-term and I-term in bounds set by parameter 78.09 PID output range. This parameter is read-only.	0.000
	32767.000 32767.000	Sum of proportional term and integration term.	1000 = 1
78.75	Trim factor used	Displays the cumulative trim factor generated by all trims configured in parameter 78.31 Trim mode control. The value is limited according to bounds set in parameters 78.38 Minimum trim factor and 78.39 Maximum trim factor. This parameter is read-only.	0.000
	-32767.000 32767.000	Cumulative trim factor	1000 = 1
78.79	PID output trimmed	Displays the final output of PID controller which is product of parameters 78.69 PID output limited and 78.75 Trim factor used.  This parameter is read-only.	0.000
	-32767.000 32767.000	PID controller output	1000 = 1

No. Name/Value	Description	Def/FbEq16
79 Mechanical losses compensation	Friction compensation control and setup.  See section Friction compensation on page 58.  For proper adjustment of the friction compensation, use the following procedure:  1. Place an empty core into the driven section.  2. Set parameter 79.11 Friction compensation enable = Selected.  3. Switch drive to local control mode (example, from a control panel).  4. Set motor speed reference to 1% total speed range (RPM ref = 0.01 • 75.61 Max motor speed at core).  5. Start the drive and make sure load is rotating. Observe parameter 01.10 Motor torque % signal is also displayed on the front page of the control panel.  6. Note the average value of parameter 01.10 Motor torque and save it to parameter 79.12 Static friction torque.  7. Increase the speed to 5% of 75.61 Max motor speed at core.  8. Save the average of parameter 01.10 Motor torque % value to parameter 79.13 Friction torque at 5% speed.  9. Increase the speed to 10% of 75.61 Max motor speed at core.  10. Save the average of parameter 01.10 Motor torque % value to parameter 79.14 Friction torque at 10% speed.  11. Increase the speed to 20% of 75.61 Max motor speed at core.  12. Save the average of parameter 01.10 Motor torque % value to parameter 79.15 Friction torque at 20% speed.  13. Increase the speed to 40% of 75.61 Max motor speed at core.  14. Save the average of parameter 01.10 Motor torque % value to parameter 79.16 Friction torque at 40% speed.  15. Increase the speed to 60% of 75.61 Max motor speed at core.  16. Save the average of parameter 01.10 Motor torque % value to parameter 79.16 Friction torque at 80% speed.  17. Increase the speed to 80% of 75.61 Max motor speed at core.  18. Save the average of parameter 01.10 Motor torque % value to parameter 79.17 Friction torque at 80% speed.  17. Increase the speed to 100% of parameter 75.61 Max motor speed at core.  20. Save the average of parameter 01.10 Motor torque % value to parameter 79.18 Friction torque at 80% speed.  19. Increase the speed to 100% of parameter 75.61 Max motor speed at core.	
79.11 Friction compensation enable	Enables Friction compensation function or selects the source for the activation signal.	Selected
Not selected	Disables Friction compensation function.	0
Selected	Enables Friction compensation function.	1


Winder cw bit 13	No.	Name/Value	Description	Def/FbEq16
bit 13 = 1 Parameter 74.51 Winder control status, bit 13 shows the status of friction compensation.  Other Source selection (see Terms and abbreviations on page 156).  79.12 Static friction torque Defines the friction torque at 1% of the maximum speed. 75.01 Max line speed.  10.00100.00% Friction torque at 1% of the maximum speed. 10.00 = 1%  Prinction torque at 5% of the maximum speed. 10.00100.00% Friction torque at 5% of the maximum speed. 10.00100.00% Friction torque at 5% of the maximum speed. 10.00100.00% Friction torque at 10% of the maximum speed. 10.00100.00% Friction torque at 10% of the maximum speed. 10.00100.00% Friction torque at 10% of the maximum speed. 10.00100.00% Friction torque at 20% of the maximum speed. 10.00100.00% Friction torque at 20% of the maximum speed. 10.00100.00% Friction torque at 20% of the maximum speed. 10.00100.00% Friction torque at 20% of the maximum speed. 10.00100.00% Friction torque at 40% of the maximum speed. 10.00100.00% Friction torque at 40% of the maximum speed. 10.00100.00% Friction torque at 40% of the maximum speed. 10.00100.00% Friction torque at 40% of the maximum speed. 10.00100.00% Friction torque at 80% of the maximum speed. 10.00100.00% Friction torque at 80% of the maximum speed. 10.00100.00% Friction torque at 80% of the maximum speed. 10.00100.00% Friction torque at 80% of the maximum speed. 10.00100.00% Friction torque at 80% of the maximum speed. 10.00100.00% Friction torque at 80% of the maximum speed. 10.00100.00% Friction torque at 80% of the maximum speed. 10.00100.00% Friction torque at 80% of the maximum speed. 10.00100.00% Friction torque at 80% of the maximum speed. 10.00100.00% Friction torque at 80% of the maximum speed. 10.00100.00% Friction torque at 80% of the maximum speed. 10.00100.00% Friction torque at 80% of the maximum speed. 10.00100.00% Friction torque at 80% of the maximum speed. 10.00100.00% Friction torque at 80% of the maximum speed. 10.00		Winder cw bit 13	• enabled if parameter 74.49 Winder control word, bit 13 = 0	2
Source selection (see Terms and abbreviations on page 156).  79.12 Static friction torque  Defines the friction torque at 1% of the maximum speed 75.01 Max line speed.  10.00100.00%  Friction torque at 1% of the maximum speed 75.01 Max line speed.  Defines the friction torque at 5% of the maximum speed 75.01 Max line speed.  10.00100.00%  Friction torque at 5% of the maximum speed. 10.00100.00%  Friction torque at 5% of the maximum speed. 10.00100.00%  Friction torque at 10% of the maximum speed. 10.00100.00%  Friction torque at 10% of the maximum speed. 10.00100.00%  Friction torque at 10% of the maximum speed. 10.00100.00%  Friction torque at 20% of the maximum speed. 10.00100.00%  Friction torque at 20% of the maximum speed. 10.00100.00%  Friction torque at 20% of the maximum speed. 10.00100.00%  Friction torque at 40% of the maximum speed. 10.00100.00%  Friction torque at 40% of the maximum speed. 10.00100.00%  Friction torque at 40% of the maximum speed. 10.00100.00%  Friction torque at 60% of the maximum speed. 10.00100.00%  Friction torque at 80% of the maximum speed. 10.00100.00%  Friction torque at 80% of the maximum speed. 10.00100.00%  Friction torque at 80% of the maximum speed. 10.00100.00%  Friction torque at 80% of the maximum speed. 10.00100.00%  Friction torque at 80% of the maximum speed. 10.00100.00%  Friction torque at 80% of the maximum speed. 10.00100.00%  Friction torque at 80% of the maximum speed. 10.00100.00%  Friction torque at 80% of the maximum speed. 10.00100.00%  Friction torque at 80% of the maximum speed. 10.00100.00%  Friction torque at 80% of the maximum speed. 10.00100.00%  Friction torque at 80% of the maximum speed. 10.00100.00%  Friction torque at 80% of the maximum speed. 10.00100.00%  Friction torque at 100% of the maximum speed. 10.00100.00%  Friction torque at 100% of the maximum speed. 10.00100.00%  Friction torque at 80% of the maximum speed. 10.00100.00%  Friction torque at 80% of			bit 13 = 1	
Page 156).  Pelines the friction torque at 1% of the maximum speed 75.01 Max line speed.  Defines the friction torque at 1% of the maximum speed.  Priction torque at 1% of the maximum speed.  Priction torque at 5% of the maximum speed.  Priction torque at 5% of the maximum speed.  Priction torque at 5% of the maximum speed.  Priction torque at 10% of the maximum speed.  Priction torque at 10% of the maximum speed.  Defines the friction torque at 10% of the maximum speed.  Defines the friction torque at 10% of the maximum speed.  Defines the friction torque at 20% of the maximum speed.  Defines the friction torque at 20% of the maximum speed.  Priction torque at 20% of the maximum speed.  Priction torque at 40% speed.  Defines the friction torque at 40% of the maximum speed.  Defines the friction torque at 40% of the maximum speed.  Defines the friction torque at 40% of the maximum speed.  Defines the friction torque at 40% of the maximum speed.  Defines the friction torque at 60% of the maximum speed.  Defines the friction torque at 60% of the maximum speed.  Defines the friction torque at 80% of the maximum speed.  Defines the friction torque at 80% of the maximum speed.  Defines the friction torque at 80% of the maximum speed.  Priction torque at 20% of the maximum speed.  Defines the friction torque at 80% of the maximum speed.  Defines the friction torque at 80% of the maximum speed.  Defines the friction torque at 80% of the maximum speed.  Defines the friction torque at 80% of the maximum speed.  Defines the friction torque at 80% of the maximum speed.  Defines the friction torque at 80% of the maximum speed.  Defines the friction torque at 80% of the maximum speed.  Defines the friction torque at 80% of the maximum speed.  Defines the friction torque at 80% of the maximum speed.  Defines the friction torque at 80% of the maximum speed.  Defines the friction torque at 80% of the maximum speed.  Defines the friction torque at 80% of the maximum speed.  Defines the friction torque at 80% of the maximum spee				
79.13 Friction torque at 10% of the maximum speed.  79.14 Friction torque at 75.01 Max line speed.  79.15 Friction torque at 75.01 Max line speed.  79.16 Friction torque at 75.01 Max line speed.  79.17 Friction torque at 75.01 Max line speed.  79.18 Friction torque at 75.01 Max line speed.  79.19 Friction torque at 75.01 Max line speed.  79.10 Defines the friction torque at 10% of the maximum speed 75.01 Max line speed.  79.15 Friction torque at 75.01 Max line speed.  79.16 Friction torque at 75.01 Max line speed.  79.17 Friction torque at 75.01 Max line speed.  79.18 Friction torque at 75.01 Max line speed.  79.19 Defines the friction torque at 40% of the maximum speed 75.01 Max line speed.  79.18 Friction torque at 75.01 Max line speed.  79.19 Defines the friction torque at 40% of the maximum speed 75.01 Max line speed.  79.18 Friction torque at 75.01 Max line speed.  79.19 Defines the friction torque at 60% of the maximum speed 75.01 Max line speed.  79.10 Defines the friction torque at 60% of the maximum speed 75.01 Max line speed.  79.18 Friction torque at 75.01 Max line speed.  79.19 Friction torque at 75.01 Max line speed.  79.10 Defines the friction torque at 80% of the maximum speed 75.01 Max line speed.  79.19 Friction torque at 75.01 Max line speed.  79.19 Friction torque at 75.01 Max line speed.  79.10 Defines the friction torque at 100% of the maximum speed 75.01 Max line speed.  79.19 Friction torque at 75.01 Max line speed.  79.10 Defines the friction torque at 100% of the maximum speed 75.01 Max line speed.  79.11 Inertia additive compensation or selects the source for the activation signal.  Note: If fieldbus is used as line speed reference source in parameter 75.02 Line speed reference sirc, then set correct value in parameter 75.05 Line ref source cycle time for the function to work properly.		Other		-
Defines the friction torque at 5% of the maximum speed   0.00%	79.12	Static friction torque		0.00%
75.01 Max line speed.  0.00100.00% Friction torque at 10% of the maximum speed.  0.00100.00% Friction torque at 10% of the maximum speed.  0.00100.00% Friction torque at 10% of the maximum speed.  75.01 Max line speed.  0.00100.00% Friction torque at 10% of the maximum speed.  79.15 Friction torque at 20% of the maximum speed.  0.00100.00% Friction torque at 20% of the maximum speed.  75.01 Max line speed.  0.00100.00% Friction torque at 20% of the maximum speed.  75.01 Max line speed.  0.00100.00% Friction torque at 40% of the maximum speed.  75.01 Max line speed.  0.00100.00% Friction torque at 40% of the maximum speed.  75.01 Max line speed.  0.00100.00% Friction torque at 40% of the maximum speed.  75.01 Max line speed.  0.00100.00% Friction torque at 60% of the maximum speed.  0.00100.00% Friction torque at 60% of the maximum speed.  0.00100.00% Friction torque at 80% of the maximum speed.  100 = 1%  79.18 Friction torque at 75.01 Max line speed.  0.00100.00% Friction torque at 80% of the maximum speed.  0.00100.00% Friction torque at 80% of the maximum speed.  0.00100.00% Friction torque at 100% of the maximum speed.  75.01 Max line speed.  0.00100.00% Friction torque at 100% of the maximum speed.  0.00% Speed  0.00100.00% Friction torque at 100% of the maximum speed.  0.00% Speed  0.00100.00% Friction torque at 100% of the maximum speed.  0.00% Speed  0.00100.00% Friction torque at 100% of the maximum speed.  0.00% Speed  0.00100.00% Friction torque at 100% of the maximum speed.  0.00% Speed  0.00100.00% Friction torque at 100% of the maximum speed.  0.00% Speed  0.00100.00% Friction torque at 100% of the maximum speed.  0.00% Speed  0.00100.00% Friction torque at 100% of the maximum speed.  0.00% Speed  0.00100.00% Speed		0.00100.00%	Friction torque at 1% of the maximum speed.	100 = 1%
79.14 Friction torque at 10% of the maximum speed 75.01 Max line speed.  0.00100.00% Friction torque at 10% of the maximum speed.  79.15 Friction torque at 20% of the maximum speed 75.01 Max line speed.  0.00100.00% Friction torque at 20% of the maximum speed 75.01 Max line speed.  79.16 Friction torque at 40% of the maximum speed 75.01 Max line speed.  0.00100.00% Friction torque at 40% of the maximum speed 75.01 Max line speed.  0.00100.00% Friction torque at 40% of the maximum speed 75.01 Max line speed.  0.00100.00% Friction torque at 40% of the maximum speed 75.01 Max line speed.  0.00100.00% Friction torque at 60% of the maximum speed 75.01 Max line speed.  0.00100.00% Friction torque at 80% of the maximum speed 75.01 Max line speed.  0.00100.00% Friction torque at 80% of the maximum speed 75.01 Max line speed.  0.00100.00% Friction torque at 80% of the maximum speed 75.01 Max line speed.  0.00100.00% Friction torque at 80% of the maximum speed 75.01 Max line speed.  0.00100.00% Friction torque at 80% of the maximum speed.  100 = 1%  79.19 Friction torque at 100% of the maximum speed.  0.00100.00% Friction torque at 80% of the maximum speed.  100 = 1%  79.21 Friction torque at 75.01 Max line speed.  0.00100.00% Friction torque at 100% of the maximum speed.  100 = 1%  79.21 Friction torque at 60% of the maximum speed.  100 = 1%  1	79.13			0.00%
10% speed  0.00100.00%  Friction torque at 10% of the maximum speed.  100 = 1%  Priction torque at 20% of the maximum speed 75.01 Max line speed.  0.00100.00%  Friction torque at 20% of the maximum speed 75.01 Max line speed.  100 = 1%  Priction torque at 40% of the maximum speed 75.01 Max line speed.  0.00100.00%  Friction torque at 40% of the maximum speed 75.01 Max line speed.  0.00100.00%  Friction torque at 40% of the maximum speed 75.01 Max line speed.  0.00100.00%  Friction torque at 60% of the maximum speed 75.01 Max line speed.  0.00100.00%  Friction torque at 60% of the maximum speed 75.01 Max line speed.  0.00100.00%  Friction torque at 80% of the maximum speed 75.01 Max line speed.  0.00100.00%  Friction torque at 80% of the maximum speed 75.01 Max line speed.  0.00100.00%  Friction torque at 80% of the maximum speed 75.01 Max line speed.  0.00100.00%  Friction torque at 80% of the maximum speed 75.01 Max line speed.  0.00100.00%  Friction torque at 100% of the maximum speed 75.01 Max line speed.  0.00100.00%  Friction torque at 100% of the maximum speed 75.01 Max line speed.  100 = 1%  Priction torque at 100% of the maximum speed 75.01 Max line speed.  100 = 1%  Priction torque at 100% of the maximum speed 75.01 Max line speed.  100 = 1%  Priction torque at 100% of the maximum speed 75.01 Max line speed.  100 = 1%  Priction torque at 100% of the maximum speed.  100 = 1%  Priction torque at 100% of the maximum speed.  100 = 1%  Priction torque at 100% of the maximum speed.  100 = 1%  Priction torque at 100% of the maximum speed.  100 = 1%  Priction torque at 100% of the maximum speed.  100 = 1%  Priction torque at 100% of the maximum speed.  100 = 1%  Priction torque at 100% of the maximum speed.  100 = 1%  Priction torque at 100% of the maximum speed.  100 = 1%  Priction torque at 100% of the maximum speed.  100 = 1%  Priction torque at 100% of the maximum speed.  100 = 1%  Priction torque at 100% of the maximum speed.  100 = 1%  Priction torque at 100% of the ma		0.00100.00%	Friction torque at 5% of the maximum speed.	100 = 1%
Defines the friction torque at 20% of the maximum speed   0.00%	79.14			0.00%
20% speed   75.01 Max line speed.   100 = 1%		0.00100.00%	Friction torque at 10% of the maximum speed.	100 = 1%
79.16 Friction torque at 40% speed  0.00100.00% Friction torque at 40% of the maximum speed.  0.00100.00% Friction torque at 40% of the maximum speed.  79.17 Friction torque at 60% speed  0.00100.00% Friction torque at 60% of the maximum speed.  0.00100.00% Friction torque at 60% of the maximum speed.  100 = 1%  79.18 Friction torque at 80% of the maximum speed.  100 = 1%  79.19 Friction torque at 80% of the maximum speed.  100 = 1%  79.19 Friction torque at 100% of the maximum speed.  100 = 1%  79.21 Friction torque at 100% of the maximum speed.  100 = 1%  79.21 Friction torque at 25.01 Max line speed.  100 = 1%	79.15			0.00%
40% speed75.01 Max line speed.0.00100.00%Friction torque at 40% of the maximum speed.100 = 1%79.17Friction torque at 60% speed0.00% of the maximum speed.0.00%0.00100.00%Friction torque at 60% of the maximum speed.100 = 1%79.18Friction torque at 80% speed0.00100.00%0.00100.00%0.00100.00%Friction torque at 80% of the maximum speed.100 = 1%79.19Friction torque at 100% speed0.00100.00%0.00100.00%0.00100.00%Friction torque at 100% of the maximum speed.0.00%79.21Friction torque at 2dditive0.00% of the maximum speed.100 = 1%79.21Friction torque additive0.00% of the maximum speed.100 = 1%79.31Inertia compensation output value.0.00%79.31Inertia compensation enableEnables inertia compensation, or selects the source for the activation signal.Note: If fieldbus is used as line speed reference source in parameter 75.02 Line speed reference src, then set correct value in parameter 75.02 Line ref source cycle time for the function to work properly.Not selected		0.00100.00%	Friction torque at 20% of the maximum speed.	100 = 1%
79.17 Friction torque at 60% of the maximum speed 75.01 Max line speed.  0.00100.00% Friction torque at 60% of the maximum speed.  79.18 Friction torque at 80% of the maximum speed 75.01 Max line speed.  0.00100.00% Priction torque at 80% of the maximum speed 75.01 Max line speed.  0.00100.00% Friction torque at 80% of the maximum speed 75.01 Max line speed.  79.19 Friction torque at 75.01 Max line speed.  0.00100.00% Friction torque at 100% of the maximum speed 75.01 Max line speed.  79.21 Friction torque at 75.01 Max line speed.  79.21 Friction torque additive Defines the additive torque reference to the final friction compensation output value.  1000.00 Additive friction torque.  79.31 Inertia compensation enable Enables inertia compensation, or selects the source for the activation signal.  Note: If fieldbus is used as line speed reference source in parameter 75.02 Line speed reference src, then set correct value in parameter 75.05 Line ref source cycle time for the function to work properly.  Not selected Disables inertia compensation function.	79.16			0.00%
75.01 Max line speed.  0.00100.00% Friction torque at 60% of the maximum speed.  79.18 Friction torque at 80% of the maximum speed.  0.00100.00% Friction torque at 80% of the maximum speed.  0.00100.00% Friction torque at 80% of the maximum speed.  79.19 Friction torque at 100% of the maximum speed.  0.00100.00% Friction torque at 100% of the maximum speed.  100 = 1%  79.21 Friction torque at 100% of the maximum speed.  100 = 1%  Periodic torque at 100% of the maximum speed.  100 = 1%  Additive  100 = 1%  Periodic torque at 100% of the maximum speed.  100 = 1%  Periodic torque additive  100 = 1%  Additive friction torque.  100 = 1%  Periodic torque additive torque reference to the final friction compensation output value.  100 = 1%  Periodic torque additive torque reference to the final friction compensation output value.  100 = 1%  Periodic torque additive torque reference to the final friction compensation output value.  100 = 1%  Periodic torque additive torque reference source for the activation signal.  Note: If fieldbus is used as line speed reference source in parameter 75.02 Line speed reference src, then set correct value in parameter 75.02 Line speed reference src, then set correct value in parameter 75.05 Line ref source cycle time for the function to work properly.  Not selected  Disables inertia compensation function.		0.00100.00%	Friction torque at 40% of the maximum speed.	100 = 1%
79.18 Friction torque at 80% of the maximum speed 75.01 Max line speed.  0.00100.00% Friction torque at 80% of the maximum speed.  79.19 Friction torque at 100% of the maximum speed 75.01 Max line speed.  0.00100.00% Friction torque at 100% of the maximum speed 75.01 Max line speed.  0.00100.00% Friction torque at 100% of the maximum speed 10.00% 75.01 Max line speed.  79.21 Friction torque additive 100% of the maximum speed 10.00% 100 = 1% 100 = 1% 100.00 100.00% 100.00% 100.00% 100.00% 100 100.00% 100 100.00% 100	79.17			0.00%
80% speed   75.01 Max line speed.   100 = 1%		0.00100.00%	Friction torque at 60% of the maximum speed.	100 = 1%
79.19       Friction torque at 100% speed       Defines the friction torque at 100% of the maximum speed       0.00%         79.21       Friction torque additive       Defines the additive torque reference to the final friction compensation output value.       0.00%         79.31       Inertia compensation enable       Enables inertia compensation, or selects the source for the activation signal.       Note: If fieldbus is used as line speed reference source in parameter 75.02 Line speed reference src, then set correct value in parameter 75.05 Line ref source cycle time for the function to work properly.         Not selected       Disables inertia compensation function.       0	79.18			0.00%
100% speed       75.01 Max line speed.         0.00100.00%       Friction torque at 100% of the maximum speed.       100 = 1%         79.21 Friction torque additive       Defines the additive torque reference to the final friction compensation output value.       0.00%         -1000.00 1000.00%       Additive friction torque.       100 = 1%         79.31 Inertia compensation enable       Enables inertia compensation, or selects the source for the activation signal.       Note: If fieldbus is used as line speed reference source in parameter 75.02 Line speed reference source in parameter 75.05 Line ref source cycle time for the function to work properly.         Not selected       Disables inertia compensation function.       0		0.00100.00%	Friction torque at 80% of the maximum speed.	100 = 1%
79.21 Friction torque additive Defines the additive torque reference to the final friction compensation output value.  -1000.00 1000.00%  Additive friction torque.  100 = 1%  Enables inertia compensation, or selects the source for the activation signal.  Note: If fieldbus is used as line speed reference source in parameter 75.02 Line speed reference src, then set correct value in parameter 75.05 Line ref source cycle time for the function to work properly.  Not selected  Disables inertia compensation function.	79.19			0.00%
additive compensation output value.  -1000.00 1000.00%  Additive friction torque.  Enables inertia compensation, or selects the source for the activation signal. Note: If fieldbus is used as line speed reference source in parameter 75.02 Line speed reference src, then set correct value in parameter 75.05 Line ref source cycle time for the function to work properly.  Not selected  Disables inertia compensation function.  0		0.00100.00%	Friction torque at 100% of the maximum speed.	100 = 1%
79.31 Inertia compensation, or selects the source for the activation signal.  Note: If fieldbus is used as line speed reference source in parameter 75.02 Line speed reference src, then set correct value in parameter 75.05 Line ref source cycle time for the function to work properly.  Not selected  Disables inertia compensation function.	79.21			0.00%
compensation enable  Note: If fieldbus is used as line speed reference source in parameter 75.02 Line speed reference src, then set correct value in parameter 75.05 Line ref source cycle time for the function to work properly.  Not selected  Disables inertia compensation function.			Additive friction torque.	100 = 1%
· ·	79.31	compensation	activation signal. <b>Note</b> : If fieldbus is used as line speed reference source in parameter 75.02 Line speed reference src, then set correct value in parameter 75.05 Line ref source cycle time for the	Not selected
Selected Enables inertia compensation function. 1		Not selected	Disables inertia compensation function.	0
		Selected	Enables inertia compensation function.	1

No.	Name/Value	Description	Def/FbEq16
	Winder cw bit 12	<ul> <li>Inertia compensation function</li> <li>enabled if parameter 74.49 Winder control word, bit 12 = 0</li> <li>disabled if parameter 74.49 Winder control word, bit 12 = 1</li> <li>Parameter 74.51 Winder control status, bit 12 shows the status of inertia compensation.</li> </ul>	2
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
79.32	Inertia calculation method	Selects the method for estimating the load inertia.	Based on Estimated Weight
	Based on Estimated Weight	Roll weight is calculated based on supposed amount of material present on a roll. Parameters of group 74  Application setup are used.	0
	Scaled to 79.34 Full roll weight and Actual Diameter	Resulting roll weight is known, and the inertia is estimated based on known proportion to the actual roll diameter. Parameter 79.34 Full roll weight must be set.	1
79.33	Fixed inertia	Defines the fixed inertia including the inertia of the motor, shaft and gearing. Inertia of the shaft and gearbox must be reflected on the motor side.  Fixed inertia = Motor inertia + Gear inertia + Shaft inertia Gear ratio <sup>2</sup> For correct values, see Appendix A: Motor rotor inertia, IEC on page 707. Fixed inertia can be either calculated or detected by the mechanics ID run.	0.0000 kgm <sup>2</sup>
	0.0000 32767.000 kgm <sup>2</sup>	Fixed inertia.	1000 = 1 kgm <sup>2</sup>
79.34	Full roll weight	Defines the weight of the complete roll.  Note: This parameter is used only when parameter 79.32  Inertia calculation method is set to Scaled to 79.34 Full roll weight and Actual Diameter.	0.0 kg
	0.065535.0 kg	Weight of the full roll.	10 = 1 kg
79.41	Acceleration comp gain	Defines torque reference multiplier applied to parameter 79.65 Inertial torque demand % input while line speed is accelerating.	1.00
	0.00 10.00	Torque reference multiplier.	100 = 1
79.42	Deceleration comp gain	Defines torque reference multiplier applied to parameter 79.65 Inertial torque demand % input while line speed is decelerating.	1.00
	0.00 10.00	Torque reference multiplier.	100 = 1
79.43	Steady-speed comp gain	Defines torque reference multiplier applied to parameter 79.65 Inertial torque demand % input while line speed reference does not change. But compensation torque is generated to support motor speed transition as roll diameter changes.	0.25
	0.00 10.00	Torque reference multiplier.	100 = 1

No.	Name/Value	Description	Def/FbEq16
79.48	Min line speed step	Defines absolute minimum line speed reference step for the inertia compensation function to distinguish between steady-speed state and acceleration/deceleration.  Example: If parameter 75.01 Max line speed = 2000 m/min and this value is set to 0.1%/s, then speed change lower	0.00%/s
		than 0.1% of 2000 = 2 m/min/s will not be considered as acceleration or deceleration, but will be interpreted as reference fluctuations in steady-speed state.	
	0.00 100.00%/s	Percentage of minimum line speed change per second.	100 = 1%/s
79.49	IC filter time	Defines the filter time for inertia compensation torque reference. Filtering helps to reduce undesired torque spikes that can occur at sudden speed reference changes.	12 ms
	032767 ms	Filter time.	1 = 1 ms
79.51	Actual motor speed %	Displays actual motor speed in % of 75.61 Max motor speed at core. This parameter is read-only.	0.00%
	0.00100.00%	Speed in %.	100 = 1%
79.55	Friction torque used %	Displays friction torque added to the final torque reference. This parameter is read-only.	0.00%
	-100.00100.00%	Final torque reference in %.	100 = 1%
79.56	Friction impact on Tension	Displays a supposed loss in surface tension due to friction at actual motor speed and by taking into consideration actual diameter.  This parameter is read-only.	0.0 N
	-32767.0 32767.0 N	Tension value.	10 = 1 N
79.61	Used weight	Displays the used weight. This parameter is read-only.	0.0 kg
	0.065535.0 kg	Used weight.	10 = 1 kg
79.62	Actual load inertia	Displays the actual inertia. This parameter is read-only.	0.0000 kgm <sup>2</sup>
	0.0000 32767.0000 kgm <sup>2</sup>	Actual inertia.	10000 = 1 kgm <sup>2</sup>
79.63	Load angular acceleration	Displays angular acceleration of the driven load. This parameter is read-only.	0.00 rpm/s
	-32767.00 32767.00 rpm/s	Angular acceleration.	100 = 1 rpm/s
79.65	Inertial torque demand %	Displays motor torque reference demand needed to support current motor speed reference change. The magnitude of torque demand depends on current acceleration/ deceleration rate and the estimated load inertia.  This parameter is read-only.	0.00 %
	-1600.00 1600.00%	Motor torque reference.	100 = 1 %
79.66	Used IC gain	Displays the compensation gain currently use, depending on whether the line speed reference is accelerating, decelerating or staying unchanged. This parameter is read-only.	0.00
	-10.00 10.00	Compensation gain.	100 = 1

No.	Name/Value	Description	Def/FbEq16
79.67	Inertial torque ref used %	Displays motor torque reference used to support motor speed transition with respect to the compensation gain factor set in parameters 79.4179.43.  This parameter is read-only.	0.00 %
	-1000.00 1000.00%	Motor torque reference.	100 = 1 %





80.01	Take torque sample	Selects the source for the trigger command to capture a torque sample.	Not selected
	Not selected	Torque memory sampling not activated.	0
	Selected	Torque memory sampling activated.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	8
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	9
	Winder cw bit 8	Torque memory sampling activated if parameter 74.49  Winder control word, bit 8 = 1.  Parameter 74.51 Winder control status, bit 8 shows the status of torque memory sampling.	10
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-

No.	Name/Value	Description	Def/FbEq16
80.02	Torque memory enable	Activates/deactivates the torque memory usage (torque memory used as the torque reference), or selects the source for the activation signal.	Not selected
	Not selected	Torque memory usage not activated.	0
	Selected	Torque memory usage activated.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	8
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	9
	Winder cw bit 9	Torque memory usage enabled if parameter 74.49 Winder control word, bit 9 = 1.  Parameter 74.51 Winder control status, bit 9 shows the status of torque memory usage.	10
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
80.09	TM ref change rate	Defines the torque reference change rate used by Torque memory function.	25.0%/s
	0.032767.0 %/s	Torque reference change rate.	10 = 1%/s
80.11	TM reference boost %	Defines the boost in percent of memorized torque.	0.00%
	-1000.00 1000.00%	Torque boost.	100 = 1%
80.12	Boost ON-delay	Defines the delay time before the torque boost (80.11 TM reference boost %) takes effect. Delay counter starts from the moment when the enable signal (80.02 Torque memory enable) got on.	0.00 s
	0.0032767.00 s	Delay time.	100 = 1 s
80.15	Torque boost force cmd	Defines the source for torque boost command signal. The torque boost command is triggered before the On-delay timer is elapsed.  Note: This parameter is effective only when Torque memory function is enabled.	Not selected
	Not selected	Torque boost command is not selected.	0
	Selected	Torque boost command is selected.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
80.41	Overspeed tolerance %	Defines speed in percent of signal 75.63 Motor ref diameter scaled.	10.00%
	0.0032767.00 %	Overspeed tolerance in percent.	100 = 1%

No.	Name/Value	Description	Def/FbEq16
80.42	Overspeed tolerance (rpm)	Defines the maximum allowed motor speed deviation from the reference speed. Prevents uncontrolled acceleration (e.g.when material is cut). If actual speed exceeds overspeed tolerance threshold then rush control function prevents the motor from overspeeding. Also, the drive interprets this as a web-loss condition.  Note: This parameter is active only when Torque memory function is On.	50.0 rpm
	0.032767.0 rpm	Maximum allowed motor speed deviation.	10 = 1 rpm
80.43	Overspeed tolerance selection	Selects the overspeed tolerance used for process safety.	p80.41 - speed in %
	p80.41 - speed in %	Overspeed tolerance in percent (parameter 80.41 Overspeed tolerance %) is selected.	0
	p80.42 - speed in RPM	Overspeed tolerance in rpm (parameter 80.42 Overspeed tolerance (rpm)) selected.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
80.44	Overspeed recovery ramp time	Defines the ramp time used by the drive to recover from overspeed condition back to the target speed reference after Torque memory function is switched Off.	60.00 s
	0.0032767.00 s	Ramp time.	100 = 1 s
80.48	Torque memory signal src	Selects the source for torque signal used by the Torque Memory function.	25.1 SPD_ctrl T- ref to TC
	NULL	None.	0
	25.1 SPD_ctrl T-ref to TC	Output of the speed controller signal 25.01 Torque reference speed control.	1
	26.2 Torque ref used	Cumulative motor torque reference signal 26.02 Torque reference used.	2
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
80.49	TM torque filter time	Defines the filter time for the actual torque signal to be filtered before torque memory function takes it into use.	12 ms
	032767 ms	Filter time.	1 = 1 ms
80.51	TM torque filtered	Displays the actual torque value with effect of filtering caused by setting in parameter 80.49 TM torque filter time. This parameter is read-only.	0.00%
	-1600.00 1600.00%	Filtered torque percentage.	100 = 1%
80.52	Memorised torque sample %	Displays the memorized torque. Torque boost is included. This parameter is read-only.	0.00%
	-1600.00 1600.00%	Memorized torque.	100 = 1%
80.53	TM torque reference used %	Displays torque reference currently produced by the Torque memory function. This parameter is read-only.  Note: This value is used only when Torque memory function (par. 80.59 TM function state) indicates as active.	0.00%

No.	Name/Value	Description	Def/FbEq16
	-1600.00 1600.00%	Torque reference.	100 = 1%
80.59	TM function state	Displays the current state of the Torque memory function. This parameter is read-only.	Inactive
	Inactive	Torque memory function is not activated.	0
	Disabled	Torque memory function is disabled.	1
	Missing torque sample	Torque sample is missing.	2
	Torque sample taken	Torque sample is taken.	3
	TM active - boost delayed	Torque boost is delayed when Torque memory function is activated.	4
	TM active - boosted	Torque boosted when Torque memory function is activated.	5
80.61	Torque mode overspeed limit	Displays the motor speed limit applied when Torque memory function is active. This parameter is read-only.	0.0 rpm
	-32767.0 32767.0 rpm	Motor speed limit in Torque mode.	10 = 1 rpm

81 Wii	nder safety	Settings for web loss. See section Web loss on page 61.	
81.01	Web-loss function	Enables/disables the web loss detection, and selects how the drive reacts when a web loss is detected.	Fault
	Disabled	Web loss detection disabled.	0
	Warning	Web loss detection enabled. The warning <i>E200 Web Loss</i> is generated when a web loss is detected.	1
	Fault	Web loss detection enabled. The fault <i>E100 Web Loss</i> is generated when a web loss is detected.	2
81.02	Web-loss sensor src	Selects the digital sensor input (if available) informing application about the web loss.	Not selected
	Not selected	Web loss sensor not activated.	0
	Selected	Web loss sensor activated.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	8
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	9
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-

No.	Name/Value	Description	Def/FbEq16
81.04	Speed error low %	Defines the threshold for the speed error signal supervision function. When speed error gets too small, i.e. surpasses offset defined by parameters 75.31 and 75.32, it could be an indicator of loose tension (or poor diameter estimation).  Note: The function is active only when Tension control mode is in open-loop or torque memory mode.	5.00 %
	0.00100.00 %	Speed error signal level.	100 = 1 %
81.05	Open-loop supervision	Defines the source for a digital signal to enable/disable the Open-loop supervision function.	Selected
	Not selected	Open-loop supervision function disabled.	0
	Selected	Open-loop supervision function enabled.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
81.09	Open-loop trip delay	Defines the time delay before open-loop supervision function triggers a reaction set in parameter 81.01 Web-loss function. Delay counter activates when the value of parameter 81.53 Observed value goes below the value of parameter 81.04 Speed error low %. If the observed value goes back above the tripping level, the counter is reset.	0.50 s
	0.0032767.00 s	Delay time.	100 = 1 s
81.11	PID feedback supervision	Defines control word to set up closed-loop supervision function mode of operation.	-

Bit	Name	Description	
0	Disable all	1 = Prevents any reaction on PID feedback signals status	
1	Below low level	1 = Triggers web-loss function reaction as the PID feedback signal goes below the threshold set in parameter 81.12 Level low.	
2	Above high level	1 = Triggers web-loss function reaction as the PID feedback signal goes above the threshold set in parameter 81.13 Level high.	
3	Between low and high	1 = Triggers web-loss function reaction as the PID feedback signal is between the thresholds set in parameters 81.12 Level low and 81.13 Level high.	
4	High or low 1 = Triggers web-loss function reaction as PID feedback signal goes below threshold set in parameter 81.12 Level low or above threshold set in parameter 81.13 Level high.		
515	Not used		

	0b0000 0b1111	Control word.	1 = 1
81.12	Level low	Defines low level threshold for the closed-loop supervision function.  Note: Set up in parameter 81.11 PID feedback supervision.	5.00%
	-32767.00 32767.00 %	Percent of low level threshold.	100 = 1 %
81.13	Level high	Defines high level threshold for the closed-loop supervision function.  Note: Set up in parameter 81.11 PID feedback supervision.	95.00%
	-32767.00 32767.00%	Percent of low level threshold.	100 = 1 %

No.	Name/Value	Description	Def/FbEq16
81.14	PID error threshold %	Defines the tripping threshold for the PID error signal 78.60 Controller error. Set this value to what you consider a normal control deviation.	5.00%
		If the control error goes above this value, in combination with the trigger set in parameter 81.11 PID feedback supervision, the drive may trip to a Web-loss condition.	
	-32767.00 32767.00%	PID error tripping threshold.	100 = 1 %
81.15	Closed-loop supervision	Defines the source for a digital signal to enable/disable the Closed-loop supervision function.	Selected
	Not selected	Closed-loop supervision function disabled.	0
	Selected	Closed-loop supervision function enabled.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
81.19	Closed-loop trip delay	Defines the time delay before the closed-loop supervision function triggers a reaction set in parameter 81.01 Web-loss function.  The delay counter activates when 78.60 Controller error signal goes above the value set in parameter 81.14 PID error threshold % and at least one of the triggers set in parameter 81.11 PID feedback supervision is active.	0.50 s
	0.0032767.00 s	Closed loop trip delay time.	100 = 1 s
81.41	Motor speed limit set	Selects the motor speed limit settings. The used speed limits are displayed in drive parameters 30.11 Minimum speed and 30.12 Maximum speed.	Automatic
	Automatic	Program adjusts motor speed limits automatically based on the used core diameter, maximum line speed and gear ratio settings.	0
	Manual p.81.42; p81.43	Speed limits are taken from parameters 81.42 Motor speed minimum and 81.43 Motor speed maximum.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
81.42	Motor speed minimum	Defines the user defined minimum motor speed.  Note: Parameter 81.41 Motor speed limit set must be set to Manual p.81.42; p81.43, otherwise motor speed limits are set automatically.	-1500.0 rpm
	-32767.0 0.0 rpm	Minimum motor speed.	10 = 1 rpm
81.43	Motor speed maximum	Defines the user defined maximum motor speed.  Note: Parameter 81.41 Motor speed limit set must be set to Manual p.81.42; p81.43, otherwise motor speed limits are set automatically.	1500.0 rpm
	0.0 32767.0 rpm	Maximum motor speed.	10 = 1 rpm
81.51	WL detection status	Displays the detection state of the web loss function. This parameter is read-only.	Not active now
	Not active now	No supervision is active in the current control state.	0
	Observer is up at safe zone	Observer is up at safe zone.	1
	Tripping timer active	Trip delay counter is active.	2
	Web loss detected	Web loss is detected.	3

No.	Name/Value	Description	Def/FbEq16
81.06	WL trip delay	Defines the time delay before the web loss function causes a trip. Delay counter actives when the value of parameter 81.53 Observed value goes below the value of parameter 81.04 Speed error low %. If observed value goes back above the tripping level, the counter is reset.	1.00 s
	0.0032767.00 s	Web loss delay.	100 = 1 s
81.52	WL supervision signal	Displays the supervision mode for web loss. Web loss is supervised automatically based on parameter 77.02 Tension control mode.  This parameter is read-only.	N/A in active Ctrl-mode
	N/A in active Ctrl- mode	Not applicable in active control mode	0
	Speed error watchdog	Speed error watchdog	1
	PID feedback signal	PID feedback signal	2
81.53	Observed value	Displays the presently monitored value which depends on the setting of parameter 77.02 Tension control mode. This parameter is read-only.	0.00%
	-100.00100.00%	Web loss monitored value.	100 = 1%

No.	Name/Value	Description	Def/FbEq16
81.59	Observer status word	Displays the actual status of the web-loss observer function. This parameter is read-only.	0b0000

Bit	Name	Description	
0	PID supervision is on	<ul><li>1 = PID supervision is activated.</li><li>0 = PID supervision is disabled.</li></ul>	
1	Below low level	1 = PID feedback signal is below the threshold level set in parameter 81.12  Level low. 0 = PID feedback signal is above the threshold level set in parameter 81.12  Level low.	
2	Above high level	<ul> <li>1 = PID feedback signal is above the threshold level set in parameter 81.13 Level high.</li> <li>0 = PID feedback signal is below the threshold level set in parameter 81.13 Level high.</li> </ul>	
3	Between low and high	1 = PID feedback signal is between the thresholds set in parameters 81.12 Level low and 81.13 Level high. 0 = PID feedback signal is beyond the thresholds set in parameters 81.12 Le low and 81.13 Level high.	
4	High or Low	1 = PID feedback signal is either below the threshold set in parameter 81.1 Level low or above the threshold set in parameter 81.13 Level high. 0 = PID feedback signal is between the values set with parameters 81.12 Llow and 81.13 Level high	
5	PID error flag high	1 = PID error signal is above the threshold set in parameter 81.14 PID error threshold %. 0 = PID error signal is below the threshold set in parameter 81.14 PID error threshold %.	
6	Closed-loop timer is on	1 = Closed-loop timer is On. 0 = Closed-loop timer is Off.	
7	Closed-loop trigger	1 = Observed signal satisfies either of the triggering conditions set in 81.11 F feedback supervision and the trip delay time has elapsed. 0 = All trigger conditions are not satisfied.	
89	Reserved		
10	Watchdog is on	1 = Open-loop supervision is active now. 0 = Open-loop supervision is not active.	
11	Speed-error too low	1 = Observed speed error signal is below 81.04 Speed error low % signal. 0 = Observed speed error signal is above the threshold.	
12	Open-loop trigger	<ul><li>1 = Observed signal satisfies the triggering condition and trip delay time has elapsed.</li><li>0 = All trigger conditions are not satisfied.</li></ul>	
13	Reserved		
14	Digital sensor status	1 = Web-loss sensor is activated. 0 = Web-loss sensor is not activated.	
15	Web-loss detected	1 = Web-loss function is enabled. 0 = Web-loss function is disabled.	

No.	Name/Value	Description	Def/FbEq16
82 Vir	tual Roll	Settings for the virtual roll function. See section <i>Virtual roll</i> on page <i>61</i> .	
82.11	Counter source selection	Selects the source for the length counter shaft position feedback.	Virtual Line Encoder Pos
	Virtual Line Encoder Pos	Virtual line encoder position.	0
	Encoder1 Pos	Encoder 1 position.	1
	Encoder2 Pos	Encoder 2 position.	2
	Load position scaled	Load position scaled.	3
82.12	Encoder placement	Selects the encoder placement.	On Motor shaft
	On the Line	Encoder is located on the line pulley.	0
	On Motor shaft	Encoder is located on the motor shaft.	1
	On Roll shaft	Encoder is located on the roller shaft.	2
82.13	Counter input type	Selects the type of position signal used for the wrap counter.	Single-turn
	Single-turn	Incoming encoder position data is scaled within one revolution (01). The Virtual roll function shall count the number of wraps.	0
	Multi-turn absolute	Incoming encoder data represents the exact position including number of turns, that is there is no need for internal wrap count.	1
82.15	VR line feed constant	Defines the circumference of the wheel feeding material onto the virtual roll.  Note: This parameter is used only if parameter 82.12  Encoder placement is set to On the Line.	1.00000 unit/rev
	0.00000 32767.00000 unit/rev	Circumference.	100000 = 1 unit/rev
82.19	Hold roll counter	Stops the length (and therefore diameter) counter at any time.	Virtual roll is full
	Not selected	Virtual roll counter keeps counting.	0
	Selected	Virtual roll counter is on hold.	1
	Virtual roll is full	Virtual roll is full.	2
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
82.21	Reset VR diameter	Selects the source for reset the length counter and virtual roll diameter to zero.	User Reset cmd (74.51.4)
	Not selected	Reset of the virtual roll is not activated.	0
	Selected	Reset of the virtual roll is activated.	1
	User Reset cmd (74.51.4)	User reset command is the source for the reset of the virtual roll.	2
	User Preset cmd (74.51.5)	User preset command is the source for the preset of the virtual roll.	3
	DI5	Source for reset is DI5.	4

No.	Name/Value	Description	Def/FbEq16
	DI6	Source for reset is DI6.	5
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
82.22	Preset VR diameter	Selects the source for preset the virtual roll diameter to a value defined with parameter 82.23 VR diameter preset source.	User Preset cmd (74.51.5)
	Not selected	Reset of the virtual roll is not activated.	0
	Selected	Reset of the virtual roll is activated.	1
	User Reset cmd (74.51.4)	User reset command is the source for the reset of the virtual roll.	2
	User Preset cmd (74.51.5)	User preset command is the source for the preset of the virtual roll.	3
	DI5	Source for preset is DI5.	4
	DI6	Source for preset is DI6.	5
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
82.23	VR diameter preset source	Selects the source for diameter preset. Length for the counter preset is calculated automatically.	User preset value (76.26)
	NULL		0
	User preset value (76.26)	User preset command is the source for the preset of the virtual roll.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
82.36	Estimated tension filter time	Defines the filter time for the tension estimate made by Virtual roll function.	60 ms
	032767 ms	Filter time.	1 = 1 ms
82.51	Max speed Sim can take	Displays maximum speed possible for the simulator. This parameter is read-only.	-
	0.0 32767.0 m/min	Maximum speed.	10 = 1 m/min
82.54	Detected line speed	Displays line speed calculated based on used feedback and the virtual roll settings. This parameter is read-only.	-
	0.0 32767.0 m/min	Line speed.	10 = 1 m/min
82.56	VR rotating speed	Displays rotating speed calculated based on used feedback and the virtual roll settings. This parameter is read-only.	-
	0.0 32767.0 rpm	Rotating speed.	10 = 1 rpm
82.60	Length on roll	Displays amount of material delivered onto the virtual roll. This parameter is read-only.	-
	0.0100000.0 m	Amount of material.	10 = 1 m
82.61	Virtual roll diameter	Displays calculated diameter based on used feedback and virtual roll settings. This parameter is read-only.	-
	0.032767.0 mm	Diameter of the virtual roll.	10 = 1 mm

No.	Name/Value	Description	Def/FbEq16
82.62		Displays diameter ratio of virtual roll. This parameter is read-only.	-
	0.000010.0000	Diameter ratio.	10000 = 1
82.64	-	Displays actual wrap count. This parameter is read-only.	-
	0.0065536.00	Wrap count.	100 = 1
82.71		Displays estimated tension of virtual roll. This parameter is read-only.	-
	-32767.0 32767.0 N/m	Estimated tension.	10 = 1 N/m
82.72		Displays estimated force of virtual roll. This parameter is read-only.	-
	-32767.0 32767.0 N	Estimated tension.	10 = 1 N
82.89		Simulator status of virtual roll. This parameter is read-only.	0b0000
Bit	Name	Description	
0	Simulation Mode	1 = Simulation mode is activated. 0 = Simulation mode is disabled.	
1	Counter on Hold	1 = Wrap counter is on hold. 0 = Wrap counter is activated.	
2	Winding-on	1 = Counter is increasing the virtual roll diameter. 0 = Counter is not increasing the virtual roll diameter.	
3	Unwinding	<ul><li>1 = Counter is decreasing the virtual roll diameter.</li><li>0 = Counter is not decreasing the virtual roll diameter.</li></ul>	
4	Diameter count active	<ul><li>1 = Diameter counter is active.</li><li>0 = Diameter counter is not active.</li></ul>	
5	Reserved		
6	VR Reset active	1 = Virtual roll reset is active. 0 = Virtual roll reset is not active.	
7	VR Preset active	1 = Virtual roll preset is active. 0 = Virtual roll preset is not active.	
8	VR is at Core	1 = Virtual roll is at core. 0 = Virtual roll is not at core.	
9	VR got over Full Ro	1 = Virtual roll has full roll. 0 = Virtual roll is not at full roll.	
10	13 Reserved		

0b0000 0b111111	Simulator status.	1 = 1

14

15

Length counter overflow

Limit

Speed above Sim

1 = Length counter has reached overflow limit.0 = Length counter is within overflow limit.

1 = Speed is above the virtual roll simulator limit.

0 = Speed is within the virtual roll simulator limit.

No.	Name/Value	Description	Def/FbEq16
90 Fee	edback selection	Motor and load feedback configuration. See also section <i>Encoder support</i> (page <i>91</i> ) and <i>Position counter</i> (page <i>93</i> ),and the diagram on page <i>683</i> .	
90.01	Motor speed for control	Displays estimated or measured motor speed that is used for speed control, i.e. final motor speed feedback selected by parameter 90.41 Motor feedback selection and filtered by 90.42 Motor speed filter time.  In case measured feedback is selected, it is also scaled by the motor gear function (90.43 Motor gear numerator and 90.44 Motor gear denominator).  This parameter is read-only.	-
	-32768.00 32767.00 rpm	Motor speed used for control.	See par. 46.01
90.02	Motor position	Displays motor position (within one revolution) received from the source selected by parameter 90.41 Motor feedback selection.  In case measured feedback is selected, it is also scaled by the motor gear function (90.43 Motor gear numerator and 90.44 Motor gear denominator).  This parameter is read-only.	-
	0.00000000 1.00000000 rev	Motor position.	32767 = 1 rev
90.03	Load speed	Displays estimated or measured load speed that is used for motor control, i.e. final load speed feedback selected by parameter 90.51 Load feedback selection and filtered by parameter 90.52 Load speed filter time.  In case measured feedback is selected, it is also scaled by the load gear function (90.53 Load gear numerator and 90.54 Load gear denominator).  In case motor feedback or estimated feedback is used, it is inversely scaled by 90.61 Gear numerator and 90.62 Gear denominator (that is 90.62 divided by 90.61).  This parameter is read-only.	-
	-32768.00 32767.00 rpm	Load speed.	See par. 46.01
90.04	Load position	Displays load position received from the source selected by parameter 90.51 Load feedback selection. The value is multiplied as specified by parameter 90.57 Load position resolution.  In case measured feedback is selected, it is also scaled by the load gear function (90.53 Load gear numerator and 90.54 Load gear denominator).  In case motor feedback or estimated feedback is used, it is inversely scaled by 90.61 Gear numerator and 90.62 Gear denominator (i.e. 90.62 divided by 90.61).  An offset can be defined by 90.56 Load position offset. This parameter is read-only.	-
	-2147483648 2147483647	Load position.	-

No.	Name/Value	Description	Def/FbEq16
90.05	Load position scaled	Displays scaled load position in decimal format. The position is relative to the initial position set by parameters 90.65 and 90.66.  The number of decimal places is defined by parameter 90.38 Pos counter decimals.  Note: This is a floating point parameter, and the accuracy is compromised near the ends of the range. Consider using parameter 90.07 Load position scaled int instead of this parameter.  This parameter is read-only.	-
	-2147483.264 2147483.264	Scaled load position in decimal format.	-
90.06	Motor position scaled	Displays calculated motor position. The axis mode (linear or rollover) and resolution are defined by parameters 90.48 Motor position axis mode and 90.49 Motor position resolution respectively.  Note: The position value can be sent on a fast time level to the fieldbus controller by selecting Position in either 50.07 FBA A actual 1 type, 50.08 FBA A actual 2 type, 50.37 FBA B actual 1 type or 50.38 FBA B actual 2 type. This parameter is read-only.	-
	-2147483.648 2147483.647	Motor position.	-
90.07	Load position scaled int	Displays output of position counter function as an integer, enabling backwards compatibility with ACS 600 and ACS800 drives. The position is relative to the initial position set by parameters 90.58 and 90.59. See section Position counter (page 93), and the block diagram on page 684. This parameter is read-only.	-
	-2147483648 2147483647	Scaled load position in integer format.	-
90.10	Encoder 1 speed	Displays encoder 1 speed in rpm. This parameter is read-only.	-
	-32768.00 32767.00 rpm	Encoder 1 speed.	See par. 46.01
90.11	Encoder 1 position	Displays actual position of encoder 1 within one revolution. This parameter is read-only.	-
	0.00000000 1.00000000 rev	Encoder 1 position within one revolution.	32767 = 1 rev
90.12	Encoder 1 multiturn revolutions	Displays revolutions (multi turn) of encoder 1 within its value range (see parameter 92.14 Revolution data width).  This parameter is read-only.	-
	016777215	Encoder 1 revolutions.	-

No.	Name/Value	Description	Def/FbEq16
90.13	Encoder 1 revolution extension	Displays revolution count extension for encoder 1.  With a single-turn encoder, the counter is incremented when encoder position (parameter 90.11) wraps around in the positive direction, and decremented in the negative direction.  With a multi turn encoder, the counter is incremented when the revolutions count (parameter 90.12) exceeds the value range in the positive direction, and decremented in the negative direction.  This parameter is read-only.	-
	-2147483648 2147483647	Encoder 1 revolution count extension.	-
90.14	Encoder 1 position raw	Displays raw measurement data of encoder 1 position (within one revolution) as a 24-bit unsigned integer received from the encoder interface.  This parameter is read-only.	-
	016777215	Raw encoder 1 position within one revolution.	-
90.15	Encoder 1 revolutions raw	Displays revolutions of (multi turn) encoder 1 within its value range (see parameter 92.14 Revolution data width) as a raw measurement.  This parameter is read-only.	-
	016777215	Raw encoder 1 revolution count.	-
90.20	Encoder 2 speed	Displays encoder 2 speed in rpm. This parameter is read-only.	-
	-32768.00 32767.00 rpm	Encoder 2 speed.	See par. 46.01
90.21	Encoder 2 position	Displays actual position of encoder 2 within one revolution. This parameter is read-only.	-
	0.00000000 1.00000000 rev	Encoder 2 position within one revolution.	-
90.22	Encoder 2 multiturn revolutions	Displays revolutions of (multi turn) encoder 2 within its value range (see parameter 93.14 Revolution data width). This parameter is read-only.	-
	016777215	Encoder 2 revolutions.	-
90.23	Encoder 2 revolution extension	Displays revolution count extension for encoder 2. With a single-turn encoder, the counter is incremented when encoder position (parameter 90.21) wraps around in the positive direction, and decremented in the negative direction. With a multi turn encoder, the counter is incremented when the revolutions count (parameter 90.22) exceeds the value range in the positive direction, and decremented in the negative direction. This parameter is read-only.	-
	-2147483648 2147483647	Encoder 2 revolution count extension.	-
90.24	Encoder 2 position raw	Displays raw measurement data of encoder 2 position (within one revolution) as a 24-bit unsigned integer received from the encoder interface.  This parameter is read-only.	-
			1

1 = 1

No.	Name/Value	Description	Def/FbEq16
90.25	Encoder 2 revolutions raw	Displays revolutions (multi turn) of encoder 2 within its value range (see parameter 93.14 Revolution data width) as a raw measurement.  This parameter is read-only.	-
	016777215	Raw encoder 2 revolution count.	-
90.26	Motor revolution extension	Displays motor revolution count extension. The counter is incremented when the position selected by 90.41 Motor feedback selection wraps around in the positive direction, and decremented in the negative direction. This parameter is read-only.	-
	-2147483648 2147483647	Motor revolution count extension.	-
90.27	Load revolution extension	Displays load revolution count extension.  The counter is incremented when the position selected by 90.51 Load feedback selection wraps around in the positive direction, and decremented in the negative direction.  This parameter is read-only.	-
	-2147483648 2147483647	Load revolution count extension.	-
90.35	Pos counter status	Status information related to the position counter function. See section <i>Position counter</i> (page 93). This parameter is read-only.	-

Bit	Name	Value
0	Encoder 1 feedback	1 = Encoder 1 selected as load feedback source
1	Encoder 2 feedback	1 = Encoder 2 selected as load feedback source
2	Internal position feedback	1 = Internal load position estimate selected as load feedback source
3	Motor feedback	1 = Motor feedback selected as load feedback source
4	Pos counter init ready	<ul> <li>0 = Position counter not initialized, or encoder feedback was lost.</li> <li>Fresh counter initialization recommended.</li> <li>1 = Position counter successfully initialized</li> </ul>
5	Position counter re-init disabled	1 = Position counter initialization is being prevented by par. 90.68
6	Position data inaccurate	1 = Encoder feedback intermittent or lost. (If the drive is running, estimated position is used whenever encoder feedback is unavailable. If the drive is in stopped state, position counting will continue based on encoder data after the connection is restored.)
715	Reserved	

Position counter status word.

0000 0000b ...

0111 1111b

No.	Name/Value	Description	Def/FbEq16
90.38	Pos counter decimals	Scales the value of parameters 90.05 Load position scaled and 90.65 Pos counter init value when written from or read to from an external source (e.g. fieldbus). The setting corresponds to the number of decimal places. For example, with the value set as 3, an integer value of 66770 written into 90.65 Pos counter init value is divided by 1000, so the final value applied is 66.770. Likewise, the value of 90.05 Load position scaled is multiplied by 1000 when read.	3
	09	Number of position counter decimal places.	1 = 1
90.41	Motor feedback selection	Selects the motor speed feedback value used in control.  Note: With a permanent magnet motor, make sure an autophasing routine (see page 101) is performed using the selected encoder. If necessary, set parameter 99.13 ID run requested to Autophasing to request a fresh autophasing routine.	Estimate
	Estimate	A calculated speed estimate generated from the DTC core is used.	0
	Encoder 1	Actual speed measured by encoder 1. The encoder is set up by the parameters in group 92 Encoder 1 configuration.	1
	Encoder 2	Actual speed measured by encoder 2. The encoder is set up by the parameters in group 93 Encoder 2 configuration.	2
90.42	Motor speed filter time	Defines a filter time for motor speed feedback used for speed control (90.01 Motor speed for control).	3 ms
	0 10000 ms	Motor speed filter time.	1 = 1 ms
90.43	Motor gear numerator	Parameters 90.43 and 90.44 define a gear function between the motor speed feedback and motor control. The gear is used to correct a difference between the motor and encoder speeds for example if the encoder is not mounted directly on the motor shaft.  90.43 Motor gear numerator  Motor speed	1
		90.44 Motor gear denominator Encoder speed	+
		See also section <i>Load and motor feedback</i> (page <i>92</i> ). <b>Note:</b> This parameter cannot be changed while the drive is running.	
	-2147483648 2147483647	Motor gear numerator.	-
90.44	Motor gear denominator	See parameter 90.43 Motor gear numerator.  Note: This parameter cannot be changed while the drive is running.	1
	-2147483648 2147483647	Motor gear denominator.	-
90.45	Motor feedback fault	Selects how the drive reacts to loss of measured motor feedback.	Fault
	Fault	Drive trips on a 7301 Motor speed feedback or 7381 Encoder fault.	0

No.	Name/Value	Description	Def/FbEq16
	Warning	Drive generates a A798 Encoder option comm loss, A7B0 Motor speed feedback or A7E1 Encoder warning and continues operation using estimated feedbacks.  Note: Before using this setting, test the stability of the speed control loop with estimated feedback by running the drive on estimated feedback (see 90.41 Motor feedback selection).	1
90.46	Force open loop	Forces the DTC motor model to use estimated motor speed as feedback. This parameter can be activated when the encoder data is obviously unreliable because of slippage, for example.  Note: This parameter only affects the selection of feedback for the motor model, not for the speed controller.	No
	No	The motor model uses the feedback selected by 90.41 Motor feedback selection.	0
	Yes	The motor model uses the calculated speed estimate (regardless of the setting of 90.41 Motor feedback selection) which in this case only selects the source of feedback for speed controller.	1
90.48	Motor position axis mode	Selects the axis type for motor position measurement.	Rollover
	Linear	Linear.	0
	Rollover	The value is between 0 and 1 revolutions, and rolls over at 360 degrees.	1
90.49	Motor position resolution	Defines how many bits are used for motor position count within one revolution. For example, with the setting of 24, the position value is multiplied by 16777216 for display in parameter 90.06 Motor position scaled (or for fieldbus).	24
	031	Motor position resolution.	-
90.51	Load feedback selection	Selects the source of load speed and position feedbacks used in control.	None
	None	No load feedback selected.	0
	Encoder 1	Load feedbacks are updated based on the speed and position values read from encoder 1.  The values are scaled by the load gear function (90.53 Load gear numerator and 90.54 Load gear denominator).  The encoder is set up by the parameters in group 92 Encoder 1 configuration.	1
	Encoder 2	Load feedbacks are updated based on the speed and position values read from encoder 2.  The values are scaled by the load gear function (90.53 Load gear numerator and 90.54 Load gear denominator).  The encoder is set up by the parameters in group 93 Encoder 2 configuration.	2
	Estimate	Calculated speed and position estimates are used. The values are scaled from the motor side to the load side using the inverted ratio between 90.61 Gear numerator and 90.62 Gear denominator (that is 90.62 divided by 90.61).	3
	Motor feedback	The source selected by parameter 90.41 Motor feedback selection for motor feedback is also used for load feedback. Any difference between the motor and load speeds (and positions) can be compensated using the inverted ratio between 90.61 Gear numerator and 90.62 Gear denominator (that is 90.62 divided by 90.61).	4

No.	Name/Value	Description	Def/FbEq16
90.52	Load speed filter time	Defines a filter time for load speed feedback (90.03 Load speed).	4 ms
	0 10000 ms	Load speed filter time.	-
90.53	Load gear numerator	Parameters 90.53 and 90.54 define a gear function between the load (driven equipment) speed and the encoder feedback selected by parameter 90.51 Load feedback selection. The gear can be used to correct a difference between the load and encoder speeds for example if the encoder is not mounted directly on the rotated machinery.  90.53 Load gear numerator  90.54 Load gear denominator  See also section Load and motor feedback (page 92).  Note: This parameter cannot be changed while the drive is running.	1
	-2147483648 2147483647	Load gear numerator.	-
90.54	Load gear denominator	See parameter 90.53 Load gear numerator.  Note: This parameter cannot be changed while the drive is running.	1
	-2147483648 2147483647	Load gear denominator.	-
90.55	Load feedback fault	Selects how the drive reacts to loss of load feedback.	Fault
	Fault	Drive trips on a 73A1 Load feedback fault.	0
	Warning	Drive generates an A798 Encoder option comm loss or A7B1 Load speed feedback warning and continues operation using estimated feedbacks.	1
90.56	Load position offset	Defines a load-side position offset. The resolution is determined by parameter 90.57 Load position resolution.	0 rev
	-2147483648 2147483647	Load-side position offset.	-
90.57	Load position resolution	Defines how many bits are used for load position count within one revolution. For example, with the setting of 16, the position value is multiplied by 65536 for display in parameter 90.04 Load position.	16
	031	Load position resolution.	-
90.58	Pos counter init value int	Defines an initial position (or distance) for the position counter (as an integer value) when parameter 90.59 Pos counter init value int source is set to Pos counter init value int.  See also section Position counter (page 93).	0
	-2147483648 2147483647	Initial integer value for position counter.	-
90.59	Pos counter init value int source	Selects the source of the initial position integer value. When the source selected by 90.67 Pos counter init cmd source activates, the value selected in this parameter is assumed to be the position of the load.	Pos counter init value int
	Zero	0.	0
	Pos counter init value int	Parameter 90.58 Pos counter init value int.	1

No.	Name/Value	Description	Def/FbEq16
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
90.60	Pos counter error and boot action	Selects how the position counter reacts to loss of load feedback.	Request re- initialization
	Request re- initialization	Bit 4 of 90.35 Pos counter status is cleared. Reinitialization of position counter is recommended.	0
	Continue from previous value	Position counting resumes from the previous value over a loss of load feedback or control unit reboot. Bit 4 of 90.35  Pos counter status is not cleared, but bit 6 is set to indicate that an error has occurred.  WARNING! If load feedback is lost when the drive is in stopped state or not powered, the counter is not updated even if the load moves.	1
90.61	Gear numerator	Parameters 90.61 and 90.62 define a gear function between the motor and load speeds.	1
		90.61 Gear numerator Motor speed	
		90.62 Gear denominator Load speed	
		See also section <i>Load and motor feedback</i> (page 92).	
	-2147483648 2147483647	Gear numerator (motor-side).	-
90.62	Gear denominator	See parameter 90.61 Gear numerator.	1
	-2147483648 2147483647	Gear denominator (load-side).	-
90.63	Feed constant numerator	Parameters 90.63 and 90.64 define the feed constant for the position calculation:	1
		90.63 Feed constant numerator	
		90.64 Feed constant denominator	
		The feed constant converts rotational motion into translatory motion. The feed constant is the distance the load moves during one turn of the motor shaft.  The translatory load position is shown by parameter 90.05  Load position scaled.	
		<b>Note</b> : Load position is updated only after the new position input data is received.	
	-2147483648 2147483647	Feed constant numerator.	-
90.64	Feed constant denominator	See parameter 90.63 Feed constant numerator.	1
	-2147483648 2147483647	Feed constant denominator.	-
90.65	Pos counter init value	Defines an initial position (or distance) for the position counter (as a decimal number) when parameter 90.66 Pos counter init value source is set to Pos counter init value. See also section Position counter (page 93). The number of decimal places is defined by parameter 90.38 Pos counter decimals.	0.000
	-2147483.648 2147483.647	Initial value for position counter.	-

No.	Name/Value	Description	Def/FbEq16
90.66	Pos counter init value source	Selects the source of the initial position value. When the source selected by 90.67 Pos counter init cmd source activates, the value selected in this parameter is assumed to be the position of the load (in decimal format).	Pos counter init value
	Zero	0.	0
	Pos counter init value	Parameter 90.65 Pos counter init value.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
90.67	Pos counter init cmd source	Selects a digital source (for example, a limit switch connected to a digital input) that initializes the position counter. When the digital source activates, the value selected by 90.66 Pos counter init value source is assumed to be the position of the load.  Note: You can prevent the position counter initialization with parameter 90.68 Disable pos counter initialization.	Not selected
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
90.68	Disable pos counter initialization	Selects a source that prevents the initialization of the position counter.	Not selected
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-
90.69	Reset pos counter init ready	Selects a source that enables a new initialization of the position counter, that is resets bit 4 of 90.35 Pos counter status.	Not selected
	Not selected	0.	0

No.	Name/Value	Description	Def/FbEq16
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 156).	-

91 End setting	coder module gs	Configuration of encoder interface modules.	
91.01	FEN DI status	Displays the status of the digital inputs of FEN-xx encoder interface modules. This parameter is read-only.	-

Bit	Name	Information
0	DI1 /module 1	DI1 of interface module 1 (see parameters 91.11 and 91.12)
1	DI2 /module 1	DI2 of interface module 1 (see parameters 91.11 and 91.12)
23	Reserved	
4	DI1 /module 2 DI1 of interface module 2 (see parameters 91.13 and 91.14)	
5	DI2 /module 2 DI2 of interface module 2 (see parameters 91.13 and 91.14)	
615	Reserved	

	0000 0000b 0011 0011b	Status word of digital inputs on FEN-xx modules.	1 = 1
91.02	Module 1 status	Displays the type of the interface module found in the location specified by parameter 91.12 Module 1 location. This parameter is read-only.	-
	No option	No module detected in the specified slot.	0
	No communication	A module has been detected but cannot be communicated with.	1
	Unknown	The module type is unknown.	2
	FEN-01	An FEN-01 module has been detected and is active.	16
	FEN-11	An FEN-11 module has been detected and is active.	17
	FEN-21	An FEN-21 module has been detected and is active.	18
	FEN-31	An FEN-31 module has been detected and is active.	21
	FSE-31	An FSE-31 module has been detected and is active.	25
91.03	Module 2 status	Displays the type of the interface module found in the location specified by parameter 91.14 Module 2 location. For the indications, see parameter 91.02 Module 1 status. This parameter is read-only.	-

No.	Name/Value	Description	Def/FbEq16
91.04	Module 1 temperature	Displays the temperature measured through the sensor input of interface module 1. The unit is selected by parameter 96.16 Unit selection.  Note: With a PTC sensor, the unit is ohms. This parameter is read-only.	-
	01000 °C, °F or ohm	Temperature measured through interface module 1.	-
91.06	Module 2 temperature	Displays the temperature measured through the sensor input of interface module 2. The unit is selected by parameter 96.16 Unit selection.  Note: With a PTC sensor, the unit is ohms. This parameter is read-only.	-
	01000 °C, °F or ohm	Temperature measured through interface module 2.	-
91.10	Encoder parameter refresh	Validates any changed encoder interface module parameters. This is needed for any parameter changes in groups 9093 to take effect.  After refreshing, the value reverts automatically to <i>Done</i> . <b>Notes:</b> • Permanent magnet motors only: The drive will perform a fresh autophasing routine (see page 101) at next start if the motor feedback encoder settings have been changed.  • The parameter cannot be changed while the drive is running.	Done
	Done	Refreshing done.	0
	Refresh	Refreshing.	1
91.11	Module 1 type	Defines the type of the module used as interface module 1.	None
	None	None (communication disabled).	0
	FEN-01	FEN-01.	1
	FEN-11	FEN-11.	2
	FEN-21	FEN-21.	3
	FEN-31	FEN-31.	4
	FSE-31	Reserved.	5
91.12	Module 1 location	Specifies the slots 13 on the control unit of the drive into which the interface module is installed. Alternatively, specifies the node ID of the slot on an FEA-03 extension adapter.	Slot 2
	Slot 1	Slot 1.	1
	Slot 2	Slot 2.	2
	Slot 3	Slot 3.	3
	4254	Node ID of the slot on the FEA-03 extension adapter.	1 = 1
91.13	Module 2 type	Defines the type of the module used as interface module 2.	None
	None	None (communication disabled).	0
	FEN-01	FEN-01.	1
	FEN-11	FEN-11.	2
	FEN-21	FEN-21.	3
	FEN-31	FEN-31.	4
	FSE-31	Reserved.	5

No.	Name/Value	Description	Def/FbEq16
91.14	Module 2 location	Specifies the slot (13) on the control unit of the drive into which the interface module is installed. Alternatively, specifies the node ID of the slot on an FEA-03 extension adapter.	Slot 3
	Slot 1	Slot 1.	1
	Slot 2	Slot 2.	2
	Slot 3	Slot 3.	3
	4254	Node ID of the slot on the FEA-03 extension adapter.	1 = 1
91.21	Module 1 temp sensor type	Specifies the type of temperature sensor connected to interface module 1.	None
	None	None.	0
	PTC	PTC. (The unit is ohms.)	1
	KTY-84	KTY84. (The unit is selected by parameter <i>96.16 Unit selection</i> .)	2
91.22	Module 1 temp filter time	Defines a filtering time for the temperature measurement through interface module 1.	1500 ms
	010000 ms	Filtering time for temperature measurement.	-
91.24	Module 2 temp sensor type	Specifies the type of temperature sensor connected to interface module 2.	None
	None	None.	0
	PTC	PTC. (The unit is ohms.)	1
	KTY-84	KTY84. (The unit is selected by parameter 96.16 Unit selection.)	2
91.25	Module 2 temp filter time	Defines a filtering time for the temperature measurement through interface 2.	1500 ms
	010000 ms	Filtering time for temperature measurement.	-
91.31	Module 1 TTL output source	Selects the encoder input on interface module 1 whose signal is echoed by or emulated to the TTL output.  See also section <i>Encoder support</i> (page 91).	Not selected
	Not selected	TTL output not in use.	0
	Module input 1	Input 1 is echoed by or emulated to the TTL output.	1
	Module input 2	Input 2 is echoed by or emulated to the TTL output.	2
91.32	Module 1 emulation pulses/rev	Defines the number of TTL pulses per revolution for encoder emulation output of interface module 1.	0
	065535	Number of TTL pulses for emulation.	1 = 1
91.33	Module 1 emulated Z-pulse offset	With interface module 1, defines when zero pulses are emulated in relation to zero position received from the encoder.  For example, with a value of 0.50000, a zero pulse is emulated whenever the encoder position passes 0.5 revolutions. With a value of 0.00000, a zero pulse is emulated whenever the encoder position passes zero position.	0.00000
	0.00000 1.00000 rev	Position of emulated zero pulses.	32767 = 1 rev

No.	Name/Value	Description	Def/FbEq16
91.41	Module 2 TTL output source	Selects the encoder input on interface module 2 whose signal is echoed by or emulated to the TTL output.  See also section <i>Encoder support</i> (page <i>91</i> ).	Not selected
	Not selected	TTL output not in use.	0
	Module input 1	Input 1 is echoed by or emulated to the TTL output.	1
	Module input 2	Input 2 is echoed by or emulated to the TTL output.	2
91.42	Module 2 emulation pulses/rev	Defines the number of TTL pulses per revolution for encoder emulation output of interface module 2.	0
	065535	Number of TTL pulses for emulation.	1 = 1
91.43	Module 2 emulated Z-pulse offset	With interface module 2, defines when zero pulses are emulated in relation to zero position received from the encoder.  For example, with a value of 0.50000, a zero pulse is emulated whenever the encoder position passes 0.5 revolutions. With a value of 0.00000, a zero pulse is emulated whenever the encoder position passes zero position.	0
	0.00000 1.00000 rev	Position of emulated zero pulses.	32767 = 1 rev
	coder 1 guration	Settings for encoder 1.     Notes:     The contents of the parameter group vary according to the selected encoder type.     It is recommended that encoder connection 1 (this group)	
		is used whenever possible since the data received through that interface is fresher than the data received through connection 2 (group 93 Encoder 2 configuration).	
92.01	Encoder 1 type	Selects the type of encoder/resolver 1.	None configured
	None configured	None.	0
	TTL	TTL. Module type (input): FEN-01 (X31), FEN-11 (X41) or FEN-21 (X51).	1
	TTL+	TTL+ (with commutation signals). Module type (input): FEN-01 (X32).	2
	Absolute encoder	Absolute encoder. Module type (input): FEN-11 (X42).	3
	Resolver	Resolver. Module type (input): FEN-21 (X52).	4
	HTL	HTL. Module type (input): FEN-31 (X82).	5
	HTL 1	HTL. Module type (input): FSE-31 (X31).	6
	HTL 2	HTL. Module type (input): FSE-31 (X32). Not supported at the time of publication.	7
92.02	Encoder 1 source	Selects the interface module that the encoder is connected to. (The physical locations and types of encoder interface modules are defined in parameter group 91 Encoder module settings.)	Module 1
	Module 1	Interface module 1.	0
	Madula O	Interface module 2.	1
	Module 2		
92.10	Pulses/revolution	(Visible when a TTL, TTL+ or HTL encoder is selected) Defines the pulse number per revolution.	2048

No.	Name/Value	Description	Def/FbEq16
92.10	Sine/cosine number	(Visible when an absolute encoder is selected) Defines the number of sine/cosine wave cycles within one revolution.  Note: This parameter need not be set when an EnDat or SSI encoder is used in continuous mode. See parameter 92.30 Serial link mode.	0
	065535	Number of sine/cosine wave cycles within one revolution.	-
92.10	Excitation signal frequency	(Visible when a resolver is selected) Defines the frequency of the excitation signal.  Note: With an EnDat or HIPERFACE encoder and FEN-11 FPGA version VIE12200 or later, this parameter is automatically set upon validation of encoder settings (91.10 Encoder parameter refresh).	1 kHz
	120 kHz	Excitation signal frequency.	1 = 1 kHz
92.11	Pulse encoder type	(Visible when a TTL, TTL+ or HTL encoder is selected) Selects the type of encoder.	Quadrature
	Quadrature	Quadrature encoder (with two channels, A and B)	0
	Single track	Single-track encoder (with one channel, A). <b>Note:</b> With this setting, the measured speed value is always positive regardless of direction of rotation.	1
92.11	Absolute position source	(Visible when an absolute encoder is selected) Selects the source of the absolute position information.	None
	None	Not selected.	0
	Commut signals	Commutation signals.	1
	EnDat	Serial interface: EnDat encoder.	2
	Hiperface	Serial interface: HIPERFACE encoder.	3
	SSI	Serial interface: SSI encoder.	4
	Tamagawa	Serial interface: Tamagawa 17/33-bit encoder.	5
92.11	Excitation signal amplitude	(Visible when a resolver is selected) Defines the amplitude of the excitation signal.Resolver	4.0 V
	4.0 12.0 V	Excitation signal amplitude.	10 = 1 V
92.12	Speed calculation mode	(Visible when a TTL, TTL+ or HTL encoder is selected) Selects the speed calculation mode.  *With a single-track encoder (parameter 92.11 Pulse encoder type is set to Single track), the speed is always positive.	Auto rising
	A&B all	Channels A and B: Rising and falling edges are used for speed calculation.  *Channel B: Defines the direction of rotation.  Note: With a single-track encoder (parameter 92.11 Pulse encoder type), this setting acts like setting A all.	0
	A all	Channel A: Rising and falling edges are used for speed calculation. *Channel B: Defines the direction of rotation.	1
	A rising	Channel A: Rising edges are used for speed calculation. *Channel B: Defines the direction of rotation.	2
	A falling	Channel A: Falling edges are used for speed calculation. *Channel B: Defines the direction of rotation.	3

No.	. Name/Value Description			Def/FbEq16	
	Auto rising	One of the above modes is selected automatically depending on the pulse frequency as follows:		4	
		Pulse frequency of the channel(s)	Used mode		
		< 2442 Hz	A&B all		
		24424884 Hz	A all		
		> 4884 Hz	A rising		
	Auto falling	One of the above modes is selected depending on the pulse frequence		5	
		Pulse frequency of the channel(s)	Used mode		
		< 2442 Hz	A&B all		
		24424884 Hz	A all		
		> 4884 Hz	A falling		
92.12	Zero pulse enable	(Visible when an absolute encoder is selected) Enables the encoder zero pulse for the absolute encoder input (X42) of the FEN-11 interface module.  Note: No zero pulse exists with serial interfaces, i.e. when parameter 92.11 Absolute position source is set to EnDat, Hiperface, SSI or Tamagawa.		Disable	
	Disable	Zero pulse disabled.		0	
	Enable	Zero pulse enabled.		1	
92.12	Resolver polepairs	(Visible when a resolver is select Defines the number of pole pairs		1	
	132	Number of resolver pole pairs.		1 = 1	
92.13	Position estimation enable	(Visible when a TTL, TTL+ or HT Selects whether position estimat to increase position data resolution	ion is used with encoder 1	Enable	
	Disable	Measured position used. (The re revolution for quadrature encode for single-track encoders.)		0	
	Enable	Estimated position used. (Uses pextrapolated at the time of data r		1	
92.13	Position data width	(Visible when an absolute encode Defines the number of bits used one revolution. For example, a set to 32768 positions per revolution. The value is used when parameter source is set to EnDat, Hiperface 92.11 Absolute position source is parameter is internally set to 17.  Note: With an EnDat or HIPERFA FPGA version VIE12200 or later, automatically set upon validation Encoder parameter refresh).	to indicate position within etting of 15 bits corresponds of the second state of the second state of the second se	0	
	032	Number of bits used in position in revolution.	ndication within one	1 = 1	

No.	Name/Value	Description	Def/FbEq16
92.14	Speed estimation enable	(Visible when a TTL, TTL+ or HTL encoder is selected) Selects whether calculated or estimated speed is used. Estimation increases the speed ripple in steady state operation, but improves the dynamics.	Disable
	Disable	Last calculated speed used. (The calculation interval is 62.5 microseconds to 4 milliseconds.)	0
	Enable	Estimated speed (estimated at the time of data request) is used.	1
92.14	Revolution data width	(Visible when an absolute encoder is selected)  Defines the number of bits used in revolution counting with a multiturn encoder. For example, a setting of 12 bits would support counting up to 4096 revolutions.  The value is used when parameter 92.11 Absolute position source is set to EnDat, Hiperface or SSI. When parameter 92.11 Absolute position source is set to Tamagawa, setting this parameter to a non-zero value activates multiturn data requesting.  Note: With an EnDat or HIPERFACE encoder and FEN-11 FPGA version VIE12200 or later, this parameter is automatically set upon validation of encoder settings (91.10 Encoder parameter refresh).	0
	032	Number of bits used in revolution count.	1 = 1
92.15	Transient filter	(Visible when a TTL, TTL+ or HTL encoder is selected) Activates transient filtering for the encoder (changes in direction of rotation are ignored above the selected pulse frequency).	4880 Hz
	4880 Hz	Change in direction of rotation allowed below 4880 Hz.	0
	2440 Hz	Change in direction of rotation allowed below 2440 Hz.	1
	1220 Hz	Change in direction of rotation allowed below 1220 Hz.	2
	Disabled	Change in direction of rotation allowed at any pulse frequency.	3
92.17	Accepted pulse freq of encoder 1	(Visible when parameter 92.01 Encoder 1 type = HTL 1 or HTL 2)  Defines the maximum pulse frequency of encoder 1.	0 kHz
	0300 kHz	Pulse frequency.	1 = 1 kHz
92.21	Encoder cable fault mode	(Visible when a TTL, TTL+ or HTL encoder is selected) Selects which encoder cable channels and wires are monitored for wiring faults.	A, B
	A, B	A and B.	0
	A, B, Z	A, B and Z.	1
	A+, A-, B+, B-	A+, A-, B+ and B	2
	A+, A-, B+, B-, Z+, Z-	A+, A-, B+, B-, Z+ and Z	3

No.	Name/Value	Description	Def/FbEq16
92.23	Maximum pulse waiting time	<ul> <li>(Visible when parameter 92.01 Encoder 1 type = TTL or HTL)</li> <li>Determines a pulse waiting time used in speed calculation for the encoder interface. If no pulse edges are detected within this time, the measured speed is zeroed by the interface.</li> <li>Increasing the setting can improve measuring performance especially at low, near zero speeds.</li> <li>Notes:</li> <li>The parameter is only supported by FEN-xx modules with FPGA version VIEx 2000 or later. On older modules, the pulse waiting time is fixed to 4 ms.</li> <li>The parameter only affects speed measurement. Position is updated whenever a new pulse edge is detected. When the measured speed from the interface is zero, the drive updates its speed data based on position changes.</li> </ul>	4 ms
	1200 ms	Maximum pulse waiting time.	1 = 1 ms
92.24	Pulse edge filtering	<ul> <li>(Visible when parameter 92.01 Encoder 1 type = HTL)         Enables pulse edge filtering. Pulse edge filtering can improve the reliability of measurements especially from encoders with a single-ended connection.     </li> <li>Notes:         <ul> <li>Pulse edge filtering is only supported by FEN-31 modules with FPGA version VIE3 2200 or later.</li> <li>Pulse edge filtering decreases the maximum pulse frequency. With 2 μs filtering time, the maximum pulse frequency is 200 kHz.</li> </ul> </li> </ul>	No filtering
	No filtering	Filtering disabled.	0
·	1 µs	Filtering time: 1 microsecond.	1
	2 µs	Filtering time: 2 microseconds.	2
92.25	Pulse overfrequency function	(Visible when parameter 92.01 Encoder 1 type = HTL) Selects how the drive reacts when the encoder interface detects a pulse overfrequency condition.  Note: This parameter is effective only with FEN-xx module FPGA version VIEx 2200 or later.	Fault
	Warning	The drive generates a warning, 7381 Encoder. The FEN-xx module will continue to update speed and position data.	0
	Fault	The drive trips on fault A7E1 Encoder.	1
92.30	Serial link mode	(Visible when an absolute encoder is selected) Selects the serial link mode with an EnDat or SSI encoder.	Initial position
	Initial position	Single position transfer mode (initial position).	0
	Continuous	Continuous position data transfer mode.	1
	Continuous speed and position	Continuous speed and position data transfer mode. This setting is intended for EnDat 2.2 encoders without sin/cos signals.  Note: This setting requires an FEN-11 interface revision H or later.	2

No.	Name/Value	Description	Def/FbEq16
92.31	EnDat max calculation time	(Visible when an absolute encoder is selected) Selects the maximum encoder calculation time for an EnDat encoder.  Note: This parameter needs to be set only when an EnDat encoder is used in continuous mode, i.e. without incremental sin/cos signals (supported only as encoder 1). See also parameter 92.30 Serial link mode.	50 ms
	10 us	10 microseconds.	0
	100 us	100 microseconds.	1
	1 ms	1 millisecond.	2
	50 ms	50 milliseconds.	3
92.32	SSI cycle time	(Visible when an absolute encoder is selected) Selects the transmission cycle for an SSI encoder.  Note: This parameter needs to be set only when an SSI encoder is used in continuous mode, i.e. without incremental sin/cos signals (supported only as encoder 1). See also parameter 92.30 Serial link mode.	100 us
	50 us	50 microseconds.	0
	100 us	100 microseconds.	1
	200 us	200 microseconds.	2
	500 us	500 microseconds.	3
	1 ms	1 millisecond.	4
	2 ms	2 milliseconds.	5
92.33	SSI clock cycles	(Visible when an absolute encoder is selected)  Defines the length of an SSI message. The length is defined as the number of clock cycles. The number of cycles can be calculated by adding 1 to the number of bits in an SSI message frame.	2
	2127	SSI message length.	-
92.34	SSI position msb	(Visible when an absolute encoder is selected) With an SSI encoder, defines the location of the MSB (most significant bit) of the position data within an SSI message.	1
	1126	Position data MSB location (bit number).	-
92.35	SSI revolution msb	(Visible when an absolute encoder is selected) With an SSI encoder, defines the location of the MSB (most significant bit) of the revolution count within an SSI message.	1
	1126	Revolution count MSB location (bit number).	-
92.36	SSI data format	(Visible when an absolute encoder is selected) Selects the data format for an SSI encoder.	Binary
	Binary	Binary code.	0
	Gray	Gray code.	1
92.37	SSI baud rate	(Visible when an absolute encoder is selected) Selects the baud rate for an SSI encoder.	100 kBit/s
	10 kBit/s	10 kbit/s.	0
	50 kBit/s	50 kbit/s.	1
	100 kBit/s	100 kbit/s.	2
	200 kBit/s	200 kbit/s.	3

No.	Name/Value	Description	Def/FbEq16
	500 kBit/s	500 kbit/s.	4
	1000 kBit/s	1000 kbit/s.	5
92.40	SSI zero phase	(Visible when an absolute encoder is selected)  Defines the phase angle within one sine/cosine signal period that corresponds to the value of zero on the SSI serial link data. The parameter is used to adjust the synchronization of the SSI position data and the position based on sine/cosine incremental signals. Incorrect synchronization may cause an error of ±1 incremental period.  Note: This parameter needs to be set only when an SSI encoder is used in initial position mode (see parameter 92.30 Serial link mode).	315-45 deg
	315-45 deg	315-45 degrees.	0
	135-225 deg	135-225 degrees.	2
	225-315 deg	225-315 degrees.	3
92.45	Hiperface parity	(Visible when an absolute encoder is selected)  Defines the use of parity and stop bits with a HIPERFACE encoder.  Typically this parameter need not be set.	Odd
	Odd	Odd parity indication bit, one stop bit.	0
	Even	Even parity indication bit, one stop bit.	1
92.46	Hiperface baud rate	(Visible when an absolute encoder is selected)  Defines the transfer rate of the link with a HIPERFACE encoder.  Typically this parameter need not be set.	4800 bits/s
	4800 bits/s	4800 bit/s.	0
	9600 bits/s	9600 bit/s.	1
	19200 bits/s	19200 bit/s.	2
	38400 bits/s	38400 bit/s.	3
92.47	Hiperface node address	(Visible when an absolute encoder is selected) Defines the node address for a HIPERFACE encoder. Typically this parameter need not be set.	64
	0255	HIPERFACE encoder node address.	-
	coder 2 guration	Settings for encoder 2.  Notes:  The contents of the parameter group vary according to the selected encoder type.  It is recommended that encoder connection 1 (group 92 Encoder 1 configuration) is used whenever possible since the data received through that interface is fresher than the data received through connection 2 (this group).	
93.01	Encoder 2 type	Selects the type of encoder/resolver 2.	None configured
	None configured	None.	0
	TTL	TTL. Module type (input): FEN-01 (X31), FEN-11 (X41) or FEN-21 (X51).	1
	TTL+	TTL+ (with commutation signals). Module type (input): FEN-01 (X32).	2
	Absolute encoder	Absolute encoder. Module type (input): FEN-11 (X42).	3

No.	Name/Value	Description	Def/FbEq16
	Resolver	Resolver. Module type (input): FEN-21 (X52).	4
	HTL	HTL. Module type (input): FEN-31 (X82).	5
	HTL 1	HTL. Module type (input): FSE-31 (X31).	6
	HTL 2	HTL. Module type (input): FSE-31 (X32). Not supported at the time of publication.	7
	HTL 2	Reserved.	6
	TTL 1	Reserved.	7
93.02	Encoder 2 source	Selects the interface module that the encoder is connected to. (The physical locations and types of encoder interface modules are defined in parameter group 91 Encoder module settings.)	Module 1
	Module 1	Interface module 1.	1
	Module 2	Interface module 2.	2
93.10	Pulses/rev	(Visible when a TTL, TTL+ or HTL encoder is selected) See parameter 92.10 Pulses/revolution.	2048
93.10	Sine/cosine number	(Visible when a TTL, TTL+ or HTL encoder is selected) See parameter 92.10 Sine/cosine number.	0
93.10	Excitation signal frequency	(Visible when a resolver is selected) See parameter 92.10 Excitation signal frequency.	1 kHz
93.11	Pulse encoder type	(Visible when a TTL, TTL+ or HTL encoder is selected) See parameter 92.11 Pulse encoder type.	Quadrature
93.11	Absolute position source	(Visible when an absolute encoder is selected) See parameter 92.11 Absolute position source.	None
93.11	Excitation signal amplitude	(Visible when a resolver is selected) See parameter 92.11 Excitation signal amplitude.	4.0 V
93.12	Speed calculation mode	(Visible when a TTL, TTL+ or HTL encoder is selected) See parameter 92.12 Speed calculation mode.	Auto rising
93.12	Zero pulse enable	(Visible when an absolute encoder is selected) See parameter 92.12 Zero pulse enable.	Disable
93.12	Resolver polepairs	(Visible when a resolver is selected) See parameter 92.12 Resolver polepairs.	1
93.13	Position estimation enable		
93.13	Position data width	data width (Visible when an absolute encoder is selected) See parameter 92.13 Position data width.	
93.14	Speed estimation enable	(Visible when a TTL, TTL+ or HTL encoder is selected) See parameter 92.14 Speed estimation enable.	Disable
93.14	Revolution data width	(Visible when an absolute encoder is selected) See parameter 92.14 Revolution data width.	0
93.15	Transient filter	(Visible when a TTL, TTL+ or HTL encoder is selected) See parameter 92.15 Transient filter.	4880 Hz
93.17	Accepted pulse freq of encoder 2	(Visible when parameter 93.01 Encoder 2 type = HTL 1 or HTL 2) See parameter 92.17 Accepted pulse freq of encoder 1.	0 kHz
93.21	Encoder cable fault mode	(Visible when a TTL, TTL+ or HTL encoder is selected) See parameter 92.21 Encoder cable fault mode.	A, B

No. Name/Value Do		ame/Value Description	
93.23	Maximum pulse waiting time	(Visible when parameter 93.01 Encoder 2 type = TTL or HTL) See parameter 92.23 Maximum pulse waiting time.	4 ms
93.24	Pulse edge filtering	(Visible when parameter 93.01 Encoder 2 type = HTL) See parameter 92.24 Pulse edge filtering.	No filtering
93.25	Pulse overfrequency function	(Visible when parameter 93.01 Encoder 2 type = HTL) See parameter 92.25 Pulse overfrequency function.	Fault
93.30	Serial link mode	(Visible when an absolute encoder is selected) See parameter 92.30 Serial link mode.	Initial position
93.31	EnDat calc time	(Visible when an absolute encoder is selected) See parameter 92.31 EnDat max calculation time.	50 ms
93.32	SSI cycle time	(Visible when an absolute encoder is selected) See parameter 92.32 SSI cycle time.	100 us
93.33	SSI clock cycles	(Visible when an absolute encoder is selected) See parameter 92.33 SSI clock cycles.	2
93.34	SSI position msb	(Visible when an absolute encoder is selected) See parameter 92.34 SSI position msb.	1
93.35	SSI revolution msb	(Visible when an absolute encoder is selected) See parameter 92.35 SSI revolution msb.	1
93.36	SSI data format	(Visible when an absolute encoder is selected) See parameter 92.36 SSI data format.	Binary
93.37	SSI baud rate	(Visible when an absolute encoder is selected) See parameter 92.37 SSI baud rate.	100 kBit/s
93.40	SSI zero phase	(Visible when an absolute encoder is selected) See parameter 92.40 SSI zero phase.	315-45 deg
93.45	Hiperface parity	(Visible when an absolute encoder is selected) See parameter 92.45 Hiperface parity.	Odd
93.46	Hiperface baud rate	(Visible when an absolute encoder is selected) See parameter 92.46 Hiperface baud rate.	4800 bits/s
93.47	Hiperface node address	(Visible when an absolute encoder is selected) See parameter 92.47 Hiperface node address.	64

94 LSU control	Control of the supply unit of the drive, such as DC voltage and reactive power reference.  Note: References defined here must also be selected as the reference source in the supply control program to be effective.  This group is visible only when supply unit control is activated with parameter 95.20 HW options word 1.  See also section Control of a supply unit (LSU) (page 83).	
94.01 LSU control	Enables/disables the internal INU-LSU state machine. When the state machine is enabled, the inverter unit (INU) controls the supply unit (LSU) and prevents the inverter unit from starting until the supply unit is ready. When the state machine is disabled, the status of the supply unit (LSU) is ignored by the inverter unit.	On
Off	INU-LSU state machine disabled.	0
On	INU-LSU state machine enabled.	1

No.	Name/Value	Description	Def/FbEq16
94.02	LSU panel communication	Enables/disables control panel and PC tool access to the supply unit (line-side converter) via the inverter unit (motor side converter).  Note: This feature is supported only by the following drives:  ACS880-11  ACS880-31  ACS880-37 based on an integrated drive module.	Disable
	Disable	Control panel and PC tool access to supply unit via inverter unit disabled.	0
	Enable	Control panel and PC tool access to supply unit via inverter unit enabled.	1
94.04	INU-LSU status word profile	(Only visible with certain drive types.) Selects the functionality of bit 1 of 06.11 Main status word.	ABB single drives standard SW
	ABB single drives standard SW	The drive sets bit 1 of <i>06.11 Main status word</i> after the DC link is charged.	0
	Backwards compatible SW	The drive sets bit 1 of 06.11 Main status word after the main contactor is closed and the supply unit (line-side converter) is running.  This setting can be used eg. when installing the drive into an existing set-up with other ACS880 as well as ACS800 drives.	1
94.10	LSU max charging time	Defines the maximum time the supply unit (LSU) is allowed for charging before a fault (7584 LSU charge failed) is generated.	15 s
	065535 s	Maximum charging time.	1 = 1 s
94.11	LSU stop delay	Defines a stop delay for the supply unit. This parameter can be used to delay the opening of the main breaker/contactor when a restart is expected.	1.0 s
	0.0 3600.0 s	Supply unit stop delay.	10 = 1 s
94.20	DC voltage reference	(Visible only when IGBT supply unit control is activated by 95.20) Displays the DC voltage reference sent to the supply unit. This parameter is read-only.	-
	0.0 2000.0 V	DC voltage reference sent to supply unit.	10 = 1 V
94.21	DC voltage ref source	(Visible only when IGBT supply unit control is activated by 95.20) Selects the source of the DC voltage reference to be sent to the supply unit.	User ref
	Zero	None.	0
	User ref	94.22 User DC voltage reference.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
94.22	User DC voltage reference	(Visible only when IGBT supply unit control is activated by 95.20) Defines the DC voltage reference for the supply unit when 94.21 DC voltage ref source is set to User ref.	0.0 V
	0.0 2000.0 V	User DC reference.	10 = 1 V

No.	lo. Name/Value Description		
94.30	(Visible only when IGBT supply unit control is activated by 95.20)  Displays the reactive power reference sent to the supply unit.  This parameter is read-only.		-
	-3276.8 3276.7 kvar	Reactive power reference sent to the supply unit.	10 = 1 kvar
94.31	Reactive power ref source	(Visible only when IGBT supply unit control is activated by 95.20) Selects the source of the reactive power reference to be sent to the supply unit.	User ref
	Zero	None.	0
	User ref	94.32 User reactive power reference.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
94.32	User reactive power reference	(Visible only when IGBT supply unit control is activated by 95.20)  Defines the reactive power reference for the supply unit when 94.31 Reactive power ref source is set to User ref.	0.0 kvar
	-3276.8 3276.7 kvar	User reactive power reference.	10 = 1 kvar
94.40	Power mot limit on net loss	Defines the maximum shaft power for motoring mode upon a supply network failure when IGBT supply unit control is active (bit 15 of 95.20 HW options word 1 is on). The value is given in percent of nominal motor power.  Note: With a diode supply unit (bit 11 of parameter 95.20 is on), the motoring shaft power is limited to 2% upon a network failure regardless of this parameter.	600.00%
	0.00 600.00%	Maximum shaft power for motoring mode upon a supply network failure.	1 = 1%
94.41	Power gen limit on net loss	Defines the maximum shaft power for generating upon a supply network failure when supply unit control is active (bit 11 or 15 of 95.20 HW options word 1 is on).  The value is given in percent of nominal motor power.	-600.00%
	-600.00 0.00%r	Maximum shaft power for generating mode upon a supply network failure.	1 = 1%

No.	Name/Value	Description	Def/FbEq16
95 HW	configuration	Various hardware-related settings.	
95.01	Supply voltage	Selects the supply voltage range. This parameter is used by the drive to determine the nominal voltage of the supply network. The parameter also affects the current ratings and the DC voltage control functions (trip and brake chopper activation limits) of the drive.  WARNING! An incorrect setting may cause the motor to rush uncontrollably, or the brake chopper or resistor to overload.  Notes:  The selections shown depend on the hardware of the drive. If only one voltage range is valid for the drive in question, it is selected by default.  This parameter cannot be changed while the drive is running.	-
	Not given	No voltage range selected. The drive will not start modulating before a range is selected.	0
	208240 V	208240 V	1
	380415 V	380415 V	2
	440480 V	440480 V	3
	500 V	500 V	4
	525600 V	525600 V	5
	660690 V	660690 V	6
95.02	Adaptive voltage limits	Enables adaptive voltage limits.  Adaptive voltage limits can be used if, for example, an IGBT supply unit is used to raise the DC voltage level. If the communication between the inverter and the IGBT supply unit is active (95.20 HW options word 1), the voltage limits are related to the DC voltage reference transmitted to the supply unit (94.20 DC voltage reference) assuming that the reference is high enough. Otherwise, the limits are calculated based on the measured DC voltage at the end of the pre-charging sequence.  This function is also useful if the AC supply voltage to the drive is high, as the warning levels are raised accordingly.	Disable; Enable (95.20 b15)
	Disable	Adaptive voltage limits disabled.	0
	Enable	Adaptive voltage limits enabled.	1
95.04	Control board supply	Specifies how the control unit of the drive is powered.	Internal 24V; External 24V (95.20 b4)
	Internal 24V	The drive control unit is powered from the drive power unit it is connected to.	0
	External 24V	The drive control unit is powered from an external power supply.	1
	Redundant external 24V	(Type BCU control units only) The drive control unit is powered from two redundant external power supplies. The loss of one of the supplies generates a warning (AFEC External power signal missing).	2

No.	Name/Value	Description	Def/FbEq16
95.08	DC switch monitoring	Enables/disables DC switch monitoring via the DIIL input. This setting is intended for use with inverter modules with an internal charging circuit that are connected to the DC bus through a DC switch.  An auxiliary contact of the DC switch must be wired to the DIIL input so that the input switches off when the DC switch is opened.  DC bus    DC bus	Disable; Enable (95.20 b5)
	Disable	DC switch monitoring through the DIIL input disabled.	0
	Enable	DC switch monitoring through the DIIL input enabled.	1
95.09	Switch fuse controller	(Only visible with a BCU control unit) Activates communication to a BSFC charging controller. This setting is intended for use with inverter modules that are connected to a DC bus through a DC switch/charging circuit controlled by a charging controller. On units without a DC switch, this parameter should be set to Disable The charging controller monitors the charging of the inverter unit, and sends an enable command when the charging has finished (ie. DC switch is closed after the 'charging OK' lamp lights, and charging switch opened). For more information, see BSFC documentation.	Enable
	Disable	Communication with BSFC disabled.	0
	Enable	Communication with BSFC enabled.	1

No.	Name/Va	alue	Descrip	tion	Def/FbEq16	
95.13	065535		Specifie This par value of If the co specifie generate See sec 0 = Red 112 = Note: TI running. Number (Only vis Shows v	tion du/dt filter support (page 135). uced run disabled Number of modules available his parameter cannot be changed while the drive is		
	Bit	Name	De	scription	ı 	
	0	Module 1		: Module 1 has been detected.		
	1	Module 2		Module 2 has been detected.		
		Woddio Z		Modulo 2 Hab Booth dottottod.		
	11	Module 12	1 =	1 = Module 12 has been detected.		
	1215	Reserved		Module 12 has been detected.		
	1210	rteserved				
	0000hF	FFFFh	Inverter	modules connected.	1 = 1	
95.15	Special HW settings		disabled Notes: The ii parar other drive.	parameter cannot be changed while the drive is	-	
	Bit	Name		Description		
	0	EX motor		The driven motor is an Ex motor provided by ABB for potentially explosive atmospheres. This sets the required minimum switching frequency for ABB Ex motors. <b>Note:</b> For non-ABB Ex motors, contact your local ABB representative.		
	1	ABB sine fil	ter	1 = An ABB sine filter is connected to the output of the drive/inverter.	he	
	<ul><li>2 High speed</li><li>3 Custom sine</li></ul>		mode	mode 1 = Minimum switching frequency limit adaptation to output frequency active. This setting improves control performance at high output frequencies (typically above 120 Hz).		
			e filter 1 = A custom sine filter is connected to the output of the drive/inverter. See also parameters 97.01, 97.02, 99.18, 99.19.			
	415	Reserved				
	0000b0	0111b	Hardwai	re options configuration word.	1 = 1	
		<del>-</del>		1g	<u>'</u>	

No. Name/Value Descr	ption	Def/FbEq16
Enable router anothe config conner	visible with a BCU control unit) es/disables router mode of the BCU control unit. When mode is active, the PSL2 channels connected to er BCU (ie. those selected by 95.17 Router channel are routed to the power units (converter modules) cted to this BCU. ection Router mode for BCU control unit (page 136). This parameter cannot be changed while the drive is g.	Off
Off Router	mode inactive.	0
On Router	mode active.	1
Other [bit] Source page	e selection (see <i>Terms and abbreviations</i> on 156).	-
config  Select connect Notes  The characon from  The the  The ther  This runi	visible with a BCU control unit) s which PSL2 channels on the BCU control unit are cted to another BCU and routed to a local power unit. local power units are to be connected to successive nnels starting from CH1. The other BCU is then nected to one or more successive channels starting in the first free channel. lowest channel selected in this parameter is routed to local power unit with the lowest number, etc. re must be at least as many local power modules as e are routed channels. s parameter cannot be changed while the drive is ning. ection Router mode for BCU control unit (page 136).	0000h
Bit Name Descri	ption	
0 ch1 0		
	annel CH2 is routed to the local power unit (which is cted to CH1).	
11   ch12   1 = Ch	annel CH12 is routed to a local power unit.	
10 15 5		
1215 Reserved		

1 = 1

No.	Nam	e/Value I	Description	Def/FbEq16	
95.20	HW		Specifies hardware-related options that require differentiated parameter defaults. Activating a bit in this parameter makes the necessary changes in other parameters – for example, activating an emergency stop option reserves a digital input. In many cases, the differentiated parameters will also be write-protected.  This parameter, as well as the changes in other parameters implemented by it, are not affected by a parameter restore.  WARNING! After switching any bits in this work, recheck the values of the affected parameters.	-	
	Bit	Name	Information		
	0	Supply frequency 60 Hz	y 0 = 50 Hz; 1 = 60 Hz. Affects parameters 11.45, 11.59, 12 30.11, 30.12, 30.13, 30.14, 31.26, 31.27, 40.15, 40.37, 43.46.01, 46.02.		
	1	Emergency stop Cat 0	1 = Emergency stop, Category 0, without FSO module. A 21.05, 23.11.	ffects 21.04,	
	2	Emergency stop Cat 1	1 = Emergency stop, Category 1, without FSO module. Affects <i>10.24</i> , <i>21.04</i> , <i>21.05</i> , <i>23.11</i> .		
	3	RO2 for -07 cabinet cooling fa	1 = Control of cabinet cooling fan (used only with specific hardware). Affects 10.27, 10.28, 10.29.	ACS880-07	
	4	Externally power control unit	ed 1 = Control unit powered externally. Affects 95.04. (Visible ZCU control unit)	e only with a	
	5	DC supply switch	1 = DC switch monitoring active. Affects 20.12, 31.03, 95.08. (Visible only with a ZCU control unit)		
	6	DOL motor switc	h 1 = Motor fan control active. Affects 10.24, 35.100, 35.10	3, 35.104.	
	7	Not used			
	8	Service switch or PTC/Pt100 relay	,	31.01,	
	9	Output contactor	1 = Output contactor present. Affects 10.24, 20.12.		
	10	Brake resistor, sir filter, IP54 fan	ne 1 = Status (e.g. thermal) switches connected to DIIL input 20.11, 20.12.	t. Affects	
	11	Not used			
	12	Reserved			
	13	du/dt filter activation	1 = Active: An external du/dt filter is connected to the drive setting will limit the output switching frequency. With inversion frame sizes R5i to R7i, the fan of the module will be force speed.      Note: This bit is to be left at 0 if the drive/inverter module with internal du/dt filtering (for example, frame R8i inverte with option +E205).	rter module d to full is equipped or modules	
	14	DOL fan activation	on 1 = The inverter unit consists of frame R8i modules with a cooling fans (option +C188). Disables fan feedback moni changes fan control to ON/OFF type.		
	15	INU-ISU communication	*1 = IGBT supply unit control by inverter unit is active. Aff and 95.02. Makes several parameters visible in groups 0.30, 31, 60, 61, 62 and 96.		

Hardware options configuration word.

0000h...FFFFh

No.	Name/	Value	Description	Def/FbEq16
95.21	НW ор	tions word 2	Specifies more hardware-related options that require differentiated parameter defaults. See parameter 95.20 HW options word 1.  WARNING! After switching any bits in this word, recheck the values of the affected parameters.  Note: This parameter cannot be changed while the drive is running.	-
	Bit	Name	Information	
	0	Dual use	1 = Dual use active. For drives with option +N8200. (Allo output frequencies and frequency reference limits.)	ws higher
	1	SynRM	1 = Synchronous reluctance motor used. Affects parame 25.03, 25.15, 99.03.	ters 25.02,
	2	Salient PM	25.02, 25.03, 25.15, 99.03.	
	3	LV Synchro	Contact your local ABB representative for more informati	
	4 Aux fan 1 supervision			
	5	Aux fan 2 supervision	1 = Auxiliary fan 2 installed and supervised.	
	615 Reserved			
	0000h.	FFFFh	Hardware options configuration word 2.	1 = 1
95.30	Paralle filter	l type list	(Only visible with a BCU control unit) Filters the list of drive/inverter types listed by parameter 95.31 Parallel type configuration.  Note: This parameter cannot be changed while the drive is running.	No filter
	No filte	r	All types listed.	0
		-415V)	-3 (380415 V) types listed.	1
	` .	)-500V)	-5 (380500 V) types listed.	2
	-7 (525	6-690V)	-7 (525690 V) types listed.	3
	-7 (525	6-690V)	-7 (525690 V) types listed.	4
	-7 LC (	525-690V)	Liquid-cooled -7 (525690 V) types listed.	5
95.31	Paralle configu		(Only visible with a BCU control unit) Defines the drive/inverter type if it consists of parallel- connected modules. If the drive/inverter consists of a single module, leave the  value at Not selected. Note: This parameter cannot be changed while the drive is  running.	Not selected
	Not sel	ected	The drive/inverter does not consist of parallel-connected modules, or type not selected.	0
	[Drive/i	nverter type]	Drive/inverter type consisting of parallel-connected modules.	-
95.40	Transfo	ormation ratio	Defines the ratio of the step-up transformer.	0.000
	0.000	100.000	Step-up transformation ratio.	1000 = 1

No.	Name/Value	Description	Def/FbEq16
96 Sys	stem	Language selection; access levels; macro selection; parameter save and restore; control unit reboot; user parameter sets; unit selection; data logger triggering; parameter checksum calculation; user lock.	
96.01	Language	Selects the language of the parameter interface and other displayed information when viewed on the control panel.  Notes:  Not all languages listed below are necessarily supported.  This parameter does not affect the languages visible in the Drive composer PC tool. (Those are specified under View – Settings.)	-
	Not selected	None.	0
	English	English.	1033
	Deutsch	German.	1031
	Italiano	Italian.	1040
	Español	Spanish.	3082
	Português	Portuguese.	2070
	Nederlands	Dutch.	1043
	Français	French.	1036
	Dansk	Danish.	1030
	Suomi	Finnish.	1035
	Svenska	Swedish.	1053
	Русский	Russian.	1049
	Polski	Polish.	1045
	Česky	Czech.	1029
	Chinese (Simplified, PRC)	Simplified Chinese.	2052
	Türkçe	Turkish.	1055
	Japanese	Japanese.	1041

No.	Name/V	/alue	Description	Def/FbEq16
96.02	Pass co	de	Pass codes can be entered into this parameter to activate further access levels (see parameter 96.03 Access levels active) or to configure the user lock.  Entering "358" toggles the parameter lock, which prevents the changing of all other parameters through the control panel or the Drive composer PC tool.  Entering the user pass code (by default, "10000000") enables parameters 96.10096.102, which can be used to define a new user pass code and to select the actions that are to be prevented.  Entering an invalid pass code will close the user lock if open, i.e. hide parameters 96.10096.102. After entering the code, check that the parameters are in fact hidden. If they are not, enter another (random) pass code.  Entering several invalid pass codes introduces a delay before a new attempt can be made. Entering further invalid codes will progressively lengthen the delay.  Note: You must change the default user pass code to maintain a high level of cybersecurity. Store the code in a safe place – the protection cannot be disabled even by ABB if the code is lost.	0
			See also section <i>User lock</i> (page <i>134</i> ).	
	09999	99999	Pass code.	-
96.03	Access	levels active	Shows which access levels have been activated by pass codes entered into parameter 96.02 Pass code.	0001h
			This parameter is read-only.	
	Bit	Name	I his parameter is read-only.	
	0	End user	I his parameter is read-only.	
	0	End user Service		
	0 1 2	End user Service Advanced	orogrammer	
	0 1 2 310	End user Service Advanced   Reserved	programmer	
	0 1 2 310	End user Service Advanced   Reserved OEM acces	programmer ss level 1	
	0 1 2 310 11	End user Service Advanced   Reserved OEM access	programmer ss level 1 ss level 2	
	0 1 2 310	End user Service Advanced   Reserved OEM acces	programmer  ss level 1 ss level 2 ss level 3	
	0 1 2 310 11 12 13	End user Service Advanced   Reserved OEM acces OEM acces	programmer  as level 1 as level 2 as level 3 lock	
	0 1 2 310 11 12 13 14	End user Service Advanced   Reserved OEM acces OEM acces OEM acces Parameter	programmer  as level 1 as level 2 as level 3 lock	
	0 1 2 310 11 12 13 14	End user Service Advanced   Reserved OEM acces OEM acces Parameter R&D acces	programmer  as level 1 as level 2 as level 3 lock	
96.04	0 1 2 310 11 12 13 14 15	End user Service Advanced   Reserved OEM acces OEM acces Parameter R&D acces	programmer  as level 1  as level 2  as level 3  lock as level	- Done
06.04	0 1 2 310 11 12 13 14 15	End user Service Advanced   Reserved OEM acces OEM acces Parameter R&D acces	programmer  as level 1 as level 2 as level 3 lock as level  Active access levels.  Selects the application macro. See chapter Application macros (page 139) for more information. After a selection is made, the parameter reverts	
06.04	0 1 2 310 11 12 13 14 15	End user Service Advanced   Reserved OEM acces OEM acces Parameter R&D acces	programmer  as level 1 as level 2 as level 3 lock as level  Active access levels.  Selects the application macro. See chapter Application macros (page 139) for more information.  After a selection is made, the parameter reverts automatically to Done.	Done
96.04	0 1 2 310 11 12 13 14 15 0000h	End user Service Advanced   Reserved OEM acces OEM acces Parameter R&D acces	programmer  as level 1 as level 2 as level 3 lock as level  Active access levels.  Selects the application macro. See chapter Application macros (page 139) for more information.  After a selection is made, the parameter reverts automatically to Done.  Macro selection complete; normal operation.  Factory macro (see page 140).	Done 0
96.04	0 1 2 310 11 12 13 14 15  0000h  Macro s  Done Factory Hand/Au	End user Service Advanced   Reserved OEM acces OEM acces Parameter R&D acces	programmer  as level 1 as level 2 as level 3 lock as level  Active access levels.  Selects the application macro. See chapter Application macros (page 139) for more information.  After a selection is made, the parameter reverts automatically to Done.  Macro selection complete; normal operation.  Factory macro (see page 140).  Hand/Auto macro (see page 142).	Done 0 1 2
96.04	0 1 2 310 11 12 13 14 15  0000h  Macro s  Done Factory Hand/Au PID-CTI	End user Service Advanced   Reserved OEM acces OEM acces Parameter R&D acces  .FFFFh relect	programmer  ss level 1 ss level 2 ss level 3 lock ss level  Active access levels.  Selects the application macro. See chapter Application macros (page 139) for more information.  After a selection is made, the parameter reverts automatically to Done.  Macro selection complete; normal operation.  Factory macro (see page 140).  Hand/Auto macro (see page 142).  PID control macro (see page 144).	Done 0 1 2 3
96.04	0 1 2 310 11 12 13 14 15  0000h  Macro s  Done Factory Hand/Au PID-CTI T-CTRL	End user Service Advanced   Reserved OEM acces OEM acces Parameter R&D acces  .FFFFh relect	programmer  as level 1 as level 2 as level 3 lock as level  Active access levels.  Selects the application macro. See chapter Application macros (page 139) for more information.  After a selection is made, the parameter reverts automatically to Done.  Macro selection complete; normal operation.  Factory macro (see page 140).  Hand/Auto macro (see page 142).	Done 0 1 2

No.	Name/Value	Description	Def/FbEq16
96.05	Macro active	Shows which application macro is currently selected. See chapter <i>Application macros</i> (page 139) for more information. To change the macro, use parameter 96.04 Macro select.	Factory
	Factory	Factory macro (see page 140).	1
	Hand/Auto	Hand/Auto macro (see page 142).	2
	PID-CTRL	PID control macro (see page 144).	3
	T-CTRL	Torque control macro (see page 148).	4
	Sequence control	Sequential control macro (see page 150).	5
	FIELDBUS	Fieldbus control macro (see page 153).	6
96.06	Parameter restore	Restores the original settings of the control program, i.e. parameter default values.  Note: This parameter cannot be changed while the drive is running.	Done
	Done	Restoring is completed.	0
	Restore defaults	All editable parameter values are restored to default values, except  • motor data and ID run results • parameter 31.42 Overcurrent fault limit • control panel/PC communication settings • I/O extension module settings • fieldbus adapter settings • encoder configuration data • application macro selection and the parameter defaults implemented by it • parameter 95.01 Supply voltage • parameter 95.09 Switch fuse controller • differentiated defaults implemented by parameters 95.20  HW options word 1 and 95.21 HW options word 2 • user lock configuration parameters 96.10096.102	8
	Clear all	<ul> <li>All editable parameter values are restored to default values, except</li> <li>control panel/PC communication settings</li> <li>application macro selection and the parameter defaults implemented by it</li> <li>parameter 95.01 Supply voltage</li> <li>parameter 95.09 Switch fuse controller</li> <li>differentiated defaults implemented by parameters 95.20 HW options word 1 and 95.21 HW options word 2</li> <li>user lock configuration parameters 96.10096.102.</li> <li>PC tool communication is interrupted during the restoring.</li> <li>Note: Activating this selection will restore the default settings of the fieldbus adapter if one is connected, potentially including settings that cannot be accessed through drive parameters.</li> </ul>	62
	Reset all fieldbus settings	Fieldbus adapter and embedded fieldbus interface settings (parameter groups 5058) are restored to default values. This will also restore the default settings of the fieldbus adapter if one is connected, potentially including settings that cannot be accessed through drive parameters.	32

No.	Name/Value	Description	Def/FbEq16
96.07	Parameter save manually	Saves the valid parameter values to permanent memory. This parameter should be used to store values sent from a fieldbus, or when using an external power supply to the control board as the supply might have a very short hold-up time when powered off.  Note: A new parameter value is saved automatically when changed from the PC tool or control panel but not when altered through a fieldbus adapter connection.	Done
	Done	Save completed.	0
	Save	Save in progress.	1
96.08	Control board boot	Changing the value of this parameter to 1 reboots the control unit (without requiring a power off/on cycle of the complete drive module).  The value reverts to 0 automatically.  Note: This parameter cannot be changed while the drive is running.	0
	01	1 = Reboot the control unit.	1 = 1
96.09	FSO reboot	Changing the value of (or the source selected by) this parameter from 0 to 1 reboots the optional FSO-xx safety functions module.  Note: The value does not revert to 0 automatically.	False
	False	0.	0
	True	1.	1
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
96.10	User set status	Shows the status of the user parameter sets. This parameter is read-only. See also section <i>User parameter sets</i> (page <i>133</i> ).	-
	n/a	No user parameter sets have been saved.	0
	Loading	A user set is being loaded.	1
	Saving	A user set is being saved.	2
	Faulted	Invalid parameter set.	3
	User set 1	User set 1 has been loaded.	4
	User set 2	User set 2 has been loaded.	5
	User set 3	User set 3 has been loaded.	6
	User set 4	User set 4 has been loaded.	7

No.	Name/Value	Description			Def/FbEq16
96.11	User set save/load	parameter settings. (page 133). The set that was in use after the next point in the set that was in use after the next point included. (groups 1416, 5) and parameters input/output value included in user point in user po	See section User puse before powering over-up.  Tration settings such and encoder configuration settings and encoder configuration and 50.31), a second seco	g down the drive is in  h as I/O extension guration parameters93, part of group 95, nd forced and 10.04) are not ing a set are not saved using this ing to load a set will ive parameter	No action
	No action	Load or save operat	ion complete; norm	nal operation.	0
	User set I/O mode	Load user paramete //O mode in1 and 96	r set using parame	ters 96.12 User set	1
	Load set 1	Load user paramete	r set 1.		2
	Load set 2	Load user paramete	r set 2.		3
	Load set 3	·			
	Load set 4	Load user paramete	r set 4.		5
	Save to set 1	Save user paramete	er set 1.		18
	Save to set 2	Save user paramete	er set 2.		19
	Save to set 3	Save user paramete	er set 3.		20
	Save to set 4	Save user paramete	er set 4.		21
96.12	User set I/O mode in1	I/O mode, selects the parameter 96.13 Us  Status of source defined by par. 96.12	e user parameter s		Not selected
		0	0	Set 1	
		1	0	Set 2	
		0	1	Set 3	
		1	1	Set 4	
	Not selected	0.			0
	Selected	1.			1
	DI1	Digital input DI1 (10)	.02 DI delayed stat	<i>us</i> , bit 0).	2
	DI2	Digital input DI2 (10	.02 DI delayed stat	<i>us</i> , bit 1).	3
	DI3	Digital input DI3 (10	.02 DI delayed stat	us, bit 2).	4
	DI4	Digital input DI4 (10	.02 DI delayed stat	us, bit 3).	5

No.	Name/V	alue	Description		Def/FbEq16
	DI5		Digital input I	DI5 (10.02 DI delayed status, bit 4).	6
	DI6		Digital input I	DI6 (10.02 DI delayed status, bit 5).	7
	DIO1		Digital input/o	output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2		Digital input/o	output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [b	oit]	Source select 156).	ction (see <i>Terms and abbreviations</i> on page	-
96.13	User se in2	t I/O mode	See paramet	er 96.12 User set I/O mode in1.	Not selected
96.16	Unit sel	ection	Selects the u and torque.	nit of parameters indicating power, temperature	0000 0000b
	Bit	Name		Information	
	0	Power unit		0 = kW	
				1 = hp	
	1	Reserved		T	
	2	Temperatui	re unit	0 = C (°C) 1 = F (°F)	
	3	Reserved			
	4	Torque unit	İ	0 = Nm (N·m) 1 = lbft (lb·ft)	
	515	Reserved			
	0000 00 0001 01		Unit selection	n word.	1 = 1
96.20	Time sy source	nc primary	drive time and The date and 96.2496.26	priority external source for synchronizing the d date. It time can also be directly set into parameters in which case this parameter is ignored, that all source selected.	DDCS Controller
	Internal		No external s	source selected.	0
	DDCS (	Controller	External conf	troller.	1
	Fieldbus	s A or B	Fieldbus inte	rface A or B.	2
	Fieldbus	s A	Fieldbus inte	rface A.	3
	Fieldbus	s B	Fieldbus inte	rface B.	4
	D2D or	M/F	The master s	station on a master/follower or drive-to-drive	5
	Embedo	ded FB	Reserved.		6
	Panel lii	nk	Control pane control panel	l, or Drive composer PC tool connected to the	8
	Etherne	t tool link	Drive compo	ser PC tool through an FENA module.	9
96.23		l D2D clock nization		r drive, activates clock synchronization for ver and drive-to-drive communication.	Inactive
			0	!	0
	Inactive		Clock synchr	onization not active.	0

No.	Name/Value	Description	Def/FbEq16
96.24	Full days since 1st Jan 1980	Number of full days passed since beginning of the year 1980. This parameter, together with 96.25 Time in minutes within 24 h and 96.26 Time in ms within one minute makes it possible to set the date and time in the drive via the parameter interface from a fieldbus or application program. This may be necessary if the fieldbus protocol does not support time synchronization.	-
	159999	Days since beginning of 1980.	1 = 1
96.25	Time in minutes within 24 h	Number of full minutes passed since midnight. For example, the value 860 corresponds to 2:20 pm. See parameter 96.24 Full days since 1st Jan 1980.	0 min
	11439	Minutes since midnight.	1 = 1
96.26	Time in ms within one minute	Number of milliseconds passed since last minute. See parameter 96.24 Full days since 1st Jan 1980.	0 ms
	059999	Number of milliseconds since last minute.	1 = 1
96.29	Time sync source status	Time source status word. This parameter is read-only.	-

Bit	Name	Description
0	Time tick received	1 = 1st priority tick received: Tick is received from 1st priority source (or from parameters 96.2496.26).
1	Aux Time tick received	1 = 2nd priority tick received: Tick is received from 2nd priority source.
2	Tick interval is too long	1 = Yes: Tick interval is too long (accuracy compromised).
3	DDCS controller	1 = Tick received: Tick is received from an external controller.
4	Master/Follower	1 = Tick received: Tick is received through the master/follower link.
5	Reserved	
6	D2D	1 = Tick received: Tick is received through the drive-to-drive link.
7	FbusA	1 = Tick received: Tick is received through fieldbus interface A.
8	FbusB	1 = Tick received: Tick is received through fieldbus interface B.
9	EFB	1 = Tick received: Tick is received through the embedded fieldbus interface.
10	Reserved	
11	Panel link	1 = Tick received: Tick is received from the control panel, or Drive composer PC tool connected to the control panel.
12	Ethernet tool link	1 = Tick received: Tick is received from Drive composer PC tool through an FENA module.
13	Parameter setting	1 = Tick received: Tick is set by parameters 96.2496.26.
14	RTC	1 = RTC time in use: Time and date is read from the real-time clock.
15	Drive On-Time	1 = Drive on-time in use: Time and date are displaying drive on-time.

		_
0000hFFFFh	Time source status word 1.	1 = 1

No.	Name/Value	Description	Def/FbEq16
96.31	Drive ID number	Specifies an ID number for the drive. The ID can be read by an external controller through DDCS, for example, for comparison with an ID contained by the controller's application.	0
	032767	ID number.	1 = 1
96.51	Clear fault and event logger	Clears the contents of the event logs. See section <i>Event logs</i> (page <i>594</i> ).	00000
	00001	Clear the event logs. (The value will automatically revert to 00000.)	1
96.39	Power up event logging	Enables/disables power-up logging. When enabled, an event ( <i>B5A2 Power up</i> ) is logged by the drive upon each power-up.	Enable
	Disable	Power-up event logging disabled.	0
	Enable	Power-up event logging enabled.	1
96.53	Actual checksum	Displays the actual parameter configuration checksum. The checksum is generated and updated whenever an action is selected in 96.54 Checksum action.  The parameters included in the calculation have been preselected, but the selection can be edited using the Drive customizer PC tool.  See also section Parameter checksum calculation (page 133).	0000h
	00000000h FFFFFFFh	Actual checksum.	-
96.54	Checksum action	Selects how the drive reacts if the parameter checksum (96.53 Actual checksum) does not match any of the active approved checksums (96.5696.59). The active checksums are selected by 96.55 Checksum control word.	No action
	No action	No action taken. (The checksum feature is not in use.)	0
	Pure event	The drive generates an event log entry (B686 Checksum mismatch).	1
	Warning	The drive generates a warning (A686 Checksum mismatch).	2
	Warning and prevent start	The drive generates a warning ( <i>A686 Checksum mismatch</i> ). Starting the drive is prevented.	3
	Fault	The drive trips on 6200 Checksum mismatch.	4

No.	Name/	Value	Description		Def/FbEq16	
96.55	Checksum control word		96.5696.59) th Bits 47 select a	to which approved checksums (out of e actual checksum (96.53) is compared. an approved (reference) checksum 696.59) into which the actual checksum 96.53 is copied.	0000000b	
	Bit	Name		Description		
	0	Approved	checksum 1	1 = Enabled: Checksum 1 (96.56) is obs	served.	
	1	Approved	checksum 2	1 = Enabled: Checksum 2 (96.57) is obs		
	2	Approved	checksum 3	1 = Enabled: Checksum 3 (96.58) is obs	served.	
	3	Approved (	checksum 4	1 = Enabled: Checksum 4 (96.59) is obs	served.	
	4	Set approv	ed checksum 1	1 = Set: Copy value of 96.53 into 96.56.		
	5	Set approv	ed checksum 2	1 = Set: Copy value of 96.53 into 96.57.		
	6		ed checksum 3	1 = Set: Copy value of 96.53 into 96.58.		
	7	Set approved checksum 4		1 = Set: Copy value of 96.53 into 96.59.		
	815 Reserved					
	000000		Checksum contro	ol word.	1 = 1	
96.56	Approv checks		Approved (refere	nce) checksum 1.	0000h	
	000000 FFFFF		Approved checks	sum 1.	-	
96.57	Approved checksum 2		Approved (refere	nce) checksum 2.	0000h	
	000000 FFFFF		Approved checks	sum 2.	-	
96.58	Approv checks		Approved (refere	nce) checksum 3.	0000h	
	000000 FFFFF		Approved checks	sum 3.	-	
96.59	Approv checks		Approved (refere	nce) checksum 4.	0000h	
	000000 FFFFF		Approved checks	sum 4.	-	

No.	Name/	Value	Description	Def/FbEq16	
96.61	User data logger status word		Provides status information on the user data logger (see page 595). This parameter is read-only.	0000b	
	Bit	Name	Description		
	0	Running	1 = The user data logger is running. The bit is cleared after trigger time has passed.	the post-	
	1	Triggered	1 = The user data logger has been triggered. The bit is clear logger is restarted.	red when the	
	2	Data available	1 = The user data logger contains data that can be read. Note that the bit is not cleared because the data is saved to the memory unit.		
	3	Configured	1 = The user data logger has been configured. Note that the cleared because the configuration data is saved to the mem		
	415	Reserved			
	0000b.	1111b	User data logger status word.	1 = 1	
96.63	User data logger trigger		Triggers, or selects a source that triggers, the user data logger.	Off	
	Off		0.	0	
	On		1.	1	
	Other [	[bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-	
96.64	User data logger start		Starts, or selects a source that starts, the user data logger.	Off	
	Off		0.	0	
	On		1.	1	
	Other [	[bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>156</i> ).	-	
96.65	Factory time le	y data logger vel	Selects the sampling interval for the factory data logger (see page 594).	500us	
	500us		500 microseconds.	500	
	2ms		2 milliseconds.	2000	
	10ms		10 milliseconds.	10000	
96.70	Disable prograi	e adaptive m	Enables/disables the adaptive program (if present). See also section <i>Adaptive programming</i> (page 67). <b>Note</b> : This parameter cannot be changed while the drive is running.	No	
	No		Adaptive program enabled.	0	
	Yes		Adaptive program disabled.	1	

No.	Name/Value	Description	Def/FbEq16
96.100	Change user pass code	(Visible when user lock is open) To change the current user pass code, enter a new code into this parameter as well as 96.101 Confirm user pass code. A warning will be active until the new pass code is confirmed. To cancel changing the pass code, close the user lock without confirming. To close the lock, enter an invalid pass code in parameter 96.02 Pass code, activate parameter 96.08 Control board boot, or cycle the power. See also section User lock (page 134).	1000000
	10000000 99999999	New user pass code.	-
96.101	Confirm user pass code	(Visible when user lock is open) Confirms the new user pass code entered in 96.100 Change user pass code.	
	10000000 9999999	Confirmation of new user pass code.	-

No.	Name/Va	alue	Descrip	tion	Def/FbEq16	
6.102	User loca functions		Selects user loc Note: Chan close ABB functi	the actions or functionalities to be prevented by the k.  ges made are effective only when the user lock is d. See parameter 96.02 Pass code.  recommends you to select all the actions and conalities unless otherwise required by the cation.	10000b	
	Bit	Name		Information		
	0	Disable ABI	3 access	1 = ABB access levels (service, advanced programm parameter 96.03) are disabled	ier, etc.; see	
	1	Freeze para	ameter	1 = Changing the parameter lock state is prevented, code 358 has no effect	i.e., pass	
	<ul> <li>Disable file download</li> <li>Disable FB v hidden</li> </ul>			<ul> <li>1 = Loading of files to drive is prevented. This applies</li> <li>firmware upgrades</li> <li>safety functions module (FSO-xx) configuration</li> <li>parameter restore</li> <li>loading an adaptive program</li> <li>loading and debugging an application program</li> <li>changing home view of control panel</li> <li>editing drive texts</li> <li>editing the favorite parameters list on control panel</li> <li>configuration settings made through control panel time/date formats and enabling/disabling clock dis</li> </ul>	el such as	
			write to	rom fieldbus		
	45	Reserved		is prevented.		
	6	Protect AP		1 = Creating a backup and restoring from a backup is	s prevented.	
	7	Disable par Bluetooth	el	1 = Bluetooth is disabled on ACS-AP-W control pane is part of a panel bus, Bluetooth is disabled on all pa		
	810	Reserved				
	11	Disable OE access leve	l 1	1 = OEM access level 1 is disabled		
	12	Disable OE access leve	12	1 = OEM access level 2 is disabled		
	13	Disable OE access leve		1 = OEM access level 3 is disabled		
	1415	Reserved	Г		Γ	
	0000h	FFFFh		n of actions to be prevented by user lock.	-	
6.108	LSU con boot	atrol board	95.20) Changin control udrive system)	only when IGBT supply unit control is activated by  ig the value of this parameter to 1 reboots the supply unit (without requiring a power off/on cycle of the  . ue reverts to 0 automatically.		
	01			oot the supply control unit.	1 = 1	

No.	Name/Value	Description	Def/FbEq16
97 Mo	tor control	Motor model settings.	
97.01	Switching frequency reference	When parameter 97.09 Switching freq mode is set to Custom, defines the switching frequency when it is not otherwise being internally limited.  Note: This is an expert level parameter and should not be adjusted without appropriate skill.	4.500 kHz
	0.000 24.000 kHz	Switching frequency reference.	1000 = 1 kHz
97.02	Minimum switching frequency	<ul> <li>When parameter 97.09 Switching freq mode is set to Custom,, defines a minimum switching frequency reference. The actual switching frequency will not fall below this limit under any circumstances.</li> <li>Notes:</li> <li>This is an expert level parameter and should not be adjusted without appropriate skill.</li> <li>The drive has internal switching frequency limits that may override the value entered here.</li> </ul>	1.500 kHz
	0.000 24.000 kHz	Minimum switching frequency.	1000 = 1 kHz
97.03	Slip gain	Defines the slip gain which is used to improve the estimated motor slip. 100% means full slip gain; 0% means no slip gain. The default value is 100%. Other values can be used if a static speed error is detected despite having the setting at full slip gain.  Example (with nominal load and nominal slip of 40 rpm): A 1000 rpm constant speed reference is given to the drive.  Despite having full slip gain (= 100%), a manual tachometer measurement from the motor axis gives a speed value of 998 rpm. The static speed error is 1000 rpm - 998 rpm = 2 rpm. To compensate the error, the slip gain should be increased to 105% (2 rpm / 40 rpm = 5%).	100%
	0 200%	Slip gain.	1 = 1%
97.04	Voltage reserve	Defines the minimum allowed voltage reserve. When the voltage reserve has decreased to the set value, the drive enters the field weakening area.   Note: This is an expert level parameter and should not be adjusted without appropriate skill.   If the intermediate circuit DC voltage $U_{\rm dc}$ = 550 V and the voltage reserve is 5%, the rms value of the maximum output voltage in steady-state operation is 0.95 × 550 V / sqrt(2) = 369 V   The dynamic performance of the motor control in the field weakening area can be improved by increasing the voltage reserve value, but the drive enters the field weakening area earlier.	-2%
	- 4 50%	Voltage reserve.	1 = 1%
97.05	Flux braking	Defines the level of flux braking power. (Other stopping and braking modes can be configured in parameter group 21 Start/stop mode).  See section Flux braking (page 104).  Note: This is an expert level parameter and should not be adjusted without appropriate skill.	Disabled
	Disabled	Flux braking is disabled.	0

No.	Name/Value	Description	Def/FbEq16
	Moderate	Flux level is limited during the braking. Deceleration time is longer compared to full braking.	1
	Full	Maximum braking power. Almost all available current is used to convert the mechanical braking energy to thermal energy in the motor.	2
97.06	Flux reference select	Defines the source of flux reference. <b>Note:</b> This is an expert level parameter and should not be adjusted without appropriate skill.	User flux reference
	Zero	None.	0
	User flux reference	Parameter 97.07 User flux reference.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page 156).	-
97.07	User flux reference	Defines the flux reference when parameter 97.06 Flux reference select is set to User flux reference.	100.00%
	0.00200.00%	User-defined flux reference.	100 = 1%
97.08	Optimizer minimum torque	This parameter can be used to improve the control dynamics of a synchronous reluctance motor or a salient permanent magnet synchronous motor.  As a rule of thumb, define a level to which the output torque must rise with minimum delay. This will increase the motor current and improve the torque response at low speeds.	0.0%
	0.0 1600.0%	Optimizer torque limit.	10 = 1%
97.09	Switching freq mode	<ul> <li>An optimization setting for balancing between control performance and motor noise level.</li> <li>Notes:</li> <li>This is an expert level parameter and should not be adjusted without appropriate skill.</li> <li>Other settings than <i>Normal</i> may require derating. Refer to the rating data in the <i>Hardware manual</i> of the drive</li> </ul>	Normal
	Normal	Control performance optimized for long motor cables.	0
	Low noise	Minimizes motor noise.	1
	Cyclic	Control performance optimized for cyclic load applications.	2
	Custom	This setting is to be used by ABB-authorized service personnel only.	3
97.10	Signal injection	<ul> <li>Enables signal injection. A high-frequency alternating signal is injected into the motor at low speeds to improve the stability of torque control. Signal injection can be enabled with different amplitude levels.</li> <li>Notes:</li> <li>This is an expert level parameter and should not be adjusted without appropriate skill.</li> <li>Use as low a level as possible that gives satisfactory performance.</li> <li>Signal injection cannot be applied to asynchronous motors.</li> </ul>	Disabled
	Disabled	Signal injection disabled.	0
	Enabled (5 %)	Signal injection enabled with an amplitude level of 5%.	1
	Enabled (10 %)	Signal injection enabled with an amplitude level of 10%.	2
	Enabled (15 %)	Signal injection enabled with an amplitude level of 15%.	3
	Enabled (20 %)	Signal injection enabled with an amplitude level of 20%.	4

No.	Name/Value	Description	Def/FbEq16
97.11	TR tuning	Rotor time constant tuning.  This parameter can be used to improve torque accuracy in closed-loop control of an induction motor. Normally, the motor identification run provides sufficient torque accuracy, but manual fine-tuning can be applied in exceptionally demanding applications to achieve optimal performance. Note: This is an expert level parameter and should not be adjusted without appropriate skill.	100%
	25400%	Rotor time constant tuning.	1 = 1%
97.12	IR comp step-up frequency	IR compensation (i.e. output voltage boost) can be used in step-up applications to compensate for resistive losses in the step-up transformer, cabling and motor. As voltage cannot be fed through a step-up transformer at 0 Hz, a specific type of IR compensation should be used. This parameter adds a frequency breakpoint for parameter 97.13 IR compensation as shown below.  U / U <sub>N</sub> (%)  Relative output voltage with IR compensation  100%  Field weakening point  0.0 Hz = Breakpoint disabled.	0.0 Hz
	0.0 50.0 Hz	IR compensation breakpoint for step-up applications.	1 = 1 Hz

No.	Name/Value	Description	Def/FbEq16
97.13	IR compensation	Defines the relative output voltage boost at zero speed (IR compensation). The function is useful in applications with a high break-away torque where direct torque control (DTC mode) cannot be applied.  ### Compensation    V / U_N (%)	0.00%
	0.00 50.00%	Voltage boost at zero speed in percent of nominal motor voltage.	1 = 1%
97.15	Motor model temperature adaptation	Selects whether the temperature-dependent parameters (such as stator or rotor resistance) of the motor model adapt to actual (measured or estimated) temperature or not. See parameter group 35 Motor thermal protection for selection of temperature measurement sources.	Disabled
	Disabled	Temperature adaptation of motor model disabled.	0
	Estimated temperature	Estimated temperature (35.01 Motor estimated temperature) used for adaptation of motor model.	1
	Measured temperature 1	Measured temperature 1 (35.02 Measured temperature 1) used for adaptation of motor model.	2
	Measured temperature 2	Measured temperature 1 (35.03 Measured temperature 2) used for adaptation of motor model.	3
97.18	Hexagonal field weakening	Activates hexagonal motor flux pattern in the field weakening area, i.e. above the limit defined by parameter 97.19 Hexagonal field weakening point.  Note: This parameter is only effective in scalar motor control mode.  See also section Hexagonal motor flux pattern (page 107).	Off
	Off	The rotating flux vector follows a circular pattern.	0
	On	The flux vector follows a circular pattern below, and a hexagonal pattern above, the hexagonal field weakening point (97.19).	1

No.	Name/Value	Description	Def/FbEq16
97.19	Hexagonal field weakening point	Defines the activation limit for hexagonal field weakening (in percent of the field weakening point, i.e. the frequency at which maximum output voltage is reached). See parameter 97.18 Hexagonal field weakening.  Note: This parameter is effective only in scalar motor control mode.	120.0%
	0.0 500.0%	Activation limit for hexagonal field weakening.	1 = 1%
97.32	Motor torque unfiltered	Unfiltered motor torque in percent of the nominal motor torque. This parameter is read-only.	-
	-1600.0 1600.0%	Unfiltered motor torque.	See par. 46.03
97.33	Speed estimate filter time	Defines a filtering time for estimated speed. See the diagram on page 683.	5.00 ms
	0.00 100.00 ms	Filtering time for estimated speed.	1 = 1 ms

98 User motor parameters	Motor values supplied by the user that are used in the motor model.  These parameters are useful for non-standard motors, or to just get more accurate motor control of the motor on site. A better motor model always improves the shaft performance.	
98.01 User motor model mode	<ul> <li>Activates the motor model parameters 98.0298.14 and the rotor angle offset parameter 98.15.</li> <li>Notes:</li> <li>Parameter value is automatically set to zero when ID run is selected by parameter 99.13 ID run requested. The values of parameters 98.0298.15 are then updated according to the motor characteristics identified during the ID run.</li> <li>Measurements made directly from the motor terminals during the ID run are likely to produce slightly different values than those on a datasheet from a motor manufacturer.</li> <li>This parameter cannot be changed while the drive is running.</li> </ul>	Not selected
Not selected	The values detected during the ID run are being used.	0
Motor parameters	The values of parameters 98.0298.14 are used as the motor model.	1
Position offset	The value of parameter 98.15 is used as the rotor angle offset. Parameters 98.0298.14 are inactive.	2
Motor parameters & position offset	The values of parameters 98.0298.14 are used as the motor model, and the value of parameter 98.15 is used as the rotor angle offset.	3
98.02 Rs user	Defines the stator resistance $R_{\rm S}$ of the motor model. With a star-connected motor, $R_{\rm S}$ is the resistance of one winding. With a delta-connected motor, $R_{\rm S}$ is one-third of the resistance of one winding. Resistance value is given at 20 °C (68 °F).	0.00000 p.u.
0.00000 0.50000 p.u.	Stator resistance in per unit.	-

No.	Name/Value	Description	Def/FbEq16
98.03	Rr user	Defines the rotor resistance $R_{\rm R}$ of the motor model. Resistance value is given at 20 °C (68 °F). <b>Note:</b> This parameter is valid only for asynchronous motors.	0.00000 p.u.
	0.00000 0.50000 p.u.	Rotor resistance in per unit.	-
98.04	Lm user	Defines the main inductance $L_{\rm M}$ of the motor model. <b>Note:</b> This parameter is valid only for asynchronous motors.	0.00000 p.u.
	0.00000 10.00000 p.u.	Main inductance in per unit.	-
98.05	SigmaL user	Defines the leakage inductance $\sigma_{L_S}$ . <b>Note:</b> This parameter is valid only for asynchronous motors.	0.00000 p.u.
	0.00000 1.00000 p.u.	Leakage inductance in per unit.	-
98.06	Ld user	Defines the direct axis (synchronous) inductance. <b>Note:</b> This parameter is valid only for permanent magnet motors.	0.00000 p.u.
	0.00000 10.00000 p.u	Direct axis inductance in per unit.	-
98.07	Lq user	Defines the quadrature axis (synchronous) inductance. <b>Note:</b> This parameter is valid only for permanent magnet motors.	0.00000 p.u.
	0.00000 10.00000 p.u	Quadrature axis inductance in per unit.	-
98.08	PM flux user	Defines the permanent magnet flux. <b>Note:</b> This parameter is valid only for permanent magnet motors.	0.00000 p.u.
	0.00000 2.00000 p.u	Permanent magnet flux in per unit.	-
98.09	Rs user SI	Defines the stator resistance $R_{\rm S}$ of the motor model. Resistance value is given at 20 °C (68 °F).	0.00000 ohm
	0.00000 100.00000 ohm	Stator resistance.	-
98.10	Rr user SI	Defines the rotor resistance $R_{\rm R}$ of the motor model. Resistance value is given at 20 °C (68 °F). <b>Note:</b> This parameter is valid only for asynchronous motors.	0.00000 ohm
	0.00000 100.00000 ohm	Rotor resistance.	-
98.11	Lm user SI	Defines the main inductance $L_{\rm M}$ of the motor model. <b>Note:</b> This parameter is valid only for asynchronous motors.	0.00 mH
	0.00 100000.00 mH	Main inductance.	1 = 10 mH
98.12	SigmaL user SI	Defines the leakage inductance $\sigma L_{\rm S}$ . Note: This parameter is valid only for asynchronous motors.	0.00 mH
	0.00 100000.00 mH	Leakage inductance.	1 = 10 mH

No.	Name/Value	Description	Def/FbEq16
98.13	Ld user SI	Defines the direct axis (synchronous) inductance. <b>Note:</b> This parameter is valid only for permanent magnet motors.	0.00 mH
	0.00 100000.00 mH	Direct axis inductance.	1 = 10 mH
98.14	Lq user SI	Defines the quadrature axis (synchronous) inductance. <b>Note:</b> This parameter is valid only for permanent magnet motors.	0.00 mH
	0.00 100000.00 mH	Quadrature axis inductance.	1 = 10 mH
98.15	Position offset user	Defines an angle offset between the zero position of the synchronous motor and the zero position of the position sensor.  This value is initially set by the autophasing routine when an absolute encoder or an incremental encoder with Z-pulse is used. The value can be fine-tuned by setting 98.01 User motor model mode to Position offset or Motor parameters & position offset.  Notes:  The value is in electrical degrees. The electrical angle equals the mechanical angle multiplied by the number of motor pole pairs.  This parameter is valid only for permanent magnet motors.	0.0 deg
	0.0360.0 deg	Angle offset.	1 = 1 deg

99 Motor data		Motor configuration settings.	
99.03	Motor type	Selects the motor type.  Note: This parameter cannot be changed while the drive is running.	Asynchro- nous motor, SynRM (95.21 b1)
	Asynchronous motor	Standard squirrel cage AC induction motor (asynchronous induction motor).	0
	Permanent magnet motor	Permanent magnet motor. Three-phase AC synchronous motor with permanent magnet rotor and sinusoidal BackEMF voltage.	1
	SynRM	Synchronous reluctance motor. Three-phase AC synchronous motor with salient pole rotor without permanent magnets.	2

No.	Name/Value	Description	Def/FbEq16
99.04	Motor control mode	Selects the motor control mode.  Note: This parameter cannot be changed while the drive is running.	DTC
	DTC	Direct torque control. This mode is suitable for most applications.  Note: Instead of direct torque control, scalar control is also available, and should be used in the following situations:  • with multi-motor applications 1) if the load is not equally shared between the motors, 2) if the motors are of different sizes, or 3) if the motors are going to be changed after the motor identification (ID run)  • if the nominal current of the motor is less than 1/6 of the nominal output current of the drive  • if the drive is used with no motor connected (for example, for test purposes).  See also section Operating modes of the drive (page 43).	0
	Scalar	Scalar control. The outstanding motor control accuracy of DTC cannot be achieved in scalar control.  Refer to the <i>DTC</i> selection above for a list of applications where scalar control should definitely be used.  Notes:  Correct motor operation requires that the magnetizing current of the motor does not exceed 90% of the nominal current of the inverter.  Some standard features are disabled in scalar control mode.  See also section <i>Scalar motor control</i> (page <i>Scalar motor control</i> ), and section <i>Operating modes of the drive</i> (page <i>43</i> ).	1
99.06	Motor nominal current	Defines the nominal motor current. This setting must match the value on the rating plate of the motor. If multiple motors are connected to the drive, enter the total current of the motors.  Notes:  Correct motor operation requires that the magnetizing current of the motor does not exceed 90% of the nominal current of the drive.  This parameter cannot be changed while the drive is running.	0.0 A
	0.0 6400.0 A	Nominal current of the motor. The allowable range is $1/62 \times I_N$ (nominal current) of the drive $(02 \times I_N)$ with scalar control mode).	1 = 1 A

No.	Name/Value	Description	Def/FbEq16	
99.07	Motor nominal voltage	<ul> <li>Defines the nominal motor voltage supplied to the motor. This setting must match the value on the rating plate of the motor.</li> <li>Notes:</li> <li>With permanent magnet motors, the nominal voltage is the BackEMF voltage at nominal speed of the motor. If the voltage is given as voltage per rpm, e.g. 60 V per 1000 rpm, the voltage for a nominal speed of 3000 rpm is 3 × 60 V = 180 V. Note that nominal voltage is not the same as equivalent DC motor voltage (EDCM) given by some manufacturers. The nominal voltage can be calculated by dividing the EDCM voltage by 1.7 (or square root of 3).</li> <li>The stress on the motor insulation is always dependent on the drive supply voltage. This also applies to the case where the motor voltage rating is lower than that of the drive and the supply.</li> <li>This parameter cannot be changed while the drive is</li> </ul>	0.0 V	
		running.		
	0.0 800.0 V	Nominal voltage of the motor. The allowable range is $1/62 \times U_N$ (nominal voltage) of the drive. $U_N$ equals the upper bound of the supply voltage range selected by parameter $95.01$ Supply voltage.	10 = 1 V	
99.08	Motor nominal frequency	Defines the nominal motor frequency. This setting must match the value on the rating plate of the motor.  Note: This parameter cannot be changed while the drive is running.	50.00 Hz	
	0.00 1000.00 Hz	Nominal frequency of the motor.	10 = 1 Hz	
99.09	Motor nominal speed	Defines the nominal motor speed. The setting must match the value on the rating plate of the motor.  Note: This parameter cannot be changed while the drive is running.	0 rpm	
	0 30000 rpm	Nominal speed of the motor.	1 = 1 rpm	
99.10	Motor nominal power	Defines the nominal motor power. The setting must match the value on the rating plate of the motor. If nominal power is not shown on the rating plate, nominal torque can be entered instead in parameter 99.12.  If multiple motors are connected to the drive, enter the total power of the motors.  The unit is selected by parameter 96.16 Unit selection.  Note: This parameter cannot be changed while the drive is running.	0.00 kW or hp	
	0.0010000.00 kW	Nominal power of the motor.	1 = 1 unit	
	or 0.0013404.83 hp			
99.11	Motor nominal cos Φ	Defines the cosphi of the motor for a more accurate motor model. The value is not obligatory, but is useful with an asynchronous motor, especially when performing a standstill identification run. The setting should match the value on the rating plate of the motor.  With a permanent magnet or synchronous reluctance motor, this value is not needed.  Note: This parameter cannot be changed while the drive is running.	0.00	
		· · · · · · · · · · · · · · · · · · ·		

No.	Name/Value	Description	Def/FbEq16
99.12	Motor nominal torque	Defines the nominal motor shaft torque. This value can be given instead of nominal power (99.10) if shown on the rating plate of the motor.  The unit is selected by parameter 96.16 Unit selection.  Notes:  This setting is an alternative to the nominal power value (99.10). If both are entered, 99.12 takes priority.  This parameter cannot be changed while the drive is running.	0.000 N·m or lb·ft
	0.000 4000000.000 N·m or lb·ft	Nominal motor torque.	1 = 1 unit
99.13	None	Selects the type of the motor identification routine (ID run) performed at the next start of the drive. During the ID run, the drive will identify the characteristics of the motor for optimum motor control.  If no ID run has been performed yet (or if default parameter values have been restored using parameter 96.06  Parameter restore), this parameter is automatically set to Standstill, signifying that an ID run must be performed.  After the ID run, the drive stops and this parameter is automatically set to None.  Notes:  For the Advanced ID run, the machinery must always be de-coupled from the motor.  Before activating the ID run, configure motor temperature measurement (if used) in parameter group 35 Motor thermal protection and in parameter 97.15.  If a sine filter is installed, set the appropriate bit in parameter 95.15 Special HW settings before activating the ID run. With a non-ABB (custom) filter, set also 99.18 and 99.19.  With scalar control mode (99.04 Motor control mode = Scalar), only the Current measurement calibration ID run mode is possible.  Once the ID run is activated, it can be canceled by stopping the drive.  The ID run must be performed every time any of the motor parameters (99.04, 99.0699.12) have been changed.  Ensure that the Safe torque off and emergency stop circuits (if any) are closed during the ID run.  Mechanical brake (if present) is not opened by the logic for the ID run.  This parameter cannot be changed while the drive is running.	None
	None	No motor ID run is requested. This mode can be selected only if the ID run ( <i>Normal, Reduced, Standstill, Advanced, Advanced Standstill</i> ) has already been performed once.	0

No.	Name/Value	Description	Def/FbEq16
	Normal	<ul> <li>Normal ID run. Guarantees good control accuracy for all cases. The ID run takes about 90 seconds. This mode should be selected whenever it is possible.</li> <li>Notes: <ul> <li>If the load torque will be higher than 20% of motor nominal torque, or if the machinery is not able to withstand the nominal torque transient during the ID run, then the driven machinery must be de-coupled from the motor during a Normal ID run.</li> <li>Check the direction of rotation of the motor before starting the ID run. During the run, the motor will rotate in the forward direction.</li> </ul> </li> </ul>	1
		WARNING! The motor will run at up to approximately 50100% of the nominal speed during the ID run. ENSURE THAT IT IS SAFE TO RUN THE MOTOR BEFORE PERFORMING THE ID RUN!	
	Reduced	<ul> <li>Reduced ID run. This mode should be selected instead of the <i>Normal</i> or <i>Advanced</i> ID Run if</li> <li>mechanical losses are higher than 20% (i.e. the motor cannot be de-coupled from the driven equipment), or if</li> <li>flux reduction is not allowed while the motor is running (i.e. in case of a motor with an integrated brake supplied from the motor terminals).</li> <li>With Reduced ID run, the control in the field weakening area or at high torques is not necessarily as accurate as with the Normal ID run. Reduced ID run is completed faster than the Normal ID Run (&lt; 90 seconds).</li> <li>Note: Check the direction of rotation of the motor before starting the ID run. During the run, the motor will rotate in the forward direction.</li> <li>WARNING! The motor will run at up to approximately 50100% of the nominal speed during the ID run. ENSURE THAT IT IS SAFE TO RUN THE MOTOR BEFORE PERFORMING THE ID RUN!</li> </ul>	2
	Standstill	Standstill ID run. The motor is injected with DC current. With an AC induction (asynchronous) motor, the motor shaft is not rotated. With a permanent magnet motor or synchronous reluctance motor, the shaft can rotate up to half a revolution.  Note: A standstill ID run should be selected only if the Normal, Reduced or Advanced ID run is not possible due to the restrictions caused by the connected mechanics (e.g. with lift or crane applications).  See also selection Advanced Standstill.	3


No.	Name/Value	Description	Def/FbEq16
	Autophasing	The autophasing routine determines the start angle of a permanent magnet or synchronous reluctance motor (see page 101). Autophasing does not update the other motor model values.  Autophasing is automatically performed as part of the Normal, Reduced, Standstill, Advanced or Advanced Standstill ID runs. Using this setting, it is possible to perform autophasing alone. This is useful after changes in the feedback configuration, such as the replacement or addition of an absolute encoder, resolver, or pulse encoder with commutation signals.  Notes:  This setting can only be used after a Normal, Reduced, Standstill, Advanced or Advanced Standstill ID run has already been performed.  Depending on the selected autophasing mode, the shaft can rotate during autophasing. See parameter 21.13	4
		Autophasing mode.	
	Current measurement calibration	Requests current measurement calibration, that is identification of current measurement offset and gain errors.	5
	Advanced	Advanced ID run. Guarantees the best possible control accuracy. The ID run can take a couple of minutes. This mode should be selected when top performance is needed across the whole operating area.  Note: The driven machinery must be de-coupled from the motor because of high torque and speed transients that are applied.  WARNING! The motor will run at up to approximately 50100% of the nominal speed during the ID run. Several accelerations and decelerations are done.  ENSURE THAT IT IS SAFE TO RUN THE MOTOR BEFORE PERFORMING THE ID RUN!	6
	Advanced Standstill	Advanced Standstill ID run.  This selection is recommended with AC induction motors up to 75 kW instead of the <i>Standstill</i> ID run if  • the exact nominal ratings of the motor are not known, or  • the control performance of the motor is not satisfactory after a <i>Standstill</i> ID run.  Note: The time it takes for the <i>Advanced Standstill</i> ID run to complete varies according to motor size. With a small motor, the ID run typically completes within 5 minutes; with a large motor, the ID run may take up to an hour.	7
99.14	Last ID run performed	Shows the type of ID run that was performed last. For more information about the different modes, see the selections of parameter 99.13 ID run requested.	None
	None	No ID run has been performed.	0
	Normal	Normal ID run.	1
	Reduced	Reduced ID run.	2
	Standstill	Standstill ID run.	3
	Autophasing	Autophasing.	4
	Current measurement calibration	Current measurement calibration.	5

No.	Name/Value	Description	Def/FbEq16
	Advanced	Advanced ID run.	6
	Advanced Standstill	Advanced Standstill ID run.	7
99.15	Motor polepairs calculated	Calculated number of pole pairs in the motor. This parameter is read-only.	0
	01000	Number of pole pairs.	1 = 1
99.16	Motor phase order	<ul> <li>Switches the rotation direction of motor. This parameter can be used if the motor turns in the wrong direction (for example, because of the wrong phase order in the motor cable), and correcting the cabling is considered impractical.</li> <li>Notes: <ul> <li>Changing this parameter does not affect speed reference polarities, so positive speed reference will rotate the motor forward. The phase order selection just ensures that "forward" is in fact the correct direction.</li> <li>After changing this parameter, the sign of encoder feedback (if any) must be checked. This can be done by setting parameter 90.41 Motor feedback selection to Estimate, and comparing the sign of 90.01 Motor speed for control to 90.10 Encoder 1 speed (or 90.20 Encoder 2 speed). If the sign of the measurement is incorrect, the encoder wiring must be corrected or the sign of 90.43 Motor gear numerator reversed.</li> <li>This parameter cannot be changed while the drive is running.</li> </ul> </li> </ul>	UVW
	UVW	Normal.	0
	UWV	Reversed rotation direction.	1
99.18	Sine filter inductance	Defines the inductance of a custom sine filter, i.e., when parameter 95.15 Special HW settings bit 3 is activated.  Note: For an ABB sine filter (95.15 Special HW settings bit 1), this parameter is set automatically and should not be adjusted.	-
	0.000 100000.000 mH	Inductance of custom sine filter.	1000 = 1 μH

No.	Name/Value	Description	Def/FbEq16
99.19	Sine filter capacitance	Defines the capacitance of a custom sine filter, i.e., when parameter 95.15 Special HW settings bit 3 is activated. If the capacitors are star/wye-connected, enter the capacitance of one leg into the parameter.	-
		Drive Sine filter 99.19 = C	
		If the capacitors are delta-connected, multiply the capacitance of <u>one leg</u> by 3 and enter the result into the parameter.	
		Drive Sine filter $99.19 = 3 \times C$	
		<b>Note</b> : For an ABB sine filter (95.15 Special HW settings bit 1), this parameter is set automatically and should not be adjusted.	
	0.00 100000.00 μF	Capacitance of custom sine filter.	100 = 1 μF

200 Safety	FSO-xx settings.						
This group contains parameters related to the optional FSO-xx safety functions module. For details, refer to the documentation of the FSO-xx module.							
206 I/O bus configuration	Distributed I/O bus settings. These groups are only visible with a BCU control unit.						
207 I/O bus service							
208 I/O bus diagnostics							
209 I/O bus fan identification							

These groups contain parameters related to the distributed I/O bus, which is used with some drives for monitoring the cooling fans of the cabinet system. For details, refer to CIO-01 I/O module for distributed I/O bus control user's manual (3AXD50000126880 [English]).



# Additional parameter data

### What this chapter contains

This chapter lists the parameters with some additional data such as their ranges and 32-bit fieldbus scaling. For parameter descriptions, see chapter *Parameters* (page 155).

#### Terms and abbreviations

Term	Definition	
FbEq32  32-bit fieldbus equivalent: The scaling between the integer used communication and the value shown on the panel when a 32-bit selected for transmission to an external system.  The corresponding 16-bit scalings are listed in chapter <i>Paramete</i> (page 155).		
int16	16-bit integer value (15 bits + sign).	
int32	32-bit integer value (31 bits + sign).	
No.	Parameter number.	
real32	32-bit floating point number.	
uint16	16-bit unsigned integer.	
uint32	32-bit unsigned integer.	
Туре	Parameter type. See int16, int32, real32, uint16, uint32.	

## Fieldbus addresses

Refer to the *User's manual* of the fieldbus adapter.

# Parameter groups 1...9

No.	Name	Туре	Range	Unit	FbEq32
01 Actua	al values				
01.01	Motor speed used	real32	-30000.00 30000.00	rpm	100 = 1 rpm
01.02	Motor speed estimated	real32	-30000.00 30000.00	rpm	100 = 1 rpm
01.03	Motor speed %	real32	-1000.00 1000.00	%	100 = 1%
01.04	Encoder 1 speed filtered	real32	-30000.00 30000.00	rpm	100 = 1 rpm
01.05	Encoder 2 speed filtered	real32	-30000.00 30000.00	rpm	100 = 1 rpm
01.06	Output frequency	real32	-500.00 500.00	Hz	100 = 1 Hz
01.07	Motor current	real32	0.00 30000.00	Α	100 = 1 A
01.08	Motor current % of motor nom	real32	0.0 1000.0	%	10 = 1%
01.10	Motor torque	real32	-1600.0 1600.0	%	10 = 1%
01.11	DC voltage	real32	0.00 2000.00	V	100 = 1 V
01.13	Output voltage	real32	02000	V	1 = 1 V
01.14	Output power	real32	-32768.00 32767.00	kW or hp	100 = 1 unit
01.15	Output power % of motor nom	real32	-300.00 300.00	%	10 = 1%
01.17	Motor shaft power	real32	-32768.00 32767.00	kW or hp	100 = 1 unit
01.18	Inverter GWh motoring	int16	032767	GWh	1 = 1 GWh
01.19	Inverter MWh motoring	int16	0999	MWh	1 = 1 MWh
01.20	Inverter kWh motoring	real32	0999	kWh	1 = 1 kWh
01.21	U-phase current	real32	-30000.00 30000.00	Α	100 = 1 A
01.22	V-phase current	real32	-30000.00 30000.00	Α	100 = 1 A
01.23	W-phase current	real32	-30000.00 30000.00	Α	100 = 1 A
01.24	Flux actual %	real32	0200	%	1 = 1%
01.25	INU momentary cos fii	real32	-1.00 1.00	-	100 = 1
01.29	Speed change rate	real32	-15000 15000	rpm/s	1 = 1 rpm/s
01.30	Nominal torque scale	uint32	0.000	N·m or lb·ft	1000 = 1 unit
01.31	Ambient temperature	real32	-32768 32767	°C or °F	10 = 1°
01.32	Inverter GWh regenerating	int16	032767	GWh	1 = 1 GWh
01.33	Inverter MWh regenerating	int16	0999	MWh	1 = 1 MWh
01.34	Inverter kWh regenerating	real32	0999	kWh	1 = 1 kWh
01.35	Mot - regen energy GWh	int16	-32768 32767	GWh	1 = 1 GWh
01.36	Mot - regen energy MWh	int16	-999999	MWh	1 = 1 MWh
01.37	Mot - regen energy kWh	real32	-999999	kWh	1 = 1 kWh
01.61	Abs motor speed used	real32	0.00 30000.00	rpm	100 = 1 rpm
01.62	Abs motor speed %	real32	0.00 1000.00	%	100 = 1%
01.63	Abs output frequency	real32	0.00 500.00	Hz	100 = 1 Hz
01.64	Abs motor torque	real32	0.0 1600.0	%	10 = 1%
01.65	Abs output power	real32	0.00 32767.00	kW or hp	100 = 1 unit
01.66	Abs output power % motor nom	real32	0.00 300.00	%	10 = 1%

No.	Name	Туре	Range	Unit	FbEq32
04.07	Active warning 2	uint16	0000hFFFFh	-	1 = 1
04.08	Active warning 3	uint16	0000hFFFFh	-	1 = 1
04.09	Active warning 4	uint16	0000hFFFFh	-	1 = 1
04.10	Active warning 5	uint16	0000hFFFFh	-	1 = 1
04.11	Latest fault	uint16	0000hFFFFh	-	1 = 1
04.12	2nd latest fault	uint16	0000hFFFFh	-	1 = 1
04.13	3rd latest fault	uint16	0000hFFFFh	-	1 = 1
04.14	4th latest fault	uint16	0000hFFFFh	-	1 = 1
04.15	5th latest fault	uint16	0000hFFFFh	-	1 = 1
04.16	Latest warning	uint16	0000hFFFFh	-	1 = 1
04.17	2nd latest warning	uint16	0000hFFFFh	-	1 = 1
04.18	3rd latest warning	uint16	0000hFFFFh	-	1 = 1
04.19	4th latest warning	uint16	0000hFFFFh	-	1 = 1
04.20	5th latest warning	uint16	0000hFFFFh	-	1 = 1
04.21	Fault word 1	uint16	0000hFFFFh	-	1 = 1
04.22	Fault word 2	uint16	0000hFFFFh	-	1 = 1
04.25	Faulted modules	uint16	0000hFFFFh	-	1 = 1
04.31	Warning word 1	uint16	0000hFFFFh	-	1 = 1
04.32	Warning word 2	uint16	0000hFFFFh	-	1 = 1
04.40	Event word 1	uint16	0000hFFFFh	-	1 = 1
04.41	Event word 1 bit 0 code	uint16	0000hFFFFh	-	1 = 1
04.42	Event word 1 bit 0 aux code	uint32	0000 0000h FFFF FFFFh	-	1 = 1
04.43	Event word 1 bit 1 code	uint16	0000hFFFFh	-	1 = 1
04.44	Event word 1 bit 1 aux code	uint32	0000 0000h FFFF FFFFh	-	1 = 1
			•••		
04.71	Event word 1 bit 15 code	uint16	0000hFFFFh	1	1 = 1
04.72	Event word 1 bit 15 aux code	uint32	0000 0000h FFFF FFFFh	-	1 = 1
04.120	Fault/Warning word compatibility	uint16	01	-	1 = 1
05 Diag	nostics				
05.01	On-time counter	uint16	065535	d	1 = 1 d
05.02	Run-time counter	uint16	065535	d	1 = 1 d
05.04	Fan on-time counter	uint16	065535	d	1 = 1 d
05.09	Time from power-up	uint32	04294967295	-	1 = 1
05.11	Inverter temperature	real32	-40.0 160.0	%	10 = 1%
05.22	Diagnostic word 3	uint16	0000hFFFFh	-	1 = 1
05.41	Main fan service counter	real32	0150	%	1 = 1%
05.42	Aux. fan service counter	real32	0150	%	1 = 1%
(Par	ameters <i>05.111</i> and <i>05.121</i> are	visible only w	hen IGBT supply unit cont	rol is activate	ed by 95.20)

No.	Name	Туре	Range	Unit	FbEq32			
05.111	Line converter temperature	real32	-40.0 160.0	%	10 = 1%			
05.121	MCB closing counter	real32	0 4294967295	%	1 = 1%			
06 Cont	06 Control and status words							
06.01	Main control word	uint16	0000hFFFFh	-	1 = 1			
06.02	Application control word	uint16	0000hFFFFh	-	1 = 1			
06.03	FBAA transparent control word	uint32	00000000hFFFFFFFh	-	1 = 1			
06.04	FBA B transparent control word	uint32	00000000hFFFFFFFh	-	1 = 1			
06.05	EFB transparent control word	uint32	00000000hFFFFFFFh	-				
06.11	Main status word	uint16	0000hFFFFh	-	1 = 1			
06.16	Drive status word 1	uint16	0000hFFFFh	-	1 = 1			
06.17	Drive status word 2	uint16	0000hFFFFh	-	1 = 1			
06.18	Start inhibit status word	uint16	0000hFFFFh	-	1 = 1			
06.19	Speed control status word	uint16	0000hFFFFh	-	1 = 1			
06.20	Constant speed status word	uint16	0000hFFFFh	-	1 = 1			
06.21	Drive status word 3	uint16	0000hFFFFh	-	1 = 1			
06.25	Drive inhibit status word 2	uint16	0000hFFFFh	-	1 = 1			
06.29	MSW bit 10 sel	uint32	-	-	1 = 1			
06.30	MSW bit 11 sel	uint32	-	-	1 = 1			
06.31	MSW bit 12 sel	uint32	-	-	1 = 1			
06.32	MSW bit 13 sel	uint32	-	-	1 = 1			
06.33	MSW bit 14 sel	uint32	-	-	1 = 1			
	(Parameters 06.3606.43 are	visible only	when supply unit control is a	ctivated by	95.20)			
06.36	LSU Status Word	uint16	0000hFFFFh	-	1 = 1			
06.39	Internal state machine LSU CW	uint16	0000hFFFFh	-	1 = 1			
06.40	LSU CW user bit 0 selection	uint32	-	-	1 = 1			
06.41	LSU CW user bit 1 selection	uint32	-	-	1 = 1			
06.42	LSU CW user bit 2 selection	uint32	-	-	1 = 1			
06.43	LSU CW user bit 3 selection	uint32	-	-	1 = 1			
06.45	Follower CW user bit 0 selection	uint32	-	-	1 = 1			
06.46	Follower CW user bit 1 selection	uint32	-	-	1 = 1			
06.47	Follower CW user bit 2 selection	uint32	-	-	1 = 1			
06.48	Follower CW user bit 3 selection	uint32	-	-	1 = 1			
06.50	User status word 1	uint16	0000hFFFFh	-	1 = 1			
06.60	User status word 1 bit 0 sel	uint32	-	-	1 = 1			
06.61	User status word 1 bit 1 sel	uint32	-	-	1 = 1			
06.62	User status word 1 bit 2 sel	uint32	-	-	1 = 1			

No.	Name	Type	Range	Unit	FbEq32
06.63	User status word 1 bit 3 sel	uint32	-	-	1 = 1
06.64	User status word 1 bit 4 sel	uint32	-	-	1 = 1
06.65	User status word 1 bit 5 sel	uint32	-	-	1 = 1
06.66	User status word 1 bit 6 sel	uint32	-	-	1 = 1
06.67	User status word 1 bit 7 sel	uint32	-	-	1 = 1
06.68	User status word 1 bit 8 sel	uint32	-	-	1 = 1
06.69	User status word 1 bit 9 sel	uint32	-	-	1 = 1
06.70	User status word 1 bit 10 sel	uint32	-	-	1 = 1
06.71	User status word 1 bit 11 sel	uint32	-	-	1 = 1
06.72	User status word 1 bit 12 sel	uint32	-	-	1 = 1
06.73	User status word 1 bit 13 sel	uint32	-	-	1 = 1
06.74	User status word 1 bit 14 sel	uint32	-	-	1 = 1
06.75	User status word 1 bit 15 sel	uint32	-	-	1 = 1
06.100	User control word 1	uint16	0000hFFFFh	-	1 = 1
06.101	User control word 2	uint16	0000hFFFFh	-	1 = 1
	(Parameters 06.11606.118 are	visible on	ly when supply unit control is a	activated b	y 95.20)
06.116	LSU drive status word 1	uint16	0000hFFFFh	-	1 = 1
06.118	LSU start inhibit status word	uint16	0000hFFFFh	-	1 = 1
07 Syste	em info				
07.03	Drive rating id	uint16	-	-	1 = 1
07.04	Firmware name	uint32	-	-	1 = 1
07.05	Firmware version	uint32	-	-	1 = 1
07.06	Loading package name	uint32	-	-	1 = 1
07.07	Loading package version	uint32	-	-	1 = 1
07.08	Bootloader version	uint32	-	-	1 = 1
07.11	Cpu usage	uint32	0100	%	1 = 1%
07.13	PU logic version number	uint16	-	-	1 = 1
07.15	FPGA logic version number	uint16	0000hFFFFh	-	1 = 1
(F	arameters 07.21 and 07.24 are	visible only	with option +N8010 [applicati	on progran	nmability])
07.21	Application environment status 1	uint16	0000hFFFFh	-	1 = 1
07.22	Application environment status 2	uint16	0000hFFFFh	-	1 = 1
07.23	Application name	uint32	-	-	1 = 1
07.24	Application version	uint32	-	-	1 = 1
07.25	Customization package name	uint32	-	-	1 = 1
07.26	Customization package version	uint32	-	-	1 = 1
07.30	Adaptive program status	uint16	0000hFFFFh	-	1 = 1
(Parameters 07.40 and 07.41 are visible only with option +N8010 [application programmability])					
07.40	IEC application Cpu usage peak	real32	0.0 100.0	%	10 = 1%

No.	Name	Туре	Range	Unit	FbEq32		
07.41	IEC application Cpu load average	real32	0.0 100.0	%	10 = 1%		
07.51	Slot 1 option module	uint16	-	-	1 = 1		
07.52	Slot 2 option module	uint16	-	-	1 = 1		
07.53	Slot 3 option module	uint16	-	-	1 = 1		
(Parameters 07.10607.107 are visible only when supply unit control is activated by 95.20)							
07.106	LSU loading package name	uint16	-	-	1 = 1		
07.107	LSU loading package version	uint16	-	-	1 = 1		
09 Winder actual signals							
09.01	Winder status word	uint16	0000hFFFFh	-	1 = 1		
09.02	Drive control state	uint16	09	-	1 = 1		
09.03	Actual tension ctrl mode	uint16	04	-	1 = 1		
09.11	Actual diameter	real32	0.032767.0	mm	10 = 1 mm		
09.12	Actual diameter %	real32	0.00100.00	%	100 = 1%		
09.13	Diameter ratio	real32	0.00001.0000	-	10000 = 1		
09.14	Diameter ratio inversed	real32	1.00100.00	-	100 = 1		
09.21	Estimated length	real32	0.0100000.0	m	10 = 1 m		
09.25	Roll estimated weight	real32	0.0 32767.0	kg	10 = 1 kg		
09.31	Actual tension	real32	0.032767.0	N/m	10 = 1 N/m		
09.36	Torque trim	real32	-100.00 100.00	%	100 = 1%		
09.37	Speed trim	real32	-1000.0 1000.0	rpm	10 = 1 rpm		
09.41	Load model torque ref	real32	-32767.000 32767.000	Nm	1000 = 1 Nm		
09.42	Tension torque demand	real32	-32767.000 32767.000	Nm	1000 = 1 Nm		
09.43	Friction compensation torque	real32	-32767.000 32767.000	Nm	1000 = 1 Nm		
09.44	Inertia compensation torque	real32	-32767.000 32767.000	Nm	1000 = 1 Nm		

## Parameter groups 10...99

No.	Name	Туре	Range	Unit	FbEq32				
10 Standard DI, RO									
10.01	DI status	uint16	0000hFFFFh	-	1 = 1				
10.02	DI delayed status	uint16	0000hFFFFh	-	1 = 1				
10.03	DI force selection	uint16	0000hFFFFh	-	1 = 1				
10.04	DI force data	uint16	0000hFFFFh	-	1 = 1				
10.05	DI1 ON delay	uint32	0.0 3000.0	s	10 = 1 s				
10.06	DI1 OFF delay	uint32	0.0 3000.0	s	10 = 1 s				
10.07	DI2 ON delay	uint32	0.0 3000.0	s	10 = 1 s				
10.08	DI2 OFF delay	uint32	0.0 3000.0	s	10 = 1 s				
10.09	DI3 ON delay	uint32	0.0 3000.0	s	10 = 1 s				
10.10	DI3 OFF delay	uint32	0.0 3000.0	S	10 = 1 s				
10.11	DI4 ON delay	uint32	0.0 3000.0	S	10 = 1 s				
10.12	DI4 OFF delay	uint32	0.0 3000.0	S	10 = 1 s				
10.13	DI5 ON delay	uint32	0.0 3000.0	s	10 = 1 s				
10.14	DI5 OFF delay	uint32	0.0 3000.0	S	10 = 1 s				
10.15	DI6 ON delay	uint32	0.0 3000.0	s	10 = 1 s				
10.16	DI6 OFF delay	uint32	0.0 3000.0	s	10 = 1 s				
10.21	RO status	uint16	0000hFFFFh	-	1 = 1				
10.24	RO1 source	uint32	-	-	1 = 1				
10.25	RO1 ON delay	uint32	0.0 3000.0	S	10 = 1 s				
10.26	RO1 OFF delay	uint32	0.0 3000.0	S	10 = 1 s				
10.27	RO2 source	uint32	-	-	1 = 1				
10.28	RO2 ON delay	uint32	0.0 3000.0	S	10 = 1 s				
10.29	RO2 OFF delay	uint32	0.0 3000.0	S	10 = 1 s				
10.30	RO3 source	uint32	-	-	1 = 1				
10.31	RO3 ON delay	uint32	0.0 3000.0	S	10 = 1 s				
10.32	RO3 OFF delay	uint32	0.0 3000.0	S	10 = 1 s				
10.51	DI filter time	uint32	0.3 100.0	ms	10 = 1 ms				
10.99	RO/DIO control word	uint16	0000hFFFFh	-	1 = 1				
11 Stan	dard DIO, FI, FO	<u> </u>							
11.01	DIO status	uint16	0000hFFFFh	-	1 = 1				
11.02	DIO delayed status	uint16	0000hFFFFh	-	1 = 1				
11.05	DIO1 function	uint16	02	-	1 = 1				
11.06	DIO1 output source	uint32	-		1 = 1				
11.07	DIO1 ON delay	uint32	0.0 3000.0	S	10 = 1 s				
11.08	DIO1 OFF delay	uint32	0.0 3000.0	S	10 = 1 s				
11.09	DIO2 function	uint16	02	-	1 = 1				
11.10	DIO2 output source	uint32	-		1 = 1				
11.11	DIO2 ON delay	uint32	0.0 3000.0	s	10 = 1 s				

No.	Name	Туре	Range	Unit	FbEq32
11.12	DIO2 OFF delay	uint32	0.0 3000.0	S	10 = 1 s
11.38	Freq in 1 actual value	real32	016000	Hz	1 = 1 Hz
11.39	Freq in 1 scaled	real32	-32768.000 32767.000	-	1000 = 1
11.42	Freq in 1 min	real32	016000	Hz	1 = 1 Hz
11.43	Freq in 1 max	real32	016000	Hz	1 = 1 Hz
11.44	Freq in 1 at scaled min	real32	-32768.000 32767.000	-	1000 = 1
11.45	Freq in 1 at scaled max	real32	-32768.000 32767.000	-	1000 = 1
11.54	Freq out 1 actual value	real32	016000	Hz	1 = 1 Hz
11.55	Freq out 1 source	uint32	-	-	1 = 1
11.58	Freq out 1 src min	real32	-32768.000 32767.000	-	1000 = 1
11.59	Freq out 1 src max	real32	-32768.000 32767.000	-	1000 = 1
11.60	Freq out 1 at src min	real32	016000	Hz	1 = 1 Hz
11.61	Freq out 1 at src max	real32	016000	Hz	1 = 1 Hz
11.81	DIO filter time	uint32	0.3 100.0	ms	10 = 1 ms
12 Stan	dard Al				
12.01	Al tune	uint16	04	-	
12.03	Al supervision function	uint16	04	-	1 = 1
12.04	Al supervision selection	uint16	0000hFFFFh	-	1 = 1
12.05	Al supervision force	uint16	0000hFFFFh	-	1 = 1
12.11	Al1 actual value	real32	-22.000 22.000	mA or V	1000 = 1 unit
12.12	Al1 scaled value	real32	-32768.000 32767.000	-	1000 = 1
12.15	Al1 unit selection	real32	-	-	1 = 1
12.16	Al1 filter time	real32	0.000 30.000	S	1000 = 1 s
12.17	Al1 min	real32	-22.000 22.000	mA or V	1000 = 1 mA or V
12.18	Al1 max	real32	-22.000 22.000	mA or V	1000 = 1 mA or V
12.19	Al1 scaled at Al1 min	real32	-32768.000 32767.000	-	1000 = 1
12.20	Al1 scaled at Al1 max	real32	-32768.000 32767.000	-	1000 = 1
12.21	Al2 actual value	real32	-22.000 22.000	mA or V	1000 = 1 mA or V
12.22	Al2 scaled value	real32	-32768.000 32767.000	-	1000 = 1
12.25	Al2 unit selection	real32	-	-	1 = 1
12.26	AI2 filter time	real32	0.000 30.000	S	1000 = 1 s
12.27	Al2 min	real32	-22.000 22.000	mA or V	1000 = 1 mA or V
12.28	Al2 max	real32	-22.000 22.000	mA or V	1000 = 1 mA or V
12.29	Al2 scaled at Al2 min	real32	-32768.000 32767.000	-	1000 = 1
12.30	Al2 scaled at Al2 max	real32	-32768.000 32767.000	-	1000 = 1
13 Stan	dard AO				
13.11	AO1 actual value	real32	0.000 22.000	mA	1000 = 1 mA
13.12	AO1 source	uint32	-	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32
13.16	AO1 filter time	real32	0.000 30.000	s	1000 = 1 s
13.17	AO1 source min	real32	-32768.0 32767.0	-	10 = 1
13.18	AO1 source max	real32	-32768.0 32767.0	-	10 = 1
13.19	AO1 out at AO1 src min	real32	0.000 22.000	mA	1000 = 1 mA
13.20	AO1 out at AO1 src max	real32	0.000 22.000	mA	1000 = 1 mA
13.21	AO2 actual value	real32	0.000 22.000	mA	1000 = 1 mA
13.22	AO2 source	uint32	-	-	1 = 1
13.26	AO2 filter time	real32	0.000 30.000	s	1000 = 1 s
13.27	AO2 source min	real32	-32768.0 32767.0	-	10 = 1
13.28	AO2 source max	real32	-32768.0 32767.0	-	10 = 1
13.29	AO2 out at AO2 src min	real32	0.000 22.000	mA	1000 = 1 mA
13.30	AO2 out at AO2 src max	real32	0.000 22.000	mA	1000 = 1 mA
13.91	AO1 data storage	real32	-327.68 327.67	1	100 = 1
13.92	AO2 data storage	real32	-327.68 327.67	-	100 = 1
14 I/O e	xtension module 1				
14.01	Module 1 type	uint16	04	-	1 = 1
14.02	Module 1 location	uint16	1254	-	1 = 1
14.03	Module 1 status	uint16	04	-	1 = 1
	Dlx (	14.01 Modu	ule 1 type = FDIO-01)		
14.05	DI status	uint16	00000000hFFFFFFFh	-	1 = 1
14.06	DI delayed status	uint16	00000000hFFFFFFFh	-	1 = 1
14.08	DI filter time	real32	0.8 100.0	ms	10 = 1 ms
14.12	DI1 ON delay	real32	0.00 3000.00	s	100 = 1 s
14.13	DI1 OFF delay	real32	0.00 3000.00	S	100 = 1 s
14.17	DI2 ON delay	real32	0.00 3000.00	s	100 = 1 s
14.18	DI2 OFF delay	real32	0.00 3000.00	S	100 = 1 s
14.22	DI3 ON delay	real32	0.00 3000.00	s	100 = 1 s
14.23	DI3 OFF delay	real32	0.00 3000.00	s	100 = 1 s
	Common parameters for	or DIOx (14	1.01 Module 1 type = FIO-01 o	r <i>FIO-11</i> )	
14.05	DIO status	uint16	00000000hFFFFFFFh	-	1 = 1
14.06	DIO delayed status	uint16	00000000hFFFFFFFh	-	1 = 1
	DIO1/DIO2 (1	14.01 Modu	le 1 type = FIO-01 or FIO-11)		
14.08	DIO filter time	real32	0.8 100.0	ms	10 = 1 ms
14.09	DIO1 function	uint16	01	-	1 = 1
14.11	DIO1 output source	uint32	-	-	1 = 1
14.12	DIO1 ON delay	real32	0.00 3000.00	S	100 = 1 s
14.13	DIO1 OFF delay	real32	0.00 3000.00	S	100 = 1 s
14.14	DIO2 function	uint16	01	-	1 = 1
14.16	DIO2 output source	uint32	-	-	1 = 1
14.17	DIO2 ON delay	real32	0.00 3000.00	S	100 = 1 s
14.18	DIO2 OFF delay	real32	0.00 3000.00	S	100 = 1 s

No.	Name	Туре	Range	Unit	FbEq32					
	DIO3/DIO4 (14.01 Module 1 type = FIO-01)									
14.19	DIO3 function	uint16	01	-	1 = 1					
14.21	DIO3 output source	uint32	-	-	1 = 1					
14.22	DIO3 ON delay	real32	0.00 3000.00	S	100 = 1 s					
14.23	DIO3 OFF delay	real32	0.00 3000.00	S	100 = 1 s					
14.24	DIO4 function	uint16	01	-	1 = 1					
14.26	DIO4 output source	uint32	-	-	1 = 1					
14.27	DIO4 ON delay	real32	0.00 3000.00	S	100 = 1 s					
14.28	DIO4 OFF delay	real32	0.00 3000.00	S	100 = 1 s					
	RO1/RO2 (14	1.01 Module	e 1 type = FIO-01 or FDIO-01)							
14.31	RO status	uint16	0000hFFFFh	-	1 = 1					
14.34	RO1 source	uint32	-	-	1 = 1					
14.35	RO1 ON delay	real32	0.00 3000.00	S	100 = 1 s					
14.36	RO1 OFF delay	real32	0.00 3000.00	s	100 = 1 s					
14.37	RO2 source	uint32	-	-	1 = 1					
14.38	RO2 ON delay	real32	0.00 3000.00	s	100 = 1 s					
14.39	RO2 OFF delay	real32	0.00 3000.00	s	100 = 1 s					
	Common parameters t	for Alx (14.0	01 Module 1 type = FIO-11 or	FAIO-01)						
14.19	Al supervision function	uint16	04	-	1 = 1					
14.20	Al supervision selection	uint16	0000hFFFFh	-	1 = 1					
14.21	Al tune	uint16	06 (FIO-11) 04 (FAIO-01	-	1 = 1					
14.22	Al force selection	uint16	0000hFFFFh	-	1 = 1					
	AI1/AI2 (14.	01 Module	1 type = FIO-11 or FAIO-01)							
14.26	Al1 actual value	real32	-22.000 22.000	mA or V	1000 = 1 unit					
14.27	Al1 scaled value	real32	-32768.000 32767.000	-	1000 = 1					
14.28	Al1 force data	real32	-22.000 22.000	mA or V	1000 = 1 unit					
14.29	Al1 HW switch position	uint16	-	-	1 = 1					
14.30	Al1 unit selection	uint16	-	-	1 = 1					
14.31	Al1 filter gain	uint16	07	-	1 = 1					
14.32	Al1 filter time	real32	0.000 30.000	s	1000 = 1 s					
14.33	Al1 min	real32	-22.000 22.000	mA or V	1000 = 1 mA or V					
14.34	Al1 max	real32	-22.000 22.000	mA or V	1000 = 1 mA or V					
14.35	Al1 scaled at Al1 min	real32	-32768.000 32767.000	-	1000 = 1					
14.36	Al1 scaled at Al1 max	real32	-32768.000 32767.000	-	1000 = 1					
14.41	Al2 actual value	real32	-22.000 22.000	mA or V	1000 = 1 unit					
14.42	Al2 scaled value	real32	-32768.000 32767.000	-	1000 = 1					
14.43	Al2 force data	real32	-22.000 22.000	mA or V	1000 = 1 unit					
14.44	AI2 HW switch position	uint16	-	-	1 = 1					
14.45	Al2 unit selection	uint16	-	-	1 = 1					

No.	Name	Туре	Range	Unit	FbEq32
14.46	Al2 filter gain	uint16	07	-	1 = 1
14.47	Al2 filter time	real32	0.000 30.000	S	1000 = 1 s
14.48	Al2 min	real32	-22.000 22.000	mA or V	1000 = 1 mA or V
14.49	Al2 max	real32	-22.000 22.000	mA or V	1000 = 1 mA or V
14.50	Al2 scaled at Al2 min	real32	-32768.000 32767.000	-	1000 = 1
14.51	Al2 scaled at Al2 max	real32	-32768.000 32767.000	-	1000 = 1
	AI3	(14.01 Mod	lule 1 type = FIO-11)		
14.56	Al3 actual value	real32	-22.000 22.000	mA or V	1000 = 1 unit
14.57	Al3 scaled value	real32	-32768.000 32767.000	-	1000 = 1
14.58	Al3 force data	real32	-22.000 22.000	mA or V	1000 = 1 unit
14.59	AI3 HW switch position	uint16	-	-	1 = 1
14.60	AI3 unit selection	uint16	-	-	1 = 1
14.61	Al3 filter gain	uint16	07	-	1 = 1
14.62	AI3 filter time	real32	0.000 30.000	s	1000 = 1 s
14.63	AI3 min	real32	-22.000 22.000	mA or V	1000 = 1 mA or V
14.64	Al3 max	real32	-22.000 22.000	mA or V	1000 = 1 mA or V
14.65	Al3 scaled at Al3 min	real32	-32768.000 32767.000	-	1000 = 1
14.66	Al3 scaled at Al3 max	real32	-32768.000 32767.000	-	1000 = 1
	Common parameters fo	or AOx (14.	01 Module 1 type = FIO-11 or	FAIO-01)	
14.71	AO force selection	uint16	00000000hFFFFFFFh	-	1 = 1
	AO1 (14.0	1 Module 1	type = FIO-11 or FAIO-01)		
14.76	AO1 actual value	real32	0.000 22.000	mA	1000 = 1 mA
14.77	AO1 source	uint32	-	-	1 = 1
14.78	AO1 force data	real32	0.000 22.000	mA	1000 = 1 mA
14.79	AO1 filter time	real32	0.000 30.000	s	1000 = 1 s
14.80	AO1 source min	real32	-32768.0 32767.0	-	10 = 1
14.81	AO1 source max	real32	-32768.0 32767.0	-	10 = 1
14.82	AO1 out at AO1 src min	real32	0.000 22.000	mA	1000 = 1 mA
14.83	AO1 out at AO1 src max	real32	0.000 22.000	mA	1000 = 1 mA
	AO2 (	(14.01 Moa	lule 1 type = FAIO-01)		
14.86	AO2 actual value	real32	0.000 22.000	mA	1000 = 1 mA
14.87	AO2 source	uint32	-	-	1 = 1
14.88	AO2 force data	real32	0.000 22.000	mA	1000 = 1 mA
14.89	AO2 filter time	real32	0.000 30.000	s	1000 = 1 s
14.90	AO2 source min	real32	-32768.0 32767.0	-	10 = 1
14.91	AO2 source max	real32	-32768.0 32767.0	-	10 = 1
14.92	AO2 out at AO2 src min	real32	0.000 22.000	mA	1000 = 1 mA
14.93	AO2 out at AO2 src max	real32	0.000 22.000	mA	1000 = 1 mA

No.	Name	Type	Range	Unit	FbEq32			
15 I/O extension module 2								
15.01	Module 2 type	uint16	04	-	1 = 1			
15.02	Module 2 location	uint16	1254	-	1 = 1			
15.03	Module 2 status	uint16	02	-	1 = 1			
	DIx	(15.01 Modu	ule 2 type = FDIO-01)					
15.05	DI status	uint16	00000000hFFFFFFFh	-	1 = 1			
15.06	DI delayed status	uint16	00000000hFFFFFFFh	-	1 = 1			
15.08	DI filter time	real32	0.8 100.0	ms	10 = 1 ms			
15.12	DI1 ON delay	real32	0.00 3000.00	S	100 = 1 s			
15.13	DI1 OFF delay	real32	0.00 3000.00	S	100 = 1 s			
15.17	DI2 ON delay	real32	0.00 3000.00	S	100 = 1 s			
15.18	DI2 OFF delay	real32	0.00 3000.00	s	100 = 1 s			
15.22	DI3 ON delay	real32	0.00 3000.00	s	100 = 1 s			
15.23	DI3 OFF delay	real32	0.00 3000.00	s	100 = 1 s			
	Common parameters	for DIOx (15	5.01 Module 2 type = FIO-01 o	r <i>FIO-11</i> )				
15.05	DIO status	uint16	00000000hFFFFFFFh	-	1 = 1			
15.06	DIO delayed status	uint16	00000000hFFFFFFFh	-	1 = 1			
	DIO1/DIO2 (	15.01 Modu	ile 2 type = FIO-01 or FIO-11)					
15.08	DIO filter time	real32	0.8 100.0	ms	10 = 1 ms			
15.09	DIO1 function	uint16	01	-	1 = 1			
15.11	DIO1 output source	uint32	-	-	1 = 1			
15.12	DIO1 ON delay	real32	0.0 0 3000.00	s	100 = 1 s			
15.13	DIO1 OFF delay	real32	0.00 3000.00	s	100 = 1 s			
15.14	DIO2 function	uint16	01	1	1 = 1			
15.16	DIO2 output source	uint16	-	i	1 = 1			
15.17	DIO2 ON delay	uint32	0.00 3000.00	s	100 = 1 s			
15.18	DIO2 OFF delay	real32	0.00 3000.00	S	100 = 1 s			
	DIO3/D	IO4 (15.01	Module 2 type = FIO-01)					
15.19	DIO3 function	uint16	01	-	1 = 1			
15.21	DIO3 output source	uint32	-	ı	1 = 1			
15.22	DIO3 ON delay	real32	0.00 3000.00	S	100 = 1 s			
15.23	DIO3 OFF delay	real32	0.00 3000.00	S	100 = 1 s			
15.24	DIO4 function	uint16	01	-	1 = 1			
15.26	DIO4 output source	uint32	-	-	1 = 1			
15.27	DIO4 ON delay	real32	0.00 3000.00	S	100 = 1 s			
15.28	DIO4 OFF delay	real32	0.00 3000.00	S	100 = 1 s			
	RO1/RO2 (1	5.01 Module	e 2 type = FIO-01 or FDIO-01)					
15.31	RO status	uint16	0000hFFFFh	-	1 = 1			
15.34	RO1 source	uint32	-	-	1 = 1			
15.35	RO1 ON delay	real32	0.00 3000.00	S	100 = 1 s			
15.36	RO1 OFF delay	real32	0.00 3000.00	S	100 = 1 s			

No.	Name	Туре	Range	Unit	FbEq32				
15.37	RO2 source	uint32	-	-	1 = 1				
15.38	RO2 ON delay	real32	0.00 3000.00	s	100 = 1 s				
15.39	RO2 OFF delay	real32	0.00 3000.00	s	100 = 1 s				
	Common parameters for AIx (15.01 Module 2 type = FIO-11 or FAIO-01)								
15.19	Al supervision function	uint16	04	-	1 = 1				
15.20	Al supervision selection	uint16	0000hFFFFh	-	1 = 1				
15.21	Al tune	uint16	06 (FIO-11) 04 (FAIO-01)	-	1 = 1				
15.22	Al force selection	uint16	00000000hFFFFFFFh	-	1 = 1				
	AI1/AI2 (15.	01 Module	2 type = FIO-11 or FAIO-01)						
15.26	Al1 actual value	real32	-22.000 22.000	mA or V	1000 = 1 unit				
15.27	Al1 scaled value	real32	-32768.000 32767.000	-	1000 = 1				
15.28	Al1 force data	real32	-22.000 22.000	mA or V	1000 = 1 unit				
15.29	AI1 HW switch position	uint16	-	-	1 = 1				
15.30	Al1 unit selection	uint16	-	-	1 = 1				
15.31	Al1 filter gain	uint16	07	-	1 = 1				
15.32	Al1 filter time	real32	0.000 30.000	s	1000 = 1 s				
15.33	Al1 min	real32	-22.000 22.000	mA or V	1000 = 1 mA or V				
15.34	Al1 max	real32	-22.000 22.000	mA or V	1000 = 1 mA or V				
15.35	Al1 scaled at Al1 min	real32	-32768.000 32767.000	-	1000 = 1				
15.36	Al1 scaled at Al1 max	real32	-32768.000 32767.000	-	1000 = 1				
15.41	Al2 actual value	real32	-22.000 22.000	mA or V	1000 = 1 unit				
15.42	Al2 scaled value	real32	-32768.000 32767.000	-	1000 = 1				
15.43	Al2 force data	real32	-22.000 22.000	mA or V	1000 = 1 unit				
15.44	AI2 HW switch position	uint16	-	-	1 = 1				
15.45	Al2 unit selection	uint16	-	-	1 = 1				
15.46	Al2 filter gain	uint16	07	-	1 = 1				
15.47	Al2 filter time	real32	0.000 30.000	s	1000 = 1 s				
15.48	Al2 min	real32	-22.000 22.000	mA or V	1000 = 1 mA or V				
15.49	Al2 max	real32	-22.000 22.000	mA or V	1000 = 1 mA or V				
15.50	Al2 scaled at Al2 min	real32	-32768.000 32767.000	-	1000 = 1				
15.51	Al2 scaled at Al2 max	real32	-32768.000 32767.000	-	1000 = 1				
	AI3	(15.01 Mod	lule 2 type = FIO-11)	1					
15.56	Al3 actual value	real32	-22.000 22.000	mA or V	1000 = 1 unit				
15.57	Al3 scaled value	real32	-32768.000 32767.000	-	1000 = 1				
15.58	Al3 force data	real32	-22.000 22.000	mA or V	1000 = 1 unit				
15.59	AI3 HW switch position	uint16	-	-	1 = 1				
15.60	Al3 unit selection	uint16	-	-	1 = 1				
15.61	Al3 filter gain	uint16	07	-	1 = 1				

No.	Name	Туре	Range	Unit	FbEq32
15.62	Al3 filter time	real32	0.000 30.000	S	1000 = 1 s
15.63	Al3 min	real32	-22.000 22.000	mA or V	1000 = 1 mA or V
15.64	Al3 max	real32	-22.000 22.000	mA or V	1000 = 1 mA or V
15.65	Al3 scaled at Al3 min	real32	-32768.000 32767.000	-	1000 = 1
15.66	Al3 scaled at Al3 max	real32	-32768.000 32767.000	-	1000 = 1
	Common parameters fo	or AOx (15.	01 Module 2 type = FIO-11 or	FAIO-01)	
15.71	AO force selection	uint16	00000000hFFFFFFFh	-	1 = 1
	AO1 (15.0	1 Module 2	<i>type = FIO-11</i> or <i>FAIO-01</i> )		
15.76	AO1 actual value	real32	0.000 22.000	mA	1000 = 1 mA
15.77	AO1 source	uint32	-	-	1 = 1
15.78	AO1 force data	real32	0.000 22.000	mA	1000 = 1 mA
15.79	AO1 filter time	real32	0.000 30.000	s	1000 = 1 s
15.80	AO1 source min	real32	-32768.0 32767.0	-	10 = 1
15.81	AO1 source max	real32	-32768.0 32767.0	-	10 = 1
15.82	AO1 out at AO1 src min	real32	0.000 22.000	mA	1000 = 1 mA
15.83	AO1 out at AO1 src max	real32	0.000 22.000	mA	1000 = 1 mA
	AO2 (	15.01 Mod	ule 2 type = FAIO-01)		
15.86	AO2 actual value	real32	0.000 22.000	mA	1000 = 1 mA
15.87	AO2 source	uint32	-	-	1 = 1
15.88	AO2 force data	real32	0.000 22.000	mA	1000 = 1 mA
15.89	AO2 filter time	real32	0.000 30.000	S	1000 = 1 s
15.90	AO2 source min	real32	-32768.0 32767.0	-	10 = 1
15.91	AO2 source max	real32	-32768.0 32767.0	-	10 = 1
15.92	AO2 out at AO2 src min	real32	0.000 22.000	mA	1000 = 1 mA
15.93	AO2 out at AO2 src max	real32	0.000 22.000	mA	1000 = 1 mA
16 I/O e	xtension module 3				
16.01	Module 3 type	uint16	04	-	1 = 1
16.02	Module 3 location	uint16	1254	-	1 = 1
16.03	Module 3 status	uint16	02	-	1 = 1
	DIx (	16.01 Modu	ile 3 type = FDIO-01)		
16.05	DI status	uint16	00000000hFFFFFFFh	-	1 = 1
16.06	DI delayed status	uint16	00000000hFFFFFFFh	-	1 = 1
16.08	DI filter time	real32	0.8 100.0	ms	10 = 1 ms
16.12	DI1 ON delay	real32	0.00 3000.00	S	100 = 1 s
16.13	DI1 OFF delay	real32	0.00 3000.00	S	100 = 1 s
16.17	DI2 ON delay	real32	0.00 3000.00	S	100 = 1 s
16.18	DI2 OFF delay	real32	0.00 3000.00	S	100 = 1 s
16.22	DI3 ON delay	real32	0.00 3000.00	S	100 = 1 s
16.23	DI3 OFF delay	real32	0.00 3000.00	S	100 = 1 s

No.	Name	Туре	Range	Unit	FbEq32			
	Common parameters f	or DIOx (16	6.01 Module 3 type = FIO-01 c	or <i>FIO-11</i> )				
16.05	DIO status	uint16	00000000hFFFFFFFh	-	1 = 1			
16.06	DIO delayed status	uint16	00000000hFFFFFFFh	-	1 = 1			
DIO1/DIO2 (16.01 Module 3 type = FIO-01 or FIO-11)								
16.08	DIO filter time	real32	0.8 100.0	ms	10 = 1 ms			
16.09	DIO1 function	uint16	01	-	1 = 1			
16.11	DIO1 output source	uint32	-	-	1 = 1			
16.12	DIO1 ON delay	real32	0.00 3000.00	S	100 = 1 s			
16.13	DIO1 OFF delay	real32	0.00 3000.00	S	100 = 1 s			
16.14	DIO2 function	uint16	01	-	1 = 1			
16.16	DIO2 output source	uint32	-	-	1 = 1			
16.17	DIO2 ON delay	real32	0.00 3000.00	S	100 = 1 s			
16.18	DIO2 OFF delay	real32	0.00 3000.00	S	100 = 1 s			
	DIO3/DI	04 (16.01 )	Module 3 type = FIO-01)					
16.19	DIO3 function	uint16	01	-	1 = 1			
16.21	DIO3 output source	uint32	-	-	1 = 1			
16.22	DIO3 ON delay	real32	0.00 3000.00	S	100 = 1 s			
16.23	DIO3 OFF delay	real32	0.00 3000.00	S	100 = 1 s			
16.24	DIO4 function	uint16	01	-	1 = 1			
16.26	DIO4 output source	uint32	-	-	1 = 1			
16.27	DIO4 ON delay	real32	0.00 3000.00	S	100 = 1 s			
16.28	DIO4 OFF delay	real32	0.00 3000.00	S	100 = 1 s			
	RO1/RO2 (16	6.01 Module	e 3 type = FIO-01 or FDIO-01)					
16.31	RO status	uint16	0000hFFFFh	-	1 = 1			
16.34	RO1 source	uint32	-	-	1 = 1			
16.35	RO1 ON delay	real32	0.00 3000.00	S	100 = 1 s			
16.36	RO1 OFF delay	real32	0.00 3000.00	s	100 = 1 s			
16.37	RO2 source	uint32	-	-	1 = 1			
16.38	RO2 ON delay	real32	0.00 3000.00	s	100 = 1 s			
16.39	RO2 OFF delay	real32	0.00 3000.00	s	100 = 1 s			
	Common parameters i	for Alx (16.0	01 Module 3 type = FIO-11 or	FAIO-01)				
16.19	Al supervision function	uint16	04	-	1 = 1			
16.20	Al supervision selection	real32	0000hFFFFh	-	1 = 1			
16.21	Al tune	uint32	06	-	1 = 1			
16.22	Al force selection	real32	00000000hFFFFFFFh	-	1 = 1			
	AI1/AI2 (16.	01 Module	3 type = FIO-11 or FAIO-01)					
16.26	Al1 actual value	uint32	-22.000 22.000	mA or V	1000 = 1 unit			
16.27	Al1 scaled value	real32	-32768.000 32767.000	-	1000 = 1			
16.28	Al1 force data	real32	-22.000 22.000	mA or V	1000 = 1 unit			
16.29	Al1 HW switch position	uint16	-	-	1 = 1			
16.30	Al1 unit selection	uint16	-	-	1 = 1			

No.	Name	Туре	Range	Unit	FbEq32
16.31	Al1 filter gain	uint16	07	-	1 = 1
16.32	Al1 filter time	real32	0.000 30.000	S	1000 = 1 s
16.33	Al1 min	real32	-22.000 22.000	mA or V	1000 = 1 mA or V
16.34	Al1 max	uint32	-22.000 22.000	mA or V	1000 = 1 mA or V
16.35	Al1 scaled at Al1 min	real32	-32768.000 32767.000	-	1000 = 1
16.36	Al1 scaled at Al1 max	real32	-32768.000 32767.000	-	1000 = 1
16.41	Al2 actual value	real32	-22.000 22.000	mA or V	1000 = 1 unit
16.42	Al2 scaled value	real32	-32768.000 32767.000	-	1000 = 1
16.43	Al2 force data	real32	-22.000 22.000	mA or V	1000 = 1 unit
16.44	Al2 HW switch position	uint16	-	-	1 = 1
16.45	Al2 unit selection	uint16	-	-	1 = 1
16.46	Al2 filter gain	uint16	07	-	1 = 1
16.47	Al2 filter time	real32	0.000 30.000	s	1000 = 1 s
16.48	AI2 min	real32	-22.000 22.000	mA or V	1000 = 1 mA or V
16.49	Al2 max	real32	-22.000 22.000	mA or V	1000 = 1 mA or V
16.50	Al2 scaled at Al2 min	real32	-32768.000 32767.000	-	1000 = 1
16.51	Al2 scaled at Al2 max	real32	-32768.000 32767.000	-	1000 = 1
	AI3	(16.01 Mod	lule 3 type = FIO-11)		
16.56	Al3 actual value	real32	-22.000 22.000	mA or V	1000 = 1 unit
16.57	Al3 scaled value	real32	-32768.000 32767.000	-	1000 = 1
16.58	Al3 force data	real32	-22.000 22.000	mA or V	1000 = 1 unit
16.59	AI3 HW switch position	uint16	-	-	1 = 1
16.60	Al3 unit selection	uint16	-	-	1 = 1
16.61	Al3 filter gain	uint16	07	-	1 = 1
16.62	Al3 filter time	real32	0.000 30.000	S	1000 = 1 s
16.63	Al3 min	real32	-22.000 22.000	mA or V	1000 = 1 mA or V
16.64	Al3 max	real32	-22.000 22.000	mA or V	1000 = 1 mA or V
16.65	Al3 scaled at Al3 min	real32	-32768.000 32767.000	-	1000 = 1
16.66	Al3 scaled at Al3 max	real32	-32768.000 32767.000	-	1000 = 1
	Common parameters for	or AOx (16.	01 Module 3 type = FIO-11 or	FAIO-01)	
16.71	AO force selection	uint16	00000000hFFFFFFFh	-	1 = 1
	AO1 (16.0	1 Module 3	<i>type = FIO-11</i> or <i>FAIO-01</i> )		
16.76	AO1 actual value	real32	0.000 22.000	mA	1000 = 1 mA
10.70				1	
16.77	AO1 source	uint32	-	-	1 = 1
		uint32 real32	- 0.000 22.000	- mA	1 = 1 1000 = 1 mA
16.77	AO1 source		- 0.000 22.000 0.000 30.000		

No.	Name	Туре	Range	Unit	FbEq32
16.81	AO1 source max	real32	-32768.0 32767.0	-	10 = 1
16.82	AO1 out at AO1 src min	real32	0.000 22.000	mA	1000 = 1 mA
16.83	AO1 out at AO1 src max	real32	0.000 22.000	mA	1000 = 1 mA
	AO2	(16.01 Mod	ule 3 type = FAIO-01)	<del>!</del>	
16.86	AO2 actual value	real32	0.000 22.000	mA	1000 = 1 mA
16.87	AO2 source	uint32	-	-	1 = 1
16.88	AO2 force data	real32	0.000 22.000	mA	1000 = 1 mA
16.89	AO2 filter time	real32	0.000 30.000	S	1000 = 1 s
16.90	AO2 source min	real32	-32768.0 32767.0	-	10 = 1
16.91	AO2 source max	real32	-32768.0 32767.0	-	10 = 1
16.92	AO2 out at AO2 src min	real32	0.000 22.000	mA	1000 = 1 mA
16.93	AO2 out at AO2 src max	real32	0.000 22.000	mA	1000 = 1 mA
19 Oper	ration mode				
19.01	Actual operation mode	uint16	-	-	1 = 1
19.11	Ext1/Ext2 selection	uint32	-	-	1 = 1
19.12	Ext1 control mode	uint16	17	-	1 = 1
19.14	Ext2 control mode	uint16	17	-	1 = 1
19.16	Local control mode	uint16	01	-	1 = 1
19.17	Local control disable	uint16	01	-	1 = 1
19.20	Scalar control reference unit	uint16	01	-	1 = 1
20 Start	/stop/direction				
20.01	Ext1 commands	uint16	-	-	1 = 1
20.02	Ext1 start trigger type	uint16	01	-	1 = 1
20.03	Ext1 in1 source	uint32	-	-	1 = 1
20.04	Ext1 in2 source	uint32	-	-	1 = 1
20.05	Ext1 in3 source	uint32	-	-	1 = 1
20.06	Ext2 commands	uint16	-	-	1 = 1
20.07	Ext2 start trigger type	uint16	01	-	1 = 1
20.08	Ext2 in1 source	uint32	•	-	1 = 1
20.09	Ext2 in2 source	uint32	•	-	1 = 1
20.10	Ext2 in3 source	uint32	-	-	1 = 1
20.11	Run enable stop mode	uint16	02	-	1 = 1
20.12	Run enable 1 source	uint32	-	-	1 = 1
20.19	Enable start command	uint16	•	-	1 = 1
20.23	Positive speed enable	uint16	-	-	1 = 1
20.24	Negative speed enable	uint32	-	-	1 = 1
20.25	Jogging enable	uint32	-	-	1 = 1
20.26	Jogging 1 start source	uint32	-	-	1 = 1
20.27	Jogging 2 start source	uint32	-	-	1 = 1
20.29	Local start trigger type	uint16	01	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32
22.41	Speed ref safe	real32	-30000.00 30000.00	rpm	100 = 1 rpm
22.42	Jogging 1 ref	real32	-30000.00 30000.00	rpm	100 = 1 rpm
22.43	Jogging 2 ref	real32	-30000.00 30000.00	rpm	100 = 1 rpm
22.51	Critical speed function	uint16	00b11b	-	1 = 1
22.52	Critical speed 1 low	real32	-30000.00 30000.00	rpm	100 = 1 rpm
22.53	Critical speed 1 high	real32	-30000.00 30000.00	rpm	100 = 1 rpm
22.54	Critical speed 2 low	real32	-30000.00 30000.00	rpm	100 = 1 rpm
22.55	Critical speed 2 high	real32	-30000.00 30000.00	rpm	100 = 1 rpm
22.56	Critical speed 3 low	real32	-30000.00 30000.00	rpm	100 = 1 rpm
22.57	Critical speed 3 high	real32	-30000.00 30000.00	rpm	100 = 1 rpm
22.71	Motor potentiometer function	uint16	02	-	1 = 1
22.72	Motor potentiometer initial value	real32	-32768.00 32767.00	-	100 = 1
22.73	Motor potentiometer up source	uint32	-	-	1 = 1
22.74	Motor potentiometer down source	uint32	-	-	1 = 1
22.75	Motor potentiometer ramp time	real32	0.0 3600.0	s	10 = 1 s
22.76	Motor potentiometer min value	real32	-32768.00 32767.00	-	100 = 1
22.77	Motor potentiometer max value	real32	-32768.00 32767.00	-	100 = 1
22.80	Motor potentiometer ref act	real32	-32768.00 32767.00	-	100 = 1
22.81	Speed reference act 1	real32	-30000.00 30000.00	rpm	100 = 1 rpm
22.82	Speed reference act 2	real32	-30000.00 30000.00	rpm	100 = 1 rpm
22.83	Speed reference act 3	real32	-30000.00 30000.00	rpm	100 = 1 rpm
22.84	Speed reference act 4	real32	-30000.00 30000.00	rpm	100 = 1 rpm
22.85	Speed reference act 5	real32	-30000.00 30000.00	rpm	100 = 1 rpm
22.86	Speed reference act 6	real32	-30000.00 30000.00	rpm	100 = 1 rpm
22.87	Speed reference act 7	real32	-30000.00 30000.00	rpm	100 = 1 rpm
23 Spee	d reference ramp				
23.01	Speed ref ramp input	real32	-30000.00 30000.00	rpm	100 = 1 rpm
23.02	Speed ref ramp output	real32	-30000.00 30000.00	rpm	100 = 1 rpm
23.11	Ramp set selection	uint32	-	-	1 = 1
23.12	Acceleration time 1	real32	0.0001800.000	s	1000 = 1 s
23.13	Deceleration time 1	real32	0.0001800.000	s	1000 = 1 s
23.14	Acceleration time 2	real32	0.0001800.000	s	1000 = 1 s
23.15	Deceleration time 2	real32	0.0001800.000	s	1000 = 1 s
23.16	Shape time acc 1	real32	0.0001800.000	s	1000 = 1 s
23.17	Shape time acc 2	real32	0.0001800.000	s	1000 = 1 s
23.18	Shape time dec 1	real32	0.0001800.000	s	1000 = 1 s
23.19	Shape time dec 2	real32	0.0001800.000	s	1000 = 1 s
23.20	Acc time jogging	real32	0.0001800.000	s	1000 = 1 s
23.21	Dec time jogging	real32	0.0001800.000	s	1000 = 1 s

No.	Name	Type	Range	Unit	FbEq32
23.23	Emergency stop time	real32	0.0001800.000	S	1000 = 1 s
23.24	Speed ramp in zero source	uint32	-	-	1 = 1
23.26	Ramp out balancing enable	uint32	-	-	1 = 1
23.27	Ramp out balancing ref	real32	-30000.00 30000.00	rpm	100 = 1 rpm
23.28	Variable slope enable	uint32	01	-	1 = 1
23.29	Variable slope rate	real32	230000	ms	1 = 1 ms
23.39	Follower speed correction out	real32	-30000.00 30000.00	rpm	100 = 1 rpm
23.40	Follower speed correction enable	uint32	-	-	1 = 1
23.41	Follower speed correction gain	real32	0.00 100.00	%	100 = 1%
23.42	Follower speed corr torq source	uint32	-	-	1 = 1
24 Spee	d reference conditioning				
24.01	Used speed reference	real32	-30000.00 30000.00	rpm	100 = 1 rpm
24.02	Used speed feedback	real32	-30000.00 30000.00	rpm	100 = 1 rpm
24.03	Speed error filtered	real32	-30000.0 30000.0	rpm	100 = 1 rpm
24.04	Speed error inverted	real32	-30000.0 30000.0	rpm	100 = 1 rpm
24.11	Speed correction	real32	-10000.00 10000.00	rpm	100 = 1 rpm
24.12	Speed error filter time	real32	010000	ms	1 = 1 ms
24.13	RFE speed filter	uint16	0 1	-	1 = 1
24.14	Frequency of zero	real32	0.50 500.00	Hz	10 = 1 Hz
24.15	Damping of zero	real32	-1.000 1.000	-	100 = 1
24.16	Frequency of pole	real32	0.50 500.00	Hz	10 = 1 Hz
24.17	Damping of pole	real32	-1.000 1.000	-	100 = 1
24.41	Speed error window control enable	uint32	-	-	1 = 1
24.42	Speed window control mode	uint16	01	-	1 = 1
24.43	Speed error window high	real32	0.00 3000.00	rpm	100 = 1 rpm
24.44	Speed error window low	real32	0.00 3000.00	rpm	100 = 1 rpm
24.46	Speed error step	real32	-3000.00 3000.00	rpm	100 = 1 rpm
25 Spee	d control				
25.01	Torque reference speed control	real32	-1600.0 1600.0	%	10 = 1%
25.02	Speed proportional gain	real32	0.00 250.00	-	100 = 1
25.03	Speed integration time	real32	0.00 1000.00	s	100 = 1 s
25.04	Speed derivation time	real32	0.000 10000.000	S	1000 = 1 s
25.05	Derivation filter time	real32	010000	ms	1 = 1 ms
25.06	Acc comp derivation time	real32	0.00 1000.00	s	100 = 1 s
25.07	Acc comp filter time	real32	0.0 1000.0	ms	10 = 1 ms
25.08	Drooping rate	real32	0.00 100.00	%	100 = 1%
25.09	Speed ctrl balancing enable	real32	-	-	1 = 1
25.10	Speed ctrl balancing ref	real32	-300.0 300.0	%	10 = 1%

No.	Name	Туре	Range	Unit	FbEq32
25.11	Speed control min torque	real32	-1600.0 0.0	%	10 = 1%
25.12	Speed control max torque	real32	0.0 1600.0	%	10 = 1%
25.13	Min torq sp ctrl em stop	real32	-1600 0	%	10 = 1%
25.14	Max torq sp ctrl em stop	real32	01600	%	10 = 1%
25.15	Proportional gain em stop	real32	1.00 250.00	-	100 = 1
25.18	Speed adapt min limit	real32	030000	rpm	1 = 1 rpm
25.19	Speed adapt max limit	real32	030000	rpm	1 = 1 rpm
25.21	Kp adapt coef at min speed	real32	0.000 10.000	-	1000 = 1
25.22	Ti adapt coef at min speed	real32	0.000 10.000	-	1000 = 1
25.25	Torque adapt max limit	real32	0.0 1600.0	%	10 = 1%
25.26	Torque adapt filt time	real32	0.000 100.000	s	1000 = 1 s
25.27	Kp adapt coef at min torque	real32	0.000 10.000	-	1000 = 1
25.30	Flux adaption enable	uint16	01	-	1 = 1
25.33	Speed controller autotune	uint32	-	-	1 = 1
25.34	Speed controller autotune mode	uint16	02	-	1 = 1
25.37	Mechanical time constant	real32	0.00 1000.00	s	100 = 1 s
25.38	Autotune torque step	real32	0.00 100.00	%	100 = 1%
25.39	Autotune speed step	real32	0.00 100.00	%	100 = 1%
25.40	Autotune repeat times	real32	110	-	1 = 1
25.41	Torque reference Autotune2	real32	-1600.0 1600.0	%	10 = 1%
25.42	Integral term enable	uint32	-	-	1 = 1
25.53	Torque prop reference	real32	-30000.0 30000.0	%	10 = 1%
25.54	Torque integral reference	real32	-30000.0 30000.0	%	10 = 1%
25.55	Torque deriv reference	real32	-30000.0 30000.0	%	10 = 1%
25.56	Torque acc compensation	real32	-30000.0 30000.0	%	10 = 1%
25.57	Torque reference unbalanced	real32	-30000.0 30000.0	%	10 = 1%
26 Torq	ue reference chain				
26.01	Torque reference to TC	real32	-1600.0 1600.0	%	10 = 1%
26.02	Torque reference used	real32	-1600.0 1600.0	%	10 = 1%
26.08	Minimum torque ref	real32	-1000.0 0.0	%	10 = 1%
26.09	Maximum torque ref	real32	0.0 1000.0	%	10 = 1%
26.11	Torque ref1 source	uint32	-	-	1 = 1
26.12	Torque ref2 source	uint32	-	-	1 = 1
26.13	Torque ref1 function	uint16	05	-	1 = 1
26.14	Torque ref1/2 selection	uint32	-	-	1 = 1
26.15	Load share	real32	-8.000 8.000	-	1000 = 1
26.16	Torque additive 1 source	uint32	-	-	1 = 1
26.17	Torque ref filter time	real32	0.000 30.000	S	1000 = 1 s
26.18	Torque ramp up time	real32	0.000 60.000	S	1000 = 1 s
26.19	Torque ramp down time	real32	0.000 60.000	S	1000 = 1 s

No.	Name	Туре	Range	Unit	FbEq32
26.25	Torque additive 2 source	uint32	-	-	1 = 1
26.26	Force torque ref add 2 zero	uint32	-	-	1 = 1
26.41	Torque step	real32	-300.0 300.0	%	10 = 1%
26.42	Torque step enable	uint32	01	-	1 = 1
26.43	Torque step pointer enable	uint32	-	-	1 = 1
26.44	Torque step source	uint32	-	-	1 = 1
26.51	Oscillation damping	uint32	-	-	1 = 1
26.52	Oscillation damping out enable	uint32	-	-	1 = 1
26.53	Oscillation compensation input	uint32	01	-	1 = 1
26.55	Oscillation damping frequency	real32	0.0 60.0	Hz	10 = 1 Hz
26.56	Oscillation damping phase	real32	0360	deg	1 = 1 deg
26.57	Oscillation damping gain	real32	0.0 100.0	%	10 = 1%
26.58	Oscillation damping output	real32	-1600.000 1600.000	%	1000 = 1%
26.70	Torque reference act 1	real32	-1600.0 1600.0	%	10 = 1%
26.71	Torque reference act 2	real32	-1600.0 1600.0	%	10 = 1%
26.72	Torque reference act 3	real32	-1600.0 1600.0	%	10 = 1%
26.73	Torque reference act 4	real32	-1600.0 1600.0	%	10 = 1%
26.74	Torque ref ramp out	real32	-1600.0 1600.0	%	10 = 1%
26.75	Torque reference act 5	real32	-1600.0 1600.0	%	10 = 1%
26.76	Torque reference act 6	real32	-1600.0 1600.0	%	10 = 1%
26.77	Torque ref add A actual	real32	-1600.0 1600.0	%	10 = 1%
26.78	Torque ref add B actual	real32	-1600.0 1600.0	%	10 = 1%
26.81	Rush control gain	real32	0.0 10000.0	-	10 = 1
26.82	Rush control integration time	real32	0.0 10.0	s	10 = 1 s
28 Freq	uency reference chain				
28.01	Frequency ref ramp input	real32	-500.00 500.00	Hz	100 = 1 Hz
28.02	Frequency ref ramp output	real32	-500.00 500.00	Hz	100 = 1 Hz
28.11	Frequency ref1 source	uint32	-	-	1 = 1
28.12	Frequency ref2 source	uint32	-	-	1 = 1
28.13	Frequency ref1 function	uint16	05	-	1 = 1
28.14	Frequency ref1/2 selection	uint32	-	-	1 = 1
28.21	Constant frequency function	uint16	00b11b	-	1 = 1
28.22	Constant frequency sel1	uint32	-	-	1 = 1
28.23	Constant frequency sel2	uint32	-	-	1 = 1
28.24	Constant frequency sel3	uint32	-	-	1 = 1
28.26	Constant frequency 1	real32	-500.00 500.00	Hz	100 = 1 Hz
28.27	Constant frequency 2	real32	-500.00 500.00	Hz	100 = 1 Hz
28.28	Constant frequency 3	real32	-500.00 500.00	Hz	100 = 1 Hz
28.29	Constant frequency 4	real32	-500.00 500.00	Hz	100 = 1 Hz
28.30	Constant frequency 5	real32	-500.00 500.00	Hz	100 = 1 Hz
28.31	Constant frequency 6	real32	-500.00 500.00	Hz	100 = 1 Hz

No.	Name	Туре	Range	Unit	FbEq32
28.32	Constant frequency 7	real32	-500.00 500.00	Hz	100 = 1 Hz
28.41	Frequency ref safe	real32	-500.00 500.00	Hz	100 = 1 Hz
28.51	Critical frequency function	uint16	00b11b	-	1 = 1
28.52	Critical frequency 1 low	real32	-500.00 500.00	Hz	100 = 1 Hz
28.53	Critical frequency 1 high	real32	-500.00 500.00	Hz	100 = 1 Hz
28.54	Critical frequency 2 low	real32	-500.00 500.00	Hz	100 = 1 Hz
28.55	Critical frequency 2 high	real32	-500.00 500.00	Hz	100 = 1 Hz
28.56	Critical frequency 3 low	real32	-500.00 500.00	Hz	100 = 1 Hz
28.57	Critical frequency 3 high	real32	-500.00 500.00	Hz	100 = 1 Hz
28.71	Freq ramp set selection	uint32	-	-	1 = 1
28.72	Freq acceleration time 1	real32	0.0001800.000	S	1000 = 1 s
28.73	Freq deceleration time 1	real32	0.0001800.000	s	1000 = 1 s
28.74	Freq acceleration time 2	real32	0.0001800.000	s	1000 = 1 s
28.75	Freq deceleration time 2	real32	0.0001800.000	s	1000 = 1 s
28.76	Freq ramp in zero source	uint32	-	-	1 = 1
28.77	Freq ramp hold	uint32	-	-	1 = 1
28.78	Freq ramp output balancing	real32	-500.00 500.00	Hz	100 = 1 Hz
28.79	Freq ramp out balancing enable	uint32	-	-	1 = 1
28.90	Frequency ref act 1	real32	-500.00 500.00	Hz	100 = 1 Hz
28.91	Frequency ref act 2	real32	-500.00 500.00	Hz	100 = 1 Hz
28.92	Frequency ref act 3	real32	-500.00 500.00	Hz	100 = 1 Hz
28.96	Frequency ref act 7	real32	-500.00 500.00	Hz	100 = 1 Hz
28.97	Frequency ref unlimited	real32	-500.00 500.00	Hz	100 = 1 Hz
30 Limit	ts				
30.01	Limit word 1	uint16	0000hFFFFh	-	1 = 1
30.02	Torque limit status	uint16	0000hFFFFh	-	1 = 1
30.11	Minimum speed	real32	-30000.00 30000.00	rpm	100 = 1 rpm
30.12	Maximum speed	real32	-30000.00 30000.00	rpm	100 = 1 rpm
30.13	Minimum frequency	real32	-500.00 500.00	Hz	100 = 1 Hz
30.14	Maximum frequency	real32	-500.00 500.00	Hz	100 = 1 Hz
30.15	Maximum start current enable	uint16	01	-	1 = 1
30.16	Maximum start current	real32	0.00 30000.00	Α	100 = 1 A
30.17	Maximum current	real32	0.00 30000.00	Α	100 = 1 A
30.18	Minimum torque sel	uint32	-	-	1 = 1
30.19	Minimum torque 1	real32	-1600.0 0.0	%	10 = 1%
30.20	Maximum torque 1	real32	0.0 1600.0	%	10 = 1%
30.21	Minimum torque 2 source	uint32	-	-	1 = 1
30.22	Maximum torque 2 source	uint32	-	-	1 = 1
30.23	Minimum torque 2	real32	-1600.0 0.0	%	10 = 1%
30.24	Maximum torque 2	real32	0.0 1600.0	%	10 = 1%

No.	Name	Type	Range	Unit	FbEq32
31.33	Emergency ramp supervision delay	real32	032767	s	1 = 1 s
31.35	Main fan fault function	uint16	02	-	1 = 1
	(Parameter 3	1.36 only vi	isible with a ZCU control unit)	1	l
31.36	Aux fan fault function	uint16	01	-	1 = 1
31.37	Ramp stop supervision	real32	0300	%	1 = 1%
31.38	Ramp stop supervision delay	real32	032767	s	1 = 1 s
31.40	Disable warnings	uint16	0000hFFFFh	-	1 = 1
31.42	Overcurrent fault limit	real32	0.030000.0	Α	100 = 1 A
31.54	Fault action	uint16	01	-	1 = 1
31.55	Ext I/O comm loss event	uint16	02	-	1 = 1
(Par	ameters 31.120 and 31.121 are	visible only	when IGBT supply unit contro	ol is activat	ted by 95.20)
31.120	LSU earth fault	uint16	01	-	1 = 1
31.121	LSU supply phase loss	uint16	01	-	1 = 1
32 Supe	ervision				
32.01	Supervision status	uint16	000b111b	-	1 = 1
32.05	Supervision 1 function	uint16	06	-	1 = 1
32.06	Supervision 1 action	uint16	02	-	1 = 1
32.07	Supervision 1 signal	uint32	-	-	1 = 1
32.08	Supervision 1 filter time	real32	0.000 30.000	s	1000 = 1 s
32.09	Supervision 1 low	real32	-21474830.00 21474830.00	-	100 = 1
32.10	Supervision 1 high	real32	-21474830.00 21474830.00	-	100 = 1
32.15	Supervision 2 function	uint16	06	-	1 = 1
32.16	Supervision 2 action	uint16	03	-	1 = 1
32.17	Supervision 2 signal	uint32	-	-	1 = 1
32.18	Supervision 2 filter time	real32	0.000 30.000	S	1000 = 1 s
32.19	Supervision 2 low	real32	-21474830.00 21474830.00	-	100 = 1
32.20	Supervision 2 high	real32	-21474830.00 21474830.00	-	100 = 1
32.25	Supervision 3 function	uint16	06	-	1 = 1
32.26	Supervision 3 action	uint16	02	-	1 = 1
32.27	Supervision 3 signal	uint32	-	-	1 = 1
32.28	Supervision 3 filter time	real32	0.000 30.000	S	1000 = 1 s
32.29	Supervision 3 low	real32	-21474830.00 21474830.00	-	100 = 1
32.30	Supervision 3 high	real32	-21474830.00 21474830.00	-	100 = 1
33 Gene	eric timer & counter				
33.01	Counter status	uint16	000000b111111b	-	1 = 1
33.10	On-time 1 actual	real32	04294967295	S	1 = 1 s

No.	Name	Туре	Range	Unit	FbEq32
35.03	Measured temperature 2	real32	-60 5000 °C, -76 9032 °F, 0 ohm or [35.22] ohm	°C, °F or ohm	1 = 1 unit
35.04	FPTC status word	uint16	0000hFFFFh	-	1 = 1
35.05	Motor overload level	real32	0.0 300.0	%	10 = 1%
35.11	Temperature 1 source	uint16	011	-	1 = 1
35.12	Temperature 1 fault limit	real32	-60 5000 °C or ohm, or -76 9032 °F	°C, °F or ohm	1 = 1 unit
35.13	Temperature 1 warning limit	real32	-60 5000 °C or ohm, or -76 9032 °F	°C, °F or ohm	1 = 1 unit
35.14	Temperature 1 Al source	uint32	-	-	1 = 1
35.21	Temperature 2 source	uint16	011	-	1 = 1
35.22	Temperature 2 fault limit	real32	-60 5000 °C or ohm, or -76 9032 °F	°C, °F or ohm	1 = 1 unit
35.23	Temperature 2 warning limit	real32	-60 5000 °C or ohm, or -76 9032 °F	°C, °F or ohm	1 = 1 unit
35.24	Temperature 2 Al source	uint32	-	-	1 = 1
35.30	FPTC configuration word	uint16	0000hFFFFh	-	1 = 1
35.50	Motor ambient temperature	real32	-60 100 °C or -76 212 °F	°C or °F	1 = 1°
35.51	Motor load curve	real32	50150	%	1 = 1%
35.52	Zero speed load	real32	25150	%	1 = 1%
35.53	Break point	real32	1.00 500.00	Hz	100 = 1 Hz
35.54	Motor nominal temperature rise	real32	0300 °C or 32572 °F	°C or °F	1 = 1°
35.55	Motor thermal time constant	real32	10010000	S	1 = 1 s
35.56	Motor overload action	uint16	0 2	-	1 = 1
35.57	Motor overload class	uint16	0 4	-	1 = 1
35.60	Cable temperature	real32	0.0 200.0	%	10 = 1%
35.61	Cable nominal current	real32	0.00 10000.0	Α	100 = 1 A
35.62	Cable thermal rise time	real32	050000	s	1 = 1 s
35.100	DOL starter control source	uint32	-	-	1 = 1
35.101	DOL starter on delay	real32	042949673	S	1 = 1 s
35.102	DOL starter off delay	real32	0715828	min	1 = 1 min
35.103	DOL starter feedback source	uint32	-	-	1 = 1
35.104	DOL starter feedback delay	real32	042949673	s	1 = 1 s
35.105	DOL starter status word	uint16	0000b1111b	-	1 = 1
35.106	DOL starter event type	uint16	02	-	1 = 1
36 Load	analyzer			1	
36.01	PVL signal source	uint32	-	-	1 = 1
36.02	PVL filter time	real32	0.00 120.00	S	100 = 1 s
36.06	AL2 signal source	uint32	-	-	1 = 1
36.07	AL2 signal scaling	real32	0.00 32767.00	-	100 = 1
36.08	Logger function	uint16	00b11b	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32
36.09	Reset loggers	uint16	03	-	1 = 1
36.10	PVL peak value	real32	-32768.00 32767.00	-	100 = 1
36.11	PVL peak date	uint16	-	-	1 = 1
36.12	PVL peak time	uint32	-	-	1 = 1
36.13	PVL current at peak	real32	-32768.00 32767.00	Α	100 = 1 A
36.14	PVL DC voltage at peak	real32	0.00 2000.00	V	100 = 1 V
36.15	PVL speed at peak	real32	-32768.00 32767.00	rpm	100 = 1 rpm
36.16	PVL reset date	uint16	-	-	1 = 1
36.17	PVL reset time	uint32	-	-	1 = 1
36.20	AL1 below 10%	real32	0.00 100.00	%	100 = 1%
36.21	AL1 10 to 20%	real32	0.00 100.00	%	100 = 1%
36.22	AL1 20 to 30%	real32	0.00 100.00	%	100 = 1%
36.23	AL1 30 to 40%	real32	0.00 100.00	%	100 = 1%
36.24	AL1 40 to 50%	real32	0.00 100.00	%	100 = 1%
36.25	AL1 50 to 60%	real32	0.00 100.00	%	100 = 1%
36.26	AL1 60 to 70%	real32	0.00 100.00	%	100 = 1%
36.27	AL1 70 to 80%	real32	0.00 100.00	%	100 = 1%
36.28	AL1 80 to 90%	real32	0.00 100.00	%	100 = 1%
36.29	AL1 over 90%	real32	0.00 100.00	%	100 = 1%
36.40	AL2 below 10%	real32	0.00 100.00	%	100 = 1%
36.41	AL2 10 to 20%	real32	0.00 100.00	%	100 = 1%
36.42	AL2 20 to 30%	real32	0.00 100.00	%	100 = 1%
36.43	AL2 30 to 40%	real32	0.00 100.00	%	100 = 1%
36.44	AL2 40 to 50%	real32	0.00 100.00	%	100 = 1%
36.45	AL2 50 to 60%	real32	0.00 100.00	%	100 = 1%
36.46	AL2 60 to 70%	real32	0.00 100.00	%	100 = 1%
36.47	AL2 70 to 80%	real32	0.00 100.00	%	100 = 1%
36.48	AL2 80 to 90%	real32	0.00 100.00	%	100 = 1%
36.49	AL2 over 90%	real32	0.00 100.00	%	100 = 1%
36.50	AL2 reset date	uint16	-	-	1 = 1
36.51	AL2 reset time	uint32	-	-	1 = 1
37 User	load curve				
37.01	ULC output status word	uint16	0000hFFFFh	-	1 = 1
37.02	ULC supervision signal	uint32	-	-	1 = 1
37.03	ULC overload actions	uint16	03	-	1 = 1
37.04	ULC underload actions	uint16	03	-	1 = 1
37.11	ULC speed table point 1	real32	0.0 30000.0	rpm	10 = 1 rpm
37.12	ULC speed table point 2	real32	0.0 30000.0	rpm	10 = 1 rpm
37.13	ULC speed table point 3	real32	0.0 30000.0	rpm	10 = 1 rpm
37.14	ULC speed table point 4	real32	0.0 30000.0	rpm	10 = 1 rpm
37.15	ULC speed table point 5	real32	0.0 30000.0	rpm	10 = 1 rpm

No.	Name	Туре	Range	Unit	FbEq32
37.16	ULC frequency table point 1	real32	0.0 500.0	Hz	10 = 1 Hz
37.17	ULC frequency table point 2	real32	0.0 500.0	Hz	10 = 1 Hz
37.18	ULC frequency table point 3	real32	0.0 500.0	Hz	10 = 1 Hz
37.19	ULC frequency table point 4	real32	0.0 500.0	Hz	10 = 1 Hz
37.20	ULC frequency table point 5	real32	0.0 500.0	Hz	10 = 1 Hz
37.21	ULC underload point 1	real32	0.0 1600.0	%	10 = 1%
37.22	ULC underload point 2	real32	0.0 1600.0	%	10 = 1%
37.23	ULC underload point 3	real32	0.0 1600.0	%	10 = 1%
37.24	ULC underload point 4	real32	0.0 1600.0	%	10 = 1%
37.25	ULC underload point 5	real32	0.0 1600.0	%	10 = 1%
37.31	ULC overload point 1	real32	0.0 1600.0	%	10 = 1%
37.32	ULC overload point 2	real32	0.0 1600.0	%	10 = 1%
37.33	ULC overload point 3	real32	0.0 1600.0	%	10 = 1%
37.34	ULC overload point 4	real32	0.0 1600.0	%	10 = 1%
37.35	ULC overload point 5	real32	0.0 1600.0	%	10 = 1%
37.41	ULC overload timer	real32	0.0 10000.0	s	10 = 1 s
37.42	ULC underload timer	real32	0.0 10000.0	s	10 = 1 s
40 Proc	ess PID set 1				
40.01	Process PID output actual	real32	-32768.00 32767.00	rpm, % or Hz	100 = 1 rpm, % or Hz
40.02	Process PID feedback actual	real32	-32768.00 32767.00	rpm, % or Hz	100 = 1 rpm, % or Hz
40.03	Process PID setpoint actual	real32	-32768.00 32767.00	rpm, % or Hz	100 = 1 rpm, % or Hz
40.04	Process PID deviation actual	real32	-32768.00 32767.00	rpm, % or Hz	100 = 1 rpm, % or Hz
40.05	Process PID trim output act	real32	-32768.00 32767.00	rpm, % or Hz	100 = 1 rpm, % or Hz
40.06	Process PID status word	uint16	0000hFFFFh	-	1 = 1
40.07	Set 1 PID operation mode	uint16	02	-	1 = 1
40.08	Set 1 feedback 1 source	uint32	-	-	1 = 1
40.09	Set 1 feedback 2 source	uint32	-	-	1 = 1
40.10	Set 1 feedback function	uint16	011	-	1 = 1
40.11	Set 1 feedback filter time	real32	0.000 30.000	S	1000 = 1 s
40.12	Set 1 unit selection	uint16	02	-	1 = 1
40.14	Set 1 setpoint scaling	real32	-32768.00 32767.00	-	100 = 1
40.15	Set 1 output scaling	uint32	-32768.00 32767.00	-	100 = 1
40.16	Set 1 setpoint 1 source	uint32	-	-	1 = 1
40.17	Set 1 setpoint 2 source	uint16	-	-	1 = 1
40.18	Set 1 setpoint function	uint32	011	-	1 = 1
40.19	Set 1 internal setpoint sel1	uint32	-	-	1 = 1
40.20	Set 1 internal setpoint sel2	real32	-	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32
40.21	Set 1 internal setpoint 1	real32	-32768.00 32767.00	rpm, % or Hz	100 = 1 rpm, % or Hz
40.22	Set 1 internal setpoint 2	real32	-32768.00 32767.00	rpm, % or Hz	100 = 1 rpm, % or Hz
40.23	Set 1 internal setpoint 3	real32	-32768.00 32767.00	rpm, % or Hz	100 = 1 rpm, % or Hz
40.24	Set 1 internal setpoint 4	real32	-32768.00 32767.00	rpm, % or Hz	100 = 1 rpm, % or Hz
40.25	Set 1 setpoint selection	uint32	-	-	1 = 1
40.26	Set 1 setpoint min	real32	-32768.00 32767.00	-	100 = 1
40.27	Set 1 setpoint max	real32	-32768.00 32767.00	-	100 = 1
40.28	Set 1 setpoint increase time	real32	0.0 1800.0	S	10 = 1 s
40.29	Set 1 setpoint decrease time	real32	0.0 1800.0	s	10 = 1 s
40.30	Set 1 setpoint freeze enable	uint32	-	-	1 = 1
40.31	Set 1 deviation inversion	uint32	-	-	1 = 1
40.32	Set 1 gain	real32	0.10 100.00	-	100 = 1
40.33	Set 1 integration time	real32	0.0 32767.0	s	10 = 1 s
40.34	Set 1 derivation time	real32	0.000 10.000	s	1000 = 1 s
40.35	Set 1 derivation filter time	real32	0.0 10.0	s	10 = 1 s
40.36	Set 1 output min	real32	-32768.0 32767.0	-	10 = 1
40.37	Set 1 output max	real32	-32768.0 32767.0	-	10 = 1
40.38	Set 1 output freeze enable	uint32	-	-	1 = 1
40.39	Set 1 deadband range	real32	0.0 32767.0	-	10 = 1
40.40	Set 1 deadband delay	real32	0.0 3600.0	s	10 = 1 s
40.41	Set 1 sleep mode	uint16	02	-	1 = 1
40.42	Set 1 sleep enable	uint32	-	-	1 = 1
40.43	Set 1 sleep level	real32	0.0 32767.0	-	10 = 1
40.44	Set 1 sleep delay	real32	0.0 3600.0	s	10 = 1 s
40.45	Set 1 sleep boost time	real32	0.0 3600.0	S	10 = 1 s
40.46	Set 1 sleep boost step	real32	0.0 32767.0	-	10 = 1
40.47	Set 1 wake-up deviation	real32	-32768.00 32767.00	rpm, % or Hz	100 = 1 rpm, % or Hz
40.48	Set 1 wake-up delay	real32	0.00 60.00	S	100 = 1 s
40.49	Set 1 tracking mode	uint32	-	-	1 = 1
40.50	Set 1 tracking ref selection	uint16	-	-	1 = 1
40.51	Set 1 trim mode	uint16	03	-	1 = 1
40.52	Set 1 trim selection	uint16	13	-	1 = 1
40.53	Set 1 trimmed ref pointer	uint16	-	-	1 = 1
40.54	Set 1 trim mix	real32	0.000 1.000	-	1000 = 1
40.55	Set 1 trim adjust	real32	-100.000 100.000	-	1000 = 1
40.56	Set 1 trim source	uint16	12	-	1 = 1
40.57	PID set1/set2 selection	uint32	-	-	1 = 1
40.60	Set 1 PID activation source	uint32	-	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32
40.91	Feedback data storage	real32	-327.68 327.67	-	100 = 1
40.92	Setpoint data storage	real32	-327.68 327.67	-	100 = 1
41 Proc	ess PID set 2	<u> </u>			
41.07	Set 2 PID operation mode	uint16	02	-	1 = 1
41.08	Set 2 feedback 1 source	uint32	-	-	1 = 1
41.09	Set 2 feedback 2 source	uint32	-	-	1 = 1
41.10	Set 2 feedback function	uint16	011	-	1 = 1
41.11	Set 2 feedback filter time	real32	0.000 30.000	s	1000 = 1 s
41.12	Set 2 unit selection	uint16	02	-	1 = 1
41.14	Set 2 setpoint scaling	real32	-32768 32767	-	100 = 1
41.15	Set 2 output scaling	real32	-32768 32767	-	100 = 1
41.16	Set 2 setpoint 1 source	uint32	-	-	1 = 1
41.17	Set 2 setpoint 2 source	uint32	-	-	1 = 1
41.18	Set 2 setpoint function	uint16	011	-	1 = 1
41.19	Set 2 internal setpoint sel1	uint32	-	-	1 = 1
41.20	Set 2 internal setpoint sel2	uint32	-	-	1 = 1
41.21	Set 2 internal setpoint 1	real32	-32768.0 32767.0	rpm, % or Hz	100 = 1 rpm, % or Hz
41.22	Set 2 internal setpoint 2	real32	-32768.0 32767.0	rpm, % or Hz	100 = 1 rpm, % or Hz
41.23	Set 2 internal setpoint 3	real32	-32768.0 32767.0	rpm, % or Hz	100 = 1 rpm, % or Hz
41.24	Set 2 internal setpoint 4	real32	-32768.0 32767.0	rpm, % or Hz	100 = 1 rpm, % or Hz
41.25	Set 2 setpoint selection	uint32	-	-	1 = 1
41.26	Set 2 setpoint min	real32	-32768.0 32767.0	-	100 = 1
41.27	Set 2 setpoint max	real32	-32768.0 32767.0	-	100 = 1
41.28	Set 2 setpoint increase time	real32	0.0 1800.0	S	10 = 1 s
41.29	Set 2 setpoint decrease time	real32	0.0 1800.0	s	10 = 1 s
41.30	Set 2 setpoint freeze enable	uint32	-	-	1 = 1
41.31	Set 2 deviation inversion	uint32	-	-	1 = 1
41.32	Set 2 gain	real32	0.1 100.0	-	100 = 1
41.33	Set 2 integration time	real32	0.0 3600.0	S	10 = 1 s
41.34	Set 2 derivation time	real32	0.0 10.0	S	1000 = 1 s
41.35	Set 2 derivation filter time	real32	0.0 10.0	S	10 = 1 s
41.36	Set 2 output min	real32	-32768.0 32767.0	-	10 = 1
41.37	Set 2 output max	real32	-32768.0 32767.0	-	10 = 1
41.38	Set 2 output freeze enable	uint32	-	-	1 = 1
41.39	Set 2 deadband range	real32	0.0 32767.0	-	10 = 1
41.40	Set 2 deadband delay	real32	0.0 3600.0	s	10 = 1 s
41.41	Set 2 sleep mode	uint16	02	-	1 = 1
41.42	Set 2 sleep enable	uint32	-	_	1 = 1

No.	Name	Type	Range	Unit	FbEq32
44.18	Brake fault delay	real32	0.00 60.00	s	100 = 1 s
44.21	Filter time brake torque memory	real32	0100.00	ms	1 = 1 ms
45 Ener	gy efficiency	<u> </u>			
45.01	Saved GW hours	uint16	065535	GWh	1 = 1 GWh
45.02	Saved MW hours	uint16	0999	MWh	1 = 1 MWh
45.03	Saved kW hours	uint16	0.0 999.0	kWh	10 = 1 kWh
45.05	Saved money x1000	uint32	04294967295	thousand	1 = 1 thousand
45.06	Saved money	uint32	0.00 999.99	(selecta- ble)	100 = 1 unit
45.08	CO2 reduction in kilotons	uint16	065535	metric kiloton	1 = 1 metric kiloton
45.09	CO2 reduction in tons	uint16	0.0 999.9	metric ton	10 = 1 metric ton
45.11	Energy optimizer	uint32	01	-	1 = 1
45.12	Energy tariff 1	uint32	0.000 4294967.295	(selecta- ble)	1000 = 1 unit
45.13	Energy tariff 2	uint32	0.000 4294967.295	(selecta- ble)	1000 = 1 unit
45.14	Tariff selection	uint32	-	-	1 = 1
45.17	Tariff currency unit	uint16	100102	-	1 = 1
45.18	CO2 conversion factor	uint16	0.000 65.535	metric ton/ MWh	1000 = 1 metric ton/MWh
45.19	Comparison power	real32	0.0 100000.0	kW	10 = 1 kW
45.21	Energy calculations reset	uint16	01	-	1 = 1
46 Moni	toring/scaling settings				
46.01	Speed scaling	real32	0.10 30000.00	rpm	100 = 1 rpm
46.02	Frequency scaling	real32	0.10 1000.00	Hz	100 = 1 Hz
46.03	Torque scaling	real32	0.1 1000.0	%	10 = 1%
46.04	Power scaling	real32	0.10 30000.00 kW or 0.10 40214.48 hp	kW or hp	100 = 1 unit
46.05	Current scaling	real32	030000	Α	1 = 1 A
46.06	Speed ref zero scaling	real32	0.00 30000.00	rpm	100 = 1 rpm
46.07	Frequency ref zero scaling	real32	0.00 1000.00	Hz	100 = 1 Hz
46.11	Filter time motor speed	real32	020000	ms	1 = 1 ms
46.12	Filter time output frequency	real32	020000	ms	1 = 1 ms
46.13	Filter time motor torque	real32	020000	ms	1 = 1 ms
46.14	Filter time power out	real32	020000	ms	1 = 1 ms
46.21	At speed hysteresis	real32	0.00 30000.00	rpm	100 = 1 rpm
46.22	At frequency hysteresis	real32	0.00 1000.00	Hz	100 = 1 Hz
46.23	At torque hysteresis	real32	0.0 300.0	%	1 = 1%
46.31	Above speed limit	real32	0.00 30000.00	rpm	100 = 1 rpm
46.32	Above frequency limit	real32	0.00 1000.00	Hz	100 = 1 Hz

No.	Name	Туре	Range	Unit	FbEq32
46.33	Above torque limit	real32	0.0 1600.0	%	10 = 1%
46.42	Torque decimals	uint16	02	-	1 = 1
47 Data	storage				
47.01	Data storage 1 real32	real32	Defined by 47.31	-	1000 = 1
47.02	Data storage 2 real32	real32	Defined by 47.32	-	1000 = 1
47.03	Data storage 3 real32	real32	Defined by 47.33	-	1000 = 1
47.04	Data storage 4 real32	real32	Defined by 47.34	-	1000 = 1
47.05	Data storage 5 real32	real32	Defined by 47.35	-	1000 = 1
47.06	Data storage 6 real32	real32	Defined by 47.36	-	1000 = 1
47.07	Data storage 7 real32	real32	Defined by 47.37	-	1000 = 1
47.08	Data storage 8 real32	real32	Defined by 47.38	-	1000 = 1
47.11	Data storage 1 int32	int32	-2147483648 2147483647	-	1 = 1
47.12	Data storage 2 int32	int32	-2147483648 2147483647	-	1 = 1
47.13	Data storage 3 int32	int32	-2147483648 2147483647	-	1 = 1
47.14	Data storage 4 int32	int32	-2147483648 2147483647	-	1 = 1
47.15	Data storage 5 int32	int32	-2147483648 2147483647	-	1 = 1
47.16	Data storage 6 int32	int32	-2147483648 2147483647	-	1 = 1
47.17	Data storage 7 int32	int32	-2147483648 2147483647	-	1 = 1
47.18	Data storage 8 int32	int32	-2147483648 2147483647	-	1 = 1
47.21	Data storage 1 int16	int16	-32768 32767	-	1 = 1
47.22	Data storage 2 int16	int16	-32768 32767	-	1 = 1
47.23	Data storage 3 int16	int16	-32768 32767	-	1 = 1
47.24	Data storage 4 int16	int16	-32768 32767	-	1 = 1
47.25	Data storage 5 int16	int16	-32768 32767	-	1 = 1
47.26	Data storage 6 int16	int16	-32768 32767	-	1 = 1
47.27	Data storage 7 int16	int16	-32768 32767	-	1 = 1
47.28	Data storage 8 int16	int16	-32768 32767	-	1 = 1
47.31	Data storage 1 real32 type	uint16	05	-	1 = 1
47.32	Data storage 2 real32 type	uint16	05	-	1 = 1
47.33	Data storage 3 real32 type	uint16	05	-	1 = 1
47.34	Data storage 4 real32 type	uint16	05	-	1 = 1
47.35	Data storage 5 real32 type	uint16	05	-	1 = 1
47.36	Data storage 6 real32 type	uint16	05	-	1 = 1
47.37	Data storage 7 real32 type	uint16	05	-	1 = 1
47.38	Data storage 8 real32 type	uint16	05	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32
49 Pane	I port communication				
49.01	Node ID number	uint32	132	-	1 = 1
49.03	Baud rate	uint32	15	-	1 = 1
49.04	Communication loss time	uint32	0.3 3000.0	S	10 = 1 s
49.05	Communication loss action	uint16	05	-	1 = 1
49.06	Refresh settings	uint16	01	-	1 = 1
49.07	Panel comm supervision force	uint16	0000hFFFFh	-	1 = 1
49.08	Secondary comm. loss action	uint16	05	-	1 = 1
49.14	Panel speed reference unit	uint16	01	-	1 = 1
49.15	Minimum ext speed ref panel	real32	-30000.00 30000.00	rpm	100 = 1 rpm
49.16	Maximum ext speed ref panel	real32	-30000.00 30000.00	rpm	100 = 1 rpm
49.17	Minimum ext frequency ref panel	real32	-500.00 500.00	Hz	100 = 1 Hz
49.18	Maximum ext frequency ref panel	real32	-500.00 500.00	Hz	100 = 1 Hz
49.24	Panel actual source	uint32	-	-	1 = 1
50 Field	bus adapter (FBA)				
50.01	FBA A enable	uint16	03	-	1 = 1
50.02	FBA A comm loss func	uint16	05	-	1 = 1
50.03	FBA A comm loss t out	uint16	0.3 6553.5	S	10 = 1 s
50.04	FBA A ref1 type	uint16	05	-	1 = 1
50.05	FBA A ref2 type	uint16	05	-	1 = 1
50.06	FBA A SW sel	uint16	01	-	1 = 1
50.07	FBA A actual 1 type	uint16	06	-	1 = 1
50.08	FBA A actual 2 type	uint16	06	-	1 = 1
50.09	FBA A SW transparent source	uint32	-	-	1 = 1
50.10	FBA A act1 transparent source	uint32	-	-	1 = 1
50.11	FBA A act2 transparent source	uint32	-	-	1 = 1
50.12	FBA A debug mode	uint16	01	-	1 = 1
50.13	FBA A control word	uint32	00000000h FFFFFFFh	-	1 = 1
50.14	FBA A reference 1	int32	-2147483648 2147483647	-	1 = 1
50.15	FBA A reference 2	int32	-2147483648 2147483647	-	1 = 1
50.16	FBA A status word	uint32	00000000h FFFFFFFh	-	1 = 1
50.17	FBA A actual value 1	int32	-2147483648 2147483647	-	1 = 1
50.18	FBA A actual value 2	int32	-2147483648 2147483647	-	1 = 1
50.21	FBA A timelevel sel	uint16	03	-	1 = 1
50.26	FBA A comm supervision force	uint16	0000hFFFFh	-	1 = 1
50.31	FBA B enable	uint16	01	-	1 = 1
50.32	FBA B comm loss func	uint16	05	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32
50.33	FBA B comm loss timeout	uint16	0.3 6553.5	s	10 = 1 s
50.34	FBA B ref1 type	uint16	05	-	1 = 1
50.35	FBA B ref2 type	uint16	05	-	1 = 1
50.36	FBA B SW sel	uint16	01	-	1 = 1
50.37	FBA B actual 1 type	uint16	06	-	1 = 1
50.38	FBA B actual 2 type	uint16	06	-	1 = 1
50.39	FBA B SW transparent source	uint32	-	-	1 = 1
50.40	FBA B act1 transparent source	uint32	-	-	1 = 1
50.41	FBA B act2 transparent source	uint32	-	-	1 = 1
50.42	FBA B debug mode	uint16	01	-	1 = 1
50.43	FBA B control word	uint32	00000000h FFFFFFFh	-	1 = 1
50.44	FBA B reference 1	int32	-2147483648 2147483647	-	1 = 1
50.45	FBA B reference 2	int32	-2147483648 2147483647	-	1 = 1
50.46	FBA B status word	uint32	00000000h FFFFFFFh	-	1 = 1
50.47	FBA B actual value 1	int32	-2147483648 2147483647	-	1 = 1
50.48	FBA B actual value 2	int32	-2147483648 2147483647	-	1 = 1
50.51	FBA B timelevel sel	uint16	03	-	1 = 1
50.56	FBA B comm supervision force	uint16	0000hFFFFh	-	1 = 1
51 FBA	A settings				
51.01	FBA A type	uint16	-	-	1 = 1
51.02	FBA A Par2	uint16	065535	-	1 = 1
51.26	FBA A Par26	uint16	065535	-	1 = 1
51.27	FBA A par refresh	uint16	01	-	1 = 1
51.28	FBAA par table ver	uint16	-	-	1 = 1
51.29	FBAA drive type code	uint16	065535	-	1 = 1
51.30	FBAA mapping file ver	uint16	065535	ı	1 = 1
51.31	D2FBA A comm status	uint16	06	-	1 = 1
51.32	FBAA comm SW ver	uint16	-	-	1 = 1
51.33	FBA A appl SW ver	uint16	-	1	1 = 1
52 FBA	A data in				
52.01	FBA A data in1	uint32	-	-	1 = 1
52.12	FBA A data in12	uint32	-	-	1 = 1
53 FBA	A data out				
53.01	FBA A data out1	uint32	-	-	1 = 1
53.12	FBA A data out12	uint32	-	-	1 = 1

No.	Name	Type	Range	Unit	FbEq32
54 FBA	B settings				
54.01	FBA B type	uint16			
54.02	FBA B Par2	uint16	065535	-	
			•••		
54.26	FBA B Par26	uint16	065535	-	
54.27	FBA B par refresh	uint16	01	-	
54.28	FBA B par table ver	uint16	065535	-	
54.29	FBA B drive type code	uint16	065535	-	
54.30	FBA B mapping file ver	uint16	065535	-	
54.31	D2FBA B comm status	uint16	06	-	
54.32	FBA B comm SW ver	uint16	065535	-	
54.33	FBA B appl SW ver	uint16	065535	-	
55 FBA	B data in				
55.01	FBA B data in1	uint32	-	-	1 = 1
55.12	FBA B data in12	uint32	-	-	1 = 1
56 FBA	B data out				
56.01	FBA B data out1	uint32	-	-	1 = 1
56.12	FBA B data out12	uint32	-	-	1 = 1
58 Emb	edded fieldbus				
58.01	Protocol enable	uint16	01	-	1 = 1
58.02	Protocol ID	uint16	0000hFFFFh	-	1 = 1
58.03	Node address	uint16	0255	-	1 = 1
58.04	Baud rate	uint16	27	-	1 = 1
58.05	Parity	uint16	03	-	1 = 1
58.06	Communication control	uint16	02	-	1 = 1
58.07	Communication diagnostics	uint16	0000hFFFFh	-	1 = 1
58.08	Received packets	uint32	04294967295	-	1 = 1
58.09	Transmitted packets	uint32	04294967295	-	1 = 1
58.10	All packets	uint32	04294967295	-	1 = 1
58.11	UART errors	uint32	04294967295	-	1 = 1
58.12	CRC errors	uint32	04294967295	-	1 = 1
58.14	Communication loss action	uint16	05	-	1 = 1
58.15	Communication loss mode	uint16	12	-	1 = 1
58.16	Communication loss time	uint16	0.0 6000.0	s	10 = 1 s
58.17	Transmit delay	uint16	065535	ms	1 = 1 ms
58.18	EFB control word	uint32	0000hFFFFh	-	1 = 1
58.19	EFB status word	uint32	0000hFFFFh	-	1 = 1
58.25	Control profile	uint16	0, 2	-	1 = 1
58.26	EFB ref1 type	uint16	05	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32
58.27	EFB ref2 type	uint16	05	-	1 = 1
58.28	EFB act1 type	uint16	06	-	1 = 1
58.29	EFB act2 type	uint16	06	-	1 = 1
58.30	EFB status word transparent source	uint32	-	-	1 = 1
58.31	EFB act1 transparent source	uint32	-	-	1 = 1
58.32	EFB act2 transparent source	uint32	-	-	1 = 1
58.33	Addressing mode	uint16	02	-	1 = 1
58.34	Word order	uint16	01	-	1 = 1
58.36	EFB comm supervision force	uint16	0000hFFFFh	-	1 = 1
58.101	Data I/O 1	uint32	-	-	1 = 1
58.102	Data I/O 2	uint32	-	-	1 = 1
58.103	Data I/O 3	uint32	-	-	1 = 1
58.104	Data I/O 4	uint32	-	-	1 = 1
58.105	Data I/O 5	uint32	-	-	1 = 1
58.106	Data I/O 6	uint32	-	-	1 = 1
58.107	Data I/O 7	uint32	-	-	1 = 1
58.124	Data I/O 24	uint32	-	-	1 = 1
60 DDC	S communication				
60.01	M/F communication port	uint16	-	-	-
60.02	M/F node address	uint16	1254	-	-
60.03	M/F mode	uint16	06	-	-
60.05	M/F HW connection	uint16	01	-	-
60.07	M/F link control	uint16	115	-	-
60.08	M/F comm loss timeout	uint16	065535	ms	-
60.09	M/F comm loss function	uint16	03	-	-
60.10	M/F ref1 type	uint16	05	-	-
60.11	M/F ref2 type	uint16	05	-	-
60.12	M/F act1 type	uint16	05	-	-
60.13	M/F act2 type	uint16	05	-	-
60.14	M/F follower selection	uint32	016	-	-
60.15	Force master	uint32	-	-	1 = 1
60.16	Force follower	uint16	-	-	1 = 1
60.17	Follower fault action	uint16	02	-	-
60.18	Follower enable	uint16	06	-	-
60.19	M/F comm supervision sel 1	uint16	0000h FFFFh	-	1 = 1
60.20	M/F comm supervision sel 2	uint16	0000h FFFFh	-	1 = 1
60.23	M/F status supervision sel 1	uint16	0000h FFFFh	-	1 = 1
60.24	M/F status supervision sel 2	uint16	0000h FFFFh	-	1 = 1
60.27	M/F status supv mode sel 1	uint16	0000h FFFFh	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32
60.28	M/F status supv mode sel 2	uint16	0000h FFFFh	-	1 = 1
60.31	M/F wake up delay	uint16	0.0180.0	s	10 = 1 s
60.32	M/F comm supervision force	uint16	0000hFFFFh	-	1 = 1
60.41	Extension adapter com port	uint16	-	-	-
60.50	DDCS controller drive type	uint16	01	-	-
60.51	DDCS controller comm port	uint16	-	-	-
60.52	DDCS controller node address	uint16	1254	-	-
60.55	DDCS controller HW connection	uint16	01	-	-
60.56	DDCS controller baud rate	uint16	1, 2, 4, 8	-	-
60.57	DDCS controller link control	uint16	115	-	-
60.58	DDCS controller comm loss time	uint16	060000	ms	-
60.59	DDCS controller comm loss function	uint16	05	-	-
60.60	DDCS controller ref1 type	uint16	05	-	-
60.61	DDCS controller ref2 type	uint16	05	-	-
60.62	DDCS controller act1 type	uint16	05	-	-
60.63	DDCS controller act2 type	uint16	05	-	-
60.64	Mailbox dataset selection	uint16	01	-	-
60.65	DDCS controller comm supervision force	uint16	0000hFFFFh	-	1 = 1
	(Parameters 60.7160.79 are	visible only	when supply unit control is a	activated by	95.20)
60.71	INU-LSU communication port	uint16	-	-	1 = 1
60.77	INU-LSU link control	uint16	115	-	-
60.78	INU-LSU comm loss timeout	uint16	065535	ms	-
60.79	INU-LSU comm loss function	uint16	-	-	1 = 1
61 D2D	and DDCS transmit data				
61.01	M/F data 1 selection	uint32	-	-	-
61.02	M/F data 2 selection	uint32	-	-	-
61.03	M/F data 3 selection	uint32	-	-	-
61.25	M/F data 1 value	uint16	065535	-	-
61.26	M/F data 2 value	uint16	065535	-	-
61.27	M/F data 3 value	uint16	065535	-	-
61.45	Data set 2 data 1 selection	uint32	-	-	-
61.46	Data set 2 data 2 selection	uint32	-	-	-
61.47	Data set 2 data 3 selection	uint32	-	-	-
61.48	Data set 4 data 1 selection	uint32	-	-	-
61.49	Data set 4 data 2 selection	uint32	-	-	-
61.50	Data set 4 data 3 selection	uint32	-	-	-
61.51	Data set 11 data 1 selection	uint32	-	-	-
61.52	Data set 11 data 2 selection	uint32	-	-	-

No.	Name	Туре	Range	Unit	FbEq32
61.53	Data set 11 data 3 selection	uint32	-	-	-
61.54	Data set 13 data 1 selection	uint32	-	-	-
61.55	Data set 13 data 2 selection	uint32	-	-	-
61.56	Data set 13 data 3 selection	uint32	-	-	-
61.57	Data set 15 data 1 selection	uint32	-	-	-
61.58	Data set 15 data 2 selection	uint32	-	-	-
61.59	Data set 15 data 3 selection	uint32	-	-	-
61.60	Data set 17 data 1 selection	uint32	-	-	-
61.61	Data set 17 data 2 selection	uint32	-	-	-
61.62	Data set 17 data 3 selection	uint32	-	-	-
61.63	Data set 19 data 1 selection	uint32	-	-	-
61.64	Data set 19 data 2 selection	uint32	-	-	-
61.65	Data set 19 data 3 selection	uint32	-	-	-
61.66	Data set 21 data 1 selection	uint32	-	-	-
61.67	Data set 21 data 2 selection	uint32	-	-	1
61.68	Data set 21 data 3 selection	uint32	-	-	1
61.69	Data set 23 data 1 selection	uint32	-	-	-
61.70	Data set 23 data 2 selection	uint32	-	-	-
61.71	Data set 23 data 3 selection	uint32	-	-	-
61.72	Data set 25 data 1 selection	uint32	-	-	1
61.73	Data set 25 data 2 selection	uint32	-	-	1
61.74	Data set 25 data 3 selection	uint32	-	-	-
61.95	Data set 2 data 1 value	uint16	065535	-	-
61.96	Data set 2 data 2 value	uint16	065535	-	-
61.97	Data set 2 data 3 value	uint16	065535	-	-
61.98	Data set 4 data 1 value	uint16	065535	-	-
61.99	Data set 4 data 2 value	uint16	065535	-	-
61.100	Data set 4 data 3 value	uint16	065535	-	1
61.101	Data set 11 data 1 value	uint16	065535	-	1
61.102	Data set 11 data 2 value	uint16	065535	-	-
61.103	Data set 11 data 3 value	uint16	065535	-	-
61.104	Data set 13 data 1 value	uint16	065535	-	-
61.105	Data set 13 data 2 value	uint16	065535	-	ı
61.106	Data set 13 data 3 value	uint16	065535	-	-
61.107	Data set 15 data 1 value	uint16	065535	-	-
61.108	Data set 15 data 2 value	uint16	065535	-	-
61.109	Data set 15 data 3 value	uint16	065535	-	-
61.110	Data set 17 data 1 value	uint16	065535	-	-
61.111	Data set 17 data 2 value	uint16	065535	-	-
61.112	Data set 17 data 3 value	uint16	065535	-	-
61.113	Data set 19 data 1 value	uint16	065535	-	-

No.	Name	Туре	Range	Unit	FbEq32
61.114	Data set 19 data 2 value	uint16	065535	-	-
61.115	Data set 19 data 3 value	uint16	065535	-	-
61.116	Data set 21 data 1 value	uint16	065535	-	-
61.117	Data set 21 data 2 value	uint16	065535	-	-
61.118	Data set 21 data 3 value	uint16	065535	-	-
61.119	Data set 23 data 1 value	uint16	065535	-	-
61.120	Data set 23 data 2 value	uint16	065535	-	-
61.121	Data set 23 data 3 value	uint16	065535	-	-
61.122	Data set 25 data 1 value	uint16	065535	-	-
61.123	Data set 25 data 2 value	uint16	065535	-	-
61.124	Data set 25 data 3 value	uint16	065535	-	-
	(Parameters 61.15161.203 are	e visible only	y when supply unit control i	s activated by	/ 95.20)
61.151	INU-LSU Data set 10 data 1 sel	uint32	-	-	-
61.152	INU-LSU Data set 10 data 2 sel	uint32	-	-	-
61.153	INU-LSU Data set 10 data 3 sel	uint32	-	-	-
61.201	INU-LSU Data set 10 data 1 value	uint16	065535	-	-
61.202	INU-LSU Data set 10 data 2 value	uint16	065535	-	-
61.203	INU-LSU Data set 10 data 3 value	uint16	065535	-	-
62 D2D	and DDCS receive data				
62.01	M/F data 1 selection	uint32	-	-	-
62.02	M/F data 2 selection	uint32	-	-	-
62.03	M/F data 3 selection	uint32	-	-	-
62.04	Follower node 2 data 1 sel	uint32	-	-	-
62.05	Follower node 2 data 2 sel	uint32	-	-	-
62.06	Follower node 2 data 3 sel	uint32	-	-	-
62.07	Follower node 3 data 1 sel	uint32	-	-	-
62.08	Follower node 3 data 2 sel	uint32	-	-	-
62.09	Follower node 3 data 3 sel	uint32	-	-	-
62.10	Follower node 4 data 1 sel	uint32	-	-	-
62.11	Follower node 4 data 2 sel	uint32	-	-	-
62.12	Follower node 4 data 3 sel	uint32	-	-	-
62.25	MF data 1 value	uint16	065535	-	-
62.26	MF data 2 value	uint16	065535	-	-
62.27	MF data 3 value	uint16	065535	-	-
62.28	Follower node 2 data 1 value	uint16	065535	-	-
62.29	Follower node 2 data 2 value	uint16	065535	-	-
62.30	Follower node 2 data 3 value	uint16	065535	-	-

No.	Name	Туре	Range	Unit	FbEq32
62.31	Follower node 3 data 1 value	uint16	065535	-	-
62.32	Follower node 3 data 2 value	uint16	065535	-	-
62.33	Follower node 3 data 3 value	uint16	065535	-	-
62.34	Follower node 4 data 1 value	uint16	065535	-	-
62.35	Follower node 4 data 2 value	uint16	065535	-	-
62.36	Follower node 4 data 3 value	uint16	065535	-	-
62.37	M/F communication status 1	uint16	0000h FFFFh	-	1 = 1
62.38	M/F communication status 2	uint16	0000h FFFFh	-	1 = 1
62.41	M/F follower ready status 1	uint16	0000h FFFFh	-	1 = 1
62.42	M/F follower ready status 2	uint16	0000h FFFFh	-	1 = 1
62.45	Data set 1 data 1 selection	uint32	-	-	-
62.46	Data set 1 data 2 selection	uint32	-	-	-
62.47	Data set 1 data 3 selection	uint32	-	-	-
62.48	Data set 3 data 1 selection	uint32	-	-	-
62.49	Data set 3 data 2 selection	uint32	-	-	-
62.50	Data set 3 data 3 selection	uint32	-	-	-
62.51	Data set 10 data 1 selection	uint32	•	-	ı
62.52	Data set 10 data 2 selection	uint32	-	-	ı
62.53	Data set 10 data 3 selection	uint32	-	-	ı
62.54	Data set 12 data 1 selection	uint32	-	-	-
62.55	Data set 12 data 2 selection	uint32	-	-	ı
62.56	Data set 12 data 3 selection	uint32	•	-	ı
62.57	Data set 14 data 1 selection	uint32	•	1	1
62.58	Data set 14 data 2 selection	uint32	-	-	-
62.59	Data set 14 data 3 selection	uint32	•	-	ı
62.60	Data set 16 data 1 selection	uint32	•	-	1
62.61	Data set 16 data 2 selection	uint32	-	-	-
62.62	Data set 16 data 3 selection	uint32	-	-	-
62.63	Data set 18 data 1 selection	uint32	-	-	-
62.64	Data set 18 data 2 selection	uint32	-	-	-
62.65	Data set 18 data 3 selection	uint32	-	-	-
62.66	Data set 20 data 1 selection	uint32	-	-	-
62.67	Data set 20 data 2 selection	uint32	-	-	-
62.68	Data set 20 data 3 selection	uint32	-	-	-
62.69	Data set 22 data 1 selection	uint32	-	-	-
62.70	Data set 22 data 2 selection	uint32	-	-	-
62.71	Data set 22 data 3 selection	uint32	-	-	-
62.72	Data set 24 data 1 selection	uint32	-	-	-
62.73	Data set 24 data 2 selection	uint32	-	-	-
62.74	Data set 24 data 3 selection	uint32	-	-	-
62.95	Data set 1 data 1 value	uint16	065535	-	-

No.	Name	Туре	Range	Unit	FbEq32
62.96	Data set 1 data 2 value	uint16	065535	-	-
62.97	Data set 1 data 3 value	uint16	065535	-	-
62.98	Data set 3 data 1 value	uint16	065535	-	-
62.99	Data set 3 data 2 value	uint16	065535	-	-
62.100	Data set 3 data 3 value	uint16	065535	-	-
62.101	Data set 10 data 1 value	uint16	065535	-	-
62.102	Data set 10 data 2 value	uint16	065535	-	-
62.103	Data set 10 data 3 value	uint16	065535	-	-
62.104	Data set 12 data 1 value	uint16	065535	-	-
62.105	Data set 12 data 2 value	uint16	065535	-	-
62.106	Data set 12 data 3 value	uint16	065535	-	-
62.107	Data set 14 data 1 value	uint16	065535	-	-
62.108	Data set 14 data 2 value	uint16	065535	-	-
62.109	Data set 14 data 3 value	uint16	065535	-	-
62.110	Data set 16 data 1 value	uint16	065535	-	-
62.111	Data set 16 data 2 value	uint16	065535	-	-
62.112	Data set 16 data 3 value	uint16	065535	-	-
62.113	Data set 18 data 1 value	uint16	065535	-	-
62.114	Data set 18 data 2 value	uint16	065535	-	-
62.115	Data set 18 data 3 value	uint16	065535	-	-
62.116	Data set 20 data 1 value	uint16	065535	-	-
62.117	Data set 20 data 2 value	uint16	065535	-	-
62.118	Data set 20 data 3 value	uint16	065535	-	-
62.119	Data set 22 data 1 value	uint16	065535	-	-
62.120	Data set 22 data 2 value	uint16	065535	-	-
62.121	Data set 22 data 3 value	uint16	065535	-	-
62.122	Data set 24 data 1 value	uint16	065535	-	-
62.123	Data set 24 data 2 value	uint16	065535	-	-
62.124	Data set 24 data 3 value	uint16	065535	-	-
(	Parameters 62.15162.203 are	visible onl	y when supply unit control is	activated by	/ 95.20)
62.151	INU-LSU data set 11 data 1 sel	uint32	-	-	-
62.152	INU-LSU data set 11 data 2 sel	uint32	-	-	-
62.153	INU-LSU data set 11 data 3 sel	uint32	-	-	-
62.201	INU-LSU data set 11 data 1 value	uint16	065535	-	-
62.202	INU-LSU data set 11 data 2 value	uint16	065535	-	-
62.203	INU-LSU data set 11 data 3 value	uint16	065535	-	-
74 Appli	cation setup				
74.05	Winding mode	uint16	01	-	1 = 1
74.06	Motor direction	uint16	01	_	1 = 1

No.	Name	Type	Range	Unit	FbEq32		
75.63	Motor ref diameter scaled	real32	-32767.032767.0	rpm	10 = 1 rpm		
75.66	Speed ref additive	real32	-32767.032767.0	rpm	10 = 1 rpm		
75.67	Speed match trim	real32	-32767.032767.0	rpm	10 = 1 rpm		
75.89	Speed reference status	real32	0b00000b111111	-	1 = 1		
76 Diameter calculation							
76.01	Diameter calculation mode	uint16	03	-	1 = 1		
76.02	Diameter feedback Src	uint16	07	-	1 = 1		
76.03	Actual diameter filter time	real32	032767	ms	1 = 1 ms		
76.05	Count up enable	uint16	02	-	1 = 1		
76.06	Count down enable	uint16	02	-	1 = 1		
76.07	Hold diameter count	uint16	01	-	1 = 1		
76.08	Core diameter	real32	0.032767.0	mm	10 = 1 mm		
76.09	Full roll diameter	real32	0.032767.0	mm	10 = 1 mm		
76.11	Reset estimated diameter	uint16	04	-	1 = 1		
76.25	Preset estimated diameter	uint16	04	-	1 = 1		
76.26	Estimation preset value	real32	0.032767.0	mm	10 = 1 mm		
76.29	Reset/Preset while running	uint16	04	-	1 = 1		
76.31	Min speed for diameter calc	real32	0.00100.00	%	100 = 1%		
76.32	Min tension for diameter calc	real32	0.00100.00	%	100 = 1%		
76.35	Estimation slope gain	real32	0.000 100.000	-	1000 = 1		
76.36	Estimation boost time	real32	0.0032767.00	s	100 = 1 s		
76.37	Estimation boost multiplier	real32	0.000100.000	-	1000 = 1		
76.49	Raw estimate filter time	real32	0 65536	ms	1 = 1 ms		
76.50	Raw diameter estimation	real32	0.0 32767.0	mm	10 = 1 mm		
76.51	Estimated diameter filtered	real32	0.032767.0	mm	10 = 1 mm		
76.61	Measured diameter	real32	0.032767.0	mm	10 = 1 mm		
76.88	Diameter hold status	uint16	0b00000b111111	-	1 = 1		
77 Tens	ion/Dancer control						
77.01	Enable tension control	uint16	09	-	1 = 1		
77.02	Tension control mode	uint16	04	-	1 = 1		
77.03	Tension reference Src	uint16	010	-	1 = 1		
77.04	Load cell feedback Src	uint16	07	-	1 = 1		
77.05	Max tension	real32	0.065535.0	N/m	10 = 1 N/m		
77.06	Tension reference scaling	real32	0 32767	-	1 = 1		
77.09	Tension ref change rate	real32	0.0 32767.0	%/s	10 = 1 %/s		
77.11	Taper mode	uint16	03	-	1 = 1		
77.12	Tapering reference signal	uint16	02	-	1 = 1		
77.13	Taper starting point	real32	-32767.0032767.00	-	100 = 1		
77.14	Taper end point	real32	-32767.0032767.00	-	100 = 1		
77.15	Max taper tension trim %	real32	-100.00100.00	%	100 = 1%		
77.21	Stall function enable	uint16	01	-	1 = 1		

No.	Name	Туре	Range	Unit	FbEq32
78.32	Trim multiplier	real32	-32767.000032767.0000	-	10000 = 1
78.33	User trim source	uint16	07	-	1 = 1
78.34	Speed trim min	real32	0.001.00	-	100 = 1
78.38	Minimum trim factor	real32	-32767.0032767.00	-	100 = 1
78.39	Maximum trim factor	real32	-32767.0032767.00	-	100 = 1
78.49	PID feedback filter time	real32	0 32767	ms	1 = 1 ms
78.51	PID feedback used %	real32	-32767.00 32767.00	%	100 = 1%
78.52	PID reference used %	real32	-32767.00 32767.00	%	100 = 1%
78.56	Used P-gain	real32	0.0032767.00	-	100 = 1
78.57	Used I-time	real32	0.00032767.000	S	1000 = 1 s
78.58	Used D-time	real32	0.0 32767.0 ms	ms	10 = 1 ms
78.60	Controller error	real32	-32767.0032767.00	-	100 = 1
78.61	P term actual	real32	-32767.00032767.000	-	1000 = 1
78.62	I-term actual	real32	-32767.00032767.000	-	1000 = 1
78.63	D-term actual	real32	-32767.00032767.000	-	1000 = 1
78.69	PID output limited	real32	-32767.00032767.000	-	1000 = 1
78.75	Trim factor used	real32	-32767.00032767.000	-	1000 = 1
78.79	PID output trimmed	real32	-32767.00032767.000	-	1000 = 1
79 Mech	nanical losses compensation				
79.11	Friction compensation enable	uint16	01	-	1 = 1
79.12	Static friction torque	real32	0.00100.00	%	100 = 1%
79.13	Friction torque at 5% speed	real32	0.00100.00	%	100 = 1%
79.14	Friction torque at 10% speed	real32	0.00100.00	%	100 = 1%
79.15	Friction torque at 20% speed	real32	0.00100.00	%	100 = 1%
79.16	Friction torque at 40% speed	real32	0.00100.00	%	100 = 1%
79.17	Friction torque at 60% speed	real32	0.00100.00	%	100 = 1%
79.18	Friction torque at 80% speed	real32	0.00100.00	%	100 = 1%
79.19	Friction torque at 100% speed	real32	0.00100.00	%	100 = 1%
79.21	Friction torque additive	real32	-100.00100.00	%	100 = 1%
79.31	Inertia compensation enable	uint16	01	-	1 = 1
79.32	Inertia calculation method	uint16	01	-	1 = 1
79.33	Fixed inertia	real32	0.0000 32767.000	kgm <sup>2</sup>	$1000 = 1 \text{ kgm}^2$
79.34	Full roll weight	real32	0.0 65535.0	kg	10 = 1 kg
79.41	Acceleration comp gain	real32	0.0010.00	-	100 = 1
79.42	Deceleration comp gain	real32	0.0010.00	-	100 = 1
79.43	Steady-speed comp gain	real32	0.0010.00	-	100 = 1
79.48	Min line speed step	real32	0.00100.00	%/s	100 = 1%/s
79.49	IC filter time	real32	032767	ms	1 = 1 ms
79.51	Actual motor speed %	real32	-2147483648.00 2147483648.00	%	100 = 1 %
79.55	Friction torque used %	real32	-100.00100.00	%	100 = 1 %

No.	Name	Туре	Range	Unit	FbEq32
79.56	Friction impact on Tension	real32	-32767.0 32767.0	N	10 = 1 N
79.61	Used weight	real32	0.065535.0	kg	10 = 1 kg
79.62	Actual load inertia	real32	0.000032767.0000	kgm <sup>2</sup>	10000 = 1 kgm <sup>2</sup>
79.63	Load angular acceleration	real32	-32767.00 32767.00	rpm/s	100 = 1 rpm/s
79.65	Inertial torque demand %	real32	-1600.001600.00	%	10 = 1 %
79.66	Used IC gain	real32	-10.0010.00	-	100 = 1
79.67	Inertial torque ref used %	real32	-1000.001000.00	%	100 = 1 %
80 Turre	ting assistance				
80.01	Take torque sample	uint16	09	-	1 = 1
80.02	Torque memory enable	uint16	09	-	1 = 1
80.09	TM ref change rate	real32	0.032767.0	%/s	10 = 1 %/s
80.11	TM reference boost %	real32	-1000.001000.00	%	100 = 1 %
80.12	Boost ON-delay	real32	0.0032767.00	s	100 = 1 s
80.15	Torque boost force cmd	uint16	02	-	1 = 1
80.41	Overspeed tolerance %	real32	0.0032767.00	%	100 = 1 %
80.42	Overspeed tolerance (rpm)	real32	0.032767.0	rpm	10 = 1 rpm
80.43	Overspeed tolerance selection	uint16	02	-	1 = 1
80.44	Overspeed recovery ramp time	real32	0.0032767.00	S	100 = 1 s
80.48	Torque memory signal src	uint16	02	-	1 = 1
80.49	TM torque filter time	real32	032767	ms	1 = 1 ms
80.51	TM torque filtered	real32	-1600.00 1600.00	%	100 = 1%
80.52	Memorised torque sample %	real32	-1600.00 1600.00	%	100 = 1%
80.53	TM torque reference used %	real32	-1600.00 1600.00	%	100 = 1%
80.59	TM function state	uint16	05	-	1 = 1
80.61	Torque mode overspeed limit	real32	-32767.0 32767.0	rpm	10 = 1 rpm
81 Wind	ler safety				
81.01	Web-loss function	uint16	02	-	1 = 1
81.02	Web-loss sensor src	uint16	09	-	1 = 1
81.03	WL supervision mode	uint16	02	-	1 = 1
81.04	Speed error low %	real32	0.00100.00	%	100 = 1%
81.05	Open-loop supervision	uint16	01	-	1 = 1
81.06	WL trip delay	real32	0.0032767.00	s	100 = 1 s
81.09	Open-loop trip delay	real32	0.0032767.00	s	100 = 1 s
81.11	PID feedback supervision	uint16	0b00000b111111	-	1 = 1
81.12	Level low	real32	-32767.00 32767.00	%	100 = 1 %
81.13	Level high	real32	-32767.00 32767.00	%	100 = 1 %
81.14	PID error threshold %	real32	-32767.00 32767.00	%	100 = 1 %
81.15	Closed-loop supervision	uint16	01	-	1 = 1
81.19	Closed-loop trip delay	real32	0.0032767.00	s	100 = 1 s
81.41	Motor speed limit set	uint16	01	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32
81.42	Motor speed minimum	real32	-32767.0 0.0	rpm	10 = 1 rpm
81.43	Motor speed maximum	real32	0.0 32767.0	rpm	10 = 1 rpm
81.51	WL detection status	uint16	02	-	1 = 1
81.52	WL supervision signal	uint16	03	-	1 = 1
81.53	Observed value	real32	-100.00100.00	%	100 = 1%
81.59	Observer status word	uint16	0b00000b111111	-	1 = 1
82 Virtu	al Roll				
82.11	Counter source selection	uint16	03	-	1 = 1
82.12	Encoder placement	uint16	02	-	1 = 1
82.13	Counter input type	uint16	01	-	1 = 1
82.15	VR line feed constant	real32	0.0000032767.00000	unit/rev	100000 = 1 unit/rev
82.19	Hold roll counter	uint16	02	-	1 = 1
82.21	Reset VR diameter	uint16	05	-	1 = 1
82.22	Preset VR diameter	uint16	05	-	1 = 1
82.23	VR diameter preset source	uint16	01	-	1 = 1
82.36	Estimated tension filter time	real32	0 32767	ms	1 = 1 ms
82.51	Max speed Sim can take	real32	0.032767.0	m/min	10 = 1 m/min
82.54	Detected line speed	real32	0.032767.0	m/min	10 = 1 m/min
82.56	VR rotating speed	real32	0.032767.0	rpm	10 = 1 rpm
82.60	Length on roll	real32	0.0100000.0	m	10 = 1 m
82.61	Virtual roll diameter	real32	0.032767.0	mm	10 = 1 mm
82.62	VR Diameter ratio	real32	0.000010.0000	-	10000 = 1
82.64	Actual wrap count	real32	0.0065536.00	-	100 = 1
82.71	VR Estimated tension	real32	-32767.032767.0	N/m	10 = 1 N/m
82.72	VR Estimated force	real32	-32767.032767.0	N	10 = 1 N
82.89	VR Function status	uint16	0b00000b111111	-	1 = 1
89 Bloc	ck programming				
89.01	AND1 In_A	uint16	01	-	1 = 1
89.02	AND1 In_B	uint16	01	-	1 = 1
89.03	AND2 In_A	uint16	01	-	1 = 1
89.04	AND2 In_B	uint16	01	-	1 = 1
89.05	AND3 In_A	uint16	01	-	1 = 1
89.06	AND3 In_B	uint16	01	-	1 = 1
89.07	AND4 In_A	uint16	01	-	1 = 1
89.08	AND4 In_B	uint16	01	-	1 = 1
89.09	AND4 In_C	uint16	01	-	1 = 1
89.10	AND-blocks status	uint16	0b00000b111111	-	1 = 1
89.11	OR1 In_A	uint16	01	-	1 = 1
89.12	OR1 In_B	uint16	01	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32
89.13	OR2 In_A	uint16	01	-	1 = 1
89.14	OR2 In_B	uint16	01	-	1 = 1
89.15	OR3 In_A	uint16	01	-	1 = 1
89.16	OR3 In_B	uint16	01	-	1 = 1
89.17	OR4 In_A	uint16	01	-	1 = 1
89.18	OR4 In_B	uint16	01	-	1 = 1
89.19	OR4 In_C	uint16	01	-	1 = 1
89.20	OR-blocks status	uint16	0b00000b111111	-	1 = 1
89.21	COMPARE1 In_A	uint16	01	-	1 = 1
89.22	COMPARE1 In_B	uint16	01	-	1 = 1
89.23	COMPARE2 In_A	uint16	01	-	1 = 1
89.24	COMPARE2 In_B	real32	-32767.00032767.000	-	1 = 1
89.25	COMPARE3 In_A	uint16	01	-	1 = 1
89.26	COMPARE3 In_B	real32	-32767.00032767.000	-	1 = 1
89.30	COMP-blocks status	uint16	0b00000b111111	-	1 = 1
89.31	Stopwatc 1_time_set	Real	0.00065.536	2	100 = 1 s
89.32	Stopwatch1 trigger	uint16	01	-	1 = 1
89.40	Timers status	uint16	0b00000b111111	-	1 = 1
90 Feed	dback selection		<u>,                                      </u>		
90.01	Motor speed for control	real32	-32768.00 32767.00	rpm	100 = 1 rpm
90.02	Motor position	real32	0.00000000 1.00000000	rev	100000000 = 1 rev
90.03	Load speed	real32	-32768.00 32767.00	rpm	100 = 1 rpm
90.04	Load position	int32	-2147483648 2147483647	-	1 = 1
90.05	Load position scaled	real32	-2147483.264 2147483.264	-	100000 = 1
90.06	Motor position scaled	int32	-2147483.648 2147483.647	-	1000 = 1
90.07	Load position scaled int	int32	-2147483648 2147483647	-	1 = 1
90.10	Encoder 1 speed	real32	-32768.00 32767.00	rpm	100 = 1 rpm
90.11	Encoder 1 position	real32	0.00000000 1.00000000	rev	100000000 = 1 rev
90.12	Encoder 1 multiturn revolutions	uint32	016777215	-	1 = 1
90.13	Encoder 1 revolution extension	int32	-2147483648 2147483647	-	1 = 1
90.14	Encoder 1 position raw	uint32	016777215		1 = 1
90.15	Encoder 1 revolutions raw	uint32	016777215	-	1 = 1
90.20	Encoder 2 speed	real32	-32768.00 32767.00	rpm	100 = 1 rpm
90.21	Encoder 2 position	real32	0.00000000 1.00000000	rev	100000000 = 1 rev

No.	Name	Туре	Range	Unit	FbEq32
90.22	Encoder 2 multiturn revolutions	uint32	016777215	-	1 = 1
90.23	Encoder 2 revolution extension	int32	-2147483648 2147483647	-	1 = 1
90.24	Encoder 2 position raw	uint32	016777215	-	1 = 1
90.25	Encoder 2 revolutions raw	uint32	016777215	-	1 = 1
90.26	Motor revolution extension	int32	-2147483648 2147483647	-	1 = 1
90.27	Load revolution extension	real32	-2147483648 2147483647	-	1 = 1
90.35	Pos counter status	uint16	000000b111111b	-	1 = 1
90.38	Pos counter decimals	uint16	09	-	1 = 1
90.41	Motor feedback selection	uint16	02	-	1 = 1
90.42	Motor speed filter time	real32	010000	ms	1 = 1 ms
90.43	Motor gear numerator	int32	-3276832767	-	1 = 1
90.44	Motor gear denominator	int32	-3276832767	-	1 = 1
90.45	Motor feedback fault	uint16	01	-	1 = 1
90.46	Force open loop	uint16	01	-	1 = 1
90.48	Motor position axis mode	uint16	01	-	1 = 1
90.49	Motor position resolution	uint16	031	-	1 = 1
90.51	Load feedback selection	uint16	04	-	1 = 1
90.52	Load speed filter time	real32	010000	ms	1 = 1 ms
90.53	Load gear numerator	int32	-2147483648 2147483647		1 = 1
90.54	Load gear denominator	int32	-2147483648 2147483647	-	1 = 1
90.55	Load feedback fault	uint16	01	-	1 = 1
90.56	Load position offset	int32	-2147483648 2147483647	rev	1 = 1 rev
90.57	Load position resolution	uint16	031	-	1 = 1
90.58	Pos counter init value int	int32	-2147483648 2147483647	-	1 = 1
90.59	Pos counter init value int source	uint32	-	-	1 = 1
90.60	Pos counter error and boot action	uint16	01	-	1 = 1
90.61	Gear numerator	int32	-2147483648 2147483647	-	1 = 1
90.62	Gear denominator	int32	-2147483648 2147483647	-	1 = 1
90.63	Feed constant numerator	int32	-2147483648 2147483647	-	1 = 1
90.64	Feed constant denominator	int32	-2147483648 2147483647	-	1 = 1
90.65	Pos counter init value	real32	-2147483.264 2147483.264	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32
92.17	Accepted pulse freq of encoder 1	uint16	0300	kHz	1 = 1 kHz
92.21	Encoder cable fault mode	uint16	03	_	1 = 1
92.23	Maximum pulse waiting time	real32	1200	ms	1 = 1 ms
92.24	Pulse edge filtering	uint16	02	-	1 = 1
92.25	Pulse overfrequency function	uint16	01	-	1 = 1
	Other parameters in a	this group wi	hen an absolute encoder is	selected	
92.10	Sine/cosine number	uint16	065535	-	1 = 1
92.11	Absolute position source	uint16	05	-	1 = 1
92.12	Zero pulse enable	uint16	01	-	1 = 1
92.13	Position data width	uint16	032	-	1 = 1
92.14	Revolution data width	uint16	032	-	1 = 1
92.30	Serial link mode	uint16	02	-	1 = 1
92.31	EnDat max calculation time	uint16	03	-	1 = 1
92.32	SSI cycle time	uint16	05	-	1 = 1
92.33	SSI clock cycles	uint16	2127	-	1 = 1
92.34	SSI position msb	uint16	1126	-	1 = 1
92.35	SSI revolution msb	uint16	1126	-	1 = 1
92.36	SSI data format	uint16	01	-	1 = 1
92.37	SSI baud rate	uint16	05	-	1 = 1
92.40	SSI zero phase	uint16	03	-	1 = 1
92.45	Hiperface parity	uint16	01	-	1 = 1
92.46	Hiperface baud rate	uint16	03	-	1 = 1
92.47	Hiperface node address	uint16	0255	-	1 = 1
	Other paramete	rs in this gro	up when a resolver is selec	ted	
92.10	Excitation signal frequency	uint16	120	kHz	1 = 1 kHz
92.11	Excitation signal amplitude	uint16	4.0 12.0	V	10 = 1 V
92.12	Resolver polepairs	uint16	132	-	1 = 1
93 Enco	oder 2 configuration				
93.01	Encoder 2 type	uint16	09	-	1 = 1
93.02	Encoder 2 source	uint16	12	-	1 = 1
			TTL, TTL+ and HTL encod pending on encoder type se		ed
93.10	Pulses/rev	uint16	065535	-	1 = 1
93.11	Pulse encoder type	uint16	01	-	1 = 1
93.12	Speed calculation mode	uint16	05	-	1 = 1
93.13	Position estimation enable	uint16	01	-	1 = 1
93.14	Speed estimation enable	uint16	01	-	1 = 1
93.15	Transient filter	uint16	03	-	1 = 1
93.17	Accepted pulse freq of encoder 2	uint16	0300	kHz	1 = 1 kHz
93.21	Encoder cable fault mode	uint16	03	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32
	(Parameters 94.4094.41 are	visible only v	when supply unit control is	activated by	95.20)
94.40	Power mot limit on net loss	real32	0.00 600.00	%	100 = 1%
94.41	Power gen limit on net loss	real32	-600.00 0.00	%	100 = 1%
95 HW c	configuration	1			
95.01	Supply voltage	uint16	06	-	1 = 1
95.02	Adaptive voltage limits	uint16	01	-	1 = 1
95.04	Control board supply	uint16	02	-	1 = 1
	(Parameter 9	5.08 is visible	only with a ZCU control ur	nit)	
95.08	DC switch monitoring	uint16	01	-	1 = 1
	(Parameters 95.09	95.14 are vi	isible only with a BCU cont	trol unit)	
95.09	Switch fuse controller	uint16	01	-	1 = 1
95.13	Reduced run mode	uint16	065535	-	1 = 1
95.14	Connected modules	uint16	0000hFFFFh	-	1 = 1
95.15	Special HW settings	uint16	0000hFFFFh	-	1 = 1
95.16	Router mode	uint32	-	-	1 = 1
95.17	Router channel config	uint16	0000hFFFFh	-	1 = 1
95.20	HW options word 1	uint16	0000hFFFFh	-	1 = 1
95.21	HW options word 2	uint16	0000hFFFFh	-	1 = 1
	(Parameters 95.30	95.31 are vi	isible only with a BCU cont	trol unit)	
95.30	Parallel type list filter	uint16	15	-	1 = 1
95.31	Parallel type configuration	uint16	-	-	1 = 1
95.40	Transformation ratio	real32	0.000100.000	-	1000 = 1
96 Syst	em				
96.01	Language	uint16	-	-	1 = 1
96.02	Pass code	uint32	099999999	-	1 = 1
96.03	Access levels active	uint16	0000hFFFFh	-	1 = 1
96.04	Macro select	uint16	06	-	1 = 1
96.05	Macro active	uint16	16	-	1 = 1
96.06	Parameter restore	uint16	-	-	1 = 1
96.07	Parameter save manually	uint16	01	-	1 = 1
96.08	Control board boot	uint16	01	-	1 = 1
96.09	FSO reboot	uint32	-	-	-
96.10	User set status	uint16	-	-	-
96.11	User set save/load	uint16	-	-	-
96.12	User set I/O mode in1	uint32	-	-	-
96.13	User set I/O mode in2	uint32	-	-	-
96.16	Unit selection	uint16	0000hFFFFh	-	1 = 1
96.20	Time sync primary source	uint16	09	-	1 = 1
96.23	M/F and D2D clock synchronization	uint16	01	-	1 = 1
96.24	Full days since 1st Jan 1980	uint16	159999	-	1 = 1

No.	Name	Type	Range	Unit	FbEq32
96.25	Time in minutes within 24 h	uint16	01439	-	1 = 1
96.26	Time in ms within one minute	uint16	059999	-	1 = 1
96.29	Time sync source status	uint16	0000hFFFFh	-	1 = 1
96.31	Drive ID number	uint16	032767	-	1 = 1
96.39	Power up event logging	uint16	01	-	1 = 1
96.51	Clear fault and event logger	uint16	065535	-	1 = 1
96.53	Actual checksum	uint32	00000000hFFFFFFFh	-	1 = 1
96.54	Checksum action	uint16	04	-	1 = 1
96.55	Checksum control word	uint16	0000hFFFFh	-	1 = 1
96.56	Approved checksum 1	uint32	00000000hFFFFFFFh	-	1 = 1
96.57	Approved checksum 2	uint32	00000000hFFFFFFFh	-	1 = 1
96.58	Approved checksum 3	uint32	00000000hFFFFFFFh	-	1 = 1
96.59	Approved checksum 4	uint32	00000000hFFFFFFFh	-	1 = 1
96.61	User data logger status word	uint16	0000hFFFFh	-	1 = 1
96.63	User data logger trigger	uint32	-	-	-
96.64	User data logger start	uint32	-	-	-
96.65	Factory data logger time level	uint16	-	-	1 = 1
96.70	Disable adaptive program	uint16	01	-	1 = 1
	(Parameters 96.10096.10	02 are visib	ole only when enabled by para	meter 96.0	02)
96.100	Change user pass code	uint32	1000000099999999	-	1 = 1
96.101	Confirm user pass code	uint32	1000000099999999	-	1 = 1
96.102	User lock functionality	uint16	0000hFFFFh	-	1 = 1
	(Parameter 96.108 is visible of	only when	IGBT supply unit control is en	abled by 95	5.20)
96.108	LSU control board boot	real32	01	-	1 = 1
97 Moto	r control				
97.01	Switching frequency reference	real32	0.00024.000	kHz	1000 = 1%
97.02	Minimum switching frequency	real32	0.00024.000	kHz	1000 = 1%
97.03	Slip gain	real32	0200	%	1 = 1%
97.04	Voltage reserve	real32	-450	%	1 = 1%
97.05	Flux braking	uint16	02	-	1 = 1
97.06	Flux reference select	uint32	-	-	1 = 1
97.07	User flux reference	real32	0.00200.00	%	100 = 1%
97.08	Optimizer minimum torque	real32	0.01600.0	%	10 = 1%
97.09	Switching freq mode	uint16	03	-	1 = 1
97.10	Signal injection	uint16	04	-	1 = 1
97.11	TR tuning	real32	25400	%	1 = 1%
97.12	IR comp step-up frequency	real32	0.0 50.0	Hz	10 = 1 Hz
97.13	IR compensation	real32	0.00 50.00	%	100 = 1%
97.15	Motor model temperature adaptation	uint16	03	-	1 = 1
97.18	Hexagonal field weakening	uint16	01	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32
97.19	Hexagonal field weakening point	real32	0.0500.0	%	10 = 1%
97.32	Motor torque unfiltered	real32	-1600.0 1600.0	%	10 = 1%
97.33	Speed estimate filter time	real32	0.00 100.00	ms	100 = 1 ms
98 User	motor parameters				
98.01	User motor model mode	uint16	03	-	1 = 1
98.02	Rs user	real32	0.0000 0.50000	p.u.	100000 = 1 p.u.
98.03	Rr user	real32	0.0000 0.50000	p.u.	100000 = 1 p.u.
98.04	Lm user	real32	0.00000 10.00000	p.u.	100000 = 1 p.u.
98.05	SigmaL user	real32	0.00000 1.00000	p.u.	100000 = 1 p.u.
98.06	Ld user	real32	0.00000 10.00000	p.u.	100000 = 1 p.u.
98.07	Lq user	real32	0.00000 10.00000	p.u.	100000 = 1 p.u.
98.08	PM flux user	real32	0.00000 2.00000	p.u.	100000 = 1 p.u.
98.09	Rs user SI	real32	0.00000 100.00000	ohm	100000 = 1 p.u.
98.10	Rr user SI	real32	0.00000 100.00000	ohm	100000 = 1 p.u.
98.11	Lm user SI	real32	0.00 100000.00	mH	100 = 1 mH
98.12	SigmaL user SI	real32	0.00 100000.00	mH	100 = 1 mH
98.13	Ld user SI	real32	0.00 100000.00	mH	100 = 1 mH
98.14	Lq user SI	real32	0.00 100000.00	mH	100 = 1 mH
98.15	Position offset user	real32	0360	degrees electrical	1 = deg
99 Moto	r data				
99.03	Motor type	uint16	01 or 02	-	1 = 1
99.04	Motor control mode	uint16	01	-	1 = 1
99.06	Motor nominal current	real32	0.0 6400.0	Α	10 = 1 A
99.07	Motor nominal voltage	real32	0.0 800.0	V	10 = 1 V
99.08	Motor nominal frequency	real32	0.00 1000.00	Hz	10 = 1 Hz
99.09	Motor nominal speed	real32	0 30000	rpm	1 = 1 rpm
99.10	Motor nominal power	real32	0.0010000.00 kW or 0.0013404.83 hp	kW or hp	100 = 1 unit
99.11	Motor nominal cos Φ	real32	0.00 1.00	-	100 = 1
99.12	Motor nominal torque	uint32	0.0004000000.000	N·m or lb·ft	1000 = 1 unit
99.13	ID run requested	uint16	07	-	1 = 1
99.14	Last ID run performed	uint16	07	-	1 = 1
99.15	Motor polepairs calculated	uint16	01000	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32
99.16	Motor phase order	uint16	01	-	1 = 1
99.18	Sine filter inductance	real32	0.000100000.000	mH	1000 = 1 mH
99.19	Sine filter capacitance	real32	0.00100000.00	μF	100 = 1 μF

#### 200 Safety

This group contains parameters related to the optional FSO-xx safety functions module. For details on the parameters in this group, refer to the documentation of the FSO-xx module.


206 I/O bus configuration

207 I/O bus service

208 I/O bus diagnostics

209 I/O bus fan identification

(Groups only visible with a BCU control unit) These groups contain parameters related to the distributed I/O bus, which is used with some drives for monitoring the cooling fans of the cabinet system. For details, refer to ACS880 distributed I/O bus supplement (3AXD50000126880 [English]).



# Fault tracing

## What this chapter contains

The chapter lists the warning and fault messages including possible causes and corrective actions. The causes of most warnings and faults can be identified and corrected using the information in this chapter. If not, an ABB service representative should be contacted.

Warnings and faults are listed below in separate tables. Each table is sorted by warning/fault code.

## Safety



**WARNING!** Only qualified electricians are allowed to service the drive. Read the Safety instructions on the first pages of the Hardware manual before working on the drive.

## **Indications**

## Warnings and faults

Warnings and faults indicate an abnormal drive status. The codes and names of active warnings/faults are displayed on the control panel of the drive as well as the Drive composer PC tool. Only the codes of warnings/faults are available over fieldbus.

Warnings do not need to be reset; they stop showing when the cause of the warning ceases. Warnings do not latch and the drive will continue to operate the motor.

Faults do latch inside the drive and cause the drive to trip, and the motor stops. After the cause of a fault has been removed, the fault can be reset from a selectable

source (see parameter 31.11 Fault reset selection) such as the control panel, Drive composer PC tool, the digital inputs of the drive, or fieldbus. After the fault is reset, the drive can be restarted. Note that some faults require a reboot of the control unit either by switching the power off and on, or using parameter 96.08 Control board boot – this is mentioned in the fault listing wherever appropriate.

Warning and fault indications can be directed to a relay output or a digital input/output by selecting *Warning*, *Fault* or *Fault* (-1) in the source selection parameter. See sections

- Programmable digital inputs and outputs (page 71)
- Programmable relay outputs (page 72), and
- Programmable I/O extensions (page 72).

#### Pure events

In addition to warnings and faults, there are pure events that are only recorded in the event logs of the drive. The codes of these events are included in the *Firmware* warning messages table.

#### Editable messages

For some warnings and faults, the message text can be edited and instructions and contact information added. To edit these messages, choose **Menu - Settings - Edit texts** on the control panel, or use the Localization editor in Drive composer pro.

## Warning/fault history and analysis

## Event logs

The drive has two event logs. One log contains faults and fault resets; the other contains warnings, pure events, and clearing entries. Each log contains the 64 most recent events with a time stamp and other information.

The logs can be accessed separately from the main Menu on the control panel. The logs are displayed as a single list when viewed using the Drive composer PC tool.

The logs can be cleared using parameter 96.51 Clear fault and event logger.

#### **Auxiliary codes**

Some events generate an auxiliary code that often helps in pinpointing the problem. The auxiliary code is displayed on the control panel together with the message. It is also stored in the event log details. In the Drive composer PC tool, the auxiliary code (if any) is shown in the event listing.

#### Factory data logger

The drive has a data logger that samples preselected drive values at 500-microsecond (default; see parameter 96.65 Factory data logger time level) intervals.

Approximately 7000 samples recorded immediately before and after a fault are saved to the memory unit of the drive. The fault data of the last five faults is accessible in the event log when viewed in the Drive composer PC tool. (The fault data is not accessible through the control panel.)

The values that are recorded in the factory data log are 01.07 Motor current, 01.10 Motor torque, 01.11 DC voltage, 01.24 Flux actual %, 06.01 Main control word, 06.11 Main status word, 24.01 Used speed reference, 30.01 Limit word 1, 30.02 Torque limit status and 90.01 Motor speed for control. The selection of parameters cannot be changed by the user.

#### Other data loggers

#### User data logger

A custom data logger can be configured using the Drive composer pro PC tool. This functionality enables the free selection of up to eight drive parameters to be sampled at selectable intervals. The triggering conditions and the length of the monitoring period can also be defined by the user within the limit of approximately 8000 samples. In addition to the PC tool, the status of the logger is shown by drive parameter 96.61 User data logger status word. The triggering sources can be selected by parameters 96.63 User data logger trigger and 96.64 User data logger start). The configuration, status and collected data is saved to the memory unit for later analysis.

#### PSL2 data logger

The BCU control unit used with certain drive types (especially those with parallelconnected inverter modules) contains a data logger that collects data from the inverter modules to help fault tracing and analysis. The data is saved onto the SD card attached to the BCU, and can be analyzed by ABB service personnel.

## Parameters containing warning/fault information

The drive is able to store a list of the active faults actually causing the drive to trip at the present time. The faults are displayed in parameter group 04 Warnings and faults (page 166). The parameter group also displays a list of faults and warnings that have previously occurred.

#### **Event word (parameters** *04.40...04.72***)**

Parameter 04.40 Event word 1 can be configured by the user to indicate the status of 16 selectable events (i.e. faults, warnings or pure events). It is possible to specify an auxiliary code for each event to filter out other auxiliary codes.

## QR code generation for mobile service application

A QR code (or a series of QR codes) can be generated by the drive for display on the control panel. The QR code contains drive identification data, information on the latest events, and values of status and counter parameters. The code can be read with a mobile device containing the ABB service application, which then sends the data to ABB for analysis. For more information on the application, contact your local ABB service representative.

The QR code can be generated by choosing **Menu - Assistants - QR code** on the control panel.

## Firmware warning messages

**Note:** The list also contains events that only appear in the Event log.

Code (hex)	Warning	Cause	What to do
A2A1	Current calibration	Current offset and gain measurement calibration will occur at next start.	Informative warning. (See parameter 99.13 ID run requested.)
A2B3	Earth leakage	Drive has detected load unbalance typically due to earth fault in motor or motor cable.	Check there are no power factor correction capacitors or surge absorbers in motor cable. Check for an earth fault in motor or motor cables by measuring the insulation resistances of motor and motor cable. Try running the motor in scalar control mode if allowed. (See parameter 99.04 Motor control mode.) If no earth fault can be detected, contact your local ABB representative.
A2B4	Short circuit	Short-circuit in motor cable(s) or motor.	Check motor and motor cable for cabling errors. Check there are no power factor correction capacitors or surge absorbers in motor cable.
A2BA	IGBT overload	Excessive IGBT junction to case temperature. This warning protects the IGBT(s) and can be activated by a short circuit in the motor cable.	Check motor cable. Check ambient conditions. Check air flow and fan operation. Check heat sink fins for dust pick-up. Check motor power against drive power.
A3A1	DC link overvoltage	Intermediate circuit DC voltage too high (when the drive is stopped).	Check the supply voltage setting (parameter 95.01 Supply voltage). Note that the wrong setting of the parameter
A3A2	DC link undervoltage	Intermediate circuit DC voltage too low (when the drive is stopped).	may cause the motor to rush uncontrollably, or may overload the brake chopper or resistor. Check the supply voltage.
АЗАА	DC not charged	The voltage of the intermediate DC circuit has not yet risen to operating level.	If the problem persists, contact your local ABB representative.
A480	Motor cable overload	Calculated motor cable temperature has exceeded warning limit.	Check the settings of parameters 35.61 and 35.62. Check the dimensioning of the motor cable in regard to required load.
A490	Incorrect temperature sensor setup	Sensor type mismatch	Check the settings of temperature source parameters 35.11 and 35.21 against 91.21 and 91.24.
		Faulty wiring between an encoder interface module and the temperature sensor.	Check the wiring of the sensor. The auxiliary code identifies the interface module. (0 = Module 1, 1 = Module 2).

Code (hex)	Warning	Cause	What to do
A490	Incorrect temperature sensor setup	Problem with motor temperature measurement.	Check the auxiliary code (format 0XYY ZZZZ).  "X" identifies the affected temperature monitoring function (1 = parameter 35.11, 2 = parameter 35.21).  "YY" indicates the selected temperature source, ie. the setting of the selection parameter in hexadecimal.  "ZZZZ" indicates the problem (see actions for each code below).
	0001	Sensor type mismatch	Check parameters <i>35.11/35.21</i> against <i>91.21/91.24</i> .
	0002	Temperature under limit	Check parameters
	0003	Short circuit	35.1135.14/35.2135.24 (and 91.21/91.24 if sensor is connected to an
	0004	Open circuit	encoder interface). Check the sensor and its wiring.
A491	External temperature 1 (Editable message text)	Measured temperature 1 has exceeded warning limit.	Check the auxiliary code (format 0XYY ZZZZ).  "X" identifies the affected temperature monitoring function (1 = parameter 35.11, 2 = parameter 35.21).  "YY" indicates the selected temperature source, ie. the setting of the selection parameter in hexadecimal.  "ZZZZ" indicates the problem (see actions for each code below)
A492	External temperature 2 (Editable message text)	Measured temperature 2 has exceeded warning limit.	Check the value of parameter 35.03  Measured temperature 2.  Check the cooling of the motor (or other equipment whose temperature is being measured).  Check the value of 35.23 Temperature 2 warning limit.
A497	Motor temperature 1 (Editable message text)	The thermistor protection module installed in slot 1 indicates overtemperature.	Check the cooling of the motor. Check the motor load and drive ratings. Check the wiring of the temperature
A498	Motor temperature 2 (Editable message text)	The thermistor protection module installed in slot 2 indicates overtemperature.	sensor. Repair wiring if faulty.  Measure the resistance of the sensor.  Replace sensor if faulty.
A499	Motor temperature 3 (Editable message text)	The thermistor protection module installed in slot 3 indicates overtemperature.	
A4A0	Control board temperature	Control unit temperature is excessive.	Check the auxiliary code. See actions for each code below.
	(none)	Temperature above warning limit	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up.
	1	Thermistor broken	Contact an ABB service representative for control unit replacement.

Code (hex)	Warning	Cause	What to do
A4A9	Cooling	Drive module temperature is excessive.	Check ambient temperature. If it exceeds 40 °C (104 °F), ensure that load current does not exceed derated load capacity of drive. See appropriate <i>Hardware manual</i> . Check drive module cooling air flow and fan operation.  Check inside of cabinet and heatsink of drive module for dust pick-up. Clean whenever necessary.
A4B0	Excess temperature	Power unit module temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check the setting of 31.36 Aux fan fault function (if present). Check heatsink fins for dust pick-up. Check motor power against drive power. See A5EA Measurement circuit temperature (page 601).
A4B1	Excess temperature difference	High temperature difference between the IGBTs of different phases.	Check the motor cabling. Check cooling of drive module(s). Check the auxiliary code (format XXXY YYZZ). "XXX" indicates the source of difference (0: Single module, difference between phase IGBTs, 1: parallel-connected modules, minimum-maximum difference between all IGBTs of all modules). 2: parallel-connected modules, minimum-maximum difference between auxiliary power supply boards). With parallel-connected modules, "Y YY" specifies through which BCU control unit channel the fault was received. "ZZ" specifies the phase (0: single module, 1: U-phase [parallel connection], 2: W-phase [parallel connection], 3: W-phase [parallel connection]).
A4B2	PCB space cooling	Temperature difference between ambient and drive module PCB space is excessive.	Check the cooling fan inside the PCB space. With parallel-connected modules, check the auxiliary code (format XXXY YYZZ). "Y YY" specifies through which BCU control unit channel the fault was received.
A4F6	IGBT temperature	Drive IGBT temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check heat sink fins for dust pick-up. Check motor power against drive power.

Code (hex)	Warning	Cause	What to do
A580	PU communication	Communication errors detected between the drive control unit and the power unit.	Check the connections between the drive control unit and the power unit. Check the auxiliary code (format XXXY YYZZ). With parallel-connected modules, "Y YY" specifies the affected BCU control unit channel (0: broadcast). "ZZ" specifies the error source (8: Transmission errors in PSL link [see "XXX"], 9: Transmitter FIFO warning limit hit). "XXX" specifies the transmission error direction and detailed warning code (0: Rx/communication error, 1: Tx/Reed-Solomon symbol error, 2: Tx/no synchronization error, 3: Tx/Reed-Solomon decoder failures, 4: Tx/Manchester coding errors). Read the PSL2 data log. In Drive composer pro, check the time stamp of the A580 fault. Load the log with the same date and time. When the file opens, click "Show fault log". Check the power unit hardware.
A581	Fan Programmable warning: 31.35 Main fan fault function	Cooling fan stuck or disconnected.	Check the setting of parameter 95.20  HW options word 1, bit 14.  Code 0 denotes main fan 1. Other codes (format XYZ): "X" specifies state code (1: ID run, 2: normal). "Y" specifies the index of the inverter module connected to BCU (0n, always 0 for ZCU control units). "Z" specifies the index of the fan (1: Main fan 1, 2: Main fan 2, 3: Main fan 3). Note that modules are coded starting from 0. For example, the code 101 means that Main fan 1 of module 1 (connected to BCU channel V1T/V1R) has faulted during its ID run. Check fan operation and connection. Replace fan if faulty.
A582	Auxiliary fan not running Programmable warning: 31.36 Aux fan fault function	An auxiliary cooling fan (connected to the fan connectors on the control unit) is stuck or disconnected.	The auxiliary code identifies the fan (1: Auxiliary fan 1, 2: Auxiliary fan 2). Check that the auxiliary fan supervision selection in parameter 95.21 HW options word 2 matches the hardware. Make sure the front cover of the drive module is in place and tightened. Check auxiliary fan(s) and connection(s). Replace faulty fan.
A5A0	Safe torque off Programmable warning: 31.22 STO indication run/stop	Safe torque off function is active, i.e. safety circuit signal(s) connected to connector XSTO is lost.	Check safety circuit connections. For more information, see appropriate drive hardware manual and description of parameter 31.22 STO indication run/stop (page 320).

Code (hex)	Warning	Cause	What to do
A5EA	Measurement circuit temperature	Problem with internal temperature measurement of the drive.	Check the auxiliary code (format XXXY YYZZ). "Y YY" specifies through which BCU control unit channel the fault was received ("0 00" with a ZCU control unit). "ZZ" specifies the location (1: U-phase, IGBT, 2: V-phase IGBT, 3: W-phase IGBT, 4: Power supply board, 5: Power unit xINT board, 6: Brake chopper, 7: Air inlet (TEMP3, X10), 8: du/dt filter (TEMP2, X7), 9: TEMP1 (X6)).
A5EB	PU board powerfail	Power unit power supply failure.	Contact your local ABB representative.
A5EC	PU communication internal	Communication errors detected between the drive control unit and the power unit.	Check the connections between the drive control unit and the power unit.
A5ED	Measurement circuit ADC	Problem with measurement circuit of power unit (analog to digital converter)	Contact your local ABB representative.
A5EE	Measurement circuit DFF	Problem with current or voltage measurement of power unit	Contact your local ABB representative.
A5EF	PU state feedback	State feedback from output phases does not match control signals.	Contact your local ABB representative.
A5F0	Charging feedback	Charging in progress	Informative warning. Wait until charging finishes before starting the inverter unit.
A5F3	Switching frequency below requested	Adequate motor control at requested output frequency cannot be reached because of limited switching frequency (e.g. by parameter 95.15).	Informative warning.
A5F4	Control unit battery	The battery of the control unit is low.	Replace control unit battery. This warning can be suppressed using parameter <i>31.40</i> .
A682	Flash erase speed exceeded	The flash memory (in the memory unit) has been erased too frequently, compromising the lifetime of the memory.	Avoid forcing unnecessary parameter saves by parameter 96.07 or cyclic parameter writes (such as user logger triggering through parameters).  Check the auxiliary code (format XYYY YZZZ). "X" specifies the source of warning (1: generic flash erase supervision). "ZZZ" specifies the flash subsector number that generated the warning.
A683	Data saving to power unit	An error in saving data to the power unit.	Check the auxiliary code. See actions for each code below.
	0 1 2	An error is preventing saving from initializing.  Write error.	Cycle the power to the drive. If the control unit is externally powered, also reboot the control unit (using parameter 96.08 Control board boot) or by cycling
			its power. If the problem persists, contact your local ABB representative.
A684	SD card	Error related to SD card used to store data (BCU control unit only).	Check the auxiliary code. See actions for each code below.

Code (hex)	Warning	Cause	What to do
	1	No SD card	Insert a compatible, writable SD card into
	2	SD card write-protected	the SD CARD slot of the BCU control unit.
	3	SD card unreadable	
A685	Power fail saving	Power fail saving is requested too frequently. Because of the limited saving interval, some of the requests do not trigger the saving and power fail data may be lost. This may be caused by DC voltage oscillation.	Check the supply voltage.
A686	Checksum mismatch Programmable warning: 96.54 Checksum action	The calculated parameter checksum does not match any enabled reference checksum.	Check that all necessary approved (reference) checksums (96.5696.59) are enabled in 96.55 Checksum control word.  Check the parameter configuration. Using 96.55 Checksum control word, enable a checksum parameter and copy the actual checksum into that parameter.
A687	Checksum configuration	An action has been defined for a parameter checksum mismatch but the feature has not been configured.	Contact your local ABB representative for configuring the feature, or disable the feature in 96.54 Checksum action.
A688	Parameter map configuration	Too much data in parameter mapping table created in Drive customizer.	See the <i>Drive customizer PC tool user's manual</i> (3AUA0000104167 [English]).
A689	Mapped parameter value cut	Parameter value saturated e.g. by the scaling specified in parameter mapping table (created in Drive customizer).	Check parameter scaling and format in parameter mapping table. See the <i>Drive customizer PC tool user's manual</i> (3AUA0000104167 [English]).
A6A4	Motor nominal value	The motor parameters are set incorrectly.	Check the auxiliary code. See actions for each code below.
		The drive is not dimensioned correctly.	
	1	Slip frequency is too small	Check the settings of the motor
	2	Synchronous and nominal speeds differ too much	configuration parameters in groups 98 and 99.  Check that the drive is sized correctly for
	3	Nominal speed is higher than synchronous speed with 1 pole pair	the motor.
	4	Nominal current is outside limits	
	5	Nominal voltage is outside limits	
	6	Nominal power is higher than apparent power	
	7	Nominal power is not consistent with nominal speed and torque	

Code (hex)	Warning	Cause	What to do
A6A5	No motor data	Parameters in group 99 have not been set.	Check that all the required parameters in group 99 have been set.  Note: It is normal for this warning to appear during the start-up and continue until the motor data is entered.
A6A6	Supply voltage unselected	The supply voltage has not been defined.	Set supply voltage in parameter 95.01 Supply voltage.
A6B0	User lock is open	The user lock is open, i.e. user lock configuration parameters 96.10096.102 are visible.	Close the user lock by entering an invalid pass code in parameter 96.02 Pass code. See section User lock (page 134).
A6B1	User pass code not confirmed	A new user pass code has been entered in parameter 96.100 but not confirmed in 96.101.	Confirm the new pass code by entering the same code in 96.101. To cancel, close the user lock without confirming the new code. See section <i>User lock</i> (page 134).
A6D1	FBA A parameter conflict	The drive does not have a functionality requested by a PLC, or requested functionality has not been activated.	Check PLC programming. Check settings of parameter groups 50 Fieldbus adapter (FBA) and 51 FBA A settings.
A6D2	FBA B parameter conflict	The drive does not have a functionality requested by a PLC, or requested functionality has not been activated.	Check PLC programming. Check settings of parameter groups 50 Fieldbus adapter (FBA) and 54 FBA B settings.
A6DA	Reference source parametrization	A reference source is simultaneously connected to multiple parameters with different units.	Check the reference source selection parameters. Check the auxiliary code (format XXYY 00ZZ). "XX" and "YY" specify the two sets of parameters where the source was connected to (01 = speed reference chain [22.11, 22.12, 22.15, 22.17], 02 = frequency reference chain [28.11, 28.12], 03 = torque reference chain [26.11, 26.12, 26.16], 04 = other torque-related parameters [26.25, 30.21, 30.22, 44.09], 05 = process PID control parameters [40.16, 40.17, 40.50, 41.16, 41.17, 41.50]). "ZZ" indicates the conflicting reference source (010E = index in parameter group 3, 33 = process PID control, 3D = motor potentiometer, 65 = AI1, 66 = AI2, 6F = frequency input).
A6E5	Al parametrization	The current/voltage hardware setting of an analog input does not correspond to parameter settings.	Check the auxiliary code. The code identifies the analog input whose settings are in conflict.  Adjust either the hardware setting (on the drive control unit) or parameter 12.15/12.25.  Note: Control board reboot (either by cycling the power or through parameter 96.08 Control board boot) is required to validate any changes in the hardware settings.
A6E6	ULC configuration	User load curve configuration error.	Check the auxiliary code (format XXXX ZZZZ). "ZZZZ" indicates the problem (see actions for each code below).

Warning	Cause	What to do
0000	Speed points inconsistent.	Check that each speed point (parameters 37.1137.15) has a higher value than the previous point.
0001	Frequency points inconsistent.	Check that each frequency point (37.1637.20) has a higher value than the previous point.
0002	Underload point above overload point.	Check that each overload point (37.3137.35) has a higher value than
0003	Overload point below underload point.	the corresponding underload point (37.2137.25).
Motor stall Programmable warning: 31.24 Stall function	Motor is operating in stall region because of e.g. excessive load or insufficient motor power.	Check motor load and drive ratings. Check fault function parameters.
Motor fan Programmable warning: 35.106 DOL starter event type	No feedback received from external fan.	Check external fan (or other equipment controlled) by the logic. Check settings of parameters 35.10035.106.
FEN temperature	Error in temperature measurement when temperature sensor (KTY or PTC) connected to encoder interface FEN-xx is used.	Check that parameter 35.11 Temperature 1 source / 35.21 Temperature 2 source setting corresponds to actual encoder interface installation.
	Error in temperature measurement when KTY sensor connected to encoder interface FEN-01 is used.	FEN-01 does not support temperature measurement with KTY sensor. Use PTC sensor or other encoder interface module.
Motor overload Programmable warning: 35.56 Motor overload action	Motor current is too high.	Check for overloaded motor. Adjust the parameters used for the motor overload function (35.5135.53) and 35.5535.56.
Brake resistor	Brake resistor broken or not connected.	Check that a brake resistor has been connected. Check the condition of the brake resistor.
BR excess temperature	Brake resistor temperature has exceeded warning limit defined by parameter 43.12 Brake resistor warning limit.	Stop drive. Let resistor cool down. Check resistor overload protection function settings (parameter group 43 Brake chopper). Check warning limit setting, parameter 43.12 Brake resistor warning limit. Check that the resistor has been dimensioned correctly. Check that braking cycle meets allowed limits.
BR data	Brake resistor data has not been given.	One or more of the resistor data settings (parameters 43.0843.10) is incorrect. The parameter is specified by the auxiliary code.
0000 0001	Resistance value too low.	Check value of 43.10.
0000 0002	Thermal time constant not given.	Check value of 43.08.
	Motor stall Programmable warning: 31.24 Stall function  Motor fan Programmable warning: 35.106 DOL starter event type  FEN temperature  Motor overload Programmable warning: 35.56 Motor overload action  Brake resistor  BR excess temperature	O000 Speed points inconsistent.  O001 Frequency points inconsistent.  O002 Underload point above overload point.  O003 Overload point below underload point.  Motor stall Programmable warning: 31.24 Stall function  Motor fan Programmable warning: 35.106 DOL starter event type  FEN temperature  Error in temperature measurement when temperature sensor (KTY or PTC) connected to encoder interface FEN-xx is used.  Error in temperature measurement when KTY sensor connected to encoder interface FEN-01 is used.  Motor overload Programmable warning: 35.56 Motor overload action  Brake resistor  Brake resistor broken or not connected.  BR excess temperature  Brake resistor temperature has exceeded warning limit defined by parameter 43.12 Brake resistor warning limit.  BR data  Brake resistor data has not been given.  O000 0001 Resistance value too low.  Thermal time constant not

Code (hex)	Warning	Cause	What to do
	0000 0003	Maximum continuous power not given.	Check value of 43.09.
A797	Speed feedback configuration	Speed feedback configuration has changed.	Check the auxiliary code (format XXYY ZZZZ). "XX" specifies the number of the encoder interface module (01: 91.11/91.12, 02: 91.13/91.14), "YY" specifies the encoder (01: 92 Encoder 1 configuration, 02: 93 Encoder 2 configuration). "ZZZZ" indicates the problem (see actions for each code below).
	0001	Adapter not found in specified slot.	Check module location (91.12 or 91.14).
	0002	Detected type of interface module does not match parameter setting.	Check the module type (91.11 or 91.13) against status (91.02 or 91.03).
	0003	Logic version too old.	Contact your local ABB representative.
	0004	Software version too old.	Contact your local ABB representative.
	0006	Encoder type incompatible with interface module type.	Check module type (91.11 or 91.13) against encoder type (92.01 or 93.01).
	0007	Adapter not configured.	Check module location (91.12 or 91.14).
	0008	Speed feedback configuration has changed.	Use parameter 91.10 Encoder parameter refresh) to validate any changes in the settings.
	0009	No encoders configured to encoder module	Configure the encoder in group 92 Encoder 1 configuration or 93 Encoder 2 configuration.
	000A	Non-existing emulation input.	Check input selection (91.31 or 91.41).
	000B	Echo not supported by selected input (for example, resolver or absolute encoder).	Check input selection (91.31 or 91.41), interface module type, and encoder type.
	000C	Emulation in continuous mode not supported.	Check input selection (91.31 or 91.41) and serial link mode (92.30 or 93.30) settings.
A798	Encoder option comm loss	Encoder feedback not used as actual feedback, or measured motor feedback lost (and parameter 90.45/90.55 is set to Warning).	Check that the encoder is selected as feedback source in parameter 90.41 or 90.51.  Check that the encoder interface module is properly seated in its slot.  Check that the encoder interface module or slot connectors are not damaged. To pinpoint the problem, try installing the module into a different slot.  If the module is installed on a FEA-03 extension adapter, check the fiber optic connections.  Check the auxiliary code (format XXXX YYYY). "YYYY" indicates the problem (see actions for each code below).
	0001	Failed answer to encoder configuration message.	Contact your local ABB representative.

Code (hex)	Warning	Cause	What to do
	0002	Failed answer to adapter watchdog disable message.	Contact your local ABB representative.
	0003	Failed answer to adapter watchdog enable message.	Contact your local ABB representative.
	0004	Failed answer to adapter configuration message.	Contact your local ABB representative.
	0005	Too many failed answers inline to speed and position messages.	Contact your local ABB representative.
	0006	DDCS driver failed.	Contact your local ABB representative.
A799	Ext I/O comm loss Programmable warning: 31.55 Ext I/O comm loss event	The I/O extension module types specified by parameters do not match the detected configuration.	Check the auxiliary code (format XXYY YYYY). "XX" specifies the number of the I/O extension module (01: parameter group 14 I/O extension module 1, 02: 15 I/O extension module 2, 03: 16 I/O extension module 3). "YY YYYY" indicates the problem (see actions for each code below).
	00 0001	Communication with module failed.	Check that the module is properly seated in its slot. Check that the module and the slot connector is not damaged. Try installing the module into another slot.
	00 0002	Module not found.	Check the type and location settings of
	00 0003	Configuration of module failed.	the modules (parameters 14.01/14.02, 15.01/15.02 or 16.01/16.02).
	00 0004	Configuration of module failed.	Check that the module is properly seated in its slot. Check that the module and the slot connector is not damaged. Try installing the module into another slot.
A79B	BC short circuit	Short circuit in brake chopper IGBT	Replace brake chopper if external. Drives with internal choppers will need to be returned to ABB. Ensure brake resistor is connected and not damaged.

Code (hex)	Warning	Cause	What to do
A79C	BC IGBT excess temperature	Brake chopper IGBT temperature has exceeded internal warning limit.	Let chopper cool down. Check for excessive ambient temperature. Check for cooling fan failure. Check for obstructions in the air flow. Check the dimensioning and cooling of the cabinet. Check resistor overload protection function settings (parameters 43.0643.10). Check minimum allowed resistor value for the chopper being used. Check that braking cycle meets allowed limits. Check that drive supply AC voltage is not excessive.
A7A1	Mechanical brake closing failed Programmable warning: 44.17 Brake fault function	Status of mechanical brake acknowledgment is not as expected during brake close.	Check mechanical brake connection. Check mechanical brake settings in parameter group 44 Mechanical brake control. Check that acknowledgment signal matches actual status of brake.
A7A2	Mechanical brake opening failed Programmable warning: 44.17 Brake fault function	Status of mechanical brake acknowledgment is not as expected during brake open.	Check mechanical brake connection. Check mechanical brake settings in parameter group 44 Mechanical brake control. Check that acknowledgment signal matches actual status of brake.
A7A5	Mechanical brake opening not allowed Programmable warning: 44.17 Brake fault function	Open conditions of mechanical brake cannot be fulfilled (for example, brake has been prevented from opening by parameter 44.11 Keep brake closed).	Check mechanical brake settings in parameter group 44 Mechanical brake control (especially 44.11 Keep brake closed).  Check that acknowledgment signal (if used) matches actual status of brake.
A7AA	Extension AI parametrization	The hardware current/voltage setting of an analog input (on an I/O extension module) does not correspond to parameter settings.	Check the auxiliary code (format XX00 00YY). "XX" specifies the number of the I/O extension module (01: parameter group 14 I/O extension module 2, 03: 16 I/O extension module 3). "YY" specifies the analog input on the module. For example, in case of I/O extension module 1, analog input Al1 (auxiliary code 0000 0101), the hardware current/voltage setting on the module is shown by parameter 14.29. The corresponding parameter setting is 14.30. Adjust either the hardware setting on the module or the parameter to solve the mismatch.  Note: Control board reboot (either by cycling the power or through parameter 96.08 Control board boot) is required to validate any changes in the hardware settings.

Code (hex)	Warning	Cause	What to do
A7AB	Extension I/O configuration failure	The I/O extension module types and locations specified by parameters do not match the detected configuration.	Check the type and location settings of the modules (parameters 14.01, 14.02, 15.01, 15.02, 16.01 and 16.02). Check that the modules are properly installed. Check the auxiliary code. See <i>Drive application programming manual (IEC 61131-3)</i> (3AUA0000127808 [English]).
A7B0	Motor speed feedback Programmable warning: 90.45 Motor feedback fault	No motor speed feedback is received.	Check the auxiliary code (format XXYY ZZZZ). "XX" specifies the number of the encoder interface module (01: 91.11/91.12, 02: 91.13/91.14), "YY" specifies the encoder (01: 92 Encoder 1 configuration, 02: 93 Encoder 2 configuration). "ZZZZ" indicates the problem (see actions for each code below).
	0001	Motor gear definition invalid or outside limits.	Check motor gear settings (90.43 and 90.44).
	0002	Encoder not configured.	Check encoder settings (92 Encoder 1 configuration or 93 Encoder 2 configuration).  Use parameter 91.10 Encoder parameter refresh) to validate any changes in the settings.
	0003	Encoder stopped working.	Check encoder status.
	0004	Encoder drift detected.	Check for slippage between encoder and motor.
A7B1	Load speed feedback Programmable warning: 90.55 Load feedback fault	No load speed feedback is received.	Check the auxiliary code (format XXYY ZZZZ). "XX" specifies the number of the encoder interface module (01: 91.11/91.12, 02: 91.13/91.14), "YY" specifies the encoder (01: 92 Encoder 1 configuration, 02: 93 Encoder 2 configuration). "ZZZZ" indicates the problem (see actions for each code below).
	0001	Load gear definition invalid or outside limits.	Check load gear settings (90.53 and 90.54).
	0002	Feed constant definition invalid or outside limits.	Check feed constant settings (90.63 and 90.64).
	0003	Encoder stopped working.	Check encoder status.
A7C1	FBA A communication Programmable warning: 50.02 FBA A comm loss func	Cyclical communication between drive and fieldbus adapter module A or between PLC and fieldbus adapter module A is lost.	Check status of fieldbus communication. See user documentation of fieldbus interface. Check settings of parameter groups 50 Fieldbus adapter (FBA), 51 FBA A settings, 52 FBA A data in and 53 FBA A data out. Check cable connections. Check if communication master is able to communicate.

Code (hex)	Warning	Cause	What to do
A7C2	FBA B communication Programmable warning: 50.32 FBA B comm loss func	Cyclical communication between drive and fieldbus adapter module B or between PLC and fieldbus adapter module B is lost.	Check status of fieldbus communication. See user documentation of fieldbus interface. Check settings of parameter group 50 Fieldbus adapter (FBA). Check cable connections. Check if communication master is able to communicate.
A7CA	DDCS controller comm loss Programmable warning: 60.59 DDCS controller comm loss function	DDCS (fiber optic) communication between drive and external controller is lost.	Check status of controller. See user documentation of controller. Check settings of parameter group 60 DDCS communication. Check cable connections. If necessary, replace cables.
A7CB	MF comm loss Programmable warning: 60.09 M/F comm loss function	Master/follower communication is lost.	Check the auxiliary code. The code indicates which node address (defined by parameter 60.02 in each drive) on the master/follower link is affected.  Check settings of parameter group 60 DDCS communication.  Check cable connections. If necessary, replace cables.
A7CE	EFB comm loss Programmable warning: 58.14 Communication loss action	Communication break in embedded fieldbus (EFB) communication.	Check the status of the fieldbus master (online/offline/error etc.). Check cable connections to the XD2D connector on the control unit.
A7E1	Encoder Programmable warning: 90.45 Motor feedback fault	Encoder error.	Check the event log for an auxiliary code (format XXYY ZZZZ). "XX" specifies the number of the encoder interface module (01: 91.11/91.12, 02: 91.13/91.14), "YY" specifies the encoder (01: 92 Encoder 1 configuration, 02: 93 Encoder 2 configuration). "ZZZZ" indicates the problem (see actions for each code below).
	0001	Cable fault	Check the conductor order at both ends of the encoder cable. Check the groundings of the encoder cable. If the encoder was working previously, check the encoder, encoder cable and encoder interface module for damage. See also parameter 92.21 Encoder cable fault mode.
	0002	No encoder signal	Check the condition of the encoder.
	0003	Overspeed	Contact your local ABB representative.
	0004	Overfrequency	Contact your local ABB representative.
	0005	Resolver ID run failed	Contact your local ABB representative.
	0006	Resolver overcurrent fault	Contact your local ABB representative.
	0007	Speed scaling error	Contact your local ABB representative.
	8000	Absolute encoder communication error	Contact your local ABB representative.

Code (hex)	Warning	Cause	What to do
	0009	Absolute encoder initialization error	Contact your local ABB representative.
	000A	Absolute SSI encoder configuration error	Contact your local ABB representative.
	000B	Encoder reported an internal error	See the documentation of the encoder.
	000C	Encoder reported a battery error	See the documentation of the encoder.
	000D	Encoder reported overspeed or decreased resolution due to overspeed	See the documentation of the encoder.
	000E	Encoder reported a position counter error	See the documentation of the encoder.
	000F	Encoder reported an internal error	See the documentation of the encoder.
A7EE	Control panel loss Programmable warning: 49.05 Communication loss action	Control panel or PC tool has stopped communicating.	Check PC tool or control panel connection. Check control panel connector. Check mounting platform if being used. Disconnect and reconnect the control panel.
A880	Motor bearing Programmable warnings: 33.14 On-time 1 warn message 33.24 On-time 2 warn message 33.55 Value counter 1 warn message 33.65 Value counter 2 warn message	Warning generated by an ontime timer or a value counter.	Check the event log for an auxiliary code. Check the source of the warning corresponding to the code: 0: 33.13 On-time 1 source 1: 33.23 On-time 2 source 4: 33.53 Value counter 1 source 5: 33.63 Value counter 2 source.
A881	Output relay	Warning generated by an edge	Check the event log for an auxiliary code. Check the source of the warning corresponding to the code: 2: 33.33 Edge counter 1 source 3: 33.43 Edge counter 2 source.
A882	Motor starts	counter.  Programmable warnings:	
A883	Power ups	33.35 Edge counter 1 warn	
A884	Main contactor	message 33.45 Edge counter 2 warn message	
A885	DC charge		
A886	On-time 1 (Editable message text) Programmable warning: 33.14 On-time 1 warn message	Warning generated by on-time timer 1.	Check the source of the warning (parameter 33.13 On-time 1 source).
A887	On-time 2 (Editable message text) Programmable warning: 33.24 On-time 2 warn message	Warning generated by on-time timer 2.	Check the source of the warning (parameter 33.23 On-time 2 source).
A888	Edge counter 1 (Editable message text) Programmable warning: 33.35 Edge counter 1 warn message	Warning generated by edge counter 1.	Check the source of the warning (parameter 33.33 Edge counter 1 source).

Code (hex)	Warning	Cause	What to do
A889	Edge counter 2 (Editable message text) Programmable warning: 33.45 Edge counter 2 warn message	Warning generated by edge counter 2.	Check the source of the warning (parameter 33.43 Edge counter 2 source).
A88A	Value counter 1 (Editable message text) Programmable warning: 33.55 Value counter 1 warn message	Warning generated by value counter 1.	Check the source of the warning (parameter 33.53 Value counter 1 source).
A88B	Value counter 2 (Editable message text) Programmable warning: 33.65 Value counter 2 warn message	Warning generated by value counter 2.	Check the source of the warning (parameter 33.63 Value counter 2 source).
A88C	Device clean	Warning generated by an on-	Check the auxiliary code. Check the
A88D	DC capacitor	time timer. Programmable warnings:	source of the warning corresponding to the code:
A88E	Cabinet fan	33.14 On-time 1 warn message	0: 33.13 On-time 1 source 1: 33.23 On-time 2 source 10: 05.04 Fan on-time counter.
A88F	Cooling fan	33.24 On-time 2 warn message	
A890	Additional cooling		
A8A0	Al supervision Programmable warning: 12.03 Al supervision function	An analog signal is outside the limits specified for the analog input.	Check the auxiliary code (format XYY):  "X" specifies the location of the input (0: Al on control unit; 1: I/O extension module 1, etc). "YY" specifies the input and limit: (01: Al1 under minimum, 02: Al1 over maximum, 03: Al2 under minimum, 04: Al2 over maximum). Check signal level at the analog input. Check the wiring connection to the input. Check the minimum and maximum limits of the input in parameter group 12 Standard Al.
A8B0	Signal supervision (Editable message text) Programmable warning: 32.06 Supervision 1 action	Warning generated by the signal supervision 1 function.	Check the source of the warning (parameter 32.07 Supervision 1 signal).
A8B1	Signal supervision 2 (Editable message text) Programmable warning: 32.16 Supervision 2 action	Warning generated by the signal supervision 2 function.	Check the source of the warning (parameter 32.17 Supervision 2 signal).
A8B2	Signal supervision 3 (Editable message text) Programmable warning: 32.26 Supervision 3 action	Warning generated by the signal supervision 3 function.	Check the source of the warning (parameter 32.27 Supervision 3 signal).
A8BE	ULC overload warning Programmable fault: 37.03 ULC overload actions	Selected signal has exceeded the user overload curve.	Check for any operating conditions increasing the monitored signal (for example, the loading of the motor if the torque or current is being monitored). Check the definition of the load curve (parameter group 37 User load curve).

Code (hex)	Warning	Cause	What to do
A8BF	ULC underload warning Programmable fault: 37.04 ULC underload actions	Selected signal has fallen below the user underload curve.	Check for any operating conditions decreasing the monitored signal (for example, loss of load if the torque or current is being monitored).  Check the definition of the load curve (parameter group 37 User load curve).
A8C0	Fan service counter	A cooling fan has reached the end of its estimated lifetime. See parameters 05.41 and 05.42.	Check the auxiliary code. The code indicates which fan is to be replaced.  0: Main cooling fan  1: Auxiliary cooling fan  2: Auxiliary cooling fan 2  3: Cabinet cooling fan  4: PCB compartment fan Refer to the hardware manual of the drive for fan replacement instructions.
A981	External warning 1 (Editable message text) Programmable warning: 31.01 External event 1 source 31.02 External event 1 type	Fault in external device 1.	Check the external device. Check setting of parameter 31.01 External event 1 source.
A982	External warning 2 (Editable message text) Programmable warning: 31.03 External event 2 source 31.04 External event 2 type	Fault in external device 2.	Check the external device. Check setting of parameter 31.03 External event 2 source.
A983	External warning 3 (Editable message text) Programmable warning: 31.05 External event 3 source 31.06 External event 3 type	Fault in external device 3.	Check the external device. Check setting of parameter 31.05 External event 3 source.
A984	External warning 4 (Editable message text) Programmable warning: 31.07 External event 4 source 31.08 External event 4 type	Fault in external device 4.	Check the external device. Check setting of parameter 31.07 External event 4 source.
A985	External warning 5 (Editable message text) Programmable warning: 31.09 External event 5 source 31.10 External event 5 type	Fault in external device 5.	Check the external device. Check setting of parameter 31.09 External event 5 source.
AF80	INU-LSU comm loss Programmable warning: 60.79 INU-LSU comm loss function	DDCS (fiber optic) communication between converters (for example, the inverter unit and the supply unit) is lost. Note that the inverter unit will continue operating based on the status information that was last received from the other converter.	Check status of other converter (parameters 06.36 and 06.39). Check settings of parameter group 60 DDCS communication. Check the corresponding settings in the control program of the other converter. Check cable connections. If necessary, replace cables.

Code (hex)	Warning	Cause	What to do
AF85	Line side unit warning	The supply unit (or other converter) has generated a warning.	The auxiliary code specifies the original warning code in the supply unit control program. Refer to the firmware manual of the supply unit.
AF8C	Process PID sleep mode	The drive is entering sleep mode.	Informative warning. See section Sleep function for process PID control (page 109), and parameters 40.4140.48.
AF90	Speed controller autotuning	The speed controller autotune routine did not complete successfully.	Check the auxiliary code (format XXXX YYYY). "YYYY" indicates the problem (see actions for each code below).
	0000	The drive was stopped before the autotune routine finished.	Repeat autotune until successful.
	0001	The drive was started but was not ready to follow the autotune command.	Make sure the prerequisites of the autotune run are fulfilled. See section Before activating the autotune routine (page 87).
	0002	Required torque reference could not be reached before the drive reached maximum speed.	Decrease torque step (parameter 25.38) or increase speed step (25.39).
	0003	Motor could not accelerate/decelerate to maximum/minimum speed.	Increase torque step (parameter 25.38) or decrease speed step (25.39).
	0005	Motor could not decelerate with full autotune torque.	Decrease torque step (parameter 25.38) or speed step (25.39).
AFAA	Autoreset	A fault is about to be autoreset.	Informative warning. See the settings in parameter group <i>31 Fault functions</i> .
AFE1	Emergency stop (off2)	Drive has received an emergency stop (mode selection off2) command.	Check that it is safe to continue operation. Reset the source of the emergency stop signal (such as an emergency stop push button). Restart drive.  If the emergency stop was unintentional, check the source of the stop signal (for example, 21.05 Emergency stop source, or control word received from an external control system).
		(Follower drive in a master/follower configuration) Drive has received a stop command from the master.	Informative warning. After stopping on a ramp stop (Off1 or Off3) command, the master sends a short, 10-millisecond coast stop (Off2) command to the follower(s). The Off2 stop is stored in the event log of the follower.
AFE2	Emergency stop (off1 or off3)	Drive has received an emergency stop (mode selection off1 or off3) command.	Check that it is safe to continue operation. Reset the source of the emergency stop signal (such as an emergency stop push button). Restart the drive.  If the emergency stop was unintentional, check the source of the stop signal (for example, 21.05 Emergency stop source, or control word received from an external control system).

## 614 Fault tracing

Code (hex)	Warning	Cause	What to do
AFE7	Follower	A follower drive has tripped.	Check the event log for an auxiliary code. Add 2 to the code to find out the node address of the faulted drive. Correct the fault in the follower drive.
AFEA	Enable start signal missing (Editable message text)	No enable start signal received.	Check the setting of (and the source selected by) parameter 20.19 Enable start command.
AFEB	Run enable missing	No run enable signal is received.	Check setting of parameter 20.12 Run enable 1 source. Switch signal on (e.g. in the fieldbus Control Word) or check wiring of selected source.
AFEC	External power signal missing	95.04 Control board supply is set to External 24V but no voltage is connected to the XPOW connector of the control unit.	Check the external 24 V DC power supply to the control unit, or change the setting of parameter 95.04.
AFF6	Identification run	Motor ID run will occur at next start or is in progress.	Informative warning.
AFF7	Autophasing	Autophasing will occur at next start.	Informative warning.
B5A0	STO event Programmable event: 31.22 STO indication run/stop	Safe torque off function is active, i.e. safety circuit signal(s) connected to connector XSTO is lost.	Check safety circuit connections. For more information, see appropriate drive hardware manual and description of parameter 31.22 STO indication run/stop (page 320).
B5A2	Power up Programmable event: 96.39 Power up event logging	The drive is powered up.	Informative event.
B5A4	SW internal diagnostics	Control unit rebooted unexpectedly.	Informative event.
B686	Checksum mismatch Programmable event: 96.54 Checksum action	The calculated parameter checksum does not match any enabled reference checksum.	See A686 Checksum mismatch (page 602).

# **Application warning messages**

Code (hex)	Warning	Cause	What to do
E200	Web Loss	The processed material (web, wire or cable) may be broken.	If the material is not broken, check the settings of parameter group 81 Winder safety. Check the event log for an auxiliary code. See appropriate actions for each code below.
	1	Speed error detected by speed error watchdog is below the tripping level set with parameter 81.04 Speed error low %.	If the material is not broken, increase the tripping delay (parameter 81.09 Open-loop trip delay) and raise the speed additive (parameters 75.31 Overspeed ref offset and 75.32 Dynamic offset trim).
	2	Tension or dancer feedback signal is below the tripping level set with parameter 81.04 Speed error low %.	If the material is not broken, check the settings of parameter group 81 Winder safety.  Especially check the parameter 81.04 Speed error low % for too high value.
E210	Invalid Diameter Settings	Some diameter settings need to be corrected.	Verify the settings of parameter group 76  Diameter calculation.  Check the event log for an auxiliary code.  See appropriate actions for each code below.
	1	76.09 Full roll diameter is less than 76.08 Core diameter.	Set valid diameter values for parameters 76.08 Core diameter and 76.09 Full roll diameter.
E299	Simulation Mode	Simulation mode is active.	Take a note of that. Only passive load tests are allowed in simulation mode, so never run a machine with a real material in tension if this warning is active.

# Firmware fault messages

Code (hex)	Fault	Cause	What to do
2281	Calibration	Measured offset of output phase current measurement or difference between output phase U2 and W2 current measurement is too great (the values are updated during current calibration).	Try performing the current calibration again (select <i>Current measurement calibration</i> at parameter <i>99.13</i> ). If the fault persists, contact your local ABB representative.
2310	Overcurrent	Output current has exceeded internal fault limit.	Check motor load.  If the control unit is externally powered, check the setting of parameter 95.04  Control board supply.  Check acceleration times in parameter group 23 Speed reference ramp (speed control), 26 Torque reference chain (torque control) or 28 Frequency reference chain (frequency control). Also check parameters 46.01 Speed scaling, 46.02 Frequency scaling and 46.03  Torque scaling.  Check motor and motor cable (including phasing and delta/star connection).  Check there are no contactors opening and closing in motor cable.  Check that the start-up data in parameter group 99 corresponds to the motor rating plate.  Check that there are no power factor correction capacitors or surge absorbers in motor cable.  Check encoder cable (including phasing).  Check the auxiliary code (format XXXY YYZZ). With parallel-connected inverter modules, "Y YY" specifies through which BCU control unit channel the fault was received. "ZZ" indicates the phase that triggered the fault (0: No detailed information available, 1: U-phase, 2: V-phase, 4: W-phase, 3/5/6/7: multiple phases).

U-phase. 2: Lower branch of U-phase. 4: Upper branch of V-phase, 8: Lower branch of V-phase, 10: Upper branch of W-phase, 20: Lower branch of W-phase, other: combinations of the above). After correcting the cause of the fault, reboot the control unit (using parameter 96.08 Control board boot) or by cycling

power.

Check motor cable.

Check ambient conditions.

Check air flow and fan operation.

Check heatsink fins for dust pick-up.

Check motor power against drive power.

Excessive IGBT junction to

case temperature. This fault

protects the IGBT(s) and can

be activated by a short circuit

in the motor cable.

2330

2340

2381

IGBT overload

Code (hex)	Fault	Cause	What to do
2391	BU current difference	AC phase current difference between parallel-connected inverter modules is excessive.	Check motor cabling. Check there are no power factor correction capacitors or surge absorbers in motor cable. Check the auxiliary code (format XXXY YYZZ). "XXX" specifies the source of the first error (see "YYY"). "YYY" specifies the module through which BCU control unit channel the fault was received (1: Channel 1, 2: Channel 2, 4: Channel 3, 8: Channel 4,, 800: Channel 12, other: combinations of the above). "ZZ" indicates the phase (1: U, 2: V, 3: W).
2392	BU earth leakage	Total earth leakage of inverter modules is excessive.	Check there are no power factor correction capacitors or surge absorbers in motor cable.  Measure insulation resistances of motor cables and motor.  Contact your local ABB representative.
3130	Input phase loss	Intermediate circuit DC voltage is oscillating due to missing input power line phase or blown fuse.	Check input power line fuses. Check for loose power cable connections. Check for input power supply imbalance.
3180	Charge relay lost	No acknowledgment received from charge relay.	Contact your local ABB representative.
3181	Wiring or earth fault Programmable fault: 31.23	The drive hardware is supplied from a common DC bus.	Switch off the protection in parameter 31.23.
	Wiring or earth fault	Incorrect input power and motor cable connection (i.e. input power cable is connected to the motor connection).	Check the power connections. Check the input fuses.
		Drive has detected load unbalance typically due to earth fault in motor or motor cable.	Check there are no power factor correction capacitors or surge absorbers in motor cable. Check for an earth fault in motor or motor cables by measuring the insulation resistances of motor and motor cable. Try running the motor in scalar control mode if allowed. (See parameter 99.04 Motor control mode.)

Code (hex)	Fault	Cause	What to do
3210	DC link overvoltage	Excessive intermediate circuit DC voltage.	Check that overvoltage control is on (parameter 30.30 Overvoltage control). Check that the supply voltage matches the nominal input voltage of the drive. Check the supply line for static or transient overvoltage. Check brake chopper and resistor (if present). Check deceleration time. Use coast-to-stop function (if applicable). Retrofit drive with brake chopper and brake resistor. With parallel-connected modules, check the event log for an auxiliary code (format XXXY YYZZ). "Y YY" specifies through which BCU control unit channel the fault was received.
3220	DC link undervoltage	Intermediate circuit DC voltage is not sufficient because of a missing supply phase, blown fuse or fault in the rectifier bridge.	Check supply cabling, fuses and switchgear. With parallel-connected modules, check the event log for an auxiliary code (format XXXY YYZZ). "Y YY" specifies through which BCU control unit channel the fault was received.
3280	Standby timeout	Automatic restart failed (see section <i>Automatic restart</i> on page <i>118</i> ).	Check the condition of the supply (voltage, cabling, fuses, switchgear).
3291	BU DC link difference	Difference in DC voltages between parallel-connected inverter modules.	Check the auxiliary code (format XXXY YYZZ). "XXX" specifies the source of the first error (see "YYY"). "YYY" specifies the module through which BCU control unit channel the fault was received (1: Channel 1, 2: Channel 2, 4: Channel 3, 8: Channel 4,, 800: Channel 12).
3381	Output phase loss Programmable fault: 31.19 Motor phase loss	Motor circuit fault due to missing motor connection (all three phases are not connected).	Connect motor cable.
3385	Autophasing	Autophasing routine (see section <i>Autophasing</i> on page 101) has failed.	For more information, check the auxiliary code. Check that the motor ID run has been successfully completed. Clear parameter 98.15 Position offset user. Check the setting of parameter 99.03 Motor type.
	0001	Estimated and measured positions have opposite signs.	Check the signs of measured and estimated speeds. Reverse encoder cable phasing or edit parameter 99.16. Check that the load torque is not too high for the Turning mode (must be less than 5%).

Code (hex)	Fault	Cause	What to do
	0002	Motor is rotating during autophasing.	Check that the motor is not already rotating when the autophasing routine starts.
	0003	Too much difference between measured and estimated positions	Check that encoder is not slipping. Check parameter <i>98.15</i> several times to verify that the autophasing routine gives consistent results. Check the motor model parameters.
	0004	Rotor did not rotate as expected between zero pulses.	Check that the zero pulses are given correctly.
	0005	Position estimate did not stabilize.	Check that the selected mode (parameter <i>21.13</i> ) is appropriate for the motor.
	0006	Measured position status information changed.	Check that parameter 90.41 is not changed to <i>Estimate</i> during the routine.
	0007	General autophasing failure.	Contact your local ABB representative.
	0008	Selected mode not supported.	Check that the selected mode (parameter <i>21.13</i> ) is supported by the motor type.
	0009	(LV-Synchro) Standstill failure.	Contact your local ABB representative.
4000	Motor cable overload	Calculated motor cable temperature has exceeded warning limit.	Check the settings of parameters 35.61 and 35.62. Check the dimensioning of the motor cable in regard to required load.
4210	IGBT overtemperature	Estimated drive IGBT temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against drive power.
4290	Cooling	Drive module temperature is excessive.	Check ambient temperature. If it exceeds 40 °C (104 °F), ensure that load current does not exceed derated load capacity of drive. See appropriate <i>Hardware manual</i> . Check drive module cooling air flow and fan operation.  Check inside of cabinet and heatsink of drive module for dust pick-up. Clean whenever necessary.
42F1	IGBT temperature	Drive IGBT temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against drive power.
4310	Excess temperature	Power unit module temperature is excessive.	See A4B0 Excess temperature (page 599).
4380	Excess temperature difference	High temperature difference between the IGBTs of different phases.	See A4B1 Excess temperature difference (page 599).

Code (hex)	Fault	Cause	What to do
4981	External temperature 1 (Editable message text)	Measured temperature 1 has exceeded fault limit.	Check the value of parameter 35.02  Measured temperature 1.  Check the cooling of the motor (or other equipment whose temperature is being measured).  Check the value of parameter 35.12  Temperature 1 fault limit.
4982	External temperature 2 (Editable message text)	Measured temperature 2 has exceeded fault limit.	Check the value of parameter 35.03  Measured temperature 2.  Check the cooling of the motor (or other equipment whose temperature is being measured).  Check the value of parameter 35.22  Temperature 2 fault limit.
4990	FPTC not found	A thermistor protection module has been activated by parameter 35.30 but cannot be detected.	Power down the control unit and check that the module is properly inserted in the correct slot.  The last digit of the auxiliary code identifies the slot.
4991	Safe motor temperature 1 (Editable message text)	The thermistor protection module installed in slot 1 indicates overtemperature.	Check the cooling of the motor. Check the motor load and drive ratings. Check the wiring of the temperature
4992	Safe motor temperature 2 (Editable message text)	The thermistor protection module installed in slot 2 indicates overtemperature.	sensor. Repair wiring if faulty.  Measure the resistance of the sensor.  Replace sensor if faulty.
4993	Safe motor temperature 3 (Editable message text)	The thermistor protection module installed in slot 3 indicates overtemperature.	
5080	Fan Programmable warning: 31.35 Main fan fault function	Cooling fan stuck or disconnected.	See <i>A581 Fan</i> (page <i>600</i> ).
5081	Auxiliary fan broken Programmable warning: 31.36 Aux fan fault function	An auxiliary cooling fan (connected to the fan connectors on the control unit) is stuck or disconnected.	See A582 Auxiliary fan not running (page 600).
5090	STO hardware failure	Safe torque off hardware failure.	Contact your local ABB representative, quoting the auxiliary code. The code contains location information, especially with parallel-connected inverter modules. When converted into a 32-bit binary number, the bits of the code indicate the following:  3128: Number of faulty inverter module (011 decimal). 1111: STO_ACT states of control unit and inverter modules in conflict  27: STO_ACT state of inverter modules in conflict  27: STO_ACT state of control unit  26: STO_ACT state of control unit  25: STO1 of control unit  24: STO2 of control unit  2312: STO1 of inverter modules 121 (Bits of non-existing modules set to 1)

Code (hex)	Fault	Cause	What to do
5091	Safe torque off Programmable fault: 31.22 STO indication run/stop	Safe torque off function is active, i.e. safety circuit signal(s) connected to connector XSTO is broken during start or run.	Check safe torque off circuit connections. For more information, see appropriate drive hardware manual and description of parameter 31.22 STO indication run/stop (page 320).
5092	PU logic error	Power unit memory has cleared.	Cycle the power to the drive. If the control unit is externally powered, also reboot the control unit (using parameter 96.08 Control board boot) or by cycling its power. If the problem persists, contact your local ABB representative.
5093	Rating ID mismatch	The hardware of the drive does not match the information stored in the memory unit. This may occur e.g. after a firmware update or memory unit replacement.	Cycle the power to the drive. Check the auxiliary code. The auxiliary code categories are as follows:  1 = PU and CU ratings not the same. Rating ID has changed.  2 = Parallel connection rating ID has changed.  3 = PU types not the same in all power units.  4 = Parallel connection rating ID is active in a single power unit setup.  5 = It is not possible to implement the selected rating with the current PUs.  6 = PU rating ID is 0.  7 = Reading PU rating ID or PU type failed on PU connection.  8 = PU not supported (illegal rating ID).  9 = Incompatible module current rating (unit contains a module with too low a current rating).  10 = Selected parallel rating ID not found from database.  With parallel connection faults, the format of the auxiliary code is 0X0Y. "Y" indicates the auxiliary code category, "X" indicates the first faulty PU channel in hexadecimal (1C). (With a ZCU control unit, "X" can be 1 or 2 but this is irrelevant to the fault.)
5094	Measurement circuit temperature	Problem with internal temperature measurement of the drive.	See A5EA Measurement circuit temperature (page 601).

Code (hex)	Fault	Cause	What to do
5695	Reduced run	Number of inverter modules detected does not match the value of parameter 95.13 Reduced run mode.	Check that the value of 95.13 Reduced run mode corresponds to the number of inverter modules present. Check that the modules present are powered from the DC bus and connected by fiber optic cables to the BCU control unit.  If all modules of the inverter unit are in fact available (eg. maintenance work has been completed), check that parameter 95.13 is set to 0 (reduced run function disabled).
5696	PU state feedback	State feedback from output phases does not match control signals.	Contact your local ABB representative quoting the auxiliary code.
5697	Charging feedback	The charging switch and DC switch were operated out of sequence, or a start command was issued before the unit was ready.	<ol> <li>The normal power-up sequence is:</li> <li>Close charging switch.</li> <li>After charging finishes (charging OK lamp lights), close DC switch.</li> <li>Open charging switch.</li> </ol>
		Charging circuit fault.	Check the charging circuit. With a frame R6i/R7i inverter module, the auxiliary code "FA" indicates that the charging contactor status feedback does not match the control signal. With parallel-connected frame R8i modules, the auxiliary code (format XX00), "XX" specifies the affected BCU control unit channel.
		Brake circuit fault	Check the wiring condition of brake resistor.
5698	Unknown power unit fault	Unidentified power unit logic fault.	Check power unit logic and firmware compatibility. Contact your local ABB representative.
6000	Internal SW error	Internal error.	Contact your local ABB representative quoting the auxiliary code.
6181	FPGA version incompatible	Firmware and FPGA file version in the power unit are incompatible.	Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power. If the problem persists, contact your local ABB representative.
6200	Checksum mismatch Programmable fault: 96.54 Checksum action	The calculated parameter checksum does not match any enabled reference checksum.	See A686 Checksum mismatch (page 602).
6306	FBA A mapping file	Fieldbus adapter A mapping file read error.	Contact your local ABB representative.
6307	FBA B mapping file	Fieldbus adapter B mapping file read error.	Contact your local ABB representative.
6481	Task overload	Internal fault.	Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power. If the problem persists, contact your local ABB representative.

Code (hex)	Fault	Cause	What to do
6487	Stack overflow	Internal fault.	Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power. If the problem persists, contact your local ABB representative.
64A1	Internal file load	File read error.	Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power. If the problem persists, contact your local ABB representative.
64A2	Internal record load	Internal record load error.	Contact your local ABB representative.
64A3	Application loading	Application file incompatible or corrupted.	Check the auxiliary code. See actions for each code below.
	8006	Not enough memory for the application.	
	8007	The application contains the wrong library version.	
	800A	The application contains an unknown target (system) library function.	
64A5	Licensing fault	Running the control program is prevented either because a restrictive license exists, or because a required license is missing.	Record the auxiliary codes of all active licensing faults and contact your product vendor for further instructions.
64A6	Adaptive program	Error running the adaptive program.	Check the auxiliary code (format XXXX YYYY). "XXXX" specifies the number of the function block ( <b>0000</b> = generic error). "YYYY" indicates the problem (see actions for each code below).
	000A	Program corrupted or block non-existent	Restore the template program or download the program to the drive.
	000C	Required block input missing	Check the inputs of the block.
	000E	Program corrupted or block non-existent	Restore the template program or download the program to the drive.
	0011	Program too large.	Remove blocks until the error stops.
	0012	Program is empty.	Correct the program and download it to the drive.
	001C	A non existing parameter or block is used in the program.	Edit the program to correct the parameter reference, or to use an existing block.
	001D	Parameter type invalid for selected pin.	Edit the program to correct the parameter reference.
	001E	Output to parameter failed because the parameter was write-protected.	Check the parameter reference in the program. Check for other sources affecting the target parameter.
	0023	Program file incompatible with	Adapt the program to current block
	0024	current firmware version.	library and firmware version.
	Other	_	Contact your local ABB representative, quoting the auxiliary code.

Code (hex)	Fault	Cause	What to do
64B0	Memory unit detached	The memory unit was detached when the control unit was powered.	Switch off the power to the control unit and reinstall the memory unit.  In case the memory unit was not actually removed when the fault occurred, check that the memory unit is properly inserted into its connector and its mounting screw is tight. Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power. If the problem persists, contact your local ABB representative.
64B1	Internal SSW fault	Internal fault.	Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power. If the problem persists, contact your local ABB representative.
64B2	User set fault	Loading of user parameter set failed because  • set is not compatible with control program  • drive was switched off during loading.	Ensure that a valid user parameter set exists. Reload if uncertain.
64E1	Kernel overload	Operating system error.	Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power. If the problem persists, contact your local ABB representative.
64FF	Fault reset	Informative fault.	An active fault has been reset.
6581	Parameter system	Parameter load or save failed.	Try forcing a save using parameter 96.07  Parameter save manually. Retry.
65A1	FBA A parameter conflict	The drive does not have a functionality requested by PLC, or requested functionality has not been activated.	Check PLC programming. Check settings of parameter groups 50 Fieldbus adapter (FBA) and 51 FBA A settings.
65A2	FBA B parameter conflict	The drive does not have a functionality requested by PLC, or requested functionality has not been activated.	Check PLC programming. Check settings of parameter groups 50 Fieldbus adapter (FBA) and 54 FBA B settings.
65B1	Reference source parametrization	A reference source is simultaneously connected to multiple parameters with different units.	See A6DA Reference source parametrization (page 603).
6681	EFB comm loss Programmable fault: 58.14 Communication loss action	Communication break in embedded fieldbus (EFB) communication.	Check the status of the fieldbus master (online/offline/error, etc.). Check cable connections to the XD2D connector on the control unit.
6682	EFB config file	Embedded fieldbus (EFB) configuration file could not be read.	Contact your local ABB representative.
6683	EFB invalid parameterization	Embedded fieldbus (EFB) parameter settings inconsistent or not compatible with selected protocol.	Check the settings in parameter group 58 Embedded fieldbus.

Code (hex)	Fault	Cause	What to do
6684	EFB load fault	Embedded fieldbus (EFB) protocol firmware could not be loaded.	Contact your local ABB representative.
		Version mismatch between EFB protocol firmware and drive firmware.	
6881	Text data overflow	Internal fault.	Reset the fault. Contact your local ABB representative if the fault persists.
6882	Text 32-bit table overflow	Internal fault.	Reset the fault. Contact your local ABB representative if the fault persists.
6883	Text 64-bit table overflow	Internal fault.	Reset the fault. Contact your local ABB representative if the fault persists.
6885	Text file overflow	Internal fault.	Reset the fault. Contact your local ABB representative if the fault persists.
7080	Option module comm loss	Communication between drive and an option module is lost.	See A798 Encoder option comm loss (page 605).
7081	Control panel loss Programmable fault: 49.05 Communication loss action	Control panel or PC tool selected as active control location for drive has ceased communicating.	Check PC tool or control panel connection. Check control panel connector. Disconnect and reconnect the control panel. Check the auxiliary code. The code specifies the I/O port used as follows: 0: Panel, 1: Fieldbus interface A, 2: Fieldbus interface B, 3: Ethernet, 4: D2D/EFB port)
7082	Ext I/O comm loss Programmable fault: 31.55 Ext I/O comm loss event	The I/O extension module types specified by parameters do not match the detected configuration.	See A799 Ext I/O comm loss (page 606).
7083	Panel reference conflict	Use of saved control panel reference in multiple control modes attempted.	The control panel reference can only be saved for one reference type at a time. Consider the possibility of using a copied reference instead of saved reference (see the reference selection parameter).
7084	Panel/PC tool version conflict	The current version of the control panel and/or PC tool does not support a function. (For example, older panel versions cannot be used as a source of external reference.)	Update control panel and/or PC tool. Contact your local ABB representative if necessary.
7085	Incompatible option module	Option module not supported. (For example, type Fxxx-xx-M fieldbus adapter modules are not supported.)	Check the auxiliary code. The code specifies the interface to which the unsupported module is connected:  1: Fieldbus interface A, 2: Fieldbus interface B.  Replace the module with a supported type.
7121	Motor stall Programmable fault: 31.24 Stall function	Motor is operating in stall region because of e.g. excessive load or insufficient motor power.	Check motor load and drive ratings. Check fault function parameters.

Code (hex)	Fault	Cause	What to do
7122	Motor overload Programmable fault: 35.56 Motor overload action	Motor current is too high.	Check for overloaded motor. Adjust the parameters used for the motor overload function 35.5135.53 and 35.5535.56.
7181	Brake resistor	DC overvoltage detected during braking.	Check that a brake resistor has been connected. Check the condition of the brake resistor. Check the dimensioning of the brake chopper and resistor.
7183	BR excess temperature	Brake resistor temperature has exceeded fault limit defined by parameter 43.11 Brake resistor fault limit.	Stop drive. Let resistor cool down. Check resistor overload protection function settings (parameter group 43 Brake chopper). Check fault limit setting, parameter 43.11 Brake resistor fault limit. Check that braking cycle meets allowed limits.
7184	Brake resistor wiring	Brake resistor short circuit or brake chopper control fault.	Check brake chopper and brake resistor connection.  Ensure brake resistor is not damaged.  After correcting the cause of the fault, reboot the control unit (using parameter 96.08 Control board boot) or by cycling power.
7191	BC short circuit	Short circuit in brake chopper IGBT.	Ensure brake resistor is connected and not damaged. Check the electrical specifications of the brake resistor against the <i>Hardware manual</i> . Replace brake chopper (if replaceable). After correcting the cause of the fault, reboot the control unit (using parameter 96.08 Control board boot) or by cycling power.
7192	BC IGBT excess temperature	Brake chopper IGBT temperature has exceeded internal fault limit.	Let chopper cool down. Check for excessive ambient temperature. Check for cooling fan failure. Check for obstructions in the air flow. Check the dimensioning and cooling of the cabinet. Check resistor overload protection function settings (parameter group 43 Brake chopper). Check that braking cycle meets allowed limits. Check that drive supply AC voltage is not excessive.
71A2	Mechanical brake closing failed Programmable fault: 44.17 Brake fault function	Mechanical brake control fault. Activated e.g. if brake acknowledgement is not as expected during brake closing.	Check mechanical brake connection. Check mechanical brake settings in parameter group 44 Mechanical brake control. Check that acknowledgement signal matches actual status of brake.

Code (hex)	Fault	Cause	What to do
71A3	Mechanical brake opening failed Programmable fault: 44.17 Brake fault function	Mechanical brake control fault. Activated e.g. if brake acknowledgement is not as expected during brake opening.	Check mechanical brake connection. Check mechanical brake settings in parameter group 44 Mechanical brake control. Check that acknowledgement signal matches actual status of brake.
71A5	Mechanical brake opening not allowed Programmable fault: 44.17 Brake fault function	Open conditions of mechanical brake cannot be fulfilled (for example, brake has been prevented from opening by parameter 44.11 Keep brake closed).	Check mechanical brake settings in parameter group 44 Mechanical brake control (especially 44.11 Keep brake closed).  Check that acknowledgement signal (if used) matches actual status of brake.
		In an encoder-less application, the brake is kept closed by a brake close request (either from parameter 44.12 Brake close request or from an FSO-xx safety functions module) against a modulating drive for longer than 5 seconds.	Check the source signal selected by parameter 44.12 Brake close request. Check the safety circuits connected to the FSO-xx safety functions module.
71B1	Motor fan Programmable fault: 35.106 DOL starter event type	No feedback received from external fan.	Check external fan (or other equipment controlled) by the logic. Check settings of parameters 35.10035.106.
7301	Motor speed feedback Programmable fault: 90.45 Motor feedback fault	No motor speed feedback received.	See A7B0 Motor speed feedback (page 608).
7310	Overspeed	Motor is turning faster than highest allowed speed due to incorrectly set minimum/maximum speed, insufficient braking torque or changes in load when using torque reference.	Check minimum/maximum speed settings, parameters 30.11 Minimum speed, 30.12 Maximum speed and 30.30 Overspeed trip margin. Check adequacy of motor braking torque. Check applicability of torque control. Check need for brake chopper and resistor(s).
		Incorrect estimated speed.	Check the status of motor current measurement.  Perform a Normal, Advanced or Advanced Standstill ID run instead of, for example, a Reduced or Standstill ID run. See parameter 99.13 ID run requested (page 528).
7380	Encoder internal	Internal fault.	Contact your local ABB representative.
7381	Encoder Programmable fault: 90.45 Motor feedback fault	Encoder feedback fault.	See A7E1 Encoder (page 609).
73A0	Speed feedback configuration	Speed feedback configuration incorrect.	See A797 Speed feedback configuration (page 605).

Code (hex)	Fault	Cause	What to do
73A1	Load feedback Programmable warning: 90.55 Load feedback fault	No load position feedback received.	Check the auxiliary code (format XXYY ZZZZ). "XX" specifies the number of the encoder interface module (01: 91.11/91.12, 02: 91.13/91.14), "YY" specifies the encoder (01: 92 Encoder 1 configuration, 02: 93 Encoder 2 configuration). "ZZZZ" indicates the problem (see actions for each code below).
	0001	Load gear definition invalid or outside limits.	Check load gear settings (90.53 and 90.54).
	0002	Feed constant definition invalid or outside limits.	Check feed constant settings (90.63 and 90.64).
	0003	Motor/load gear definition invalid or outside limits.	Check motor/load gear settings (90.61 and 90.62).
	0004	Encoder not configured.	Check encoder settings (92 Encoder 1 configuration or 93 Encoder 2 configuration).  Use parameter 91.10 Encoder parameter refresh) to validate any changes in the settings.
	0005	Encoder stopped working.	Check encoder status.
73B0	Emergency ramp failed	Emergency stop did not finish within expected time.	Check the settings of parameters 31.32  Emergency ramp supervision and 31.33  Emergency ramp supervision delay.  Check the predefined ramp times (23.1123.19 for mode Off1, 23.23 for mode Off3).
73B1	Stop failed	Ramp stop did not finish within expected time.	Check the settings of parameters 31.37 Ramp stop supervision and 31.38 Ramp stop supervision delay. Check the predefined ramp times in parameter group 23 Speed reference ramp.
7510	FBA A communication Programmable fault: 50.02 FBA A comm loss func	Cyclical communication between drive and fieldbus adapter module A or between PLC and fieldbus adapter module A is lost.	Check status of fieldbus communication. See user documentation of fieldbus interface. Check settings of parameter groups 50 Fieldbus adapter (FBA), 51 FBA A settings, 52 FBA A data in and 53 FBA A data out. Check cable connections. Check if communication master is able to communicate.
7520	FBA B communication Programmable fault: 50.32 FBA B comm loss func	Cyclical communication between drive and fieldbus adapter module B or between PLC and fieldbus adapter module B is lost.	Check status of fieldbus communication. See user documentation of fieldbus interface. Check settings of parameter group 50 Fieldbus adapter (FBA). Check cable connections. Check if communication master is able to communicate.

Code (hex)	Fault	Cause	What to do
7581	DDCS controller comm loss Programmable fault: 60.59 DDCS controller comm loss function	DDCS (fiber optic) communication between drive and external controller is lost.	Check status of controller. See user documentation of controller. Check settings of parameter group 60 DDCS communication. Check cable connections. If necessary, replace cables.
7582	MF comm loss Programmable fault: 60.09 M/F comm loss function	Master/follower communication is lost.	See A7CB MF comm loss (page 609).
7583	Line side unit faulted	The supply unit (or other converter) connected to the inverter unit has generated a fault.	The auxiliary code specifies the original fault code in the supply unit control program. See section <i>Auxiliary codes for line-side converter faults</i> (page 638).
7584	LSU charge failed	The supply unit was not ready (ie. the main contactor/breaker could not be closed) within expected time.	Check that communication to the supply unit has been activated by 95.20 HW options word 1.  Check setting of parameter 94.10 LSU max charging time.  Check that the supply unit is enabled, allowed to start, and can be controlled by the inverter unit (eg. not in local control mode).
8001	ULC underload fault Programmable fault: 37.04 ULC underload actions	Selected signal has fallen below the user underload curve.	See A8BF ULC underload warning (page 612).
8002	ULC overload fault Programmable fault: 37.03 ULC overload actions	Selected signal has exceeded the user overload curve.	See A8BE ULC overload warning (page 611).
80A0	Al supervision Programmable fault: 12.03 Al supervision function	An analog signal is outside the limits specified for the analog input.	Check the auxiliary code (format XXXX XYZZ). "Y" specifies the location of the input (0: Control unit, 1: I/O extension module 1, 2: I/O extension module 2, 3: I/O extension module 3). "ZZ" specifies the limit (01: Al1 under minimum, 02: Al1 above maximum, 03: Al2 under minimum, 04: Al2 above maximum). Check signal level at the analog input. Check the wiring connected to the input. Check the minimum and maximum limits of the input in parameter group 12 Standard AI.
80B0	Signal supervision (Editable message text) Programmable fault: 32.06 Supervision 1 action	Fault generated by the signal supervision 1 function.	Check the source of the fault (parameter 32.07 Supervision 1 signal).
80B1	Signal supervision 2 (Editable message text) Programmable fault: 32.16 Supervision 2 action	Fault generated by the signal supervision 2 function.	Check the source of the fault (parameter 32.17 Supervision 2 signal).
80B2	Signal supervision 3 (Editable message text) Programmable fault: 32.26 Supervision 3 action	Fault generated by the signal supervision 3 function.	Check the source of the fault (parameter 32.27 Supervision 3 signal).

Code (hex)	Fault	Cause	What to do
9081	External fault 1 (Editable message text) Programmable fault: 31.01 External event 1 source 31.02 External event 1 type	Fault in external device 1.	Check the external device. Check setting of parameter 31.01 External event 1 source.
9082	External fault 2 (Editable message text) Programmable fault: 31.03 External event 2 source 31.04 External event 2 type	Fault in external device 2.	Check the external device. Check setting of parameter 31.03 External event 2 source.
9083	External fault 3 (Editable message text) Programmable fault: 31.05 External event 3 source 31.06 External event 3 type	Fault in external device 3.	Check the external device. Check setting of parameter 31.05 External event 3 source.
9084	External fault 4 (Editable message text) Programmable fault: 31.07 External event 4 source 31.08 External event 4 type	Fault in external device 4.	Check the external device. Check setting of parameter 31.07 External event 4 source.
9085	External fault 5 (Editable message text) Programmable fault: 31.09 External event 5 source 31.10 External event 5 type	Fault in external device 5.	Check the external device. Check setting of parameter 31.09 External event 5 source.
B680	SW internal diagnostics	SW internal malfunction.	Contact your local ABB representative, quoting the auxiliary code.
FA81	Safe torque off 1 loss	Safe torque off function is active, i.e. STO circuit 1 is broken.	Check safety circuit connections. For more information, see appropriate drive hardware manual and description of
FA82	Safe torque off 2 loss	Safe torque off function is active, i.e. STO circuit 2 is broken.	parameter 31.22 STO indication run/stop (page 320). Check the auxiliary code, The code contains location information, especially with parallel-connected inverter modules. When converted into a 32-bit binary number, the bits of the code indicate the following: 3128: Number of faulty inverter module (011 decimal). 1111: STO_ACT states of control unit and inverter modules in conflict 27: STO_ACT state of inverter modules 26: STO_ACT state of control unit 25: STO1 of control unit 24: STO2 of control unit 2312: STO1 of inverter modules 121 (Bits of non-existing modules set to 1) 110: STO2 of inverter modules set to 1)
FA90	STO diagnostics failure	SW internal malfunction.	Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power.

Code (hex)	Fault	Cause	What to do
FB11	Memory unit missing	No memory unit is attached to the control unit.	Power down the control unit. Check that the memory unit is properly inserted into the control unit.
		The memory unit attached to the control unit is empty.	Power down the control unit. Attach a memory unit (with the appropriate firmware) to the control unit.
FB12	Memory unit incompatible	The memory unit attached to the control unit is incompatible.	Power down the control unit. Attach a compatible memory unit.
FB13	Memory unit FW incompatible	The firmware on the attached memory unit is incompatible with the drive.	Power down the control unit. Attach a memory unit with compatible firmware.
FB14	Memory unit FW load failed	The memory unit is empty, or contains incompatible or corrupted firmware.	Power down the control unit. Check that the memory unit is properly inserted into the control unit. Check that the firmware is compatible with the drive and control unit type. If the problem persists, replace the memory unit.
FF61	ID run	Motor ID run was not completed successfully.	Check the nominal motor values in parameter group 99 Motor data. Check that no external control system is connected to the drive. Cycle the power to the drive (and its control unit, if powered separately). Check that the motor shaft is not locked. Check the event log for an auxiliary code. The second number of the code indicates the problem (see actions for each code below).
	0001	Maximum current limit too low.	Check settings of parameters 99.06  Motor nominal current and 30.17  Maximum current. Make sure that 30.17 > 99.06.  Check that the drive is dimensioned correctly according to the motor.
	0002	Maximum speed limit or calculated field weakening point too low.	Check settings of parameters  • 30.11 Minimum speed  • 30.12 Maximum speed  • 99.07 Motor nominal voltage  • 99.08 Motor nominal frequency  • 99.09 Motor nominal speed.  Make sure that  • 30.12 > (0.55 × 99.09) > (0.50 × synchronous speed)  • 30.11 ≤ 0, and  • supply voltage ≥ (0.66 × 99.07).
	0003	Maximum torque limit too low.	Check settings of parameter 99.12 Motor nominal torque, and the torque limits in group 30 Limits.  Make sure that the maximum torque limit in force is greater than 100%.

Code (hex)	Fault	Cause	What to do
	0004	Current measurement calibration did not finish within reasonable time.	Contact your local ABB representative.
	00050008	Internal error.	Contact your local ABB representative.
	0009	(Asynchronous motors only) Acceleration did not finish within reasonable time.	Contact your local ABB representative.
	000A	(Asynchronous motors only) Deceleration did not finish within reasonable time.	Contact your local ABB representative.
	000B	(Asynchronous motors only) Speed dropped to zero during ID run.	Contact your local ABB representative.
	000C	(Permanent magnet motors only) First acceleration did not finish within reasonable time.	Contact your local ABB representative.
	000D	(Permanent magnet motors only) Second acceleration did not finish within reasonable time.	Contact your local ABB representative.
	000E0010	Internal error.	Contact your local ABB representative.
FF7E	Follower	A follower drive has tripped.	Check the event log for an auxiliary code. Add 2 to the code for finding the node address of the faulted drive. Correct the fault in the follower drive.
FF81	FB A force trip	A fault trip command has been received through fieldbus adapter A.	Check the fault information provided by the PLC.
FF82	FB B force trip	A fault trip command has been received through fieldbus adapter B.	Check the fault information provided by the PLC.
FF8E	EFB force trip	A fault trip command has been received through the embedded fieldbus interface.	Check the fault information provided by the Modbus controller.

# **Application fault messages**

Code (hex)	Fault	Cause	What to do
E100	Web Loss	The processed material (web, wire or cable) may be broken.	If the material is not broken, check the settings of parameter group 81 Winder safety.  Check the event log for an auxiliary code. See appropriate actions for each code below.
	1	Speed error detected by speed error watchdog is below the tripping level set with parameter 81.04 Speed error low %.	If the material is not broken, increase the overspeed settings in parameter group 75 Winder speed settings (parameters 75.31 Overspeed ref offset and 75.32 Dynamic offset trim).
	2	Tension or dancer feedback signal is below the tripping level set with parameter 81.04 Speed error low %.	If the material is not broken, check the settings of parameter group 81 Winder safety.  Especially check the parameter 81.04 Speed error low % for too high value.

# Auxiliary codes for line-side converter warnings

The table below lists the auxiliary codes of *AF85 Line side unit warning*. For advanced troubleshooting, see the firmware manual of the line converter.

Code (hex)	Warning / Aux. code	Cause	What to do
AE01	Overcurrent	Output current has exceeded internal fault limit.	Check supply voltage. Check that there are no power factor correction capacitors or surge absorbers in supply cable. Check motor load and acceleration times. Check power semiconductors (IGBTs) and current transducers.
AE02	Earth leakage Programmable warning: 31.120 LSU earth fault	IGBT supply has detected load unbalance.	Check AC fuses. Check for earth leakages. Check supply cabling. Check power modules. Check there are no power factor correction capacitors or surge absorbers in supply cable.
AE04	IGBT overload	Excessive IGBT junction to case temperature.	Check supply cable.
AE05	BU current difference	Current difference detected by the branching unit (BU).	Check converter fuses. Check converter(s). Check inverter(s). Check LCL filter.
AE06	BU earth leakage	Earth leakage detected by the branching unit: sum of all currents exceeds the level.	Check AC fuses. Check for earth leakages. Check supply cabling. Check power modules. Check there are no power factor correction capacitors or surge absorbers in supply cable.
AE09	DC link overvoltage	Excessive intermediate circuit DC voltage.  Note: This warning can be shown only when the IGBT supply unit is not modulating.	Check that parameter 95.01 Supply voltage is set according to the supply voltage in use.
AE0A	DC link undervoltage	Intermediate circuit DC voltage is not sufficient due to missing phase in supply voltage, blown fuse or rectifier bridge internal fault.  Note: This warning can be shown only when the IGBT supply unit is not modulating.	Check supply and fuses. Check that parameter 95.01 Supply voltage is set according to the supply voltage in use.
AE0B	DC not charged	The voltage of the intermediate DC circuit has not yet risen to operating level.	Check the input voltage setting in parameter 95.01 Supply voltage. Check the input voltage. If the problem persists, contact your local ABB representative.

Code (hex)	Warning / Aux. code	Cause	What to do
AE0C	BU DC link difference	DC link voltage difference detected by the branching unit.	Check DC fuses. Check converter module connections to DC link.
AE0D	BU voltage difference	Main voltage difference detected by the branching unit.	Check AC fuses. Check supply cable.
AE14	Excess temperature	Power unit module temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against IGBT supply unit power.
AE15	Excess temperature difference	High temperature difference between the IGBTs of different phases.	Check the cabling. Check cooling of power module(s).
AE16	IGBT temperature	IGBT temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against IGBT supply unit power.
AE24	Voltage category unselected	The supply voltage range has not been defined.	Define the supply voltage range (parameter 95.01 Supply voltage).
AE5F	Temperature Warning	Supply module temperature is excessive due to eg, module overload or fan failure.	Check module cooling air flow and fan operation. Check ambient temperature. If it exceeds 40 °C (104 °F), ensure that load current does not exceed derated load capacity. See appropriate hardware manual. Check inside of cabinet and heatsink of supply module for dust pick-up. Clean whenever necessary.
AE73	Fan	Cooling fan is stuck or disconnected.	Check the auxiliary code in the line-side converter program to identify the fan. Check fan operation and connection. Replace fan if faulty.
AE78	Net lost	Net lost is detected.	Resynchronize the IGBT supply unit to the grid after net lost.
AE85	Charging count	There are too many DC link charging attempts.	Two attempts in five minutes is allowed to prevent charging circuit overheating.

# **Auxiliary codes for line-side converter faults**

The table below lists the auxiliary codes of *7583 Line side unit faulted*. For advanced troubleshooting, see the firmware manual of the line converter.

Code (hex)	Fault / Aux. code	Cause	What to do
2E00	Overcurrent	Output current has exceeded internal fault limit.	Check supply voltage. Check that there are no power factor correction capacitors or surge absorbers in supply cable. Check motor load and acceleration times. Check power semiconductors (IGBTs) and current transducers.
2E01	Earth leakage Programmable fault: 31.120 LSU earth fault	IGBT supply unit has detected an earth fault.	Check AC fuses. Check for earth leakages. Check supply cabling. Check power modules. Check there are no power factor correction capacitors or surge absorbers in supply cable. If no earth fault can be detected, contact your local ABB representative.
2E02	Short circuit	IGBT supply unit has detected short circuit.	Check supply cable. Check there are no power factor correction capacitors or surge absorbers in supply cable. After correcting the cause of the fault, reboot the control unit (using parameter 96.06 Control board boot) or by cycling power.
2E04	IGBT overload	Excessive IGBT junction to case temperature.	Check the load.
2E05	BU current difference	Current difference detected by the branching unit (BU).	Check converter fuses. Check converter(s). Check inverter(s). Check LCL filter. Power off all boards. If the fault persists, contact your local ABB representative.
2E06	BU earth leakage	Earth leakage detected by the branching unit: sum of all currents exceeds the level.	Check AC fuses. Check for earth leakages. Check supply cabling. Check power modules. Check there are no power factor correction capacitors or surge absorbers in supply cable. If no earth fault can be detected, contact your local ABB representative.

Code (hex)	Fault / Aux. code	Cause	What to do
3E00	Input phase loss Programmable fault: 31.120 LSU earth fault	Input phase loss detected by the IGBT bridge.	Check the auxiliary code. Check the source of the fault corresponding to the code:  1: Phase A  2: Phase B  4: Phase C  8: Phase cannot be detected Check the AC fuses. Check for input power supply imbalance.
3E04	DC link overvoltage	Excessive intermediate circuit DC voltage.	Check that parameter 95.01 Supply voltage is set according to the supply voltage in use.
3E05	DC link undervoltage	Intermediate circuit DC voltage is not sufficient because of a missing supply phase or blown fuse.	Check supply cabling, fuses and switchgear. Check that parameter 95.01 Supply voltage is set according to the supply voltage in use.
3E06	BU DC link difference	Difference in DC voltages between parallel-connected supply modules.	Check the DC fuses. Check the connection to the DC bus. If the problem persists, contact your local ABB representative.
3E07	BU voltage difference	Difference in main voltages between parallel-connected supply modules.	Check the supply network connections. Check the AC fuses. If the problem persists, contact your local ABB representative.
3E08	LSU charging	DC link voltage is not high enough after charging.	Check parameter 95.01 Supply voltage. Check supply voltage and fuses. Check the connection from the relay output to the charging contactor. Check that the DC voltage measuring circuit is working correctly.
4E01	Cooling	Power module temperature is excessive.	Check ambient temperature. If it exceeds 40 °C (104 °F), ensure that load current does not exceed derated load capacity. See appropriate hardware manual. Check power module cooling air flow and fan operation.  Check inside of cabinet and heatsink of power module for dust pick-up. Clean whenever necessary.
4E02	IGBT temperature	IGBT temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against IGBT supply unit power.
4E03	Excess temperature	Power unit module temperature is excessive.	See AE14 Excess temperature (page 637).

Code (hex)	Fault / Aux. code	Cause	What to do
4E04	Excess temperature difference	High temperature difference between the IGBTs of different phases. The amount of available temperatures depends on the frame size.	See AE15 Excess temperature difference (page 637).
4E06	Cabinet or LCL overtemperature	Overtemperature detected either in cabinet, LCL filter or auxiliary transformer.	Check the cooling of the cabinet, LCL filter and auxiliary transformer.
5E05	Rating ID mismatch	The hardware of the supply unit does not match the information stored in the memory unit. This may occur eg, after a firmware update or memory unit replacement.	Cycle the power to the supply unit. If the control unit is externally powered, reboot the control unit (using parameter 96.108 LSU control board boot) or by cycling its power.  If the problem persists, contact your local ABB representative.
5E06	Main contactor Fault	Control program does not receive main contactor on (1) acknowledgement through digital input even control program has closed the contactor control circuit with relay output.  Main contactor / main breaker is not functioning properly, or there is a loose / bad connection.	Check main contactor / main breaker control circuit wiring. Check the status of other switches connected to contactor control circuit. See the delivery-specific circuit diagrams. Check main contactor operating voltage level (should be 230 V). Check digital input DI3 connections.
6E19	Synchronization fault	Synchronization to supply network has failed.	Monitor possible network transients.
6E1A	Rating ID fault	Rating ID load error.	Contact your local ABB representative.
6E1F	Licensing fault	There are two types of licenses being used in ACS880 drives: licenses that need to be found from the unit which allow the firmware to be executed, and licenses that prevent the firmware from running. The license is indicated by the value of the auxiliary code field. The license is Nxxxx, where xxxx is indicated by the 4-digit value of the auxiliary code field.	Check the line-converter control program. Record the auxiliary codes of all active licensing faults and contact your product vendor for further instructions. This fault requires a reboot of the control unit either by switching the power off and on, or using parameter 96.108 LSU control board boot.
	8201	A restrictive license is found from the unit. The firmware on this supply unit cannot be executed because a Low harmonic license is found from the unit. This unit is meant to be used with IGBT supply control program (2Q) only.	Contact your product vendor for further instructions.
7E01	Panel loss	Control panel or PC tool selected as active control location has ceased communicating.	Check PC tool or control panel connection. Check control panel connector. Replace control panel in mounting platform.

Code (hex)	Fault / Aux. code	Cause	What to do
8E07	Net lost	Net lost is detected. Duration of net lost is too long.	Resynchronize the IGBT supply unit to the grid after net lost.

# Fieldbus control through the embedded fieldbus interface (EFB)

#### What this chapter contains


The chapter describes how the drive can be controlled by external devices over a communication network (fieldbus) using the embedded fieldbus interface.

#### System overview

The drive can be connected to an external control system through a communication link using either a fieldbus adapter or the embedded fieldbus interface.

The embedded fieldbus interface supports the Modbus RTU protocol. The drive control program can handle 10 Modbus registers in a 10-millisecond time level. For example, if the drive receives a request to read 20 registers, it will start its response within 22 ms of receiving the request – 20 ms for processing the request and 2 ms overhead for handling the bus. The actual response time depends on other factors as well, such as the baud rate (a parameter setting in the drive).

The drive can be set to receive all of its control information through the fieldbus interface, or the control can be distributed between the embedded fieldbus interface and other available sources, for example, digital and analog inputs.



## Connecting the fieldbus to the drive

Connect the fieldbus to terminal XD2D on the control unit of the drive. See the appropriate Hardware Manual for more information on the connection, chaining and termination of the link.

Note: If the XD2D connector is reserved by the embedded fieldbus interface (parameter 58.01 Protocol enable is set to Modbus RTU), the drive-to-drive link functionality is automatically disabled.

### Setting up the embedded fieldbus interface

Set the drive up for the embedded fieldbus communication with the parameters shown in the table below. The **Setting for fieldbus control** column gives either the value to use or the default value. The Function/Information column gives a description of the parameter.

Parame	eter	Setting for fieldbus control	Function/Information		
COMM	COMMUNICATION INITIALIZATION				
58.01	Protocol enable	Modbus RTU	Initializes embedded fieldbus communication. Drive-to-drive link operation is automatically disabled.		
EMBED	DED MODBUS CO	ONFIGURATION			
58.03	Node address	1 (default)	Node address. There must be no two nodes with the same node address online.		
58.04	Baud rate	19.2 kbps (default)	Defines the communication speed of the link. Use the same setting as in the master station.		
58.05	Parity	8 EVEN 1 (default)	Selects the parity and stop bit setting. Use the same setting as in the master station.		
58.14	Communication loss action	Fault (default)	Defines the action taken when a communication loss is detected.		
58.15	Communication loss mode	Cw / Ref1 / Ref2 (default)	Enables/disables communication loss monitoring and defines the means for resetting the counter of the communication loss delay.		
58.16	Communication loss time	3.0 s (default)	Defines the timeout limit for the communication monitoring.		
58.17	Transmit delay	0 ms (default)	Defines a response delay for the drive.		
58.25	Control profile	ABB Drives (default), Transparent	Selects the control profile used by the drive. See section <i>Basics of the embedded fieldbus interface</i> (page 649).		
58.26  58.29	EFB ref1 type EFB act2 type	Auto, Transparent, General, Torque, Speed, Frequency	Selects the reference and actual value types. With the <i>Auto</i> setting, the type is selected automatically according to the currently active drive control mode.		
58.30	EFB status word transparent source	Other	Defines the source of status word when 58.25 Control profile = Transparent.		
58.31	EFB act1 transparent source	Other	Defines the source of actual value 1 when 58.28 EFB act1 type = Transparent or General.		

Defines the source of actual value 2 when

58.29 EFB act2 type = Transparent or

General.

58.32

EFB act2

source

transparent

Other

Parame	eter	Setting for fieldbus control	Function/Information
58.33	Addressing mode	e.g. <i>Mode 0</i> (default)	Defines the mapping between parameters and holding registers in the 400001465536 (10065535) Modbus register range.
58.34	Word order	LO-HI (default)	Defines the order of the data words in the Modbus message frame.
58.101 Data I/O 1  58.124 Data I/O 24		For example, the default settings (I/Os 16 contain the control word, the status word, two references and two actual values)	Define the address of the drive parameter which the Modbus master accesses when it reads from or writes to the register address corresponding to Modbus In/Out parameters. Select the parameters that you want to read or write through the Modbus I/O words.
		RO/DIO control word, AO1 data storage, AO2 data storage, Feedback data storage, Setpoint data storage	These settings write the incoming data into storage parameters 10.99 RO/DIO control word, 13.91 AO1 data storage, 13.92 AO2 data storage, 40.91 Feedback data storage or 40.92 Setpoint data storage.
58.06	Communication control	Refresh settings	Validates the settings of the configuration parameters.

The new settings will take effect when the drive is powered up the next time, or when they are validated by parameter 58.06 Communication control.

#### **Setting the drive control parameters**

After the embedded fieldbus interface has been set up, check and adjust the drive control parameters listed in the table below. The Setting for fieldbus control column gives the value or values to use when the embedded fieldbus signal is the desired source or destination for that particular drive control signal. The Function/Information column gives a description of the parameter.

Parameter	Setting for fieldbus control	Function/Information	
CONTROL COMMAND SOURCE SELECTION			
20.01 Ext1 commands	Embedded fieldbus	Selects fieldbus as the source for the start and stop commands when EXT1 is selected as the active control location.	
20.06 Ext2 commands	Embedded fieldbus	Selects fieldbus as the source for the start and stop commands when EXT2 is selected as the active control location.	
SPEED REFERENCE SELECTION			
of LLB IXE. LIXEROL SELECTION			
22.11 Speed ref1 source	EFB ref1 or EFB ref2	Selects a reference received through the embedded fieldbus interface as speed reference 1.	

Parameter	Setting for fieldbus control	Function/Information
22.12 Speed ref2 source	EFB ref1 or EFB ref2	Selects a reference received through the embedded fieldbus interface as speed reference 2.
TOPOLIE DEFEDENCE CELECTION		

TORQUE REFERENCE SELECTION		
26.11 Torque ref1 source	EFB ref1 or EFB ref2	Selects a reference received through the embedded fieldbus interface as torque reference 1.
26.12 Torque ref2 source	EFB ref1 or EFB ref2	Selects a reference received through the embedded fieldbus interface as torque reference 2.

FREQUENCY REFERENCE SELECTION		
28.11 Frequency ref1 source	EFB ref1 or EFB ref2	Selects a reference received through the embedded fieldbus interface as frequency reference 1.
28.12 Frequency ref2 source	EFB ref1 or EFB ref2	Selects a reference received through the embedded fieldbus interface as frequency reference 2.

#### OTHER SELECTIONS

EFB references can be selected as the source at virtually any signal selector parameter by selecting *Other*, then either *03.09 EFB reference 1* or *03.10 EFB reference 2*.

CONTROL OF RELAY OUTPUTS, ANALOG OUTPUTS AND DIGITAL INPUT/OUTPUTS			
10.24 RO1 source	RO/DIO control word bit0	Connects bit 0 of storage parameter 10.99  RO/DIO control word to relay output RO1.	
10.27 RO2 source	RO/DIO control word bit1	Connects bit 1 of storage parameter 10.99  RO/DIO control word to relay output RO2.	
10.30 RO3 source	RO/DIO control word bit2	Connects bit 2 of storage parameter 10.99  RO/DIO control word to relay output RO3.	
11.05 DIO1 function 11.09 DIO2 function	Output (default)	Sets the digital input/output to output mode.	
11.06 DIO1 output source	RO/DIO control word bit8	Connects bit 8 of storage parameter 10.99  RO/DIO control word to digital input/output DIO1.	
11.10 DIO2 output source	RO/DIO control word bit9	Connects bit 9 of storage parameter 10.99  RO/DIO control word to digital input/output DIO2.	
13.12 AO1 source	AO1 data storage	Connects storage parameter 13.91 AO1 data storage to analog output AO1.	
13.22 AO2 source	AO2 data storage	Connects storage parameter 13.92 AO2 data storage to analog output AO2.	

Parameter	Setting for fieldbus control	Function/Information		
PROCESS PID FEEDE	PROCESS PID FEEDBACK AND SETPOINT			
40.08 Set 1 feedback 1 source	Feedback data storage	Connect the bits of the storage parameter (10.99 RO/DIO control word) to the digital		
40.16 Set 1 setpoint 1 source	Setpoint data storage	input/outputs of the drive.		
SYSTEM CONTROL INPUTS				
96.07 Parameter save manually	Save (reverts to Done)	Saves parameter value changes (including those made through fieldbus control) to permanent memory.		

Parameter

table

### Basics of the embedded fieldbus interface

The cyclic communication between a fieldbus system and the drive consists of 16-bit data words or 32-bit data words (with the transparent control profiles).

The diagram below illustrates the operation of the embedded fieldbus interface. The signals transferred in the cyclic communication are explained further below the diagram.

Fieldbus network 1) EXT1/2 EFB profile Cyclic communication Start commands **SEL** EFB CW 3) CW 03.09 EFB reference 2) REF1 20.01 REF2 2 03.10 EFB reference 20.06 2 Reference selection EFB SW 3) SW 2) Actual 1 3) ACT1 Actual 2 3) ACT2 58.25 Groups Data I/O 22/26/28/40 etc. selection I/O 1 I/O 2 Reference selection I/O 3 Par. 01.01...255.255 I/O 24 58.101 Groups 58.124 22/26/28/40 etc.

- 1. See also other parameters which can be controlled through fieldbus.
- 2. Data conversion if parameter 58.25 Control profile is set to ABB Drives. See section About the control profiles (page 652).
- 3. If parameter 58.25 Control profile is set to Transparent,

Acyclic communication

- the sources of the status word and actual values are selected by parameters 58.30...58.32 (otherwise, actual values 1 and 2 are automatically selected according to reference type), and
- the control word is displayed by 06.05 EFB transparent control word.

### Control word and Status word

The Control Word (CW) is a 16-bit or 32-bit packed boolean word. It is the principal means of controlling the drive from a fieldbus system. The CW is sent by the fieldbus controller to the drive. By drive parameters, the user selects the EFB CW as the source of drive control commands (such as start/stop, emergency stop, selection between external control locations 1/2, or fault reset). The drive switches between its states according to the bit-coded instructions of the CW.

The fieldbus CW is either written to the drive as it is (see parameter 06.05 EFB transparent control word), or the data is converted. See section About the control profiles (page 652).

The fieldbus Status Word (SW) is a 16-bit or 32-bit packed boolean word. It contains status information from the drive to the fieldbus controller. The drive SW is either written to the fieldbus SW as it is or the data is converted. See section *About the control profiles* (page 652).

### References

EFB references 1 and 2 are 16-bit or 32-bit signed integers. The contents of each reference word can be used as the source of virtually any signal, such as the speed, frequency, torque or process reference. In embedded fieldbus communication, references 1 and 2 are displayed by 03.09 EFB reference 1 and 03.10 EFB reference 1 respectively. Whether the references are scaled or not depends on the settings of 58.26 EFB ref1 type and 58.27 EFB ref2 type. See section About the control profiles (page 652).

### Actual values

Fieldbus actual signals (ACT1 and ACT2) are 16-bit or 32-bit signed integers. They convey selected drive parameter values from the drive to the master. Whether the actual values are scaled or not depends on the settings of 58.28 EFB act1 type and 58.29 EFB act2 type. See section About the control profiles (page 652).

# Data input/outputs

Data input/outputs are 16-bit or 32-bit words containing selected drive parameter values. Parameters 58.101 Data I/O 1 ... 58.124 Data I/O 24 define the addresses from which the master either reads data (input) or to which it writes data (output).

### Control of drive outputs through EFB

The address selection parameters of the data input/outputs have a setting with which the data can be written into a storage parameter in the drive. These storage parameters are readily selectable as signal sources of the drive outputs.

The desired values of the relay outputs (RO) and digital input/outputs (DIO) can be written in a 16-bit word into 10.99 RO/DIO control word, which is then selected as the source of those outputs. Each of the analog outputs (AO) of the drive have a

dedicated storage parameter (13.91 AO1 data storage and 13.92 AO2 data storage), which are available in the source selection parameters 13.12 AO1 source and 13.22 AO2 source.

### Sending process PID feedback and setpoint values through EFB

The drive also has storage parameters for incoming process PID feedback (40.91 Setpoint data storage) as well as a process PID setpoint (40.92 Set 2 PID operation mode). The feedback storage parameter is selectable in the source selection parameters 40.08 Set 1 feedback 1 source and 40.09 Set 1 feedback 2 source.

The corresponding parameters in process PID control set 2 (group 41 Process PID set 2) have the same selections.

### Register addressing

The address field of Modbus requests for accessing holding registers is 16 bits. This allows the Modbus protocol to support addressing of 65536 holding registers.

Historically, Modbus master devices used 5-digit decimal addresses from 40001 to 49999 to represent holding register addresses. The 5-digit decimal addressing limited to 9999 the number of holding registers that could be addressed.

Modern Modbus master devices typically provide a means to access the full range of 65536 Modbus holding registers. One of these methods is to use 6-digit decimal addresses from 400001 to 465536. This manual uses 6-digit decimal addressing to represent Modbus holding register addresses.

Modbus master devices that are limited to the 5-digit decimal addressing may still access registers 400001 to 409999 by using 5-digit decimal addresses 40001 to 49999. Registers 410000 to 465536 are inaccessible to these masters.


Note: Register addresses of 32-bit parameters cannot be accessed by using 5-digit register numbers.

# About the control profiles

A control profile defines the rules for data transfer between the drive and the fieldbus master, for example:

- if packed boolean words are converted and how
- how drive register addresses are mapped for the fieldbus master.

You can configure the drive to receive and send messages according to the ABB Drives profile or the Transparent profile. With the ABB Drives profile, the embedded fieldbus interface of the drive converts the control word and status word to and from the native data used in the drive. The Transparent profile involves no data conversion. The figure below illustrates the effect of the profile selection.



Control profile selection with parameter 58.25 Control profile:

- (0) ABB Drives
- (2) Transparent

Note that scaling of references and actual values can be selected independent of the profile selection by parameters 58.26 ... 58.29.

# The ABB Drives profile

### **Control Word**

The table below shows the contents of the fieldbus Control Word for the ABB Drives control profile. The embedded fieldbus interface converts this word to the form in which it is used in the drive. The upper case boldface text refers to the states shown in State transition diagram on page 656.

Bit	Name	Value	STATE/Description
0	OFF1_	1	Proceed to READY TO OPERATE.
	CONTROL	0	Stop along currently active deceleration ramp. Proceed to <b>OFF1 ACTIVE</b> ; proceed to <b>READY TO SWITCH ON</b> unless other interlocks (OFF2, OFF3) are active.
1	OFF2_	1	Continue operation (OFF2 inactive).
	CONTROL	0	Emergency OFF, coast to stop. Proceed to <b>OFF2 ACTIVE</b> , proceed to <b>SWITCH-ON INHIBITED</b> .
2	OFF3_	1	Continue operation (OFF3 inactive).
	CONTROL	0	Emergency stop, stop within time defined by drive parameter. Proceed to OFF3 ACTIVE; proceed to SWITCH-ON INHIBITED.
			WARNING! Ensure that the motor and driven machine can be stopped using this stop mode.
3	INHIBIT_	1	Proceed to OPERATION ENABLED.
	OPERATION		<b>Note:</b> Run enable signal must be active; see the drive documentation. If the drive is set to receive the Run enable signal from the fieldbus, this bit activates the signal.
		0	Inhibit operation. Proceed to <b>OPERATION INHIBITED</b> .
4	RAMP_OUT_ ZERO	1	Normal operation. Proceed to RAMP FUNCTION GENERATOR: OUTPUT ENABLED.
		0	Force Ramp Function Generator output to zero. Drive ramps to stop (current and DC voltage limits in force).
5	RAMP_HOLD	1	Enable ramp function.
			Proceed to RAMP FUNCTION GENERATOR: ACCELERATOR ENABLED.
		0	Halt ramping (Ramp Function Generator output held).
6	RAMP_IN_	1	Normal operation. Proceed to <b>OPERATING</b> .
	ZERO		<b>Note:</b> This bit is effective only if the fieldbus interface is set as the source for this signal by drive parameters.
		0	Force Ramp Function Generator input to zero.
7	RESET	0=>1	Fault reset if an active fault exists. Proceed to <b>SWITCH-ON INHIBITED</b> .
			<b>Note:</b> This bit is effective only if the fieldbus interface is set as the source for this signal by drive parameters.
		0	Continue normal operation.

Bit	Name	Value	STATE/Description
8	8 JOGGING_1	1	Accelerate to jogging 1 reference.  Notes: Bits 46 must be 0. See also section <i>Jogging</i> (page 97).
		0	Jogging 1 disabled.
9	JOGGING_2	1	Accelerate to jogging 2 reference. See notes at bit 8.
		0	Jogging 2 disabled.
10	REMOTE_	1	Fieldbus control enabled.
	CMD	0	Control Word <> 0 or Reference <> 0: Retain last Control Word and Reference.  Control Word = 0 and Reference = 0: Fieldbus control enabled. Reference and deceleration/acceleration ramp are locked.
11	EXT_CTRL_ LOC	1	Select External Control Location EXT2. Effective if the control location is parameterized to be selected from the fieldbus.
		0	Select External Control Location EXT1. Effective if the control location is parameterized to be selected from the fieldbus.
1215	Reserved		


# Status Word

The table below shows the fieldbus Status Word for the ABB Drives control profile. The embedded fieldbus interface converts the drive Status Word into this form for the fieldbus. The upper case boldface text refers to the states shown in State transition diagram on page 656.

Bit	Name	Value	STATE/Description
0	0 RDY_ON	1	READY TO SWITCH ON.
		0	NOT READY TO SWITCH ON.
1	RDY_RUN	1	READY TO OPERATE.
		0	OFF1 ACTIVE.
2	RDY_REF	1	OPERATION ENABLED.
		0	OPERATION INHIBITED.
3	TRIPPED	1	FAULT.
		0	No fault.
4	OFF_2_STA	1	OFF2 inactive.
		0	OFF2 ACTIVE.
5	OFF_3_STA	1	OFF3 inactive.
		0	OFF3 ACTIVE.
6	SWC_ON_	1	SWITCH-ON INHIBITED.
	INHIB	0	-
7	ALARM	1	Warning/Alarm.
		0	No warning/alarm.
8	AT_ SETPOINT	1	OPERATING. Actual value equals Reference = is within tolerance limits, i.e. in speed control, speed error is 10% max. of nominal motor speed.
		0	Actual value differs from Reference = is outside tolerance limits.
9	REMOTE	1	Drive control location: REMOTE (EXT1 or EXT2).
		0	Drive control location: LOCAL.
10	ABOVE_ LIMIT	1	Actual frequency or speed equals or exceeds supervision limit (set by drive parameter). Valid in both directions of rotation.
		0	Actual frequency or speed within supervision limit.
11	USER_0		S
12	EXT_RUN_	1	External Run enable signal received.
	ENABLE	0	No external Run enable signal received.
1315	Reserved		

### State transition diagram


The diagram below shows the state transitions in the drive when the drive is using the ABB Drives profile, and configured to follow the commands of the control word from the embedded fieldbus interface. The upper case texts refer to the states which are used in the tables representing the fieldbus Control and Status words. See sections *Control Word* on page 653 and *Status Word* on page 655.



### References

The ABB drives profile supports the use of two references, EFB reference 1 and EFB reference 2. The references are 16-bit words each containing a sign bit and a 15-bit integer. A negative reference is formed by calculating the two's complement from the corresponding positive reference.

The references are scaled as defined by parameters 40.06...40.07; which scaling is in use depends on the setting of 58.26 EFB ref1 type and 58.27 EFB ref2 type (see page 405).




The scaled references are shown by parameters 03.09 EFB reference 1 and 03.10 EFB reference 2.

# Actual values

The ABB Drives profile supports the use of two fieldbus actual values, ACT1 and ACT2. The actual values are 16-bit words each containing a sign bit and a 15-bit integer. A negative value is formed by calculating the two's complement from the corresponding positive value.

The actual values are scaled as defined by parameters 46.01 ...46.04; which scaling is in use depends on the setting of parameters 58.28 EFB act1 type and 58.29 EFB act2 type (see page 406).



# Modbus holding register addresses

The table below shows the default Modbus holding register addresses for drive data. This profile provides a converted 16-bit access to the data.

Register address	Register data (16-bit words)	
400001	Control word. See section Control Word (page 653).	
	The selection can be changed using parameter 58.101 Data I/O 1.	
400002	Reference 1 (REF1).	
	The selection can be changed using parameter 58.102 Data I/O 2.	
400003	Reference 2 (REF2).	
	The selection can be changed using parameter 58.103 Data I/O 3.	
400004	Status Word (SW). See section Status Word (page 655).	
	The selection can be changed using parameter 58.104 Data I/O 4.	
400005	Actual value 1 (ACT1).	
	The selection can be changed using parameter 58.105 Data I/O 5.	
400006	Actual value 2 (ACT2).	
	The selection can be changed using parameter 58.106 Data I/O 6.	
400007400024	Data in/out 724.	
	Selected by parameters 58.107 Data I/O 7 58.124 Data I/O 24.	
400025400089	Unused	
400090400100	Error code access. See section <i>Error code registers (holding registers 400090400100)</i> (page 666).	
400101465536	Parameter read/write.	
	Parameters are mapped to register addresses according to parameter 58.33 Addressing mode.	

# The Transparent profile

The Transparent profile enables a customizable access to the drive.

The contents of the control word are user-definable. The control word received from the fieldbus is visible in parameter 06.05 EFB transparent control word, and can be used to control the drive using pointer parameters and/or application programming.

The status word to be sent to the fieldbus controller is selected by parameter 58.30 EFB status word transparent source. This can be, for example, the user-configurable status word in 06.50 User status word 1.

The Transparent profile involves no data conversion of the control or status word. Whether references or actual values are scaled depends on the setting of parameters 58.26...58.29. The references received from the fieldbus are visible in parameters 03.09 EFB reference 1 and 03.10 EFB reference 2.

The Modbus holding register addresses for the Transparent profile are as with the ABB Drives profile (see page 659).

# **Modbus function codes**

The table below shows the Modbus function codes supported by the embedded fieldbus interface.

Code	Function name	Description
01h	Read Coils	Reads the 0/1 status of coils (0X references).
02h	Read Discrete Inputs	Reads the 0/1 status of discrete inputs (1X references).
03h	Read Holding Registers	Reads the binary contents of holding registers (4X references).
05h	Write Single Coil	Forces a single coil (0X reference) to 0 or 1.
06h	Write Single Register	Writes a single holding register (4X reference).
08h	Diagnostics	Provides a series of tests for checking the communication, or for checking various internal error conditions.  Supported subcodes:  Oth Return Query Data: Echo/loopback test.  Oth Restart Comm Option: Restarts and initializes the EFB, clears communications event counters.  Oth Force Listen Only Mode  Oth Clear Counters and Diagnostic Register  Oth Return Bus Message Count
		<ul> <li>OCh Return Bus Comm. Error Count</li> <li>ODh Return Bus Exception Error Count</li> <li>OEh Return Slave Message Count</li> <li>OFh Return Slave No Response Count</li> <li>10h Return Slave NAK (negative acknowledge) Count</li> <li>11h Return Slave Busy Count</li> <li>12h Return Bus Character Overrun Count</li> <li>14h Clear Overrun Counter and Flag</li> </ul>
0Bh	Get Comm Event Counter	Returns a status word and an event count.
0Fh	Write Multiple Coils	Forces a sequence of coils (0X references) to 0 or 1.
10h	Write Multiple Registers	Writes the contents of a contiguous block of holding registers (4X references).
16h	Mask Write Register	Modifies the contents of a 4X register using a combination of an AND mask, an OR mask, and the register's current contents.
17h	Read/Write Multiple Registers	Writes the contents of a contiguous block of 4X registers, then reads the contents of another group of registers (the same or different than those written) in a server device.

Code	Function name	Description
2Bh / 0Eh	Encapsulated Interface	Supported subcodes:
	Transport	0Eh Read Device Identification: Allows reading the identification and other information.
		Supported ID codes (access type):
		00h: Request to get the basic device identification (stream access)
		04h: Request to get one specific identification object (individual access)
		Supported Object IDs:
		00h: Vendor Name ("ABB")
		01h: Product Code (for example, "AINFX")
		02h: Major Minor Revision (combination of contents of parameters 07.05 Firmware version and 58.02 Protocol ID).
		03h: Vendor URL ("www.abb.com")
		04h: Product name (for example, "ACS880")

# **Exception codes**

The table below shows the Modbus exception codes supported by the embedded fieldbus interface.

Code	Name	Description
01h	ILLEGAL FUNCTION	The function code received in the query is not an allowable action for the server.
02h	ILLEGAL DATA ADDRESS	The data address received in the query is not an allowable address for the server.
03h	ILLEGAL DATA VALUE	The requested Quantity of Registers is larger than the drive can handle.
		<b>Note:</b> This error does not mean that a value written to a drive parameter is outside the valid range.
04h	SLAVE DEVICE FAILURE	The value written to a drive parameter is outside the valid range. See section <i>Error code registers (holding registers 400090400100)</i> on page 666.
06h	SLAVE DEVICE BUSY	The server is engaged in processing a long-duration program command.

# Coils (0xxxx reference set)

Coils are 1-bit read/write values. Control Word bits are exposed with this data type. The table below summarizes the Modbus coils (0xxxx reference set).

Reference	ABB drives profile	Transparent profile
00001	OFF1 CONTROL	Control Word bit 0
00002	OFF2_CONTROL	Control Word bit 1
00003	OFF3_CONTROL	Control Word bit 2
00004	INHIBIT OPERATION	Control Word bit 3
00005	RAMP OUT ZERO	Control Word bit 4
00006	RAMP_HOLD	Control Word bit 5
00007	RAMP_IN_ZERO	Control Word bit 6
00008	RESET	Control Word bit 7
00009	JOGGING_1	Control Word bit 8
00010	JOGGING_2	Control Word bit 9
00011	REMOTE_CMD	Control Word bit 10
00012	EXT_CTRL_LOC	Control Word bit 11
00013	User-defined (0)	Control Word bit 12
00014	User-defined (1)	Control Word bit 13
00015	User-defined (2)	Control Word bit 14
00016	User-defined (3)	Control Word bit 15
00017	Reserved	Control Word bit 16
00018	Reserved	Control Word bit 17
00019	Reserved	Control Word bit 18
00020	Reserved	Control Word bit 19
00021	Reserved	Control Word bit 20
00022	Reserved	Control Word bit 21
00023	Reserved	Control Word bit 22
00024	Reserved	Control Word bit 23
00025	Reserved	Control Word bit 24
00026	Reserved	Control Word bit 25
00027	Reserved	Control Word bit 26
00028	Reserved	Control Word bit 27
00029	Reserved	Control Word bit 28
00030	Reserved	Control Word bit 29
00031	Reserved	Control Word bit 30
00032	Reserved	Control Word bit 31
00033	Reserved	10.99 RO/DIO control word, bit 0
00034	Reserved	10.99 RO/DIO control word, bit 1

Reference	ABB drives profile	Transparent profile
00035	Reserved	10.99 RO/DIO control word, bit 2
00036	Reserved	10.99 RO/DIO control word, bit 3
00037	Reserved	10.99 RO/DIO control word, bit 4
00038	Reserved	10.99 RO/DIO control word, bit 5
00039	Reserved	10.99 RO/DIO control word, bit 6
00040	Reserved	10.99 RO/DIO control word, bit 7
00041	Reserved	10.99 RO/DIO control word, bit 8
00042	Reserved	10.99 RO/DIO control word, bit 9

# **Discrete inputs (1xxxx reference set)**

Discrete inputs are 1-bit read-only values. Status Word bits are exposed with this data type. The table below summarizes the Modbus discrete inputs (1xxxx reference set).

Reference	ABB drives profile	Transparent profile
10001	RDY_ON	Status Word bit 0
10002	RDY_RUN	Status Word bit 1
10003	RDY_REF	Status Word bit 2
10004	TRIPPED	Status Word bit 3
10005	OFF_2_STA	Status Word bit 4
10006	OFF_3_STA	Status Word bit 5
10007	SWC_ON_INHIB	Status Word bit 6
10008	ALARM	Status Word bit 7
10009	AT_SETPOINT	Status Word bit 8
10010	REMOTE	Status Word bit 9
10011	ABOVE_LIMIT	Status Word bit 10
10012	User-defined (0)	Status Word bit 11
10013	User-defined (1)	Status Word bit 12
10014	User-defined (2)	Status Word bit 13
10015	User-defined (3)	Status Word bit 14
10016	Reserved	Status Word bit 15
10017	Reserved	Status Word bit 16
10018	Reserved	Status Word bit 17
10019	Reserved	Status Word bit 18
10020	Reserved	Status Word bit 19
10021	Reserved	Status Word bit 20
10022	Reserved	Status Word bit 21
10023	Reserved	Status Word bit 22
10024	Reserved	Status Word bit 23

Reference	ABB drives profile	Transparent profile
10025	Reserved	Status Word bit 24
10026	Reserved	Status Word bit 25
10027	Reserved	Status Word bit 26
10028	Reserved	Status Word bit 27
10029	Reserved	Status Word bit 28
10030	Reserved	Status Word bit 29
10031	Reserved	Status Word bit 30
10032	Reserved	Status Word bit 31
10033	Reserved	10.02 DI delayed status, bit 0
10034	Reserved	10.02 DI delayed status, bit 1
10035	Reserved	10.02 DI delayed status, bit 2
10036	Reserved	10.02 DI delayed status, bit 3
10037	Reserved	10.02 DI delayed status, bit 4
10038	Reserved	10.02 DI delayed status, bit 5
10039	Reserved	10.02 DI delayed status, bit 6
10040	Reserved	10.02 DI delayed status, bit 7
10041	Reserved	10.02 DI delayed status, bit 8
10042	Reserved	10.02 DI delayed status, bit 9
10043	Reserved	10.02 DI delayed status, bit 10
10044	Reserved	10.02 DI delayed status, bit 11
10045	Reserved	10.02 DI delayed status, bit 12
10046	Reserved	10.02 DI delayed status, bit 13
10047	Reserved	10.02 DI delayed status, bit 14
10048	Reserved	10.02 DI delayed status, bit 15

# Error code registers (holding registers 400090...400100)

These registers contain information about the last query. The error register is cleared when a query has finished successfully.

Reference	Name	Description
90	Reset Error Registers	1 = Reset internal error registers (9195).
91	Error Function Code	Function code of the failed query.
92	Error Code	Set when exception code 04h is generated (see table above).  • 00h No error  • 02h Low/High limit exceeded  • 03h Faulty Index: Unavailable index of an array parameter  • 05h Incorrect Data Type: Value does not match the data type of the parameter  • 65h General Error: Undefined error when handling query
93	Failed Register	The last register (discrete input, coil, or holding register) that failed to be read or written.
94	Last Register Written Successfully	The last register that was written successfully.
95	Last Register Read Successfully	The last register that was read successfully.

# Fieldbus control through a fieldbus adapter

# What this chapter contains

This chapter describes how the drive can be controlled by external devices over a communication network (fieldbus) through an optional fieldbus adapter module.

The fieldbus control interface of the drive is described first, followed by a configuration example.

# System overview


The drive can be connected to an external control system through an optional fieldbus adapter mounted onto the control unit of the drive. The drive actually has two independent interfaces for fieldbus connection, called "fieldbus adapter A" (FBA A) and "fieldbus adapter B" (FBA B). The drive can be configured to receive all of its control information through the fieldbus interface(s), or the control can be distributed between the fieldbus interface(s) and other available sources such as digital and analog inputs, depending on how control locations EXT1 and EXT2 are configured.

Note: The text and examples in this chapter describe the configuration of one fieldbus adapter (FBAA) by parameters 50.01...50.21 and parameter groups 51...53. The second adapter (FBA B), if present, is configured in a similar fashion by parameters 50.31...50.51 and parameter groups 54...56. It is recommended that the FBA B interface is only used for monitoring.

Fieldbus adapters are available for various communication systems and protocols, for example

- CANopen (FCAN-01 adapter)
- ControlNet (FCNA-01 adapter)
- DeviceNet (FDNA-01 adapter)
- EtherCAT® (FECA-01 adapter)
- EtherNet/IP<sup>TM</sup> (FENA-11 or FENA-21 adapter)
- Modbus/RTU (FSCA-01 adapter)
- Modbus/TCP (FENA-11 or FENA-21 adapter)
- POWERLINK (FEPL-02 adapter)
- PROFIBUS DP (FPBA-01 adapter)
- PROFINET IO (FENA-11 or FENA-21 adapter).

Note: Fieldbus adapters with the suffix "M" (eg. FPBA-01-M) are not supported.



Parameter

table

### Basics of the fieldbus control interface

The cyclic communication between a fieldbus system and the drive consists of 16- or 32-bit input and output data words. The drive is able to support a maximum of 12 data words (16 bits) in each direction.

Data transmitted from the drive to the fieldbus controller is defined by parameters 52.01 FBA A data in1 ... 52.12 FBA A data in12. The data transmitted from the fieldbus controller to the drive is defined by parameters 53.01 FBA A data out1 ... 53.12 FBA A data out12.

#### Fieldbus network 1) **FBA Profile** Fieldbus adapter EXT1/2 Start func **DATA** Profile OUT 2) selection FBA MAIN CW 4) FBA REF1 1 FBA REF2 DATA OUT 20.01 2 selection 20.06 Fieldbus-specific interface 3 3) Speed/Torque REF1 sel 12 Par. 10.01...99.99 DATA Profile IN 2) Group 53 selection FBA MAIN SW 22.11 / 26.11 5) 5)\_ FBA ACT1 1 26.12 1 FBA ACT2 DATA IN 2 Speed/Torque selection REF2 sel 3 3) 12 Par. 01.01...99.99 Cyclic communication 22.12 | 26.11 Group 52 1 26.12

- 1) See also other parameters which can be controlled from fieldbus.
- 2) The maximum number of data words used is protocol-dependent.
- 3) Profile/instance selection parameters. Fieldbus module specific parameters. For more information, see the *User's Manual* of the appropriate fieldbus adapter module.
- 4) With DeviceNet, the control part is transmitted directly.

**Acyclic communication** See the manual of the fieldbus

adapter module.

5) With DeviceNet, the actual value part is transmitted directly.

### Control word and Status word

The Control word is the principal means for controlling the drive from a fieldbus system. It is sent by the fieldbus master station to the drive through the adapter module. The drive switches between its states according to the bit-coded instructions in the Control word, and returns status information to the master in the Status word.

For the ABB Drives communication profile, the contents of the Control word and the Status word are detailed on pages 673 and 674 respectively. The drive states are presented in the state diagram (page 675).

When a transparent communication profile is selected e.g. by parameter group *51 FBA A settings*, the control word received from the PLC is available in *06.03 FBA A transparent control word*. The individual bits of the word can then be used for drive control through bit pointer parameters. The source of the status word, for example *06.50 User status word 1*, can be selected by *50.09 FBA A SW transparent source*.

### Debugging the network words

If parameter 50.12 FBA A debug mode is set to Fast, the Control word received from the fieldbus is shown by parameter 50.13 FBA A control word, and the Status word transmitted to the fieldbus network by 50.16 FBA A status word. This "raw" data is very useful to determine if the fieldbus master is transmitting the correct data before handing control to the fieldbus network.

### References

References are 16-bit words containing a sign bit and a 15-bit integer. A negative reference (indicating reversed direction of rotation) is formed by calculating the two's complement from the corresponding positive reference.

ABB drives can receive control information from multiple sources including analog and digital inputs, the drive control panel and a fieldbus adapter module. In order to have the drive controlled through the fieldbus, the module must be defined as the source for control information such as reference. This is done using the source selection parameters in groups 22 Speed reference selection, 26 Torque reference chain and 28 Frequency reference chain.


### Debugging the network words

If parameter 50.12 FBA A debug mode is set to Fast, the references received from the fieldbus are displayed by 50.14 FBA A reference 1 and 50.15 FBA A reference 2.

### Scaling of references

Note: The scalings described below are for the ABB Drives communication profile. Fieldbus-specific communication profiles may use different scalings. For more information, see the manual of fieldbus adapter.

The references are scaled as defined by parameters 46.01...46.07; which scaling is in use depends on the setting of 50.04 FBA A ref1 type and 50.05 FBA A ref2 type.



The scaled references are shown by parameters 03.05 FB A reference 1 and 03.06 FB A reference 2.

### Actual values

Actual values are 16-bit words containing information on the operation of the drive. The types of the monitored signals are selected by parameters 50.07 FBA A actual 1 type and 50.08 FBA A actual 2 type.


### Debugging the network words

If parameter 50.12 FBA A debug mode is set to Fast, the actual values sent to the fieldbus are displayed by 50.17 FBA A actual value 1 and 50.18 FBA A actual value 2.

### Scaling of actual values

**Note**: The scalings described below are for the ABB Drives communication profile. Fieldbus-specific communication profiles may use different scalings. For more information, see the manual of fieldbus adapter.

The actual values are scaled as defined by parameters 46.01...46.04; which scaling is in use depends on the setting of parameters 50.07 FBA A actual 1 type and 50.08 FBA A actual 2 type.



# Contents of the fieldbus Control word (ABB Drives profile)

The upper case boldface text refers to the states shown in the state diagram (page 675).


Bit	Name	Value	STATE/Description		
0	Off1 control	1	Proceed to <b>READY TO OPERATE</b> .		
		0	Stop along currently active deceleration ramp. Proceed to <b>OFF1 ACTIVE</b> ; proceed to <b>READY TO SWITCH ON</b> unless other interlocks (OFF2, OFF3) are active.		
1	Off2 control	1	Continue operation (OFF2 inactive).		
			Emergency OFF, coast to a stop. Proceed to <b>OFF2 ACTIVE</b> , proceed to <b>SWITCH-ON INHIBITED</b> .		
2	Off3 control	1	Continue operation (OFF3 inactive).		
		0	Emergency stop, stop within time defined by drive parameter.  Proceed to OFF3 ACTIVE; proceed to SWITCH-ON INHIBITED.  WARNING: Ensure motor and driven machine can be stopped using this stop mode.		
3	Run	1	Proceed to OPERATION ENABLED.		
			<b>Note:</b> Run enable signal must be active. If the drive is set to receive the Run enable signal from the fieldbus, this bit activates the signal. See also parameters <i>06.18 Start inhibit status word</i> and <i>06.25 Drive</i>		
			inhibit status word 2.		
		0	Inhibit operation. Proceed to <b>OPERATION INHIBITED</b> .		
4	Ramp out zero	1	Normal operation. Proceed to RAMP FUNCTION GENERATOR: OUTPUT ENABLED.		
		0	Force Ramp function generator output to zero. The drive will immediately decelerate to zero speed (observing the torque limits).		
5 Ramp hold 1		1	Enable ramp function. Proceed to RAMP FUNCTION GENERATOR: ACCELERATOR ENABLED.		
		0	Halt ramping (Ramp Function Generator output held).		
6	Ramp in zero	1	Normal operation. Proceed to <b>OPERATING</b> . <b>Note:</b> This bit is effective only if the fieldbus interface is set as the source for this signal by drive parameters.		
		0	Force Ramp function generator input to zero.		
7	Reset	0=>1	Fault reset if an active fault exists. Proceed to <b>SWITCH-ON INHIBITED</b> .		
			<b>Note:</b> This bit is effective only if the fieldbus interface is set as the source of the reset signal by drive parameters.		
		0	Continue normal operation.		
8	Inching 1	1	Accelerate to inching (jogging) setpoint 1.  Notes:  Bits 46 must be 0.  See also section <i>Jogging</i> (page 97).		
		0	Inching (jogging) 1 disabled.		
9	Inching 2	1	Accelerate to inching (jogging) setpoint 2. See notes at bit 8.		
		0	Inching (jogging) 2 disabled.		
10	Remote cmd	1	Fieldbus control enabled.		
		0	Control word and reference not getting through to the drive, except for bits 02.		
11	Ext ctrl loc	1	Select External Control Location EXT2. Effective if control location parameterized to be selected from fieldbus.		
		0	Select External Control Location EXT1. Effective if control location is parameterized to be selected from fieldbus.		
12 to 1	5 Reserved.				

# Contents of the fieldbus Status word (ABB Drives profile)

The upper case boldface text refers to the states shown in the state diagram (page 675).

Bit	Name	Value	STATE/Description		
0	Ready to switch	1	READY TO SWITCH ON.		
	ON	0	NOT READY TO SWITCH ON.		
1	Ready run	1	READY TO OPERATE.		
		0	OFF1 ACTIVE.		
2	Ready ref	1	OPERATION ENABLED.		
		0	<b>OPERATION INHIBITED</b> . See parameters 06.18 Start inhibit status word and 06.25 Drive inhibit status word 2 for the inhibiting condition.		
3	Tripped	1	FAULT.		
		0	No fault.		
4	Off 2 inactive	1	OFF2 inactive.		
		0	OFF2 ACTIVE.		
5	Off 3 inactive	1	OFF3 inactive.		
		0	OFF3 ACTIVE.		
6	Switch-on inhibited	1	SWITCH-ON INHIBITED.		
		0	-		
7	Warning	1	Warning active.		
		0	No warning active.		
8	At setpoint	1	<b>OPERATING</b> . Actual value equals reference = is within tolerance limits (see parameters 46.2146.23).		
		0	Actual value differs from reference = is outside tolerance limits.		
9	Remote	1	Drive control location: REMOTE (EXT1 or EXT2).		
		0	Drive control location: LOCAL.		
10	Above limit	-	See parameter 06.29 MSW bit 10 sel.		
11	User bit 0	-	See parameter 06.30 MSW bit 11 sel.		
12	User bit 1	-	See parameter 06.31 MSW bit 12 sel.		
13	User bit 2	-	See parameter 06.32 MSW bit 13 sel.		
14	User bit 3	-	See parameter 06.33 MSW bit 14 sel.		
15	Reserved	Reserved			

### The state diagram (ABB Drives profile)



# Setting up the drive for fieldbus control

- 1. Install the fieldbus adapter module mechanically and electrically according to the instructions given in the *User's manual* of the module.
- 2. Power up the drive.
- 3. Enable the communication between the drive and the fieldbus adapter module with parameter 50.01 FBA A enable.
- 4. With 50.02 FBA A comm loss func, select how the drive should react to a fieldbus communication break.

Note: This function monitors both the communication between the fieldbus master and the adapter module and the communication between the adapter module and the drive.

- 5. With 50.03 FBA A comm loss t out, define the time between communication break detection and the selected action.
- 6. Select application-specific values for the rest of the parameters in group 50 Fieldbus adapter (FBA), starting from 50.04. Examples of appropriate values are shown in the tables below.
- 7. Set the fieldbus adapter module configuration parameters in group 51 FBA A settings. As a minimum, set the required node address and the communication profile.
- 8. Define the process data transferred to and from the drive in parameter groups 52 FBA A data in and 53 FBA A data out.

Note: Depending on the communication protocol and profile being used, the Control word and Status word may already be configured to be sent/received by the communication system.

- 9. Save the valid parameter values to permanent memory by setting parameter 96.07 Parameter save manually to Save.
- 10. Validate the settings made in parameter groups 51, 52 and 53 by setting parameter 51.27 FBA A par refresh to Refresh.
- 11. Configure control locations EXT1 and EXT2 to allow control and reference signals to come from the fieldbus. Examples of appropriate values are shown in the tables below.

# Parameter setting example: FPBA (PROFIBUS DP)

This example shows how to configure a basic speed control application that uses the PROFIdrive communication profile with PPO Type 2. The start/stop commands and reference are according to the PROFIdrive profile, speed control mode.

The reference values sent over the fieldbus have to be scaled within the drive so they have the desired effect. The reference value ±16384 (4000h) corresponds to the range of speed set in parameter 46.01 Speed scaling (both forward and reverse directions). For example, if 46.01 is set to 480 rpm, then 4000h sent over fieldbus will request 480 rpm.

Direction	PZD1	PZD2	PZD3	PZD4	PZD5	PZD6
Out	Control word	Speed reference	Acc time	1	Dec time	1
In	Status word	Speed actual value	Motor cu	rrent	DC volta	ge

The table below gives the recommended drive parameter settings.

Drive parameter	Setting for ACS880 drives	Description
50.01 FBA A enable	13 = [slot number]	Enables communication between the drive and the fieldbus adapter module.
50.04 FBA A ref1 type	4 = Speed	Selects the fieldbus A reference 1 type and scaling.
50.07 FBA A actual 1 type	0 = Auto	Selects the actual value type and scaling according to the currently active Ref1 mode defined in parameter 50.04.
51.01 FBA A type	<b>1</b> = FPBA <sup>1)</sup>	Displays the type of the fieldbus adapter module.
51.02 Node address	3 <sup>2)</sup>	Defines the PROFIBUS node address of the fieldbus adapter module.
51.03 Baud rate	12000 <sup>1)</sup>	Displays the current baud rate on the PROFIBUS network in kbit/s.
51.04 MSG type	<b>1</b> = PPO1 <sup>1)</sup>	Displays the telegram type selected by the PLC configuration tool.
51.05 Profile	0 = PROFIdrive	Selects the Control word according to the PROFIdrive profile (speed control mode).
51.07 RPBA mode	0 = Disabled	Disables the RPBA emulation mode.
52.01 FBA data in1	<b>4</b> = SW 16bit <sup>1)</sup>	Status word
52.02 FBA data in2	<b>5</b> = Act1 16bit	Actual value 1
52.03 FBA data in3	01.07 <sup>2)</sup>	Motor current
52.05 FBA data in5	01.11 <sup>2)</sup>	DC voltage
53.01 FBA data out1	<b>1</b> = CW 16bit <sup>1)</sup>	Control word
53.02 FBA data out2	2 = Ref1 16bit	Reference 1 (speed)
53.03 FBA data out3	23.12 <sup>2)</sup>	Acceleration time 1

The start sequence for the parameter example above is given below.

### Control word:

- · after power-on, fault or emergency stop:
  - 476h (1142 decimal) -> NOT READY TO SWITCH ON
- in normal operation:
  - 477h (1143 decimal) -> READY TO SWITCH ON (stopped)
  - 47Fh (1151 decimal) -> OPERATING (running)

<sup>1)</sup> Read-only or automatically detected/set

<sup>&</sup>lt;sup>2)</sup> Example

# Control chain diagrams

# What this chapter contains


The chapter presents the reference chains of the drive. The control chain diagrams can be used to trace how parameters interact and where parameters have an effect within the drive parameter system. See,

- Drive control diagrams on page 680
- Winder control diagrams on page 698


For a more general diagram, see section *Operating modes of the drive* (page 43).

# **Drive control diagrams**


# Speed reference source selection I




# Speed reference source selection II




# Speed reference ramping and shaping




# Motor feedback configuration




# Load feedback and position counter configuration




#### Speed error calculation




# Speed controller




# Torque reference source selection and modification




# Operating mode selection




## Reference selection for torque controller




# Torque limitation




# **Torque controller**




#### Frequency reference selection




## Frequency reference modification



# Process PID setpoint and feedback source selection




#### Process PID controller



Note! Process PID parameter set 2 is also available. See parameter group 41.

## Master/Follower communication I (Master)




Signal selection for Master's broadcast message

61.01 M/F data 1 selection Selection | v | 61.25 M/F data 1 value | Ds41.1 |

61.02 M/F data 2 selection | selection | selection | v | 61.27 M/F data 3 value | Ds41.2 |


61.03 M/F data 3 selection | selection | v | 61.27 M/F data 3 value | Ds41.3 |

# Master/Follower communication II (Follower)




# Winder control diagrams


## Winder control word logic




#### **Diameter calculation**




#### **Tension control**




#### **Dancer control**




# Friction compensation




# Inertia compensation



## Speed reference scaling



## Application PID controller





# **Appendix A: Motor rotor** inertia, IEC

The table given below is an example of common inverter duty AC motor rotor inertia. The data is from the ABB cast iron totally enclosed squirrel cage motors catalog. The electrical ratings are based on 400 V AC 50 Hz sinusoidal input.

Power (kW)	Poles	Base rpm	IEC Frame	Nominal current (A)	Nominal torque (Nm)	Inertia (kgm²)
0.75	6	935	90 S6	2.05	7.65	0.0039
	4	1410	80 M4	1.85	5	0.0021
	2	2830	80 M2	1.6	2.53	0.00097
1.1	6	920	90 L6	2.8	11.5	0.0049
	4	1410	90 S4	2.65	7.45	0.0029
	2	2835	80 M2	2.25	3.7	0.0012
1.5	6	950	100 L6	3.8	15	0.011
	4	1410	90 L4	3.45	10.1	0.0037
	2	2850	90 S2	3.0	5.0	0.0015
2.2	6	950	112 M6	5	22	0.017
	4	1425	100 L4	4.6	14.7	0.0075
	2	2840	90 L2	4.3	7.4	0.002
3	6	955	132 S6	6.5	30	0.038
	4	1415	100 L4	6.1	20.2	0.0098
	2	2870	100 L2	5.8	10	0.0044
4	6	955	132 M6	8.8	40	0.049
	4	1435	112 M4	8	26.6	0.014
	2	2880	112 M2	7.6	13	0.0075

Power (kW)	Poles	Base rpm	IEC Frame	Nominal current (A)	Nominal torque (Nm)	Inertia (kgm²)
110	6	991	315 SM	202	1060	4.9
	4	1487	315 SM	192	706	2.3
	2	2982	315 SM	194	352	1.2
132	6	991	315 ML	240	1272	5.8
	4	1487	315 SM	232	848	2.6
	2	2982	315 SM	228	423	1.4
160	6	992	355 S	280	1540	10.4
	4	1486	315 SM	282	1028	2.9
	2	2981	315 SM	269	513	1.7
200	6	992	355 SM	355	1925	12.5
	4	1486	315 ML	351	1285	3.5
	2	2978	315 ML	334	641	2.1
250	6	992	355 SM	450	2407	12.5
	4	1487	355 S	430	1606	6.5
	2	2980	355 S	410	801	3.8

# **Further information**

## **Product and service inquiries**

Address any inquiries about the product to your local ABB representative, quoting the type designation and serial number of the unit in question. A listing of ABB sales, support and service contacts can be found by navigating to abb.com/searchchannels.

# **Product training**

For information on ABB product training, navigate to new.abb.com/service/training.

## **Providing feedback on ABB Drives manuals**

Your comments on our manuals are welcome. Navigate to new.abb.com/drives/manuals-feedback-form.

#### **Document library on the Internet**

You can find manuals and other product documents in PDF format on the Internet at abb.com/drives/documents.



abb.com/drives abb.com/drivespartners

