

ABB INDUSTRIAL DRIVES

# ACS880 PCP control program (option +N5200)

Firmware manual



#### List of related manuals

Lists of hyperlinks to product manuals	Code
ACS880-01 drives	9AKK105408A7004
ACS880-04 drive modules (200 to 710 kW, 300 to 700 hp)	9AKK105713A4819
ACS880-07 drives (45 to 710 kW, 50 to 700 hp)	9AKK105408A8149
ACS880-07 drives (560 to 2800 kW)	9AKK105713A6663
ACS880-17 drives (45 to 400 kW, 60 to 450 hp)	9AKK106930A3466
ACS880-17 drives (160 to 3200 kW)	9AKK106354A1499
ACS880-37 drives (45 to 400 kW, 60 to 450 hp)	9AKK106930A3467
ACS880-37 drives (160 to 3200 kW)	9AKK106354A1500
Other drive hardware manuals	
ACS880-04XT drive module packages (500 to 1200 kW) hardware manual	3AXD50000025169
ACS880-04 single drive module packages hardware manual	3AUA0000138495
ACS880-07CLC drives hardware manual	3AXD50000131457
ACS880-14 and -34 single drive packages hardware manual	3AXD50000022021
ACS880-104 inverter modules hardware manual	3AUA0000104271
ACS880-104LC inverter modules hardware manual	3AXD50000045610
ACS880-107 inverter units hardware manual	3AUA0000102519
Drive firmware manuals and guides	
ACS880 primary control program firmware manual	3AUA0000085967
ACS880 drives with primary control program, quick start-up guide	3AUA0000098062
ACS880 PCP control program firmware manual	3AXD50000016186
Adaptive programming application guide	3AXD50000028574
Drive application programming manual (IEC 61131-3)	3AUA0000127808
Option manuals and guides	
ACX-AP-x assistant control panels user's manual	3AUA0000085685
Drive composer Start-up and maintenance PC tool user's manual	3AUA0000094606

You can find manuals and other product documents in PDF format on the Internet. See section *Document library on the Internet* on the inside of the back cover. For manuals not available in the Document library, contact your local ABB representative.

Manuals and quick guides for I/O extension modules, fieldbus adapters, encoder interfaces, etc.

<sup>\*</sup>Available in the Document library.

### Firmware manual

ACS880 PCP control program (option +N5200)

Table of contents



2. Quick start-up guide for ACS880 drives



3. PCP control start-up



1. Introduction	
Contents of this chapter	
Licensing	
Safety instructions	
Target audience	
Contents of the manual	
Related documents	
Terms and abbreviations	
Cyber security disclaimer	
Cyber security disclaimer	. 15
2. Quick start-up guide for ACS880 drives	
About this guide	. 17
Before you start	. 17
Safety	. 17
Start-up	. 19
3. PCP control start-up	
Contents of this chapter	. 25
PCP control start-up	. 25
4. Using the control panel 5. PCP program features	
Contents of this chapter	. 31
Overview of PCP control program	
Construction of PCP system	
Progressive cavity pump (PCP)	. 32
Pump starting speed	
Settings	. 33
Pump level control	. 33
Timing diagram	. 34
Sleep and wake up function	. 35
Pump pressure protection	. 39
Timing diagram	. 40
Settings	40
Pump torque protection	. 40
Rod torque 1 function	
Rod torque 2 function	
Pump underload protection	
Timing diagram	. 44
Pump temperature protection	. 45

Timing diagram	
Settings	
Shutdown procedure	
Pump backspin control	
Start delay	
Brake confirmation	. 51
6. Standard program features	
Contents of this chapter	. 53
Local control vs. external control	. 54
Local control	. 54
External control	. 55
Operating modes of the drive	. 56
Speed control mode	
Frequency control mode	. 56
Drive configuration and programming	
Programming through parameters	
Adaptive programming	. 58
Application programming	
Control interfaces	. 59
Programmable analog inputs	. 59
Programmable analog outputs	. 59
Programmable digital inputs and outputs	
Programmable relay outputs	
Programmable I/O extensions	
Fieldbus control	
Control of a supply unit (LSU)	
Motor control	
Direct torque control (DTC)	
Reference ramping	
Constant speeds/frequencies	
Critical speeds/frequencies	
Speed controller autotune	
Oscillation damping	
Resonance frequency elimination	
Rush control	
Encoder support	
Jogging	
Scalar motor control	
Autophasing	
Flux braking	
DC magnetization	
Hexagonal motor flux pattern	
Application control	
Motor potentiometer	
DC voltage control	
Overvoltage control	
Undervoltage control (power loss ride-through)	
Voltage control and trip limits	
Brake chopper	. 93



Safety and protections	
Emergency stop	
Motor thermal protection	
Thermal protection of motor cable	
User load curve	
Automatic fault resets	
Other programmable protection functions	
Diagnostics	
Fault and warning messages, data logging	
Signal supervision	
Maintenance timers and counters	
Energy savings calculator	
Load analyzer	
Miscellaneous	
User parameter sets	
Parameter checksum calculation	
User lock	
Data storage parameters	
Reduced run function	
du/dt filter support	
Sine filter support	
Router mode for BCU control unit	109
7. Default control connections	
Contents of this chapter	
PCP I/O control connections	
Sensor connection examples	
Application control PCP	
Default parameter settings for the PCP	114
8. Parameters	
Contents of this chapter	117
Terms and abbreviations	
Summary of parameter groups	
Parameter listing	
01 Actual values	
03 Input references	
04 Warnings and faults	
05 Diagnostics	
06 Control and status words	
07 System info	
09 Pump actuals	
10 Standard DI, RO	
11 Standard DIO, FI, FO	
12 Standard Al	
13 Standard AO	
14 I/O extension module 1	
15 I/O extension module 2	
16 I/O extension module 3	



19 Operation mode	204
20 Start/stop/direction	206
21 Start/stop mode	215
22 Speed reference selection	223
23 Speed reference ramp	231
24 Speed reference conditioning	238
25 Speed control	243
26 Torque reference chain	254
28 Frequency reference chain	257
30 Limits	266
31 Fault functions	275
32 Supervision	285
33 Generic timer & counter	289
35 Motor thermal protection	297
36 Load analyzer	309
•	313
37 User load curve	316
43 Brake chopper	318
45 Energy efficiency	
46 Monitoring/scaling settings	321
47 Data storage	325
49 Panel port communication	327
50 Fieldbus adapter (FBA)	330
51 FBA A settings	339
52 FBA A data in	340
53 FBA A data out	341
54 FBA B settings	341
55 FBA B data in	342
56 FBA B data out	343
58 Embedded fieldbus	344
74 Pump setup	351
75 Pump level control	355
76 Pump pressure protection	358
77 Pump torque protection	359
78 Pump underload protection	362
79 Pump temperature protection	363
80 Pump backspin control	364
90 Feedback selection	366
91 Encoder module settings	376
92 Encoder 1 configuration	379
93 Encoder 2 configuration	386
94 LSU control	388
95 HW configuration	390
96 System	397
97 Motor control	409
98 User motor parameters	414
99 Motor data	416
200 Safety	424
206 I/O bus configuration	424
207 I/O bus service	424
208 I/O bus diagnostics	424
209 I/O bus fan identification	424



#### 9. Additional parameter data

•	
Contents of this chapter	425
Terms and abbreviations	425
Fieldbus addresses	425
Parameter groups 19	426
Parameter groups 1099	
10. Fault tracing	
Contents of this chapter	473
Safety	473
Indications	474
Warnings and faults	474
Pure events	474
Editable messages	474
Warning/fault history and analysis	
Event logs	475
Other data loggers	476
Parameters warning/fault information	476
QR code generation for mobile service application	477
Warning messages	478
Fault messages	
Auxiliary codes for line-side converter warnings	
Auxiliary codes for line-side converter faults	520
11. Fieldbus control through the embedded fieldbus interface (E	:FB)
What this chapter contains	525
System overview	525
Connecting the fieldbus to the drive	
Setting up the embedded fieldbus interface	
Setting the drive control parameters	528
Basics of the embedded fieldbus interface	530
Control word and Status word	531
References	531
Actual values	531
Data input/outputs	
Register addressing	532
About the control profiles	533
The ABB Drives profile	534
Control Word	534
Status Word	
State transition diagram	537
References	
Actual values	
Modbus holding register addresses	
The Transparent profile	
Modbus function codes	
Exception codes	



Discrete inputs (1xxxx reference set)	
12. Fieldbus control through a fieldbus adapter	
Contents of this chapter  System overview  Basics of fieldbus control interface  Control word and Status word  References  Actual values  Contents of fieldbus Control word (ABB Drives profile)  Contents of the fieldbus Status word (ABB Drives profile)  The state diagram (ABB Drives profile)  Setting up the drive for fieldbus control  Parameter setting example: FPBA (PROFIBUS DP)  Parameter setting example: Using PCP application through FPBA	549 551 552 552 553 554 556 557 558 559
13. Control chain diagrams	
Contents of this chapter  Speed reference source selection I for PCP application  Speed reference source selection I  Speed reference source selection II for PCP application  Speed reference source selection II  Speed reference ramping and shaping  Motor feedback configuration  Load feedback and position counter configuration  Speed error calculation  Speed controller  Frequency reference selection	565 566 567 568 569 570 571 572 573
Frequency reference modification	574





### Introduction

#### Contents of this chapter

This chapter describes the contents of the manual. It also contains information on the compatibility, safety and intended audience.

#### **Applicability**

This manual applies to the ACS880 PCP control program (option +N5200) application version 1.31.5.0 or later, and primary control program version 2.9x or later.

You can see firmware and loading package versions in parameters.

#### Example:

Parameter	Loading package version
07.04 Firmware name	AINFC
07.05 Firmware version	2.90.2.2
07.06 Loading package name	AOALC
07.07 Loading package version	1.64.0.0


This application program is based on IEC standard 61131-3. It is an in-house application, therefore the application code is locked and cannot be modified by the user.

The PCP control program (+N5200), version AOALx v1.31 or later comes with a license key on the ZMU-02 memory unit. The program activates only after recognizing

Device	License key
ZMU-02 memory unit license key	N8019 MU Interlock key - Oil Lifting
PCP software (loading package)	N8020 Licensed appl Oil Lifting

the key and correspondingly registers itself with the PCP software.

You can see the license information in the Drive Composer PC tool or in the ACS- AP-x control panel from **System info -> Licenses**.



If the program was loaded to a ZMU-02 memory unit without the license key, then the drive indicates a fault *64A5 Licensing fault*. See the auxiliary fault code in the Event logger to know the plus code of the missing license, in this case N8019. For further assistance, contact your local ABB representative.

#### Safety instructions

Obey all safety instructions for the drive.

- Read the complete safety instructions before you install, commission, or use
  the drive. The complete safety instructions are delivered with the drive as either
  part of the Hardware manual, or, in the case of ACS880 multidrives, as a separate
  document.
- Read the firmware function-specific warnings and notes before changing parameter values. These warnings and notes are included in the parameter descriptions presented in chapter *Parameters*.

#### Target audience

This manual is intended for people who design, commission, or operate the drive system.

#### Contents of the manual

This manual contains the following chapters:

- Quick start-up guide for ACS880 drives (page 17) describes the start-up sequence of the pump control program.
- PCP control start-up (page 27) describes the start-up sequence of the pump control program.
- Using the control panel (page 29) refers to the instructions for using the control panel.
- PCP program features (page 35) describes the program features specific to the progressive cavity pump (PCP) application.
- Standard program features (page 53) describes the control locations and operation modes as well as the program features that are not specific to PCP application.
- Default control connections (page 111) presents the default connection diagram of the PCP control application.
- Parameters (page 117) describes the parameters used to program the drive.
- Additional parameter data (page 425) contains further information on the parameters.
- Fault tracing (page 473) lists the warning and fault messages with possible causes and remedies.
- Fieldbus control through the embedded fieldbus interface (EFB) (page 525) describes the communication to and from a fieldbus network using the embedded fieldbus interface of the drive.
- Fieldbus control through a fieldbus adapter (page 549) describes the communication to and from a fieldbus network using an optional fieldbus adapter module.
- Control chain diagrams (page 563) shows the parameter structure within the drive

#### Related documents

**Note:** A guick start-up sequence for a speed control application is provided by ACS880 drives with primary control program, Quick start-up guide (3AUA0000098062), delivered with the drive.

A list of related manuals is printed on the inside of the front cover.

#### Terms and abbreviations

Term/abbreviation	Definition
AC 800M	Type of programmable controller manufactured by ABB.
ACS-AP-I	Type of control panel used with ACS880 drives
ACS-AP-W	
Al	Analog input; interface for analog input signals
AO	Analog output; interface for analog output signals
BCU	Type of control unit used in ACS880 drive systems, primarily those with parallel- connected inverter or supply modules.
CIO	I/O module for controlling cabinet fans
D2D	Drive-to-drive; communication link between drives that is implemented by application programming. See <i>Drive application programming manual</i> (IEC 61131-3) (3AUA0000127808 [English]).
DC link	DC circuit between rectifier and inverter
DI	Digital input; interface for digital input signals
DIO	Digital input/output; interface that can be used as a digital input or output
DO	Digital output; interface for digital output signals
Drive	Frequency converter for controlling AC motors. The drive consists of a rectifier and an inverter connected together by the DC link. In drives up to approximately 500 kW, these are integrated into a single module (drive module). Larger drives typically consist of separate supply and inverter units.  The ACS880 PCP control program is used to control the inverter part of the drive.
DriveBus	A communication link used by, for example, ABB controllers. ACS880 drives can be connected to the DriveBus link of the controller.
DTC	Direct torque control. See page 63.
EFB	Embedded fieldbus interface. See page 525.
FBA	Fieldbus adapter
FCAN-01	Optional CANopen adapter
FCNA-01	Optional ControlNet adapter
FDIO-01	Optional digital I/O extension module
FDNA-01	Optional DeviceNet <sup>TM</sup> adapter
FEA-03	Optional I/O extension adapter
FECA-01	Optional EtherCAT® adapter
FEN-01	Optional TTL encoder interface module
FEN-11	Optional absolute encoder interface module
FEN-21	Optional resolver interface module
FEN-31	Optional HTL encoder interface module
FEX-01	Optional temperature measurement module for potentially explosive atmospheres. Not released for sales at the time of publication.
FIO-01	Optional digital I/O extension module
FIO-11	Optional analog I/O extension module
FENA-11	Optional Ethernet/IP, Modbus/TCP and PROFINET IO adapter
FENA-21	Optional dual-port Ethernet/IP, Modbus/TCP and PROFINET IO adapter
FEX-01	Optional temperature measurement module for potentially explosive atmospheres. Not released for sales at the time of publication.

Term/abbreviation	Definition
FEPL-02	Optional POWERLINK adapter
FPBA-01	Optional PROFIBUS DP adapter
FPTC-01	Optional thermistor protection module. Not released for sales at the time of publication.
FPTC-02	Optional ATEX-certified thermistor protection module for potentially explosive atmospheres. Not released for sales at the time of publication.
FSCA-01	Optional Modbus/RTU adapter
FSO-xx	Optional safety functions module
HTL	High-threshold logic
IGBT	Insulated gate bipolar transistor; a voltage-controlled semiconductor type widely used in inverters due to their easy controllability and high switching frequency
INU-LSU	Type of optical DDCS communication link between two converters, for example the supply unit and the <i>Inverter unit</i> of a drive system.
Inverter unit	The part of the drive that converts DC to AC for the motor.
I/O	Input/Output
ISU	An IGBT supply unit; type of supply unit implemented using IGBT switching components, used in regenerative and low-harmonic drives.
ID run	Motor identification run. During the identification run, the drive will identify the characteristics of the motor for optimum motor control.
LSB	Least significant bit
LSW	Least significant word
ModuleBus	A communication link used by, for example, ABB controllers. ACS880 drives can be connected to the optical ModuleBus link of the controller.
MSB	Most significant bit
MSW	Most significant word
Network control	With fieldbus protocols based on the Common Industrial Protocol (CIP <sup>TM</sup> ), such as DeviceNet and Ethernet/IP, denotes the control of the drive using the Net Ctrl and Net Ref objects of the ODVAAC/DC Drive Profile. For more information, see <a href="https://www.odva.org">www.odva.org</a> , and the following manuals: FDNA-01 DeviceNet adapter module User's manual (3AFE68573360 [English]), and <a href="#feba-01/-11">FENA-01/-11</a> Ethernet adapter module User's manual (3AUA0000093568 [English]).
Parameter	User-adjustable operation instruction to the drive, or signal measured or calculated by the drive
PCP	Progressive cavity pump. See also Progressive cavity pump (PCP) on page 36.
PID controller	Proportional-integral-derivative controller. Drive speed control is based on PID algorithm.
PLC	Programmable logic controller
Power unit	Contains the power electronics and connections of the drive. The drive control unit is connected to the power unit.
PSL2	Protocol used in communication between the drive control unit and the <i>Power unit</i> ,
Prpm	Pump rpm, units for pump speed.
PTC	Positive temperature coefficient
PU	See Power unit.
RDCO-0x	DDCS communication module

#### 14 Introduction

Term/abbreviation	Definition
RFG	Ramp function generator.
RO	Relay output; interface for a digital output signal. Implemented with a relay.
SSI	Synchronous serial interface
STO	Safe torque off
Supply unit	The part of the drive that converts AC to DC. An IGBT supply unit ( <i>ISU</i> ) is also capable of feeding regenerative energy back into the supply network.
TTL	Transistor-transistor logic
UPS	Uninterrupted power supply; power supply equipment with battery to maintain output voltage during power failure
ZCON	Type of control board used in ACS880 drives. The board is either integrated into the drive or fitted in a plastic housing. See ZCU.
ZCU	Type of control unit used in ACS880 drives that consists of a ZCON board built into a plastic housing.  The control unit may be fitted onto the drive/inverter module, or installed separately.

#### Cyber security disclaimer

This product is designed to be connected to and to communicate information and data via a network interface. It is Customer's sole responsibility to provide and continuously ensure a secure connection between the product and Customer network or any other network (as the case may be). Customer shall establish and maintain any appropriate measures (such as but not limited to the installation of firewalls. application of authentication measures, encryption of data, installation of anti-virus programs, etc) to protect the product, the network, its system and the interface against any kind of security breaches, unauthorized access, interference, intrusion, leakage and/or theft of data or information. ABB and its affiliates are not liable for damages and/or losses related to such security breaches, any unauthorized access, interference, intrusion, leakage and/or theft of data or information.

See also section *User lock* (page 106).



### Quick start-up guide for **ACS880** drives

#### About this guide

This guide describes the basic start-up sequence of an ACS880 drive. Complete documentation of the drive firmware can be found in Firmware manual (see list of manuals on the inside of the front cover).



In this guide, the drive is set up using the start-up assistant on the ACS-AP-I control panel. The start-up assistant guides the user through the essential drive settings.

The start-up assistant is not available in the Drive composer PC tool as such, but the same settings (apart from those related to the control panel itself) can also be made through drive parameters using Drive composer. For more information, refer to Drive composer Start-up and maintenance PC tool User's manual (3AUA0000094606 [English]).

#### Before you start

Ensure that the drive has been mechanically and electrically installed as described in the appropriate Quick installation guide and/or Hardware manual.

The data presented on the rating plate of the motor is needed during the start-up.

#### Safety




WARNING! All electrical installation and maintenance work on the drive should be carried out by qualified electricians only.

Never work on the drive, the braking chopper circuit, the motor cable or the motor when power is applied to the drive. Always ensure by measuring that no voltage is actually present.




#### Start-up






Highlight Assistants on the menu using and and and press (Select).  A listing of available assistants appears.	Remote ACS880 0.0 rpm Assistants Basic setup QR code
	Back 15:00 Select
Highlight Basic setup on the menu using and and press (Select).  The first setting of the assistant appears.  At any point, use to return to the previous setting (and ultimately cancel the assistant).  During the assistant, a progress bar shows how much of the assistant has been completed.	Remote ACS880 0.0 rpm  Language Language changes take some time.  Not selected  English  Deutsch Italiano  Exit 10:57 Next
Highlight the desired language on the list using and and and then press (Next).  The default units settings appear.	Remote ACS880 0.0 rpm Localization Default units. International (SI) US standard (Imperial)  Back 10:58 Next
Highlight the desired unit on the list using A and and and then press (Next).  The Units settings appear.	Remote
To change any of the unit settings, highlight it on the list using ▲ and ▼ and then press ►.  As an example, the changing of unit is shown on the right.	Remote











kg

⊕

 $(\pm)$ 




6312/C3

(+)

6210/C3

IEC 34-1





	Switch to local control to ensure that external control is disabled by pressing the Localem key. Local control is indicated by the text "Local" in the top pane.	Remote	
		Motor torque	
		[% U.U]	
		Options 10:57 Menu	
	Highlight <b>Parameters</b> and press (Select).	Local	
		Back 11:02 Select	
	Highlight Complete list using ▲ and ▼ and press (Select).  A listing of parameter groups is displayed.	Local ACS880 0.0 rpm  Complete list  01 Actual values 03 Input references 04 Warnings and faults 05 Diagnostics 06 Control and status words  Back 11:02 Select	
Mak	e the following parameter settings in the same manne	ег.	
	99.13 Identification run request This parameter selects the mode of the identification run (DTC motor control mode only).  WARNING! The identification run modes marked thus * will run the motor in the forward direction (see below for details). Make sure it is safe to run the motor before choosing any of these modes.  *Normal mode should be selected whenever possible. The driven machinery must be de-coupled from the motor if  • the load torque is higher than 20%, or  • the machinery is not able to withstand the nominal torque transient during the identification run.  *Reduced mode should be selected if the mechanical losses are higher than 20%, ie. the load cannot be de-coupled, or full flux is required to keep the motor brake open (eg. with conical motors).  The Standstill mode should be selected if neither the *Normal or *Reduced mode can be used.  Notes:  • This mode cannot be used with a permanent magnet motor if the load torque is higher than 20% or nominal.  • Mechanical brake is not opened by the logic for the identification run.		
	Ensure that the Safe torque off and emergency stop circuits (if present) are closed.		
	Start the identification run by pressing the (Start) button.	A warning will indicate that the identification run is in progress.	





# **PCP** control start-up

#### Contents of this chapter

This chapter contains the start-up sequence of the PCP control program.

#### **PCP** control start-up

This section contains the following alternative control schemes for starting up the drive with the control program:

- High pressure switch set up
- Optional speed reduction at maximum torque

In addition, this section describes how to configure the following program features:

The checklist for PCP control start up is given below:

I/O wiring		
	Connect the digital and analog I/Os according to the wiring diagram shown in page 112.	
I/O wiring parameter settings		
	Select the source of the start for external control location 1 (EXT1).	20.01 Ext1 commands
	Select the level-triggered signal type.	20.02 Ext1 start trigger type
	Select the start signal. By default, the drive starts/stops according to the status of digital input DI1 (0 = Stop, 1 = Start).	20.03 Ext1 in1 source



	Select the way motor is stopped when the run enable signal switches off.	20.11 Run enable stop mode
	Select the source of the external run enable signal. If the run enable signal is switched off, the drive will not start.	20.12 Run enable 1 source
	Select the way motor is stopped when an emergency stop command is received.	21.04 Emergency stop mode
	Select the source of the emergency stop signal.	21.05 Emergency stop source
	Select the source of an external fault reset signal. The signal resets the drive after a fault trip if the cause of the fault no longer exists.	31.11 Fault reset selection
Basic pump set up		
	The following information is required to complete the set up:    Pump sheave diameter * gear box ratio	
	motor sheave diameter	
	Maximum rod torque in lbft or Nm.	
	Enable the pump functions.	74.01 Pump enable
	Define the transmission reduction ratio.	74.03 Gear reduction ratio
	Select the reference type between motor speed or pump speed.	74.04 Reference type
	Select the source for the speed reference.  Note: If parameter 74.05 Speed ref source is selected as Al1 scaled, set the minimum and maximum values of Al1.	74.05 Speed ref source 12.19 Al1 scaled at Al1 min 12.20 Al1 scaled at Al1 max
	Set the speed reference if parameter 74.05  Speed ref source is selected as Constant ref (Prpm, rpm or Hz).	74.06 Speed ref
	Define the minimum allowed rod/pump speed.  • Warning! This value must not be higher	74.07 Minimum speed



	Define the maximum allowed rod/pump speed.  Warning! This value must not be lower than 74.07 Minimum speed (Prpm, rpm or Hz).	74.08 Maximum speed
	Define maximum allowed torque reference (Nm or lbft).	74.19 Maximum torque
	Define the acceleration time for rod/pump: from zero to 74.08 Maximum speed (s).	74.10 Acc time
	Define the deceleration time for rod/pump: from 74.08 Maximum speed to zero speed.	74.11 Dec time
	Activate Backspin function to control the reverse rotation of pump caused by back flow.	80.01 Backspin enable
	Define the reference speed/frequency limit for the Backspin function (Prpm, rpm or Hz).	80.02 Backspin ref limit
	Warning! If 80.02 Backspin ref limit is set to 0, the Pump backspin control function is not effective.	
	Define the acceleration time for the Backspin function: from zero to 80.02 Backspin ref limit (s).	80.03 Backspin acc time
	Define a torque limit for the Backspin function. When the actual torque is below the limit, Backspin function is complete and it gives coast to stop command to the drive (Nm or lbft).	80.04 Backspin stop torque
	Set the speed reference regulation range for the Backspin function.	80.05 Backspin speed range trim
	<b>Note</b> : Default = 0% is recommended because it is the safe range for backspin operation to avoid rod damages and drive overvoltage.	
Check pump rotation		
	Set a small speed reference. Start the drive. The motor rotates at a slow rate. Check that the rotation is correct for the pump. If the rotation is not correct, power down the drive and swap two of the motor cables (V2 and W2) at the drive terminal block. Re-apply power and check the rotation again.	



_		
	Set back speed reference as required.	
	High pressure switch set ι	ір
	If high pressure switch is present, wire the switch between the +24 V (XD24:2 or XD24:4) on I/O control board and required DI (XDI:1-6).	
	Enable pump pressure protection function.	76.01 Pressure protection function
	Define the latching type for pump pressure protection.	76.02 Pressure protection latching
	Enable the source of digital feedback for high pressure protection.	76.03 Digital feedback source enable
	Select the source of digital feedback for high pressure protection.	76.04 Digital feedback source
	Optional speed reduction at maximum torque	
	If it is desired to reduce the speed at maximum torque in a situation as the sand entering into the pump, the following parameters need to be set. If pump is unable to overcome the high torque situation (the solids cannot pass through the pump), the parameters setting causes the drive to trip.	
	Select the display type to view the Rod torque limit for pump torque protection.	77.01 Rod torq limit display
	Enable the Rod torque 1 function for pump torque protection.	77.02 Rod torq1 function
	Select the Rod torque 1 limit type of the fault condition in 77.04 Rod torq1 limit.	77.03 Rod torq1 limit type
	<b>Note</b> : The warning <i>D204 Rod torque 1 limit</i> is displayed during the shutdown process.	
	Define the torque limit for Rod torque 1 function in engineering units (Nm, lbft or A).	77.04 Rod torq1 limit
	Define the speed limit for rod torque 1 functionality in engineering units (Prpm, rpm or Hz).	77.05 Rod torq1 speed
	Define the time period for confirming the high torque 1 condition(s).	77.06 Rod torq1 delay time





## Using the control panel

Refer to ACS-AP-x assistant control panels user's manual (3AUA0000085685 [English]).



### PCP program features

#### Contents of this chapter

This chapter describes the functions within the control program that are specific to PCP application, how to use them and how to program them to operate.

WARNING! Make sure that the machinery into which the drive is integrated fulfills the personnel safety regulations. Note that the frequency converter (a Complete Drive Module or a Basic Drive Module, as defined in IEC 61800-2), is not considered as a safety device mentioned in the European Machinery Directive and related harmonized standards. Thus, the personnel safety of the complete machinery must not be based on a specific frequency converter feature, but it has to be implemented as defined in the application specific regulations.

#### Overview of PCP control program

The Progressive cavity pumping (PCP) control program is a drive application program used in oil pump stations and other related areas that require pumping of viscous liquids. The control program includes functions for protection of the pump and optimization of production rates.

- **Protection** is provided by monitoring selectable input signals. The control program can shut down the pump during conditions that could harm the equipment.
- Optimization is performed through automatic pump speed adjustments based on control set points and limits.

The PCP application uses Direct torque control (DTC) with speed reference in rpm or Prpm.


The PCP control program also features an automatic backspin control feature that prevents the unit from uncontrolled reverse rotation caused by back flow of fluid.

See section Pump backspin control (page 47).

#### **Construction of PCP system**

ABB industrial drive modules with the pump control program can be used to control PCP pump.

#### Progressive cavity pump (PCP)



The PCP system consists of a surface drive, a drive string and a down hole PC pump. The PC pump comprises of a single helical-shaped rotor that turns inside a double helical elastomer-lined stator. The stator is attached to the production tubing string and remains stationary during pumping.


In most cases the rotor is attached to a sucker rod string which is suspended and rotated by the surface drive.

#### Pump starting speed

The pump starting speed function allows the user to define a starting speed and acceleration time to run the pump according to requirements. For example, a faster start up acceleration time can be used for cleaning purposes and slower acceleration time can be used for equipment protection. The user can enable this function using parameter 74.12 Starting speed enable. The pump runs at starting speed in the starting speed acceleration time and then releases control to run the pump at reference speed in the normal acceleration time.

## Timing diagram

At start, the pump starting speed function controls the pump to run in the start acceleration time. After a defined delay time is passed, the function releases control and the pumps shifts to normal acceleration time to reach the reference speed.



## Settings

Parameters: 74.12 Starting speed enable, 74.13 Starting speed, 74.14 Starting speed acc time and 74.15 Starting speed time delay.

Signals: 09.06 Motor speed reference and 09.14 Pump status word (Bit 14)

Warnings: -

Faults: -

# Pump level control


The pump level control is a fluid level PI regulator for maintaining fluid level at a certain set point. The pump speed is adjusted based on the requirements during the working process. The actual fluid level value comes through a dedicated input, that reads the signal from one or several sensors. The fluid level is maintained through continuous speed adjustment in PI regulator. The user can enable this function in the parameter 75.01 Level control enable.

Note: The pump level control provides fluid level data even if the level control is disabled. It is also possible to check the fluid level through pressure data, since the values are in direct relation.

# Timing diagram


#### Non-inverted level control

When feedback from fluid level source is higher than fluid level set point, the PI regulator output decreases, causing the speed reference to decrease. The grey shaded areas indicate fluid level maintained through continuous PI adjustment to speed.



#### Inverted level control

When feedback from fluid level source is higher than fluid level set point, the PI regulator output increases, causing the speed reference to increase. The grey shaded areas indicate fluid level maintained through continuous PI adjustment to speed.



## **Settings**

Parameters: 75.01 Level control enable (page 355) to 75.09 Level control invert (page 356).

Signals: 09.08 Fluid level (page 151).

Warnings: -

Faults: -

#### Sleep and wake up function

The sleep and wake up function reduces energy consumption by running the pump only when it is required. If start command is given then sleep function constantly monitor 09.15 Sleep feedback value and generates start and stop commands according to sleep and wake up levels. When condition for sleep mode is triggered (see timing diagram), then sleep function generates a stop command for the drive. The pump goes to backspin mode, if backspin function 80.01 Backspin enable is enabled. See Pump backspin control, 47). After this, the drive goes to sleep mode. If condition to wake up is triggered (see timing diagrams) then wake up function generates a start command for the drive. Sleep time is limited by parameter 75.40 Maximum sleep time. Wake up function generates start command if parameter 09.16 Sleep time exceeds maximum sleep time. To skip this function, set value of parameter 75.40 Maximum sleep time to 0.

Note: The sleep command is deactivated by the wake up command. The wake up level has higher priority than the sleep level.


The user can enable this function in the parameter 75.30 Sleep control enable. The user can also define the sleep level and delay time parameters according to process requirements. The user also defines the sleep limit type (parameter 75.32): whether sleep starts after 09.15 Sleep feedback value goes below the sleep limit (Low limit) or exceeds it (High limit).

The timing diagrams below illustrate the operation of the function:

- with the limit type selection as Low and High
- when the sleep limit is lower than the wake-up limit and vice versa.


#### Timing diagram 1

This diagram depicts the sleep region for sleep limit type as Low. In this limit type, sleep starts only after the sleep feedback value is below sleep level and wake up level. The sleep function is activated when the sleep feedback value reaches sleep level (see diagram, Sleep level < Wakeup level). The drive shifts to sleep mode after sleep delay time is passed. The sleep function is active until the sleep feedback value reaches the wakeup level (see diagram, Sleep level > Wakeup level). The wakeup function is activated when the sleep feedback value reaches wakeup level. The drive shifts to wakeup mode after wakeup delay time is passed.



#### Timing diagram 2

This diagram depicts the sleep region for sleep limit type as High. In this limit type, sleep starts only after the sleep feedback value is more than sleep level and wake up level. The sleep function is activated when the sleep feedback value reaches sleep level (see diagram, Sleep level > Wakeup level). The drive shifts to sleep mode after sleep delay time is passed. The sleep function is active until the sleep feedback value reaches wakeup level (see diagram, Sleep level < Wakeup level). The wakeup function is activated when the sleep feedback value reaches the wakeup level. The drive shifts to wakeup mode after the wakeup delay time is passed.



#### Settings

Parameters: 75.30 Sleep control enable (page 356) to 75.40 Maximum sleep time (page 358).

Signals: 09.14 Pump status word (Bit 10) (page 152), 09.15 Sleep feedback value (page 152) and 09.16 Sleep time (page 153).

Warnings: D207 Sleep mode (page 495).

Faults: -

# Pump pressure protection

The pump pressure protection function protects the pump from high pressure. The user can enable this function in the parameter 76.01 Pressure protection function. Pressure is monitored through analog or digital signals. In high pressure conditions, the pump pressure protection generates a stop command for the drive. The pump goes to backspin mode, if backspin function (80.01) is enabled.


As soon as the safe condition is stabilized, the drive ramps up again or remains stopped according to the selected option: Non latching type (pump starts automatically after clearing the high pressure condition), Latching type (pump trips instead of auto restarting), Latch zero speed (enables Non latching type if speed is below zero or enables Latching type if speed is above zero).

The user can also select the notification for high pump pressure reaction: Warning, Fault or a selection between them depending on the pump speed.

Note: The pump pressure protection function provides pressure data even when pressure protection is disabled.

## Timing diagram

The pump pressure function is activated when the measured pressure reaches the pressure limit. The pump goes to backspin mode after the delay time is passed and thereafter stops.



## Settings

Parameter group: 76 Pump pressure protection (page 358).

Signals: 09.09 Pressure (page 151) and 09.14 Pump status word (Bits 3, 4 and 5)

(page 152).

Warnings: *D201 Pressure* (page 494). Faults: *D101 Pressure fault* (page 516).

# **Pump torque protection**

The pump torque protection function protects the pump from overload or under load condition and triggers warnings and faults. This function is activated when the measured rod torque exceeds the defined torque limit and when the measured speed exceeds the defined speed limit. The rod torque protection is based on the measurement of rod torque value. This function also enables pump protection with motor current. The user can select this option in parameter 77.01 Rod torq limit display.

- If Torque is selected, there is rod torque protection.
- If Current is selected, there is motor current protection.

The rod torque function operates in two different modes: Rod torque 1 and Rod torque 2.

- In Rod torque 1, the function maintains torque constant and controls speed.
- In Rod torque 2, the function maintains speed constant and controls torque.

The user can select the Rod torque limit type as Low or High, based on the rod torque value at lower or higher side of the predefined limit.


- For limit type low, a hysteresis (of Rod torque \* 5%) is present in the comparator meaning, once the condition is set, it latches until the Rod torque increases to a value of [Rod torq1 limit + (Rod torque \* 0.05)].
- For limit type high, a hysteresis (of Rod torque \* 5%) is present in the comparator meaning, once the condition is set, it latches until the Rod torque decreases to a value of [Rod torq1 limit - (Rod torque \* 0.05)].

#### Rod torque 1 function

This function monitors the actual torque and speed values. If the torque and speed values exceed the defined Rod torque1 limits, the drive stops the motor and notifies a warning (D204). The user can enable this function in the parameter 77.02 Rod torg1 function. For under load protection, user can define the limit as low or high in parameter 77.03 Rod torg1 limit type.

#### Timing diagram

The Rod torque 1 function is activated after the pump torque signal reaches the defined torque and speed limit. The pump torque is maintained constant, while the pump speed drops to zero in the defined delay time. After the delay time is passed, the drive shifts to backspin control.



#### Settings

Parameters: 77.02 Rod torq1 function (page 360), 77.03 Rod torq1 limit type (page 360), 77.04 Rod torg1 limit (page 360), 77.05 Rod torg1 speed (page 360) and 77.06 Rod torq1 delay time (page 360).

Signals: 09.01 Rod torque (page 151), 09.02 Maximum rod torque (page 151), 09.05 Rod speed (page 151) and 09.14 Pump status word (Bit 7) (page 152).

Warnings: D204 Rod torque 1 limit (page 494). Faults: D103 Rod torque 1 limit fault (page 517).

## Rod torque 2 function

This function monitors the actual torque and speed values. If the torque and speed values exceed the defined Rod torque2 limits, the function adds an additional speed reference to maintain constant speed before the drive shifts to backspin control. The user can enable this function in the parameter 77.07 Rod torq2 function. For under load protection, user can define the limit as low or high in parameter 77.08 Rod torg2 limit type.


Low limit: The control program triggers the Torque pressure protection function when measured torque and speed are less than or equal to defined Torque2 limits for a period of time greater than the Rod torque2 delay time.

High limit: The control program triggers the Torque pressure protection function when measured torque and speed are greater than or equal to defined Torque2 limits for a period of time greater than Rod torque2 delay time.

## Timing diagram

This timing diagram depicts the Rod torque2 function with limit type as Low. The Rod torque 2 function is activated after the pump torque signal reaches the defined torque and speed limit. The pump speed is maintained constant, while the pump torque is

lowered below the limit in the defined delay time. After the delay time is passed, the drive shifts to backspin control.



#### Settings

Parameters, 77.07 Rod torg2 function (page 360), 77.08 Rod torg2 limit type (page 361), 77.09 Rod torg2 limit (page 361), 77.10 Rod torg2 delay time (page 361), 77.11 Rod torq2 additive speed ref (page 361), 77.12 Rod torq2 speed delay time (page 361), 77.13 Rod torg2 limit counter (page 361), and 77.14 Rod torg2 time window (page 361).

Signals: 09.01 Rod torque (page 151), 09.02 Maximum rod torque (page 151), 09.05 Rod speed (page 151) and 09.14 Pump status word (Bits 8 and 15) (page 152).

Warnings: D205 Rod torque 2 speed (page 495) and D206 Rod torque 2 limit (page *495*).

Faults: D104 Rod torque 2 limit fault (page 517).

# Pump underload protection

This function supervises the load condition of the pump. For example, fluid with gas, lack of fluid in the well or a broken rod. User can define the monitoring curve for the normal load if the function is speed (load points). If the load goes below the curve, the function detects an underload condition.


The pump underload protection is based on the measurement of rod torque value. This function also enables pump protection with motor current. The user can select this option in parameter 78.01 Underload limit display.

- If *Torque* is selected, there is rod torque protection.
- If *Current* is selected, there is motor current protection.

User can also select the reaction for the pump underload condition (78.02): Warning, Fault or no reaction. This function is based on linear interpolation method.

## Timing diagram

The points (X1, Y1), (X2, Y2) and (X3, Y3) on the user defined monitoring curve are taken as reference to calculate the underload condition. The actual rod torque is compared with the interpolated points on the curve. If the value lies below the curve, it is interpreted as underload condition. The pump underload protection function is active after the delay time is passed.



#### Settings

Parameter group: 78 Pump underload protection (page 362).

Signals: 09.01 Rod torque (page 151), 09.05 Rod speed (page 151) and 09.14 Pump status word (Bit 6) (page 152).

Warnings: D202 Underload (page 494).


Faults: D102 Underload fault (page 517).

# Pump temperature protection

This function protects the pump from overheating. User can select the reaction on overheating condition: Warning, Fault or no reaction. The temperature feedback comes through analog input (PT-100) or digital input (Klixon), or both the sources can be connected and used simultaneously. The pump temperature protection function provides temperature data through analog sensor even if temperature protection is disabled.

## Timing diagram

The measured temperature is compared against the defined fault and warning temperature limits. When the measured value reaches the warning limit, the temperature protection function is activated. After the delay time in 5 seconds, a warning message is triggered. The temperature protection function is still active. After the fault limit is reached, temperature monitoring continues. After the delay time in 5 seconds, the pump temperature protection generates a stop command for the drive. The pump goes to backspin mode, if backspin function (80.01) is enabled.



# **Settings**

Parameter group: 79 Pump temperature protection (page 363).

Signals: 09.10 Measured temperature (page 151) and 09.14 Pump status word (Bits 0, 1 and 2) (page 152).

Warnings: D200 Overtemperature (page 494).

Faults: D100 Overtemperature fault (page 516).

# Shutdown procedure

There are two ways to stop the drive: by coast stop or backspin control. If Backspin control is disabled, then the drive performs normal coast stop.

#### Pump backspin control

Pump backspin control protects the pump during shutdown process. Backspin control may be performed by two different function: backspin function and start delay function.

Backspin function eliminates the effect of uncontrollable rotation of the pump in opposite direction, that is caused by the back flow of fluid. Backspin function allows to keep this reverse rotation below the defined speed limit. This sequence can be performed with any stop command. User can enable this function using parameter 80.01 Backspin enable.

When zero speed is reached, the drive begins ramping to the backspin speed reference with an acceleration time in parameter 80.03 Backspin acc time. If the torque in the pump is driving the motor in the reverse direction, then the actual backspin speed is equal to the backspin speed reference. If torque in the pump is not driving the motor in reverse, the actual speed is not equal to backspin speed reference.


Backspin speed reference is based on actual torque.

```
Backspin Speed Ref = Backspin Limit - Actual Torque Filtered
* Backspin Limit *Backspin Speed Range
```

As torque decreases, backspin speed reference increases. If torque is constant, backspin speed range increases with the decrease in backspin speed reference. The following procedure and time scheme describes the operation of backspin function:

- 1. The Drive receives an external stop command and starts to decelerate the pump down along the defined ramp (74.11 Dec time).
- At zero speed, the fluid starts flowing back from the pipe. The function keeps the drive operational (delaying the internal stop command).
- Backward flow accelerates the pump in reverse direction. The Backspin function keeps the acceleration rate under the acceleration level (80.03 Backspin acc time).
- 4. The Backspin function keeps the reverse speed under the Backspin speed limit (80.05 Backspin speed range trim) until the back flow starts running out and the torque starts decreasing.
- When the actual torque goes below the limit (80.04 Backspin stop torque), the function does not stop and initiates the Coast to stop command to the drive.
- If the actual torque stays below the limit (80.04 Backspin stop torque) longer than
  the time set in parameter (80.06 Backspin stop delay) then the controlled
  backspin function is complete.

#### **Timing diagram**



## **Settings**

Parameters: 80.01 Backspin enable (page 364), 80.02 Backspin ref limit (page 364), 80.03 Backspin acc time (page 364), 80.04 Backspin stop torque (page 364) and 80.05 Backspin speed range trim (page 365) and 80.06 Backspin stop delay (page 365).

Signals: 09.11 Backspin speed reference (page 151) and 09.13 Backspin status word (bits 0, 1 and 2) (page 152).

Warnings: D208 Backspin limit (page 495) and D209 Backspin active (page 495).

Faults: -

# Start delay

Start delay function blocks any start command after stop command is given. User can enable this function using parameter 80.11 Restart delay enable. Pump cannot start during defined time period 80.12 Restart delay time. This delay time has to be equal or longer than time period needed to complete the shutdown process.

If the Backspin control function is active when the drive is supposed to do a restart (after the delay), drive does not start but it decelerates to zero speed first. The Backspin deceleration time 80.21 Backspin dec time defines the deceleration ramp. When the speed is zero, the drive starts and accelerates to the speed reference with the normal acceleration ramp (74.10 Acc time)

Note: If the deceleration time 80.21 Backspin dec time for the Backspin control is zero, drive uses the normal deceleration ramp 74.11 Dec time to reach the zero speed before the restart.

Time remained to allow drive to start is indicating in actual signal 09.12 Start delay remain.

If drive is stopped due to power failure and then after power supply is retained, the stopped time period will be deducted from start delay time. In case, if battery of ZCU board is empty, time will not be deducted from start delay time in case of power failure.

## Settinas

Parameters: 80.11 Restart delay enable (page 365), 80.12 Restart delay time (page 365) and 80.21 Backspin dec time (page 366).


Signals: 09.12 Start delay remain (page 152), 09.13 Backspin status word (bits 10 and 11) (page 152).

Warnings: D20C Start delay active (page 495).

Faults: -

## **Brake confirmation**

The brake confirmation function is optional. This function controls the operation of the mechanical brake. If a pressure feedback is available from the mechanical brake then this function can be used to detect the failure of the brake before starting the pump. If the mechanical brake is defective, this function generates a fault and also forbids the start command.



## Settings

Parameters: 74.21 Brake confirmation enable (page 354), 74.22 Brake confirmation source (page 354), 74.23 Brake confirmation limit (page 354), 74.24 Brake confirmation speed (page 354) and 74.25 Brake confirmation time (page 354).

Signals: 09.14 Pump status word (Bit 13) (page 152).

Warnings: D20A Brake confirmation active (page 495).

Faults: D105 Brake confirmation fault (page 517).



# Standard program features


# Contents of this chapter

The control program contains all of the parameters (including actual signals) within the drive. This chapter describes some of the more important functions within the control program, how to use them and how to program them to operate.

WARNING! Make sure that the machinery into which the drive is integrated fulfills the personnel safety regulations. Note that the frequency converter (a Complete Drive Module or a Basic Drive Module, as defined in IEC 61800-2), is not considered as a safety device mentioned in the European Machinery Directive and related harmonized standards. Thus, the personnel safety of the complete machinery must not be based on a specific frequency converter feature, but it has to be implemented as defined in the application specific regulations.

## Local control vs. external control

The ACS880 has two main control locations: external and local. The control location is selected with the Loc/Rem key on the control panel or in the PC tool.



- 1) Extra inputs/outputs can be added by installing optional I/O extension modules (FIO-xx) in drive slots.
- Encoder or resolver interface module(s) (FEN-xx) installed in drive slots.

#### Local control

The control commands are given from the control panel keypad or from a PC equipped with Drive composer when the drive is in local control. Speed control mode is available for local control; frequency mode is available when scalar motor control mode is used. See parameter 19.16 Local control mode (page 205).

Local control is mainly used during commissioning and maintenance. The control panel always overrides the external control signal sources when used in local control. Changing the control location to local can be prevented by parameter 19.17 Local control disable (page 205).

Select the parameter 49.05 Communication loss action (page 328) and check how the drive reacts to a control panel or PC tool communication break (the parameter has no effect in external control).

#### External control

When the drive is in external control, control commands are given through:

- I/O terminals (digital and analog inputs), or optional I/O extension modules
- · embedded fieldbus interface or an optional fieldbus adapter module
- · control panel.

Two external control locations, EXT1 and EXT2 are available. The user can select the sources of start and stop commands separately for each location using parameters 20.01...20.10. Select the operating mode separately for each location (in parameter group 19 Operation mode), which enables guick switching between different operating modes. For example, speed control. Selection between EXT1 and EXT2 is done through any binary source such as a digital input or fieldbus control word (see parameter 19.11 Ext1/Ext2 selection (page 204). The source of reference is selectable for each operating mode separately.

The control location selection is checked on a 2 ms time level.

#### Using the control panel as an external control source

The control panel can also be used as a source of start/stop commands and/or reference in external control. Selections for the control panel are available in the start/stop command source and reference source selection parameters.

Reference source selection parameters (except PID setpoint selectors) have two selections for the control panel. The difference between the two selections is in the initial reference value after the reference source switches to the control panel.


The panel reference is saved whenever another reference source is selected. If the reference source selection parameter is set to Control panel (ref saved), the saved value is used as the initial reference when control switches back to the panel. Note that only one type of reference can be saved at a time; for example, attempting to use the same saved reference with different operating modes (speed etc.) causes the drive to trip on 7083 Panel reference conflict. The panel reference can be separately limited by parameters in group 49 Panel port communication.

With the reference source selection parameter set to Control panel (ref copied), the initial panel reference value depends on whether the operating mode changes with the reference source. If the source switches to the panel and the operating mode does not change, the last reference from the previous source is adopted. If the operating mode changes, the drive actual value corresponding to the new mode is adopted as the initial value.

# Operating modes of the drive

The drive operates in several operating modes with different types of reference. The mode is selectable for each control location (Local, EXT1 and EXT2) in parameter group 19 Operation mode.

The following is a general representation of the reference types and control chains. The page numbers refer to detailed diagrams in chapter Control chain diagrams.



# Speed control mode

The motor follows a speed reference given to the drive. This mode is used either with estimated speed used as feedback, or with an encoder or resolver for better speed control accuracy.

Speed control mode is available in both local and external control. It is also available both in DTC (Direct Torque Control) and scalar motor control modes.

# Frequency control mode


The motor follows a frequency reference given to the drive. Frequency control is only available for scalar motor control.

# **Drive configuration and programming**

The drive control program is divided into two parts:

- firmware program
- application program.

## Drive control program



The firmware program performs the main control functions, including speed control, drive logic (start/stop), I/O, feedback, communication and protection functions. Firmware functions are configured and programmed with parameters, and can be extended by application programming.

## **Programming through parameters**

Parameters configure all the standard drive operations and can be set through

- the control panel, as described in chapter Using the control panel
- the Drive composer PC tool, as described in Drive composer user's manual (3AUA0000094606 [English]), or
- the fieldbus interface, as described in chapters Fieldbus control through the embedded fieldbus interface (EFB) and Fieldbus control through a fieldbus adapter.

All parameter settings are stored automatically to the permanent memory of the drive. However, if an external +24 V DC power supply is used for the drive control unit, it is highly recommended to force a save by using parameter 96.07 Parameter save manually before powering down the control unit after any parameter changes have been made.

If necessary, the default parameter values can be restored by parameter 96.06 Parameter restore.

## Adaptive programming

Conventionally, the user can control the operation of the drive by parameters. However, the standard parameters have a fixed set of choices or a setting range. To further customize the operation of the drive, an adaptive program can be constructed out of a set of function blocks.

The Drive composer PC tool has an Adaptive programming feature with a graphical user interface for building the custom program. The function blocks include the usual arithmetic and logical functions, as well as eg. selection, comparison and timer blocks. The program can contain a maximum of 20 blocks. The adaptive program is executed on a 10 ms time level.

For selecting input to the program, the user interface has pre-selections for the physical inputs, common actual values, and other status information of the drive. Parameter values as well as constants can also be defined as inputs. The output of the program can be used eq. as a start signal, external event or reference, or connected to the drive outputs. Note that connecting the output of the adaptive program to a selection parameter will write-protect the parameter.

The status of the adaptive program is shown by parameter 07.30 Adaptive program status. The adaptive program can be disabled by 96.70 Disable adaptive program.

Please note that sequential programming is not supported.

For more information, see the Adaptive programming application guide (3AXD50000028574 [English]).

## Application programming

The functions of the firmware program can be extended with application programming. Application programmability is available as option +N8010.

Application programs can be built with function blocks based on the IEC 61131-3 standard using a PC tool available separately.

For more information, see *Drive Programming manual: Drive application* programming (IEC 61131-3) (3AUA0000127808 [English]).

#### Control interfaces

## Programmable analog inputs

The control unit has two programmable analog inputs. Each of the inputs can be independently set as a voltage (0/2...10 V or -10...10 V) or current (0/4...20 mA) input by a jumper or switch on the control unit. Each input can be filtered, inverted and scaled. The analog inputs on the control unit are read on a 0.5 ms time level.

The number of analog inputs are increased by installing FIO-11 or FAIO-01 I/O extensions (see *Programmable I/O extensions* below). The analog inputs on extension modules are read on a 2 ms time level.

The drive can be set to perform an action (for example, to generate a warning or fault) if the value of an analog input moves out of a predefined range.

#### **Settings**

See parameter group 12 Standard AI (page 167).

# Programmable analog outputs

The control unit has two current (0...20 mA) analog outputs. Each output is filtered, inverted and scaled. The analog outputs on the control unit are updated on a 0.5 ms time level

The number of analog outputs can be increased by installing FIO-11 or FAIO-01 I/O extensions (see Programmable I/O extensions below). The analog outputs on extension modules are updated on a 2 ms time level.

## **Settings**

See parameter group 13 Standard AO.

# Programmable digital inputs and outputs

The control unit has six digital inputs, a digital start interlock input, and two digital input/outputs (I/O that can be set as either an input or an output). The digital inputs on the control unit are read on a 0.5 ms time level.

One digital input (DI6) doubles as a PTC thermistor input. See section Motor thermal protection (page 94).

Digital input/output DIO1 is used as a frequency input, DIO2 as a frequency output.

The number of digital inputs/outputs can be increased by installing FIO-01, FIO-11 or FDIO-01 I/O extensions (see *Programmable I/O extensions* below). The digital inputs on extension modules are read on a 2 ms time level.

#### Settings

See parameter groups 10 Standard DI, RO (page 155) and 11 Standard DIO, FI, FO (page 162).

#### Programmable relay outputs

The control unit has three relay outputs. The signal to be indicated by the outputs can be selected by parameters. The relay outputs on the control unit are updated on a 0.5 ms time level.

Relay outputs can be added by installing FIO-01 or FDIO-01 I/O extensions. The relay outputs on extension modules are updated on a 2 ms time level.

#### Settings

See parameter group 10 Standard DI, RO (page 155).

## Programmable I/O extensions

Inputs and outputs are added using I/O extension modules. One to three modules can be mounted on the slots of the control unit. Slots can be added by connecting an FEA-03 I/O extension adapter.

The table below shows the number of I/O on the control unit as well as optional I/O extension modules.

Location	Digital inputs (DI)	Digital I/Os (DIO)	Analog inputs (AI)	Analog outputs (AO)	Relay outputs (RO)
Control unit	6 + DIIL	2	2	2	3
FIO-01	-	4	-	-	2
FIO-11	-	2	3	1	-
FAIO-01	-	1	2	2	-
FDIO-01	3	1	ı	-	2

Three I/O extension modules are activated and configured using parameter groups 14...16.

Note: Each configuration parameter group contains parameters that display the values of the inputs on that particular extension module. These parameters are the only way of utilizing the inputs on I/O extension modules as signal sources. To connect to an input, choose the setting Other in the source selector parameter, then specify the appropriate value parameter (and bit, for digital signals) in group 14, 15 or 16.

#### Settings

Parameter groups 14 I/O extension module 1 (page 175), 15 I/O extension module 2 (page 196) and 16 I/O extension module 3 (page 200).

#### Fieldbus control

The drive is connected to several different automation systems through its fieldbus interfaces. See chapter Fieldbus control through a fieldbus adapter (page 549) and Fieldbus control through a fieldbus adapter (page 549).

#### Settings

Parameter groups 50 Fieldbus adapter (FBA) (page 330), 51 FBA A settings (page 339), 52 FBA A data in (page 340), 53 FBA A data out (page 341), 54 FBA B settings (page 341), 55 FBA B data in (page 342), 56 FBA B data out (page 343) and 58 Embedded fieldbus (page 344).

## Control of a supply unit (LSU)

#### General

If the drive has separately-controlled supply and inverter units (also known as lineside and motor-side converters), the supply unit can be controlled through the inverter unit. For example, the inverter unit can send a control word and references to the supply unit, enabling the control of both units from the interfaces of one control program.

With ACS880 single drives, the two control units are connected at the factory. In ACS880 multidrives (drive systems with one supply unit and multiple inverter units), the feature is not typically used.

#### Communication

The communication between the converters and the drive consists of data sets of three 16-bit words each. The inverter unit sends a data set to the supply unit, which returns the next data set to the inverter unit.

The communication uses data sets 10 and 11, updated at 2 ms intervals. Data sets 10 is sent by the inverter unit to the supply unit, while data set 11 is sent by the supply unit to the inverter unit. The contents of the data sets are freely configurable, but data set 10 typically contains the control word, while data set 11 returns the status word.

The basic communication is initialized by parameter 95.20 HW options word 1. This will make several parameters visible (see below).

## Settings

Parameters 01.102...01.164 (page 124), 05.111...05.121 (page 134), 06.36...06.43 (page 142), 06.43...06.118 (page 143), 07.106...07.107 (page 150), 30.101...30.149 (page 273), 31.120...31.121 (page 285), 95.20 HW options word 1 (page 395) and 96.08 LSU control board boot (page 408).

#### Motor control

## Direct torque control (DTC)

The motor control of the ACS880 is based on direct torque control (DTC). The switching of the output semiconductors is controlled to achieve the required stator flux and motor torque. The switching frequency is changed only if the actual torque and stator flux values differ from their reference values by more than the allowed hysteresis. The reference value for the torque controller comes from the speed controller, DC voltage controller or directly from an external torque reference source.

Motor control requires measurement of DC voltage and two motor phase currents. Stator flux is calculated by integrating the motor voltage in vector space. Motor torque is calculated as a cross product of the stator flux and the rotor current. By utilizing the identified motor model, the stator flux estimate is improved. Actual motor shaft speed is not needed for motor control.

The main difference between traditional control and DTC is that torque control operates on the same time level as the power switch control. There is no separate frequency controlled PWM modulator. The output stage switching is based on the electromagnetic state of the motor.

The best motor control accuracy is achieved by activating a separate motor identification run (ID run).

See also section Scalar motor control (page 81).

## **Settings**

Parameters 99.04 Motor ctrl mode (page 417) and 99.13 ID run requested (page 420).

# Reference ramping

Acceleration and deceleration ramping times can be set individually for speed and frequency reference.

With a speed or frequency reference, the ramps are defined as the time it takes for the drive to accelerate or decelerate between zero speed or frequency and the value defined by parameter 46.01 Speed scaling or 46.02 Frequency scaling. The user can switch between two preset ramp sets using a binary source such as a digital input. For speed reference, the shape of the ramp can be controlled.

With a torque reference, the ramps are defined as the time it takes for the reference to change between zero and nominal motor torque (parameter 01.30 Nominal torque scale).

#### Special acceleration/deceleration ramps

The acceleration/deceleration times for the jogging function can be defined separately; see section Jogging (page 78).

The change rate of the motor potentiometer function (page 89) is adjustable. The same rate applies in both directions.

A deceleration ramp can be defined for emergency stop ("Off3" mode).

#### Settings

- Speed reference ramping: Parameters 23.11...23.19 and 46.01 (pages 232 and 321).
- Frequency reference ramping: Parameters 28.71...28.75 and 46.02 (pages 263 and 321).
- Jogging: Parameters 23.20 and 23.21 (page 235).
- Motor potentiometer: Parameter 22.75 (page 230).
- Emergency stop ("Off3" mode): Parameter 23.23 Emergency stop time (page 235).

#### Constant speeds/frequencies

Constant speeds and frequencies are predefined references that can be quickly activated, for example, through digital inputs. It is possible to define up to 7 constant speeds for speed control and 7 constant frequencies for frequency control.



WARNING: Constant speeds and frequencies override the normal reference irrespective of where the reference is coming from.

The constant speeds/frequencies function operates on a 2 ms time level.

#### Settings

Parameter groups 22 Speed reference selection (page 223) and 28 Frequency reference chain (page 257).

## Critical speeds/frequencies

Critical speeds (sometimes called "skip speeds") can be predefined for applications where it is necessary to avoid certain motor speeds or speed ranges because of, for example, mechanical resonance problems.

The critical speeds function prevents the reference from dwelling within a critical band for extended times. When a changing reference (22.87 Speed reference act 7) enters a critical range, the output of the function (22.01 Speed ref unlimited) freezes until the reference exits the range. Any instant change in the output is smoothed out by the ramping function further in the reference chain.


The function is also available for scalar motor control with a frequency reference. The input of the function is shown by 28.96 Frequency ref act 7, the output by 28.97 Frequency ref unlimited.

#### Example

A fan has vibrations in the range of 540 to 690 rpm and 1380 to 1560 rpm. To make the drive jump over these speed ranges,

- enable the critical speeds function by turning on bit 0 of parameter 22.51 Critical speed function, and
- set the critical speed ranges as shown in the figure below.

22.01 Speed ref unlimited (rpm) (output function)



1	Par. 22.52 = 540 rpm
2	Par. 22.53 = 690 rpm
3	Par. 22.54 = 1380 rpm
4	Par. 22.55 = 1560 rpm

22.87 Speed reference act 7 (rpm) (input of function)

#### Settings

- Critical speeds: parameters 22.51...22.57 (page 228)
- Critical frequencies: parameters 28.51...28.57 (page 262).


## Speed controller autotune

The speed controller of the drive can be automatically adjusted using the autotune function. Autotuning is based on an estimation of the mechanical time constant (inertia) of the motor and machine.

The autotune routine will run the motor through a series of acceleration/deceleration cycles, the number of which can be adjusted by parameter 25.40 Autotune repeat times. Higher values will produce more accurate results, especially if the difference between initial and maximum speeds is small.

The maximum torque reference used during autotuning will be the initial torque (ie. torque when the routine is activated) plus 25.38 Autotune torque step, unless limited by the maximum torque limit (parameter group 30 Limits) or the nominal motor torque (99 Motor data). The calculated maximum speed during the routine is the initial speed (ie. speed when the routine is activated) + 25.39 Autotune speed step, unless limited by 30.12 Maximum speed or 99.09 Motor nominal speed.

The diagram below shows the behavior of speed and torque during the autotune routine. In this example, 25.40 Autotune repeat times is set to 2.



#### Notes:

- If the drive cannot produce the requested braking power during the routine, the results will be based on the acceleration stages only, and not as accurate as with full braking power.
- The motor will exceed the calculated maximum speed slightly at the end of each acceleration stage.

#### Before activating the autotune routine

The prerequisites for performing the autotune routine are:

- The motor identification run (ID run) has been successfully completed
- Speed and torque limits (parameter group 30 Limits) have been set
- The speed feedback has been monitored for noise, vibrations and other disturbances caused by the mechanics of the system, and
  - speed feedback filtering (parameter group 90 Feedback selection)
  - speed error filtering (24 Speed reference conditioning) and
  - zero speed (parameters 21.06 and 21.07)


have been set to eliminate these disturbances.

The drive has been started and is running in speed control mode.

After these conditions have been fulfilled, autotuning can be activated by parameter 25.33 Speed controller autotune (or the signal source selected by it).

#### Autotune modes

Autotuning can be performed in three different ways depending on the setting of parameter 25.34 Speed controller autotune mode. The selections Smooth, Normal and Tight define how the drive torque reference should react to a speed reference step after tuning. The selection *Smooth* will produce a slow but robust response; Tight will produce a fast response but possibly too high gain values for some applications. The figure below shows speed responses at a speed reference step (typically 1...20%).



- A: Under-compensated
- B: Normally tuned (autotuning)
- C: Normally tuned (manually). Better dynamic performance than with B
- D: Overcompensated speed controller


#### Autotune results

At the end of a successful autotune routine, its results are automatically transferred into parameters

- 25.02 Speed proportional gain (proportional gain of the speed controller)
- 25.03 Speed integration time (integration time of the speed controller)
- 25.37 Mechanical time constant (mechanical time constant of the motor and machine).

Nevertheless, it is still possible to manually adjust the controller gain, integration time and derivation time.

The figure below is a simplified block diagram of the speed controller. The controller output is the reference for the torque controller.



## Warning indications

A warning message, AF90 Speed controller autotuning, will be generated if the autotune routine does not complete successfully. See chapter Fault tracing (page 473) for further information.

## Settings

Parameters 25.33...25.40 (page 252).

# Oscillation damping

The oscillation damping function can be used to cancel out oscillations caused by mechanics or an oscillating DC voltage. The input – a signal reflecting the oscillation - is selected by parameter 26.53 Oscillation compensation input. The oscillation damping function outputs a sine wave (26.58 Oscillation damping output) which can be summed with the torque reference with a suitable gain (26.57 Oscillation damping gain) and phase shift (26.56 Oscillation damping phase).

The oscillation damping algorithm can be activated without connecting the output to the reference chain, which makes it possible to compare the input and output of the function and make further adjustments before applying the result.

#### Tuning procedure for oscillation damping

Select the input by 26.53 Oscillation compensation input Activate algorithm by 26.51 Oscillation damping Set 26.57 Oscillation damping gain to 0 Calculate the oscillation frequency from the signal (use the Drive composer PC tool) and set 26.55 Oscillation damping frequency Set 26.56 Oscillation damping phase\* Increase 26.57 Oscillation damping gain gradually so that the algorithm starts to take effect. oscillation amplitude decreases oscillation amplitude increases Increase 26.57 Oscillation damping gain Try other values for 26.56 Oscillation and adjust 26.56 Oscillation damping damping phase phase if necessary \*If the phasing of a DC oscillation cannot be determined by measuring, the value of 0 Increase 26.57 Oscillation damping gain to degrees is usually a suitable initial value. suppress the oscillation totally.

Note: Changing the speed error low-pass filter time constant or the integration time of the speed controller can affect the tuning of the oscillation damping algorithm. It is recommended to tune the speed controller before the oscillation damping algorithm. (The speed controller gain can be adjusted after the tuning of this algorithm.)

#### Settings

Parameters 26.51 Oscillation damping ... 26.58 Oscillation damping output (page 255).

# Resonance frequency elimination


The control program contains a notch filter function for removing the resonance frequencies from the speed error signal.

# Settings

Parameters 24.13...24.17 (page 239).

#### Rush control

In torque control, the motor could potentially rush if the load were suddenly lost. The control program has a rush control function that decreases the torque reference whenever the motor speed exceeds 30.11 Minimum speed or 30.12 Maximum speed.



The function is based on a PI controller. The proportional gain and integration time can be defined by parameters. Setting these to zero disables rush control.

# Settings

Parameters 26.81 Rush control gain (page 257) and 26.82 Rush control integration time (page 257).

# **Encoder support**

The control program supports two single-turn or multi turn encoders (or resolvers). The following optional interface modules are available:

- TTL encoder interface FEN-01—two TTL inputs, TTL output (for encoder emulation and echo) and two digital inputs
- Absolute encoder interface FEN-11—absolute encoder input, TTL input, TTL output (for encoder emulation and echo) and two digital inputs
- · Resolver interface FEN-21—resolver input, TTL input, TTL output (for encoder emulation and echo) and two digital inputs
- HTL encoder interface FEN-31—HTL encoder input, TTL output (for encoder emulation and echo) and two digital inputs
- HTL/TTL encoder interface FSE-31 (for use with an FSO-xx safety functions module): Two HTL/TTL encoder inputs (one HTL input supported at the time of publication).

The interface module is installed onto any optional slot on the drive control unit. The module (except FSE-31) can also be installed onto an FEA-03 extension adapter.

#### Encoder echo and emulation

Both encoder echo and emulation are supported by the above-mentioned FEN-xx interfaces.

Encoder echo is available with TTL, TTL+ and HTL encoders. The signal received from the encoder is relayed to the TTL output unchanged. This enables the connection of one encoder to several drives.


Encoder emulation also relays the encoder signal to the output, but the signal is either scaled, or position data converted to pulses. Emulation can be used when absolute encoder or resolver position needs to be converted to TTL pulses, or when the signal must be converted to a different pulse number than the original.

#### Load and motor feedback

Three different sources can be used as speed and position feedback: encoder 1, encoder 2, or motor position estimate. Any of these can be used for load position calculation or motor control. The load position calculation makes it possible, for example, to determine the position of a conveyor belt or the height of the load on a crane. The feedback sources are selected by parameters 90.41 Motor feedback selection and 90.51 Load feedback selection.

For detailed parameter connections of the motor and load feedback functions, see the block diagrams on pages 569 and 570. For more information on load position calculation, see section *Position counter* (page 73).

Any mechanical gear ratios between the components (motor, motor encoder, load, load encoder) are specified using the gear parameters shown in the diagram below.



Any gear ratio between the load encoder and the load is defined by 90.53 Load gear numerator and 90.54 Load gear denominator. Similarly, any gear ratio between the motor encoder and the motor is defined by 90.43 Motor gear numerator and 90.44 Motor gear denominator. In case the internal estimated position is chosen as load feedback, the gear ratio between the motor and load can be defined by 90.61 Gear numerator and 90.62 Gear denominator. By default, all of the ratios


mentioned above are 1:1. The ratios can only be changed with the drive stopped; new settings require validation by 91.10 Encoder parameter refresh.

#### Position counter

The control program contains a position counter feature that can be used to indicate the position of a load. The output of the counter function, parameter 90.07 Load position scaled int. indicates the scaled number of revolutions read from the selected source (see section Load and motor feedback (page 72).

The relation between revolutions of the motor shaft and the translatory movement of the load (in any given unit of distance) is defined by parameters 90.63 Feed constant numerator and 90.64 Feed constant denominator. This gear function can be changed without the need of a parameter refresh or position counter reinitialization. However, the counter output is only updated after new position input data is received.

For detailed parameter connections of the feedback function, see the block diagram on page 570.



The position counter is initialized by setting a known physical position of the load into the control program. The initial position (for example, the home/zero position, or the distance from it) can be entered manually in a parameter (90.58 Pos counter init value int), or taken from another parameter. This position is set as the value of the position counter (90.07 Load position scaled int) when the source selected by 90.67 Pos counter init cmd source, such as a proximity switch connected to a digital input, is activated. A successful initialization is indicated by bit 4 of 90.35 Pos counter status.

Any subsequent initialization of the counter must first be enabled by 90.69 Reset pos counter init ready. To define a time window for initializations, 90.68 Disable pos counter initialization can be used to inhibit the signal from the proximity switch. An active fault in the drive will also prevent counter initialization.

#### **Encoder error handling**

When an encoder is used for load feedback, the action taken in case of an encoder error is specified by 90.55 Load feedback fault. If the parameter is set to Warning, the calculation will continue smoothly using estimated motor position. If the encoder recovers from the error, the calculation will smoothly switch back to encoder feedback. The load position signals (90.04, 90.05 and 90.07) will continue to be updated all the time, but bit 6 of 90.35 Pos counter status will be set to indicate potentially inaccurate position data. In addition, bit 4 of 90.35 will be cleared upon the next stop as a recommendation to reinitialize the position counter.

Parameter 90.60 Pos counter error and boot action defines whether position calculation resumes from the previous value over an encoder error or control unit reboot. By default, bit 4 of 90.35 Pos counter status is cleared after an error, indicating that reinitialization is needed. With 90.60 set to Continue from previous value, the position values are retained over an error or reboot; bit 6 of 90.35 is set however to indicate that an error occurred.

**Note:** With a multiturn absolute encoder, bit 6 of 90.35 is cleared at the next stop of the drive if the encoder has recovered from the error; bit 4 is not cleared. The status of the position counter is retained over a control unit reboot, after which position calculation resumes from the absolute position given by the encoder, taking into account the initial position specified by 90.58.

**WARNING!** If the drive is in stopped state when an encoder error occurs, or if the drive is not powered, parameters 90.04, 90.05, 90.07 and 90.35 are not updated because no movement of the load can be detected. When using previous position values (90.60 Pos counter error and boot action is set to Continue from previous value), be aware that the position data is unreliable if the load is able to move

#### Reading/writing position counter values through fieldbus

The parameters of the position counter function, such as 90.07 Load position scaled int and 90.58 Pos counter init value int, can be accessed from an upper-level control system in the following formats:

- 16-bit integer (if 16 bits are sufficient for the application)
- 32-bit integer (can be accessed as two consequent 16-bit words)

For example, to read parameter 90.07 Load position scaled int through fieldbus, set the selection parameter of the desired dataset (in group 52) to Other – 90.07, and select the format. If you select a 32-bit format, the subsequent data word is also automatically reserved.

## Configuration of HTL encoder motor feedback

- 1. Specify the type of the encoder interface module (parameter 91.11 Module 1 type = FEN-31) and the slot the module is installed into (91.12 Module 1 location).
- 2. Specify the type of the encoder (92.01 Encoder 1 type = HTL). The parameter listing will be re-read from the drive after the value is changed.
- 3. Specify the interface module that the encoder is connected to (92.02 Encoder 1 source = Module 1).
- 4. Set the number of pulses according to encoder nameplate (92.10 Pulses/revolution).
- 5. If the encoder rotates at a different speed to the motor (ie. is not mounted directly on the motor shaft), enter the gear ratio in 90.43 Motor gear numerator and 90.44 Motor gear denominator.
- 6. Set parameter 91.10 Encoder parameter refresh to Refresh to apply the new parameter settings. The parameter will automatically revert to *Done*.
- 7. Check that 91.02 Module 1 status is showing the correct interface module type (FEN-31). Also check the status of the module; both LEDs should be glowing green.
- 8. Start the motor with a reference of eg. 400 rpm.
- 9. Compare the estimated speed (01.02 Motor speed estimated) with the measured speed (01.04 Encoder 1 speed filtered). If the values are the same, set the encoder as the feedback source (90.41 Motor feedback selection = Encoder 1).
- 10. Specify the action taken in case the feedback signal is lost (90.45 Motor feedback fault).

# Example 1: Using the same encoder for both load and motor feedback

The drive controls a motor used for lifting a load in a crane. An encoder attached to the motor shaft is used as feedback for motor control. The same encoder is also used for calculating the height of the load in the desired unit. A gear exists between the motor shaft and the cable drum. The encoder is configured as Encoder 1 as shown in Configuration of HTL encoder motor feedback above. In addition, the following settings are made:

- (90.43 Motor gear numerator = 1)
- (90.44 Motor gear denominator = 1)

(No gear is needed as the encoder is mounted directly on the motor shaft.)

- 90.51 Load feedback selection = Encoder 1
- (90.53 Load gear numerator = 1)
- 90.54 Load gear denominator = 50

The cable drum turns one revolution per 50 revolutions of the motor shaft.

• (90.61 Gear numerator = 1)

(90.62 Gear denominator = 1)

(These parameters need not be changed as position estimate is not being used for feedback.)

- 90.63 Feed constant numerator = 7
- 90.64 Feed constant denominator = 10

The load moves 70 centimeters, ie. 7/10 of a meter, per one revolution of the cable drum.

The load height in meters can be read from 90.07 Load position scaled int, while 90.03 Load speed displays the rotational speed of the cable drum.

### Example 2: Using two encoders

One encoder (encoder 1) is used for motor feedback. The encoder is connected to the motor shaft through a gear. Another encoder (encoder 2) measures the line speed elsewhere in the machine. Each encoder is configured as shown in Configuration of HTL encoder motor feedback above. In addition, the following settings are made:

- (90.41 Motor feedback selection = Encoder 1)
- (90.43 Motor gear numerator = 1)
- 90.44 Motor gear denominator = 3

The encoder turns three revolutions per one revolution of the motor shaft.

90.51 Load feedback selection = Encoder 2

The line speed measured by encoder 2 can be read from 90.03 Load speed. This value is given in rpm which can be converted into another unit by using 90.53 Load gear numerator and 90.54 Load gear denominator. Note that the feed constant gear cannot be used in this conversion because it does not affect 90.03 Load speed.

### Example 3: ACS 600 / ACS800 compatibility

With ACS 600 and ACS800 drives, both the rising and falling edges from encoder channels A and B are typically counted to achieve best possible accuracy. Thus the received pulse number per revolution equals four times the nominal pulse number of the encoder.

In this example, an HTL-type 2048-pulse encoder is fitted directly on the motor shaft. The desired initial position to correspond the proximity switch is 66770.

In the ACS880, the following settings are made:

- 92.01 Encoder 1 type = HTL
- 92.02 Encoder 1 source = Module 1
- 92.10 Pulses/revolution = 2048
- 92.13 Position estimation enable = Enable
- 90.51 Load feedback selection = Encoder 1
- 90.63 Feed constant numerator = 8192 (ie. 4 × value of 92.10, as the received number of pulses is 4 times nominal. See also parameter 92.12 Resolver polepairs)
- The desired "data out" parameter is set to Other 90.58 Pos counter init value int (32-bit format). Only the high word needs to be specified – the subsequent data word is reserved for the low word automatically.
- The desired sources (such as digital inputs or user bits of the control word) are selected in 90.67 Pos counter init cmd source and 90.69 Reset pos counter init readv.

In the PLC, if the initial value is set in 32-bit format using low and high words (corresponding to ACS800 parameters POS COUNT INIT LO and POS COUNT INIT HI), enter the value 66770 into these words as follows:

### Eq. PROFIBUS:

- FBA data out x = POS COUNT INIT HI = 1 (as bit 16 equals 66536)
- FBA data out (x + 1) = POS COUNT INIT LO = 1234.

ABB Automation using DDCS communication, eg.:

- Data set 12.1 = POS COUNT INIT HI
- Data set 12.2 = POS COUNT INIT I O

To test the configuration of the PLC, initialize the position counter with the encoder connected. The initial value sent from the PLC should immediately be reflected by 90.07 Load position scaled int in the drive. The same value should then appear in the PLC after having been read from the drive.

### **Settings**

Parameter groups 90 Feedback selection (page 366), 91 Encoder module settings (page 376), 92 Encoder 1 configuration (page 379) and 93 Encoder 2 configuration (page 386).

# Jogging


The jogging function enables the use of a momentary switch to briefly rotate the motor. The jogging function is typically used during servicing or commissioning to control the machinery locally.

Two jogging functions (1 and 2) are available, each with their own activation sources and references. The signal sources are selected by parameters 20.26 Jogging 1 start source and 20.27 Jogging 2 start source. When jogging is activated, the drive starts and accelerates to the defined jogging speed (22.42 Jogging 1 ref or 22.43 Jogging 2 ref) along the defined jogging acceleration ramp (23.20 Acc time jogging). After the activation signal switches off, the drive decelerates to a stop along the defined jogging deceleration ramp (23.21 Dec time jogging).

The figure and table below provide an example of how the drive operates during jogging. In the example, the ramp stop mode is used (see parameter 21.03 Stop mode).

Jog cmd = State of source set by 20.26 Jogging 1 start source or 20.27 Jogging 2 start source

Jog enable = State of source set by 20.25 Jogging enable Start cmd = State of drive start command.



Phase	Jog cmd	Jog enable	Start cmd	Description		
1-2	1	1	0	Drive accelerates to the jogging speed along the acceleration ramp of the jogging function.		
2-3	1	1	0	Drive follows the jog reference.		
3-4	0	1	0	Drive decelerates to zero speed along the deceleration ramp of the jogging function.		
4-5	0	1	0	Drive is stopped.		
5-6	1	1	0	Drive accelerates to the jogging speed along the acceleration ramp of the jogging function.		
6-7	1	1	0	Drive follows the jog reference.		
7-8	0	1	0	Drive decelerates to zero speed along the deceleration ramp of the jogging function.		
8-9	0	1→0	0	Drive is stopped. As long as the jog enable signal is on, start commands are ignored. After jog enable switches off, a fresh start command is required.		
9-10	х	0	1	Drive accelerates to the speed reference along the selected acceleration ramp (parameters 23.1123.19).		
10-11	Х	0	1	Drive follows the speed reference.		
11-12	х	0	0	Drive decelerates to zero speed along the selected deceleration ramp (parameters 23.1123.19).		
12-13	Х	0	0	Drive is stopped.		
13-14	Х	0	1	Drive accelerates to the speed reference along the selected acceleration ramp (parameters 23.1123.19).		

Phase	Jog cmd	Jog enable	Start cmd	Description		
14-15	х	0→1	1	Drive follows the speed reference. As long as the start command is on, the jog enable signal is ignored. If the jog enable signal is on when the start command switches off, jogging is enabled immediately.		
15-16	0→1	1	0	Start command switches off. The drive starts to decelerate along the selected deceleration ramp (parameters 23.1123.19).  When the jog command switches on, the decelerating drive adopts the deceleration ramp of the jogging function.		
16-17	1	1	0	Drive follows the jog reference.		
17-18	0	1→0	0	Drive decelerates along the deceleration ramp of the jogging function.		
18-19	0	0	0	Drive decelerates to zero speed along the selected deceleration ramp (parameters 23.1123.19).		

See also the block diagram on page 568.

The jogging function operates on a 2 ms time level.

#### Notes:

- Jogging is not available when the drive is in local control.
- Jogging cannot be enabled when the drive start command is on, or the drive started when jogging is enabled. Starting the drive after the jog enable switches off requires a fresh start command.



**WARNING!** If jogging is enabled and activated while the start command is on, jogging will activate as soon as the start command switches off.

- If both jogging functions are activated, the one that was activated first has priority.
- Jogging uses the speed control mode.
- Ramp shape times (parameters 23.16...23.19) do not apply to jogging acceleration/deceleration ramps.
- The inching functions activated through fieldbus (see 06.01 Main control word, bits 8...9) use the references and ramp times defined for jogging, but do not require the jog enable signal.

#### Settings

Parameters 20.25 Jogging enable (page 214), 20.26 Jogging 1 start source (page 20.27), 20.27 Jogging 2 start source (page 20.30), 22.42 Jogging 1 ref (page 228), 22.43 Jogging 2 ref (page 228), 23.20 Acc time jogging (page 235) and 23.21 Dec time jogging (page 235).

#### Scalar motor control

Scalar control is the motor control method used instead of DTC (Direct Torque Control). In scalar control mode, the drive is controlled with a speed or frequency reference. However, the outstanding performance of DTC is not achieved in scalar control.

It is recommended to activate scalar motor control mode:

- If the nominal current of the motor is less than 1/6 of the nominal output current of the drive
- If the drive is used without a motor connected (for example, for test purposes)
- If the drive runs a medium-voltage motor through a step-up transformer, or
- · In multi motor drives, if
  - the load is not equally shared between the motors
  - the motors are of different sizes or
  - the motors are changed after motor identification (ID run)

In scalar control, some standard features are not available.


See also section Operating modes of the drive (page 56).

#### IR compensation for scalar motor control

IR compensation (also known as voltage boost) is available only when the motor control mode is scalar. When IR compensation is activated, the drive gives an extra voltage boost to the motor at low speeds. IR compensation is useful in applications that require a high break-away torque. In step-up applications, voltage cannot be fed through the transformer at 0 Hz, so an additional breakpoint is available for defining the compensation near zero frequency.

In Direct Torque Control (DTC), no IR compensation is possible or needed as it is applied automatically.





## Settings

Parameter group 28 Frequency reference chain (page 257).

Parameters 19.20 Scalar control reference unit (page 205), 97.12 IR comp step-up frequency (page 411), 97.13 IR compensation (page 412) and 99.04 Motor ctrl mode (page 417).


# Autophasing

Autophasing is an automatic measurement routine to determine the angular position of the magnetic flux of a permanent magnet synchronous motor or the magnetic axis of a synchronous reluctance motor. The motor control requires the absolute position of the rotor flux in order to control motor torque accurately.

Sensors like absolute encoders and resolvers indicate the rotor position at all times after the offset between the zero angle of rotor and that of the sensor are established. On the other hand, a standard pulse encoder determines the rotor position when it rotates but the initial position is not known. However, a pulse encoder can be used as an absolute encoder if it is equipped with Hall sensors, albeit with coarse initial position accuracy. The Hall sensors generate commutation pulses that change their state six times during one revolution. It is only known within which 60° sector of a complete revolution the initial position is.

Many encoders give a zero pulse (also called Z-pulse) once during each rotation. The position of the zero pulse is fixed. If this position is known with respect to zero position used by motor control, the rotor position at the instant of the zero pulse is also known.

Using the zero pulse improves the robustness of the rotor position measurement. The rotor position must be determined during starting because the initial value given by the encoder is zero. The autophasing routine determines the position, but there is a risk of some position error. If the zero pulse position is known in advance, the position found by autophasing can be corrected as soon as the zero pulse is detected for the first time after starting.



The autophasing routine is performed with permanent magnet synchronous motors and synchronous reluctance motors in the following cases:

- 1. One-time measurement of the rotor and encoder position difference when an absolute encoder, a resolver, or an encoder with commutation signal is used
- 2. At every power-up when an incremental encoder is used
- 3. With open-loop motor control, repetitive measurement of the rotor position at every start
- 4. When the position of the zero pulse must be measured before the first start after power-up.

Note: In closed-loop control, autophasing is performed automatically after the motor identification run (ID run). Autophasing is also performed automatically before starting when necessary.

In open-loop control, the zero angle of the rotor is determined before starting. In closed-loop control, the actual angle of the rotor is determined with autophasing when the sensor indicates zero angle. The offset of the angle must be determined because the actual zero angles of the sensor and the rotor do not usually match. The autophasing mode determines how this operation is done both in open-loop and closed-loop control.

The rotor position offset used in motor control can also be given by the user – see parameter 98.15 Position offset user. Note that the autophasing routine also writes its result into this parameter. The results are updated even if user settings are not enabled by 98.01 User motor model mode.

Note: In open-loop control, the motor always turns when it is started as the shaft is turned towards the remanence flux.

Bit 4 of 06.21 Drive status word 3 indicates if the rotor position has already been determined.

#### Autophasing modes

Several autophasing modes are available (see parameter 21.13 Autophasing mode).

The turning mode (*Turning*) is recommended especially with case 1 (see the list above) as it is the most robust and accurate method. In turning mode, the motor shaft is turned back and forward (±360/polepairs)° in order to determine the rotor position. In case 3 (open-loop control), the shaft is turned only in one direction and the angle is smaller.

Another turning mode, Turning with Z-pulse, can be used if there is difficulty using the normal turning mode, for example, because of significant friction. With this mode, the rotor is turned slowly until a zero pulse is detected from the encoder. When the zero pulse is detected for the first time, its position is stored into parameter 98.15 Position offset user, which can be edited for fine-tuning. Note that it is not mandatory to use this mode with a zero pulse encoder. In open-loop control, the two turning modes are identical.

The standstill modes (Standstill 1, Standstill 2) can be used if the motor cannot be turned (for example, when the load is connected). As the characteristics of motors and loads differ, testing must be done to find out the most suitable standstill mode.

The drive is capable of determining the rotor position when started into a running motor in open-loop or closed-loop control. In this situation, the setting of 21.13 Autophasing mode has no effect.

The autophasing routine can fail and therefore it is recommended to perform the routine several times and check the value of parameter 98.15 Position offset user. An autophasing fault (3385 Autophasing) can occur with a running motor if the estimated angle of the motor differs too much from the measured angle. This could be caused by, for example, the following:


- The encoder is slipping on the motor shaft
- An incorrect value has been entered into 98.15 Position offset user
- The motor is already turning before the autophasing routine is started
- Turning mode is selected in 21.13 Autophasing mode but the motor shaft is locked
- Turning with Z-pulse mode is selected in 21.13 Autophasing mode but no zero pulse is detected within a revolution of the motor
- The wrong motor type is selected in 99.03 Motor type
- Motor ID run has failed.

#### Settings

Parameters 06.21 Drive status word 3 (page 140), 21.13 Autophasing mode (page 221), 98.15 Position offset user (page 416), 99.13 ID run requested (420).

## Flux braking

The drive can provide greater deceleration by raising the level of magnetization in the motor. By increasing the motor flux, the energy generated by the motor during braking can be converted to motor thermal energy.



The drive monitors the motor status continuously, also during flux braking. Therefore, flux braking can be used both for stopping the motor and for changing the speed. The other benefits of flux braking are:

- The braking starts immediately after a stop command is given. The function does not need to wait for the flux reduction before it can start the braking.
- The cooling of the induction motor is efficient. The stator current of the motor increases during flux braking, not the rotor current. The stator cools much more efficiently than the rotor.
- Flux braking is used with induction motors and permanent magnet synchronous motors.

Two braking power levels are available:

- Moderate braking provides faster deceleration compared to a situation where flux braking is disabled. The flux level of the motor is limited to prevent excessive heating of the motor.
- Full braking exploits almost all available current to convert the mechanical braking energy to motor thermal energy. Braking time is shorter compared to moderate braking. In cyclic use, motor heating may be significant.



**WARNING:** The motor needs to be rated to absorb the thermal energy generated by flux braking.

# Settings

Parameter 97.05 Flux braking (page 409).

## DC magnetization

DC magnetization can be applied to the motor to

- heat the motor to remove or prevent condensation, or
- to lock the rotor at, or near, zero speed.

#### Pre-heating

A motor pre-heating function is available to prevent condensation in a stopped motor, or to remove condensation from the motor before start. Pre-heating involves feeding a DC current into the motor to heat up the windings.

Pre-heating is deactivated at start, or when one of the other DC magnetization functions is activated. With the drive stopped, pre-heating is disabled by the safe torque off function, a drive fault state, or the process PID sleep function. Pre-heating can only start after one minute has elapsed from stopping the drive.


A digital source to control pre-heating is selected by parameter 21.14 Pre-heating input source. The heating current is set by 21.16 Pre-heating current.

#### Pre-magnetization

Pre-magnetization refers to DC magnetization of the motor before start. Depending on the selected start mode (21.01 Start mode or 21.19 Scalar start mode), premagnetization is applied to guarantee the highest possible breakaway torque, up to 200% of the nominal torque of the motor. By adjusting the pre-magnetization time (21.02 Magnetization time), it is possible to synchronize the motor start and, for example, the release of a mechanical brake.

#### DC hold

The function makes it possible to lock the rotor at or near zero speed in the middle of normal operation. DC hold is activated by parameter 21.08 DC current control. When both the reference and motor speed drop below a certain level (parameter 21.09 DC hold speed), the drive stops generating sinusoidal current and start to inject DC into the motor. The current is set by parameter 21.10 DC current reference. When the reference exceeds parameter 21.09 DC hold speed, normal drive operation continues.



#### Note:

- DC hold is only available in speed control in DTC motor control mode (see page **56**).
- The function applies the DC current to one phase only, depending on the position of the rotor. The return current will be shared between the other phases.

### Post-magnetization

This feature keeps the motor magnetized for a certain period (parameter 21.11 Post magnetization time) after stopping. This is to prevent the machinery from moving under load, for example before a mechanical brake can be applied. Postmagnetization is activated by parameter 21.08 DC current control. The magnetization current is set by parameter 21.10 DC current reference.

Note: Post-magnetization is only available in speed control in DC motor control mode (see page 56), and only when ramping is the selected stop mode (see parameter 21.03 Stop mode).

#### Continuous magnetization

A digital signal, such as a user bit in the fieldbus control word, can be selected to activate continuous magnetization. This can be especially useful in processes requiring motors to be stopped (for example, to stand by until new material is processed), then guickly started without magnetizing them first.

**Note:** Continuous magnetization is only available in speed control in DTC motor control mode (see page 56), and only when ramping is the selected stop mode (see parameter 21.03 Stop mode).



**WARNING:** The motor must be designed to absorb or dissipate the thermal energy generated by continuous magnetization, for example by forced ventilation.

#### Settings

Parameters 21.01 Start mode (page 215), 21.02 Magnetization time (page 216), 21.08...21.12 (page 220), 21.14 Pre-heating input source (page 222), and 21.16 Preheating current (page 21.16).

# Hexagonal motor flux pattern

**Note:** This feature is only available in scalar motor control mode (see page 56).

Typically, the drive controls the motor flux so that the rotating flux vector follows a circular pattern. This is ideal for most applications. However, when operating above the field weakening point (FWP), it is not possible to reach 100% of the output voltage. This reduces the peak load capacity of the drive.

Using a hexagonal motor flux vector pattern, the maximum output voltage can be reached above the field weakening point. This increases the peak load capacity compared to the circular pattern, but the continuous load capacity in the range of FWP ... 1.6 × FWP is reduced because of increasing losses. With hexagonal motor flux active, the pattern changes from circular to hexagonal gradually as the frequency rises from 100% to 120% of the FWP.

# Settings

Parameters 97.18 Hexagonal field weakening and 97.19 Hexagonal field weakening point (page 412).

# **Application control**

See chapter *Default control connections* (page 111).


# Motor potentiometer


The motor potentiometer is, in effect, a counter whose value can be adjusted up and down using two digital signals selected by parameters 22.73 Motor potentiometer up source and 22.74 Motor potentiometer down source. Note that these signals have no effect when the drive is stopped.

When enabled by 22.71 Motor potentiometer function, the motor potentiometer assumes the value set by 22.72 Motor potentiometer initial value. Depending on the mode selected in 22.71, the motor potentiometer value is either retained or reset over a stop or a power cycle.

The change rate is defined in 22.75 Motor potentiometer ramp time as the time it would take for the value to change from the minimum (22.76 Motor potentiometer min value) to the maximum (22.77 Motor potentiometer max value) or vice versa. If the up and down signals are simultaneously on, the motor potentiometer value does not change.

The output of the function is shown by 22.80 Motor potentiometer ref act, which can directly be set as the source of any selector parameter such as 22.11 Speed ref1 source.





#### Settings

Parameters 22.71...22.80 (page 229).

# DC voltage control


## Overvoltage control

Overvoltage control of the intermediate DC link is typically needed when the motor is in generating mode. The motor can generate when it decelerates or when the load overhauls the motor shaft, causing the shaft to turn faster than the applied speed or frequency. To prevent the DC voltage from exceeding the overvoltage control limit, the overvoltage controller automatically decreases the generating torque when the limit is reached. The overvoltage controller also increases any programmed deceleration times if the limit is reached; to achieve shorter deceleration times, a brake chopper and resistor may be required.

## Undervoltage control (power loss ride-through)

If the incoming supply voltage is cut off, the drive will continue to operate by utilizing the kinetic energy of the rotating motor. The drive will be fully operational as long as the motor rotates and generates energy to the drive. The drive can continue operation after the break if the main contactor (if present) remained closed.

Note: Units equipped with a main contactor must be equipped with a hold circuit (example UPS) to keep the contactor control circuit closed during a short supply break



 $U_{\rm DC}$ = intermediate circuit voltage of the drive,  $f_{\rm out}$  = output frequency of the drive,  $T_{\rm M}$  = motor torque Loss of supply voltage at nominal load ( $f_{out} = 40 \text{ Hz}$ ). The intermediate circuit DC voltage drops to the minimum limit. The controller keeps the voltage steady as long as the mains is switched off. The drive runs the motor in generator mode. The motor speed falls but the drive is operational as long as the motor has enough kinetic energy.

#### Automatic restart

It is possible to restart the drive automatically after a short (maximum 5 seconds) power supply failure by using the Automatic restart function provided that the drive is allowed to run for 5 seconds without the cooling fans operating.

When enabled, the function takes the following actions upon a supply failure to enable a successful restart:

- The undervoltage fault is suppressed (but a warning is generated)
- Modulation and cooling is stopped to conserve any remaining energy
- DC circuit pre-charging is enabled.

If the DC voltage is restored before the expiration of the period defined by parameter 21.18 Auto restart time and the start signal is still on, normal operation will continue. However, if the DC voltage remains too low at that point, the drive trips on a fault, 3280 Standby timeout.

WARNING! Before you activate the function, make sure that no dangerous situations can occur. The function restarts the drive automatically and continues operation after a supply break.

# Voltage control and trip limits

The control and trip limits of the intermediate DC voltage regulator are relative to the supply voltage as well as drive/inverter type. The DC voltage is approximately 1.35 times the line-to-line supply voltage, and is displayed by parameter 01.11 DC voltage.

All levels are relative to the supply voltage range selected in parameter 95.01 Supply voltage. The following table shows the values of selected DC voltage levels in volts and in percent of  $U_{DCmax}$  (the DC voltage at the upper bound of the supply voltage range).

	Supply voltage range [V AC] (see 95.01 Supply voltage)						
Level [V DC (% of UDCmax)]	208240	380415	440480	500	525600	660690	
Overvoltage fault limit	489/440*	800	878	880	1113	1218	
Overvoltage control limit	405 (125)	700 (125)	810 (125)	810 (120)	1013 (125)	1167 (125)	
Internal brake chopper at 100% pulse width	403 (124)	697 (124)	806 (124)	806 (119)	1008 (124)	1159 (124)	
Internal brake chopper at 0% pulse width	375 (116)	648 (116)	749 (116)	780 (116)	936 (116)	1077 (116)	
Overvoltage warning limit	373 (115)	644 (115)	745 (115)	776 (115)	932 (115)	1071 (115)	
U <sub>DCmax</sub> = DC voltage at upper bound of supply voltage range	324 (100)	560 (100)	648 (100)	675 (100)	810 (100)	932 (100)	
DC voltage at lower bound of supply voltage range	281	513	594	675	709	891	
Undervoltage control and warning limit	239 (85)	436 (85)	505 (85)	574 (85)	602 (85)	757 (85)	
Charging activation/standby limit	225 (80)	410 (80)	475 (80)	540 (80)	567 (80)	713 (80)	
Undervoltage fault limit	168 (60)	308 (60)	356 (60)	405 (60)	425 (60)	535 (60)	

<sup>\*489</sup> V with frames R1...R3, 440 V with frames R4...R8.

#### Settings

Parameters 01.11 DC voltage (page 122), 30.30 Overvoltage control (page 272), 30.31 Undervoltage control (page 272), 95.01 Supply voltage (page 390) and 95.02 Adaptive voltage limits (page 390).

# Brake chopper

A brake chopper can be used to handle the energy generated by a decelerating motor. When the DC voltage rises high enough, the chopper connects the DC circuit to an external brake resistor. The chopper operates on the pulse width modulation principle.

Some ACS880 drives have an internal brake chopper as standard, some have a brake chopper available as an internal or external option. See the appropriate hardware manual or sales catalog.

The internal brake choppers of ACS880 drives start conducting when the DC link voltage reaches 1.156 ×  $U_{DCmax}$ . 100% pulse width is reached at approximately 1.2 × U<sub>DCmax</sub>, depending on supply voltage range. See table under Voltage control and trip limits (page 92). (U<sub>DCmax</sub> is the DC voltage corresponding to the maximum of the AC supply voltage range)

For information on external brake choppers, refer to their documentation.

Note: For runtime braking, overvoltage control (parameter 30.30 Overvoltage control) needs to be disabled for the chopper to operate.

### **Settings**

Parameter group 43 Brake chopper (page 316).

See parameter 01.11 DC voltage (page 122) and 30.30 Overvoltage control (page 272).

# Safety and protections

# Emergency stop

The emergency stop signal is connected to the input selected by parameter 21.05 Emergency stop source. An emergency stop can also be generated through fieldbus (parameter 06.01 Main control word, bits 0...2).

The mode of the emergency stop is selected by parameter 21.04 Emergency stop *mode*. The following modes are available:

- Off1: Stop along the standard deceleration ramp defined for the particular reference type in use
- · Off2: Stop by coasting
- Off3: Stop by the emergency stop ramp defined by parameter 23.23 Emergency stop time.

With Off1 or Off3 emergency stop modes, the ramp-down of the motor speed can be supervised by parameters 31.32 Emergency ramp supervision and 31.33 Emergency ramp supervision delay.

#### Notes:

- For SIL 3 / PL e-level emergency stop functions, the drive can be fitted with a TÜV-certified FSO-xx safety options module. The module can then be incorporated into certified safety systems.
- The installer of the equipment is responsible for installing the emergency stop devices and all additional devices needed for the emergency stop function to fulfill the required emergency stop categories. For more information, contact your local ABB representative.
- After an emergency stop signal is detected, the emergency stop function cannot be canceled even though the signal is canceled.
- If the minimum (or maximum) torque limit is set to 0%, the emergency stop function may not be able to stop the drive.
- Speed reference additives (parameters 22.15 and 22.17) and reference ramp shapes (23.16...23.19) are ignored in case of emergency ramp stops.

### Settings

Parameters 06.17 Drive status word 2 (page 137), 06.18 Start inhibit status word (page 138), 21.04 Emergency stop mode (page 217), 21.05 Emergency stop source (page 217), 23.23 Emergency stop time (page 235), 25.13 Min torq sp ctrl em stop (page 249), 25.14 Max torq sp ctrl em stop (page 249), 25.15 Proportional gain em stop (page 249), 31.32 Emergency ramp supervision (page 282) and 31.33 Emergency ramp supervision delay (page 283).

# Motor thermal protection

The control program features two separate motor temperature monitoring functions. The temperature data sources and warning/trip limits can be set up independently for each function.

The motor temperature can be monitored using

- the motor thermal protection model (estimated temperature derived internally inside the drive), or
- sensors installed in the windings. This will result in a more accurate motor model.

In addition to temperature monitoring, a protection function is available for 'Ex' motors installed in a potentially explosive atmosphere.

### Motor thermal protection model

The drive calculates the temperature of the motor on the basis of the following assumptions:


- 1. When power is applied to the drive for the first time, the motor is assumed to be at ambient temperature (defined by parameter 35.50 Motor ambient temperature). After this, when power is applied to the drive, the motor is assumed to be at the estimated temperature.
- 2. Motor temperature is calculated using the user-adjustable motor thermal time and motor load curve. The load curve should be adjusted in case the ambient temperature exceeds 30 °C.

The motor thermal protection model fulfills standard IEC/EN 61800-5-1 ed. 2.1 requirements for thermal memory retention and speed sensitivity. The estimated temperature is retained over power down. Speed dependency is set by parameters 35.51 Motor load curve, 35.52 Zero speed load and 35.53 Break point.

Note: The motor thermal model can be used when only one motor is connected to the drive.

## Temperature monitoring using PTC sensors

One PTC sensor can be connected to digital input DI6.




The resistance of the PTC sensor increases when its temperature rises. The increasing resistance of the sensor decreases the voltage at the input, and eventually its state switches from 1 to 0, indicating overtemperature.

1...3 PTC sensors can also be connected in series to an analog input and an analog output. The analog output feeds a constant excitation current of 1.6 mA through the sensor. The sensor resistance increases as the motor temperature rises, as does the voltage over the sensor. The temperature measurement function calculates the resistance of the sensor and generates an indication if overtemperature is detected.

For wiring of the sensor, refer to the Hardware Manual of the drive.

The figure below shows typical PTC sensor resistance values as a function of temperature.



In addition to the above, optional FEN-xx encoder interfaces, and FPTC-xx modules have connections for PTC sensors. Refer to the module-specific documentation for more information.

## Temperature monitoring using Pt100 or Pt1000 sensors

1...3 Pt100 or Pt 1000 sensors can be connected in series to an analog input and an analog output.

The analog output feeds a constant excitation current of 9.1 mA (Pt100) or 1 mA (1000) through the sensor. The sensor resistance increases as the motor temperature rises, as does the voltage over the sensor. The temperature measurement function reads the voltage through the analog input and converts it into degrees Celsius.

The warning and fault limits can be adjusted by parameters.

For the wiring of the sensor, refer to the Hardware Manual of the drive.


### Temperature monitoring using KTY84 sensors

One KTY84 sensor can be connected to an analog input and an analog output on the control unit.

The analog output feeds a constant excitation current of 2.0 mA through the sensor. The sensor resistance increases as the motor temperature rises, as does the voltage over the sensor. The temperature measurement function reads the voltage through the analog input and converts it into degrees Celsius.

FEN-xx encoder interfaces (optional) also have a connection for one KTY84 sensor.

The figure and table below show typical KTY84 sensor resistance values as a function of the motor operating temperature.



The warning and fault limits can be adjusted by parameters.

For the wiring of the sensor, refer to the *Hardware Manual* of the drive.

#### Motor fan control logic (parameters 35.100...35.106)

If the motor has an external cooling fan, it is possible to use a drive signal (for example, running/stopped) to control the starter of the fan via a relay or digital output. A digital input can be selected for fan feedback. A loss of the feedback signal will optionally cause a warning or a fault.

Start and stop delays can be defined for the fan. In addition, a feedback delay can be set to define the time within which feedback must be received after the fan starts.

# Ex motor support (parameter 95.15, bit 0)

The control program has a temperature protection function for Ex motors located in a potentially explosive atmosphere. The protection is enabled by setting bit 0 of parameter 95.15 Special HW settings.

#### Settings

Parameter groups 35 Motor thermal protection (page 297) and 91 Encoder module settings (page 376); parameter 95.15 Special HW settings (page 393).

# Thermal protection of motor cable

The control program contains a thermal protection function for the motor cable. This function should be used, for example, when the nominal current of the drive exceeds the current-carrying capacity of the motor cable.

The program calculates the temperature of the cable on the basis of the following data:

- Measured output current (parameter 01.07 Motor current)
- Nominal continuous current rating of the cable, specified by 35.61 Cable nominal current, and
- Thermal time constant of the cable, specified by 35.62 Cable thermal rise time.

When the calculated temperature of the cable reaches 102% of the rated maximum, a warning (A480 Motor cable overload) is given. The drive trips on a fault (4000 Motor cable overload) when 106% is reached.

## Settings


Parameters 35.60...35.62 (page 306).

#### User load curve

The user load curve provides a function that monitors an input signal (eg. motor torque or motor current) as a function of drive output speed or frequency. The function includes both high limit (overload) and low limit (underload) monitoring. Overload monitoring can, for example, be used to detect a pump becoming clogged or a saw blade hitting a knot. Underload monitoring can detect the load being lost, for example because of the snapping of a transmission belt.

The monitoring is effective within a motor speed and/or frequency range. The frequency range is used with a frequency reference in scalar motor control mode; otherwise, the speed range is used. The range is defined by five speed (parameters 37.11...37.15) or frequency (37.16...37.20) values. The values are positive, but the monitoring is symmetrically active in the negative direction as the sign of the monitored signal is ignored. Outside the speed/frequency range, the monitoring is disabled.

An underload (37.21...37.25) and overload (37.31...37.35) limit is set for each of the five speed or frequency points. Between these points, the limits are interpolated linearly to form overload and underload curves.



The action (none, warning or fault) taken when the signal exits the allowed operation area can be selected separately for overload and underload conditions (parameters 37.03 and 37.04 respectively). Each condition also has an optional timer to delay the selected action (37.41 and 37.42).

#### Settinas

Parameter group 37 User load curve (page 313).

#### Automatic fault resets

The drive can automatically reset itself after overcurrent, overvoltage, undervoltage and external faults. The user can also specify a fault (excluding Safe torque off related faults) to be reset automatically.

By default, automatic resets are off and must be specifically activated by the user.

WARNING! Before you activate the function, make sure that no dangerous situations can occur. The function resets the drive automatically and continues operation after a fault.

### Settings

Parameters 31.12...31.16 (page 277).

## Other programmable protection functions

### External events (parameters 31.01...31.10)

Five different event signals from the process can be connected to selectable inputs to generate trips and warnings for the driven equipment. When the signal is lost, an external event (fault, warning, or a mere log entry) is generated. The contents of the messages can be edited on the control panel by selecting Menu - Settings - Edit texts.

#### Motor phase loss detection (parameter 31.19)

The parameter selects how the drive reacts whenever a motor phase loss is detected.

#### Earth (Ground) fault detection (parameter 31.20)

The earth fault detection function is based on sum current measurement. Note that

- an earth fault in the supply cable does not activate the protection
- in a grounded supply, the protection activates within 2 milliseconds
- in an ungrounded supply, the supply capacitance must be 1 microfarad or more
- the capacitive currents caused by shielded motor cables up to 300 meters will not activate the protection
- the protection is deactivated when the drive is stopped.

#### Safe torque off detection (parameter 31.22)

The drive monitors the status of the Safe torque off input, and this parameter selects which indications are given when the signals are lost. (The parameter does not affect the operation of the Safe torque off function itself). For more information on the Safe torque off function, see the Hardware manual.

### Swapped supply and motor cabling (parameter 31.23)

The drive can detect if the supply and motor cables have accidentally been swapped (for example, if the supply is connected to the motor connection of the drive). The parameter selects if a fault is generated or not. Note that the protection should be disabled in drive/inverter hardware supplied from a common DC bus.

#### Stall protection (parameters 31.24...31.28)

The drive protects the motor in a stall situation. It is possible to adjust the supervision limits (current, frequency and time) and choose how the drive reacts to a motor stall condition.

### Overspeed protection (parameter 31.30)

The user can set overspeed limits by specifying a margin that is added to the currently-used maximum and minimum speed limits.

## Ramp stop supervision (parameters 31.32, 31.33, 31.37 and 31.38)

The control program has a supervision function for both the normal and emergency stop ramps. The user can either define a maximum time for stopping, or a maximum deviation from the expected deceleration rate. If the drive fails to stop in the expected manner, a fault is generated and the drive coasts to a stop.

## Main cooling fan supervision (parameter 31.35)

The parameter selects how the drive reacts to a loss of the main cooling fan.

With an inverter unit consisting of frame R8i inverter modules, it may be possible to continue operation even if a cooling fan of an inverter module stops. See the description of the parameter.

#### Custom motor current fault limit (parameter 31.42)

The control program sets a motor current limit based on drive hardware. In most cases, the default value is appropriate. However, a lower limit can be manually set by the user, for example, to protect a permanent magnet motor from demagnetization.

#### Local control loss detection (parameter 49.05)

The parameter selects how the drive reacts to a control panel or PC tool communication break.

# **Diagnostics**

## Fault and warning messages, data logging

See chapter Fault tracing (page 473).

# Signal supervision

Three signals can be selected to be supervised by this function. Whenever a supervised signal exceeds or falls below predefined limits, a bit in 32.01 Supervision status is activated, and a warning or fault generated. The contents of the message can be edited on the control panel by selecting Settings - Edit texts.

The supervised signal is low-pass filtered. The supervision operates on a 2 ms time level. The configuration parameters are scanned for changes on a 10 ms time level.

## Settings

See parameter group 32 Supervision (page 285).

#### Maintenance timers and counters

The program has six different maintenance timers or counters that can be configured to generate a warning when a pre-defined limit is reached. The contents of the message can be edited on the control panel by selecting Menu - Settings - Edit texts.

The timer/counter can be set to monitor any parameter. This feature is especially useful as a service reminder.

There are three types of counters:

- On time timers. Measures the time a binary source (for example, a bit in a status word) is on.
- Signal edge counters. The counter is incremented whenever the monitored binary source changes state.
- Value counters. The counter measures, by integration, the monitored parameter. An warning is given when the calculated area below the signal peak exceeds a user-defined limit.

#### Settings

See parameter group 33 Generic timer & counter (page 289).

# Energy savings calculator

This feature consists of the following functionalities:

- · An energy optimizer that adjusts the motor flux in such a way that the total efficiency is maximized
- · A counter that monitors used and saved energy by the motor and displays them in kWh, currency or volume of CO<sub>2</sub> emissions, and
- · A load analyzer showing the load profile of the drive (see separate section on page 103).

Note: The accuracy of the energy savings calculation is directly dependent on the accuracy of the reference motor power given in parameter 45.19 Comparison power.

# **Settings**

See parameter group 45 Energy efficiency (page 318).

## Load analyzer


## Peak value logger

The user can select a signal to be monitored by a peak value logger. The logger records the peak value of the signal along with the time the peak occurred, as well as motor current, DC voltage and motor speed at the time of the peak. The peak value is sampled at 2 ms intervals.

#### **Amplitude loggers**

The control program has two amplitude loggers. Depending on the setting of parameter 36.08 Logger function, the loggers are active continuously or only when the drive is modulating.

For amplitude logger 2, the user can select a signal to be sampled at 200 ms intervals and specify a value that corresponds to 100%. The collected samples are sorted into 10 read-only parameters according to their amplitude. Each parameter represents an amplitude range 10 percentage points wide, and displays the percentage of the collected samples that have fallen within that range. Note that the lowest range also contains the negative values (if any). while the highest range also contains the values above 100%.



Amplitude ranges (parameters 36.40...36.49)

Amplitude logger 1 is fixed to monitor motor current, and cannot be reset. With amplitude logger 1, 100% corresponds to the maximum output current of the drive  $(I_{\text{max}}, \text{ as given in the hardware manual})$ . The distribution of collected samples is shown by parameters 36.20...36.29.

# **Settings**

See parameter group 36 Load analyzer (page 309).

#### Miscellaneous

#### User parameter sets

The drive supports four user parameter sets that can be saved to the memory and recalled using drive parameters. It is also possible to use digital inputs to switch between user parameter sets.

A user parameter set contains all editable values in parameter groups 10...99 except

- forced I/O values such as parameters 10.03 DI force selection and 10.04 DI force data
- I/O extension module settings (groups 14...16)
- fieldbus communication enable parameters (50.01 FBA A enable and 50.31 FBA B enable).
- other fieldbus communication settings (groups 51...56 and 58)
- encoder configuration settings (groups 92...93)
- some hardware settings in parameter group 95 HW configuration, and
- user set selection parameters 96.11...96.13.

As the motor settings are included in the user parameter sets, make sure the settings correspond to the motor used in the application before recalling a user set. In an application where different motors are used with the drive, the motor ID run needs to be performed with each motor and the results saved to different user sets. The appropriate set can be recalled when the motor is switched.

If no parameter sets have been saved, attempting to load a set will create all sets from the currently active parameter settings.

Switching between user parameter sets is only possible with the drive stopped.

#### Settings

See parameters 96.10...96.13 (page 401).

#### Parameter checksum calculation

A parameter checksum can be calculated from a user-definable set of parameters to monitor changes in the drive configuration. The calculated checksum is compared to 1...4 reference checksums; in case of a mismatch, an event (a pure event, warning or fault) is generated.

By default, the set of parameters included in the calculation contain most parameters with the exception of

- actual signals
- parameter group 47 Data storage
- parameters that are activated to validate new settings (such as 51.27 and 96.07)
- parameters that are not saved to the flash memory (such as 96.24...96.26)
- parameters that are internally calculated from others (such as 98.09...98.14).
- dynamic parameters (eq. parameters that vary according to hardware), and
- · application program parameters.

The default set can be edited using the Drive customizer PC tool.

#### Settings

Parameters 96.53...96.59 (page 405).

#### User lock

For improved cybersecurity, it is highly recommended that you set a master pass code to prevent, for example, the changing of parameter values and/or the loading of firmware and other files.

**WARNING!** ABB will not be liable for damages or losses caused by the failure to activate the user lock using a new pass code. See *Cyber security disclaimer* (page 15).

To activate the user lock for the first time,

- Enter the default pass code, 10000000, into 96.02 Pass code. This will make parameters 96.100...96.102 visible.
- Enter a new pass code into 96.100 Change user pass code. Always use eight digits; if using Drive composer, finish with Enter.
- Confirm the new pass code in 96.101 Confirm user pass code.

**WARNING!** Store the pass code in a safe place – the user lock cannot be opened even by ABB if the pass code is lost.

- In 96.102 User lock functionality, define the actions that you want to prevent (we
  recommend you select all the actions unless otherwise required by the
  application).
- Enter an invalid (random) pass code into 96.02 Pass code.
- Activate 96.102 User lock functionality, or cycle the power to the control unit.
- Check that parameters 96.100...96.102 are hidden. If they are not, enter another random pass code into 96.02.

To reopen the lock, enter your pass code into 96.02 Pass code. This will again make parameters 96.100...96.102 visible.

#### **Settings**

Parameters 96.02 (page 398) and 96.100...96.102 (page 407).

#### Data storage parameters

Twenty four (sixteen 32-bit, eight 16-bit) parameters are reserved for data storage. These parameters are unconnected by default and can be used for eg. linking, testing and commissioning purposes. They can be written to and read from using other parameters' source or target selections.

Note that only 32-bit floating point (type real32) parameters can be selected as the source of another parameter value. In other words, parameters 47.01...47.08 can be used as value sources of other parameters while 47.11...47.28 cannot.

To use a 16-bit integer (received in DDCS data sets) as the source of another parameter, write the value into one of the real32 type storage parameters (47.01...47.08). Select the storage parameter as the source, and define a suitable scaling method between the 16-bit and 32-bit values in parameters 47.31...47.38.

#### **Settings**

See parameter group 47 Data storage (page 325).

#### Reduced run function

A "reduced run" function is available for inverter units consisting of parallel-connected inverter modules. The function makes it possible to continue operation with limited current even if one (or more) module is out of service, for example, because of maintenance work. In principle, reduced run is possible with only one module, but the physical requirements of operating the motor still apply; for example, the modules remaining in use must be able to provide the motor with enough magnetizing current.

#### Activation of the reduced run function

Note: For cabinet-built drives, the wiring accessories and the air baffle needed during the procedure are available from ABB, and are included in the delivery.



**WARNING!** Follow the safety instructions provided for the drive or inverter unit in question.

- Disconnect the supply voltage and all auxiliary voltages from the drive/inverter unit.
- 2. If the inverter control unit is powered from the faulty module, install an extension to the wiring and connect it to one of the remaining modules.
- Remove the module to be serviced from its bay. See the appropriate hardware manual for instructions.
- 4. If the Safe torque off (STO) function is in use, install jumpering in the STO wiring in place of the missing module (unless the module was the last on the chain).
- 5. Install an air baffle to the top module guide to block the airflow through the empty module bay.
- 6. In case the inverter unit has a DC switch with a charging circuit, disable the appropriate channel on the xSFC-xx charging controller.
- 7. Switch on the power to the drive/inverter unit.
- 8. Enter the number of inverter modules present into parameter 95.13 Reduced run mode.
- Reset all faults and start the drive/inverter unit. The maximum current is now automatically limited according to the new inverter configuration. A mismatch between the number of detected modules (95.14) and the value set in 95.13 will generate a fault.

After all modules have been reinstalled, parameter 95.13 Reduced run mode must be reset to 0 to disable the reduced run function. In case the inverter is equipped with a charging circuit, the charging monitoring must be reactivated for all modules. If the Safe torque off (STO) function is in use, an acceptance test must be performed (see the hardware manual of the drive/inverter unit for instructions).

#### Settings

Parameters 06.17 (page 137) and 95.13...95.14 (page 393).

## du/dt filter support

With an external du/dt filter connected to the output of the drive, bit 13 of 95.20 HW options word 1 must be switched on. The setting limits the output switching frequency. With frame size R5i...R7i inverter modules, the setting also forces the drive/inverter module fan to full speed. Note that the setting is not to be activated with inverter modules with internal du/dt filters.

## Settings

Parameter 95.20 HW options word 1 (page 395).

#### Sine filter support

The control program has a setting that enables the use of sine filters (available separately from ABB and others).

With an ABB sine filter connected to the output of the drive, bit 1 95.15 Special HW settings must be switched on. The setting limits the switching and output frequencies to

- prevent the drive from operating at filter resonance frequencies, and
- protect the filter from overheating.

With a custom sine filter, bit 3 of 95.15 Special HW settings must be switched on. (The setting does not limit the output frequency.) Additional parameters must be set according to the properties of the filter as listed below.

#### Settings


Parameters 95.15 Special HW settings (page 393), 97.01 Switching frequency reference, 97.02 Minimum switching frequency (page 409), 99.18 Sine filter inductance and 99.19 Sine filter capacitance (page 424).

#### Router mode for BCU control unit

The BCU control unit of an inverter unit can be set to a "router mode" to allow the control of locally-connected power units (for example, inverter modules) by another BCU. Using the router mode and some hardware switching, it is possible to have the same modules alternate between inverter and, for example, supply use.

The router mode involves connecting the two BCUs together by their PSL2 channels. When router mode is active, the channels coming from the other BCU are forwarded to the local modules.

In the example configuration shown below, BCU 1 has routing enabled by parameter 95.15 Special HW settings and channels CH3 and CH4 selected by parameter 95.17 Router channel config. All four modules, including those connected to BCU 1, are now controlled by BCU 2.



#### Notes:

- The local modules must be connected to successive channels starting from CH1. The immediately following channels are connected to the other BCU and routed to the local modules. There must be at least as many local modules as there are routed channels.
- In PLC control, any switchovers must be done in stopped state, and so that at least one BCU is in router mode at any given time.

#### Settings

Parameters 95.16 Router mode and 95.17 Router channel config (page 394).




# **Default control connections**


## Contents of this chapter


This chapter describes the default control connections of the PCP control application.

### PCP I/O control connections



#### Sensor connection examples





## **Application control PCP**

This default connection scheme is used for PCP application. Pump speed reference is constant and selectable through parameter 74.05 Speed ref source.

The application works through Ext1 and Ext 2 control locations.

The start/stop signal is connected to digital input DI1. The reset is determined by digital input DI2. Klixon temperature sensor is connected to input DI3. Input DI4 is responsible for pressure protection. Pressure limits and temperature limits are set through corresponding parameters, as well as protection modes.

PT100 source feedback goes through input Al1 scaled. AO2 is used for feeding excitation current. Pressure feedback source goes through Al2 scaled as a current signal in the range of 020 mA.

#### Default parameter settings for the PCP

Below is a listing of default parameter values that differ from those listed for the factory macro in *Parameter listing* (page 121).

Parame	ter	DCD control default	
No.	Name	PCP control default	
20.01	Ext1 commands	In1 Start	
20.06	Ext2 commands	Not selected	
74.01	Pump enable	Enable	
74.02	Run-time hours reset source	No	
74.05	Speed ref source	Al1 scaled	
76.01	Pressure protection function	Disable	
76.02	Pressure protection latching	Non latching	
76.03	Digital feedback source enable	FALSE	
76.04	Digital feedback source	FALSE	
76.05	Analog feedback source enable	FALSE	
76.06	Analog feedback source	Zero	
76.07	Analog feedback limit	0.00 kPa or psi	
76.08	Analog feedback limit delay time	0.000 s	
79.01	Temperature protection function	No	
79.02	Temperature protection device	Klixon	
79.03	Klixon signal source	FALSE	
79.04	PT100 source	Zero	
79.05	PT100 exitation source	Zero	
79.06	PT100 internal selection	9.10 mA	
79.07	Number of PT100 sensors in series	1	

Parameter		PCP control default
No. Name		FOF Control deladit
79.08	Warning temperature limit	0.00 °C
79.09	Fault temperature limit	0.00 °C



# **Parameters**

## **Contents of this chapter**

The chapter describes the parameters, including actual signals, of the control program.

## Terms and abbreviations

Term	Definition
Actual signal	Type of <i>parameter</i> that is the result of a measurement or calculation by the drive, or contains status information. Most actual signals are read-only, but some (especially counter-type actual signals) can be reset.
Def	(In the following table, shown on the same row as the parameter name). The default value of a <i>parameter</i> when used in the Factory macro. For information on other macro-specific parameter values, see chapter <i>Application macros</i> in See <i>ACS880 primary control program firmware manual (3AUA0000085967[English])</i> .  Note: Certain configurations or optional equipment may require specific default values. These are labeled as follows:  (95.20 bx) = Default changed or write-protected by parameter 95.20, bit x.
FbEq16	(In the following table, shown on the same row as the parameter range, or for each selection) 16-bit fieldbus equivalent: The scaling between the integer used in communication and the value shown on the panel when a 16-bit value is selected for transmission to an external system.  A dash (-) indicates that the parameter is not accessible in 16-bit format. The corresponding 32-bit scalings are listed in chapter Additional parameter data (page 425).
Other	The value is taken from another parameter.  Choosing "Other" displays a parameter list in which the user can specify the source parameter.  Note: Note: The source parameter must be of the real32 (32-bit floating point) type. To use a 16-bit integer (for example, received from an external device in data sets) as the source, data storage parameters 47.0147.08 (page 325) can be used. The parameter types are listed in chapter Additional parameter data (page 425).
Other [bit]	The value is taken from a specific bit in another parameter. Choosing "Other" displays a parameter list in which the user can specify the source parameter and bit.
Parameter	Either a user-adjustable operating instruction for the drive, or an actual signal.
p.u.	Per unit

# Summary of parameter groups

Group	Contents	Page
01 Actual values	Basic signals for monitoring the drive.	121
03 Input references	Values of references received from various sources.	125
04 Warnings and faults	Information on warnings and faults that occurred last.	126
05 Diagnostics	Various run-time-type counters and measurements related to drive maintenance.	133
06 Control and status words	Drive control and status words.	134
07 System info	Information on drive hardware, firmware and application program.	148
09 Pump actuals	Basic signals for monitoring the application.	151
10 Standard DI, RO	Configuration of digital inputs and relay outputs.	155
11 Standard DIO, FI, FO	Configuration of digital input/outputs and frequency inputs/outputs.	162
12 Standard AI	Configuration of standard analog inputs.	167
13 Standard AO	Configuration of standard analog outputs.	171
14 I/O extension module 1	Configuration of I/O extension module 1.	175
15 I/O extension module 2	Configuration of I/O extension module 2.	196
16 I/O extension module 3	Configuration of I/O extension module 3.	200
19 Operation mode	Selection of local and external control location sources and operating modes.	204
20 Start/stop/direction	Start/stop/direction and run/start/jog enable signal source selection; positive/negative reference enable signal source selection.	206
21 Start/stop mode	Start and stop modes; emergency stop mode and signal source selection; DC magnetization settings; autophasing mode selection.	215
22 Speed reference selection	Speed reference selection settings; motor potentiometer settings.	223
23 Speed reference ramp	Speed reference ramp settings (programming of the acceleration and deceleration rates for the drive).	231
24 Speed reference conditioning	Speed error calculation; speed error window control configuration; speed error step.	238
25 Speed control	Speed controller settings.	243
26 Torque reference chain	Settings for the torque reference chain.	254
28 Frequency reference chain	Settings for the frequency reference chain.	257
30 Limits	Drive operation limits.	266
31 Fault functions	Configuration of external events; selection of behavior of the drive upon fault situations.	275
32 Supervision	Configuration of signal supervision functions 13.	285
33 Generic timer & counter	Configuration of maintenance timers/counters.	289
35 Motor thermal protection	Motor thermal protection settings such as temperature measurement configuration, load curve definition and motor fan control configuration.	297
36 Load analyzer	Peak value and amplitude logger settings.	309
37 User load curve	Settings for user load curve.	313

### 120 Parameters

Group	Contents	Page
43 Brake chopper	Settings for the internal brake chopper.	316
45 Energy efficiency	Settings for the energy saving calculators.	318
46 Monitoring/scaling settings	Speed supervision settings; actual signal filtering; general scaling settings.	321
47 Data storage	Data storage parameters that can be written to and read from using other parameters' source and target settings.	325
49 Panel port communication	Communication settings for the control panel port on the drive.	327
50 Fieldbus adapter (FBA)	Fieldbus communication configuration.	330
51 FBA A settings	Fieldbus adapter A configuration.	339
52 FBA A data in	Selection of data to be transferred from drive to fieldbus controller through fieldbus adapter A.	340
53 FBA A data out	Selection of data to be transferred from fieldbus controller to drive through fieldbus adapter A.	341
54 FBA B settings	Fieldbus adapter B configuration.	341
55 FBA B data in	Selection of data to be transferred from drive to fieldbus controller through fieldbus adapter B.	342
56 FBA B data out	Selection of data to be transferred from fieldbus controller to drive through fieldbus adapter B.	343
58 Embedded fieldbus	Configuration of the embedded fieldbus (EFB) interface.	344
74 Pump setup	Basic functions of applications.	351
75 Pump level control	Pump level control function.	355
76 Pump pressure protection	Pump pressure protection function.	358
77 Pump torque protection	Pump torque protection function.	359
78 Pump underload protection	Pump underload protection function.	362
79 Pump temperature protection	Pump temperature protection function.	363
80 Pump backspin control	Basic functions of applications.	364
90 Feedback selection	Motor and load feedback configuration.	366
91 Encoder module settings	Configuration of encoder interface modules.	376
92 Encoder 1 configuration	Settings for encoder 1.	379
93 Encoder 2 configuration	Settings for encoder 2.	386
95 HW configuration	Various hardware-related settings.	390
96 System	Language selection; access levels; macro selection; parameter save and restore; control unit reboot; ; unit selection; data logger triggering;	397
97 Motor control	Motor model settings.	409
98 User motor parameters	Motor values supplied by the user that are used in the motor model.	414
99 Motor data	Motor configuration settings.	416
200 Safety	FSO-xx settings.	424
206 I/O bus configuration 207 I/O bus service 208 I/O bus diagnostics 209 I/O bus fan identification	Distributed I/O bus settings.	424

## **Parameter listing**

No.	Name/Value	Description	Def/ FbEq16
01 Ac	tual values	Basic signals for monitoring the drive. All parameters in this group are read-only unless otherwise noted.	
01.01	Motor speed used	Measured or estimated motor speed depending on which type of feedback is used (see parameter 90.41 Motor feedback selection). A filter time constant for this signa46l can be defined by parameter 46.11 Filter time motor speed.	-
	-30000.00 30000.00 rpm	Measured or estimated motor speed.	See par. 46.01
01.02	Motor speed estimated	Estimated motor speed in rpm. A filter time constant for this signal can be defined by parameter 46.11 Filter time motor speed.	-
	-30000.00 30000.00 rpm	Estimated motor speed.	See par. 46.01
01.03	Motor speed%	Shows the value of <i>01.01 Motor speed used</i> in percent of the synchronous speed of the motor.	10 = 1%
	-1000.00 1000.00%	Measured or estimated motor speed.	See par. 46.01
01.04	Encoder 1 speed filtered	Speed of encoder 1 in rpm. A filter time constant for this signal can be defined by parameter 46.11 Filter time motor speed.	-
	-30000.00 30000.00 rpm	Encoder 1 speed.	See par. 46.01
01.05	Encoder 2 speed filtered	Speed of encoder 2 in rpm. A filter time constant for this signal can be defined by parameter 46.11 Filter time motor speed.	-
	-30000.00 30000.00 rpm	Encoder 2 speed.	See par. 46.01
01.06	Output frequency	Estimated drive output frequency in Hz. A filter time constant for this signal can be defined by parameter 46.12 Filter time output frequency.	-
	-500.00 500.00 Hz	Estimated output frequency.	See par. 46.02
01.07	Motor current	Measured (absolute) motor current in A.	-
	0.0030000.00 A	Motor current.	See par. 46.05
01.08	Motor current% of motor nom	Motor current (drive output current) in percent of the nominal motor current.	-
	0.0 1000.0%	Motor current.	1 = 1%
01.10	Motor torque	Motor torque in percent of the nominal motor torque. See also parameter <i>01.30 Nominal torque scale</i> .  A filter time constant for this signal can be defined by parameter <i>46.13 Filter time motor torque</i> .	-
	-1600.01600.0%	Motor torque.	See par. 46.03

No.	Name/Value	Description	Def/ FbEq16
01.11	DC voltage	Measured DC link voltage.	-
	0.002000.00 V	DC link voltage.	10 = 1 V
01.13	Output voltage	Calculated motor voltage in V AC.	-
	02000 V	Motor voltage.	1 = 1 V
01.14	Output power	Drive output power. The unit is selected by parameter 96.16 Unit selection.	-
	-32768.00 32767.00 kW or hp	Output power.	1 = 1 unit
01.15	Output power% of motor nom	Shows the value of <i>01.14 Output power</i> in percent of the nominal power of the motor.	-
	-300.00 300.00%	Output power.	10 = 1%
01.17	Motor shaft power	Estimated mechanical power at motor shaft. The unit is selected by parameter 96.16 Unit selection.	-
	-32768.00 32767.00 kW or hp	Motor shaft power.	1 = 1 unit
01.18	Inverter GWh motoring	Amount of energy that has passed through the drive (towards the motor) in full gigawatt-hours. The minimum value is zero.	-
	032767 GWh	Motoring energy in GWh.	1 = 1 GWh
01.19	Inverter MWh motoring	Amount of energy that has passed through the drive (towards the motor) in full megawatt-hours. Whenever the counter rolls over, 01.18 Inverter GWh motoring is incremented. The minimum value is zero.	-
	01000 MWh	Motoring energy in MWh.	1 = 1 MWh
01.20	Inverter kWh motoring	Amount of energy that has passed through the drive (towards the motor) in full kilowatt-hours. Whenever the counter rolls over, 01.19 Inverter MWh motoring is incremented. The minimum value is zero.	-
	01000 kWh	Motoring energy in kWh.	10 = 1 kWh
01.21	U-phase current	Measured U-phase current.	-
	-30000.00 30000.00 A	U-phase current.	-
01.22	V-phase current	Measured V-phase current.	-
	-30000.00 30000.00 A	V-phase current.	-
01.23	W-phase current	Measured W-phase current.	-
	-30000.00 30000.00 A	W-phase current.	-
01.24	Flux actual%	Used flux reference in percent of nominal flux of motor.	-
	0200%	Flux reference.	1 = 1%
01.25	INU momentary cos fii	Momentary cosphi of the drive.	-
	-1.001.00	Cosphi	100 = 1

No.	Name/Value	Description	Def/ FbEq16
01.29	Speed change rate	Rate of actual speed change. Positive values indicate acceleration, negative values indicate deceleration.  See also parameters 31.32 Emergency ramp supervision, 31.33 Emergency ramp supervision delay, 31.37 Ramp stop supervision and 31.38 Ramp stop supervision delay.	-
	-1500015000 rpm/s	Rate of speed change.	1 = 1 rpm/s
01.30	Nominal torque scale	Torque that corresponds to 100% of nominal motor torque. The unit is selected by parameter 96.16 Unit selection Note: This value is copied from parameter 99.12 Motor nominal torque if entered. Otherwise the value is calculated from other motor data.	0.000 N·m or lb·ft
	0.0004000000.000 N·m or lb·ft	Nominal torque.	1 = 1 unit
01.31	Ambient temperature	Measured temperature of incoming cooling air. The unit is selected by parameter 96.16 Unit selection.	-
	-40.0200.0 °C or °F	Cooling air temperature.	1 = 1°
01.32	Inverter GWh regenerating	Amount of energy that has passed through the drive (towards the supply) in full gigawatt-hours. The minimum value is zero.	-
	032767 GWh	Regenerative energy in GWh.	1 = 1 GWh
01.33	Inverter MWh regenerating	Amount of energy that has passed through the drive (towards the supply) in full megawatt-hours. Whenever the counter rolls over, 01.32 Inverter GWh regenerating is incremented. The minimum value is zero.	-
	01000 MWh	Regenerative energy in MWh.	1 = 1 MWh
01.34	Inverter kWh regenerating	Amount of energy that has passed through the drive (towards the supply) in full kilowatt-hours. Whenever the counter rolls over, 01.33 Inverter MWh regenerating is incremented. The minimum value is zero.	-
	01000 kWh	Regenerative energy in kWh.	10 = 1 kWh
01.35	Mot - regen energy GWh	Amount of net energy (motoring energy - regenerating energy) that has passed through the drive in full gigawatthours.	-
	-3276832767 GWh	Energy balance in GWh.	1 = 1 GWh
01.36	Mot - regen energy MWh	Amount of net energy (motoring energy - regenerating energy) that has passed through the drive in full megawatthours. Whenever the counter rolls over, 01.35 Mot - regenenergy GWh is incremented or decremented.	-
	-10001000 MWh	Energy balance in MWh.	1 = 1 MWh
01.37	Mot - regen energy kWh	Amount of energy (motoring energy - regenerating energy) that has passed through the drive in full kilowatt-hours. Whenever the counter rolls over, 01.36 Mot - regen energy MWh is incremented or decremented.	-
	-10001000 kWh	Energy balance in kWh.	10 = 1 kWh
01.61	Abs motor speed used	Absolute value of 01.01 Motor speed used.	-
	0.00 30000.00 rpm	Measured or estimated motor speed.	See par. 46.01

No.	Name/Value	Description	Def/ FbEq16
01.62	Abs motor speed%	Absolute value of 01.03 Motor speed%.	-
	0.00 1000.00%	Measured or estimated motor speed.	10=1%
01.63	Abs output frequency	Absolute value of 01.06 Output frequency.	-
	0.00 500.00 Hz	Estimated output frequency.	See par. 46.02
01.64	Abs motor torque	Absolute value of 01.10 Motor torque.	-
	0.0 1600.0%	Motor torque.	-
01.65	Abs output power	Absolute value of 01.14 Output power.	-
	0.00 32767.00 kW or hp	Output power.	1 = 1 unit
01.66	Abs output power% motor nom	Absolute value of 01.15 Output power% of motor nom.	-
	0.00 300.00%	Output power.	10 = 1%
01.68	Abs motor shaft power	Absolute value of 01.17 Motor shaft power.	-
	0.00 32767.00 kW or hp	Motor shaft power.	1 = 1 unit
01.70	Ambient temperature%	Measured temperature of incoming cooling air. The amplitude range of 0100% corresponds to 060 °C or 32140 °F.	-
	200.00 200.000/	See also 01.31 Ambient temperature.	1 = 1%
01.71	-200.00 200.00%	Cooling air temperature.	1 = 1%
01.71	Step-up motor current	Estimated motor current in A when a step-up transformer is in use. The value is calculated from parameter <i>01.07</i> using the step-up transformer ratio (95.40) and sine filter values 99.18 and 99.19.	
	0.0030000.00 A	Estimated motor current.	See par. 46.05
01.72	U-phase RMS current	U-phase rms current.	-
	0.0030000.00 A	U-phase rms current.	See par. 46.05
01.73	V-phase RMS current	V-phase rms current.	
	0.0030000.00 A	V-phase rms current.	See par. 46.05
01.74	W-phase RMS current	W-phase rms current.	
	0.0030000.00 A	W-phase rms current.	See par. 46.05
01.102	Line current	(Only visible when IGBT supply unit control activated by 95.20) Estimated line current flowing through the supply unit.	-
	0.00 30000.00 A	Estimated line current.	-
01.104	Active current	(Only visible when IGBT supply unit control activated by 95.20) Estimated active current flowing through the supply unit.	-
	0.00 30000.00 A	Estimated active current.	-
	0.00 30000.00 A	Loumated active current.	_

No.	Name/Value	Description	Def/ FbEq16
01.106	Reactive current	(Only visible when IGBT supply unit control activated by 95.20) Estimated reactive current flowing through the supply unit.	-
	0.00 30000.00 A	Estimated reactive current nowing through the supply unit.	_
01.108	Grid frequency	(Only visible when IGBT supply unit control activated by 95.20) Estimated frequency of the power supply network.	-
	0.00 100.00 Hz	Estimated supply frequency.	-
01.109	Grid voltage	(Only visible when IGBT supply unit control activated by 95.20) Estimated voltage of the power supply network.	-
	0.00 2000.00 V	Estimated supply voltage.	10 = 1 V
01.110	Grid apparent power	(Only visible when IGBT supply unit control activated by 95.20) Estimated apparent power being transferred through the supply unit.	-
	-30000.00 30000.00 kVA	Estimated apparent power.	-
01.112	Grid power	(Only visible when IGBT supply unit control activated by 95.20) Estimated power being transferred through the supply unit.	-
	-30000.00 30000.00 kW	Estimated supply power.	-
01.114	Grid reactive power	(Only visible when IGBT supply unit control activated by 95.20) Estimated reactive power being transferred through the supply unit.	-
	-30000.00 30000.00 kvar	Estimated reactive power.	10 = 1 kvar
01.116	LSU cos ?	(Only visible when IGBT supply unit control activated by 95.20) Power factor of the supply unit.	-
	-1.00 1.00	Power factor.	100 = 1
01.164	LSU nominal power	(Only visible when IGBT supply unit control activated by 95.20) Nominal power of the supply unit.	-
	030000 kW	Nominal power.	1 = 1 kW
03 Inp	ut references	Values of references received from various sources. All parameters in this group are read-only unless otherwise	

03 Inp	out references	Values of references received from various sources. All parameters in this group are read-only unless otherwise noted.	
03.01	Panel reference	Reference given from the control panel or PC tool.	-
	-100000.00 100000.00	Control panel or PC tool reference.	1 = 10
03.02	Panel reference 2	Remote reference given from the control panel or PC tool.	-
	-30000.0030000.00	Remote control panel or PC tool reference.	1 = 10

No.	Name/Value	Description	Def/ FbEq16
03.05	FB A reference 1	Reference 1 received through fieldbus adapter A. See also chapter <i>Fieldbus control through a fieldbus</i> adapter (page 549).	-
	-100000.00 100000.00	Reference 1 from fieldbus adapter A.	1 = 10
03.06	FB A reference 2	Reference 2 received through fieldbus adapter A.	-
	-100000.00 100000.00	Reference 2 from fieldbus adapter A.	1 = 10
03.07	FB B reference 1	Reference 1 received through fieldbus adapter B.	-
	-100000.00 100000.00	Reference 1 from fieldbus adapter B.	1 = 10
03.08	FB B reference 2	Reference 2 received through fieldbus adapter B.	-
	-100000.00 100000.00	Reference 2 from fieldbus adapter B.	1 = 10
03.09	EFB reference 1	Scaled reference 1 received through the embedded fieldbus interface.	1 = 10
	-30000.00 30000.00	Reference 1 received through the embedded fieldbus interface.	1 = 10
03.10	EFB reference 2	Scaled reference 2 received through the embedded fieldbus interface.	1 = 10
	-30000.00 30000.00	Reference 2 received through the embedded fieldbus interface.	1 = 10
03.30	FB A reference 1 int32	Reference 1 received through fieldbus adapter A as a 32-bit integer.	-
	-2147483648 2147483647	Reference 1 from fieldbus adapter A.	-
03.31	FB A reference 2 int32	Reference 2 received through fieldbus adapter A as a 32-bit integer.	-
	-2147483648 2147483647	Reference 2 from fieldbus adapter A.	-
03.51	IEC application panel reference	Panel reference defined in the application program.	-
	-100000.0 100000.0	Panel reference in the application program.	1 = 1
04 Wa	rnings and faults	Information on warnings and faults that occurred last. For explanations of individual warning and fault codes, see chapter <i>Fault tracing</i> . All parameters in this group are read-only unless otherwise noted.	
04.01	Tripping fault	Code of the 1st active fault (the fault that caused the current trip).	-
	0000hFFFFh	1st active fault.	1 = 1
04.02	Active fault 2	Code of the 2nd active fault.	-
	0000hFFFFh	2nd active fault.	1 = 1
04.03	Active fault 3	Code of the 3rd active fault.	-
	0000hFFFFh	3rd active fault.	1 = 1

No.	Name/Value	Description	Def/ FbEq16
04.04	Active fault 4	Code of the 4th active fault.	-
	0000hFFFFh	4th active fault.	1 = 1
04.05	Active fault 5	Code of the 5th active fault.	-
	0000hFFFFh	5th active fault.	1 = 1
04.06	Active warning 1	Code of the 1st active warning.	-
	0000hFFFFh	1st active warning.	1 = 1
04.07	Active warning 2	Code of the 2nd active warning.	-
	0000hFFFFh	2nd active warning.	1 = 1
04.08	Active warning 3	Code of the 3rd active warning.	-
	0000hFFFFh	3rd active warning.	1 = 1
04.09	Active warning 4	Code of the 4th active warning.	-
	0000hFFFFh	4th active warning.	1 = 1
04.10	Active warning 5	Code of the 5th active warning.	-
	0000hFFFFh	5th active warning.	1 = 1
04.11	Latest fault	Code of the 1st stored (non-active) fault.	-
	0000hFFFFh	1st stored fault.	1 = 1
04.12	2nd latest fault	Code of the 2nd stored (non-active) fault.	-
	0000hFFFFh	2nd stored fault.	1 = 1
04.13	3rd latest fault	test fault Code of the 3rd stored (non-active) fault.	
	0000hFFFFh	3rd stored fault.	1 = 1
04.14	4th latest fault	Code of the 4th stored (non-active) fault.	-
	0000hFFFFh	4th stored fault.	1 = 1
04.15	5th latest fault	Code of the 5th stored (non-active) fault.	-
	0000hFFFFh	5th stored fault.	1 = 1
04.16	Latest warning	Code of the 1st stored (non-active) warning.	-
	0000hFFFFh	1st stored warning.	1 = 1
04.17	2nd latest warning	Code of the 2nd stored (non-active) warning.	-
	0000hFFFFh	2nd stored warning.	1 = 1
04.18	3rd latest warning	Code of the 3rd stored (non-active) warning.	-
	0000hFFFFh	3rd stored warning.	1 = 1
04.19	4th latest warning	Code of the 4th stored (non-active) warning.	-
	0000hFFFFh	4th stored warning.	1 = 1
04.20	5th latest warning	Code of the 5th stored (non-active) warning.	-
	0000hFFFFh	5th stored warning.	1 = 1

0000h...FFFFh

No.	Name/\	/alue De	scription		Def/ FbEq16
04.21	Fault word 1  ACS800-compatible fault word 1. The bit assignments of this word correspond to FAULT WORD 1 in the ACS800. Parameter 04.120 Fault/Warning word compatibility determines whether the bit assignments are according to the ACS800 Standard or ACS800 System control program.  Each bit can indicate several ACS800 events as listed below. This parameter is read-only.		-		
		ACS80	0 fault name		
	Bit	(04.120 = ACS80 Standard ctrl program)	0 (04.120 = ACS800 System ctrl program)	ACS880 events indicated by (see Fault tracing, page 473)	this bit
	0	SHORT CIRC	SHORT CIRC	2340	

Bit	(04.120 = ACS800 Standard ctrl program)	(04.120 = ACS800 System ctrl program)	ACS880 events indicated by this bit (see Fault tracing, page 473)
0	SHORT CIRC	SHORT CIRC	2340
1	OVERCURRENT	OVERCURRENT	2310
2	DC OVERVOLT	DC OVERVOLT	3210
3	ACS800 TEMP	ACS800 TEMP	2381, 4210,4290, 42F1, 4310, 4380
4	EARTH FAULT	EARTH FAULT	2330, 2392, 3181
5	THERMISTOR	MOTOR TEMP M	4981, 4991, 4992, 4993
6	MOTOR TEMP	MOTOR TEMP	4982
7	SYSTEM_FAULT	SYSTEM_FAULT	6481, 6487, 64A1, 64A2, 64A3, 64B1, 64E1, 6881, 6882, 6883, 6885
8	UNDERLOAD	UNDERLOAD	-
9	OVERFREQ	OVERFREQ	7310
10	Reserved	MPROT SWITCH	9081
11	Reserved	CH2 COMM LOSS	-
12	Reserved	SC (INU1)	2340 (XXYY YY01)
13	Reserved	SC (INU2)	2340 (XXYY YY02)
14	Reserved	SC (INU3)	2340 (XXYY YY03)
15	Reserved	SC (INU4)	2340 (XXYY YY04)

1 = 1

ACS800-compatible fault word 1.

No.	Name/Value	Description	Def/ FbEq16
04.22	Fault word 2	ACS800-compatible fault word 2.  The bit assignments of this word correspond to FAULT WORD 2 in the ACS800. Parameter 04.120 Fault/Warning word compatibility determines whether the bit assignments are according to the ACS800 Standard or ACS800 System control program.  Each bit can indicate several ACS880 events as listed below.  This parameter is read-only.	-

	ACS800	fault name	
Bit	(04.120 = ACS800 Standard ctrl program)	(04.120 = ACS800 System ctrl program)	ACS880 events indicated by this bit (see Fault tracing, page 473)
0	SUPPLY PHASE	SUPPLY PHASE	3130
1	NO MOT DATA	NO MOTOR DATA	-
2	DC UNDERVOLT	DC UNDERVOLT	3220
3	Reserved	CABLE TEMP	4000
4	RUN ENABLE	RUN DISABLE	AFEB
5	ENCODER ERR	ENCODER ERR	7301, 7380, 7381, 73A0, 73A1
6	I/O COMM	IO COMM ERR	7080, 7082
7	CTRL B TEMP	CTRL B TEMP	-
8	EXTERNAL FLT	SELECTABLE	9082
9	OVER SWFREQ	OVER SWFREQ	-
10	AI < MIN FUNC	AI <min func<="" td=""><td>80A0</td></min>	80A0
11	PPCC LINK	PPCC LINK	5681, 5682, 5690, 5691, 5692, 5693, 5694
12	COMM MODULE	COMM MODULE	6681, 7510, 7520
13	PANEL LOSS	PANEL LOSS	7081
14	MOTOR STALL	MOTOR STALL	7121
15	MOTOR PHASE	MOTOR PHASE	3381

0000hFFFFh	ACS800-compatible fault word 2.	1 = 1
04.25 Faulted modules	(Only visible with a BCU control unit) Indicates which parallel-connected modules have faulted. The bits of this word are cleared when all faults have been reset. This parameter is read-only.	-

Name	escription	
Module 1	= Module 1 faulted	
Module 2	Module 2 faulted	
Module 12	1 = Module 12 faulted	
Reserved		
	Module 1 Module 2	

No.	Name/V	alue Desc	cription		Def/ FbEq16
04.31	The b WOR word are ac contr Each below		D 1 in the ACS800. P compatibility determine coording to the ACS80 ol program.  may indicate several	word correspond to ALARM arameter 04.120 Fault/Warning nes whether the assignments 00 Standard or ACS800 System ACS880 warnings as listed	-
		ACS800 a	alarm name		
	Bit	(04.120 = ACS800 Standard ctrl program)	(04.120 = ACS800 System ctrl program)	ACS880 events indicated by to (see Fault tracing, page 473)	this bit
	0	START INHIBIT	START INHIBI	A5A0	
	1	Reserved	EM STOP	AFE1, AFE2	
	2	THERMISTOR	MOTOR TEMP M	A491, A497, A498, A499	
	3	MOTOR TEMP	MOTOR TEMP	A492	
	4	ACS800 TEMP	ACS800 TEMP	A2BA, A4A9, A4B0, A4B1, A4F	-6
	5	ENCODER ERR	ENCODER ERR	A797, A7B0, A7B1, A7E1	
	6	T MEAS ALM	T MEAS CIRC	A490, A5EA, A782, A8A0	
	7	Reserved	DIGITAL IO	-	
	0	Deceminad	ANALOC IO		

8	-		
	Reserved	ANALOG IO	-
9	Reserved	EXT DIGITAL IO	-
10	Reserved	EXT ANALOG IO	A6E5, A7AA, A7AB
11	Reserved	CH2 COMM LOSS	A7CE
12	COMM MODULE	MPROT SWITCH	A981
13	Reserved	EM STOP DEC	-
14	EARTH FAULT	EARTH FAULT	A2B3
15	Reserved	SAFETY SWITC	A983

No.	Name/Value	Description	Def/ FbEq16
04.32	Warning word 2	ACS800-compatible warning (alarm) word 2. The bit assignments of this word correspond to ALARM WORD 2 in the ACS800. Parameter 04.120 Fault/Warning word compatibility determines whether the bit assignments are according to the ACS800 Standard or ACS800 System control program.  Each may indicate several ACS880 warnings as listed below. This parameter is read-only.	-

	ACS800 a	larm name	
Bit	(04.120 = ACS800 Standard ctrl program)	(04.120 = ACS800 System ctrl program)	ACS880 events indicated by this bit (see Fault tracing, page 473)
0	Reserved	MOTOR FAN	A781
1	UNDERLOAD	UNDERLOAD	-
2	Reserved	INV OVERLOAD	-
3	Reserved	CABLE TEMP	A480
4	ENCODER	ENCODER A<>B	-
5	Reserved	FAN OVERTEMP	A984
6	Reserved	Reserved	-
7	POWFAIL FILE	POWFAIL FILE	-
8	ALM (OS_17)	POWDOWN FILE	-
9	MOTOR STALL	MOTOR STALL	A780
10	AI < MIN FUNC	AI <min func<="" td=""><td>A8A0</td></min>	A8A0
11	Reserved	COMM MODULE	A6D1, A6D2, A7C1, A7C2, A7CE
12	Reserved	BATT FAILURE	-
13	PANEL LOSS	PANEL LOSS	A7EE
14	Reserved	DC UNDERVOLT	A3A2
15	Reserved	RESTARTED	-

0000hFFFFh	ACS800-compatible warning (alarm) word 2.	1 = 1
04.40 Event word 1	User-defined event word. This word collects the status of the events (warnings, faults or pure events) selected by parameters 04.4104.72.  For each event, an auxiliary code can optionally be specified for filtering.  This parameter is read-only.	-

Name	Description
User bit 0	1 = Event selected by parameters 04.41 (and 04.42) is active
User bit 1	1 = Event selected by parameters 04.43 (and 04.44) is active
User bit 15	1 = Event selected by parameters <i>04.71</i> (and <i>04.72</i> ) is active
	User bit 0 User bit 1

0000hFFFFh	User-defined event word.	1 = 1

No.	Name/Value	Description	Def/ FbEq16
04.41	Event word 1 bit 0 code	Selects the hexadecimal code of an event (warning, fault or pure event) whose status is shown as bit 0 of 04.40 Event word 1. The event codes are listed in chapter Fault tracing (page 473).	0000h
	0000hFFFFh	Code of event.	1 = 1
04.42	Event word 1 bit 0 aux code	Specifies an auxiliary code for the event selected by the previous parameter. The selected event is indicated by the event word only if its auxiliary code matches the value of this parameter.  With a value of 0000 0000h, the event word will indicate the event regardless of the auxiliary code.	0000 0000h
	0000 0000h FFFF FFFFh	Code of warning, fault or pure event.	1 = 1
04.43	Event word 1 bit 1 code	Selects the hexadecimal code of an event (warning, fault or pure event) whose status is shown as bit 1 of 04.40 Event word 1. The event codes are listed in chapter Fault tracing (page 473).	0000h
	0000hFFFFh	Code of event.	1 = 1
04.44	Event word 1 bit 1 aux code	Specifies an auxiliary code for the event selected by the previous parameter. The selected event is indicated by the event word only if its auxiliary code matches the value of this parameter.  With a value of 0000 0000h, the event word will indicate the event regardless of the auxiliary code.	0000 0000h
	0000 0000h FFFF FFFFh	Code of warning, fault or pure event.	1 = 1
04.71	Event word 1 bit 15 code	Selects the hexadecimal code of an event (warning, fault or pure event) whose status is shown as bit 15 of 04.40 Event word 1. The event codes are listed in chapter Fault tracing (page 473).	0000h
	0000hFFFFh	Code of event.	1 = 1
04.72	Event word 1 bit 15 aux code	Specifies an auxiliary code for the event selected by the previous parameter. The selected event is indicated by the event word only if its auxiliary code matches the value of this parameter.  With a value of 0000 0000h, the event word will indicate the event regardless of the auxiliary code.	0000 0000h
	0000 0000h FFFF FFFFh	Code of warning, fault or pure event.	1 = 1
04.120	Fault/Warning word compatibility	Selects whether the bit assignments of parameters 04.2104.32 correspond to the ACS800 Standard control program or the ACS800 System control program.	FALSE
	ACS800 Standard ctrl program	The bit assignments of parameters 04.2104.32 correspond to the ACS800 Standard control program as follows: 04.21 Fault word 1: 03.05 FAULT WORD 1 04.22 Fault word 2: 03.06 FAULT WORD 2 04.31 Warning word 1: 03.08 ALARM WORD 1 04.32 Warning word 2: 03.09 ALARM WORD 2	0

	No Name/Value Description		1 = -
No.	Name/Value	Description	Def/ FbEq16
	ACS800 System ctrl program	The bit assignments of parameters 04.2104.32 correspond to the ACS800 System control program as follows: 04.21 Fault word 1: 09.01 FAULT WORD 1 04.22 Fault word 2: 09.02 FAULT WORD 2 04.31 Warning word 1: 09.04 ALARM WORD 1 04.32 Warning word 2: 09.05 ALARM WORD 2	1
05 Dia	gnostics	Various run-time-type counters and measurements related to drive maintenance. All parameters in this group are read-only unless otherwise noted.	
05.01	On-time counter	On-time counter. The counter runs when the drive is powered.	-
	065535 d	On-time counter.	1 = 1 d
05.02	Run-time counter	Motor run-time counter. The counter runs when the inverter modulates.	-
	065535 d	Motor run-time counter.	1 = 1 d
05.04	Fan on-time counter	Running time of the drive cooling fan. Can be reset from the control panel by keeping Reset depressed for over 3 seconds.	-
	065535 d	Cooling fan run-time counter.	1 = 1 d
05.09	Time from power-up	500-microsecond ticks elapsed since the last boot of the control unit.	-
	04294967295	500-microsecond ticks since last boot.	1 = 1
05.11	Inverter temperature	Estimated drive temperature in percent of fault limit. The actual trip temperature varies according to the type of the drive.  0.0% = 0 °C (32 °F) 94% approx. = Warning limit 100.0% = Fault limit	-
	-40.0160.0%	Drive temperature in percent.	1 = 1%
05.22	Diagnostic word 3	Diagnostic word 3.	-
	Bit 010 11 12 1315	Name   Value	
	0000hFFFFh	Diagnostic word 3.	1 = 1
05.41	Main fan service counter	Displays the age of the main cooling fan as a percentage of its estimated lifetime. The estimate is based on the duty, operating conditions and other operating parameters of the fan. When the counter reaches 100%, a warning (A8C0 Fan service counter) is generated.  Can be reset from the control panel by keeping Reset depressed for over 3 seconds.	-

No.	Name/Value	Description	Def/ FbEq16
	0150%	Main cooling fan age.	1 = 1%
05.42	Aux. fan service counter	Displays the age of the auxiliary cooling fan as a percentage of its estimated lifetime. The estimate is based on the duty, operating conditions and other operating parameters of the fan. When the counter reaches 100%, a warning ( <i>A8CO Fan service counter</i> ) is generated. Can be reset from the control panel by keeping Reset depressed for over 3 seconds.	-
	0150%	Auxiliary cooling fan age.	1 = 1%
	0000hFFFFh	Main control word.	1 = 1
05.111	Line converter temperature	(Only visible when IGBT supply unit control activated by 95.20) Estimated supply unit temperature in percent of fault limit. 0.0% = 0 °C (32 °F) 94% approx. = Warning limit 100.0% = Fault limit	-
	-40.0 160.0%	Supply unit temperature in percent.	1 = 1%
05.121	MCB closing counter	(Only visible when IGBT supply unit control activated by 95.20) Counts the closures of the main circuit breaker of the supply unit.	-
	04294967295	Count of closures of main circuit breaker.	1 = 1

	ntrol and status ords	Drive control and status words.	
06.01	Main control word	The main control word of the drive. This parameter shows the control signals as received from the selected sources (such as digital inputs, the fieldbus interfaces and the application program).  The bit assignments of the word are as described on page 554. The related status word and state diagram are presented on pages 556 respectively.  Note:  Bits 1215 can be used to carry additional control data, and used as a signal source by any binary-source selector parameter. Bit 10 must be active for bits 1215 to update.  In fieldbus control, this parameter value is not exactly the same as the control word that the drive receives from the PLC. See parameter 50.12 FBA A debug mode.  This parameter is read-only.	-
	0000hFFFFh	Main control word.	1 = 1
06.02	Application control word	The drive control word received from the application program (if any). The bit assignments are described on page 554.  This parameter is read-only.	-
	0000hFFFFh	Application program control word.	1 = 1

No.	Name/Value	Description	Def/ FbEq16
06.03	FBA A transparent control word	Displays the unaltered control word received from the PLC through fieldbus adapter A when a transparent communication profile is selected eg. by parameter group 51 FBA A settings. See section Control word and Status word (page 552).  This parameter is read-only.	-
	00000000h FFFFFFFh	Control word received through fieldbus adapter A.	-
06.04	FBA B transparent control word	Displays the unaltered control word received from the PLC through fieldbus adapter B when a transparent communication profile is selected eg. by parameter group 54 FBA B settings. See section Control word and Status word (page 552).  This parameter is read-only.	-
	00000000h FFFFFFFh	Control word received through fieldbus adapter B.	1 = 1
06.05	EFB transparent control word	Displays the unaltered control word received from the PLC through the embedded fieldbus interface when a transparent communication profile is selected in parameter 58.25 Control profile. See section The Transparent profile (page 541).  This parameter is read-only.	-
	00000000h FFFFFFFh	Control word received through the embedded fieldbus interface.	1 = 1
06.11	Main status word	Main status word of the drive.  The bit assignments are described on page 556. The related control word and state diagram are presented on pages 554 and 557 respectively.  Note: In fieldbus control, this parameter value is not exactly the same as the status word that the drive sends to the PLC.  See parameter 50.12 FBA A debug mode.  This parameter is read-only.	-
	0000hFFFFh	Main status word.	1 = 1

No.	Name/Value	Description	Def/ FbEq16
06.16	Drive status word 1	Drive status word 1. This parameter is read-only.	1

Bit	Name	Description
0	Enabled	1 = Both run enable (see par. 20.12) and start enable (20.19) signals are present, and Safe torque off has not been activated.  Notes:
		<ul> <li>In I/O or local control, clearing this bit makes the drive enter the SWITCH-ON INHIBITED state (see page 556).</li> </ul>
		This bit is not affected by the presence of a fau
1	Inhibited	1 = Start inhibited. See parameters <i>06.18</i> for th source of the inhibiting signal.
2	DC charged	1 = DC circuit has been charged. If present, the DC switch is closed, and charging switch is ope 0 = Charging not complete. If the inverter unit is not equipped with a DC switch (option +F286), check setting of 95.09.
3	Ready to start	1 = Drive is ready to receive a start command
4	Following reference	1 = Drive is ready to follow given reference
5	Started	1 = Drive has been started
6	Modulating	1 = Drive is modulating (output stage is being controlled)
7	Limiting	1 = Any operating limit (speed, torque, etc.) is active
8	Local control	1 = Drive is in local control
9	Network ctrl	1 = Drive is in <i>network control</i> (see page 13)
10	Ext1 active	1 = Control location EXT1 active
11	Ext2 active	1 = Control location EXT2 active
12	Reserved	
13	Start request	1 = Start requested  Note: At the time of publishing, a start request from the control panel does not activate this bit any start-inhibiting condition (see bit 1) is present.
1415	Reserved	<u> </u>
FFFFh	Drive status wo	rd 1.

No.	Name/Value	Description	Def/ FbEq16
06.17		Drive status word 2. This parameter is read-only.	-

1 = Motor identification (ID) run has been performed

Description

Bit

Name

Identification run

	done	moter (assume (as) tan mas seen performed
1 Magnetized 1		1 = The motor has been magnetized
2	Torque control	1 = Torque control mode active
3	Speed control	1 = Speed control mode active
4	Power control	1 = Reserved
5	Safe reference active	1 = A "safe" reference is being applied by functions such as parameters 49.05 and 50.02
6	Last speed active	1 = A "last speed" reference is being applied by functions such as parameters 49.05 and 50.02
7	Loss of reference	1 = Reference signal lost
8	Emergency stop failed	1 = Emergency stop failed (see parameters 31.32 and 31.33)
9	Jogging active	1 = Jogging enable signal is on
10	Above limit	1 = Actual speed, frequency or torque equals or exceeds limit (defined by parameters 46.3146.33). Valid in both directions of rotation.
11	Emergency stop active	1 = An emergency stop command signal is active, or the drive is stopping after receiving an emergency stop command.
12	Reduced run	1 = Reduced run active (see section <i>Reduced run function</i> on page <i>107</i> )
13	Reserved	
14	Ctan failed	1 = Stopping failed (see parameter 31.37 and 31.38.
14	Stop failed	1 - Stopping lance (See parameter \$7.57 and \$7.50.

	Name	e/Value [	Description Description FbI	f/ Eq16
8	Start in word	tr s m S	tart inhibit status word. This word specifies the source of the inhibiting condition that is preventing the drive from starting. After the condition is removed, the start command must be cycled. See bit-specific notes. the ealso parameter 06.16 Drive status word 1, bit 1 and 6.25 Drive inhibit status word 2. This parameter is read-only.	
	Bit	Name	Description	Note
	0	Not ready run	1 = DC voltage is missing or drive has not been parametrized correctly. Check the parameters in groups 95 and 99.	а
	1	Ctrl location changed	1 = Control location has changed	а,с
	2	SSW inhibit	1 = Control program is keeping itself in inhibited state	а
	3	Fault reset	1 = A fault has been reset	a,c
	4	Lost start enable	1 = Start enable signal missing	а
	5	Lost run enable	1 = Run enable signal missing	а
	6	FSO inhibit	1 = Operation prevented by FSO-xx safety functions module	b
	7	STO	1 = Safe torque off active	b
	8	Current calibration ended	1 = Current calibration routine has finished	b,c
	9	ID run ended	1 = Motor identification run has finished	b,c
	10	Auto phase ended	1 = Autophasing routine has finished	b,c
	11	Em Off1	1 = Emergency stop signal (mode Off1)	b
	12	Em Off2	1 = Emergency stop signal (mode Off2)	b
	13	Em Off3	1 = Emergency stop signal (mode Off3)	b
	14	Auto reset inhibit	1 = The autoreset function is inhibiting operation	
	15	Jogging active	1 = The jogging enable signal is inhibiting operation	b

15	Jogging active	1 = The jogging enable signal is inhibiting operation	b		
Notes	· ·				
a If bit 1 of 06.16 Drive status word 1 is still set after the removal of the inhibiting condition, and edge triggering is selected for the active external control location, a fresh rising-edge start signal is required. See parameters 20.02, 20.07 and 20.19.					
b	If bit 1 of 06.16 Drive status word 1 is still set after the removal of the inhibiting condition, a fresh rising-edge start signal is required.				
С	Informative bit. The inhibiting condition need not be removed by the user.				

No.	Name/Value	Description	Def/ FbEq16
06.19	Speed control status word	Speed control status word. This parameter is read-only.	-

Bit	Name	Description		
0	Zero speed	1 = Drive is running at zero speed, ie. the absolute value of par. 90.01 Motor speed for control has remained below 21.06 Zero speed limit for longer than 21.07 Zero speed delay.		
1	Forward	1 = Drive is running in forward direction above zero speed limit, ie. [90.01] > + [21.06] Time		
2	Reverse	1 = Drive is running in reverse direction above zero speed limit, ie. [90.01] > + [21.06]		
3	Out of window	1 = Speed error window control active (see par. 24.41)		
4	Internal speed feedback	1 = Estimated speed feedback used in motor control, ie. estimated speed is selected by par. 90.41 or 90.46, or selected encoder has faulted (par. 90.45) 0 = Encoder 1 or 2 is used for speed feedback.		
5	Encoder 1 feedback	1 = Encoder 1 used for speed feedback in motor control 0 = Encoder 1 faulted or not selected as source of speed feedback (see par. 90.41 and 90.46).		
6	Encoder 2 feedback	<ul> <li>1 = Encoder 2 used for speed feedback in motor contr</li> <li>0 = Encoder 2 faulted or not selected as source of speed feedback (see par. 90.41 and 90.46).</li> </ul>		
7	Any constant speed request	1 = A constant speed or frequency has been selected; see par. 06.20.		
8	Follower speed corr min lim	1 = Minimum limit of speed correction (in a speed-controlled follower) has been reached (see par. 23.3923.41).		
9	Follower speed corr max lim	r 1 = Maximum limit of speed correction (in a speed-controlled follower) has been reached (see par. 23.3923.41).		
1015	Reserved			

	0000hFFFFh	Speed control status word.	1 = 1
06.20	Constant speed status word	Constant speed/frequency status word. Indicates which constant speed or frequency is active (if any). See also parameter 06.19 Speed control status word, bit 7, and section Constant speeds/frequencies (page 65). This parameter is read-only.	-

Name	Description
Constant speed 1	1 = Constant speed or frequency 1 selected
Constant speed 2	1 = Constant speed or frequency 2 selected
Constant speed 3	1 = Constant speed or frequency 3 selected
Constant speed 4	1 = Constant speed or frequency 4 selected
Constant speed 5	1 = Constant speed or frequency 5 selected
Constant speed 6	1 = Constant speed or frequency 6 selected
Constant speed 7	1 = Constant speed or frequency 7 selected
Reserved	
	Constant speed 1 Constant speed 2 Constant speed 3 Constant speed 4 Constant speed 5 Constant speed 6 Constant speed 7

0000hFFFFh	Constant speed/frequency status word.	1 = 1
------------	---------------------------------------	-------

	Name/	Value	Descrip	tion	Def/ FbEq16	
21				atus word 3. ameter is read-only.	-	
	Bit	Name		Description		
	0	DC hold activ	'e	1 = DC hold is active (see par. 21.08)		
	1	Post-magneti active	zing	1 = Post-magnetizing is active (see par. 21.08)		
	2	Motor pre-he active	ating	1 = Motor pre-heating is active (see par. 21.14)		
	3	Smooth start	active	Reserved.		
	4	Rotor position	n known			
	5	Brake choppe	er active	1 = Brake chopper is active.		
	615	Reserved		1		
	0000h.	FFFFh	Drive sta	atus word 3.	1 = 1	
	word 2		starting. must be See also 06.16 D	hibiting condition that is preventing the drive from After the condition is removed, the start command cycled. See bit-specific notes.  o parameter 06.18 Start inhibit status word, and rive status word 1, bit 1.  ameter is read-only.		
	Bit	Name	De	escription	Note	
	0	Follower drive	1:	= A follower is preventing the master from starting.	а	
	1	Application		<ul> <li>The application program is preventing the drive from arting.</li> </ul>	m b	
	2	2 Reserved				
	3	Encoder feed		The encoder feedback configuration is preventing e drive from starting.	а	
	4	Ref source parametrization	on pr	= A reference source parametrization conflict is eventing the drive from starting. See warning <i>A6DA</i> eference source parametrization (page 484).	b	
	515	Reserved	· ·			
		•				
	Notes					
			0.00	atus word 1 is still set after the removal of the inhibit		

	0000hFFFFh	Start inhibit status word 2.	1 = 1
06.29	MSW bit 10 sel	Selects a binary source whose status is transmitted as bit 10 of 06.11 Main status word.	Above limit
	FALSE	0.	0
	True	1.	1

If bit 1 of 06.16 Drive status word 1 is still set after the removal of the inhibiting condition, a fresh rising-edge start signal is required.

No.	Name/Value	Description	Def/ FbEq16
	Above limit	Bit 10 of 06.17 Drive status word 2 (see page 137).	2
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
06.30	MSW bit 11 sel	Selects a binary source whose status is transmitted as bit 11 of 06.11 Main status word.	Ext ctrl loc
	FALSE	0.	0
	True	1.	1
	Ext ctrl loc	Bit 11 of 06.01 Main control word (see page 135).	2
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
06.31	MSW bit 12 sel	Selects a binary source whose status is transmitted as bit 12 of 06.11 Main status word.	Ext run enable
	FALSE	0.	0
	True	1.	1
	Ext run enable	Inverted bit 5 of 06.18 Start inhibit status word (see page 138).	2
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
06.32	MSW bit 13 sel	Selects a binary source whose status is transmitted as bit 13 of 06.11 Main status word.	FALSE
	FALSE	0.	0
	True	1.	1
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
06.33	MSW bit 14 sel	Selects a binary source whose status is transmitted as bit 14 of 06.11 Main status word.	FALSE
	FALSE	0.	0
	True	1.	1
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-

No.	Name/Value		Description	Def/ FbEq16		
06.36	LSU Sta	tus Word	(Only visible when supply unit control activated by 95.20) Shows the status of the supply unit.	-		
	_		See also section Control of a supply unit (LSU) (page 61).			
	Bit	Name	Description			
	0	Ready on	1 = Ready to switch on			
	1	Ready run	1 = Ready to operate, DC link charged			
	2	Ready ref	1 = Operation enabled			
	3	Tripped	1 = A fault is active			
	46	Reserved	1 - A lault is active			
	7	Warning	1 = A warning is active			
	8	Modulating	1 = The supply unit is modulating			
	9	Remote	1 = Remote control (EXT1 or EXT2)			
	3	Remote	0 = Local control			
	10	Net ok	1 = Supply network voltage OK			
	1112	Reserved	· Cuppi, namani ranaga ari			
	13	Charging or	1 = Bit 1 or bit 14 active			
		ready run	I - Bit I of bit 14 active			
	14 Charging		1 = Charging circuit active 0 = Charging circuit inactive			
	15	Reserved				
	0000h	FFFFh	Supply unit status word.	1 = 1		
06.39	Internal : machine	state LSU CW	(Only visible when supply unit control activated by 95.20) Shows the control word sent to the supply unit from the INULSU (inverter unit/supply unit) state machine. This parameter is read-only.	-		
	D:4	IN.	Description			
	Bit 0	Name ON/OFF	Description 1 = Start charging			
	U	ON/OFF	0 = Open main contactor (switch power off)			
	1	OFF 2	0 = Emergency stop (Off2)			
			o - Emergency stop (Onz)			
	2	OFF 3	0 = Emergency stop (Off3)			
	3		9 7 1 7			
		OFF 3	0 = Emergency stop (Off3) 1 = Start modulating			
	3	OFF 3 START	0 = Emergency stop (Off3) 1 = Start modulating	ired after reset.		
	3	OFF 3 START Reserved	0 = Emergency stop (Off3) 1 = Start modulating 0 = Stop modulating	ired after reset.		
	3 46 7	OFF 3 START Reserved RESET	0 = Emergency stop (Off3) 1 = Start modulating 0 = Stop modulating	ired after reset.		
	3 46 7 811	OFF 3 START Reserved RESET Reserved	0 = Emergency stop (Off3) 1 = Start modulating 0 = Stop modulating 0 -> 1 = Reset an active fault. A fresh start command is requ	ired after reset.		
	3 46 7 811 12	OFF 3 START Reserved RESET Reserved USER BIT 0	0 = Emergency stop (Off3)  1 = Start modulating 0 = Stop modulating  0 -> 1 = Reset an active fault. A fresh start command is requ  See parameter 06.40 LSU CW user bit 0 selection.	ired after reset.		
	3 46 7 811 12 13	OFF 3 START Reserved RESET Reserved USER BIT 0 USER BIT 1	0 = Emergency stop (Off3) 1 = Start modulating 0 = Stop modulating 0 -> 1 = Reset an active fault. A fresh start command is requ See parameter 06.40 LSU CW user bit 0 selection. See parameter 06.41 LSU CW user bit 1 selection.	ired after reset.		
	3 46 7 811 12 13 14	OFF 3 START  Reserved RESET Reserved USER BIT 0 USER BIT 1 USER BIT 2	0 = Emergency stop (Off3) 1 = Start modulating 0 = Stop modulating 0 -> 1 = Reset an active fault. A fresh start command is requ See parameter 06.40 LSU CW user bit 0 selection. See parameter 06.41 LSU CW user bit 1 selection. See parameter 06.42 LSU CW user bit 2 selection.	ired after reset.		

No.	Name/Value	Description	Def/ FbEq16
06.40	LSU CW user bit 0 selection	(Only visible when supply unit control activated by 95.20) Selects a binary source whose status is transmitted as bit 12 of 06.39 Internal state machine LSU CW to the supply unit.	MCW user bit 0
	False	0.	0
	True	1.	1
	MCW user bit 0	Bit 12 of 06.01 Main control word (see page 134).	2
	MCW user bit 1	Bit 13 of 06.01 Main control word (see page 134).	3
	MCW user bit 2	Bit 14 of 06.01 Main control word (see page 134).	4
	MCW user bit 3	Bit 15 of 06.01 Main control word (see page 134).	5
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
06.41	LSU CW user bit 1 selection	MCW user bit	
	False	0.	0
	True	1.	1
	MCW user bit 0	Bit 12 of 06.01 Main control word (see page 134).	2
	MCW user bit 1	Bit 13 of 06.01 Main control word (see page 134).	3
	MCW user bit 2	Bit 14 of 06.01 Main control word (see page 134).	4
	MCW user bit 3	Bit 15 of 06.01 Main control word (see page 134).	5
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
06.42	LSU CW user bit 2 selection	(Only visible when supply unit control activated by 95.20) Selects a binary source whose status is transmitted as bit 14 of 06.39 Internal state machine LSU CW to the supply unit.	MCW user bit 2
	False	0.	0
	True	1.	1
	MCW user bit 0	Bit 12 of 06.01 Main control word (see page 134).	2
	MCW user bit 1	Bit 13 of 06.01 Main control word (see page 134).	3
	MCW user bit 2	Bit 14 of 06.01 Main control word (see page 134).	4
	MCW user bit 3	Bit 15 of 06.01 Main control word (see page 134).	5
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
06.43	LSU CW user bit 3 selection	(Only visible when supply unit control activated by 95.20) Selects a binary source whose status is transmitted as bit 15 of 06.39 Internal state machine LSU CW to the supply unit.	MCW user bit 3
	False	0.	0
	True	1.	1
	MCW user bit 0	Bit 12 of 06.01 Main control word (see page 134).	2
	MCW user bit 1	Bit 13 of 06.01 Main control word (see page 134).	3
	MCW user bit 2	Bit 14 of 06.01 Main control word (see page 134).	4

No.	Name/Value  MCW user bit 3		Description		Def/ FbEq16	
			Bit 15 of 06.01 Main control word (see page 134).		5	
	Other [bit]			Source select	tion (see Terms and abbreviations on page	-
06.50	User status	word	1	the binary sou	status word. This word shows the status of cross selected by parameters 06.6006.75. er is read-only.	-
		Bit	Nar	ne	Description	
		0	Use	r status bit 0	Status of source selected by parameter 06.6	0
		1	Use	r status bit 1	Status of source selected by parameter 06.6	1
		 15	 Use	r status bit 15	 Status of source selected by parameter 06.7	5
	0000hFFF	Fh		User-defined	status word.	1 = 1
06.60	User status 0 sel	word 1	1 bit	Selects a bina 06.50 User st	ary source whose status is shown as bit 0 of latus word 1.	FALSE
	FALSE			0.		0
	True			1.		1
	Other [bit]			Source select page 118).	tion (see Terms and abbreviations on	-
06.61	User status word 1 bit 1 sel			Selects a bina 06.50 User st	ary source whose status is shown as bit 1 of latus word 1.	Out of windo
	FALSE			0.		0
	True			1.		1
	Out of window			Bit 3 of 06.19	Speed control status word (see page 139).	2
	Other [bit]			Source select page 118).	tion (see Terms and abbreviations on	-
06.62	User status word 1 bit 2 sel			Selects a bina	ary source whose status is shown as bit 2 of latus word 1.	Emergency stop failed
	FALSE			0.		0
	True			1.		1
	Emergency stop failed			Bit 8 of 06.17	Drive status word 2 (see page 137).	2
	Other [bit]			Source select page 118).	tion (see Terms and abbreviations on	-
06.63	User status 3 sel	word 1	1 bit	Selects a bina 06.50 User st	ary source whose status is shown as bit 3 of latus word 1.	Magnetized
	FALSE			0.		0
	True	True				1
	Magnetized		Bit 1 of 06.17	Drive status word 2 (see page 137).	2	
	Other [bit]			Source select page 118).	tion (see Terms and abbreviations on	-
06.64	User status 4 sel	word 1	1 bit	Selects a bina	ary source whose status is shown as bit 4 of latus word 1.	Run disable
	FALSE			0.		0
	True			1.		1

No.	Name/Value	Description	Def/ FbEq16
	Run disable	Bit 5 of 06.18 Start inhibit status word (see page 138).	2
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
06.65	User status word 1 bit 5 sel	Selects a binary source whose status is shown as bit 5 of 06.50 User status word 1.	FALSE
	FALSE	0.	0
	True	1.	1
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
06.66	User status word 1 bit 6 sel	Selects a binary source whose status is shown as bit 6 of 06.50 User status word 1.	FALSE
	FALSE	0.	0
	True	1.	1
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
06.67	User status word 1 bit 7 sel	Selects a binary source whose status is shown as bit 7 of 06.50 User status word 1.	Identification run done
	FALSE	0.	0
	True	1.	1
	Identification run done	Bit 0 of 06.17 Drive status word 2 (see page 137).	2
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
06.68	User status word 1 bit 8 sel	Selects a binary source whose status is shown as bit 8 of 06.50 User status word 1.	Start inhibition
	FALSE	0.	0
	True	1.	1
	Start inhibition	Bit 7 of 06.18 Start inhibit status word (see page 138).	2
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
06.69	User status word 1 bit 9 sel	Selects a binary source whose status is shown as bit 9 of 06.50 User status word 1.	Limiting
	FALSE	0.	0
	True	1.	1
	Limiting	Bit 7 of 06.16 Drive status word 1 (see page 136).	2
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
06.70	User status word 1 bit 10 sel	Selects a binary source whose status is shown as bit 10 of 06.50 User status word 1.	Torque control
	FALSE	0.	0
	True	1.	1
	Torque control	Bit 2 of 06.17 Drive status word 2 (see page 137).	2
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-

No.	Name/Value	Descript	Description				
06.71	User status word 1 bit 11 sel		binary source whose stater status word 1.	us is shown as bit 11 of	Zero speed		
	FALSE	0.			0		
	True	1.			1		
	Zero speed	Bit 0 of 06	Bit 0 of 06.19 Speed control status word (see page 139).				
	Other [bit]	Source se page 118	election (see <i>Terms and a</i> ).	bbreviations on	-		
06.72	User status word 1 bit 12 sel		binary source whose state or status word 1.	us is shown as bit 12 of	Internal speed feedback		
	FALSE	0.			0		
	True	1.			1		
	Internal speed feedback	Bit 4 of 06	6.19 Speed control status	word (see page 139).	2		
	Other [bit]	Source se page 118	election (see <i>Terms and a</i> ).	bbreviations on	-		
06.73	User status word 1 bit 13 sel		binary source whose state or status word 1.	us is shown as bit 13 of	FALSE		
	FALSE	0.			0		
	True	1.			1		
	Other [bit]	Source se page 118	election (see <i>Terms and a</i> ).	bbreviations on	-		
06.74	User status word 1 bit 14 sel		binary source whose state er status word 1.	us is shown as bit 14 of	FALSE		
	FALSE	0.			0		
	True	1.			1		
	Other [bit]	Source se page 118	election (see <i>Terms and a</i> ).	bbreviations on	-		
06.75	User status word 1 bit 15 sel		binary source whose state er status word 1.	us is shown as bit 15 of	False		
	False	0.			0		
	True	1.			1		
	Other [bit]	Source se page 118	election (see <i>Terms and a</i> ).	bbreviations on	-		
06.100	User control word 1	User-defi	ned control word 1.		-		
		Bit N	ame	Description			
			ser control word 1 bit 0	User-defined bit.			
		-	ser control word 1 bit 1	User-defined bit.			
		15 U	ser control word 1 bit 15	User-defined bit.			
	0000hFFFFh	User-defi	ned control word 1.		1 = 1		
	İ						

No.	Name/V	alue	Description	Def/ FbEq16			
06.101	User con	ntrol word 2	User-defined control word 2.	-			
			Bit Name Description				
			0 User control word 2 bit 0 User-defined bit.				
			1 User control word 2 bit 1 User-defined bit.				
			15 User control word 2 bit 15 User-defined bit.	]			
	0000h	FFFFh	User-defined control word 2.	1 = 1			
06.116	LSU driv word 1		(Only visible when IGBT supply unit control activated 95.20) Drive status word 1 received from the supply unit.	by -			
			See also section <i>Control of a supply unit (LSU)</i> (page This parameter is read-only.	61)			
	Bit	Name	Description				
	0	Enabled	1 = Run enable and start enable signals are present				
	1	Inhibited	1 = Start inhibited				
	2	Operation allowed	1 = Drive is ready to operate				
	3	Ready to start	1 = Drive is ready to receive a start command				
	4	Running	1 = Drive is ready to follow given reference				
	5	Started	1 = Drive has been started				
	6	Modulating	1 = Drive is modulating (output stage is being contro	lled)			
	7	Limiting	1 = Any operating limit is active				
	8	Local control	1 = Drive is in local control				
	9	Network control	1 = Drive is in network control				
	10	Ext1 active	1 = Control location Ext1 active				
	11	Ext2 active	1 = Control location Ext2 active				
	12	Charging relay					
	13	MCB relay	1 = MCB relay is closed				
	1415	Reserved					
	0000h	FFFFh	Drive status word 1.	1 = 1			

No.	Name/Value	Descr	Description		
06.118	LSU start inhibit status word	95.20) This w that is See al:	(Only visible when IGBT supply unit control activated by 95.20)  This word specifies the source of the inhibiting condition that is preventing the supply unit from starting.  See also section Control of a supply unit (LSU) (page 61).  This parameter is read-only.		
		Bit	Name		
		0	Not ready run		
		1	Ctrl location changed		
		2	SSW inhibit		
		3	Fault reset		
		4	Lost start enable		
		5	Lost run enable		
		68	Reserved		
		9	Charging overload		
		1011	Reserved		
		12	Em Off2		
		13	Em Off3		
		14	Auto reset inhibit		
		15	Reserved		
	0000hFFFFh	Start in	nhibit status word of supply unit.	1 = 1	
07 Sys	stem info	Informa progra All para			

07 Sys	stem info	Information on drive hardware, firmware and application program. All parameters in this group are read-only.	
07.03	Drive rating id	Type of the drive/inverter unit.	-
07.04	Firmware name	Firmware identification. The format is AINFX, where X denotes the control unit type (2 or B = BCU-x2, 6 or C = ZCU-12/14).	-
07.05	Firmware version	Version number of the firmware. The format is A.BB.C.D, where A = major version, B = minor version, C = patch (ie. firmware variant code), D = 0.	-
07.06	Loading package name	Name of the firmware loading package. The format is AINLX, where X denotes the control unit type (2 or B = BCU-x2, 6 or C = ZCU-12/14).	-
07.07	Loading package version	Version number of the firmware loading package. See parameter 07.05.	-
07.08	Bootloader version	Version number of the firmware bootloader.	-
07.11	Cpu usage	Microprocessor load in percent.	-
	0100%	Microprocessor load.	1 = 1%
07.13	PU logic version number	Version number of the power unit logic. The value of FFFF indicates that the version numbers of parallel-connected power units are different. See the drive information on the control panel.	-
07.15	FPGA logic version number	Version number of the FPGA logic of the control unit.	-

No.	Name/	Value		Descript	lian .	Defi
NO.	Name/	value		Descript	tion	Def/ FbEq16
07.21	Application environment status 1		programmer Shows w	ible with option +N8010 [application mability]) hich tasks of the application program are running. Drive (IEC 61131-3) application programming BAUA0000127808 [English]).	-	
	Bit	Name	)		Description	
	0	Pre ta			1 = Pre-task running.	
	1	Appl t	ask1		1 = Task 1 running.	
	2	Appl t	ask2		1 = Task 2 running.	
	3	Appl t			1 = Task 3 running.	
	414	Reser				
	15	Taskı	monito	pring	1 = Task monitoring enabled.	
	0000h	FFFFh	1	Application	on program task status.	1 = 1
07.22	Applica environ	tion ment sta	atus 2	programmer Shows the program. See the L	e status of the openings in the application	-
			Bit	Name	Description	]
				Opening1	Status of opening 1 in the application program.	
			1	Opening2	Status of opening 2 in the application program.	
						_
			15	Opening16	Status of opening 16 in the application program.	
	0000h.	FFFFh	1	Application	on program opening status.	1 = 1
07.23	Applica	tion nan	ne	programi First five program under Sy	ASCII letters of the name given to the application in the programming tool. The full name is visible stem info on the control panel or the Drive r PC tool.	-
07.24	Application version  Customization package name		programma Application application under Sy	(Only visible with option +N8010 [application programmability]) Application program version number given to the application program in the programming tool. Also visible under System info on the control panel or the Drive composer PC tool.		
07.25			customiz	ASCII letters of the name given to the ation package. The full name is visible under not on the control panel or the Drive composer PC None.	-	
07.26	Custom packag	nization e versio	n		ation package version number. Also visible under nfo on the control panel or the Drive composer PC	-

No.			Descrip	tion	Def/ FbEq16			
07.30			Shows the status of the adaptive program. See section Adaptive programming (page 58).					
	Bit	Name		Description				
	0	Initialized		1 = Adaptive program initialized				
	1	Editing		1 = Adaptive program is being edited				
	2	Edit done		1 = Editing of adaptive program finished				
	3	Running		1 = Adaptive program running				
	413	Reserved						
	14	State changi	ng	1 = State change in progress in adaptive program	ming engine			
	15	Faulted		1 = Error in adaptive program				
	0000h	EEEEh	Adaptive	program status.	1 = 1			
07.40		olication Cpu		sible with option +N8010 [application	1-1			
	usage peak		programmability]) Displays the peak loading of the microprocessor caused by the application program. This parameter can, for example, be used to check the effect of a given application program functionality on the CPU load.  The value is in percent of an internal quota.  Can be reset from the control panel by keeping Reset depressed for over 3 seconds.					
	0.0 1	. 100.0% Peal prog		croprocessor loading caused by application	10 = 1%			
07.41	IEC application Cpu load average		programi Displays caused b	ible with option +N8010 [application mability]) the average loading of the microprocessor by the application program. The value is in percent ernal quota.	-			
	0.0 1	00.0%	Average microprocessor loading caused by application program.		10 = 1%			
07.51	Slot 1 o	ption module	Displays control u	the type of module detected in slot 1 of the drive nit.	No option			
	No optio	on	No modu	ıle detected.	0			
	[module	type]	Type of module detected.		-			
07.52	Slot 2 o	ption module	Displays control u	the type of module detected in slot 2 of the drive nit.	No option			
	No optio	on	No modu	ule detected.	0			
	[module	type]	Type of r	module detected.	-			
07.53	-	ption module	Displays control u	the type of module detected in slot 3 of the drive nit.	No option			
	No optio	on	No modu	ıle detected.	0			
	[module		Type of r	module detected.	_			
07.106	-	nding package	(Only vis 95.20)	the loading package of the supply unit firmware.	-			

No.	Name/Value	Description	Def/ FbEq16
07.107	LSU loading package version	(Only visible when IGBT supply unit control activated by 95.20) Version number of the loading package of the supply unit firmware.	

09 Pump actuals		Basic signals for monitoring the application.	
	<u>'</u>	All parameters in this group are read-only unless otherwise noted.	
09.01	Rod torque	Estimated pump torque in engineering units.	0.00 N•m or lbft
	-100000.00 100000.00	Value range	See par. 46.200
09.02	Maximum rod torque	Maximum allowed pump torque in engineering units.	0.00
	-100000.00 100000.00	Value range	See par. 46.200
09.03	Motor torque	Actual motor torque in engineering units.	0.00 N•m or lbft
	-100000.00 100000.00	Value range	See par. 46.200
09.04	Maximum motor torque	Maximum allowed motor torque in engineering units.	0.00 N•m or lbft
	-100000.00 100000.00	Value range	See par. 46.200
09.05	Rod speed	Pump speed in engineering units.	0.00 Prpm, rpm or Hz
	-100000.00 100000.00	Value range	See par. 46.201
09.06	Motor speed reference	Motor speed reference in engineering units.	0.00 rpm or Hz
	-100000.00 100000.00	Value range	See par. 46.203
09.07	Run-time hours	Runtime of the pump in hours.	0.00 h
	0.00100000.00	Value range	10 = 1 h
09.08	Fluid level	Measured fluid level in depth units.	0.00 m, ft or Joints
	-100000.00 100000.00	Value range	1 = 1 m, ft or joints
09.09	Pressure	Measured pressure in engineering units.	0.00 kPa or psi
	-100000.00 100000.00	Value range	10 = 1 kPa or psi
09.10	Measured temperature	Measured temperature in engineering units.	0.00 °C
	-100000.00 100000.00	Value range	10 = 1 °C
09.11	Backspin speed reference	Speed reference for controllable shutdown procedure.	0.00 Prpm, rpm or Hz

No.	Nan	ne/Value	Description		Def/ FbEq16
	-100000.00 100000.00		Value range		10 = 1 Prpr rpm or Hz
09.12	12 Start delay remain 04294967.295		Remaining start de	elay time.	0.000s
			Value range	·	10 = 1 s
09.13	Backspin status word		Pump backspin sta	atus word.	0000h
	Bit	Name		Description	
	0	Backspin enab	led	Backspin function is enabled.	
	1	Backspin opera	ation active	Backspin function is active.	
	2	Backspin limit	active	Backspin limit is reached.	
	39	Reserved			
	10	Start delay ena	abled	Start delay function is enabled.	
	11	Start delay time	er active	Start delay function is active.	
	12	15 Reserved		•	
	0000	)hFFFFh	Backspin status wo	ord	1 = 1
09.14	Pum	p status word	Pump control program status word.		0000h
	Bit	Name		Description	
	0	Thermal protection reached	on alarm level	Alarm due to thermal protection failure.	
	1	Thermal protection fault level reached		Drive tripped due to thermal protection to	failure.
	2	Thermal protection		Actual temperature for thermal protection.	
	3	High pressure pre sensor	esented - digital	High pressure measured by digital sensor.	
	4	High pressure presented - analogue sensor		High pressure measured by analog sensor.	
	5	High pressure protection active		Actual value for high pressure protection.	
	6	Underload protect	tion active	Actual value for underload protection.	
	7	Rod torque 1 acti		Actual rod torque 1.	
	8	Rod torque 2 acti		Actual rod torque 2.	
	9	Torque protection		Actual value for torque protection.	
	10	Sleep mode activ		Actual value for sleep mode.	
	11	Fault delay active	•	Fault delay is active.	
	12	Replace battery		Battery from ZCU is needed to replace.	
	13	Brake confirm ac	tive	Brake confirm is active.	
	14	Starting speed ac	ctive	Drive is ready for startup ramp.	
	15	Rod torque 2 spe	ed	Reserved for rod torque 2 speed.	
		hFFFFh	Pump status word.		1 = 1
09.15	Slee	p feedback value		sleep signal feedback from different ep signal source 1 and 75.35 Sleep	0.00 SourceUnit
	100000.00100000.		Value range		1 = 1

No.	Name/Value	Description	Def/ FbEq16
09.16	Sleep time	Period of time when pump is in sleep mode.	0.000 s
	0100000.000 s	Value range	10 = 1 s
09.17	Backspin operation	Shows actual state of backspin.	Not active
	Not active	Backspin operation is not active.	0
	Active	Backspin operation is active.	1
09.18	Fault word 1	The bit assignments of this word correspond to a FAULT.	


Bit	Name	Description
0	Short circuit	See event 2340 (page 497).
1	Overcurrent	See event 2310 (page 496).
2	DC overvoltage	See event 3210 (page 497).
3	ACS880 Temp	See events 2381 (page 498), 4210, 4290, 42F1, 4310, 4380 (page 500).
4	Earth fault	See event 2330 (page 497), 2392, 3181 (page 498).
5	Thermistor	See event 4981 (page 501).
6	Motor temperature	See event 4982 (page 501)
7	System fault	See events 6481, 6487, 64A1, 64A2, 64A3, 64B1, 64E1, 6881, 6882, 6883, 6885 (page 506).
8	Underload	See event <i>D101</i> (page <i>516</i> ), <i>D202</i> (page <i>494</i> ).
9	Overfreq	See event 7310 (page 511).
10	Line converter	Reserved
1115	Reserved	•

09.19	Fault word 2	The bit assignments of this word correspond to a FAULT.	

No.	Name/Val	ue	Descrip	tion	Def/ FbEq16
	Bit	Name		Description	]
	0	Supply pha	ase	See event 3130 (page 498).	
	1	No motor o	data	See event A6A5 (page 483).	
	2	DC underv	olt	See event 3220 (page 499).	
	3	External fa	ult	See events 9081, 9082, 9083, 9084, 9085 (page 513).	
	4	Run disabl	е	See event AFEB (page 493).	
	5	Encoder fa	ıult	See event 7301, 7380, 7381, 73A0, 73A1 (page 511).	
	6	IO fault		See event 7080, 7082 (page 509).	
	7	Reserved			
	8	Al <min< td=""><td></td><td>See event 80A0 (page 513).</td><td></td></min<>		See event 80A0 (page 513).	
	910	Reserved			
	11	PPCC link	fault	See events 5681, 5682, 5690, 5691, 5692, 5693, 5694 (page 504).	
	12	Comm mod	dule	See event 6681 (page 508), 7510, 7520 (page 512).	
	13	Panel loss		See event 7081 (page 509).	
	14	Motor stall		See event 7121 (page 510).	
	15	Motor phas	se fault	See event 3381 (page 499).	]
09.20	Application word	n status	Application	on status word.	

Bit	Name	Description
0	High pressure	Pressure protection digital sensor is active.
1	High discharge pressure	Pressure protection analog sensor is active.
2	Rod torque 1 limit	Rod torque 1 protection is active.
3	Rod torque 2 limit	Rod torque 2 protection is active.
4	Rod torque 2 speed act	Rod torque 2 speed act.
5	Backspin limit	Backspin limit is reached.
6	Underload	Underload protection is active.
7	High pump temp	Thermal protection is active.
8	Reserved	
9	Motor stall warning	Motor stall warning is active. See parameter 31.24.
10	External fault	External fault is active. See parameters 31.0131.10.
11	Al <min< td=""><td>An analog signal is outside the limits specified for the analog input.</td></min<>	An analog signal is outside the limits specified for the analog input.
12	Panel loss	Control panel connection loss.
13	Relay out 1 status	Status of relay 1.
14	Relay out 2 status	Status of relay 2.
15	Relay out 3 status	Status of relay 3.


No.	Name/Value	Description	Def/ FbEq16
09.70	Inverter kWh motoring	Amount of energy that has passed through the drive (towards the motor) in full kilowatt-hours.  Whenever the counter rolls over, parameter 01.19 Inverter MWh motoring is incremented. The minimum value is zero.	-
	01000 kWh	Amount of energy in kilowatt-hour.	1 = 1 rpm
10 Sta	ndard DI, RO	Configuration of digital inputs and relay outputs.	
10.01	DI status	Displays the electrical status of digital inputs DIIL and DI6DI1. The activation/deactivation delays of the inputs (if any are specified) are ignored. A filtering time can be defined by parameter 10.51 DI filter time.  Bits 05 reflect the status of DI1DI6; bit 15 reflects the status of the DIIL input. <b>Example</b> : 100000000001011b = DIIL, DI5, DI2 and DI1 are on, DI3, DI4 and DI6 are off. This parameter is read-only.	-
	0000hFFFFh	Status of digital inputs.	1 = 1
10.02	DI delayed status	Displays the status of digital inputs DIIL and DI6DI1. This word is updated only after activation/deactivation delays (if any are specified). A filtering time can be defined by parameter 10.51 DI filter time. Bits 05 reflect the delayed status of DI1DI6; bit 15 reflects the delayed status of the DIIL input. This parameter is read-only.	-
	0000hFFFFh	Delayed status of digital inputs.	1 = 1
10.03	DI force selection	The electrical statuses of the digital inputs can be overridden for eg. testing purposes. A bit in parameter 10.04 DI force data is provided for each digital input, and its value is applied whenever the corresponding bit in this parameter is 1.	0000h
	Bit Va	ilue	
	0 1=	Force DI1 to value of bit 0 of parameter 10.04 DI force data	1.
	1 1=	Force DI2 to value of bit 1 of parameter 10.04 DI force data	1.
	2 1 =	Force DI3 to value of bit 2 of parameter 10.04 DI force data	·-
		Force DI4 to value of bit 3 of parameter 10.04 DI force data	
		Force DI5 to value of bit 4 of parameter 10.04 DI force data	
		Force DI6 to value of bit 5 of parameter 10.04 DI force data	·
	<u>-</u>	served	4-
	15 1 =	Force DIIL to value of bit 15 of parameter 10.04 DI force da	ta.
	0000hFFFFh	Override selection for digital inputs.	1 = 1
10.04	DI force data	Contains the values that the digital inputs are forced to when selected by 10.03 DI force selection.  Bit 0 is the forced value for DI1; bit 15 is the forced value for the DIIL input.	0000h



No.	Name/Value	Description	Def/ FbEq16
10.09	DI3 ON delay	Defines the activation delay for digital input DI3.	0.0 s
	*DI status —		1 — 0
	**Delayed DI status	$\langle \epsilon \rangle$ $\langle \epsilon $	1 0 Time
	$t_{\rm On}$ = 10.09 DI3 ON a $t_{\rm Off}$ = 10.10 DI3 OFF *Electrical status of d **Indicated by 10.02	<i>delay</i> igital input. Indicated by <i>10.01 DI status</i> .	
	0.0 3000.0 s	Activation delay for DI3.	10 = 1 s
10.10	DI3 OFF delay	Defines the deactivation delay for digital input DI3. See parameter 10.09 DI3 ON delay.	0.0 s
	0.0 3000.0 s	Deactivation delay for DI3.	10 = 1 s
10.11	DI4 ON delay	Defines the activation delay for digital input DI4.	0.0 s
	*DI status —  **Delayed DI		1 ——— 0 1
	status —	$\langle \cdot \rangle$ $\langle \cdot $	0
	$t_{\rm On}$ = 10.11 DI4 ON d $t_{\rm Off}$ = 10.12 DI4 OFF *Electrical status of d **Indicated by 10.02	<i>delay</i> igital input. Indicated by <i>10.01 DI status</i> .	
	0.0 3000.0 s	Activation delay for DI4.	10 = 1 s
10.12	DI4 OFF delay	Defines the deactivation delay for digital input DI4. See parameter 10.11 DI4 ON delay.	0.0 s
	0.0 3000.0 s	Deactivation delay for DI4.	10 = 1 s


No.	Name/Value	Description	Def/ FbEq16
10.13	DI5 ON delay	Defines the activation delay for digital input DI5.	0.0 s
	*DI status **Delayed DI		1 0 1
	status	$\langle \cdot, \cdot \rangle$	O Time
	$t_{\rm On}$ = 10.13 DI5 ON de $t_{\rm Off}$ = 10.14 DI5 OFF de *Electrical status of dig **Indicated by 10.02 D	<i>lay</i> e <i>lay</i> jital input. Indicated by <i>10.01 DI status</i> .	
	0.0 3000.0 s	Activation delay for DI5.	10 = 1 s
10.14	DI5 OFF delay	Defines the deactivation delay for digital input DI5. See parameter 10.13 DI5 ON delay.	0.0 s
	0.0 3000.0 s	Deactivation delay for DI5.	10 = 1 s
10.15	DI6 ON delay	Defines the activation delay for digital input DI6.	0.0 s
10.15	*DI status  **Delayed DI status  t <sub>On</sub> = 10.15 DI6 ON de	Defines the activation delay for digital input DI6. $ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	
10.15	*DI status  **Delayed DI status  ton = 10.15 DI6 ON de toff = 10.16 DI6 OFF de *Electrical status of dig **Indicated by 10.02 D	Defines the activation delay for digital input DI6. $ \begin{array}{ccccccccccccccccccccccccccccccccccc$	0.0 s  1  0 1  1  Time
	**Delayed DI status  **Delayed DI status  t <sub>On</sub> = 10.15 DI6 ON de t <sub>Off</sub> = 10.16 DI6 OFF de *Electrical status of dig **Indicated by 10.02 D  0.0 3000.0 s	Defines the activation delay for digital input DI6.    Continue	0.0 s  1  0  1  Time
10.15	*DI status  **Delayed DI status  ton = 10.15 DI6 ON de toff = 10.16 DI6 OFF de *Electrical status of dig **Indicated by 10.02 D	Defines the activation delay for digital input DI6. $ \begin{array}{ccccccccccccccccccccccccccccccccccc$	0.0 s  1  0 1  1  Time
	**Delayed DI status  **Delayed DI status  t <sub>On</sub> = 10.15 DI6 ON de t <sub>Off</sub> = 10.16 DI6 OFF de *Electrical status of dig **Indicated by 10.02 D  0.0 3000.0 s	Defines the activation delay for digital input DI6.    Continue	0.0 s  1  0  1  Time
	**Delayed DI status  **Delayed DI status   t <sub>On</sub> = 10.15 DI6 ON de t <sub>Off</sub> = 10.16 DI6 OFF de *Electrical status of dig **Indicated by 10.02 D  0.0 3000.0 s  DI6 OFF delay	Defines the activation delay for digital input DI6.    Construction   Constructio	0.0 s  1  0  1  Time  10 = 1 s  0.0 s

No.	Name/Value	Description	Def/ FbEq16
10.24	RO1 source	Selects a drive signal to be connected to relay output RO1.	Ready run; 10.01 b3 (-1) (95.20 b2); 35.105 b1 (95.20 b6); 06.16 b6 (95.20 b9)
	Not energized	Output is not energized.	0
	Energized	Output is energized.	1
	Ready run	Bit 1 of 06.11 Main status word (see page 135).	2
	Enabled	Bit 0 of 06.16 Drive status word 1 (see page 136).	4
	Started	Bit 5 of 06.16 Drive status word 1 (see page 136).	5
	Magnetized	Bit 1 of 06.17 Drive status word 2 (see page 137).	6
	Running	Bit 6 of 06.16 Drive status word 1 (see page 136).	7
	Ready ref	Bit 2 of 06.11 Main status word (see page 135).	8
	At setpoint	Bit 8 of 06.11 Main status word (see page 135).	9
	Reverse	Bit 2 of 06.19 Speed control status word (see page 139).	10
	Zero speed	Bit 0 of 06.19 Speed control status word (see page 139).	11
	Above limit	Bit 10 of 06.17 Drive status word 2 (see page 137).	12
	Warning	Bit 7 of 06.11 Main status word (see page 135).	13
	Fault	Bit 3 of 06.11 Main status word (see page 135).	14
	Fault (-1)	Inverted bit 3 of 06.11 Main status word (see page 135).	15
	Start request	Bit 13 of 06.16 Drive status word 1 (see page 136).	16
	Open brake command	Bit 0 of 44.01 Brake control status.	22
	Ext2 active	Bit 11 of 06.16 Drive status word 1 (see page 136).	23
	Remote control	Bit 9 of 06.11 Main status word (see page 135).	24
	Supervision 1	Bit 0 of 32.01 Supervision status (see page 285).	33
	Supervision 2	Bit 1 of 32.01 Supervision status (see page 285).	34
	Supervision 3	Bit 2 of 32.01 Supervision status (see page 285).	35
	RO/DIO control word bit0	Bit 0 of 10.99 RO/DIO control word (see page 161).	40
	RO/DIO control word bit1	Bit 1 of 10.99 RO/DIO control word (see page 161).	41
	RO/DIO control word bit2	Bit 2 of 10.99 RO/DIO control word (see page 161).	42
	RO/DIO control word bit8	Bit 8 of 10.99 RO/DIO control word (see page 161).	43
	RO/DIO control word bit9	Bit 9 of 10.99 RO/DIO control word (see page 161).	44
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-



No.	Name/Value	Description	Def/ FbEq16
11 Sta	ndard DIO, FI, FO	Configuration of digital input/outputs and frequency inputs/outputs.	
11.01	DIO status	Displays the status of digital input/outputs DIO2DIO1. The activation/deactivation delays (if any are specified) are ignored. A filtering time (for input mode) can be defined by parameter 10.51 DI filter time.  Example: 0010 = DIO2 is on, DIO is off. This parameter is read-only.	-
	0000b0011b	Status of digital input/outputs.	1 = 1
11.02	DIO delayed status	Displays the delayed status of digital input/outputs DIO2DIO1. This word is updated only after activation/deactivation delays (if any are specified).  Example: 0010 = DIO2 is on, DIO1 is off. This parameter is read-only.	-
	0000b0011b	Delayed status of digital input/outputs.	1 = 1
11.05	DIO1 function	Selects whether DIO1 is used as a digital output or input, or a frequency input.	Output
	Output	DIO1 is used as a digital output.	0
	Input	DIO1 is used as a digital input.	1
	Frequency	DIO1 is used as a frequency input.	2
11.06	DIO1 output source	Selects a drive signal to be connected to digital input/output DIO1 when parameter 11.05 DIO1 function is set to Output.	Ready run
	Not energized	Output is off.	0
	Energized	Output is on.	1
	Ready run	Bit 1 of 06.11 Main status word (see page 135).	2
	Enabled	Bit 0 of 06.16 Drive status word 1 (see page 136).	4
	Started	Bit 5 of 06.16 Drive status word 1 (see page 136).	5
	Magnetized	Bit 1 of 06.17 Drive status word 2 (see page 137).	6
	Running	Bit 6 of 06.16 Drive status word 1 (see page 136).	7
	Ready ref	Bit 2 of 06.11 Main status word (see page 135).	8
	At setpoint	Bit 8 of 06.11 Main status word (see page 135).	9
	Reverse	Bit 2 of 06.19 Speed control status word (see page 139).	10
	Zero speed	Bit 0 of 06.19 Speed control status word (see page 139).	11
	Above limit	Bit 10 of 06.17 Drive status word 2 (see page 137).	12
	Warning	Bit 7 of 06.11 Main status word (see page 135).	13
	Fault	Bit 3 of 06.11 Main status word (see page 135).	14
	Fault (-1)	Inverted bit 3 of 06.11 Main status word (see page 135).	15
	Start request	Bit 13 of 06.16 Drive status word 1 (see page 136).	16
	Open brake command	Bit 0 of 44.01 Brake control status. (See ACS880 primary control program firmware manual (3AUA0000085967[English])).	22
	Ext2 active	Bit 11 of 06.16 Drive status word 1 (see page 136).	23
	Remote control	Bit 9 of 06.11 Main status word (see page 135).	24

No.	Name/Value	Description	Def/ FbEq16
	Supervision 1	Bit 0 of 32.01 Supervision status (see page 285).	33
	Supervision 2	Bit 1 of 32.01 Supervision status (see page 285).	34
	Supervision 3	Bit 2 of 32.01 Supervision status (see page 285).	35
	RO/DIO control word bit0	Bit 0 of 10.99 RO/DIO control word (see page 161).	40
	RO/DIO control word bit1	Bit 1 of 10.99 RO/DIO control word (see page 161).	41
	RO/DIO control word bit2	Bit 2 of 10.99 RO/DIO control word (see page 161).	42
	RO/DIO control word bit8	Bit 8 of 10.99 RO/DIO control word (see page 161).	43
	RO/DIO control word bit9	Bit 9 of 10.99 RO/DIO control word (see page 161).	44
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
11.07	DIO1 ON delay	Defines the activation delay for digital input/output DIO1 (when used as a digital output or digital input).	0.0 s



 $t_{\text{On}}$  = 11.07 DIO1 ON delay

 $t_{\text{Off}} = 11.08 \text{ DIO1 OFF delay}$ 

\*Electrical status of DIO (in input mode) or status of selected source (in output mode). Indicated by 11.01 DIO status.

\*\*Indicated by 11.02 DIO delayed status.

	0.0 3000.0 s	Activation delay for DIO1.	10 = 1 s
11.08	DIO1 OFF delay	Defines the deactivation delay for digital input/output DIO1 (when used as a digital output or digital input). See parameter 11.07 DIO1 ON delay.	0.0 s
	0.03000.0 s	Deactivation delay for DIO1.	10 = 1 s
11.09	DIO2 function	Selects whether DIO2 is used as a digital output or input, or a frequency output.	Output
	Output	DIO2 is used as a digital output.	0
	Input	DIO2 is used as a digital input.	1
	Frequency	DIO2 is used as a frequency output.	2
11.10	DIO2 output source	Selects a drive signal to be connected to digital input/output DIO2 when parameter 11.09 DIO2 function is set to Output.  For the available selections, see parameter 11.06 DIO1 output source.	Running

No.	Name/Value	Description	Def/
			FbEq16
11.11	DIO2 ON delay	Defines the activation delay for digital input/output DIO2 (when used as a digital output or digital input).	0.0 s
	*DIO status ——		1 0 1
	**Delayed DIO status	$t_{\text{On}}$ $t_{\text{Off}}$ $t_{\text{On}}$ $t_{\text{Off}}$	0 
	$t_{\rm On}$ = 11.11 DIO2 ON $a$ $t_{\rm Off}$ = 11.12 DIO2 OFF *Electrical status of DIO 11.01 DIO status. **Indicated by 11.02 D	delay  O (in input mode) or status of selected source (in output mode	e). Indicated by
	0.03000.0 s	Activation delay for DIO2.	10 = 1 s
11.12	DIO2 OFF delay	Defines the deactivation delay for digital input/output DIO2 (when used as a digital output or digital input). See parameter 11.11 DIO2 ON delay.	0.0 s
	0.03000.0 s	Deactivation delay for DIO2.	10 = 1 s
11.38	Freq in 1 actual value	Displays the value of frequency input 1 (via DIO1 when it is used as a frequency input) before scaling. See parameter 11.42 Freq in 1 min.  This parameter is read-only.	-
	016000 Hz	Unscaled value of frequency input 1.	1 = 1 Hz
11.39	Freq in 1 scaled	Displays the value of frequency input 1 (via DIO1 when it is used as a frequency input) after scaling. See parameter 11.42 Freq in 1 min.  This parameter is read-only.	-
	-32768.000 32767.000	Scaled value of frequency input 1.	1 = 1

No.	Name/Value	Description	Def/ FbEq16
11.42	Freq in 1 min	Defines the minimum for the frequency actually arriving at frequency input 1 (DIO1 when it is used as a frequency input).  The incoming frequency signal (11.38 Freq in 1 actual value) is scaled into an internal signal (11.39 Freq in 1 scaled) by parameters 11.4211.45 as follows:  11.45  11.44  11.44  11.45  11.46	0 Hz
	016000 Hz	Minimum frequency of frequency input 1 (DIO1).	1 = 1 Hz
11.43	Freq in 1 max	Defines the maximum for the frequency actually arriving at frequency input 1 (DIO1 when it is used as a frequency input). See parameter 11.42 Freq in 1 min.	16000 Hz
	016000 Hz	Maximum frequency for frequency input 1 (DIO1).	1 = 1 Hz
11.44	Freq in 1 at scaled min	Defines the value that is required to correspond internally to the minimum input frequency defined by parameter 11.42 Freq in 1 min. See diagram at parameter 11.42 Freq in 1 min.	0.000
	-32768.000 32767.000	Value corresponding to minimum of frequency input 1.	1 = 1
11.45	Freq in 1 at scaled max	Defines the value that is required to correspond internally to the maximum input frequency defined by parameter 11.43 Freq in 1 max. See diagram at parameter 11.42 Freq in 1 min.	1500.000; 1800.000 (95.20 b0)
	-32768.000 32767.000	Value corresponding to maximum of frequency input 1.	1 = 1
11.54	Freq out 1 actual value	Displays the value of frequency output 1 after scaling. See parameter 11.58 Freq out 1 src min. This parameter is read-only.	-
	016000 Hz	Value of frequency output 1.	1 = 1
11.55	Freq out 1 source	Selects a signal to be connected to frequency output 1.	Motor speed used
	Zero	None.	0
	Motor speed used	01.01 Motor speed used (page 121).	1
	Output frequency	01.06 Output frequency (page 121).	3
	Motor current	01.07 Motor current (page 121).	4
	Motor torque	01.10 Motor torque (page 121).	6

No.	Name/Value	Description	Def/ FbEq16
	DC voltage	01.11 DC voltage (page 122).	7
	Power inu out	01.14 Output power (page 122).	8
	Speed ref ramp in	23.01 Speed ref ramp input (page 231).	10
	Speed ref ramped	23.02 Speed ref ramp output (page 232).	11
	Speed ref used	24.01 Used speed reference (page 238).	12
	Torq ref used	26.02 Torque reference used.	13
	Freq ref used	28.02 Frequency ref ramp output (page 257).	14
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
11.58	Freq out 1 src min	Defines the real value of the signal (selected by parameter 11.55 Freq out 1 source and shown by parameter 11.54 Freq out 1 actual value) that corresponds to the minimum value of frequency output 1 (defined by parameter 11.60 Freq out 1 at src min).  fout (11.54)  11.60  11.59  Signal (real) selected by parameter 11.55  Signal (real) selected by parameter 11.55	0.000
	-32768.000 32767.000	Real signal value corresponding to minimum value of frequency output 1.	1 = 1
11.59	Freq out 1 src max	Defines the real value of the signal (selected by parameter 11.55 Freq out 1 source and shown by parameter 11.54 Freq out 1 actual value) that corresponds to the maximum value of frequency output 1 (defined by parameter 11.61 Freq out 1 at src max). See parameter 11.58 Freq out 1 src min.	1500.000; 1800.000 (95.20 b0)
	-32768.000 32767.000	Real signal value corresponding to maximum value of frequency output 1.	1 = 1

No.	Name/Value	Description	Def/ FbEq16
11.60	Freq out 1 at src min	Defines the minimum value of frequency output 1. See diagrams at parameter 11.58 Freq out 1 src min.	0 Hz
	016000 Hz	Minimum value of frequency output 1.	1 = 1 Hz
11.61	Freq out 1 at src max	Defines the maximum value of frequency output 1. See diagrams at parameter 11.58 Freq out 1 src min.	16000 Hz
	016000 Hz	Maximum value of frequency output 1.	1 = 1 Hz
11.81	DIO filter time	Defines a filtering time for parameter 11.01 DIO status. The filtering time will only affect the DIOs that are in input mode.	10.0 ms
	0.3100 ms	Filtering time for 11.01.	10 = 1 ms

12 Sta	ndard Al	Configuration of standard analog inputs.	
12.01	Al tune	Triggers the analog input tuning function. Connect the signal to the input and select the appropriate tuning function.	
	No action	Al tune is not activated.	0
	Al1 min tune	Current analog input Al1 signal value is set as minimum value of Al1 into parameter 12.17 Al1 min. The value reverts back to No action automatically.	1
	Al1 max tune	Current analog input Al1 signal value is set as maximum value of Al1 into parameter 12.18 Al1 max. The value reverts back to No action automatically	2
	Al2 min tune	Current analog input Al2 signal value is set as minimum value of Al2 into parameter 12.27 Al2 min. The value reverts back to No action automatically	3
	Al2 max tune	Current analog input Al2 signal value is set as maximum value of Al2 into parameter 12.28 Al2 max. The value reverts back to No action automatically	4
12.03	Al supervision function	Selects how the drive reacts when an analog input signal moves out of the minimum and/or maximum limits specified for the input.  The supervision applies a margin of 0.5 V or 1.0 mA to the limits. For example, if the maximum limit for the input is 7.000 V, the maximum limit supervision activates at 7.500 V.  The inputs and the limits to be observed are selected by parameter 12.04 Al supervision selection.  Note: Analog input signal supervision is only active when  • the analog input is set as the source (using the Al1 scaled or Al2 scaled selection) in parameter 22.11, 22.12, 22.15, 22.17, 28.11, 28.12, 30.21, 30.22 and is being used as the active source, or  • supervision is forced using parameter 12.05 Al supervision force.	No action
	No action	No action taken.	0
	Fault	Drive trips on 80A0 AI supervision.	1
	Warning	Drive generates an A8A0 AI supervision warning.	2

000 12.05 Als  Bit 0 1 2 3 4 5 6 7	ast speed	ed				FbEq16
000 12.05 Als  Bit 0 1 2 3 4 5 6 7	peed ref sa			freezes the spe operating at. T basis of actual WARN	es a warning (A8A0 AI supervision) and eed (or frequency) to the level the drive was the speed/frequency is determined on the speed using 850 ms low-pass filtering. ING! Make sure that it is safe to continue on in case of a communication break.	3
000 12.05 Als  Bit 0 1 2 3 4 5 6 7		f safe		the speed to the ref safe (or 28. reference is be WARN	es a warning (A8A0 AI supervision) and sets ne speed defined by parameter 22.41 Speed 41 Frequency ref safe when frequency ping used). ING! Make sure that it is safe to continue on in case of a communication break.	4
Bit 0 1 2 3 4 5 6 7	I supervision election	ision			analog input limits to be supervised. See 03 AI supervision function.	0000b
Bit 0 1 2 3 4 5 6 7		Г	Bit	Name	Description	_
Bit 0 1 2 3 4 5 6 7		L	0	AI1 < MIN	1 = Minimum limit supervision of Al1 active.	
Bit 0 1 2 3 4 5 6 7			1	AI1 > MAX	1 = Maximum limit supervision of Al1 active.	
Bit   0   1   2   3   4   5   6   7		2	2	AI2 < MIN	1 = Minimum limit supervision of Al2 active.	
Bit 0 1 2 3 4 5 6 7		3	3	Al2 > MAX	1 = Maximum limit supervision of Al2 active	
Bit   0   1   2   3   4   5   6   7		4	415	Reserved		
Bit 0 1 2 3 4 5 6 7	000b111	111b		Activation of a	nalog input supervision.	1 = 1
Bit 0 1 2 3 4 5 6 7	Al supervision force		ce	Activates analog input supervision separately for each		0000 0000b
0 1 2 3 4 5 6 7				supervision wh	e 34). r is primarily intended for analog input nen the input is connected to the application iot selected as a control source by drive	
0 1 2 3 4 5 6 7	2it Na	Name		Description	20	
1 2 3 4 5 6 7		Al1 Ext	1		pervision active when EXT1 is being used.	
3 4 5 6 7		All Ext2			pervision active when EXT2 is being used.	
4 5 6 7	. Al	Al1 Loc	al	1 = Al1 supervision active when local control is being used.		sed.
6 7	Re	Reserve	ed			
6 7		Al2 Ext		1 = Al2 supervision active when EXT1 is being used.		
7		Al2 Ext2		1 = Al2 supervision active when EXT2 is being used.		
000		Al2 Loc		1 = Al2 supervision active when local control is being used.		sed.
	715 Reserved					
011	000 0000b 111 0111b			Analog input s	upervision selection.	1 = 1
	I1 actual v					-
-22. or V		-22.000 22.000 mA		Value of analo	g input AI1.	1000 = 1 mA

No.	Name/Value	Description	Def/ FbEq16
12.12	Al1 scaled value	Displays the value of analog input Al1 after scaling. See parameters 12.19 Al1 scaled at Al1 min and 12.20 Al1 scaled at Al1 max.  This parameter is read-only.	-
	-32768.000 32767.000	Scaled value of analog input Al1.	1 = 1
12.15	Al1 unit selection	Selects the unit for readings and settings related to analog input Al1.  Note: This setting must match the corresponding hardware setting on the drive control unit (see the hardware manual of the drive). Control board reboot (either by cycling the power or through parameter 96.08 Control board boot) is required to validate any changes in the hardware settings.	V
	V	Volts.	2
	mA	Milliamperes.	10
12.16	Al1 filter time	Defines the filter time constant for analog input AI1.	0.100 s
		Unfiltered signal  100  63  Filtered signal	
	0.00030.000 s	Filter time constant.	1000 = 1 s
12.17	Al1 min	Defines the minimum site value for analog input Al1. Set the value actually sent to the drive when the analog signal from plant is wound to its minimum setting. See also parameter 12.01 Al tune.	0.000 mA or V
	-22.000 22.000 mA or V	Minimum value of Al1.	1000 = 1 mA or V
12.18	Al1 max	Defines the maximum site value for analog input Al1. Set the value actually sent to the drive when the analog signal from plant is wound to its maximum setting. See also parameter 12.01 Al tune.	20.000 mA or 10.000 V
	-22.000	Maximum value of AI1.	1000 = 1 mA
	22.000 mA or V		or V

No.	Name/Value	Description	Def/ FbEq16
12.19	Al1 scaled at Al1 min	Defines the real internal value that corresponds to the minimum analog input Al1 value defined by parameter 12.17 Al1 min. (Changing the polarity settings of 12.19 and 12.20 can effectively invert the analog input.)  Al <sub>scaled</sub> (12.12)  12.17  12.18	0.000
	-32768.000 32767.000	Real value corresponding to minimum Al1 value.	1 = 1
12.20	Al1 scaled at Al1 max	Defines the real internal value that corresponds to the maximum analog input Al1 value defined by parameter 12.18 Al1 max. See the drawing at parameter 12.19 Al1 scaled at Al1 min.	1500.000; 1800.000 (95.20 b0)
	-32768.000 32767.000	Real value corresponding to maximum Al1 value.	1 = 1
12.21	Al2 actual value	Displays the value of analog input Al2 in mA or V (depending on whether the input is set to current or voltage by a hardware setting).  This parameter is read-only.	-
	-22.000 22.000 mA or V	Value of analog input Al2.	1000 = 1 mA or V
12.22	Al2 scaled value	Displays the value of analog input Al2 after scaling. See parameters 12.29 Al2 scaled at Al2 min and 12.30 Al2 scaled at Al2 max.  This parameter is read-only.	-
	-32768.000 32767.000	Scaled value of analog input AI2.	1 = 1
12.25	Al2 unit selection	Selects the unit for readings and settings related to analog input Al2.  Note: This setting must match the corresponding hardware setting on the drive control unit (see the hardware manual of the drive). Control board reboot (either by cycling the power or through parameter 96.08 Control board boot) is required to validate any changes in the hardware settings.	mA
	V	Volts.	2
	mA	Milliamperes.	10

No.	Name/Value	Description	Def/ FbEq16
12.26	Al2 filter time	Defines the filter time constant for analog input Al2. See parameter 12.16 Al1 filter time.	0.100 s
	0.00030.000 s	Filter time constant.	1000 = 1 s
12.27	Al2 min	Defines the minimum site value for analog input Al2. Set the value actually sent to the drive when the analog signal from plant is wound to its minimum setting. See also parameter 12.01 Al tune.	0.000 mA or V
	-22.000 22.000 mA or V	Minimum value of Al2.	1000 = 1 mA or V
12.28	Al2 max	Defines the maximum site value for analog input Al2. Set the value actually sent to the drive when the analog signal from plant is wound to its maximum setting. See also parameter 12.01 Al tune.	20.000 mA or 10.000 V
	-22.000 22.000 mA or V	Maximum value of AI2.	1000 = 1 mA or V
12.29	Al2 scaled at Al2 min	Defines the real value that corresponds to the minimum analog input Al2 value defined by parameter 12.27 Al2 min. (Changing the polarity settings of 12.29 and 12.30 can effectively invert the analog input.)  Al <sub>scaled</sub> (12.22)  12.30  12.27  12.29	0.000
	-32768.000 32767.000	Real value corresponding to minimum Al2 value.	1 = 1
12.30	AI2 scaled at AI2 max	Defines the real value that corresponds to the maximum analog input Al2 value defined by parameter 12.28 Al2 max. See the drawing at parameter 12.29 Al2 scaled at Al2 min.	100.000
	-32768.000 32767.000	Real value corresponding to maximum Al2 value.	1 = 1
13 Sta	nndard AO	Configuration of standard analog outputs.	
13.11	AO1 actual value	Displays the value of AO1 in mA. This parameter is read-only.	-
	0.00022.000 mA	Value of AO1.	1000 = 1 mA

No.	Name/Value	Description	Def/ FbEq16
13.12	AO1 source	Selects a signal to be connected to analog output AO1. Alternatively, sets the output to excitation mode to feed a constant current to a temperature sensor.	Motor speed used
	Zero	None.	0
	Motor speed used	01.01 Motor speed used (page 121).	1
	Output frequency	01.06 Output frequency (page 121).	3
	Motor current	01.07 Motor current (page 121).	4
	Motor torque	01.10 Motor torque (page 121).	6
	DC voltage	01.11 DC voltage (page 122).	7
	Power inu out	01.14 Output power (page 122).	8
	Speed ref ramp in	23.01 Speed ref ramp input (page 231).	10
	Speed ref ramp out	23.02 Speed ref ramp output (page 232).	11
	Speed ref used	24.01 Used speed reference (page 238).	12
	Freq ref used	28.02 Frequency ref ramp output (page 257).	14
	Force Pt100 excitation	The output is used to feed an excitation current to 13 Pt100 sensors. See section <i>Motor thermal protection</i> (page 94).	20
	Force KTY84 excitation	The output is used to feed an excitation current to a KTY84 sensor. See section <i>Motor thermal protection</i> (page 94).	21
	Force PTC excitation The output is used to feed an excitation current to 13 PTC sensors. See section <i>Motor thermal protection</i> (pa. 94).		22
	Force Pt1000 excitation	The output is used to feed an excitation current to 13 Pt1000 sensors. See section <i>Motor thermal protection</i> (page 94).	23
	AO1 data storage	13.91 AO1 data storage (page 175).	37
	AO2 data storage	13.92 AO2 data storage (page 175).	38
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
13.16	AO1 filter time	Defines the filtering time constant for analog output AO1.  " Unfiltered signal  100 63 Filtered signal  t  O = I × (1 - e <sup>-t/T</sup> )  I = filter input (step) O = filter output t = time T = filter time constant	0.100 s
	0.00030.000 s	Filter time constant.	1000 = 1 s

No.	Name/Value	Description	Def/ FbEq16
13.17	AO1 source min	Defines the real minimum value of the signal (selected by parameter 13.12 AO1 source) that corresponds to the minimum required AO1 output value (defined by parameter 13.19 AO1 out at AO1 src min).  IAO1 (mA)  13.19  13.17  13.18  Signal (real) selected by 13.12	0.0
		Programming 13.17 as the maximum value and 13.18 as the minimum value inverts the output.  IAO1 (mA)  13.19  13.18  13.17  Signal (real) selected by 13.12	
	-32768.032767.0	Real signal value corresponding to minimum AO1 output value.	1 = 1
13.18	AO1 source max	Defines the real maximum value of the signal (selected by parameter 13.12 AO1 source) that corresponds to the maximum required AO1 output value (defined by parameter 13.20 AO1 out at AO1 src max). See parameter 13.17 AO1 source min.	1500.0; 1800.0 (95.20 b0)
	-32768.032767.0	Real signal value corresponding to maximum AO1 output value.	1 = 1
13.19	AO1 out at AO1 src min	Defines the minimum output value for analog output AO1. See also drawing at parameter 13.17 AO1 source min.	0.000 mA
	0.00022.000 mA	Minimum AO1 output value.	1000 = 1 mA
13.20	AO1 out at AO1 src max	Defines the maximum output value for analog output AO1. See also drawing at parameter 13.17 AO1 source min.	20.000 mA
	0.00022.000 mA	Maximum AO1 output value.	1000 = 1 mA

No.	Name/Value	Description	Def/ FbEq16
13.21	AO2 actual value	Displays the value of AO2 in mA. This parameter is read-only.	-
	0.00022.000 mA	Value of AO2.	1000 = 1 mA
13.22	AO2 source	Selects a signal to be connected to analog output AO2. Alternatively, sets the output to excitation mode to feed a constant current to a temperature sensor.  For the selections, see parameter 13.12 AO1 source.	Motor current
13.26	AO2 filter time	Defines the filtering time constant for analog output AO2. See parameter 13.16 AO1 filter time.	0.100 s
	0.00030.000 s	Filter time constant.	1000 = 1 s
13.27	AO2 source min	Defines the real minimum value of the signal (selected by parameter 13.22 AO2 source) that corresponds to the minimum required AO2 output value (defined by parameter 13.29 AO2 out at AO2 src min).  IAO2 (mA)  13.29  13.27  13.28  Signal (real) selected by 13.22  Programming 13.27 as the maximum value and 13.28 as the minimum value inverts the output.  IAO2 (mA)  13.30  Signal (real) selected by 13.22  Signal (real) selected by 13.22	0.0
	-32768.032767.0	Real signal value corresponding to minimum AO2 output	1 = 1
	32. 00.0027 07.0	value.	. '

No.	Name/Value	Description	Def/ FbEq16
13.28	AO2 source max	Defines the real maximum value of the signal (selected by parameter 13.22 AO2 source) that corresponds to the maximum required AO2 output value (defined by parameter 13.30 AO2 out at AO2 src max). See parameter 13.27 AO2 source min.	100.0
	-32768.032767.0	Real signal value corresponding to maximum AO2 output value.	1 = 1
13.29	AO2 out at AO2 src min	Defines the minimum output value for analog output AO2. See also drawing at parameter 13.27 AO2 source min.	0.000 mA
	0.00022.000 mA	Minimum AO2 output value.	1000 = 1 mA
13.30	AO2 out at AO2 src max	Defines the maximum output value for analog output AO2. See also drawing at parameter 13.27 AO2 source min.	20.000 mA
	0.00022.000 mA	Maximum AO2 output value.	1000 = 1 mA
13.91	AO1 data storage	Storage parameter for controlling analog output AO1 eg. through fieldbus.  In 13.12 AO1 source, select AO1 data storage. Then set this parameter as the target of the incoming value data. With the embedded fieldbus interface, simply set the target selection parameter of that particular data (58.10158.124) to AO1 data storage.	0.00
	-327.68 327.67	Storage parameter for AO1.	100 = 1
13.92	AO2 data storage	Storage parameter for controlling analog output AO2 eg. through fieldbus.  In 13.22 AO2 source, select AO2 data storage. Then set this parameter as the target of the incoming value data. With the embedded fieldbus interface, simply set the target selection parameter of that particular data (58.10158.124) to AO2 data storage.	0.00
	-327.68 327.67	Storage parameter for AO2.	100 = 1

14 I/O extension 1	n module Configuration of I/O extension module 1. See also section Programmable I/O extensions (page 60). Note: The contents of the parameter group vary according to the selected I/O extension module type.	
14.01 Module 1 t	Activates (and specifies the type of) I/O extension module 1.  Note: This parameter cannot be changed while the drive is running.	None
None	Inactive.	0
FIO-01	FIO-01.	1
FIO-11	FIO-11.	2
FDIO-01	FDIO-01.	3
FAIO-01	FAIO-01.	4
14.02 Module 1 I	Specifies the slot (13) on the control unit of the drive into which the I/O extension module is installed. Alternatively, specifies the node ID of the slot on an FEA-03 extension adapter.  Note: This parameter cannot be changed while the drive is running.	Slot 1
Slot 1	Slot 1.	1

No.	Name/Value	Description	Def/ FbEq16
	Slot 2	Slot 2.	2
	Slot 3	Slot 3.	3
	4254	Node ID of the slot on the FEA-03 extension adapter.	1 = 1
14.03	Module 1 status	Displays the status of I/O extension module 1.	No option
	No option	No module detected in the specified slot.	0
	No communication	A module has been detected but cannot be communicated with.	1
	Unknown	The module type is unknown.	2
	FIO-01	An FIO-01 module has been detected and is active.	15
	FIO-11	An FIO-11 module has been detected and is active.	20
	FAIO-01	An FAIO-01 module has been detected and is active.	24
14.05	DI status	(Visible when 14.01 Module 1 type = FDIO-01) Displays the status of the digital inputs on the extension module. The activation/deactivation delays (if any are specified) are ignored. A filtering time (for input mode) can be defined by parameter 14.08 DI filter time.  Bit 0 indicates the status of DI1.  Note: The number of active bits in this parameter depends on the number of digital input/outputs on the extension module.  Example: 0101b = DI1 and DI3 are on, remainder are off. This parameter is read-only.	-
	0000b1111b	Status of digital inputs.	1 = 1
14.05	DIO status	(Visible when 14.01 Module 1 type = FIO-01 or FIO-11) Displays the status of the digital input/outputs on the extension module. The activation/deactivation delays (if any are specified) are ignored. A filtering time (for input mode) can be defined by parameter 14.08 DIO filter time. Bit 0 indicates the status of DIO1.  Note: The number of active bits in this parameter depends on the number of digital input/outputs on the extension module.  Example: 1001b = DIO1 and DIO4 are on, remainder are off. This parameter is read-only.	-
	0000b1111b	Status of digital input/outputs.	1 = 1
14.06	DI delayed status	(Visible when 14.01 Module 1 type = FDIO-01) Displays the delayed status of the digital inputs on the extension module. The word is updated only after activation/deactivation delays (if any are specified). Bit 0 indicates the status of DI1.  Note: The number of active bits in this parameter depends on the number of digital inputs on the extension module.  Example: 0101b = DI1 and DI3 are on, remainder are off. This parameter is read-only.	-
	0000b1111b	Delayed status of digital inputs.	1 = 1

No.	Name/Value	Description	Def/ FbEq16
14.06	DIO delayed status	(Visible when 14.01 Module 1 type = FIO-01 or FIO-11) Displays the delayed status of the digital input/outputs on the extension module. This word is updated only after activation/deactivation delays (if any are specified). Bit 0 indicates the status of DIO1. Note: The number of active bits in this parameter depends on the number of digital input/outputs on the extension module.  Example: 00001001b = DIO1 and DIO4 are on, remainder are off. This parameter is read-only.	-
	0000b1111b	Delayed status of digital input/outputs.	1 = 1
14.08	DI filter time	(Visible when 14.01 Module 1 type = FDIO-01) Defines a filtering time for parameter 14.05 DI status and 14.06 DI delayed status.	10.0 ms
	0.8 100.0 ms	Filtering time for DI status parameters.	10 = 1 ms
14.08	DIO filter time	(Visible when 14.01 Module 1 type = FIO-01 or FIO-11) Defines a filtering time for parameters 14.05 DI status and 14.06 DI delayed status. The filtering time will only affect the DIOs that are in input mode.	10.0 ms
	0.8100.0 ms	Filtering time for DIO status parameters.	10 = 1 ms
14.09	DIO1 function	(Visible when 14.01 Module 1 type = FIO-01 or FIO-11) Selects whether DIO1 of the extension module is used as a digital input or output.	Input
	Output	DIO1 is used as a digital output.	0
	Input	DIO1 is used as a digital input.	1
14.11	DIO1 output source	(Visible when 14.01 Module 1 type = FIO-01 or FIO-11) Selects a drive signal to be connected to digital input/output DIO1 of the extension module when parameter 14.09 DIO1 function is set to Output.	Not energized
	Not energized	Output is not energized.	0
	Energized	Output is energized.	1
	Ready run	Bit 1 of 06.11 Main status word (see page 135).	2
	Enabled	Bit 0 of 06.16 Drive status word 1 (see page 136).	4
	Started	Bit 5 of 06.16 Drive status word 1 (see page 136).	5
	Magnetized	Bit 1 of 06.17 Drive status word 2 (see page 137).	6
	Running	Bit 6 of 06.16 Drive status word 1 (see page 136).	7
	Ready ref	Bit 2 of 06.11 Main status word (see page 135).	8
	At setpoint	Bit 8 of 06.11 Main status word (see page 135).	9
	Reverse	Bit 2 of 06.19 Speed control status word (see page 139).	10
	Zero speed	Bit 0 of 06.19 Speed control status word (see page 139).	11
	Above limit	Bit 10 of 06.17 Drive status word 2 (see page 137).	12
	Warning	Bit 7 of 06.11 Main status word (see page 135).	13
	Fault	Bit 3 of 06.11 Main status word (see page 135).	14
	Fault (-1)	Inverted bit 3 of 06.11 Main status word (see page 135).	15
	Start request	Bit 13 of 06.16 Drive status word 1 (see page 136).	16

No.	Name/Value	Description	Def/ FbEq16
	Open brake command	Bit 0 of 44.01 Brake control status	22
	Ext2 active	Bit 11 of 06.16 Drive status word 1 (see page 136).	23
	Remote control	Bit 9 of 06.11 Main status word (see page 135).	24
	Supervision 1	Bit 0 of 32.01 Supervision status (see page 285).	33
	Supervision 2	Bit 1 of 32.01 Supervision status (see page 285).	34
	Supervision 3	Bit 2 of 32.01 Supervision status (see page 285).	35
	RO/DIO control word bit0	Bit 0 of 10.99 RO/DIO control word (see page 161).	40
	RO/DIO control word bit1	Bit 1 of 10.99 RO/DIO control word (see page 161).	41
	RO/DIO control word bit2	Bit 2 of 10.99 RO/DIO control word (see page 161).	42
	RO/DIO control word bit8	Bit 8 of 10.99 RO/DIO control word (see page 161).	43
	RO/DIO control word bit9	Bit 9 of 10.99 RO/DIO control word (see page 161).	44
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
14.12	DI1 ON delay	( <i>Visible when 14.01 Module 1 type = FDIO-01</i> ) Defines the activation delay for digital input DI1.	0.00 s
	*DI status		1 0 1
	**Delayed DI status t <sub>On</sub> = 14.12 DI1 ON delay	$\langle \cdot, \cdot \rangle$	──── 0 ────────────────────────────────
	$t_{\text{Off}} = 14.13  \text{DI1 OFF delay}$	status of selected source (in output mode). Indicated by 14.05 DI status	<b>3</b> .
	0.00 3000.00 s	Activation delay for DI1.	10 = 1 s

10 = 1 s

No.	Name/Value	Description	Def/ FbEq16
14.12	DIO1 ON delay	(Visible when 14.01 Module 1 type = FIO-01 or FIO-11) Defines the activation delay for digital input/output DIO1.	0.00 s
	*DIO status		1 0 1
	**Delayed DIO status —	$\leftarrow$ $\rightarrow$	0 Time
	$t_{\rm On}$ = 14.12 DIO1 ON $t_{\rm Off}$ = 14.13 DIO1 OFF *Electrical status of DI 14.05 DIO status. **Indicated by 14.06 D	Tidelay  O (in input mode) or status of selected source (in output mode)	e). Indicated by
	0.003000.00 s	Activation delay for DIO1.	10 = 1 s
14.13	DI1 OFF delay	(Visible when 14.01 Module 1 type = FDIO-01) Defines the deactivation delay for digital input DI1. See parameter 14.12 DI1 ON delay.	0.00 s
	0.00 3000.00 s	Deactivation delay for DI1.	10 = 1 s
14.13	DIO1 OFF delay	(Visible when 14.01 Module 1 type = FIO-01 or FIO-11) Defines the deactivation delay for digital input/output DIO1. See parameter 14.12 DIO1 ON delay.	0.00 s
	0.003000.00 s	Deactivation delay for DIO1.	10 = 1 s
14.14	DIO2 function	(Visible when 14.01 Module 1 type = FIO-01 or FIO-11) Selects whether DIO2 of the extension module is used as a digital input or output.	Input
	Output	DIO2 is used as a digital output.	0
	Input	DIO2 is used as a digital input.	1
14.16	DIO2 output source	(Visible when 14.01 Module 1 type = FIO-01 or FIO-11) Selects a drive signal to be connected to digital input/output DIO2 when parameter 14.14 DIO2 function is set to Output. For the available selections, see parameter 14.11 DIO1 output source.	Not energized
14.17	DI2 ON delay	(Visible when 14.01 Module 1 type = FDIO-01) Defines the activation delay for digital input DI2. See parameter 14.12 DI1 ON delay.	0.00 s
	0.00 3000.00 s	Activation delay for DI2.	10 = 1 s
14.17	DIO2 ON delay	(Visible when 14.01 Module 1 type = FIO-01 or FIO-11) Defines the activation delay for digital input/output DIO2. See parameter 14.12 DIO1 ON delay.	0.00 s

Activation delay for DIO2.

0.00...3000.00 s

No.	Name/Value	Description	Def/ FbEq16
14.18	DI2 OFF delay	(Visible when 14.01 Module 1 type = FDIO-01) Defines the deactivation delay for digital input DI2. See parameter 14.12 DI1 ON delay.	0.00 s
	0.00 3000.00 s	Deactivation delay for DI2.	10 = 1 s
14.18	DIO2 OFF delay	(Visible when 14.01 Module 1 type = FIO-01 or FIO-11) Defines the deactivation delay for digital input/output DIO2. See parameter 14.12 DIO1 ON delay.	0.00 s
	0.003000.00 s	Deactivation delay for DIO2.	10 = 1 s
14.19	DIO3 function	(Visible when 14.01 Module 1 type = FIO-01) Selects whether DIO3 of the extension module is used as a digital input or output.	Input
	Output	DIO3 is used as a digital output.	0
	Input	DIO3 is used as a digital input.	1
14.19	AI supervision function	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Selects how the drive reacts when an analog input signal moves out of the minimum and/or maximum limits specified for the input. The inputs and the limits to be observed are selected by parameter 14.20 Al supervision selection.	No action
	No action	No action taken.	0
	Fault	Drive trips on 80A0 AI supervision.	1
	Warning	Drive generates an A8A0 AI supervision warning.	2
	Last speed	Drive generates a warning (A8A0 Al supervision) and freezes the speed (or frequency) to the level the drive was operating at. The speed/frequency is determined on the basis of actual speed using 850 ms low-pass filtering.  WARNING! Make sure that it is safe to continue operation in case of a communication break.	3
	Speed ref safe	Drive generates a warning (A8A0 Al supervision) and sets the speed to the speed defined by parameter 22.41 Speed ref safe (or 28.41 Frequency ref safe when frequency reference is being used).  WARNING! Make sure that it is safe to continue operation in case of a communication break.	4

No.	Name/	Value	Description	Def/ FbEq16
14.20	AI supervision selection		(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Specifies the analog input limits to be supervised. See parameter 14.19 AI supervision function.  Note: The number of active bits in this parameters depends on the number of inputs on the extension module.	0000 0000Ь
	Bit	Name	Description	1
	0	Al1 < MIN	1 = Minimum limit supervision of Al1 active.	
	1	Al1 > MAX	1 = Maximum limit supervision of Al1 active.	
	2	AI2 < MIN	1 = Minimum limit supervision of Al2 active.	
	3	Al2 > MAX	1 = Maximum limit supervision of Al2 active.	
	4	AI3 < MIN	1 = Minimum limit supervision of Al3 active (FIO-11 only	/).
	5	AI3 > MAX	1 = Maximum limit supervision of Al3 active (FIO-11 onl	.,
	615	Reserved	· · · · · · · · · · · · · · · · · · ·	
			T	Ι
	0000 00 1111b	000b0011	Activation of analog input supervision.	1 = 1
14.21	DIO3 o	utput source	(Visible when 14.01 Module 1 type = FIO-01) Selects a drive signal to be connected to digital input/output DIO3 when parameter 14.19 DIO3 function is set to Output. For the available selections, see parameter 14.11 DIO1 output source.	Not energized
14.21	AI tune		(Visible when 14.01 Module 1 type = FIO-01 or FAIO-01) Triggers the analog input tuning function, which enables the use of actual measurements as the minimum and maximum input values instead of potentially inaccurate estimates.  Apply the minimum or maximum signal to the input and select the appropriate tuning function.  See also the drawing at parameter 14.35 Al1 scaled at Al1 min.	No action
	No action	on	Tuning action completed or no action has been requested. The parameter automatically reverts to this value after any tuning action.	0
	Al1 min	tune	The measured value of Al1 is set as the minimum value of Al1 into parameter 14.33 Al1 min.	1
	Al1 ma	x tune	The measured value of Al1 is set as the maximum value of Al1 into parameter 14.34 Al1 max.	2
	Al2 min	tune	The measured value of Al2 is set as the minimum value of Al2 into parameter 14.48 Al2 min.	3
	Al2 ma	x tune	The measured value of Al2 is set as the maximum value of Al2 into parameter 14.49 Al2 max.	4
	Al3 min	tune	(Visible when 14.01 Module 1 type = FIO-11) The measured value of Al3 is set as the minimum value of Al3 into parameter 14.63 Al3 min.	5
	Al3 ma	x tune	(Visible when 14.01 Module 1 type = FIO-11) The measured value of Al3 is set as the maximum value of Al3 into parameter 14.64 Al3 max.	6

No.	Name/Value	Description		Def/ FbEq16
14.22	DI3 ON delay		01 Module 1 type = FDIO-01) tion delay for digital input DI3. See DI1 ON delay.	0.00 s
	0.00 3000.00	Activation delay fo	r DI3.	10 = 1 s
14.22	DIO3 ON delay	Defines the activat	11 Module 1 type = FIO-01) tion delay for digital input/output DIO3. .12 DIO1 ON delay.	0.00 s
	0.003000.00 s	Activation delay fo	r DIO3.	10 = 1 s
14.22	Al force selection	The true readings for eg. testing purp provided for each	of Module 1 type = FIO-11 or FAIO-01) of the analog inputs can be overridden coses. A forced value parameter is analog input, and its value is applied esponding bit in this parameter is 1.	0000b
	Bit	alue		
	0		parameter 14.28 Al1 force data.	
	1		parameter 14.43 AI2 force data.	
	315	= Force AI3 to value of eserved.	parameter 14.58 Al3 force data (FIO-11	only).
	515	eserveu.		
	0000b0111b	Forced values sele	ector for analog inputs.	1 = 1
14.23	DI3 OFF delay		11 Module 1 type = FDIO-01) vation delay for digital input DI3. See DI1 ON delay.	0.00 s
	0.00 3000.00	Deactivation delay	for DI3.	10 = 1 s
14.23	DIO3 OFF delay	Defines the deacti	11 Module 1 type = FIO-01) vation delay for digital input/output eter 14.12 DIO1 ON delay.	0.00 s
	0.003000.00 s	Deactivation delay	for DIO3.	10 = 1 s
14.24	DIO4 function		11 Module 1 type = FIO-01) IO4 of the extension module is used as utput.	Input
	Output	DIO4 is used as a	digital output.	0
	Input	DIO4 is used as a	digital input.	1
14.26	DIO4 output soul	Selects a drive sig input/output DIO4 set to <i>Output</i> .	of Module 1 type = FIO-01) nal to be connected to digital when parameter 14.24 DIO4 function is selections, see parameter 14.11 DIO1	Not energized
14.26	Al1 actual value	Displays the value (depending on who voltage). This parameter is	<u> </u>	-
	-22.000 22.000 mA or \	Value of analog in	put AI1.	1000 = 1 mA or V

No.	Name/Value	Description	Def/ FbEq16
14.27	DIO4 ON delay	(Visible when 14.01 Module 1 type = FIO-01) Defines the activation delay for digital input/output DIO4. See parameter 14.12 DIO1 ON delay.	0.00s
	0.003000.00 s	Activation delay for DIO4.	10 = 1 s
14.27	Al1 scaled value	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Displays the value of analog input Al1 after scaling. See parameter 14.35 Al1 scaled at Al1 min. This parameter is read-only.	-
	-32768.000 32767.000	Scaled value of analog input AI1.	1 = 1
14.28	DIO4 OFF delay	(Visible when 14.01 Module 1 type = FIO-01) Defines the deactivation delay for digital input/output DIO4. See parameter 14.12 DIO1 ON delay.	0.00 s
	0.003000.00 s	Deactivation delay for DIO4.	10 = 1 s
14.28	Al1 force data	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Forced value that can be used instead of the true reading of the input. See parameter 14.22 Al force selection.	0.000 mA
	-22.000 22.000 mA or V	Forced value of analog input Al1.	1000 = 1 mA or V
14.29	Al1 HW switch pos	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Shows the position of the hardware current/voltage selector on the I/O extension module. Note: The setting of the current/voltage selector must match the unit selection made in parameter 14.30 AI1 unit selection. I/O module reboot either by cycling the power or through parameter 96.08 Control board boot is required to validate any changes in the hardware settings.	-
	V	Volts.	2
	mA	Milliamperes.	10
14.30	Al1 unit selection	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Selects the unit for readings and settings related to analog input Al1. Note: This setting must match the corresponding hardware setting on the I/O extension module (see the manual of the I/O extension module). The hardware setting is shown by parameter 14.29 Al1 HW switch pos. I/O module reboot either by cycling the power or through parameter 96.08 Control board boot is required to validate any changes in the hardware settings.	mA
	V	Volts.	2
	mA	Milliamperes.	10
14.31	RO status	(Visible when 14.01 Module 1 type = FIO-01 or FDIO-01) Status of relay outputs on the I/O extension module. Example: 00000001b = RO1 is energized, RO2 is deenergized.	-
	0000b1111b	Status of relay outputs.	1 = 1
14.31	Al1 filter gain	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Selects a hardware filtering time for Al1. See also parameter 14.32 Al1 filter time.	1 ms
	No filtering	No filtering.	0

No.	Name/Value	Description	Def/ FbEq16
	125 us	125 microseconds.	1
	250 us	250 microseconds.	2
	500 us	500 microseconds.	3
	1 ms	1 millisecond.	4
	2 ms	2 milliseconds.	5
	4 ms	4 milliseconds.	6
	7.9375 ms	7.9375 milliseconds.	7
14.32	Al1 filter time	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Defines the filter time constant for analog input Al1.   "Unfiltered signal  100 63  Filtered signal  T  O = I × (1 - e <sup>-t/T</sup> )  I = filter input (step) O = filter output t = time T = filter time constant  Note: The signal is also filtered due to the signal interface hardware. See parameter 14.31 Al1 filter gain.	0.100 s
	0.00030.000 s	Filter time constant.	1000 = 1 s
14.33	Al1 min	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Defines the minimum value for analog input Al1. See also parameter 14.21 Al tune.	0.000 mA or V
	-22.00022.000 mA or V	Minimum value of Al1.	1000 = 1 mA or V
14.34	RO1 source	(Visible when 14.01 Module 1 type = FIO-01 or FDIO-01) Selects a drive signal to be connected to relay output RO1. For the available selections, see parameter 14.11 DIO1 output source.	Not energized
14.34	Al1 max	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Defines the maximum value for analog input AI1. See also parameter 14.21 AI tune.	10.000 mA or V
	-22.00022.000 mA or V	Maximum value of AI1.	1000 = 1 mA or V

No.	Name/Value	Description	Def/ FbEq16
14.35	RO1 ON delay	(Visible when 14.01 Module 1 type = FIO-01 or FDIO-01) Defines the activation delay for relay output RO1.	0.00 s
	Status of selected source		1 0
	RO status		1 0> Time
		$t_{ m On}$ $t_{ m Off}$ $t_{ m On}$ $t_{ m Off}$	Time
	$t_{\text{On}} = 14.35 \text{ RO1 ON d}$ $t_{\text{Off}} = 14.36 \text{ RO1 OFF}$	elay delay	
	0.003000.00 s	Activation delay for RO1.	10 = 1 s
14.35	Al1 scaled at Al1 min	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Defines the real value that corresponds to the minimum analog input Al1 value defined by parameter 14.33 Al1 min.  Al <sub>scaled</sub> (14.27)  14.33  Al <sub>in</sub> (14.26)  14.34	0.000
	-32768.000 32767.000	Real value corresponding to minimum Al1 value.	1 = 1
14.36	RO1 OFF delay	(Visible when 14.01 Module 1 type = FIO-01 or FDIO-01) Defines the deactivation delay for relay output RO1. See parameter 14.35 RO1 ON delay.	0.00 s
	0.003000.00 s	Deactivation delay for RO1.	10 = 1 s
14.36	Al1 scaled at Al1 max	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Defines the real value that corresponds to the maximum analog input Al1 value defined by parameter 14.34 Al1 max. See the drawing at parameter 14.35 Al1 scaled at Al1 min.	100.000
	-32768.000 32767.000	Real value corresponding to maximum Al1 value.	1 = 1

No.	Name/Value	Description	Def/ FbEq16
14.37	RO2 source	(Visible when 14.01 Module 1 type = FIO-01 or FDIO-01) Selects a drive signal to be connected to relay output RO2. For the available selections, see parameter 14.11 DIO1 output source.	Not energized
14.38	RO2 ON delay	(Visible when 14.01 Module 1 type = FIO-01 or FDIO-01) Defines the activation delay for relay output RO2. See parameter 14.35 RO1 ON delay.	0.00 s
	0.003000.00 s	Activation delay for RO2.	10 = 1 s
14.39	RO2 OFF delay	(Visible when 14.01 Module 1 type = FIO-01 or FDIO-01) Defines the deactivation delay for relay output RO2. See parameter 14.35 RO1 ON delay.	0.00 s
	0.003000.00 s	Deactivation delay for RO2.	10 = 1 s
14.41	Al2 actual value	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Displays the value of analog input Al2 in mA or V (depending on whether the input is set to current or voltage). This parameter is read-only.	-
	-22.00022.000 mA or V	Value of analog input Al2.	1000 = 1 mA or V
14.42	AI2 scaled value	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Displays the value of analog input Al2 after scaling. See parameter 14.50 Al2 scaled at Al2 min. This parameter is read-only.	-
	-32768.000 32767.000	Scaled value of analog input AI2.	1 = 1
14.43	Al2 force data	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Forced value that can be used instead of the true reading of the input. See parameter 14.22 Al force selection.	0.000 mA
	-22.00022.000 mA or V	Forced value of analog input Al2.	1000 = 1 mA or V
14.44	AI2 HW switch pos	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Shows the position of the hardware current/voltage selector on the I/O extension module. Note: The setting of the current/voltage selector must match the unit selection made in parameter 14.45 AI2 unit selection. I/O module reboot either by cycling the power or through parameter 96.08 Control board boot is required to validate any changes in the hardware settings.	-
	V	Volts.	2
	mA	Milliamperes.	10
14.45	Al2 unit selection	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Selects the unit for readings and settings related to analog input Al2. Note: This setting must match the corresponding hardware setting on the I/O extension module (see the manual of the I/O extension module). The hardware setting is shown by parameter 14.44 Al2 HW switch pos. I/O module reboot either by cycling the power or through parameter 96.08 Control board boot is required to validate any changes in the hardware settings.	mA
	V	Volts.	2

No.	Name/Value	Description	Def/ FbEq16
	mA	Milliamperes.	10
14.46	Al2 filter gain	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Selects a hardware filtering time for Al2. See also parameter 14.47 Al2 filter time.	1 ms
	No filtering	No filtering.	0
	125 us	125 microseconds.	1
	250 us	250 microseconds.	2
	500 us	500 microseconds.	3
	1 ms	1 millisecond.	4
	2 ms	2 milliseconds.	5
	4 ms	4 milliseconds.	6
	7.9375 ms	7.9375 milliseconds.	7
14.47	Al2 filter time	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Defines the filter time constant for analog input AI2.   """  """  """  """  """  """  """	0.100 s
	0.000 00.000	hardware. See parameter 14.46 Al2 filter gain.	1000 1
11.10	0.00030.000 s	Filter time constant.	1000 = 1 s
14.48	Al2 min	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Defines the minimum value for analog input AI2. See also parameter 14.21 AI tune.	0.000 mA or V
	-22.00022.000 mA or V	Minimum value of AI2.	1000 = 1 mA or V
14.49	Al2 max	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Defines the maximum value for analog input Al2. See also parameter 14.21 Al tune.	10.000 mA or V
	-22.00022.000 mA or V	Maximum value of AI2.	1000 = 1 mA or V

No.	Name/Value	Description	Def/ FbEq16
14.50	Al2 scaled at Al2 min	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Defines the real value that corresponds to the minimum analog input AI2 value defined by parameter 14.48 AI2 min.  AI <sub>scaled</sub> (14.42)  14.48  14.48  14.49	0.000
	-32768.000 32767.000	Real value corresponding to minimum Al2 value.	1 = 1
14.51	Al2 scaled at Al2 max	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Defines the real value that corresponds to the maximum analog input AI2 value defined by parameter 14.49 AI2 max. See the drawing at parameter 14.50 AI2 scaled at AI2 min.	100.000
	-32768.000 32767.000	Real value corresponding to maximum Al2 value.	1 = 1
14.56	Al3 actual value	(Visible when 14.01 Module 1 type = FIO-11) Displays the value of analog input Al3 in mA or V (depending on whether the input is set to current or voltage). This parameter is read-only.	-
	-22.00022.000 mA or V	Value of analog input Al3.	1000 = 1 mA or V
14.57	Al3 scaled value	(Visible when 14.01 Module 1 type = FIO-11) Displays the value of analog input Al3 after scaling. See parameter 14.65 Al3 scaled at Al3 min. This parameter is read-only.	-
	-32768.000 32767.000	Scaled value of analog input Al3.	1 = 1
14.58	Al3 force data	(Visible when 14.01 Module 1 type = FIO-11) Forced value that can be used instead of the true reading of the input. See parameter 14.22 Al force selection.	0.000 mA
	-22.00022.000 mA or V	Forced value of analog input Al3.	1000 = 1 mA or V

No.	Name/Value	Description	Def/ FbEq16
14.59	Al3 HW switch pos	(Visible when 14.01 Module 1 type = FIO-11) Shows the position of the hardware current/voltage selector on the I/O extension module. Note: The setting of the current/voltage selector must match the unit selection made in parameter 14.60 Al3 unit selection. I/O module reboot either by cycling the power or through parameter 96.08 Control board boot is required to validate any changes in the hardware settings.	-
	V	Volts.	2
	mA	Milliamperes.	10
14.60	Al3 unit selection	(Visible when 14.01 Module 1 type = FIO-11) Selects the unit for readings and settings related to analog input AI3. Note: This setting must match the corresponding hardware setting on the I/O extension module (see the manual of the I/O extension module). The hardware setting is shown by parameter 14.59 AI3 HW switch pos. I/O module reboot either by cycling the power or through parameter 96.08 Control board boot is required to validate any changes in the hardware settings.	mA
	V	Volts.	2
	mA	Milliamperes.	10
14.61	Al3 filter gain	(Visible when 14.01 Module 1 type = FIO-11) Selects a hardware filtering time for Al3. See also parameter 14.62 Al3 filter time.	1 ms
	No filtering	No filtering.	0
	125 us	125 microseconds.	1
	250 us	250 microseconds.	2
	500 us	500 microseconds.	3
	1 ms	1 millisecond.	4
	2 ms	2 milliseconds.	5
	4 ms	4 milliseconds.	6
	7.9375 ms	7.9375 milliseconds.	7

No.	Name/Value	Description	Def/ FbEq16
14.62	Al3 filter time	(Visible when 14.01 Module 1 type = FIO-11) Defines the filter time constant for analog input Al3.   "Unfiltered signal  O = I × (1 - e <sup>-t/T</sup> )  I = filter input (step) O = filter output t = time T = filter time constant  Note: The signal is also filtered due to the signal interface hardware. See parameter 14.61 Al3 filter gain.	0.100 s
	0.00030.000 s	Filter time constant.	1000 = 1 s
14.63	Al3 min	(Visible when 14.01 Module 1 type = FIO-11) Defines the minimum value for analog input Al3. See also parameter 14.21 Al tune.	0.000 mA or V
	-22.00022.000 mA or V	Minimum value of Al3.	1000 = 1 mA or V
14.64	Al3 max	(Visible when 14.01 Module 1 type = FIO-11) Defines the maximum value for analog input Al3. See also parameter 14.21 Al tune.	10.000 mA or V
	-22.00022.000 mA or V	Maximum value of Al3.	1000 = 1 mA or V

No.	Name/Va	alue	Description	Def/ FbEq16
14.65	Al3 scale	d at AI3 min	(Visible when 14.01 Module 1 type = FIO-11)  Defines the real value that corresponds to the minimum analog input Al3 value defined by parameter 14.63 Al3 min.  Al <sub>scaled</sub> (14.57)  14.63  Al <sub>in</sub> (14.56)	0.000
	-32768.0 32767.		Real value corresponding to minimum Al3 value.	1 = 1
14.66	Al3 scale	ed at AI3 max	(Visible when 14.01 Module 1 type = FIO-11) Defines the real value that corresponds to the maximum analog input Al3 value defined by parameter 14.64 Al3 max. See the drawing at parameter 14.65 Al3 scaled at Al3 min.	100.000
	-32768.0 32767.		Real value corresponding to maximum Al3 value.	1 = 1
14.71	AO force	selection	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) The value of the analog output can be overridden for eg. testing purposes. A forced value parameter (14.78 AO1 force data) is provided for the analog output, and its value is applied whenever the corresponding bit in this parameter is 1.	00b
	Bit	Value		$\neg$
	0		1 to value of parameter 14.78 AO1 force data.	
	1		2 to value of parameter 14.88 AO2 force data (FAIO-01 only	).
	315	Reserved.		
	00b11b	)	Forced values selector for analog outputs.	1 = 1
14.76	AO1 actu	ial value	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Displays the value of AO1 in mA. This parameter is read-only.	-
	0.0002	2.000 mA	Value of AO1.	1000 = 1 mA
14.77	AO1 soul	rce	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Selects a signal to be connected to analog output AO1. Alternatively, sets the output to excitation mode to feed a constant current to a temperature sensor.	Zero
	Zero		None.	0

## 192 Parameters

No.	Name/Value	Description	Def/ FbEq16
	Motor speed used	01.01 Motor speed used (page 121).	1
	Output frequency	01.06 Output frequency (page 121).	3
	Motor current	01.07 Motor current (page 121).	4
	Motor torque	01.10 Motor torque (page 121).	6
	DC voltage	01.11 DC voltage (page 122).	7
	Power inu out	01.14 Output power (page 122).	8
	Speed ref ramp in	23.01 Speed ref ramp input (page 231).	10
	Speed ref ramp out	23.02 Speed ref ramp output (page 232).	11
	Speed ref used	24.01 Used speed reference (page 238).	12
	Freq ref used	28.02 Frequency ref ramp output (page 257).	14
	Force PT100 excitation	The output is used to feed an excitation current to 13 Pt100 sensors. See section <i>Motor thermal protection</i> (page 94).	20
	Force KTY84 excitation	The output is used to feed an excitation current to a KTY84 sensor. See section <i>Motor thermal protection</i> (page 94).	21
	Force PTC excitation	The output is used to feed an excitation current to 13 PTC sensors. See section <i>Motor thermal protection</i> (page 94).	22
	Force Pt1000 excitation	The output is used to feed an excitation current to 13 Pt1000 sensors. See section <i>Motor thermal protection</i> (page 94).	23
	AO1 data storage	13.91 AO1 data storage (page 175).	37
	AO2 data storage	13.92 AO2 data storage (page 175).	38
	Other	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
14.78	AO1 force data	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Forced value that can be used instead of the selected output signal. See parameter 14.71 AO force selection.	0.000 mA
	0.00022.000 mA	Forced value of analog output AO1.	1000 = 1 mA

No.	Name/Value	Description	Def/ FbEq16
14.79	AO1 filter time	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Defines the filtering time constant for analog output AO1.   "Unfiltered signal  O = I × (1 - e <sup>-t/T</sup> )  I = filter input (step) O = filter output t = time T = filter time constant	0.100 s
	0.00030.000 s	Filter time constant.	1000 = 1 s

No.	Name/Value	Description	Def/ FbEq16
14.80	AO1 source min	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Defines the real value of the signal (selected by parameter 14.77 AO1 source) that corresponds to the minimum AO1 output value (defined by parameter 14.82 AO1 out at AO1 src min).  IAO1 (mA)  14.83  14.82  14.81  14.80  Signal (real) selected by parameter 14.82  14.81  14.80  Signal (real) selected by parameter 14.82	0.0
	-32768.032767.0	Real signal value corresponding to minimum AO1 output value.	1 = 1
14.81	AO1 source max	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Defines the real value of the signal (selected by parameter 14.77 AO1 source) that corresponds to the maximum AO1 output value (defined by parameter 14.83 AO1 out at AO1 src max). See parameter 14.80 AO1 source min.	100.0
	-32768.032767.0	Real signal value corresponding to maximum AO1 output value.	1 = 1
14.82	AO1 out at AO1 src min	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Defines the minimum output value for analog output AO1. See also drawing at parameter 14.80 AO1 source min.	0.000 mA
	0.00022.000 mA	Minimum AO1 output value.	1000 = 1 mA
14.83	AO1 out at AO1 src max	(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Defines the maximum output value for analog output AO1. See also drawing at parameter 14.80 AO1 source min.	10.000 mA
	0.00022.000 mA	Maximum AO1 output value.	1000 = 1 mA

No.	Name/Value	Description	Def/ FbEq16
14.86	AO2 actual value	(Visible when 14.01 Module 1 type = FAIO-01) Displays the value of AO2 in mA. This parameter is read-only.	-
	0.00022.000 mA	Value of AO2.	1000 = 1 mA
14.87	AO2 source	(Visible when 14.01 Module 1 type = FAIO-01) Selects a signal to be connected to analog output AO2. Alternatively, sets the output to excitation mode to feed a constant current to a temperature sensor. For the selections, see parameter 14.77 AO1 source.	Zero
14.88	AO2 force data	(Visible when 14.01 Module 1 type = FAIO-01) Forced value that can be used instead of the selected output signal. See parameter 14.71 AO force selection.	0.000 mA
	0.00022.000 mA	Forced value of analog output AO2.	1000 = 1 mA
14.89	AO2 filter time	(Visible when 14.01 Module 1 type = FAIO-01) Defines the filtering time constant for analog output AO2. See parameter 14.79 AO1 filter time.	0.100 s
	0.00030.000 s	Filter time constant.	1000 = 1 s
14.90	AO2 source min	(Visible when 14.01 Module 1 type = FAIO-01)  Defines the real value of the signal (selected by parameter 14.87 AO2 source) that corresponds to the minimum AO2 output value (defined by parameter 14.92 AO2 out at AO2 src min).  IAO1 (mA)  14.93  Signal (real) selected by par. 14.87  Signal (real) selected by par. 14.87	
	-32768.032767.0	Real signal value corresponding to minimum AO2 output value.	1 = 1

No.	Name/Value	Description	Def/ FbEq16
14.91	AO2 source max	(Visible when 14.01 Module 1 type = k) Defines the real value of the signal (selected by parameter 14.87 AO2 source) that corresponds to the maximum AO2 output value (defined by parameter 14.93 AO2 out at AO2 src max). See parameter 14.90 AO2 source min.	100.0
	-32768.032767.0	Real signal value corresponding to maximum AO2 output value.	1 = 1
14.92	AO2 out at AO2 src min	(Visible when 14.01 Module 1 type = FAIO-01) Defines the minimum output value for analog output AO2. See also drawing at parameter 14.90 AO2 source min.	0.000 mA
	0.00022.000 mA	Minimum AO2 output value.	1000 = 1 mA
14.93	AO2 out at AO2 src max	(Visible when 14.01 Module 1 type = FAIO-01) Defines the maximum output value for analog output AO2. See also drawing at parameter 14.90 AO2 source min.	10.000 mA
	0.00022.000 mA	Maximum AO2 output value.	1000 = 1 mA

15 I/O 2	extension module	Configuration of I/O extension module 2. See also section <i>Programmable I/O extensions</i> (page 60). Note: The contents of the parameter group vary according to the selected I/O extension module type.	
15.01	Module 2 type	See parameter 14.01 Module 1 type.	None
15.02	Module 2 location	See parameter 14.02 Module 1 location.	Slot 1
15.03	Module 2 status	See parameter 14.03 Module 1 status.	No option
15.05	DI status	(Visible when 15.01 Module 2 type = FDIO-01) See parameter 14.05 DI status.	-
15.05	DIO status	(Visible when 15.01 Module 2 type = FIO-01 or FIO-11) See parameter 14.05 DIO status.	-
15.06	DI delayed status	(Visible when 15.01 Module 2 type = FDIO-01) See parameter 14.06 DI delayed status.	-
15.06	DIO delayed status	(Visible when 15.01 Module 2 type = FIO-01 or FIO-11) See parameter 14.06 DIO delayed status.	-
15.08	DI filter time	(Visible when 15.01 Module 2 type = FDIO-01) See parameter 14.08 DI filter time.	10.0 ms
15.08	DIO filter time	(Visible when 15.01 Module 2 type = FIO-01 or FIO-11) See parameter 14.08 DIO filter time.	10.0 ms
15.09	DIO1 function	(Visible when 15.01 Module 2 type = FIO-01 or FIO-11) See parameter 14.09 DIO1 function.	Input
15.11	DIO1 output source	(Visible when 15.01 Module 2 type = FIO-01 or FIO-11) See parameter 14.11 DIO1 output source.	Not energized
15.12	DI1 ON delay	(Visible when 15.01 Module 2 type = FDIO-01) See parameter 14.12 DI1 ON delay.	0.00 s
15.12	DIO1 ON delay	(Visible when 15.01 Module 2 type = FIO-01 or FIO-11) See parameter 14.12 DIO1 ON delay.	0.00 s
15.13	DI1 OFF delay	(Visible when 15.01 Module 2 type = FDIO-01) See parameter 14.13 DI1 OFF delay.	0.00 s
15.13	DIO1 OFF delay	(Visible when 15.01 Module 2 type = FIO-01 or FIO-11) See parameter 14.13 DIO1 OFF delay.	0.00 s

No.	Name/Value	Description	Def/ FbEq16
15.14	DIO2 function	(Visible when 15.01 Module 2 type = FIO-01 or FIO-11) See parameter 14.14 DIO2 function.	Input
15.16	DIO2 output source	(Visible when 15.01 Module 2 type = FIO-01 or FIO-11) See parameter 14.16 DIO2 output source.	Not energized
15.17	DI2 ON delay	(Visible when 15.01 Module 2 type = FDIO-01) See parameter 14.17 DI2 ON delay.	0.00 s
15.17	DIO2 ON delay	(Visible when 15.01 Module 2 type = FIO-01 or FIO-11) See parameter 14.17 DIO2 ON delay.	0.00 s
15.18	DI2 OFF delay	(Visible when 15.01 Module 2 type = FDIO-01) See parameter 14.18 DI2 OFF delay.	0.00 s
15.18	DIO2 OFF delay	(Visible when 15.01 Module 2 type = FIO-01 or FIO-11) See parameter 14.18 DIO2 OFF delay.	0.00 s
15.19	DIO3 configuration	(Visible when 15.01 Module 2 type = FIO-01) See parameter 14.19 DIO3 function.	Input
15.19	Al supervision function	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.19 AI supervision function.	No action
15.20	Al supervision selection	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.20 AI supervision selection.	0000 0000b
15.21	DIO3 output source	(Visible when 15.01 Module 2 type = FIO-01) See parameter 14.21 DIO3 output source.	Not energized
15.21	Al tune	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.21 Al tune.	No action
15.22	DI3 ON delay	(Visible when 15.01 Module 2 type = FDIO-01) See parameter 14.22 DI3 ON delay.	0.00 s
15.22	DIO3 ON delay	(Visible when 15.01 Module 2 type = FIO-01) See parameter 14.22 DIO3 ON delay.	0.00 s
15.22	Al force selection	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.22 Al force selection.	0000b
15.23	DI3 OFF delay	(Visible when 15.01 Module 2 type = FDIO-01) See parameter 14.23 DI3 OFF delay.	0.00 s
15.23	DIO3 OFF delay	(Visible when 15.01 Module 2 type = FIO-01) See parameter 14.23 DIO3 OFF delay.	0.00 s
15.24	DIO4 configuration	(Visible when 15.01 Module 2 type = FIO-01) See parameter 14.24 DIO4 function.	Input
15.26	DIO4 output source	(Visible when 15.01 Module 2 type = FIO-01) See parameter 14.26 DIO4 output source.	Not energized
15.26	Al1 actual value	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.26 AI1 actual value.	-
15.27	DIO4 ON delay	(Visible when 15.01 Module 2 type = FIO-01) See parameter 14.27 DIO4 ON delay.	0.00 s
15.27	Al1 scaled value	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.27 AI1 scaled value.	-
15.28	DIO4 OFF delay	(Visible when 15.01 Module 2 type = FIO-01) See parameter 14.28 DIO4 OFF delay.	0.00 s
15.28	Al1 force data	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.28 AI1 force data.	0.000 mA

No.	Name/Value	Description	Def/ FbEq16
15.29	Al1 HW switch pos	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.29 AI1 HW switch pos.	-
15.30	Al1 unit selection	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.30 AI1 unit selection.	mA
15.31	RO status	(Visible when 15.01 Module 2 type = FIO-01 or FDIO-01) See parameter 14.31 RO status.	-
15.31	Al1 filter gain	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.31 AI1 filter gain.	1 ms
15.32	Al1 filter time	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.32 AI1 filter time.	0.100 s
15.33	Al1 min	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.33 Al1 min.	0.000 mA or V
15.34	RO1 source	(Visible when 15.01 Module 2 type = FIO-01 or FDIO-01) See parameter 14.34 RO1 source.	Not energized
15.34	Al1 max	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.34 Al1 max.	10.000 mA or V
15.35	RO1 ON delay	(Visible when 15.01 Module 2 type = FIO-01 or FDIO-01) See parameter 14.35 RO1 ON delay.	0.00 s
15.35	Al1 scaled at Al1 min	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.35 Al1 scaled at Al1 min.	0.000
15.36	RO1 OFF delay	(Visible when 15.01 Module 2 type = FIO-01 or FDIO-01) See parameter 14.36 RO1 OFF delay.	0.00 s
15.36	Al1 scaled at Al1 max	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.36 Al1 scaled at Al1 max.	100.000
15.37	RO2 source	(Visible when 15.01 Module 2 type = FIO-01 or FDIO-01) See parameter 14.37 RO2 source.	Not energized
15.38	RO2 ON delay	(Visible when 15.01 Module 2 type = FIO-01 or FDIO-01) See parameter 14.38 RO2 ON delay.	0.00 s
15.39	RO2 OFF delay	(Visible when 15.01 Module 2 type = FIO-01 or FDIO-01) See parameter 14.39 RO2 OFF delay.	0.00 s
15.41	Al2 actual value	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.41 AI2 actual value.	-
15.42	Al2 scaled value	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.42 AI2 scaled value.	-
15.43	Al2 force data	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.43 AI2 force data.	0.000 mA
15.44	AI2 HW switch position	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.44 AI2 HW switch pos.	-
15.45	Al2 unit selection	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.45 AI2 unit selection.	mA
15.46	Al2 filter gain	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.46 AI2 filter gain.	1 ms
15.47	AI2 filter time	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.47 AI2 filter time.	0.100 s
15.48	AI2 min	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.48 AI2 min.	0.000 mA or V

No.	Name/Value	Description	Def/ FbEq16
15.49	Al2 max	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.49 AI2 max.	10.000 mA or V
15.50	Al2 scaled at Al2 min	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.50 AI2 scaled at AI2 min.	0.000
15.51	Al2 scaled at Al2 max	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.51 AI2 scaled at AI2 max.	100.000
15.56	Al3 actual value	(Visible when 15.01 Module 2 type = FIO-11) See parameter 14.56 Al3 actual value.	-
15.57	Al3 scaled value	(Visible when 15.01 Module 2 type = FIO-11) See parameter 14.57 Al3 scaled value.	-
15.58	Al3 force data	(Visible when 15.01 Module 2 type = FIO-11) See parameter 14.58 AI3 force data.	0.000 mA
15.59	AI3 HW switch position	(Visible when 15.01 Module 2 type = FIO-11) See parameter 14.59 AI3 HW switch pos.	-
15.60	Al3 unit selection	(Visible when 15.01 Module 2 type = FIO-11) See parameter 14.60 AI3 unit selection.	mA
15.61	Al3 filter gain	(Visible when 15.01 Module 2 type = FIO-11) See parameter 14.61 Al3 filter gain.	1 ms
15.62	Al3 filter time	(Visible when 15.01 Module 2 type = FIO-11) See parameter 14.62 AI3 filter time.	0.100 s
15.63	Al3 min	(Visible when 15.01 Module 2 type = FIO-11) See parameter 14.63 Al3 min.	0.000 mA or V
15.64	AI3 max	(Visible when 15.01 Module 2 type = FIO-11) See parameter 14.64 AI3 max.	10.000 mA or V
15.65	Al3 scaled at Al3 min	(Visible when 15.01 Module 2 type = FIO-11) See parameter 14.65 Al3 scaled at Al3 min.	0.000
15.66	Al3 scaled at Al3 max	(Visible when 15.01 Module 2 type = FIO-11) See parameter 14.66 AI3 scaled at AI3 max.	100.000
15.71	AO force selection	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.71 AO force selection.	00b
15.76	AO1 actual value	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.76 AO1 actual value.	-
15.77	AO1 source	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.77 AO1 source.	Zero
15.78	AO1 force data	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.78 AO1 force data.	0.000 mA
15.79	AO1 filter time	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.79 AO1 filter time.	0.100 s
15.80	AO1 source min	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.80 AO1 source min.	0.0
15.81	AO1 source max	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.81 AO1 source max.	100.0
15.82	AO1 out at AO1 src min	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.82 AO1 out at AO1 src min.	0.000 mA
15.83	AO1 out at AO1 src max	(Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.83 AO1 out at AO1 src max.	10.000 mA

No.	Name/Value	Description	Def/ FbEq16
15.86	AO2 actual value	(Visible when 15.01 Module 2 type = FAIO-01) See parameter 14.86 AO2 actual value.	-
15.87	AO2 source	(Visible when 15.01 Module 2 type = FAIO-01) See parameter 14.87 AO2 source.	Zero
15.88	AO2 force data	(Visible when 15.01 Module 2 type = FAIO-01) See parameter 14.88 AO2 force data.	0.000 mA
15.89	AO2 filter time	(Visible when 15.01 Module 2 type = FAIO-01) See parameter 14.89 AO2 filter time.	0.100 s
15.90	AO2 source min	(Visible when 15.01 Module 2 type = FAIO-01) See parameter 14.90 AO2 source min.	0.0
15.91	AO2 source max	(Visible when 15.01 Module 2 type = FAIO-01) See parameter 14.91 AO2 source max.	100.0
15.92	AO2 out at AO1 src min	(Visible when 15.01 Module 2 type = FAIO-01) See parameter 14.92 AO2 out at AO2 src min.	0.000 mA
15.93	AO2 out at AO1 src max	(Visible when 15.01 Module 2 type = FAIO-01) See parameter 14.93 AO2 out at AO2 src max.	10.000 mA

16 I/O 3	extension module	Configuration of I/O extension module 3. See also section <i>Programmable I/O extensions</i> (page 60). Note: The contents of the parameter group vary according to the selected I/O extension module type.	
16.01	Module 3 type	See parameter 14.01 Module 1 type.	None
16.02	Module 3 location	See parameter 14.02 Module 1 location.	Slot 1
16.03	Module 3 status	See parameter 14.03 Module 1 status.	No option
16.05	DI status	(Visible when 16.01 Module 3 type = FDIO-01) See parameter 14.05 DI status.	-
16.05	DIO status	(Visible when 16.01 Module 3 type = FIO-01 or FIO-11) See parameter 14.05 DIO status.	-
16.06	DI delayed status	(Visible when 16.01 Module 3 type = FDIO-01) See parameter 14.06 DI delayed status.	-
16.06	DIO delayed status	(Visible when 16.01 Module 3 type = FIO-01 or FIO-11) See parameter 14.06 DIO delayed status.	-
16.08	DI filter time	(Visible when 16.01 Module 3 type = FDIO-01) See parameter 14.08 DI filter time.	10.0 ms
16.08	DIO filter time	(Visible when 16.01 Module 3 type = FIO-01 or FIO-11) See parameter 14.08 DIO filter time.	10.0 ms
16.09	DIO1 function	(Visible when 16.01 Module 3 type = FIO-01 or FIO-11) See parameter 14.09 DIO1 function.	Input
16.11	DIO1 output source	(Visible when 16.01 Module 3 type = FIO-01 or FIO-11) See parameter 14.11 DIO1 output source.	Not energized
16.12	DI1 ON delay	(Visible when 16.01 Module 3 type = FDIO-01) See parameter 14.12 DI1 ON delay.	0.00 s
16.12	DIO1 ON delay	(Visible when 16.01 Module 3 type = FIO-01 or FIO-11) See parameter 14.12 DIO1 ON delay.	0.00 s
16.13	DI1 OFF delay	(Visible when 16.01 Module 3 type = FDIO-01) See parameter 14.13 DI1 OFF delay.	0.00 s

No.	Name/Value	Description	Def/ FbEq16
16.13	DIO1 OFF delay	(Visible when 16.01 Module 3 type = FIO-01 or FIO-11) See parameter 14.13 DIO1 OFF delay.	0.00 s
16.14	DIO2 function	(Visible when 16.01 Module 3 type = FIO-01 or FIO-11) See parameter 14.14 DIO2 function.	Input
16.16	DIO2 output source	(Visible when 16.01 Module 3 type = FIO-01 or FIO-11) See parameter 14.16 DIO2 output source.	Not energized
16.17	DI2 ON delay	(Visible when 16.01 Module 3 type = FDIO-01) See parameter 14.17 DI2 ON delay.	0.00 s
16.17	DIO2 ON delay	(Visible when 16.01 Module 3 type = FIO-01 or FIO-11) See parameter 14.17 DIO2 ON delay.	0.00 s
16.18	DI2 OFF delay	(Visible when 16.01 Module 3 type = FDIO-01) See parameter 14.18 DI2 OFF delay.	0.00 s
16.18	DIO2 OFF delay	(Visible when 16.01 Module 3 type = FIO-01 or FIO-11) See parameter 14.18 DIO2 OFF delay.	0.00 s
16.19	DIO3 function	(Visible when 16.01 Module 3 type = FIO-01) See parameter 14.19 DIO3 function.	Input
16.19	Al supervision function	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.19 AI supervision function.	No action
16.20	Al supervision selection	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.20 AI supervision selection.	0000 0000ь
16.21	DIO3 output source	(Visible when 16.01 Module 3 type = FIO-01) See parameter 14.21 DIO3 output source.	Not energized
16.21	Al tune	(Visible when 16.01 Module 3 type = FIO-01 or FAIO-01) See parameter 14.21 DIO3 output source.	No action
16.22	DI3 ON delay	(Visible when 16.01 Module 3 type = FDIO-01) See parameter 14.22 DI3 ON delay.	0.00 s
16.22	DIO3 ON delay	(Visible when 16.01 Module 3 type = FIO-01) See parameter 14.22 DIO3 ON delay.	0.00 s
16.22	Al force selection	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.22 Al force selection.	0000ь
16.23	DI3 OFF delay	(Visible when 16.01 Module 3 type = FDIO-01) See parameter 14.23 DI3 OFF delay.	0.00 s
16.23	DIO3 OFF delay	(Visible when 16.01 Module 3 type = FIO-01) See parameter 14.23 DIO3 OFF delay.	0.00 s
16.24	DIO4 configuration	(Visible when 16.01 Module 3 type = FIO-01) See parameter 14.24 DIO4 function.	Input
16.26	DIO4 output source	(Visible when 16.01 Module 3 type = FIO-01) See parameter 14.26 DIO4 output source.	Not energized
16.26	Al1 actual value	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.26 AI1 actual value.	-
16.27	DIO4 ON delay	(Visible when 16.01 Module 3 type = FIO-01) See parameter 14.27 DIO4 ON delay.	0.00 s
16.27	Al1 scaled value	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.27 AI1 scaled value.	-
16.28	DIO4 OFF delay	(Visible when 16.01 Module 3 type = FIO-01) See parameter 14.28 DIO4 OFF delay.	0.00 s

No.	Name/Value	Description	Def/ FbEq16
16.28	Al1 force data	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.28 Al1 force data.	0.000 mA
16.29	AI1 HW switch position	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.29 AI1 HW switch pos.	-
16.30	Al1 unit selection	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.30 Al1 unit selection.	mA
16.31	RO status	(Visible when 16.01 Module 3 type = FIO-11 or FDIO-01) See parameter 14.31 RO status.	-
16.31	Al1 filter gain	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.31 Al1 filter gain.	1 ms
16.32	AI1 filter time	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.32 Al1 filter time.	0.100 s
16.33	Al1 min	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.33 Al1 min.	0.000 mA or V
16.34	RO1 source	(Visible when 16.01 Module 3 type = FIO-01 or FDIO-01) See parameter 14.34 RO1 source.	Not energized
16.34	Al1 max	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.34 Al1 max.	10.000 mA or V
16.35	RO1 ON delay	(Visible when 16.01 Module 3 type = FIO-01 or FDIO-01) See parameter 14.35 RO1 ON delay.	0.00 s
16.35	Al1 scaled at Al1 min	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.35 Al1 scaled at Al1 min.	0.000
16.36	RO1 OFF delay	(Visible when 16.01 Module 3 type = FIO-01 or FDIO-01) See parameter 14.36 RO1 OFF delay.	0.00 s
16.36	Al1 scaled at Al1 max	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.36 AI1 scaled at AI1 max.	100.000
16.37	RO2 source	(Visible when 16.01 Module 3 type = FIO-01 or FDIO-01) See parameter 14.37 RO2 source.	Not energized
16.38	RO2 ON delay	(Visible when 16.01 Module 3 type = FIO-01 or FDIO-01) See parameter 14.38 RO2 ON delay.	0.00 s
16.39	RO2 OFF delay	(Visible when 16.01 Module 3 type = FIO-01 or FDIO-01) See parameter 14.39 RO2 OFF delay.	0.00 s
16.41	Al2 actual value	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.41 AI2 actual value.	-
16.42	Al2 scaled value	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.42 AI2 scaled value.	-
16.43	Al2 force data	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.43 AI2 force data.	0.000 mA
16.44	AI2 HW switch pos	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.44 AI2 HW switch pos.	-
16.45	Al2 unit selection	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.45 AI2 unit selection.	mA
16.46	Al2 filter gain	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.46 AI2 filter gain.	1 ms
16.47	AI2 filter time	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.47 AI2 filter time.	0.100 s

No.	Name/Value	Description	Def/ FbEq16
16.48	Al2 min	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.48 AI2 min.	0.000 mA or V
16.49	Al2 max	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.49 AI2 max.	10.000 mA or V
16.50	Al2 scaled at Al2 min	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.50 AI2 scaled at AI2 min.	0.000
16.51	Al2 scaled at Al2 max	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.51 AI2 scaled at AI2 max.	100.000
16.56	Al3 actual value	(Visible when 16.01 Module 3 type = FIO-11) See parameter 14.56 Al3 actual value.	-
16.57	Al3 scaled value	(Visible when 16.01 Module 3 type = FIO-11) See parameter 14.57 Al3 scaled value.	-
16.58	Al3 force data	(Visible when 16.01 Module 3 type = FIO-11) See parameter 14.58 AI3 force data.	0.000 mA
16.59	AI3 HW switch position	(Visible when 16.01 Module 3 type = FIO-11) See parameter 14.59 AI3 HW switch pos.	-
16.60	Al3 unit selection	(Visible when 16.01 Module 3 type = FIO-11) See parameter 14.60 Al3 unit selection.	mA
16.61	Al3 filter gain	(Visible when 16.01 Module 3 type = FIO-11) See parameter 14.61 Al3 filter gain.	1 ms
16.62	Al3 filter time	(Visible when 16.01 Module 3 type = FIO-11) See parameter 14.62 AI3 filter time.	0.100 s
16.63	Al3 min	(Visible when 16.01 Module 3 type = FIO-11) See parameter 14.63 AI3 min.	0.000 mA or V
16.64	Al3 max	(Visible when 16.01 Module 3 type = FIO-11) See parameter 14.64 AI3 max.	10.000 mA or V
16.65	Al3 scaled at Al3 min	(Visible when 16.01 Module 3 type = FIO-11) See parameter 14.65 AI3 scaled at AI3 min.	0.000
16.66	Al3 scaled at Al3 max	(Visible when 16.01 Module 3 type = FIO-11) See parameter 14.66 AI3 scaled at AI3 max.	100.000
16.71	AO force selection	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.71 AO force selection.	00b
16.76	AO1 actual value	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.76 AO1 actual value.	-
16.77	AO1 source	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.77 AO1 source.	Zero
16.78	AO1 force data	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.78 AO1 force data.	0.000 mA
16.79	AO1 filter time	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.79 AO1 filter time.	0.100 s
16.80	AO1 source min	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.80 AO1 source min.	0.0
16.81	AO1 source max	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.81 AO1 source max.	100.0
16.82	AO1 out at AO1 src min	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.82 AO1 out at AO1 src min.	0.000 mA

No.	Name/Value	Description	Def/ FbEq16
16.83	AO1 out at AO1 src max	(Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.83 AO1 out at AO1 src max.	10.000 mA
16.86	AO2 actual value	(Visible when 16.01 Module 3 type = FAIO-01) See parameter 14.86 AO2 actual value.	-
16.87	AO2 source	(Visible when 16.01 Module 3 type = FAIO-01) See parameter 14.87 AO2 source.	Zero
16.88	AO2 force data	(Visible when 16.01 Module 3 type = FAIO-01) See parameter 14.88 AO2 force data.	0.000 mA
16.89	AO2 filter time	(Visible when 16.01 Module 3 type = FAIO-01) See parameter 14.89 AO2 filter time.	0.100 s
16.90	AO2 source min	(Visible when 16.01 Module 3 type = FAIO-01) See parameter 14.90 AO2 source min.	0.0
16.91	AO2 source max	(Visible when 16.01 Module 3 type = FAIO-01) See parameter 14.91 AO2 source max.	100.0
16.92	AO2 out at AO2 src min	(Visible when 16.01 Module 3 type = FAIO-01) See parameter 14.92 AO2 out at AO2 src min.	0.000 mA
16.93	AO2 out at AO2 src max	(Visible when 16.01 Module 3 type = FAIO-01) See parameter 14.93 AO2 out at AO2 src max.	10.000 mA
19 Op	eration mode	Selection of local and external control location sources and operating modes.  See also section <i>Operating modes of the drive</i> (page 56).	
19.01	Actual operation mode	Displays the operating mode currently used. See parameters 19.1119.14. This parameter is read-only.	-
	Zero	None.	1
	Speed	Speed control (in DTC motor control mode).	2
	Torque	Torque control (in DTC motor control mode).	3
	Min	The torque selector is comparing the output of the speed controller (25.01 Torque reference speed control) and torque reference (26.74 Torque ref ramp out) and the smaller of the two is used.	4
	Max	The torque selector is comparing the output of the speed controller (25.01 Torque reference speed control) and torque reference (26.74 Torque ref ramp out) and the greater of the two is used.	5
	Add	The speed controller output is added to the torque reference.	6
	Scalar (Hz)	Frequency control in scalar motor control mode.	10
	Scalar (rpm)	Speed control in scalar motor control mode.	11
	Forced magn.	Motor is in magnetizing mode.	20
19.11	Ext1/Ext2 selection	Selects the source for external control location EXT1/EXT2 selection.  0 = EXT1 1 = EXT2	EXT1
	EXT1	EXT1 (permanently selected).	0
	EXT2	EXT2 (permanently selected).	1

No.	Name/Value	Description	Def/ FbEq16
	FBA A MCW bit 11	Control word bit 11 received through fieldbus interface A.	2
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	3
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	4
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	5
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	6
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	7
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	8
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	11
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	12
	EFB MCW bit 11	Control word bit 11 received through the embedded fieldbus interface.	32
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
19.12	Ext1 control mode 1	Selects the operating mode for external control location EXT1.	Speed
	Zero	None.	1
	Speed	Speed control. The torque reference used is 25.01 Torque reference speed control (output of the speed reference chain).	2
19.14	Ext2 control mode 1	Selects the operating mode for external control location EXT2. For the selections, see parameter 19.12 Ext1 control mode 1.	Speed
19.16	Local control mode	Selects the operating mode for local control.	Speed
	Speed	Speed control. The torque reference used is 25.01 Torque reference speed control (output of the speed reference chain).	0
19.17	Local control disable	Enables/disables local control (start and stop buttons on the control panel, and the local controls on the PC tool).  WARNING! Before disabling local control, ensure that the control panel is not needed for stopping the drive.	No
	No	Local control enabled.	0
	Yes	Local control disabled.	1
19.20	Scalar control reference unit	Selects the reference type for scalar motor control mode. See also section <i>Operating modes of the drive</i> (page 56), and parameter 99.04 Motor ctrl mode.  Note: This parameter cannot be changed while the drive is running.	Rpm
	Hz	Hz. The reference is taken from parameter 28.02 Frequency ref ramp output (output of the frequency control chain).	0
	Rpm	Rpm. The reference is taken from parameter 23.02 Speed ref ramp output (speed reference after ramping and shaping).	1

No. Name/V	alue	Description					Def/ FbEq16
20 Start/stop/d		Start/stop/direction ar selection; positive/neg selection. For information on co control vs. external co	gative refere	nce enab	le signal	source	
20.01 Ext1 con		Selects the source of for external control lo See also parameters	cation 1 (EX	T1).	ion comi	mands	In1 Start
Not selec	cted	No start or stop comn	nand source	s selecte	d.		0
In1 Start		The source of the sta parameter 20.03 Ext1 the source bits are int State of source 1	in1 source. terpreted as	The stat	e transit		1
		0 -> 1 (20.02 = Edg 1 (20.02 = Level)		Start Stop	illu		
In1 Start	,	The source selected I signal; the source sel determines the direct source bits are interp	ected by <mark>20</mark> . ion. The stat	04 Ext1 e transiti	in2 sourc	e	2
		State of source 1 (20.03)	State of s (20.04)	source 2	Comm	and	
		0	Any		Stop		
		0 -> 1 (20.02 = Edge	) 0		Start fo		
		1 (20.02 = Level)	1		Start re	everse	
In1 Start Start rev		The source selected I forward start signal; the source is the reverse the source bits are into	ne source se start signal.	elected by The stat	/ 20.04 E	xt1 in2	3
			State of sou (20.04)	irce 2	omman	d	
		-	)		top		
		0 -> 1 (20.02 =   ( Edge) 1 (20.02 = Level)	)	S	tart forw	ard	
		ı	) -> 1 (20.02 Edge) 1 (20.02 = L		tart reve	rse	
		1	1	S	top		

No.	Name/Value	De	escription							Def/ FbEq16
	In1P Start; In2 Stop	by sou	parameters	20.03 ate tran	Ext1 i	d stop comm n1 source ar s of the sour	nd <mark>20</mark> .	04 Ext1 in		4
		1 1 -	State of sou 20.03)	rce 1	State (20.0	e of source (4)	2 C	ommand		
		I 🗀	-> 1		1			art	_	
		Α	ny		0		St	юр		
		•				s edge-trigge ameter 20.02			ger	
	In1P Start; In2 Stop; In3 Dir	by sou det	parameters urce. The so termines the urce bits are	20.03 urce se directi interpi	Ext1 in electer on. The reted a		nd 20. xt1 in	04 Ext1 in 3 source		5
			State of source 1 (20.03)	State sour (20.0	ce 2	State of source 3 (20.05)	Com	mand		
			0 -> 1	1		0	Start	forward		
			0 -> 1	1		1		reverse		
			Any	0		Any	Stop			
						s edge-trigge ameter 20.02			ger	
	In1P Start fwd; In2P Start rev; In3 Stop	by sou	parameters urce and 20.	20.03 05 Ext	Ext1 i 1 in3 :	d stop comm n1 source, 2 source. The ted as follow	0.04 E state	Ext1 in2		6
		s (	State of source 1 (20.03)	State source (20.04	e 2	State of source 3 (20.05)		ımand		
		ΙĽ	-> 1	Any		1		forward		
		I ⊢	ny	0 -> 1		0		reverse	ł	
		_		Any		~	Stop		]	
			ting regardle			vays edge-tr eter 20.02 E				
	Control panel		e start and s nel.	top co	mman	ds are taker	from	the contr	ol	11
	Fieldbus A	ada <b>No</b>	apter A. <b>te</b> : The start ting regardle	· signal	l is alv	ds are taker vays level-tri eter 20.02 E	ggere	d with this		12

No.	Name/Value	Description	Def/ FbEq16
	Embedded fieldbus	The start and stop commands are taken from the embedded fieldbus interface.  Note: The start signal is always level-triggered with this setting regardless of parameter 20.02 Ext1 start trigger type.	14
	Application Program	The start and stop commands are taken from the application program control word (parameter 06.02 Application control word).  Note: The start signal is always level-triggered with this setting regardless of parameter 20.02 Ext1 start trigger type.	21
	ATF	Reserved.	22
20.02	Ext1 start trigger type	Defines whether the start signal for external control location EXT1 is edge-triggered or level-triggered. Note: This parameter is only effective when parameter 20.01 Ext1 commands is set to In1 Start, In1 Start; In2 Dir or In1 Start fwd; In2 Start rev, or Control panel.	Edge
	Edge	The start signal is edge-triggered.	0
	Level	The start signal is level-triggered.	1
20.03	Ext1 in1 source	Selects source 1 for parameter 20.01 Ext1 commands.	DI1
	Not selected	0 (always off).	0
	Selected	1 (always on).	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
20.04	Ext1 in2 source	Selects source 2 for parameter 20.01 Ext1 commands. For the available selections, see parameter 20.03 Ext1 in1 source.	Not selected
20.05	Ext1 in3 source	Selects source 3 for parameter 20.01 Ext1 commands. For the available selections, see parameter 20.03 Ext1 in1 source.	Not selected
20.06	Ext2 commands	Selects the source of start, stop and direction commands for external control location 2 (EXT2).  See also parameters 20.0720.10.	Not selected
	Not selected	No start or stop command sources selected.	0

No.	Name/Value	Description	Def/ FbEq16			
	In1 Start	The source of the sta parameter 20.08 Exta the source bits are in	2 in1 source. T	he state trans		1
		State of sou 0 -> 1 (20.07 1 (20.07 = Le	• ,	Command Start		
		0		Stop		
	In1 Start; In2 Dir	The source selected signal; the source sel determines the direct source bits are interp	ected by 20.09 ion. The state	9 Ext2 in2 sou transitions of	rce	2
		State of source 1 (20.08)	State of s 2 (20.09)	ource Comr	nand	
		0	Any	Stop		
		0 -> 1 (20.07 = Edge	′		orward	
		1 (20.07 = Level)	1	Start r	everse	
	In1 Start fwd; In2 Start rev	The source selected forward start signal; to source is the reverse the source bits are in	Ext2 in2	3		
		State of source 1 (20.08)	State of sou (20.09)	rce 2 Comr	nand	
		0	0	Stop		
		0 -> 1 (20.07 = Edge) 1 (20.07 = Level)	0	Start fo	orward	
		0	0 -> 1 (20.07 Edge) 1 (20.07 = Le		everse	
		1	1	Stop		
	In1P Start; In2 Stop	The sources of the st by parameters 20.08 source. The state trai interpreted as follows	Ext2 in1 source in sitions of the	e and 20.09 E	xt2 in2	4
		State of source 1 (20.08)	State of sour (20.09)	rce 2 Comr	nand	
		0 -> 1	1	Start		
		Any	0	Stop		
		Notes: • The start signal is setting regardless type.				

In1P Start; In2 Stop; In3 Dir  The sources of the start and stop commands are selected by parameters 20.08 Ext2 in1 source and 20.09 Ext2 in2 source. The source selected by 20.10 Ext2 in3 source determines the direction. The state transitions of the source bits are interpreted as follows:  State of source 1   State of source 3   (20.09)   (20.09)   (20.10)    0 > 1   1   0   Start forward   0 > 1   1   1   Start reverse   Any   0   Any   Stop  Notes:  • The start signal is always edge-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.  In1P Start fwd; In2P Start rev; In3 Stop  The sources of the start and stop commands are selected by parameters 20.08 Ext2 in1 source, 20.09 Ext2 in2 source and 20.10 Ext2 in3 source. The state transitions of the source bits are interpreted as follows:  State of source 1   State of source 3   (20.09)	No.	Name/Value	Descriptio	n				Def/ FbEq16		
Source 1   Source 2   (20.09)   (20.10)	In3 Dir by parameters 20.08 Ext2 in1 source and 20.09 Ext2 in2 source. The source selected by 20.10 Ext2 in3 source determines the direction. The state transitions of the							5		
Notes:  - The start signal is always edge-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.  In1P Start fwd; In2P Start rev; In3 Stop  The sources of the start and stop commands are selected by parameters 20.08 Ext2 in1 source, 20.09 Ext2 in2 source and 20.10 Ext2 in1 source, 20.09 Ext2 in2 source and 20.10 Ext2 in3 source. The state transitions of the source bits are interpreted as follows:  State of source 1 State of source 3 (20.09) (20.09) (20.10)  0 -> 1 Any 1 Start forward Any 0 -> 1 Start reverse Any Any 0 Stop  Note: The start signal is always edge-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.  Control panel  The start and stop commands are taken from the control panel.  Fieldbus A  The start and stop commands are taken from fieldbus adapter A.  Note: The start signal is always level-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.  Embedded fieldbus  The start and stop commands are taken from the embedded fieldbus interface.  Note: The start signal is always level-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.  Application Program  The start and stop commands are taken from the application program control word (parameter 06.02 Application control word).  Note: The start signal is always level-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.			source 1							
Any   0   Any   Stop				. ,		Start forward				
Notes:  • The start signal is always edge-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.  In1P Start fwd; In2P Start rev; In3 Stop  Start rev; In3 Stop  The sources of the start and stop commands are selected by parameters 20.08 Ext2 in1 source, 20.09 Ext2 in2 source and 20.10 Ext2 in3 source. The state transitions of the source bits are interpreted as follows:  State of source 1 source 2 (20.09) (20.10)  O > 1 Any 1 Start reverse Any 0 > 1 Stop  Note: The start signal is always edge-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.  Control panel The start and stop commands are taken from the control panel.  Fieldbus A The start signal is always level-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.  Embedded fieldbus  The start and stop commands are taken from the embedded fieldbus interface.  Note: The start signal is always level-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.  Application Program  The start and stop commands are taken from the application program control word (parameter 06.02 Application control word).  Note: The start signal is always level-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.			0 -> 1	1	1	Start reverse				
The start signal is always edge-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.  In1P Start fwd: In2P Start rev; In3 Stop  The sources of the start and stop commands are selected by parameters 20.08 Ext2 in1 source, 20.09 Ext2 in2 source and 20.10 Ext2 in3 source. The state transitions of the source bits are interpreted as follows:  State of source 1 (20.08) (20.09) (20.10)  O->1 Any 1 Start forward Any O->1 I Start reverse Any Any 0 Stop  Note: The start signal is always edge-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.  Control panel The start and stop commands are taken from the control panel.  Fieldbus A The start and stop commands are taken from fieldbus adapter A.  Note: The start signal is always level-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.  Embedded fieldbus  The start and stop commands are taken from the embedded fieldbus interface.  Note: The start signal is always level-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.  Application Program  The start and stop commands are taken from the application program control word (parameter 06.02 Application control word).  Note: The start signal is always level-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.			Any	0	Any	Stop				
by parameters 20.08 Ext2 in1 source, 20.09 Ext2 in2 source and 20.10 Ext2 in3 source. The state transitions of the source bits are interpreted as follows:    State of   State of   State of   Source 3   (20.08)   (20.09)   (20.10)		In1P Start fwd: In2P	The start setting retype.	egardless of p	parameter 20	07 Ext2 start tri		6		
Source 1 (20.08) (20.09) (20.10)   (20.10)		Start rev; In3 Stop by parameters 20.08 Ext2 in1 source, 20.09 Ext2 in2 source and 20.10 Ext2 in3 source. The state transitions of								
Any 0 -> 1 1 Start reverse Any Any 0 Stop  Note: The start signal is always edge-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.  Control panel The start and stop commands are taken from the control panel.  Fieldbus A The start and stop commands are taken from fieldbus adapter A.  Note: The start signal is always level-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.  Embedded fieldbus The start and stop commands are taken from the embedded fieldbus interface.  Note: The start signal is always level-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.  Application Program The start and stop commands are taken from the application program control word (parameter 06.02 Application control word).  Note: The start signal is always level-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.			source 1	source 2	source 3	Command				
Note: The start signal is always edge-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.  Control panel The start and stop commands are taken from the control panel.  Fieldbus A The start and stop commands are taken from fieldbus adapter A.  Note: The start signal is always level-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.  Embedded fieldbus The start and stop commands are taken from the embedded fieldbus interface.  Note: The start signal is always level-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.  Application Program The start and stop commands are taken from the application program control word (parameter 06.02 Application control word).  Note: The start signal is always level-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.				,		Start forward				
Note: The start signal is always edge-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.  Control panel The start and stop commands are taken from the control panel.  Fieldbus A The start and stop commands are taken from fieldbus adapter A.  Note: The start signal is always level-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.  Embedded fieldbus The start and stop commands are taken from the embedded fieldbus interface.  Note: The start signal is always level-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.  Application Program The start and stop commands are taken from the application program control word (parameter 06.02 Application control word).  Note: The start signal is always level-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.			Any	0 -> 1		Start reverse				
panel.  The start and stop commands are taken from fieldbus adapter A.  Note: The start signal is always level-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.  Embedded fieldbus  The start and stop commands are taken from the embedded fieldbus interface.  Note: The start signal is always level-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.  Application Program  The start and stop commands are taken from the application program control word (parameter 06.02 Application control word).  Note: The start signal is always level-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.			Note: The s	start signal is	always edge	triggered with th				
adapter A.  Note: The start signal is always level-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.  Embedded fieldbus  The start and stop commands are taken from the embedded fieldbus interface.  Note: The start signal is always level-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.  Application Program  The start and stop commands are taken from the application program control word (parameter 06.02 Application control word).  Note: The start signal is always level-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.		Control panel		nd stop comm	ands are tak	en from the con	trol	11		
embedded fieldbus interface.  Note: The start signal is always level-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.  Application Program  The start and stop commands are taken from the application program control word (parameter 06.02 Application control word).  Note: The start signal is always level-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.		Fieldbus A	adapter A. <b>Note</b> : The setting regard	The start and stop commands are taken from fieldbus adapter A.  Note: The start signal is always level-triggered with this setting regardless of parameter 20.07 Ext2 start trigger						
application program control word (parameter 06.02 Application control word).  Note: The start signal is always level-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.		Embedded fieldbus	embedded a Note: The setting regard	embedded fieldbus interface.  Note: The start signal is always level-triggered with this setting regardless of parameter 20.07 Ext2 start trigger						
ATF Reserved. 22		Application Program	application Application Note: The setting regard	program cont control word) start signal is	rol word (par always level-	ameter <i>06.02</i> triggered with th	nis er	21		
		ATF	Reserved.					22		

No.	Name/Value	Description	Def/ FbEq16
20.07	Ext2 start trigger type	Defines whether the start signal for external control location EXT2 is edge-triggered or level-triggered.  Note: This parameter is only effective when parameter 20.06 Ext2 commands is set to In1 Start, In1 Start; In2 Dir or In1 Start fwd; In2 Start rev, Control panel.	Edge
	Edge	The start signal is edge-triggered.	0
	Level	The start signal is level-triggered.	1
20.08	Ext2 in1 source	Selects source 1 for parameter 20.06 Ext2 commands. For the available selections, see parameter 20.03 Ext1 in1 source.	Not selected
20.09	Ext2 in2 source	Selects source 2 for parameter 20.06 Ext2 commands. For the available selections, see parameter 20.03 Ext1 in1 source.	Not selected
20.10	Ext2 in3 source	Selects source 3 for parameter 20.06 Ext2 commands. For the available selections, see parameter 20.03 Ext1 in1 source.	Not selected
20.11	Run enable stop mode	Selects the way the motor is stopped when the run enable signal switches off.  The source of the run enable signal is selected by parameter 20.12 Run enable 1 source.	Coast (95.20 b10)
	Coast	Stop by switching off the output semiconductors of the drive. The motor coasts to a stop.  WARNING! If a mechanical brake is used, ensure it is safe to stop the drive by coasting.	0
	Ramp	Stop along the active deceleration ramp. See parameter group 23 Speed reference ramp on page 231.	1
	Torque limit	Stop according to torque limits (parameters 30.19 and 30.20).	2
20.12	Run enable 1 source	Selects the source of the external run enable signal. If the run enable signal is switched off, the drive will not start. If already running, the drive will stop according to the setting of parameter 20.11 Run enable stop mode.  1 = Run enable signal on.  Note: The warning that indicates a missing signal can be suppressed using parameter 20.30 Enable signals warning function.  See also parameter 20.19 Enable start command.	DIIL (95.20 b10); Selected (95.20 b5); DI5 (95.20 b9);
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	FBA A MCW bit 3	Control word bit 3 received through fieldbus interface A.	30

No.	Name/Value	Description	Def/ FbEq16
	EFB MCW bit 3	Control word bit 3 received through the embedded fieldbus interface.	32
	DIIL	DIIL input (10.02 DI delayed status, bit 15).	33
	Active control source MCW bit 3	Control word bit 3 received from the active control source. In case the active source is the control panel, PC tool or drive I/O, the run enable signal is always on.  Notes:  If the drive is running, switching bit 3 off effectively removes both the start and run enable signals. In this case, the stop mode is determined by either 20.11 Run enable stop mode or 21.03 Stop mode, whichever mode has higher priority. The order of stop modes from highest to lowest priority is Coast – Torque limit – Ramp.  In case the active source is the control panel, PC tool or drive I/O, the run enable signal is always on.	34
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
20.19	Enable start command	Selects the source for the start enable signal.  1 = Start enable.  With the signal switched off, any drive start command is inhibited. (Switching the signal off while the drive is running will not stop the drive.)  Notes:  • If a level-triggered start command is on when the start enable signal switches on, the drive will start. (An edge-triggered start signal must be cycled for the drive to start.) See parameters 20.02 Ext1 start trigger type, 20.07 Ext2 start trigger type and 20.29 Local start trigger type.  • The warning that indicates a missing signal can be suppressed using parameter 20.30 Enable signals warning function.  See also parameter 20.12 Run enable 1 source.	Selected
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	DIIL	DIIL input (10.02 DI delayed status, bit 15).	30
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-

No.	Name/Value	Description	Def/ FbEq16
20.23	Positive speed enable	Selects the source of the positive speed enable command.  1 = Positive speed enabled.  0 = Positive speed interpreted as zero speed reference. In the figure below, 23.01 Speed ref ramp input is set to zero after the positive speed enable signal has cleared.  Actions in different control modes:  Speed control: Speed reference is set to zero and the motor ramps down along the currently active deceleration ramp. The drive keeps modulating. The rush controller prevents additional torque terms from running the motor in the positive direction.  Torque control: The rush controller monitors the rotation direction of the motor.	Selected
	20.23 Positive speed	enable	-
	20.24 Negative speed	d enable	
	23.01 Speed ref ramp 01.01 Motor speed us		-
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
20.24	Negative speed enable	Selects the source of the negative speed reference enable command. See parameter 20.23 Positive speed enable.	Selected

No.	Name/Value	Description	Def/ FbEq16
20.25	Jogging enable	Selects the source for a jog enable signal. (The sources for jogging activation signals are selected by parameters 20.26 Jogging 1 start source and 20.27 Jogging 2 start source.)  1 = Jogging is enabled. 0 = Jogging is disabled.  Note: Jogging can be enabled only when no start command from an external control location is active. On the other hand, if jogging is already enabled, the drive cannot be started from an external control location (apart from inching commands through fieldbus).  See section Jogging (page 78).	Not selected
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
20.26	Jogging 1 start source	If enabled by parameter 20.25 Jogging enable, selects the source for the activation of jogging function 1. (Jogging function 1 can also be activated through fieldbus regardless of parameter 20.25.)  1 = Jogging 1 active.  Note: If both jogging 1 and 2 are activated, the one that was activated first has priority.	Not selected
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-

No.	Name/Value	Descri	ntion		Def/
140.	Name/ Value	Descri	ption		FbEq16
20.27	Jogging 2 start source	If enabled by parameter 20.25 Jogging enable, selects the source for the activation of jogging function 2. (Jogging function 2 can also be activated through fieldbus regardless of parameter 20.25.)  1 = Jogging 2 active.  For the selections, see parameter 20.26 Jogging 1 start source.  Note: If both jogging 1 and 2 are activated, the one that was activated first has priority.			Not selected
20.29	Local start trigger type		e, control panel o	rt signal for local control (for or PC tool) is edge-triggered or	Edge
	Edge	The sta	rt signal is edge-	triggered.	0
	Level	The sta	rt signal is level-	triggered.	1
20.30	Enable signals warning function	Selects enable signal (for example, run enable, start enable) warnings to be suppressed. This parameter can be used to prevent these warnings from flooding the event log.  Whenever a bit of this parameter is set to 1, the corresponding warning is suppressed, that is no warning is generated even if the signal is switched off.  The bits of this binary number correspond to the following warnings:			00b
		Bit	Name	Warning	1
		0	Enable Start	AFEA Enable start signal missing	-
		1	Run enable 1	AFEB Run enable missing	
		215	Reserved		
	00b11b	Suppression of "enable signal missing" warnings.			1 = 1
21 Sta	rt/stop mode	source		mergency stop mode and signal agnetization settings; autophasing	
21.01	Start mode	Selects the motor start function for the DTC motor control mode, ie. when 99.04 Motor ctrl mode is set to DTC.  Notes:  The start function for the scalar motor control mode is selected by parameter 21.19 Scalar start mode.  Starting into a rotating motor is not possible when DC magnetizing is selected (Fast or Constant time).  With permanent magnet motors and synchronous reluctance motors, Automatic start mode must be used.  This parameter cannot be changed while the drive is running.  See also section DC magnetization (page 86).			Automatic
	Fast	magnet typically	izing time is dete v 200 ms to 2 s d hould be selecte	es the motor before start. The pre- emined automatically, being depending on motor size. This d if a high break-away torque is	0

No.	Name/Value	Description		Def/ FbEq16
	Constant time	The drive pre-magnetizes magnetizing time is definage in the secondary and the secondary the seconda	1	
	Automatic	Automatic start guarantee cases. It includes the flyir rotating motor) and the ai stopped motor can be reswaiting the motor flux to diprogram identifies the flux of the motor and starts the conditions.	2	
	Flying start	and is optimized for appli	or asynchronous motors only, cations where the drive must be tor at high frequencies (above	3
21.02	Magnetization time	Defines the pre-magnetiz  parameter 21.01 Start DTC motor control mo parameter 21.19 Scala (in scalar motor control After the start command, premagnetizes the motor magnetizing, set this para higher than, the rotor time rule-of-thumb value giver	500 ms	
		Motor rated power	Constant magnetizing time	
		< 1 kW	≥ 50 to 100 ms	
		1 to 10 kW	≥ 100 to 200 ms	
		10 to 200 kW	≥ 200 to 1000 ms	
		200 to 1000 kW	≥ 1000 to 2000 ms	
		<b>Note:</b> This parameter car running.	nnot be changed while the drive is	
	010000 ms	Constant DC magnetizing	g time.	1 = 1 ms
21.03	Stop mode	Selects the way the moto command is received. Additional braking is poss parameter 97.05 Flux bra	Ramp	
	Coast	Stop by switching off the drive. The motor coasts to WARNING! If a miss safe to stop the	0	

No.	Name/Value	Description	Def/ FbEq16
	Ramp	Stop along the active deceleration ramp. See parameter group 23 Speed reference ramp on page 231.	1
	Torque limit	Stop according to torque limits (parameters 30.19 and 30.20).	2
21.04	Emergency stop mode	Selects the way the motor is stopped when an emergency stop command is received.  The source of the emergency stop signal is selected by parameter 21.05 Emergency stop source.	Ramp stop (Off1); Coast stop (Off2) (95.20 b1); Eme ramp stop (Off3) (95.20 b2)
	Ramp stop (Off1)	With the drive running:  1 = Normal operation.  0 = Normal stop along the standard deceleration ramp defined for the particular reference type (see section Reference ramping [page 63]). After the drive has stopped, it can be restarted by removing the emergency stop signal and switching the start signal from 0 to 1.  With the drive stopped:  1 = Starting allowed.  Starting not allowed.	0
	Coast stop (Off2)	With the drive running:  1 = Normal operation.  0 = Stop by coasting. The drive can be restarted by restoring the start interlock signal and switching the start signal from 0 to 1.  With the drive stopped:  1 = Starting allowed.  0 = Starting not allowed.	1
	Eme ramp stop (Off3)	With the drive running:  1 = Normal operation.  0 = Stop by ramping along emergency stop ramp defined by parameter 23.23 Emergency stop time. After the drive has stopped, it can be restarted by removing the emergency stop signal and switching the start signal from 0 to 1.  With the drive stopped:  1 = Starting allowed.  0 = Starting not allowed.	2
21.05	Emergency stop source	Selects the source of the emergency stop signal. The stop mode is selected by parameter 21.04 Emergency stop mode.  0 = Emergency stop active 1 = Normal operation  Note: This parameter cannot be changed while the drive is running.	Inactive (true); DI4 (95.20 b1, 95.20 b2)
	Active (false)	0.	0
	Inactive (true)	1.	1
	DIIL	DIIL input (10.02 DI delayed status, bit 15).	2
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	3
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	4
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	5

## 218 Parameters

No.	Name/Value	Description	Def/ FbEq16
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	6
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	7
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	8
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	11
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	12
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
21.06	Zero speed limit	Defines the zero speed limit. The motor is stopped along a speed ramp (when ramped stop is selected) until the defined zero speed limit is reached. After the zero speed delay, the motor coasts to a stop.	30.00 rpm
	0.0030000.00 rpm	Zero speed limit.	See par. 46.01

No.	Name/Value	Description	Def/ FbEq16
21.07	Zero speed delay	Defines the delay for the zero speed delay function. The function is useful in applications where a smooth and quick restarting is essential. During the delay, the drive knows the rotor position accurately.	0 ms
		Without zero speed delay: The drive receives a stop command and decelerates along a ramp. When actual motor speed falls below the value of parameter 21.06 Zero speed limit, inverter modulation is stopped and the motor coasts to a standstill.	
		Speed controller switched off:  Motor coasts to a stop.  21.06 Zero speed limit  Time	
		With zero speed delay: The drive receives a stop command and decelerates along a ramp. When actual motor speed falls below the value of parameter 21.06 Zero speed limit, the zero speed delay function activates. During the delay the function keeps the speed controller live: the inverter modulates, motor is magnetized and the drive is ready for a quick restart.	
		Speed Speed controller remains active. Motor is decelerated to true zero speed.	
		Delay Time	
	030000 ms	Zero speed delay.	1 = 1 ms

No.	Name/Value	Description	Def/ FbEq16
21.08	DC current control	Activates/deactivates the DC hold and post-magnetization functions. See section DC magnetization (page 86).  Notes:  These functions are only available in speed control in DTC motor control mode (see page 56).  DC magnetization causes the motor to heat up. In applications where long DC magnetization times are required, externally ventilated motors should be used. If the DC magnetization period is long, DC magnetization cannot prevent the motor shaft from rotating if a constant load is applied to the motor.	0000Ь
	Note: 1 1 1 = En	able DC hold. See section DC hold (page 87).  The DC hold function has no effect if the start signal is switch able post-magnetization. See section Post-magnetization (page 25).	age 87).
		Post-magnetization is only available when ramping is the sele (see parameter 21.03 Stop mode). ved	ected stop
	0000b0011b	DC magnetization selection.	1 = 1
21.09	DC hold speed	Defines the DC hold speed. See parameter 21.08 DC current control, and section DC hold (page 87).	5.00 rpm
	0.001000.00 rpm	DC hold speed.	See par. 46.01
21.10	DC current reference	Defines the DC hold current in percent of the motor nominal current. See parameter 21.08 DC current control, and section DC magnetization (page 86).	30.0%
	0.0100.0%	DC hold current.	1 = 1%
21.11	Post magnetization time	Defines the length of time for which post-magnetization is active after stopping the motor. The magnetization current is defined by parameter 21.10 DC current reference. See parameter 21.08 DC current control.	0 s
	03000 s	Post-magnetization time.	1 = 1 s

No.	Name/Value	Description	Def/ FbEq16
21.12	Continuous magnetization command	Activates/deactivates (or selects a source that activates/deactivates) continuous magnetization. See section Continuous magnetization (page 88).  The magnetization current is calculated on the basis of flux reference (see parameter group 97 Motor control).  Notes:  This function is only available when ramping is the selected stop mode (see parameter 21.03 Stop mode), and only in speed control in DTC motor control mode (see page 56).  Continuous magnetization causes the motor to heat up. In applications where long magnetization times are required, externally ventilated motors should be used.  Continuous magnetization may not be able to prevent the motor shaft from rotating during a long period if a constant load is applied to the motor.  Normal operation  Magnetization active	Off
	Off	0.	0
	On	1.	1
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
21.13	Autophasing mode	Selects the way autophasing is performed. See section <i>Autophasing</i> on page <i>82</i> . <b>Note:</b> This parameter cannot be changed while the drive is running.	Turning
	Turning	This mode gives the most accurate autophasing result. This mode can be used, and is recommended, if the motor is allowed to rotate and the start-up is not time-critical. Note: This mode will cause the motor to rotate. The load torque must be less than 5%.	0
	Standstill 1	Faster than the <i>Turning</i> mode, but not as accurate. The motor will not rotate.	1
	Standstill 2	An alternative standstill autophasing mode that can be used if the <i>Turning</i> mode cannot be used, and the <i>Standstill 1</i> mode gives erratic results. However, this mode is considerably slower than <i>Standstill 1</i> .	2
	Turning with Z-pulse	This mode should be used if the zero pulse signal of the pulse encoder is to be observed, and other modes do not give a result. The motor will turn until a zero pulse is detected.	3

No.	Name/Value	Description	Def/ FbEq16
21.14	Pre-heating input source	Selects the source of the motor pre-heat on/off command. See section <i>Pre-heating</i> (page 86).  Note: The pre-heating function will not activate if  • the Safe torque off function is active,  • a fault is active,  • less than one minute has elapsed after stopping, or  • PID sleep function is active.  Pre-heating is deactivated when the drive is started, and overridden by pre-magnetization, post-magnetization or continuous magnetization.  0 = Pre-heating inactive  1 = Pre-heating active	Off
	Off	Pre-heating is always deactivated.	0
	On	Pre-heating is always activated when the drive is stopped (apart from conditions stated above).	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	Supervision 1	Supervision 1 active (32.01 Supervision status, bit 0).	8
	Supervision 2	Supervision 2 active (32.01 Supervision status, bit 1).	9
	Supervision 3	Supervision 3 active (32.01 Supervision status, bit 2).	10
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
21.16	Pre-heating current	Defines the motor pre-heating current that is fed into the motor when the source selected by 21.14 Pre-heating input source is on. The value is in percent of the nominal motor current.	0.0%
	0.0 30.0%	Pre-heating current.	1 = 1%
21.18	Auto restart time	The motor can be automatically started after a short supply power failure using the automatic restart function. See section <i>Automatic restart</i> (page 91).  When this parameter is set to 0.0 seconds, automatic restarting is disabled. Otherwise, the parameter defines the maximum duration of the power failure after which restarting is attempted. Note that this time also includes the DC pre-charging delay.	5.0 s
		WARNING! The function restarts the drive automatically and continues operation after a supply break. Make sure that no dangerous situations can occur.	
	0.0 s	Automatic restarting disabled.	0
	0.15.0 s	Maximum power failure duration.	1 = 1 s

No. Name/Value	Description	Def/ FbEq16
21.19 Scalar start mode	Selects the motor start function for the scalar motor control mode, ie. when 99.04 Motor ctrl mode is set to Scalar.  Notes:  The start function for the DTC motor control mode is selected by parameter 21.01 Start mode.  With permanent magnet motors, Automatic start mode must be used.  This parameter cannot be changed while the drive is running.  See also section DC magnetization (page 86).	Nomal
Normal	Immediate start from zero speed.	0
Const time	The drive pre-magnetizes the motor before start. The pre-magnetizing time is defined by parameter 21.02 Magnetization time. This mode should be selected if constant pre-magnetizing time is required. This setting also guarantees the highest possible break-away torque when the pre-magnetizing time is set long enough.  Note: This mode cannot be used to start into a rotating motor.  WARNING! The drive starts after the set magnetizing time has passed even if motor magnetization is not completed. In applications where a full break-away torque is essential, ensure that the constant magnetizing time is long enough to allow generation of full magnetization and torque.	1
Automatic	This setting should be used in applications where flying starts (ie. starting into a rotating motor) are required.	2
22 Speed reference selection	Speed reference selection settings; motor potentiometer settings.  See the control chain diagrams on pages 564565.	
22.01 Speed ref unlimited	Displays the output of the speed reference selection block. See the control chain diagram on page 565. This parameter is read-only.	-
-30000.00 30000.00 rpm	Value of the selected speed reference.	See par. 46.01

No.	Name/Value	Description	Def/ FbEq16
22.11	Speed ref1 source	Selects speed reference source 1.  Two signal sources can be defined by this parameter and 22.12 Speed ref2 source. A digital source selected by 22.14 Speed ref1/2 selection can be used to switch between the two sources, or a mathematical function (22.13 Speed ref1 function) applied to the two signals to create the reference.	Par 09.06 (Other)
	0	22.13  Ref1  ADD  SUB  MUL  22.14  0  22.14	2.83
	Zero	None.	0
	Al1 scaled	12.12 Al1 scaled value (see page 169).	1
	Al2 scaled	12.22 Al2 scaled value (see page 170).	2
	FB A ref1	03.05 FB A reference 1 (see page 126).	4
	FB A ref2	03.06 FB A reference 2 (see page 126).	5
	EFB ref1	03.09 EFB reference 1 (see page 126).	8
	EFB ref2	03.10 EFB reference 2 (see page 126).	9
	Motor potentiometer	22.80 Motor potentiometer ref act (output of the motor potentiometer).	15
	Control panel (ref saved)	Control panel reference, with initial value from previous source or actual value. See section <i>Using the control panel</i> as an external control source (page 55).	
	Control panel (ref copied)	Control panel reference, with initial value from previous source or actual value. See section <i>Using the control panel</i> as an external control source (page 55).	
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
22.12	Speed ref2 source	Selects speed reference source 2. For the selections, and a diagram of reference source selection, see parameter 22.11 Speed ref1 source.	Zero
22.13	Speed ref1 function	Selects a mathematical function between the reference sources selected by parameters 22.11 Speed ref1 source and 22.12 Speed ref2 source. See diagram at 22.11 Speed ref1 source.	Ref1
	Ref1	Signal selected by 22.11 Speed ref1 source is used as speed reference 1 as such (no function applied).	0
	Add (ref1 + ref2)	The sum of the reference sources is used as speed reference 1.	1

No.	Name/Value	Description	Def/ FbEq16
	Sub (ref1 - ref2)	The subtraction ([22.11 Speed ref1 source] - [22.12 Speed ref2 source]) of the reference sources is used as speed reference 1.	2
	Mul (ref1 × ref2)	The multiplication of the reference sources is used as speed reference 1.	3
	Min (ref1, ref2)	The smaller of the reference sources is used as speed reference 1.	4
	Max (ref1, ref2)	The greater of the reference sources is used as speed reference 1.	5
22.14	Speed ref1/2 selection	Configures the selection between speed references 1 and 2. See diagram at 22.11 Speed ref1 source.  0 = Speed reference 1 1 = Speed reference 2	Follow Ext1/Ext2 selection
	Speed reference 1	0.	0
	Speed reference 2	1.	1
	Follow Ext1/Ext2 selection	Speed reference 1 is used when external control location EXT1 is active. Speed reference 2 is used when external control location EXT2 is active.  See also parameter 19.11 Ext1/Ext2 selection.	2
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	3
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	4
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	5
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	6
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	7
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	8
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	11
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	12
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
22.15	Speed additive 1 source	Defines a reference to be added to the speed reference after reference selection (see page 564). For the selections, see parameter 22.11 Speed ref1 source. Note: For safety reasons, the additive is not applied when any of the stop functions are active.	Zero
22.16	Speed share	Defines a scaling factor for the selected speed reference (speed reference 1 or 2, multiplied by the defined value). Speed reference 1 or 2 is selected by parameter 22.14 Speed ref1/2 selection.	1.000
	-8.0008.000	Speed reference scaling factor.	1000 = 1
22.17	Speed additive 2 source	Defines a reference to be added to the speed reference after the speed share function (see page 564). For the selections, see parameter 22.11 Speed ref1 source.  Note: For safety reasons, the additive is not applied when any of the stop functions are active.	Zero

No.	Name/	Value	lue Description			Def/ FbEq	16
22.21	Consta function	nt speed า	Determines how cor whether the rotation when applying a cor	direction signal is		0000b	
	Bit	Name	Information				
	0	Constant spee	ed 1 = Packed: 7 con defined by parame	nstant speeds are seters 22.22, 22.23		hree so	urces
			the sources define	ed by parameters 2	and 3 are separately 22.22, 22.23 and 22.2 and with the smaller nu	4 respe	ctively.
	1 Direction enable  1 = Start dir: To determine running direction for a sign of the constant speed setting (parameters 2 multiplied by the direction signal (forward: +1, re effectively allows the drive to have 14 (7 forward speeds if all values in 22.2622.32 are positive  WARNING: If the direction signal is revered constant speed is negative, the drive will direction.  0 = Accord Par: The running direction for the condetermined by the sign of the constant speed setting the sign of	parameters 22.262; ward: +1, reverse: -1 4 (7 forward, 7 reversare positive. gnal is reverse and the drive will run in the	2.32) is ). This se) cons ne active e forwar eed is	e rd			
	22.2622.32). 215 Reserved						
	0000b.	0011b	Constant speed con	figuration word.		1 = 1	
22.22	Consta	nt speed sel1	When bit 0 of param 0 (Separate), select speed 1. When bit 0 of param 1 (Packed), this para Constant speed select three sources speeds as follows:	s a source that act neter 22.21 Consta ameter and param 2 and 22.24 Consta	ivates constant  nt speed function is eters 22.23 ant speed sel3	Not se	elected
		Source define		Source defined by par. 22.24	Constant speed a	ctive	
		0	0	0	None		
		1	0	0	Constant speed	l 1	
		0	1	0	Constant speed	12	
		1	1	0	Constant speed		
		0	0	1	Constant speed		
		1	0	1	Constant speed		
		0	1	1	Constant speed		
		1	1	1	Constant speed	17	
	Not selected Selected		0 (always off). 1 (always on).		0		
	Selecte		, , ,			1	
	Selecte DI1		, , ,	.02 DI delayed sta	<i>tus</i> , bit 0).	1 2	
			1 (always on).		<u> </u>		

No.	Name/Value	Description	Def/ FbEq16
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
22.23	Constant speed sel2	When bit 0 of parameter 22.21 Constant speed function is 0 (Separate), selects a source that activates constant speed 2. When bit 0 of parameter 22.21 Constant speed function is 1 (Packed), this parameter and parameters 22.22 Constant speed sel1 and 22.24 Constant speed sel3 select three sources that are used to activate constant speeds. See table at parameter 22.22 Constant speed sel1. For the selections, see parameter 22.22 Constant speed sel1. When bit 0 of parameter 22.21 Constant speed function is	Not selected
22.24	Constant speed sel3	When bit 0 of parameter 22.21 Constant speed function is 0 (Separate), selects a source that activates constant speed 3. When bit 0 of parameter 22.21 Constant speed function is 1 (Packed), this parameter and parameters 22.22 Constant speed sel1 and 22.23 Constant speed sel2 select three sources that are used to activate constant speeds. See table at parameter 22.22 Constant speed sel1. For the selections, see parameter 22.22 Constant speed sel1.	Not selected
22.26	Constant speed 1	Defines constant speed 1 (the speed the motor will turn when constant speed 1 is selected).	300.00 rpm
	-30000.00 30000.00 rpm	Constant speed 1.	See par. 46.01
22.27	Constant speed 2	Defines constant speed 2.	0.00 rpm
	-30000.00 30000.00 rpm	Constant speed 2.	See par. 46.01
22.28	Constant speed 3	Defines constant speed 3.	0.00 rpm
	-30000.00 30000.00 rpm	Constant speed 3.	See par. 46.01
22.29	Constant speed 4	Defines constant speed 4.	0.00 rpm
	-30000.00 30000.00 rpm	Constant speed 4.	See par. 46.01
22.30	Constant speed 5	Defines constant speed 5.	0.00 rpm
	-30000.00 30000.00 rpm	Constant speed 5.	See par. 46.01
22.31	Constant speed 6	Defines constant speed 6.	0.00 rpm
	-30000.00 30000.00 rpm	Constant speed 6.	See par. 46.01

No.	Name/Value		Description		Def/ FbEq16
22.32	Constant speed 7	7	Defines constar	nt speed 7.	0.00 rpm
	-30000.00 30000.00 rpm		Constant speed	17.	See par. 46.01
22.41	Speed ref safe		<ul> <li>supervision fun</li> <li>12.03 AI sup</li> <li>49.05 Comm</li> <li>50.02 FBA A</li> <li>50.32 FBA B</li> </ul>	speed reference value that is used with ctions such as vervision function nunication loss action comm loss func a comm loss func acomm loss func nunication loss action.	0.00 rpm
	-30000.00 30000.00 rpm		Safe speed refe	erence.	See par. 46.01
22.42	Jogging 1 ref		Defines the spe	eed reference for jogging function 1.	0.00 rpm
	-30000.00 30000.00 rpm		Speed reference	e for jogging function 1.	See par. 46.01
22.43	Jogging 2 ref		Defines the spe	eed reference for jogging function 2.	0.00 rpm
	-30000.00 30000.00 rpm		Speed reference	e for jogging function 2.	See par. 46.01
	Critical speed function		determines who both rotating di See also sectio	n Critical speeds/frequencies (page 65).	
		Bit	Name	Information	
		0	Enable	1 = Enable: Critical speeds enabled. 0 = Disable: Critical speeds disabled.	
		21	Sign mode	Signed: The signs of parameters     22.5222.57 are taken into account.     O = Absolute: Parameters 22.5222.57 are handled as absolute values. Each range is effective in both directions of rotation.	
	0000b0011b		•	configuration word.	1 = 1
22.52	Critical speed 1 lo	ritical speed 1 low Defines the low limit for critical sp. Note: This value must be less tha 22.53 Critical speed 1 high.		e must be less than or equal to the value of	0.00 rpm
	-30000.00 30000.00 rpm		Low limit for crit	tical speed 1.	See par. 46.01
22.53	Critical speed 1 h	nigh	•	h limit for critical speed range 1. e must be greater than or equal to the value I speed 1 low.	0.00 rpm
	-30000.00 30000.00 rpm		High limit for cri	itical speed 1.	See par. 46.01

No.	Name/Value	Description	Def/ FbEq16
22.54	Critical speed 2 low	Defines the low limit for critical speed range 2.  Note: This value must be less than or equal to the value of 22.55 Critical speed 2 high.	0.00 rpm
	-30000.00 30000.00 rpm	Low limit for critical speed 2.	See par. 46.01
22.55	Critical speed 2 high	Defines the high limit for critical speed range 2.  Note: This value must be greater than or equal to the value of 22.54 Critical speed 2 low.	0.00 rpm
	-30000.00 30000.00 rpm	High limit for critical speed 2.	See par. 46.01
22.56	Critical speed 3 low	Defines the low limit for critical speed range 3.  Note: This value must be less than or equal to the value of 22.57 Critical speed 3 high.	0.00 rpm
	-30000.00 30000.00 rpm	Low limit for critical speed 3.	See par. 46.01
22.57	Critical speed 3 high	Defines the high limit for critical speed range 3.  Note: This value must be greater than or equal to the value of 22.56 Critical speed 3 low.	0.00 rpm
	-30000.00 30000.00 rpm	High limit for critical speed 3.	See par. 46.01
22.71	Motor potentiometer function	Activates and selects the mode of the motor potentiometer. See section <i>Motor potentiometer</i> (page 89).	Disabled
	Disabled	Motor potentiometer is disabled and its value set to 0.	0
	Enabled (init at stop/power-up)	When enabled, the motor potentiometer first adopts the value defined by parameter 22.72 Motor potentiometer initial value. When the drive is running, the value can be adjusted from the up and down sources defined by parameters 22.73 Motor potentiometer up source and 22.74 Motor potentiometer down source.  A stop or a power cycle will reset the motor potentiometer to the initial value (22.72).	1
	Enabled (resume always)	As Enabled (init at stop/power-up), but the motor potentiometer value is retained over a stop or a power cycle.	2
22.72	Motor potentiometer initial value	Defines an initial value (starting point) for the motor potentiometer. See the selections of parameter 22.71 Motor potentiometer function.	0.00
	-32768.00 32767.00	Initial value for motor potentiometer.	1 = 1
22.73	Motor potentiometer up source	Selects the source of motor potentiometer up signal.  0 = No change 1 = Increase motor potentiometer value. (If both the up and down sources are on, the potentiometer value will not change.)	Not selected
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4

No.	Name/Value	Description	Def/ FbEq16
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
22.74	Motor potentiometer down source	Selects the source of motor potentiometer down signal.  0 = No change  1 = Decrease motor potentiometer value. (If both the up and down sources are on, the potentiometer value will not change.)  For the selections, see parameter 22.73 Motor potentiometer up source.	Not selected
22.75	Motor potentiometer ramp time	Defines the change rate of the motor potentiometer. This parameter specifies the time required for the motor potentiometer to change from minimum (22.76) to maximum (22.77). The same change rate applies in both directions.	60.0 s
	0.0 3600.0 s	Motor potentiometer change time.	10 = 1 s
22.76	Motor potentiometer min value	Defines the minimum value of the motor potentiometer.	-1500.00
	-32768.00 32767.00	Motor potentiometer minimum.	1 = 1
22.77	Motor potentiometer max value	Defines the maximum value of the motor potentiometer.	1500.00
	-32768.00 32767.00	Motor potentiometer maximum.	1 = 1
22.80	Motor potentiometer ref act	Displays the output of the motor potentiometer function. (The motor potentiometer is configured using parameters 22.7122.74.) This parameter is read-only.	-
	-32768.00 32767.00	Value of motor potentiometer.	1 = 1
22.81	Speed reference act 1	Displays the value of speed reference source 1 (selected by parameter 22.11 Speed ref1 source). See the control chain diagram on page 564.  This parameter is read-only.	-
	-30000.00 30000.00 rpm	Value of reference source 1.	See par. 46.01
22.82	Speed reference act 2	Displays the value of speed reference source 2 (selected by parameter 22.12 Speed ref2 source). See the control chain diagram on page 564.  This parameter is read-only.	-
	-30000.00 30000.00 rpm	Value of reference source 2.	See par. 46.01

No.	Name/Value	Description	Def/ FbEq16
22.83	Speed reference act 3	Displays the value of speed reference after the mathematical function applied by parameter 22.13 Speed ref1 function and reference 1/2 selection (22.14 Speed ref1/2 selection). See the control chain diagram on page 564.  This parameter is read-only.	-
	-30000.00 30000.00 rpm	Speed reference after source selection.	See par. 46.01
22.84	Speed reference act 4	Displays the value of speed reference after application of 1st speed additive (22.15 Speed additive 1 source). See the control chain diagram on page 564.  This parameter is read-only.	-
	-30000.00 30000.00 rpm	Speed reference after additive 1.	See par. 46.01
22.85	Speed reference act 5	Displays the value of speed reference after the application of the speed share scaling factor (22.16 Speed share). See the control chain diagram on page 564.  This parameter is read-only.	-
	-30000.00 30000.00 rpm	Speed reference after speed share scaling.	See par. 46.01
22.86	Speed reference act 6	Displays the value of speed reference after application of 2nd speed additive (22.17 Speed additive 2 source). See the control chain diagram on page 564.  This parameter is read-only.	-
	-30000.00 30000.00 rpm	Speed reference after additive 2.	See par. 46.01
22.87	Speed reference act 7	Displays the value of speed reference before application of critical speeds. See the control chain diagram on page 565.  The value is received from 22.86 Speed reference act 6 unless overridden by  • any constant speed  • a jogging reference  • network control reference  • control panel reference  • safe speed reference.  This parameter is read-only.	-
	-30000.00 30000.00 rpm	Speed reference before application of critical speeds.	See par. 46.01
23 Sp	eed reference ramp	Speed reference ramp settings (programming of the acceleration and deceleration rates for the drive).  See the control chain diagram on page 565.	
23.01	Speed ref ramp input	Displays the used speed reference (in rpm) before it enters the ramping and shaping functions. See the control chain diagram on page 565.  This parameter is read-only.	-
	-30000.00 30000.00 rpm	Speed reference before ramping and shaping.	See par. 46.01

No.	Name/Value	Description	Def/ FbEq16
23.02	Speed ref ramp output	Displays the ramped and shaped speed reference in rpm. See the control chain diagram on page 565. This parameter is read-only.	-
	-30000.00 30000.00 rpm	Speed reference after ramping and shaping.	See par. 46.01
23.11	Ramp set selection	Selects the source that switches between the two sets of acceleration/deceleration ramp times defined by parameters 23.1223.15.  0 = Acceleration time 1 and deceleration time 1 are active 1 = Acceleration time 2 and deceleration time 2 are active	DI4; Acc/Dec time 2 (95.20 b1)
	Acc/Dec time 1	0.	0
	Acc/Dec time 2	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
23.12	Acceleration time 1	Defines acceleration time 1 as the time required for the speed to change from zero to the speed defined by parameter 46.01 Speed scaling (not to parameter 30.12 Maximum speed).  If the speed reference increases faster than the set acceleration rate, the motor speed will follow the acceleration rate.  If the speed reference increases slower than the set acceleration rate, the motor speed will follow the reference.  If the acceleration time is set too short, the drive will automatically prolong the acceleration in order not to exceed the drive torque limits.	20.000 s
	0.0001800.000 s	Acceleration time 1.	10 = 1 s

No.	Name/Value	Description	Def/ FbEq16
23.13	Deceleration time 1	Defines deceleration time 1 as the time required for the speed to change from the speed defined by parameter 46.01 Speed scaling (not from parameter 30.12 Maximum speed) to zero. If the speed reference decreases slower than the set deceleration rate, the motor speed will follow the reference. If the reference changes faster than the set deceleration rate, the motor speed will follow the deceleration rate. If the deceleration rate is set too short, the drive will automatically prolong the deceleration in order not to exceed drive torque limits (or not to exceed a safe DC link voltage). If there is any doubt about the deceleration time being too short, ensure that DC overvoltage control is on (parameter 30.30 Overvoltage control).  Note: If a short deceleration time is needed for a high inertia application, the drive should be equipped with braking equipment such as a brake chopper and brake resistor.	20.000 s
	0.0001800.000 s	Deceleration time 1.	10 = 1 s
23.14	Acceleration time 2	Defines acceleration time 2. See parameter 23.12 Acceleration time 1.	60.000 s
	0.0001800.000 s	Acceleration time 2.	10 = 1 s
23.15	Deceleration time 2	Defines deceleration time 2. See parameter 23.13  Deceleration time 1.	60.000 s
	0.0001800.000 s	Deceleration time 2.	10 = 1 s

No.	Name/Value	Description	Def/ FbEq16
23.16	Shape time acc 1	Defines the shape of the acceleration ramp at the beginning of the acceleration.  0.000 s: Linear ramp. Suitable for steady acceleration or deceleration and for slow ramps.  0.0011000.000 s: S-curve ramp. S-curve ramps are ideal for lifting applications. The S-curve consists of symmetrical curves at both ends of the ramp and a linear part in between.  Acceleration:	0.000 s
		Linear ramp: 23.17 = 0 s  Shape time  23.16 = 0 s  S-curve ramp: 23.17 > 0 s  S-curve ramp: 23.16 > 0 s  Time	
		Deceleration:	
		Speed  S-curve ramp: 23.18 > 0 s  Linear ramp: 23.19 > 0 s  Linear ramp: 23.19 = 0 s  Time	
	0.0001800.000 s	Ramp shape at start of acceleration.	10 = 1 s
23.17	Shape time acc 2	Defines the shape of the acceleration ramp at the end of the acceleration. See parameter 23.16 Shape time acc 1.	0.000 s
	0.0001800.000 s	Ramp shape at end of acceleration.	10 = 1 s
23.18	Shape time dec 1	Defines the shape of the deceleration ramp at the beginning of the deceleration. See parameter 23.16 Shape time acc 1.	0.000 s
	0.0001800.000 s	Ramp shape at start of deceleration.	10 = 1 s

No. Name/Value		Description	Def/ FbEq16
23.19	Shape time dec 2	Defines the shape of the deceleration ramp at the end of the deceleration. See parameter 23.16 Shape time acc 1.	0.000 s
	0.0001800.000 s	Ramp shape at end of deceleration.	10 = 1 s
23.20	Acc time jogging	Defines the acceleration time for the jogging function i.e. the time required for the speed to change from zero to the speed value defined by parameter 46.01 Speed scaling.	60.000 s
	0.0001800.000 s	Acceleration time for jogging.	10 = 1 s
23.21	Dec time jogging	Defines the deceleration time for the jogging function i.e. the time required for the speed to change from the speed value defined by parameter <i>46.01 Speed scaling</i> to zero.	60.000 s
	0.0001800.000 s	Deceleration time for jogging.	10 = 1 s
23.23	Emergency stop time	In speed control mode, this parameter defines the deceleration rate for emergency stop Off3 as the time it would take for the speed to decrease from the value of parameter 46.01 Speed scaling to zero. This also applies to torque control (if present) because the drive switches to speed control on receiving an emergency stop Off3 command.  In frequency control mode, this parameter specifies the time it would take for the frequency to decrease from the value of 46.02 Frequency scaling to zero.  The emergency stop mode and activation source are selected by parameters 21.04 Emergency stop mode and 21.05 Emergency stop source respectively. Emergency stop can also be activated through fieldbus.  Note: Emergency stop Off1 uses the standard deceleration ramp as defined by parameters 23.1123.19 (speed control) or 28.7128.75 (frequency control).	3.000 s
	0.0001800.000 s	Emergency stop Off3 deceleration time.	10 = 1 s
23.24	Speed ramp in zero source	Selects a source that forces the speed reference to zero just before it enters the ramp function.  0 = Force speed reference to zero before the ramp function  1 = Speed reference continues towards the ramp function as normal	Inactive
	Active	0.	0
	Inactive	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-

No.	Name/Value	Description	Def/ FbEq16
23.26	Ramp out balancing enable	Selects the source for enabling/disabling speed reference ramp balancing.  This function is used to generate a smooth transfer from a torque- or tension-controlled motor back to being speed-controlled. The balancing output would be tracking the present "line" speed of the application and when transfer is required, the speed reference can then be quickly "seeded" to the correct line speed. Balancing is also possible in the speed controller, see parameter 25.09 Speed ctrl balancing enable.  See also parameter 23.27 Ramp out balancing ref.  0 = Disabled  1 = Enabled	Application program
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Application program	The start and stop commands are taken from the application program control word (parameter 06.02 Application control word).  Note: The start signal is always level-triggered with this setting regardless of parameter 20.02 Ext1 start trigger type.	21
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
23.27	Ramp out balancing ref	Defines the reference for speed ramp balancing. The output of the ramp generator is forced to this value when balancing is enabled by parameter 23.26 Ramp out balancing enable.	0.00 rpm
	-30000.00 30000.00 rpm	Speed ramp balancing reference.	See par. 46.01

No.	Name/Value	Description	Def/ FbEq16
23.28	Variable slope enable	Activates the variable slope function, which controls the slope of the speed ramp during a speed reference change. This allows for a constantly variable ramp rate to be generated, instead of just the standard two ramps normally available.  If the update interval of the signal from an external control system and the variable slope rate (23.29 Variable slope rate) are equal, the resulting speed reference (23.02 Speed ref ramp output) is a straight line.  Speed reference  Speed reference  Time  t = update interval of signal from external control system A = speed reference change during t	Off
	Off	Variable slope disabled.	0
	On	Variable slope enabled (not available in local control).	1
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
23.29	Variable slope rate	Defines the rate of the speed reference change when variable slope is enabled by parameter 23.28 Variable slope enable.  For the best result, enter the reference update interval into this parameter.	50 ms
	230000 ms	Variable slope rate.	1 = 1 ms
23.39	Follower speed correction out	Displays the speed correction term for the load share function with a speed-controlled follower drive.  See section <i>Motor control</i> (page 63).  This parameter is read-only.	-
	-30000.00 30000.00 rpm	Speed correction term.	See par. 46.01
23.40	Follower speed correction enable	With a speed-controlled follower, selects the source for enabling/disabling the load share function.  See section <i>Motor control</i> (page 63).  0 = Disabled  1 = Enabled	Not selected
	Not selected	0.	0
	Selected	1.	1

No.	Name/Value	Description	Def/ FbEq16
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
23.41	Follower speed correction gain	Adjusts the gain of the speed correction term in a speed-controlled follower. In effect, defines how accurately the follower follows the master torque. A greater value results in a more accurate performance.  See section <i>Motor control</i> (page 63).	1.00%
	0.00100.00%	Speed correction term adjustment.	1 = 1%
23.42	Follower speed corr torq source	Selects the source of the torque reference for the load share function.	MF ref 2
	NULL	None.	0
	MF ref 2	-	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
	eed reference nditioning	Speed error calculation; speed error window control configuration; speed error step.  See the control chain diagrams on pages 570 and 572.	
24.01	Used speed reference	Displays the ramped and corrected speed reference (before speed error calculation). See the control chain diagram on page 570.  This parameter is read-only.	-
	-30000.00 30000.00 rpm	Speed reference used for speed error calculation.	See par. 46.01
24.02	Used speed feedback	Displays the speed feedback used for speed error calculation. See the control chain diagram on page 570. This parameter is read-only.	-
	-30000.00 30000.00 rpm	Speed feedback used for speed error calculation.	See par. 46.01
24.03	Speed error filtered	Displays the filtered speed error. See the control chain diagram on page 570. This parameter is read-only.	-
	-30000.0 30000.0 rpm	Filtered speed error.	See par. 46.01
24.04	Speed error inverted	Displays the inverted (unfiltered) speed error. See the control chain diagram on page 570. This parameter is read-only.	-
	-30000.0 30000.0 rpm	Inverted speed error.	See par. 46.01

No.	Name/Value	Description	Def/ FbEq16
24.11	Speed correction	Defines a speed reference correction, ie. a value added to the existing reference between ramping and limitation. This is useful to trim the speed if necessary, for example to adjust draw between sections of a paper machine.  Note: For safety reasons, the correction is not applied when an emergency stop is active.  WARNING! If the speed reference correction exceeds 21.06 Zero speed limit, a ramp stop may be impossible. Make sure the correction is reduced or removed when a ramp stop is required.  See the control chain diagram on page 570.	0.00 rpm
	-10000.00 10000.00 rpm	Speed reference correction.	See par. 46.01
24.12	Speed error filter time	Defines the time constant of the speed error low-pass filter. If the used speed reference changes rapidly, the possible interferences in the speed measurement can be filtered with the speed error filter. Reducing the ripple with this filter may cause speed controller tuning problems. A long filter time constant and fast acceleration time contradict one another. A very long filter time results in unstable control.	0 ms
	010000 ms	Speed error filtering time constant. 0 = filtering disabled.	1 = 1 ms
24.13	RFE speed filter	Enables/disables resonance frequency filtering. The filtering is configured by parameters 24.1324.17.  The speed error value coming to the speed controller is filtered by a common 2nd order band-elimination filter to eliminate the amplification of mechanical resonance frequencies.  Note: Tuning the resonance frequency filter requires a basic understanding of frequency filters. Incorrect tuning can amplify mechanical oscillations and damage the drive hardware. To ensure the stability of the speed controller, stop the drive or disable the filtering before changing the parameter settings.  0 = Resonance frequency filtering disabled. 1 = Resonance frequency filtering enabled.	Off
	Off	0.	0
	On	1.	1

24.14 Frequency		
	Defines the zero frequency of the resonance frequency filter. The value must be set near the resonance frequency, which is filtered out before the speed controller. The drawing shows the frequency response. $20\log_{10} H(\omega) $ $20$ $-20$ $-40$ $-60$ $0$ $50$ $100$ $150$ $f (Hz)$	45.00 Hz
0.50 500	Hz Zero frequency.	1 = 1 Hz
24.15 Damping of	Defines the damping coefficient for parameter $24.14$ . The value of 0 corresponds to the maximum elimination of the resonance frequency. $20\log_{10} H(\omega) $ $20$ $f_{zero} = 45 \text{ Hz}$ $\xi_{zero} = 0.250$ $\xi_{pole} = 1$ $f_{zero} = 45 \text{ Hz}$ $\xi_{zero} = 0.250$ $\xi_{pole} = 1$ $f_{zero} = 45 \text{ Hz}$ $\xi_{zero} = 0$ $\xi_{pole} = 1$ $f_{zero} = 0$ $\xi_{pole} = 1$ $f_{zero} = 0$ $\xi_{pole} = 1$	0.000 z)
	Smaller triair 47.11.	

No.	Name/Value	Description	Def/ FbEq16
24.16	Frequency of pole	Defines the frequency of pole of the resonance frequency filter. $20\log_{10} H(\omega) $ $40$ $20$ $-2$	40.00 Hz
		which can damage the driven machine.	
	0.50 500.00 Hz	Frequency of pole.	1 = 1 Hz
24.17	Damping of pole	Defines the damping coefficient for parameter 24.16. The coefficient shapes the frequency response of the resonance frequency filter. A narrower bandwidth results in better dynamic properties. By setting this parameter to 1, the effect of the pole is eliminated. $ 20\log_{10} H(\omega)  $ $ 40                                 $	0.250
	-1.000 1.000	smaller than 24.17.  Damping coefficient.	100 = 1
	- 1.000 1.000	Damping Coefficient.	100 - 1

No.	Name/Value	Description	Def/ FbEq16
224.41	Speed error window control enable	Enables/disables (or selects a source that enables/disables) speed error window control, sometimes also referred to as deadband control or strip break protection. It forms a speed supervision function for a torque-controlled drive, preventing the motor from running away if the material that is being held under tension breaks.  Note: Speed error window control is only effective when the operating mode is active (see parameters 19.12 and 19.14), or when the drive is a speed-controlled follower (see page 63).  If the motor load is lost, then the motor speed rises. The speed error (speed reference - actual speed) increases until it exits the speed error window. When this is detected, the exceeding part of the error value is connected to the speed controller. The speed controller produces a reference term relative to the input and gain (25.02 Speed proportional gain).  The activation of speed error window control is indicated by bit 3 of 06.19 Speed control status word.  The window boundaries are defined by 24.43 Speed error window high and 24.44 Speed error window low as follows:	Disable
		Speed (rpm)  Reference + [24.44] rpm  Reference window  Reference - [24.43] rpm  Forward	
		Reverse 0 rpm	
		Speed error Window  Reference + [24.43] rpm  Reference - [24.44] rpm	
		Note: Parameter 24.44 (rather than 24.43) defines the overspeed limit in both directions of rotation. This is because the function monitors speed error (which is negative in case of overspeed, positive in case of underspeed).  0 = Speed error window control disabled 1 = Speed error window control enabled	
	Disable	0.	0
	Enable	1.	1
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-

No.	Name/Value	Description	Def/ FbEq16
24.42	Speed window control mode	When speed error window control (see parameter 24.41 Speed error window control enable) is enabled, this parameter determines whether the speed controller only observes the proportional term instead of all three (P, I and D) terms.	Normal speed control
	Normal speed control	All these terms (parameters 25.02, 25.03 and 25.04) are observed by the speed controller.	0
	P-control	Only the proportional term (25.02) is observed by the speed controller. The integral and derivative terms are internally forced to zero.	1
24.43	Speed error window high	Defines the upper boundary of the speed error window. See parameter 24.41 Speed error window control enable.	0.00 rpm
	0.003000.00 rpm	Upper boundary of speed error window.	See par. 46.01
24.44	Speed error window low	Defines the lower boundary of the speed error window. See parameter 24.41 Speed error window control enable.	0.00 rpm
	0.003000.00 rpm	Lower boundary of speed error window.	See par. 46.01
24.46	Speed error step	Defines an additional speed error step given to the input of the speed controller (and added to the speed error value). This can be used in large drive systems for dynamic speed normalizing.  WARNING! Make sure the error step value is removed when a stop command is given.	0.00 rpm
	-3000.00 3000.00 rpm	Speed error step.	See par. 46.01
25 Sp	eed control	Speed controller settings. See the control chain diagrams on pages 570 and 572.	
25.01	Torque reference speed control	Displays the speed controller output that is transferred to the torque controller. See the control chain diagram on page 572.  This parameter is read-only.	-
	-1600.01600.0%	Limited speed controller output torque.	See par. 46.03

No.	Name/Value	Description	Def/ FbEq16
25.02	Speed proportional gain	Defines the proportional gain $(K_p)$ of the speed controller. Too high a gain may cause speed oscillation. The figure below shows the speed controller output after an error step when the error remains constant.	10.00; 5.00 (95.21 b1/b2)
	%	•	
		Gain = $K_p = 1$ $T_1$ = Integration time = 0 $T_D$ = Derivation time = 0	
		E	
	Controller output = K <sub>p</sub> × e		: Error value
		Ti	me
		If gain is set to 1, a 10% change in error value (reference-actual value) causes the speed controller output to change by 10%, ie. the output value is input × gain.  Note: This parameter is automatically set by the speed controller autotune function. See section Speed controller autotune (page 66).	
	0.00250.00	Proportional gain for speed controller.	100 = 1

No.	Name/Value	Description	Def/ FbEq16
25.03	Speed integration time	Defines the integration time of the speed controller. The integration time defines the rate at which the controller output changes when the error value is constant and the proportional gain of the speed controller is 1. The shorter the integration time, the faster the continuous error value is corrected.  Setting the integration time to zero disables the I-part of the controller. This is useful to do when tuning the proportional gain; adjust the proportional gain first, then return the integration time.  The integrator has anti-windup control for operation at a torque or current limit.  The figure below shows the speed controller output after an error step when the error remains constant.	2.50 s; 5.00 (95.21 b1/b2)
	% K <sub>p</sub> ×e {	Controller output $\begin{aligned} \text{Gain} &= \text{K}_{\text{p}} = 1 \\ T_{\text{I}} &= \text{Integration time} > 0 \\ T_{\text{D}} &= \text{Derivation time} = 0 \end{aligned}$	
	K <sub>p</sub> ×e {	e = Error value	
		$T_{\rm l}$	
		Note: This parameter is automatically set by the speed controller autotune function. See section Speed controller autotune (page 66)	
	0.00 1000.00 s	Integration time for speed controller.	10 = 1 s

No.	Name/Value	Description	Def/ FbEq16
25.04	Speed derivation time	Defines the derivation time of the speed controller. Derivative action boosts the controller output if the error value changes. The longer the derivation time, the more the speed controller output is boosted during the change. If the derivation time is set to zero, the controller works as a PI controller, otherwise as a PID controller. The derivation makes the control more responsive for disturbances. For simple applications (especially those without an encoder), derivative time is not normally required and should be left at zero.  The figure below shows the speed controller output after an error step when the error remains constant. The speed error derivative must be filtered with a low pass filter to eliminate external disturbances.	0.000 s
	$K_{p} \times T_{D} \times \frac{\Delta e}{T_{s}} \begin{cases} \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ $	Error value  e = Error  Time	value
	$T_{I} = T_{D} = T_{S} = T_{S}$	n = K <sub>p</sub> = 1 Integration time > 0 Derivation time > 0 Sample time period = 500 μs Error value change between two samples	
	0.00010.000 s	Derivation time for speed controller.	1000 = 1 s
25.05	Derivation filter time	Defines the derivation filter time constant. See parameter 25.04 Speed derivation time.	8 ms
	010000 ms	Derivation filter time constant.	1 = 1 ms

No.	Name/Value	Description	Def/ FbEq16
25.06	Acc comp derivation time	Defines the derivation time for acceleration(/deceleration) compensation. In order to compensate for a high inertia load during acceleration, a derivative of the reference is added to the output of the speed controller. The principle of a derivative action is described under parameter 25.04 Speed derivation time.  Note: As a general rule, set this parameter to the value between 50 and 100% of the sum of the mechanical time constants of the motor and the driven machine.  The figure below shows the speed responses when a high inertia load is accelerated along a ramp.  No acceleration compensation:	0.00 s
		Speed reference - Actual speed Time	
		Acceleration compensation:	
		- Speed reference - Actual speed Time	
	0.001000.00 s	Acceleration compensation derivation time.	10 = 1 s
25.07	Acc comp filter time	Defines the acceleration (or deceleration) compensation filter time constant. See parameters 25.04 Speed derivation time and 25.06 Acc comp derivation time.	8.0 ms
	0.01000.0 ms	Acceleration/deceleration compensation filter time.	1 = 1 ms

	Name/V	/alue	Description	Def/ FbEq16
25.08	Droopin	g rate	Defines the droop rate in percent of the nominal motor speed. Drooping decreases the drive speed slightly as the drive load increases. The actual speed decrease at a certain operating point depends on the droop rate setting and the drive load (= torque reference / speed controller output). At 100% speed controller output, drooping is at its nominal level, that is equal to the value of this parameter. The drooping effect decreases linearly to zero along with the decreasing load.  The correct droop rate for a process must be found out case by case in practice.	0.00%
	Exampl 1500 rp	e: Speed cont m.	need controller output $\times$ Drooping $\times$ Nominal speed roller output is 50%, droop rate is 1%, nominal speed of the $60 \times 0.01 \times 1500$ rpm = 7.5 rpm.	drive is
	Motor s of nomi	peed in% nal		
		I	No drooping	
	100%		Drooping 25.08 Drooping rate	
			Speed controller / Drive load output /%	
	_		100%	
	0.0010	00.00%	Droop rate.	100 = 1%
25.09	Speed c enable	trl balancing	Selects the source for enabling/disabling speed controller output balancing.  This function is used to generate a smooth transfer from a torque- or tension-controlled motor back to being speed-controlled. When balancing is enabled, the output of the speed controller is forced to the value of 25.10 Speed ctrl balancing ref.	Not selected
			Balancing is also possible in the ramp generator, see parameter 23.26 Ramp out balancing enable.	
	N. C.		Balancing is also possible in the ramp generator, see parameter 23.26 Ramp out balancing enable.  0 = Disabled 1 = Enabled	
	Not sele		Balancing is also possible in the ramp generator, see parameter 23.26 Ramp out balancing enable.  0 = Disabled 1 = Enabled 0.	1
	Selected		Balancing is also possible in the ramp generator, see parameter 23.26 Ramp out balancing enable.  0 = Disabled 1 = Enabled 0. 1.	2
	Selected DI1		Balancing is also possible in the ramp generator, see parameter 23.26 Ramp out balancing enable.  0 = Disabled 1 = Enabled 0. 1. Digital input DI1 (10.02 DI delayed status, bit 0).	2
	Selected DI1 DI2		Balancing is also possible in the ramp generator, see parameter 23.26 Ramp out balancing enable.  0 = Disabled 1 = Enabled 0. 1. Digital input DI1 (10.02 DI delayed status, bit 0). Digital input DI2 (10.02 DI delayed status, bit 1).	2 2 3
	Selected DI1		Balancing is also possible in the ramp generator, see parameter 23.26 Ramp out balancing enable.  0 = Disabled 1 = Enabled 0. 1. Digital input DI1 (10.02 DI delayed status, bit 0). Digital input DI2 (10.02 DI delayed status, bit 1). Digital input DI3 (10.02 DI delayed status, bit 2).	2
	Selected DI1 DI2 DI3		Balancing is also possible in the ramp generator, see parameter 23.26 Ramp out balancing enable.  0 = Disabled 1 = Enabled 0. 1. Digital input DI1 (10.02 DI delayed status, bit 0). Digital input DI2 (10.02 DI delayed status, bit 1).	2 2 3 4

No.	Name/Value	Description	Def/ FbEq16
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
25.10	Speed ctrl balancing ref	Defines the reference used in speed controller output balancing. The output of the speed controller is forced to this value when balancing is enabled by parameter 25.09 Speed ctrl balancing enable.	0.0%
	-300.0300.0%	Speed control output balancing reference.	See par. 46.03
25.11	Speed control min torque	Defines the minimum speed controller output torque.	-300.0%
	-1600.00.0%	Minimum speed controller output torque.	See par. 46.03
25.12	Speed control max torque	Defines the maximum speed controller output torque.	300.0%
	0.01600.0%	Maximum speed controller output torque.	See par. 46.03
25.13	Min torq sp ctrl em stop	Defines the minimum speed controller output torque during a ramped emergency stop (Off1 or Off3).	-400.0%
	-1600.0 0.0%	Minimum speed controller output torque for ramped emergency stop.	See par. 46.03
25.14	Max torq sp ctrl em stop	Defines the maximum speed controller output torque during a ramped emergency stop (Off1 or Off3).	400.0%
	0.01600.0%	Maximum speed controller output torque for ramped emergency stop.	See par. 46.03
25.15	Proportional gain em stop	Defines the proportional gain for the speed controller when an emergency stop is active. See parameter 25.02 Speed proportional gain.	10.00; 5.00 (95.21 b1/b2)
	1.00250.00	Proportional gain upon an emergency stop.	100 = 1

No.	Name/Value	Description	Def/ FbEq16
25.18	Speed adapt min limit  Coeffic	Minimum actual speed for speed controller adaptation. Speed controller gain and integration time can be adapted according to actual speed (90.01 Motor speed for control). This is done by multiplying the gain (25.02 Speed proportional gain) and integration time (25.03 Speed integration time) by coefficients at certain speeds. The coefficients are defined individually for both gain and integration time.  When actual speed is below or equal to 25.18 Speed adapt min limit, the gain is multiplied by 25.21 Kp adapt coef at min speed and the integration time divided by 25.22 Tr adapt coef at min speed.  When actual speed is equal to or above 25.19 Speed adapt max limit, no adaptation takes place (the coefficient is 1).  When actual speed is between 25.18 Speed adapt min limit and 25.19 Speed adapt max limit, the coefficients for the gain and integration time are calculated linearly on the basis of the breakpoints.  See also the block diagram on page 572.	0 rpm
		1.000	
	25.21 Kp adapt coef at or 25.22 Ti adapt coef speed	at min	Actual speed 90.01) (rpm)
	030000 rpm	Minimum actual speed for speed controller adaptation.	1 = 1 rpm
25.19	Speed adapt max limit	Maximum actual speed for speed controller adaptation. See parameter 25.18 Speed adapt min limit.	0 rpm
	030000 rpm	Maximum actual speed for speed controller adaptation.	1 = 1 rpm
25.21	Kp adapt coef at min speed	Proportional gain coefficient at minimum actual speed. See parameter 25.18 Speed adapt min limit.	1.000
	0.00010.000	Proportional gain coefficient at minimum actual speed.	1000 = 1
25.22	Ti adapt coef at min speed	Integration time coefficient at minimum actual speed. See parameter 25.18 Speed adapt min limit.	1.000
	0.00010.000	Integration time coefficient at minimum actual speed.	1000 = 1

No.	Name/Value	Description	Def/ FbEq16	
25.25	Torque adapt max limit			
		The functionality involves multiplying the gain (25.02 Speed proportional gain) by a coefficient within a certain torque range.		
		When the torque reference is 0%, the gain is multiplied by the value of parameter 25.27 <i>Kp adapt coef at min torque</i> .		
		When the torque reference is equal to or above 25.25 Torque adapt max limit, no adaptation takes place (the coefficient is 1).		
		Between 0% and 25.25 Torque adapt max limit, the coefficient for the gain is calculated linearly on the basis of the breakpoints.		
		Filtering can be applied on the torque reference using parameter 25.26 Torque adapt filt time.  See also the block diagram on page 572.		
	Coefficient for $K_p$ (proportional gain)			
		<u>†</u>		
		1.000		
	25.27 Kp adapt coef		ue reference	
		(26.01) (r		
		0 25.25 Torque adapt max limit		
	0.01600.0%	Maximum torque reference for speed controller adaptation.	See par. 46.03	
25.26	Torque adapt filt time	Defines a filter time constant for the adaptation, in effect adjusting the rate of change of the gain.  See parameter 25.25 Torque adapt max limit.	0.000 s	
	0.000100.000 s	Filter time for adaptation.	100 = 1 s	
25.27	Kp adapt coef at min torque	Proportional gain coefficient at 0% torque reference. See parameter 25.25 Torque adapt max limit.	1.000	

No.	Name/Value	Description	Def/ FbEq16
25.30	Flux adaptation enable	Enables/disables speed controller adaptation based on motor flux reference (01.24 Flux actual%).  The proportional gain of the speed controller is multiplied by a coefficient of 01 between 0100% flux reference respectively.  See also the block diagram on page 572.  Coefficient for K <sub>p</sub> (proportional gain)  Flux reference (01.24) (%)	Enable
	Disable	Speed controller adaptation based on flux reference disabled.	0
	Enable	Speed controller adaptation based on flux reference enabled.	1
25.33	Speed controller autotune	Activates (or selects a source that activates) the speed controller autotune function. See section Speed controller autotune (page 66).  The autotune will automatically set parameters 25.02 Speed proportional gain, 25.03 Speed integration time and 25.37 Mechanical time constant.  The prerequisites for performing the autotune routine are:  • the motor identification run (ID run) has been successfully completed  • the speed and torque limits (parameter group 30 Limits) have been set  • speed feedback filtering (parameter group 90 Feedback selection), speed error filtering (24 Speed reference conditioning) and zero speed (21 Start/stop mode) have been set, and  • the drive has been started and is running in speed control mode.  WARNING! The motor and machinery will run against the torque and speed limits during the autotune routine. MAKE SURE IT IS SAFE TO  ACTIVATE THE AUTOTUNE FUNCTION!  The autotune routine can be aborted by stopping the drive.  0 -> 1 = Activate speed controller autotune  Note: The value does not revert to 0 automatically.	Off
	Off	0.	0
	On	1.	1

No.	Name/Value	Description	Def/ FbEq16
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
25.34	Speed controller autotune mode	Defines a control preset for the speed controller autotune function. The setting affects the way the torque reference will respond to a speed reference step.	Normal
	Smooth	Slow but robust response.	0
	Normal	Medium setting.	1
	Tight	Fast response. May produce too high a gain value for some applications.	2
25.37	Mechanical time constant	Mechanical time constant of the drive and the machinery as determined by the speed controller autotune function. The value can be adjusted manually.	-
	0.00 1000.00 s	Mechanical time constant.	10 = 1 s
25.38	Autotune torque step	Defines an added torque value used by the autotune function. This value is scaled to motor nominal torque. Note that the torque used by the autotune function can also be limited by the torque limits (in parameter group 30 Limits) and nominal motor torque.	10.00%
	0.00 100.00%	Autotune torque step.	100 = 1%
25.39	Autotune speed step	Defines a speed value added to the initial speed for the autotune routine. The initial speed (speed used when autotune is activated) plus the value of this parameter is the calculated maximum speed used by the autotune routine. The maximum speed can also be limited by the speed limits (in parameter group 30 Limits) and nominal motor speed.  The value is scaled to motor nominal speed.	10.00%
		Note: The motor will exceed the calculated maximum speed slightly at the end of each acceleration stage.	
	0.00 100.00%	Autotune speed step.	100 = 1%
25.40	Autotune repeat times	Determines how many acceleration/deceleration cycles are performed during the autotune routine. Increasing the value will improve the accuracy of the autotune function, and allow the use of smaller torque or speed step values.	10
	110	Number of cycles during autotune routine.	1 = 1
25.41	Torque reference Autotune2	Reserved.	-
25.42	Integral term enable	Selects a source that enables/disables the integral (I) part of the speed controller.  0 = I-part disabled  1 = I-part enabled	Selected
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7

No.	Name/Value	Description	Def/ FbEq16
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
25.53	Torque prop reference	Displays the output of the proportional (P) part of the speed controller. See the control chain diagram on page 572.  This parameter is read-only.	-
	-30000.030000.0%	P-part output of speed controller.	See par. 46.03
25.54	Torque integral reference	Displays the output of the integral (I) part of the speed controller. See the control chain diagram on page 572. This parameter is read-only.	-
	-30000.030000.0%	I-part output of speed controller.	See par. 46.03
25.55	Torque deriv reference	Displays the output of the derivative (D) part of the speed controller. See the control chain diagram on page 572. This parameter is read-only.	-
	-30000.030000.0%	D-part output of speed controller.	See par. 46.03
25.56	Torque acc compensation	Displays the output of the acceleration compensation function. See the control chain diagram on page 572. This parameter is read-only.	-
	-30000.030000.0%	Output of acceleration compensation function.	See par. 46.03
25.57	Torque reference unbalanced	Displays the acceleration-compensated output of the speed controller. See the control chain diagram on page 572.  This parameter is read-only.	-
	-30000.030000.0%	Acceleration-compensated output of speed controller.	See par. 46.03
26 Torque reference		Settings for the torque reference chain.	

26 Torque reference chain		Settings for the torque reference chain.	
26.01	Torque reference to TC	Displays the final torque reference given to the torque controller in percent. This reference is then acted upon by various final limiters, like power, torque, load etc.  This parameter is read-only.	-
	-1600.0 1600.0%	Torque reference for torque control.	-
26.02	Torque reference used	Displays the final torque reference (in percent of motor nominal torque) given to the DTC core, and comes after frequency, voltage and torque limitation.  This parameter is read-only.	-
	-1600.0 1600.0%	Torque reference for torque control.	-
26.43	Torque step pointer enable	Selects a source that enables/disables the torque step defined by parameter 26.44 Torque step source.  1 = Torque step enabled.	Selected
	Not selected	0.	0
	Selected	1.	1

No.	Name/Value	Description	Def/ FbEq16
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
26.44	Torque step source	Selects the source of the torque step enabled by 26.43 Torque step pointer enable.	Zero
	Zero	None.	0
	Al1 scaled	12.12 Al1 scaled value (see page 169).	1
	Al2 scaled	12.22 Al2 scaled value (see page 170).	2
	FB A ref1	03.05 FB A reference 1 (see page 126).	4
	FB A ref2	03.06 FB A reference 2 (see page 126).	5
	EFB ref1	03.09 EFB reference 1 (see page 126).	8
	EFB ref2	03.10 EFB reference 2 (see page 126).	9
	DDCS ctrl ref1		10
	DDCS ctrl ref2		11
	M/F reference 1		12
	M/F reference 2		13
	Motor potentiometer	22.80 Motor potentiometer ref act (output of the motor potentiometer).	15
	PID		16
	Control panel (ref saved)	Control panel reference, with initial value from last-used panel reference. See section <i>Using the control panel as an external control source</i> (page 21).	18
	Control panel (ref copied)	Control panel reference, with initial value from previous source or actual value. See section <i>Using the control panel</i> as an external control source (page 21).	19
	Other	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
26.51	Oscillation damping	Parameters 26.5126.58 configure the oscillation damping function. See section Oscillation damping (page 69).  This parameter enables (or selects a source that enables) the oscillation damping algorithm.  1 = Oscillation damping algorithm enabled	Not selected
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3

Ot 26.52 Os	14 15	Digital input DI3 (10.02 DI delayed status, bit 2).  Digital input DI4 (10.02 DI delayed status, bit 3).  Digital input DI5 (10.02 DI delayed status, bit 4).  Digital input DI6 (10.02 DI delayed status, bit 5).  Digital input/output DIO1 (11.02 DIO delayed status, bit 0).  Digital input/output DIO2 (11.02 DIO delayed status, bit 1).  Source selection (see Terms and abbreviations on page 118).  Determines (or selects a source that determines) whether the output of the oscillation damping function is added to the torque reference or not.  Note: Before enabling the oscillation damping output, adjust parameters 26.5326.57. Then monitor the input signal (selected by 26.53) and the output (26.58) to make sure that the correction is safe to apply.  1 = Add oscillation damping output to torque reference	4 5 6 7 10 111 - Not selected
DI D	IS IG IG1 IO2 Ither [bit] Iscillation damping ut enable	Digital input DI5 (10.02 DI delayed status, bit 4).  Digital input DI6 (10.02 DI delayed status, bit 5).  Digital input/output DIO1 (11.02 DIO delayed status, bit 0).  Digital input/output DIO2 (11.02 DIO delayed status, bit 0).  Source selection (see Terms and abbreviations on page 118).  Determines (or selects a source that determines) whether the output of the oscillation damping function is added to the torque reference or not.  Note: Before enabling the oscillation damping output, adjust parameters 26.5326.57. Then monitor the input signal (selected by 26.53) and the output (26.58) to make sure that the correction is safe to apply.	6 7 10 11
DI DI OI	IGIO1 IO2 Ither [bit] Iscillation damping ut enable	Digital input DI6 (10.02 DI delayed status, bit 5).  Digital input/output DIO1 (11.02 DIO delayed status, bit 0).  Digital input/output DIO2 (11.02 DIO delayed status, bit 0).  Digital input/output DIO2 (11.02 DIO delayed status, bit 1).  Source selection (see Terms and abbreviations on page 118).  Determines (or selects a source that determines) whether the output of the oscillation damping function is added to the torque reference or not.  Note: Before enabling the oscillation damping output, adjust parameters 26.5326.57. Then monitor the input signal (selected by 26.53) and the output (26.58) to make sure that the correction is safe to apply.	7 10 11 -
DI DI Oi	IO1 IO2 ther [bit] scillation damping ut enable	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).  Digital input/output DIO2 (11.02 DIO delayed status, bit 1).  Source selection (see Terms and abbreviations on page 118).  Determines (or selects a source that determines) whether the output of the oscillation damping function is added to the torque reference or not.  Note: Before enabling the oscillation damping output, adjust parameters 26.5326.57. Then monitor the input signal (selected by 26.53) and the output (26.58) to make sure that the correction is safe to apply.	10 11 -
Ot 26.52 Os	ther [bit] scillation damping ut enable	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).  Source selection (see Terms and abbreviations on page 118).  Determines (or selects a source that determines) whether the output of the oscillation damping function is added to the torque reference or not.  Note: Before enabling the oscillation damping output, adjust parameters 26.5326.57. Then monitor the input signal (selected by 26.53) and the output (26.58) to make sure that the correction is safe to apply.	11 -
Ot 26.52 Os	ther [bit] scillation damping ut enable	Source selection (see <i>Terms and abbreviations</i> on page 118).  Determines (or selects a source that determines) whether the output of the oscillation damping function is added to the torque reference or not.  Note: Before enabling the oscillation damping output, adjust parameters 26.5326.57. Then monitor the input signal (selected by 26.53) and the output (26.58) to make sure that the correction is safe to apply.	-
26.52 Os	scillation damping ut enable	Determines (or selects a source that determines) whether the output of the oscillation damping function is added to the torque reference or not.  Note: Before enabling the oscillation damping output, adjust parameters 26.5326.57. Then monitor the input signal (selected by 26.53) and the output (26.58) to make sure that the correction is safe to apply.	
	ut enable	the output of the oscillation damping function is added to the torque reference or not.  Note: Before enabling the oscillation damping output, adjust parameters 26.5326.57. Then monitor the input signal (selected by 26.53) and the output (26.58) to make sure that the correction is safe to apply.	Not selected
	at adjusted	, 5 ,	
No	ot selected	0.	0
Se	elected	1.	1
DI	l1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
DI	12	Digital input DI2 (10.02 DI delayed status, bit 1).	3
DI	13	Digital input DI3 (10.02 DI delayed status, bit 2).	4
DI	14	Digital input DI4 (10.02 DI delayed status, bit 3).	5
DI	15	Digital input DI5 (10.02 DI delayed status, bit 4).	6
DI	16	Digital input DI6 (10.02 DI delayed status, bit 5).	7
DI	IO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
DI	102	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
Ot	ther [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
	scillation ompensation input	Selects the input signal for the oscillation damping function.  Note: Before changing this parameter run-time, disable the oscillation damping output using parameter 26.52. Monitor the behavior of 26.58 before re-enabling the output.	Speed error
Sp	peed error	24.01 Used speed reference - unfiltered motor speed.  Note: This setting is not supported in scalar motor control mode.	0
DO	C voltage	01.11 DC voltage. (The value is internally filtered.)	1
	scillation damping equency	Defines the center frequency of the oscillation damping filter.  Set the value according to the number of oscillation peaks in the monitored signal (selected by 26.53) per second.  Note: Before changing this parameter run-time, disable the oscillation damping output using parameter 26.52. Monitor the behavior of 26.58 before re-enabling the output.	31.0 Hz
0.	1 60.0 Hz	Center frequency for oscillation damping.	10 = 1 Hz

No.	Name/Value	Description	Def/ FbEq16
26.56	Oscillation damping phase	Defines a phase shift for the output of the filter.  Note: Before changing this parameter run-time, disable the oscillation damping output using parameter 26.52. Monitor the behavior of 26.58 before re-enabling the output.	180 deg
	0360 deg	Phase shift for oscillation damping function output.	10 = 1 deg
26.57	Oscillation damping gain	Defines a gain for the output of the oscillation damping function, ie. how much the output of the filter is amplified before it is added to the torque reference.  Oscillation gain is scaled according to the speed controller gain so that changing the gain will not disturb oscillation damping.  Note: Before changing this parameter run-time, disable the oscillation damping output using parameter 26.52.  Monitor the behavior of 26.58 before re-enabling the output.	1.0%
	0.0 100.0%	Gain setting for oscillation damping output.	10 = 1%
26.58	Oscillation damping output	Displays the output of the oscillation damping function. This value is added to the torque reference (as allowed by parameter 26.52 Oscillation damping out enable). This parameter is read-only.	-
	-1600.000 1600.000%	Output of the oscillation damping function.	10 = 1%
26.81	Rush control gain	Rush controller gain term. See section <i>Rush control</i> (page 71).	10.0
	0.010000.0	Rush controller gain (0.0 = disabled).	1 = 1
26.82	Rush control integration time	Rush controller integration time term.	2.0 s
	0.010.0 s	Rush controller integration time (0.0 = disabled).	1 = 1 s
29 Err	equency reference	Settings for the frequency reference chain.	

28 Frequency reference chain		Settings for the frequency reference chain. See the control chain diagrams on pages 573 and 573.	
28.01	Frequency ref ramp input	Displays the used frequency reference before ramping. See the control chain diagram on page 573.  This parameter is read-only.	-
	-500.00500.00 Hz	Frequency reference before ramping.	See par. 46.02
28.02	Frequency ref ramp output	Displays the final frequency reference (after selection, limitation and ramping). See the control chain diagram on page 573.  This parameter is read-only.	-
	-500.00500.00 Hz	Final frequency reference.	See par. 46.02

No.	Name/Value	Description	Def/ FbEq16
28.11	Frequency ref1 source	Selects frequency reference source 1. Two signal sources can be defined by this parameter and 28.12 Frequency ref2 source. A digital source selected by 28.14 Frequency ref1/2 selection can be used to switch between the two sources, or a mathematical function (28.13 Frequency ref1 function) applied to the two signals to create the reference.	Zero
	0 AI FB Other 28.12	28.13  Ref1  ADD  SUB  MUL  28.14  0  28.14	8.92
	Zero	None.	0
	Al1 scaled	12.12 Al1 scaled value (see page 169).	1
	Al2 scaled	12.22 Al2 scaled value (see page 170).	2
	FB A ref1	03.05 FB A reference 1 (see page 126).	4
	FB A ref2	03.06 FB A reference 2 (see page 126).	5
	EFB ref1	03.09 EFB reference 1 (see page 126).	8
	EFB ref2	03.10 EFB reference 2 (see page 126).	9
	Motor potentiometer	22.80 Motor potentiometer ref act (output of the motor potentiometer).	15
	Control panel (ref saved)	Control panel reference, with initial value from last-used panel reference. See section <i>Using the control panel as an external control source</i> (page 55).	
	Control panel (ref copied)	Control panel reference, with initial value from previous source or actual value. See section <i>Using the control panel</i> as an external control source (page 55).	
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
28.12	Frequency ref2 source	Selects frequency reference source 2. For the selections, and a diagram of reference source selection, see parameter 28.11 Frequency ref1 source.	Zero
28.13	Frequency ref1 function	Selects a mathematical function between the reference sources selected by parameters 28.11 Frequency ref1 source and 28.12 Frequency ref2 source. See diagram at 28.11 Frequency ref1 source.	Ref1
	Ref1	Signal selected by 28.11 Frequency ref1 source is used as frequency reference 1 as such (no function applied).	0
	Add (ref1 + ref2)	The sum of the reference sources is used as frequency reference 1.	1

No.	Name/Value	Description	Def/ FbEq16
	Sub (ref1 - ref2)	The subtraction ([28.11 Frequency ref1 source] - [28.12 Frequency ref2 source]) of the reference sources is used as frequency reference 1.	2
	Mul (ref1 × ref2)	The multiplication of the reference sources is used as frequency reference 1.	3
	Min (ref1, ref2)	The smaller of the reference sources is used as frequency reference 1.	4
	Max (ref1, ref2)	The greater of the reference sources is used as frequency reference 1.	5
28.14	Frequency ref1/2 selection	Configures the selection between frequency references 1 and 2. See diagram at 28.11 Frequency ref1 source.  0 = Frequency reference 1 1 = Frequency reference 2	Follow Ext1/Ext2 selection
	Frequency reference 1	0.	0
	Frequency reference 2	1.	1
	Follow Ext1/Ext2 selection	Frequency reference 1 is used when external control location EXT1 is active. Frequency reference 2 is used when external control location EXT2 is active.  See also parameter 19.11 Ext1/Ext2 selection.	2
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	3
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	4
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	5
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	6
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	7
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	8
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-

No.	Name/	Value	Description			Def/	
NO.	o. Name/Value		Description			FbEq	16
28.21	Constar function	nt frequency	Determines how cor whether the rotation when applying a cor	direction signal is		0000b	1
	Bit	Name	Information				
	0	Constant freq			are selectable using	the thre	е
		mode	0 = Separate: Cor by the sources de	nstant frequencies fined by paramete se of conflict, the o	2, 28.23 and 28.24. 1, 2 and 3 are separates 28.22, 28.23 and 2 constant frequency w	28.24	
	1	Direction enable	sign of the consta multiplied by the c effectively allows frequencies if all v WARNING constant fr direction.	nt frequency settin direction signal (for the drive to have 1 values in 28.2626). If the direction si equency is negativer: The running directions directions in the direction si equency is negativer.	rection for a constant g (parameters 28.26. ward: +1, reverse: -1 4 (7 forward, 7 revers 3.32 are positive. gnal is reverse and the, the drive will run in rection for the constant int speed setting (par	28.32 ). This se) cons ne active n the for	et) is stant erward ency is
			28.2628.32).	sign of the consta	int speed setting (par	ameter	5
	0000b	.0011b	Constant frequency	configuration word	l.	1 = 1	
28.22	28.22 Constant frequency sel1		When bit 0 of param function is 0 (Separa constant frequency When bit 0 of param function is 1 (Packe: 28.23 Constant frequency sel3 selections that the constant frequencies: 28.25 Constant frequenc	ate), selects a sour 1. neter 28.21 Consta d), this parameter a uency sel2 and 28 ct three sources wh	nt frequency and parameters	Not se	elected
	İ	Source define	d Source defined	Source defined	Constant freque	nov	1
		by par. 28.22		by par. 28.24	active	псу	
		0	0	0	None		
		1	0	0	Constant frequen	,	
		0	1	0	Constant frequen		
		1	1	0	Constant frequen	•	
		0	0	1	Constant frequen	•	
		1	0	1	Constant frequen		
		0	1	1	Constant frequen	,	
		1	1	1	Constant frequen	cy /	
Not selected		^			0		
	NOT SELE	ected	0.				
	Selecte		1.			1	
				.02 DI delayed sta	tus, bit 0).	1 2	
	Selecte		1.	<u> </u>	<u> </u>		

No.	Name/Value	Description	Def/ FbEq16
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
28.23	Constant frequency sel2	When bit 0 of parameter 28.21 Constant frequency function is 0 (Separate), selects a source that activates constant frequency 2.  When bit 0 of parameter 28.21 Constant frequency function is 1 (Packed), this parameter and parameters 28.22 Constant frequency sel1 and 28.24 Constant frequency sel3 select three sources that are used to activate constant frequencies. See table at parameter 28.22 Constant frequency sel1.  For the selections, see parameter 28.22 Constant frequency sel1.	Not selected
28.24	Constant frequency sel3	When bit 0 of parameter 28.21 Constant frequency function is 0 (Separate), selects a source that activates constant frequency 3.  When bit 0 of parameter 28.21 Constant frequency function is 1 (Packed), this parameter and parameters 28.22 Constant frequency sel1 and 28.23 Constant frequency sel2 select three sources that are used to activate constant frequencies. See table at parameter 28.22 Constant frequency sel1.  For the selections, see parameter 28.22 Constant frequency sel1.	Not selected
28.26	Constant frequency 1	Defines constant frequency 1 (the frequency the motor will turn when constant frequency 1 is selected).	0.00 Hz
	-500.00 500.00 Hz	Constant frequency 1.	See par. 46.02
28.27	Constant frequency 2	Defines constant frequency 2.	0.00 Hz
	-500.00 500.00 Hz	Constant frequency 2.	See par. 46.02
28.28	Constant frequency 3	Defines constant frequency 3.	0.00 Hz
	-500.00 500.00 Hz	Constant frequency 3.	See par. 46.02
28.29	Constant frequency 4	Defines constant frequency 4.	0.00 Hz
	-500.00 500.00 Hz	Constant frequency 4.	See par. 46.02
28.30	Constant frequency 5	Defines constant frequency 5.	0.00 Hz
	-500.00 500.00 Hz	Constant frequency 5.	See par. 46.02
28.31	Constant frequency 6	Defines constant frequency 6.	0.00 Hz
	-500.00 500.00 Hz	Constant frequency 6.	See par. 46.02

No.	Name/Value		Description		Def/ FbEq16
28.32	Constant frequency	<sup>7</sup>	Defines consta	int frequency 7.	0.00 Hz
	-500.00 500.00 H	Ηz	Constant frequ	ency 7.	See par. 46.02
28.41	Frequency ref safe		supervision fur 12.03 AI sup 49.05 Comm 50.02 FBA A 50.32 FBA B	frequency reference value that is used with actions such as pervision function munication loss action A comm loss func 3 comm loss func munication loss action.	0.00 Hz
	-500.00500.00 H	z	Safe frequency	reference.	See par. 46.02
28.51	Critical frequency function		determines wh both rotating di	es the critical frequencies function. Also ether the specified ranges are effective in irections or not.  on Critical speeds/frequencies (page 65).	0000Ь
		Bit	Name	Information	
		0	Enable	1 = Enable: Critical frequencies enabled.	
				0 = Disable: Critical frequencies disabled.	
		1	Sign mode	1 = According to par: The signs of paramete 28.5228.57 are taken into account.	
				0 = Absolute: Parameters 28.5228.57 are handled as absolute values. Each range is effective in both directions of rotation.	
	0000b0011b		Critical frequer	ncies configuration word.	1 = 1
28.52	Critical frequency 1 low		Note: This valu	v limit for critical frequency 1. le must be less than or equal to the value of requency 1 high.	0.00 Hz
	-500.00500.00 H	z	Low limit for cr	itical frequency 1.	See par. 46.02
28.53	Critical frequency 1 high		Note: This valu	th limit for critical frequency 1. The must be greater than or equal to the value all frequency 1 low.	0.00 Hz
	-500.00500.00 H	Z	High limit for cr	itical frequency 1.	See par. 46.02
28.54	Critical frequency 2 low		Note: This valu	v limit for critical frequency 2. the must be less than or equal to the value of requency 2 high.	0.00 Hz
	-500.00500.00 H	z	Low limit for cr	itical frequency 2.	See par. 46.02
28.55	Critical frequency 2 high		Note: This valu	th limit for critical frequency 2. The must be greater than or equal to the value all frequency 2 low.	0.00 Hz
	-500.00500.00 H	z	High limit for cr	ritical frequency 2.	See par. 46.02

No.	Name/Value	Description	Def/ FbEq16
28.56	Critical frequency 3 low	Defines the low limit for critical frequency 3.  Note: This value must be less than or equal to the value of 28.57 Critical frequency 3 high.	0.00 Hz
	-500.00500.00 Hz	Low limit for critical frequency 3.	See par. 46.02
28.57	Critical frequency 3 high	Defines the high limit for critical frequency 3.  Note: This value must be greater than or equal to the value of 28.56 Critical frequency 3 low.	0.00 Hz
	-500.00500.00 Hz	High limit for critical frequency 3.	See par. 46.02
28.71	Freq ramp set selection	Selects a source that switches between the two sets of acceleration/deceleration times defined by parameters 28.7228.75.  0 = Acceleration time 1 and deceleration time 1 are in force 1 = Acceleration time 2 and deceleration time 2 are in force	Acc/Dec time 1
	Acc/Dec time 1	0.	0
	Acc/Dec time 2	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
28.72	Freq acceleration time 1	Defines acceleration time 1 as the time required for the frequency to change from zero to the frequency defined by parameter 46.02 Frequency scaling (not to parameter 30.14 Maximum frequency).  If the reference increases faster than the set acceleration rate, the motor will follow the acceleration rate. If the reference increases slower than the set acceleration rate, the motor frequency will follow the reference. If the acceleration time is set too short, the drive will	20.000 s
	0.0001800.000 s	automatically prolong the acceleration in order not to exceed the drive torque limits.  Acceleration time 1.	10 = 1 s
		1	

No.	Name/Value	Description	Def/ FbEq16
28.73	Freq deceleration time 1	Defines deceleration time 1 as the time required for the frequency to change from the frequency defined by parameter 46.02 Frequency scaling (not from parameter 30.14 Maximum frequency) to zero. If there is any doubt about the deceleration time being too short, ensure that DC overvoltage control (30.30 Overvoltage control) is on.  Note: If a short deceleration time is needed for a high inertia application, the drive should be equipped with braking equipment such as a brake chopper and brake resistor.	20.000 s
	0.0001800.000 s	Deceleration time 1.	10 = 1 s
28.74	Freq acceleration time 2	Defines acceleration time 2. See parameter 28.72 Freq acceleration time 1.	60.000 s
	0.0001800.000 s	Acceleration time 2.	10 = 1 s
28.75	Freq deceleration time 2	Defines deceleration time 2. See parameter 28.73 Freq deceleration time 1.	60.000 s
	0.0001800.000 s	Deceleration time 2.	10 = 1 s
28.76	Freq ramp in zero source	Selects a source that forces the frequency reference to zero.  0 = Force frequency reference to zero 1 = Normal operation	Inactive
	Active	0.	0
	Inactive	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
28.77	Freq ramp hold	Selects a source that forces the output of the frequency ramp generator to actual frequency value.  0 = Force ramp output to actual frequency 1 = Normal operation	Inactive
	Active	0.	0
	Inactive	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7

No.	Name/Value	Description	Def/ FbEq16
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
28.78	Freq ramp output balancing	Defines a reference for frequency ramp balancing. The output of the ramp generator is forced to this value when balancing is enabled by parameter 28.79 Freq ramp output balancing enable.	0.00 Hz
	-500.00500.00 Hz	Frequency ramp balancing reference.	See par. 46.02
28.79	Freq ramp output balancing enable	Selects the source for enabling/disabling speed ramp balancing. See parameter 28.78 Freq ramp output balancing.  0 = Disabled 1 = Enabled	Not selected
	Not selected	0.	
	Selected	1.	
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
28.90	Frequency ref act 1	Displays the value of frequency reference source 1 (selected by parameter 28.11 Frequency ref1 source). See the control chain diagram on page 573.  This parameter is read-only.	-
	-500.00500.00 Hz	Value of frequency reference source 1.	See par. 46.02
28.91	Frequency ref act 2	Displays the value of frequency reference source 2 (selected by parameter 28.12 Frequency ref2 source). See the control chain diagram on page 573.  This parameter is read-only.	-
	-500.00500.00 Hz	Value of frequency reference source 2.	See par. 46.02
28.92	Frequency ref act 3	Displays the frequency reference after the function applied by parameter 28.13 Frequency ref1 function (if any), and after selection (28.14 Frequency ref1/2 selection). See the control chain diagram on page 573.  This parameter is read-only.	-
	-500.00500.00 Hz	Frequency reference after selection.	See par. 46.02

0000h...FFFFh

Limit word 1.

No.	Name/Value	Description	Def/ FbEq16
28.96	Frequency ref act 7	Displays the frequency reference after application of constant frequencies, control panel reference, etc. See the control chain diagram on page 573.  This parameter is read-only.	-
	-500.00500.00 Hz	Frequency reference 7.	See par. 46.02
28.97	Frequency ref unlimited	Displays the frequency reference after application of critical frequencies, but before ramping and limiting. See the control chain diagram on page 573.  This parameter is read-only.	-
	-500.00500.00 Hz	Frequency reference before ramping and limiting.	See par. 46.02

30 Limits	Drive operation limits.	
30.01 Limit word 1	Displays limit word 1. This parameter is read-only.	-

Bit	Name	Description
0	Torq lim	1 = Drive torque is being limited by the motor control (undervoltage control, current control, load angle control or pull-out control), or by the torque limits defined by parameters.
1	Spd ctl tlim min	1 = Speed controller output is being limited by 25.11 Speed control min torque
2	Spd ctl tlim max	1 = Speed controller output is being limited by 25.12 Speed control max torque
3	Torq ref max	1 = Torque reference ramp input is being limited by 26.09 Maximum torque ref, source of 30.25 Minimum torque sel, 30.26 Power motoring limit or 30.27 Power generating limit.
4	Torq ref min	1 = Torque reference ramp input is being limited by 26.08 Minimum torque ref, source of 30.18 Minimum torque sel, 30.26 Power motoring limit or 30.27 Power generating limit.
5	Tlim max speed	1 = Torque reference is being limited by the rush control because of maximum speed limit (30.12 Maximum speed)
6	Tlim min speed	1 = Torque reference is being limited by the rush control because of minimum speed limit (30.11 Minimum speed)
7	Max speed ref lim	Speed reference is being limited by 30.12 Maximum speed or maximum permanent magnet motor speed limit based on DC voltage
8	Min speed ref lim	Speed reference is being limited by 30.11 Minimum speed or maximum permanent magnet motor speed limit based on DC voltage
9	Max freq ref lim	1 = Frequency reference is being limited by 30.14 Maximum frequency
10	Min freq ref lim	1 = Frequency reference is being limited by 30.13 Minimum frequency
11	Reserved	
12	Sw freq ref lim	1 = Requested output frequency cannot be reached because of switching frequency limitation (because of output filtering or ATEX-related protections)
1315	Reserved	

1 = 1

No.	Name/Value	Description	Def/ FbEq16
30.02	Torque limit status	Displays the torque controller limitation status word. This parameter is read-only.	-

Bit	Name	Description	
0	Undervoltage	*1 = Intermediate DC circuit undervoltage	
1	Overvoltage	*1 = Intermediate DC circuit overvoltage	
2	Minimum torque	*1 = Torque is being limited by 30.19 Minimum torque 1, 30.26 Power motoring limit or 30.27 Power generating limit	
3	Maximum torque	*1 = Torque is being limited by 30.20 Maximum torque 1, 30.26 Power motoring limit or 30.27 Power generating limit	
4	Internal current	1 = An inverter current limit (identified by bits 811) is active	
5	Load angle	(With permanent magnet motors and synchronous reluctance motors only)	
		1 = Load angle limit is active, ie. the motor cannot produce any more torque	
6	Motor pullout	(With asynchronous motors only)  1 = Motor pull-out limit is active, ie. the motor cannot produce any more torque	
7	Reserved		
8	Thermal	1 = Input current is being limited by the main circuit thermal limit	
9	Max current	*1 = Maximum output current (I <sub>MAX</sub> ) is being limited	
10	User current	*1 = Output current is being limited by 30.17 Maximum current	
11	Thermal IGBT	*1 = Output current is being limited by a calculated thermal current value	
12	IGBT overtemperature	re *1 = Output current is being limited because of estimated IGBT temperature	
13	IGBT overload	*1 = Output current is being limited because of IGBT junction to case temperature	
1415	Reserved		
*Only or	e out of bits 03, and o	ne out of bits 913 can be on simultaneously. The bit typically	

indicates the limit that is exceeded first.

		<u> </u>	
	0000hFFFFh	Torque limitation status word.	1 = 1
30.11	Minimum speed	Defines the minimum allowed speed.  WARNING!  This value must not be higher than 30.12 Maximum speed.  In frequency control mode, this limit is not effective. Make sure the frequency limits (30.13 and 30.14) are set appropriately if frequency control is used.	-1500.00 rpm; -1800.00 rpm (95.20 b0)
	-30000.00 30000.00 rpm	Minimum allowed speed.	See par. 46.01
30.12	Maximum speed	Defines the maximum allowed speed.  WARNING! This value must not be lower than 30.11 Minimum speed.  WARNING! In frequency control mode, this limit is not effective. Make sure the frequency limits (30.13 and 30.14) are set appropriately if frequency control is used.	1500.00 rpm; 1800.00 rpm (95.20 b0)
	-30000.00 30000.00 rpm	Maximum speed.	See par. 46.01

No.	Name/Value	Description	Def/ FbEq16
30.13	Minimum frequency	Defines the minimum allowed frequency.  WARNING! This value must not be higher than 30.14 Maximum frequency.  WARNING! This limit is effective in frequency control mode only.	-50.00 Hz; -60.00 Hz (95.20 b0)
	-500.00500.00 Hz	Minimum frequency.	See par. 46.02
30.14	Maximum frequency	Defines the maximum allowed frequency.  WARNING! This value must not be lower than 30.13 Minimum frequency.  WARNING! This limit is effective in frequency control mode only.	50.00 Hz; 60.00 Hz (95.20 b0)
	-500.00500.00 Hz	Maximum frequency.	See par. 46.02
30.15	Maximum start current enable	A temporary motor current limit specifically for starting can be defined by this parameter and 30.16 Maximum start current.  When this parameter is set to Enable, the drive observes the start current limit defined by 30.16 Maximum start current. The limit is in force for 2 seconds after initial magnetization (of an asynchronous induction motor) or autophasing (of a permanent magnet motor), but not more often than once in every 7 seconds. Otherwise, the limit defined by 30.17 Maximum current is in force.  Note: The availability of a start current higher than the general limit depends on drive hardware.	Disable
	Disable	Start current limit disabled.	0
	Enable	Start current limit enabled.	1
30.16	Maximum start current	Defines the maximum start current when enabled by parameter 30.15 Maximum start current enable.	0.00 A
	0.0030000.00 A	Maximum motor start current.	1 = 1 A
30.17	Maximum current	Defines the maximum allowed motor current.	0.00 A
	0.0030000.00 A	Maximum motor current.	1 = 1 A

No.	Name/Value	Description	Def/ FbEq16
30.18	Minimum torque sel	Selects a source that switches between two different predefined minimum torque limits.  0 = Minimum torque limit defined by 30.19 is active  1 = Minimum torque limit selected by 30.21 is active  The user can define two sets of torque limits, and switch between the sets using a binary source such as a digital input. The minimum limit selection (30.18) is independent of the maximum limit selection (30.25).  The first set of limits is defined by parameters 30.19 and 30.20. The second set has selector parameters for both the minimum (30.21) and maximum (30.22) limits that allows the use of a selectable analog source (such as an analog input).	Minimum torque 1
		30.21 0 Al1 Al2 PID 30.23 Other 30.19 30.22	
		O Al1 Al2 PID 30.24 Other User-defined maximum torque limit	
		The limit selection parameters are updated on a 10 ms time level.  Note: In addition to the user-defined limits, torque may be limited for other reasons (such as power limitation).	
	Minimum torque 1	0 (minimum torque limit defined by 30.19 is active).	0
	Minimum torque 2 source	1 (minimum torque limit selected by 30.21 is active).	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-

No.	Name/Value	Description	Def/ FbEq16
30.19	Minimum torque 1	Defines a minimum torque limit for the drive (in percent of nominal motor torque). See diagram at parameter 30.18 Minimum torque sel.  The limit is effective when  • the source selected by 30.18 Minimum torque sel is 0, or  • 30.18 is set to Minimum torque 1.  Note: Do not set this parameter to 0% in an attempt to prevent reverse rotation. In an open-loop application, that is likely to prevent the motor from stopping altogether. To prevent reverse rotation, use the speed/frequency limits in this parameter group, or parameters 20.23/20.24.	-300.0%
	-1600.00.0%	Minimum torque limit 1.	See par. 46.03
30.20	Maximum torque 1	Defines a maximum torque limit for the drive (in percent of nominal motor torque). See diagram at parameter 30.18 Minimum torque sel.  The limit is effective when  the source selected by 30.25 Maximum torque sel is 0, or  30.25 is set to Maximum torque 1.	300.0%
	0.01600.0%	Maximum torque 1.	See par. 46.03
30.21	Minimum torque 2 source	Defines the source of the minimum torque limit for the drive (in percent of nominal motor torque) when  • the source selected by parameter 30.18 Minimum torque sel is 1, or  • 30.18 is set to Minimum torque 2 source.  See diagram at 30.18 Minimum torque sel.  Note: Any positive values received from the selected source are inverted.	Minimum torque 2
	Zero	None.	0
	Al1 scaled	12.12 Al1 scaled value (see page 169).	1
	Al2 scaled	12.22 Al2 scaled value (see page 170).	2
	Minimum torque 2	30.23 Minimum torque 2.	6
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
30.22	Maximum torque 2 source	Defines the source of the maximum torque limit for the drive (in percent of nominal motor torque) when  the source selected by parameter 30.25  is 1, or  30.25 is set to Maximum torque 2 source. See diagram at 30.18 Minimum torque sel.  Note: Any negative values received from the selected source are inverted.	Maximum torque 2
	Zero	None.	0
	Al1 scaled	12.12 Al1 scaled value (see page 169).	1
	Al2 scaled	12.22 Al2 scaled value (see page 170).	2
	Maximum torque 2	30.24 Maximum torque 2.	6
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-

No.	Name/Value	Description	Def/ FbEq16
30.23	Minimum torque 2	Defines the minimum torque limit for the drive (in percent of nominal motor torque) when  • the source selected by parameter 30.18 Minimum torque sel is 1, and  • 30.21 is set to Minimum torque 2.  Note: Do not set this parameter to 0% in an attempt to prevent reverse rotation. In an open-loop application, that is likely to prevent the motor from stopping altogether. To prevent reverse rotation, use the speed/frequency limits in this parameter group, or parameters 20.23/20.24.  See diagram at 30.18 Minimum torque sel.	-300.0%
	-1600.00.0%	Minimum torque limit 2.	See par. 46.03
30.24	Maximum torque 2	Defines the maximum torque limit for the drive (in percent of nominal motor torque) when  the source selected by parameter 30.25 Maximum torque sel is 1, and  30.22 is set to Maximum torque 2. See diagram at 30.18 Minimum torque sel.	300.0%
	0.01600.0%	Maximum torque limit 2.	See par. 46.03
30.25	Maximum torque sel	Selects a source that switches between two different maximum torque limits.  0 = Maximum torque limit 1 defined by 30.20 is active 1 = Maximum torque limit selected by 30.22 is active See also parameter 30.18 Minimum torque sel.	Maximum torque 1
	Maximum torque 1	0.	0
	Maximum torque 2 source	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
30.26	Power motoring limit	Defines the maximum shaft power in motoring mode, ie. when power is being transferred from the motor to the machinery. The value is given in percent of nominal motor power.	300.00%
	0.00600.00%	Maximum shaft power in motoring mode.	1 = 1%

No.	Name/Value	Description	Def/ FbEq16
30.27	Power generating limit	Defines the maximum shaft power in generating mode, ie. when power is being transferred from the machinery to the motor. The value is given in percent of nominal motor power.  Note: Do not set this parameter to 0% in an attempt to prevent reverse rotation. In an open-loop application, that is likely to prevent the motor from stopping altogether. To prevent reverse rotation, use the speed/frequency limits in this parameter group, or parameters 20.23/20.24.	-300.00%
	-600.000.00%	Maximum shaft power in generating mode.	1 = 1%
30.30	Overvoltage control	Enables the overvoltage control of the intermediate DC link. Fast braking of a high inertia load causes the voltage to rise to the overvoltage control limit. To prevent the DC voltage from exceeding the limit, the overvoltage controller automatically decreases the braking torque.  Note: If the drive is equipped with a brake chopper and resistor, or a regenerative supply unit, the controller must be disabled.	Enable
	Disable	Overvoltage control disabled.	0
	Enable	Overvoltage control enabled.	1
30.31	Undervoltage control	Enables the undervoltage control of the intermediate DC link. If the DC voltage drops due to input power cut off, the undervoltage controller will automatically decrease the motor torque in order to keep the voltage above the lower limit. By decreasing the motor torque, the inertia of the load will cause regeneration back to the drive, keeping the DC link charged and preventing an undervoltage trip until the motor coasts to a stop. This will act as a power-loss ride-through functionality in systems with high inertia, such as a centrifuge or a fan.	Enable
	Disable	Undervoltage control disabled.	0
	Enable	Undervoltage control enabled.	1
30.35	Thermal current limitation	Enables/disables temperature-based output current limitation. The limitation should only be disabled if required by the application.	Enable
	Disable	Undervoltage control disabled.	0
	Enable	Undervoltage control enabled.	1

1 = 1

No.	Name/	Value	Description	Def/ FbEq16
0.101	1 LSU limit word 1		(Only visible when IGBT supply unit control activated by 95.20) Displays limit word 1 of the supply unit.	-
			This parameter is read-only.	
	Bit	Name	Description	
	0	P user ref ma	-	program
	1	P user ref mi	parameters	
	2	P user max	1 = Power is being limited by parameter 30.149	
	3	P user min	1 = Power is being limited by parameter 30.148	
	4	P cooling overtemp	1 = Power reference is being limited because of cools overtemperature	int
	5	P power unit overtemp	1 = Power reference is being limited because of supp overtemperature	ly unit
	615	Reserved		
	0000h	FFFFh	Supply unit limit word 1.	1 = 1
0.102	LSU lim	nit word 2	(Only visible when IGBT supply unit control activated by 95.20) Displays limit word 2 of the supply unit.	-
			This parameter is read-only.	
	Bit	Name	Description	
	0	Q user ref ma	-	
	1	Q user ref mi		
	2	Q cooling overtemp	1 = Reactive power reference is being limited becaus overtemperature	e of coolant
	3	Q power unit overtemp	1 = Reactive power reference is being limited becaus overtemperature	e of supply ur
	4	AC overvolta	ge 1 = AC overvoltage protection	
	56	Reserved		
	7	AC diff max	1 = (When AC voltage-type reactive power reference	is being used
	8	AC diff min	Input of AC control is being limited	•
	915 Reserved		l	

Supply unit limit word 2.

0000h...FFFFh

No.	Name/\	/alue	Description	Def/ FbEq16	
0.103	LSU lim	it word 3	(Only visible when IGBT supply unit control activated by 95.20) Displays limit word 3 of the supply unit. This parameter is read-only.	-	
	Bit	Name	Description		
	0	Undervoltage limit	1 = Power is being limited by the undervoltage controlle	er	
	1	Overvoltage lii	mit 1 = Power is being limited by the overvoltage controller		
	2	Motoring power		er limits (see	
	3	Generating power	parameters 30.148 and 30.149)		
	4	Active current limit	1 = Active current is being limited. For details, see bits 1415.	69 and	
	5	Reactive curre	ent 1 = Reactive current is being limited. For details, see bi	ts 1213.	
	6	Thermal limit	1 = Active current is being limited by internal main circu	it thermal lim	
	7	SOA limit	1 = Active current is being limited by internal safe opera	ation area lim	
	8		mit 1 = Active current is being limited by current limit set by program parameters	supply contr	
	9	Thermal IGBT	1 = Active current is being limited based on internal maximum therma IGBT stress limit		
	1011	Reserved			
	12	Q act neg	1 = Negative reactive current is being limited by maximum total current		
	13	Q act pos	Positive reactive current is being limited by maximum total current     Negative active current is being limited by maximum total current     Positive active current is being limited by maximum total current		
	14	P act neg			
	15	P act pos			
	0000h	.FFFFh	Supply unit limit word 3.	1 = 1	
0.104	95. Dis		(Only visible when IGBT supply unit control activated by 95.20) Displays limit word 4 of the supply unit. This parameter is read-only.	-	
	Bit	Name	Description		
	0	Udc ref max	1 = DC reference is being limited by supply control prog	gram	
	1	Udc ref min	parameters		
	2	User I max	1 = Current is being limited by supply control program p	parameters	
	3	Temp I max	1 = Current is being limited based on temperature	1 = Current is being limited based on temperature	
	415	Reserved			
	0000h	.FFFFh	Supply unit limit word 4.	1 = 1	
0.148	LSU mii limit	nimum power	(Only visible when IGBT supply unit control activated by 95.20)	-130.0%	
			Defines a minimum power limit for the supply unit.  Negative values refer to regenerating, ie. feeding power into the supply network.		

No.	Name/Value	Description	Def/ FbEq16
30.149	LSU maximum power limit	(Only visible when IGBT supply unit control activated by 95.20) Defines a maximum power limit for the supply unit.	130.0%
	0.0 200.0%	Maximum power limit for supply unit.	1 = 1%

31 Fa	ult functions	Configuration of external events; selection of behavior of the drive upon fault situations.	
31.01	External event 1 source	Defines the source of external event 1. See also parameter 31.02 External event 1 type. 0 = Trigger event 1 = Normal operation	Inactive (true); DI6 (95.20 b8)
	Active (false)	0.	0
	Inactive (true)	1.	1
	DIIL	DIIL input (10.02 DI delayed status, bit 15).	2
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	3
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	4
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	5
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	6
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	7
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	8
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	11
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	12
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
31.02	External event 1 type	Selects the type of external event 1.	Fault (95.20 b8)
	Fault	The external event generates a fault.	0
	Warning	The external event generates a warning.	1
	Warning/Fault	If the drive is modulating, the external event generates a fault. Otherwise, the event generates a warning.	3
31.03	External event 2 source	Defines the source of external event 2. See also parameter 31.04 External event 2 type. For the selections, see parameter 31.01 External event 1 source.	Inactive (true), DIIL (95.20 b8)
31.04	External event 2 type	Selects the type of external event 2.	
	Fault	The external event generates a fault.	0
	Warning	The external event generates a warning.	1
	Warning/Fault	If the drive is modulating, the external event generates a fault. Otherwise, the event generates a warning.	3
31.05	External event 3 source	Defines the source of external event 3. See also parameter 31.06 External event 3 type. For the selections, see parameter 31.01 External event 1 source.	Inactive (true)
31.06	External event 3 type	Selects the type of external event 3.	
	Fault	The external event generates a fault.	0
	Warning	The external event generates a warning.	1

No.	Name/Value	Description	Def/ FbEq16
	Warning/Fault	If the drive is modulating, the external event generates a fault. Otherwise, the event generates a warning.	3
31.07	External event 4 source	Defines the source of external event 4. See also parameter 31.08 External event 4 type. For the selections, see parameter 31.01 External event 1 source.	Inactive (true)
31.08	External event 4 type	Selects the type of external event 4.	
	Fault	The external event generates a fault.	0
	Warning	The external event generates a warning.	1
	Warning/Fault	If the drive is modulating, the external event generates a fault. Otherwise, the event generates a warning.	3
31.09	External event 5 source	Defines the source of external event 5. See also parameter 31.10 External event 5 type. For the selections, see parameter 31.01 External event 1 source.	Inactive (true)
31.10	External event 5 type	Selects the type of external event 5.	
	Fault	The external event generates a fault.	0
	Warning	The external event generates a warning.	1
	Warning/Fault	If the drive is modulating, the external event generates a fault. Otherwise, the event generates a warning.	3
31.11	Fault reset selection	Selects the source of an external fault reset signal. This signal will be observed even if it is not the active source in the current control location (EXT1/EXT2/Local). (A reset from the active source will be observed regardless of this parameter.)  0 -> 1 = Reset	Not selected
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	FBA A MCW bit 7	Control word bit 7 received through fieldbus interface A.	30
	EFB MCW bit 7	Control word bit 7 received through the embedded fieldbus interface.	32
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-

No.	. Name/Value		Description	Def/ FbEq16
31.12			Selects faults that are automatically reset. The parameter is a 16-bit word with each bit corresponding to a fault type. Whenever a bit is set to 1, the corresponding fault is automatically reset.  The number and interval of reset attempts are defined by parameters 31.1431.16.  Note:  The autoreset function is only available in external control; see section Local control vs. external control (page 54).  Faults related to the Safe torque off (STO) function cannot be automatically reset.  The bits of this binary number correspond to the following faults:	0000h
	Bit	Fault		
	0	Overcurren	t	
	1	Overvoltage	е	
	2	Undervolta	ge	
	3	Al supervis	ion fault	
	4	Supply unit		
	57	Reserved		
	8	Application	fault 1 (defined in the application program)	
	9		fault 2 (defined in the application program)	
	10		fault (see parameter 31.13 User selectable fault)	
	11	External fau	ult 1 (from source selected by parameter 31.01 External even	t 1 source)
	12		ult 2 (from source selected by parameter 31.03 External even	
	13		ult 3 (from source selected by parameter 31.05 External even	
	14		ult 4 (from source selected by parameter 31.07 External even	
	15	External fau	ult 5 (from source selected by parameter 31.09 External even	t 5 source)
	0000hF	FFFh	Automatic reset configuration word.	1 = 1
31.13	User sele	ctable fault	Defines the fault that can be automatically reset using parameter 31.12 Autoreset selection, bit 10. The faults are listed in chapter Fault tracing (page 473).	0000h
	0000hF	FFFh	Fault code.	10 = 1
31.14	1.14 Number of trials		Defines the maximum number of automatic resets that the drive is allowed to attempt within the time specified by 31.15 Total trials time.  If the fault persists, subsequent reset attempts will be made at intervals defined by 31.16 Delay time.  The faults to be automatically reset are defined by 31.12 Autoreset selection.	-
	05		Number of automatic resets.	1 = 1

No.	Name/Value	Description	Def/ FbEq16
31.15	Total trials time	Defines a time window for automatic fault resets. The maximum number of attempts made during any period of this length is defined by 31.14 Number of trials.  Note: If the fault condition remains and cannot be reset, each reset attempt will generate an event and start a new time window. In practice, if the specified number of resets (31.14) at specified intervals (31.16) take longer than the value of 31.15, the drive will continue to attempt resetting the fault until the cause is eventually removed.	30.0 s
	1.0600.0 s	Time for automatic resets.	10 = 1 s
31.16	Delay time	Defines the time that the drive will wait after a fault (or a previous reset attempt) before attempting an automatic reset. See parameter 31.12 Autoreset selection.	0.0 s
	0.0120.0 s	Autoreset delay.	10 = 1 s
31.19	Motor phase loss	Selects how the drive reacts when a motor phase loss is detected.  Note: The drive may not be able to reliably detect a phase loss in a multimotor application: a separate protection method (eg. a motor protection switch) should be installed for each motor.	Fault
	No action	No action taken.	0
	Fault	The drive trips on fault 3381 Output phase loss.	1
31.20	Earth fault	Selects how the drive reacts when an earth fault or current unbalance is detected in the motor or the motor cable. See also section <i>Earth (Ground) fault detection (parameter 31.20)</i> (page 100).	Fault
	No action	No action taken.	0
	Warning	The drive generates an A2B3 Earth leakage warning.	1
	Fault	The drive trips on fault 2330 Earth leakage.	2

No.	Name/Value	Descr	iptior	1		Def/ FbEq16
31.22	STO indication run/stop	Selects which indications are given when one or both Safe torque off (STO) signals are switched off or lost. The indications also depend on whether the drive is running or stopped when this occurs.  The tables at each selection below show the indications generated with that particular setting.  Notes:  This parameter does not affect the operation of the STO function itself. The STO function will operate regardless of the setting of this parameter: a running drive will stop upon removal of one or both STO signals, and will not start until both STO signals are restored and all faults reset.  The loss of only one STO signal always generates a fault as it is interpreted as a malfunction.  This parameter cannot be changed while the drive is running.  For more information on the STO, see the Hardware manual of the drive.			Fault/Fault	
	Fault/Fault					0
		Input	s	Indication (running	ng or stopped)	
		IN1	IN2		.g c. ctoppou)	
		0	11.1			
		0				
		1	0		orque off and FA82 Safe	
			4	torque off 2 loss		
		1	1	(Normal operation)		
	Fault/Warning	1				1
	Ŭ	Inpu	ts	Indication		
		IN1	IN2		Stopped	
		0	0	Fault 5091 Safe	Warning <i>A5A0 Safe</i>	
				torque off	torque off	
		0	1	Faults 5091 Safe torque off and FA81	Warning A5A0 Safe torque off and fault	
				Safe torque off 1	FA81 Safe torque off 1	
				loss	loss	
		1	0	Faults 5091 Safe	Warning A5A0 Safe	
				torque off and FA82 Safe torque off 2	torque off and fault FA82 Safe torque off 2	
				loss	loss	
			4 4 (A) 1 (C)			

No.	Name/Value	Description				Def/ FbEq16
	Fault/Event					2
		Inpu	outs Indication			
		IN1	IN2	Running	Stopped	
		0	0	Fault 5091 Safe torque off	Event B5A0 STO event	
		0	1	Faults 5091 Safe	Event B5A0 STO	
				torque off and FA81 Safe torque off 1 loss	event and fault FA81 Safe torque off 1 loss	
		1	0	Faults 5091 Safe	Event B5A0 STO	
				torque off and FA82 Safe torque off 2 loss	event and fault FA82 Safe torque off 2 loss	
		1	1	(Normal operation)	Sale torque on 2 loss	
		l.	ı	1 /		
	Warning/Warning					3
		Inpu		Indication (running	or stopped)	
		IN1	IN2		-	
		0	0	Warning A5A0 Safe to		
		0	1	Warning A5A0 Safe to FA81 Safe torque off	orque oπ and fault 1 loss	
		1	0	Warning A5A0 Safe to	orque off and fault	
		l	ļ	FA82 Safe torque off	2 loss	
		1	1	(Normal operation)		
	Event/Event				4	
		Inpu	ıts	Indication (running	or stopped)	
		IN1	IN2	_ ` `	, or otoppou,	
		0	0	Event B5A0 STO ev	ent	
		0	1	Event B5A0 STO eventorque off 1 loss	ent and fault FA81 Safe	
		1	0	Event B5A0 STO eve		
				torque off 2 loss		
		1	1	(Normal operation)		
No indication/No					5	
	indication	Inpu	ıte	Indication (running	ag or stopped)	
		IN1	IN2		ig or stopped)	
		0	0	None		
		0	1	Fault FA81 Safe to	rque off 1 loss	
		1	0	Fault FA82 Safe to	rque off 2 loss	
		1	1	(Normal operation)		
31.23	Wiring or earth fault	motor conne Note:	cable cted t The p	e connection (i.e. input to drive motor connecti	on). bled with drive/inverter	Fault, No action (95.20 b15)
	No action	No action taken (protection disabled).				0
	Fault	The drive trips on fault 3181 Cross connection.			1	
<u> </u>			- "			

No.	Name/Value	Description	Def/ FbEq16
31.24	Stall function	Selects how the drive reacts to a motor stall condition. A stall condition is defined as follows: The drive exceeds the stall current limit (31.25 Stall current limit), and the output frequency is below the level set by parameter 31.27 Stall frequency limit or the motor speed is below the level set by parameter 31.26 Stall speed limit, and the conditions above have been true longer than the time set by parameter 31.28 Stall time.	Fault
	No action	None (stall supervision disabled).	0
	Warning	The drive generates an A780 Motor stall warning.	1
	Fault	The drive trips on fault 7121 Motor stall.	2
31.25	Stall current limit	Stall current limit in percent of the nominal current of the motor. See parameter 31.24 Stall function.	200.0%
	0.01600.0%	Stall current limit.	10 = 1%
31.26	Stall speed limit	Stall speed limit in rpm. See parameter 31.24 Stall function.	150.00 rpm; 180.00 rpm (95.20 b0)
	0.0010000.00 rpm	Stall speed limit.	See par. 46.01
31.27	Stall frequency limit	Stall frequency limit. See parameter 31.24 Stall function.  Note: Setting the limit below 10 Hz is not recommended.	15.00 Hz; 18.00 Hz (95.20 b0)
	0.00500.00 Hz	Stall frequency limit.	See par. 46.02
31.28	Stall time	Stall time. See parameter 31.24 Stall function.	20 s
	03600 s	Stall time.	1 = 1s

No.	Name/Value	Description	Def/ FbEq16
31.30	Overspeed trip margin	Defines, together with 30.11 Minimum speed and 30.12 Maximum speed, the maximum allowed speed of the motor (overspeed protection). If 90.01 Motor speed for control exceeds the speed limit defined by parameter 30.11 or 30.12 by more than the value of this parameter, the drive trips on the 7310 Overspeed fault.  Example: If the maximum speed is 1420 rpm and speed trip margin is 300 rpm, the drive trips at 1720 rpm.  Speed (90.01)  Overspeed trip level  31.30  Time  30.11	500.00 rpm
	0.0010000.0 rpm	Overspeed trip margin.	See par. 46.01
31.32	Emergency ramp supervision	Parameters 31.32 Emergency ramp supervision and 31.33 Emergency ramp supervision delay, together with 01.29 Speed change rate, provide a supervision function for emergency stop modes Off1 and Off3.  The supervision is based on either  • observing the time within which the motor stops, or  • comparing the actual and expected deceleration rates. If this parameter is set to 0%, the maximum stop time is directly set in parameter 31.33. Otherwise, 31.32 defines the maximum allowed deviation from the expected deceleration rate, which is calculated from parameters 23.1123.19 (Off1) or 23.23 Emergency stop time (Off3). If the actual deceleration rate (01.29) deviates too much from the expected rate, the drive trips on 73B0 Emergency ramp failed, sets bit 8 of 06.17 Drive status word 2, and coasts to a stop. If 31.32 is set to 0% and 31.33 is set to 0 s, the emergency stop ramp supervision is disabled.  See also parameter 21.04 Emergency stop mode.	0%
	0300%	Maximum deviation from expected deceleration rate.	1 = 1%

No.	Name/Value	Description	Def/ FbEq16
31.33	Emergency ramp supervision delay	If parameter 31.32 Emergency ramp supervision is set to 0%, this parameter defines the maximum time an emergency stop (mode Off1 or Off3) is allowed to take. If the motor has not stopped when the time elapses, the drive trips on 73B0 Emergency ramp failed, sets bit 8 of 06.17 Drive status word 2, and coasts to a stop. If 31.32 is set to a value other than 0%, this parameter defines a delay between the receipt of the emergency stop command and the activation of the supervision. It is recommended to specify a short delay to allow the speed change rate to stabilize.	0 s
	032767 s	Maximum ramp-down time, or supervision activation delay.	1 = 1 s
31.35	Main fan fault function	Selects how the drive reacts when a main cooling fan fault is detected.  Note: With an inverter unit consisting of one or more frame R8i inverter modules with speed-controlled fans, it may be possible to continue operation even if one main fan of a module stops. When fan failure is detected, the control program will automatically  • set the other fan of the module to full speed  • set the fans of the other modules (if any) to full speed  • decrease the switching frequency to a minimum, and  • disable the supervision of temperature difference between the modules.  If this parameter is set to Fault, the inverter unit will trip (but still carry out the actions listed above). Otherwise, the inverter will attempt to continue operation	Fault
	Fault	The drive trips on fault 5080 Fan.	0
	Warning	The drive generates an <i>A581 Fan</i> warning.	1
	No action	No action taken.	2
31.36	Aux fan fault function	(Only visible with a ZCU control unit) Selects how the drive reacts when an auxiliary fan fault is detected.	Fault
	Fault	The drive trips on fault 5081 Auxiliary fan not running.  Note: The fault is suppressed for two minutes after power-up. During this time, the drive only generates a warning, A582 Auxiliary fan not running.	0
	Warning	The drive generates a warning, A582 Auxiliary fan not running.	1

No.	Name/V	'alue	e Description			
31.37 Ramp stop supervision			Parameters 31.37 Ramp stop supervision and 31.38 Ramp stop supervision delay, together with 01.29 Speed change rate, provide a supervision function for normal (ie. non-emergency) ramp stopping.  The supervision is based on either  • observing the time within which the motor stops, or  • comparing the actual and expected deceleration rates. If this parameter is set to 0%, the maximum stop time is directly set in parameter 31.38. Otherwise, 31.37 defines the maximum allowed deviation from the expected deceleration rate, which is calculated from parameters 23.1123.19. If the actual deceleration rate (01.29) deviates too much from the expected rate, the drive trips on 73B1 Stop failed, sets bit 14 of 06.17 Drive status word 2, and coasts to a stop. If 31.37 is set to 0% and 31.38 is set to 0 s, the ramp stop supervision is disabled.	0%		
	0300%	, 0	Maximum deviation from expected deceleration rate.	1 = 1%		
31.38	Ramp st supervis	op ion delay	If parameter 31.37 Ramp stop supervision is set to 0%, this parameter defines the maximum time a ramp stop is allowed to take. If the motor has not stopped when the time elapses, the drive trips on 73B1 Stop failed, sets bit 14 of 06.17 Drive status word 2, and coasts to a stop. If 31.37 is set to a value other than 0%, this parameter defines a delay between the receipt of the stop command and the activation of the supervision. It is recommended to specify a short delay to allow the speed change rate to stabilize.	0 s		
	032767 s		Maximum ramp-down time, or supervision activation delay.	1 = 1 s		
31.40 Disable warning messages		•	Selects warnings to be suppressed. The parameter is a 16-bit word with each bit corresponding to a warning. Whenever a bit is set to 1, the corresponding warning is suppressed.  The bits of this binary number correspond to the following warnings:	0000Ь		
	Bit Fault			<del></del>		
	0	Overvoltage		<del>-  </del>		
	1	Reserved				
	2	Encoder 1				
	3	Encoder 2				
	4	CU (Control u	ınit) battery			
	515	Reserved				
	000b1	101b	Warning suppression word.	1 = 1		

No.	Name/V	alue	Description		Def/ FbEq16
31.42	Overcurr	ent fault limit	The drive au according to appropriate it to set a lowe permanent ments. The limphase.	m motor current fault limit. tomatically sets an internal motor current limit the drive hardware. The internal limit is n most cases, but this parameter can be used r current limit, for example, to protect a nagnet motor from demagnetization. nit defines the maximum peak current of one ameter at 0.0 A, only the internal limit is in	
	0.00 3	80000.00 A	Custom moto	or current fault limit	-
31.54	Fault act	ion	Selects the s	stop mode when a non-critical fault occurs.	Coast
	Coast		The drive coa	asts to a stop.	0
	Emerger	ncy ramp		lows the ramp specified for an emergency neter 23.23 Emergency stop time.	1
31.120	LSU eart	th fault	95.20) Selects how	when IGBT supply unit control activated by the supply unit reacts when an earth fault or lance is detected.	Fault
	No action	n	No action tak	ken.	0
	Warning		The supply u warning.	nit generates an AE02 Earth leakage	1
	Fault		The supply u	ınit trips on fault <i>2E01 Earth leakage</i> .	2
31.121	LSU sup loss	ply phase	95.20)	when IGBT supply unit control activated by the supply unit reacts when a supply phase ted.	Fault
	No action	n	No action taken.		0
	Fault		The supply u	nit trips on fault 3E00 Input phase loss.	1
32 Supervision			Three values fault is gener exceeded.	n of signal supervision functions 13. s can be chosen to be monitored; a warning or rated whenever predefined limits are stion Signal supervision (page 102).	
32.01	Supervis	ion status	Indicates who supervision f limits.  Note: This w	vision status word. ether the values monitored by the signal unctions are within or outside their respective word is independent of the drive actions arameters 32.06, 32.16 and 32.26.	0000Ь
	Bit Name 0 Supervision 1			Description	1
			•		S.
	1	Supervision 2		1 = Signal selected by 32.17 is outside its limit	
	2	Supervision 3		1 = Signal selected by 32.27 is outside its limit	
	315 Reserved			· ·	
		•			
	00000	111b	Signal super	vision status word.	1 = 1

No.	Name/Value	Description	Def/ FbEq16
32.05	Supervision 1 function	Selects the mode of signal supervision function 1.  Determines how the monitored signal (see parameter 32.07) is compared to its lower and upper limits (32.09 and 32.10 respectively). The action to be taken when the condition is fulfilled is selected by 32.06.	Disabled
	Disabled	Signal supervision 1 not in use.	0
	Low	Action is taken whenever the signal falls below its lower limit.	1
	High	Action is taken whenever the signal rises above its upper limit.	2
	Abs low	Action is taken whenever the absolute value of the signal falls below its (absolute) lower limit.	3
	Abs high	Action is taken whenever the absolute value of the signal rises above its (absolute) upper limit.	4
	Both	Action is taken whenever the signal falls below its low limit or rises above its high limit.	5
	Abs both	Action is taken whenever the absolute value of the signal falls below its (absolute) low limit or rises above its (absolute) high limit.	6
32.06	Supervision 1 action	Selects the action the drive takes when the value monitored by signal supervision 1 exceeds its limits. Note: This parameter does not affect the status indicated by 32.01 Supervision status.	No action
	No action	No action taken.	0
	Warning	A warning (A8B0 Signal supervision) is generated.	1
	Fault	The drive trips on 80B0 Signal supervision.	2
	Fault if running	If running, the drive trips on 80B0 Signal supervision.	3
32.07	Supervision 1 signal	Selects the signal to be monitored by signal supervision function 1.	Zero
	Zero	None.	0
	Speed	01.01 Motor speed used (page 121).	1
	Frequency	01.06 Output frequency (page 121).	3
	Current	01.07 Motor current (page 121).	4
	Torque	01.10 Motor torque (page 121).	6
	DC voltage	01.11 DC voltage (page 122).	7
	Output power	01.14 Output power (page 122).	8
	Al1	12.11 Al1 actual value (page 168).	9
	Al2	12.21 Al2 actual value (page 170).	10
	Speed ref ramp in	23.01 Speed ref ramp input (page 231).	18
	Speed ref ramp out	23.02 Speed ref ramp output (page 232).	19
	Speed ref used	24.01 Used speed reference (page 238).	20
	Torque ref used	26.02 Torque reference used	21
	Freq ref used	28.02 Frequency ref ramp output (page 257).	22
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-

No.	Name/Value	Description	Def/ FbEq16
32.08	Supervision 1 filter time	Defines a filter time constant for the signal monitored by signal supervision 1.	0.000 s
	0.00030.000 s	Signal filter time.	1000 = 1 s
32.09	Supervision 1 low	Defines the lower limit for signal supervision 1.	0.00
	-21474830.00 21474830.00	Low limit.	-
32.10	Supervision 1 high	Defines the upper limit for signal supervision 1.	0.00
	-21474830.00 21474830.00	Upper limit.	-
32.15	Supervision 2 function	Selects the mode of signal supervision function 2.  Determines how the monitored signal (see parameter 32.17) is compared to its lower and upper limits (32.19 and 32.20 respectively). The action to be taken when the condition is fulfilled is selected by 32.16.	Disabled
	Disabled	Signal supervision 2 not in use.	0
	Low	Action is taken whenever the signal falls below its lower limit.	1
	High	Action is taken whenever the signal rises above its upper limit.	2
	Abs low	Action is taken whenever the absolute value of the signal falls below its (absolute) lower limit.	3
	Abs high	Action is taken whenever the absolute value of the signal rises above its (absolute) upper limit.	4
	Both	Action is taken whenever the signal falls below its low limit or rises above its high limit.	5
	Abs both	Action is taken whenever the absolute value of the signal falls below its (absolute) low limit or rises above its (absolute) high limit.	6
32.16	Supervision 2 action	Selects the action the drive takes when the value monitored by signal supervision 2 exceeds its limits.  Note: This parameter does not affect the status indicated by 32.01 Supervision status.	No action
	No action	No action taken.	0
	Warning	A warning (A8B1 Signal supervision 2) is generated.	1
	Fault	The drive trips on 80B1 Signal supervision 2.	2
	Fault if running	If running, the drive trips on 80B1 Signal supervision 2.	3
32.17	Supervision 2 signal	Selects the signal to be monitored by signal supervision function 2. For the available selections, see parameter 32.07 Supervision 1 signal.	Zero
32.18	Supervision 2 filter time	Defines a filter time constant for the signal monitored by signal supervision 2.	0.000 s
	0.00030.000 s	Signal filter time.	1000 = 1 s
32.19	Supervision 2 low	Defines the lower limit for signal supervision 2.	0.00
	-21474830.00 21474830.00	Low limit.	-

No.	Name/Value	Description	Def/ FbEq16
32.20	Supervision 2 high	Defines the upper limit for signal supervision 2.	0.00
	-21474830.00 21474830.00	Upper limit.	-
32.25	Supervision 3 function	Selects the mode of signal supervision function 3.  Determines how the monitored signal (see parameter 32.27) is compared to its lower and upper limits (32.29 and 32.30 respectively). The action to be taken when the condition is fulfilled is selected by 32.26.	Disabled
	Disabled	Signal supervision 3 not in use.	0
	Low	Action is taken whenever the signal falls below its lower limit.	1
	High	Action is taken whenever the signal rises above its upper limit.	2
	Abs low	Action is taken whenever the absolute value of the signal falls below its (absolute) lower limit.	3
	Abs high	Action is taken whenever the absolute value of the signal rises above its (absolute) upper limit.	4
	Both	Action is taken whenever the signal falls below its low limit or rises above its high limit.	5
	Abs both	Action is taken whenever the absolute value of the signal falls below its (absolute) low limit or rises above its (absolute) high limit.	6
32.26	Supervision 3 action	Selects the action the drive takes when the value monitored by signal supervision 3 exceeds its limits.  Note: This parameter does not affect the status indicated by 32.01 Supervision status.	No action
	No action	No action taken.	0
	Warning	A warning (A8B2 Signal supervision 3) is generated.	1
	Fault	The drive trips on 80B2 Signal supervision 3.	2
	Fault if running	If running, the drive trips on 80B2 Signal supervision 3.	3
32.27	Supervision 3 signal	Selects the signal to be monitored by signal supervision function 3.  For the available selections, see parameter 32.07  Supervision 1 signal.	Zero
32.28	Supervision 3 filter time	Defines a filter time constant for the signal monitored by signal supervision 3.	0.000 s
	0.00030.000 s	Signal filter time.	1000 = 1 s
32.29	Supervision 3 low	Defines the lower limit for signal supervision 3.	0.00
	-21474830.00 21474830.00	Low limit.	-
32.30	Supervision 3 high	Defines the upper limit for signal supervision 3.	0.00
	-21474830.00 21474830.00	Upper limit.	-

No.	Name/Va	lue	[	Description		Def/ FbEq16
33 Generic timer & counter			S	U	of maintenance timers/counters.  on Maintenance timers and counters (page	
33.01	Counters	tatus	ir e			-
			Bit	Name	Description	
			0	On-time1	1 = On-time timer 1 has reached its preset	limit.
			1	On-time2	1 = On-time timer 2 has reached its preset	limit.
			2	Edge 1	1 = Signal edge counter 1 has reached its	preset limit.
			3	Edge 2	1 = Signal edge counter 2 has reached its	
			4	Value 1	1 = Value counter 1 has reached its preset	
			5	Value 2	1 = Value counter 2 has reached its preset	limit.
			61	5 Reserved		
						1
	0000 0000 1111b	0b0011	N	laintenance tii	me/counter status word.	1 = 1
			3 W W a T	3.13 On-time When the timer varn limit, bit 0 varning specifi Iso given if en he timer can b	whenever the signal selected by parameter 1 source is on.  r exceeds the limit set by 33.11 On-time 1 of 33.01 Counter status is set to 1. The ed by 33.14 On-time 1 wam message is abled by 33.12 On-time 1 function.  De reset from the Drive composer PC tool, trol panel by keeping Reset depressed for is.	
	042949	67295 s	Α	ctual present	value of on-time timer 1.	-
33.11	On-time 1	warn lim	it S	ets the warnir	ng limit for on-time timer 1.	0 s
	042949	67295 s	٧	Varning limit fo	or on-time timer 1.	-
33.12	On-time 1	function	С	configures on-	time timer 1.	0000b
	Bit	Functio	n			
	Counter mode 0 = Loop: When the limit is reached, the counter is reset. The counter status (bit 0 33.01) switches to 1 for one second. The warning (if enabled) stays active for at leas seconds. 1 = Saturate: When the limit is reached, the counter status (bit 0 of 33.01) switches and remains so until 33.10 is reset. The warning (if enabled) also stays active until 33.10 is reset.					e for at least 10 ) switches to 1,
	1	1 = Enal	ble: No ble: A v	o warning is g	iven when the limit is reached 33.14) is given when the limit is reached	
	215	Reserve	d			
	0000b0	011b	С	n-time timer 1	1 configuration word.	1 = 1

No.	Name/Value	Description	Def/ FbEq16
33.13	On-time 1 source	Selects the signal to be monitored by on-time timer 1.	False
	False	Constant 0 (timer disabled).	0
	True	Constant 1.	1
	RO1	Bit 0 of 10.21 RO status (page 158).	2
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
33.14	On-time 1 warn message	Selects the optional warning message for on-time timer 1.	On-time 1 exceeded
	On-time 1 exceeded	A886 On-time 1. The message text can be edited on the control panel by choosing Menu – Settings – Edit texts.	0
	Clean device	A88C Device clean.	6
	Maintain additional cooling fan	A890 Additional cooling.	7
	Maintain cabinet fan	A88E Cabinet fan.	8
	Maintain DC capacitors	A88D DC capacitor.	9
	Maintain motor bearing	A880 Motor bearing.	10
33.20	On-time 2 actual	Displays the actual present value of on-time timer 2. The timer runs whenever the signal selected by parameter 33.23 On-time 2 source is on.  When the timer exceeds the limit set by 33.21 On-time 2 warn limit, bit 1 of 33.01 Counter status is set to 1. The warning specified by 33.24 On-time 2 warn message is also given if enabled by 33.22 On-time 2 function.  The timer can be reset from the Drive composer PC tool, or from the control panel by keeping Reset depressed for over 3 seconds.	-
	04294967295 s	Actual present value of on-time timer 2.	-
33.21	On-time 2 warn limit	Sets the warning limit for on-time timer 2.	0 s
	04294967295 s	Warning limit for on-time timer 2.	-
33.22	On-time 2 function	Configures on-time timer 2.	0000b

Bit	Function	Function						
0	Counter mode 0 = Loop: When the limit is reached, the counter is reset. The counter status (bit 1 of 33.01) switches to 1 for one second. The warning (if enabled) stays active for at least 10 seconds. 1 = Saturate: When the limit is reached, the counter status (bit 1 of 33.01) switches to 1, and remains so until 33.20 is reset. The warning (if enabled) also stays active until 33.20 is reset.							
1	Warning enable 0 = Disable: No warning is given when the limit is reached 1 = Enable: A warning (see 33.24) is given when the limit is reached							
215	Reserved							
_								
0000b0011b On-time timer 2 configuration word. 1 = 1								

No.	Name/Value	Description	Def/ FbEq16
33.23	On-time 2 source	Selects the signal to be monitored by on-time timer 2.	False
	False	Constant 0 (timer disabled).	0
	True	Constant 1.	1
	RO1	Bit 0 of 10.21 RO status (page 158).	2
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
33.24	On-time 2 warn message	Selects the optional warning message for on-time timer 2.	On-time 2 exceeded
	On-time 2 exceeded	A887 On-time 2. The message text can be edited on the control panel by choosing Menu – Settings – Edit texts.	1
	Clean device	A88C Device clean.	6
	Maintain additional cool fan	A890 Additional cooling.	7
	Maintain cabinet fan	A88E Cabinet fan.	8
	Maintain DC capacitors	A88D DC capacitor.	9
	Maintain motor bearing	A880 Motor bearing.	10
33.30	Edge counter 1 actual	Actual present value of signal edge counter 1.  The counter is incremented every time the signal selected by parameter 33.33 Edge counter 1 source switches on or off (or either, depending on the setting of 33.32 Edge counter 1 function). A divisor may be applied to the count (see 33.34 Edge counter 1 divider).  When the counter exceeds the limit set by 33.31 Edge counter 1 warn limit, bit 2 of 33.01 Counter status is set to 1. The warning specified by 33.35 Edge counter 1 warn message is also given if enabled by 33.32 Edge counter 1 function.  The counter can be reset from the Drive composer PC tool, or from the control panel by keeping Reset depressed for over 3 seconds.	-
	04294967295	Actual present value of signal edge counter 1.	-
33.31	Edge counter 1 warn limit	Sets the warning limit for signal edge counter 1.	0
	04294967295	Warning limit for signal edge counter 1.	-

No.	Name/	Value	Description	Def/ FbEq16	
33.32	Edge co	ounter 1	Configures signal edge counter 1.	0000b	
	Bit	Function			
	0	33.01) switch (if enabled) s 1 = Saturate	hen the limit is reached, the counter is reset. The counter states to 1 and remains so until the counter is again incremented stays active for at least 10 seconds.  When the limit is reached, the counter status (bit 2 of 33.01) so until 33.30 is reset. The warning (if enabled) also stays a	d. The warning switches to 1,	
	1	Warning ena 0 = Disable:			
	2		edges Rising edges are not counted Rising edges are counted		
	3		edges Falling edges are not counted Falling edges are counted		
	415	Reserved			
	0000b1111b		Edge counter 1 configuration word.	1 = 1	
33.33	Edge counter 1 source		Selects the signal to be monitored by signal edge counter 1.	False	
	False		Constant 0.	0	
	True		Constant 1.	1	
	RO1		Bit 0 of 10.21 RO status (page 158).	2	
	Other [b	oit]	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-	
33.34	Edge co	ounter 1	Defines a divisor for signal edge counter 1. Determines how many signal edges increment the counter by 1.	1	
	1429	4967295	Divisor for signal edge counter 1.	-	
33.35	Edge co	ounter 1 warn je	Selects the optional warning message for signal edge counter 1.	Edge counter 1 exceeded	
	Edge counter 1 exceeded		A888 Edge counter 1. The message text can be edited on the control panel by choosing Menu – Settings – Edit texts.	2	
	Counted main contactor		A884 Main contactor.	11	
	Counted output relay		A881 Output relay.	12	
	Counte	d motor starts	A882 Motor starts.	13	
	Counte	d power ups	A883 Power ups.	14	
	Counted	d DC charges	A885 DC charge.	15	

No.	Name/Value	Description	Def/ FbEq16
33.40	Edge counter 2 actual	Displays the actual present value of signal edge counter 2. The counter is incremented every time the signal selected by parameter 33.43 Edge counter 2 source switches on or off (or either, depending on the setting of 33.42 Edge counter 2 function). A divisor may be applied to the count (see 33.44 Edge counter 2 divider).  When the counter exceeds the limit set by 33.41 Edge counter 2 warn limit, bit 3 of 33.01 Counter status is set to 1. The warning specified by 33.45 Edge counter 2 warn message is also given if enabled by 33.42 Edge counter 2 function.  The counter can be reset from the Drive composer PC tool, or from the control panel by keeping Reset depressed for over 3 seconds.	-
	04294967295	Actual present value of signal edge counter 2.	-
33.41	Edge counter 2 warn limit	Sets the warning limit for signal edge counter 2.	0
	04294967295	Warning limit for signal edge counter 2.	-
33.42	Edge counter 2 function	Configures signal edge counter 2.	0000b

Bit	Function
0	Counter mode 0 = Loop: When the limit is reached, the counter is reset. The counter status (bit 3 of 33.01) remains 1 until the counter is again incremented. The warning (if enabled) stays active for at least 10 seconds. 1 = Saturate: After the limit is reached, the counter status (bit 3 of 33.01) remains 1 until 33.40 is reset. The warning (if enabled) also stays active until 33.40 is reset.
1	Warning enable 0 = Disable: No warning is given when the limit is reached 1 = Enable: A warning (see 33.45) is given when the limit is reached
2	Count rising edges 0 = Disable: Rising edges are not counted 1 = Enable: Rising edges are counted
3	Count falling edges 0 = Disable: Falling edges are not counted 1 = Enable: Falling edges are counted
415	Reserved

	0000b1111b	Edge counter 2 configuration word.	1 = 1
33.43	Edge counter 2 source	Selects the signal to be monitored by signal edge counter 2.	False
	False	0.	0
	True	1.	1
	RO1	Bit 0 of 10.21 RO status (page 158).	2
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
33.44	Edge counter 2 divider	Defines a divisor for signal edge counter 2. Determines how many signal edges increment the counter by 1.	1
	14294967295	Divisor for signal edge counter 2.	-

No.	Name/Value	Description	Def/ FbEq16
33.45	Edge counter 2 warn message	Selects the optional warning message for signal edge counter 2.	Edge counter 2 exceeded
	Edge counter 2 exceeded	A889 Edge counter 2. The message text can be edited on the control panel by choosing Menu – Settings – Edit texts.	3
	Counted main contactor	A884 Main contactor.	11
	Counted output relay	A881 Output relay.	12
	Counted motor starts	A882 Motor starts.	13
	Counted power ups	A883 Power ups.	14
	Counted DC charges	A885 DC charge.	15
33.50	Value counter 1 actual	Displays the actual present value of value counter 1. The value of the source selected by parameter 33.53 Value counter 1 source is read at one-second intervals and added to the counter. A divisor can be applied to the count (see 33.54 Value counter 1 divider). When the counter exceeds the limit set by 33.51 Value counter 1 warn limit, bit 4 of 33.01 Counter status is set to 1. The warning specified by 33.55 Value counter 1 warn message is also given if enabled by 33.52 Value counter 1 function.  The counter can be reset from the Drive composer PC tool, or from the control panel by keeping Reset depressed for over 3 seconds.	-
	-2147483008 2147483008	Actual present value of value counter 1.	-
33.51	Value counter 1 warn limit	Sets the limit for value counter 1. With a positive limit, bit 4 of 33.01 Counter status is set to 1 (and a warning optionally generated) when the counter is equal or greater than the limit. With a negative limit, bit 4 of 33.01 Counter status is set to 1 (and a warning optionally generated) when the counter is equal or smaller than the limit.  0 = Counter disabled.	0
	-2147483008 2147483008	Limit for value counter 1.	-

No.	Name/\	<b>Value</b>	Description	Def/ FbEq16
33.52	Value counter 1 function		Configures value counter 1.	0000b
	Bit	Function		
	0	33.01) switch seconds. 1 = Saturate:	nen the limit is reached, the counter is reset. The counter states to 1 for one second. The warning (if enabled) stays active.  When the limit is reached, the counter status (bit 4 of 33.01) is so until 33.50 is reset. The warning (if enabled) also stays ac	for at least 10 switches to 1
	215		ble No warning is given when the limit is reached warning (see 33.55) is given when the limit is reached	
	215	Reserved		
	0000b	.0011b	Value counter 1 configuration word.	1 = 1
33.53	Value counter 1 source		Selects the signal to be monitored by value counter 1.	Not selecte
	Not sele	ected	None (counter disabled).	0
	Motor s	peed	01.01 Motor speed used (see page 121).	1
	Other		Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
33.54	Value co divider	ounter 1	Defines a divisor for value counter 1. The value of the monitored signal is divided by this value before integration.	1.000
	0.001	2147483.000	Divisor for value counter 1.	-
33.55	Value counter 1 warn message		Selects the optional warning message for value counter 1.	Value coun
	Value co	ounter 1 ed	A88A Value counter 1. The message text can be edited on the control panel by choosing Menu – Settings – Edit texts.	4
	Maintair bearing		A880 Motor bearing.	10
33.60	Value counter 2 actual		Displays the actual present value of value counter 2. The value of the source selected by parameter 33.63 Value counter 2 source is read at one-second intervals and added to the counter. A divisor can be applied to the count (see 33.64 Value counter 2 divider). When the counter exceeds the limit set by 33.61 Value counter 2 warn limit, bit 5 of 33.01 Counter status is set to 1. The warning specified by 33.65 Value counter 2 warn message is also given if enabled by 33.62 Value counter 2 function.  The counter can be reset from the Drive composer PC tool, or from the control panel by keeping Reset depressed for over 3 seconds.	-
	-214748	33008	Actual present value of value counter 2.	-

...2147483008

No.	Name/\	/alue	Description	Def/ FbEq16
33.61	33.61 Value counter 2 warn limit		Sets the limit for value counter 2. With a positive limit, bit 5 of 33.01 Counter status is set to 1 (and a warning optionally generated) when the counter is equal or greater than the limit. With a negative limit, bit 5 of 33.01 Counter status is set to 1 (and a warning optionally generated) when the counter is equal or smaller than the limit.  0 = Counter disabled.	0
	-214748 21474		Limit for value counter 2.	-
33.62	Value co function		Configures value counter 2.	0000b
	Bit	Function		
	0	Counter mode 0 = Loop: When the limit is reached, the counter is reset. The counter s 33.01) switches to 1 for one second. The warning (if enabled) stays act 10 seconds. 1 = Saturate: When the limit is reached, the counter status (bit 5 of 33. 1, and remains so until 33.60 is reset. The warning (if enabled) also sta 33.60 is reset.		
	1	1 = Enable: A	ble  No warning is given when the limit is reached  A warning (see 33.65) is given when the limit is reached	
	215 Reserved			
	0000b0011b		Value counter 2 configuration word.	1 = 1
33.63	Value counter 2 source		Selects the signal to be monitored by value counter 2.	Not selected
	Not sele	cted	None (counter disabled).	0
	Motor sp	peed	01.01 Motor speed used (see page 121).	1
	Other  Value counter 2 divider  0.0012147483.000		Source selection (see <i>Terms and abbreviations</i> on page 118).	-
33.64			Defines a divisor for value counter 2. The value of the monitored signal is divided by this value before integration.	1.000
			Divisor for value counter 2.	-
33.65	Value co messag	ounter 2 warn e	Selects the optional warning message for value counter 2.	Value counter 2 exceeded
	Value co		A88B Value counter 2. The message text can be edited on the control panel by choosing Menu – Settings – Edit texts.	5
	Maintair bearing	n motor	A880 Motor bearing.	10

No.	Name/Value	Description	Def/ FbEq16
	tor thermal otection	Motor thermal protection settings such as temperature measurement configuration, load curve definition and motor fan control configuration.  See also section <i>Motor thermal protection</i> (page 94).	
35.01 Motor estimated temperature		Displays the motor temperature as estimated by the internal motor thermal protection model (see parameters 35.5035.55). The unit is selected by parameter 96.16 Unit selection  This parameter is read-only.	-
	-601000 °C or °F	Estimated motor temperature.	1 = 1°
35.02	Measured temperature 1	Displays the temperature received through the source defined by parameter 35.11 Temperature 1 source. The unit is selected by parameter 96.16 Unit selection.  Note: With a PTC sensor, the unit is ohms.  This parameter is read-only.	-
	-60 1000 °C, -76 1832 °F or 05000 ohm	Measured temperature 1.	1 = 1 unit
35.03	Measured temperature 2	Displays the temperature received through the source defined by parameter 35.21 Temperature 2 source. The unit is selected by parameter 96.16 Unit selection.  Note: With a PTC sensor, the unit is ohms. This parameter is read-only.	-
	-60 1000 °C, -76 1832 °F or 05000 ohm	Measured temperature 2.	1 = 1 unit

No.	Name/Value		Descriptio	n	Def/ FbEq16
35.04	FPTC status word		protection r of eg. exter <b>Note:</b> The " whether the the "fault ac if the modu parameter"	e status of optional FPTC-xx thermistor modules. The word can be used as the source nal events.  'module found" bits are updated regardless of ecorresponding module is activated. However, stive" and "warning active" bits are not updated le is not activated. Modules are activated by 35.30 FPTC configuration word. eter is read-only.	-
	Bit	Name		Description	
	0	Module found	d in slot 1	1 = Yes: An FEX-01/FPTC-01 module has beer slot 1.	n detected in
	1	Fault active i	n slot 1	1 = Yes: The module in slot 1 has an active fau	lt (4991).
	2	Warning active in slot 1		1 = Yes: The module in slot 1 has an active wa	rning ( <i>A4</i> 97).
	3	Module found in slot 2		1 = Yes: An FEX-01/FPTC-01 module has beer slot 2.	n detected in
	4	Fault active in slot 2 Warning active in slot 2		1 = Yes: The module in slot 2 has an active fault (4992). 1 = Yes: The module in slot 2 has an active warning (A498).	
	5				0 ( )
	6	Module found in slot 3		1 = Yes: An FEX-01/FPTC-01 module has beer slot 3.	n detected in
	7	Fault active in slot 3		1 = Yes: The module in slot 3 has an active fault (4993).	
	8	Warning active in slot 3		1 = Yes: The module in slot 3 has an active warning (A499).	
	915	915 Reserved			
	0000hFFFFh		FEX-01/FP	TC-01 status word.	1 = 1
35.11	Tempera source	ature 1	read.	source from which measured temperature 1 is	Disabled
			For wiring e	examples, see the hardware manual of the	
	Disabled N Estimated temperature		Usually this motor contra	source is from a sensor connected to the olled by the drive, but it could be used to and monitor a temperature from other parts of the long as a suitable sensor is used as per the st.	
			None. Temp	perature monitoring function 1 is disabled.	0
			estimated to The temper calculation.	motor temperature (see parameter 35.01 Motor emperature). rature is estimated from an internal drive It is important to set up the ambient e of the motor in 35.50 Motor ambient e.	1

No.	Name/Value	Description	Def/ FbEq16
	KTY84 analog I/O	KTY84 sensor connected to the analog input selected by parameter 35.14 Temperature 1 AI source and an analog output. The analog input can be from the standard I/O or from an extension module.  The following settings are required:  Set the hardware jumper or switch related to the analog input to U (voltage). Any change must be validated by a control unit reboot.  Set the unit selection parameter of the input to volt.  Set the source selection parameter of the analog output to "Force KTY84 excitation".  Select the analog input in parameter 35.14. In case the input is located on an I/O extension module, use the selection Other to point at the actual input value parameter (for example, 14.26 Al1 actual value).  The analog output feeds a constant current through the sensor. As the resistance of the sensor changes along with its temperature, the voltage over the sensor changes. The voltage is read by the analog input and converted into degrees.	2
	KTY84 encoder module 1	KTY84 sensor connected to encoder interface 1. See also parameters 91.21 Module 1 temp sensor type and 91.22 Module 1 temp filter time.	3
	KTY84 encoder module 2	KTY84 sensor connected to encoder interface 2. See also parameters 91.24 Module 2 temp sensor type and 91.25 Module 2 temp filter time.	4
	1 × Pt100 analog I/O	Pt100 sensor connected to a standard analog input selected by parameter 35.14 Temperature 1 Al source and an analog output. The input and output can be on the drive control unit or on an extension module.  The required settings are the same as with selection KTY84 analog I/O, except that the source selection parameter of the analog output must be set to Force Pt100 excitation.	5
	2 × Pt100 analog I/O	As selection 1 × Pt100 analog I/O, but with two sensors connected in series. Using multiple sensors improves measurement accuracy significantly.	6
	3 × Pt100 analog I/O	As selection 1 × Pt100 analog I/O, but with three sensors connected in series. Using multiple sensors improves measurement accuracy significantly.	7
	PTC DI6	PTC sensor connected to digital input DI6 (see the connection diagram on page 95).  Note: Either 0 ohm (normal temperature) or the value of parameter 35.02 Measured temperature 1 (excessive temperature) is shown. By default, an excessive temperature will generate a warning as per parameter 35.13 Temperature 1 warning limit. If you want a fault instead, set 35.12 Temperature 1 fault limit to 4000 ohm.	8

No.	Name/Value	Description	Def/ FbEq16
	PTC analog I/O	PTC sensor connected to a standard analog input selected by parameter 35.14 Temperature 1 AI source and an analog output. The input and output can be on the drive control unit or on an extension module.  The required settings are the same as with selection KTY84 analog I/O, except that the source selection parameter of the analog output must be set to Force PTC excitation.	20
	PTC encoder module 1	PTC sensor connected to encoder interface 1. See also parameters 91.21 Module 1 temp sensor type and 91.22 Module 1 temp filter time.	9
	PTC encoder module 2	PTC sensor connected to encoder interface 2. See also parameters 91.24 Module 2 temp sensor type and 91.25 Module 2 temp filter time.	10
	Direct temperature	The temperature is taken from the source selected by parameter 35.14 Temperature 1 Al source. The value of the source is assumed to be in the unit of temperature specified by 96.16 Unit selection.	11
	1 × Pt1000 analog I/O	Pt1000 sensor connected to a standard analog input selected by parameter 35.14 Temperature 1 Al source and an analog output. The input and output can be on the drive control unit or on an extension module.  The required settings are the same as with selection KTY84 analog I/O, except that the source selection parameter of the analog output must be set to Force Pt1000 excitation.	13
	2 × Pt1000 analog I/O	As selection 1 × Pt1000 analog I/O, but with two sensors connected in series. Using multiple sensors improves measurement accuracy significantly.	14
	3 × Pt1000 analog I/O	As selection 1 × Pt1000 analog I/O, but with three sensors connected in series. Using multiple sensors improves measurement accuracy significantly.	15
35.12	Temperature 1 fault limit	Defines the fault limit for temperature monitoring function 1. When measured temperature 1 exceeds the limit, the drive trips on fault 4981 External temperature.  The unit is selected by parameter 96.16 Unit selection.  Note: With a PTC sensor, the unit is ohms.	130 °C, 266 °F or 4500 ohm
	-60 1000 °C, -76 1832 °F or 05000 ohm	Fault limit for temperature monitoring function 1.	1 = 1 unit
35.13	Temperature 1 warning limit	Defines the warning limit for temperature monitoring function 1. When measured temperature 1 exceeds this limit, a warning (A491 External temperature) is generated. The unit is selected by parameter 96.16 Unit selection. Note: With a PTC sensor, the unit is ohms.	110 °C, 230 °F or 4000 ohm
	-60 1000 °C, -76 1832 °F or 05000 ohm	Warning limit for temperature monitoring function 1.	1 = 1 unit

No.	Name/Value	Description	Def/ FbEq16
35.14	Temperature 1 AI source	Specifies the analog input when the setting of 35.11 Temperature 1 source requires measurement through an analog input.  Note: If the input is located on an I/O extension module, use the selection Other to point to the AI actual value in group 14, 15 or 16, eg. 14.26 AI1 actual value.	Not selected
	Not selected	None.	0
	Al1 actual value	Analog input Al1 on the control unit.	1
	Al2 actual value	Analog input Al2 on the control unit.	2
	Other	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
35.21	Temperature 2 source	Selects the source from which measured temperature 2 is read.  Usually this source is from a sensor connected to the motor controlled by the drive, but it could be used to measure and monitor a temperature from other parts of the process as long as a suitable sensor is used as per the selection list.	Disabled
	Disabled	None. Temperature monitoring function 2 is disabled.	0
	Estimated temperature	Estimated motor temperature (see parameter 35.01 Motor estimated temperature).  The temperature is estimated from an internal drive calculation. It is important to set up the ambient temperature of the motor in 35.50 Motor ambient temperature.	1
	KTY84 analog I/O	KTY84 sensor connected to the analog input selected by parameter 35.24 Temperature 2 AI source and an analog output. The input and output can be on the drive control unit or on an extension module.  The following settings are required:  Set the hardware jumper or switch related to the analog input to U (voltage). Any change must be validated by a control unit reboot.  Set the unit selection parameter of the input to volt.  Set the source selection parameter of the analog output to "Force KTY84 excitation".  Select the analog input in parameter 35.24. In case the input is located on an I/O extension module, use the selection Other to point at the actual input value parameter (for example, 14.26 Al1 actual value).  The analog output feeds a constant current through the sensor. As the resistance of the sensor changes along with its temperature, the voltage over the sensor changes. The voltage is read by the analog input and converted into degrees.	2
	KTY84 encoder module 1	KTY84 sensor connected to encoder interface 1. See also parameters 91.21 Module 1 temp sensor type and 91.22 Module 1 temp filter time.	3
	KTY84 encoder module 2	KTY84 sensor connected to encoder interface 2. See also parameters 91.24 Module 2 temp sensor type and 91.25 Module 2 temp filter time.	4

No.	Name/Value	Description	Def/ FbEq16
	1 × Pt100 analog I/O	Pt100 sensor connected to a standard analog input selected by parameter 35.24 Temperature 2 Al source and an analog output. The input and output can be on the drive control unit or on an extension module.  The required settings are the same as with selection KTY84 analog I/O, except that the source selection parameter of the analog output must be set to Force Pt100 excitation.	5
	2 × Pt100 analog I/O	As selection 1 × Pt100 analog I/O, but with two sensors connected in series. Using multiple sensors improves measurement accuracy significantly.	6
	3 × Pt100 analog I/O	As selection 1 × Pt100 analog I/O, but with three sensors connected in series. Using multiple sensors improves measurement accuracy significantly.	7
	PTC DI6	PTC sensor connected to digital input DI6 (see the connection diagram on page 95).  Note: Either 0 ohm (normal temperature) or the value of parameter 35.03 Measured temperature 2 (excessive temperature) is shown. By default, an excessive temperature will generate a warning as per parameter 35.23 Temperature 2 warning limit. If you want a fault instead, set 35.22 Temperature 2 fault limit to 4000 ohm.	8
	PTC analog I/O	PTC sensor connected to a standard analog input selected by parameter 35.24 Temperature 2 AI source and an analog output. The input and output can be on the drive control unit or on an extension module.  The required settings are the same as with selection KTY84 analog I/O, except that the source selection parameter of the analog output must be set to Force PTC excitation.	20
	PTC encoder module 1	PTC sensor connected to encoder interface 1. See also parameters 91.21 Module 1 temp sensor type and 91.22 Module 1 temp filter time.	9
	PTC encoder module 2	PTC sensor connected to encoder interface 2. See also parameters 91.24 Module 2 temp sensor type and 91.25 Module 2 temp filter time.	10
	Direct temperature	The temperature is taken from the source selected by parameter 35.24 Temperature 2 Al source. The value of the source is assumed to be in the unit of temperature specified by 96.16 Unit selection.	11
	1 × Pt1000 analog I/O	Pt1000 sensor connected to a standard analog input selected by parameter 35.24 Temperature 2 Al source and an analog output. The input and output can be on the drive control unit or on an extension module.  The required settings are the same as with selection KTY84 analog I/O, except that the source selection parameter of the analog output must be set to Force Pt1000 excitation.	13
	2 × Pt1000 analog I/O	As selection 1 × Pt1000 analog I/O, but with two sensors connected in series. Using multiple sensors improves measurement accuracy significantly.	14
	3 × Pt1000 analog I/O	As selection 1 × Pt1000 analog I/O, but with three sensors connected in series. Using multiple sensors improves measurement accuracy significantly.	15

No.	Name/V	'alue	Descriptio	n	Def/ FbEq16
35.22	limit 2. When drive trip The unit		2. When me drive trips on The unit is s	fault limit for temperature monitoring function hasured temperature 2 exceeds the limit, the in fault 4982 External temperature 2. Selected by parameter 96.16 Unit selection. The a PTC sensor, the unit is ohms.	130 °C, 266 °F or 4500 ohm
	-60 10 -76 18 05000	332 °F or	Fault limit fo	or temperature monitoring function 2.	1 = 1 unit
35.23	Tempera warning		function 2. \ limit, a warr generated. The unit is s	warning limit for temperature monitoring When measured temperature 2 exceeds the hing (A492 External temperature 2) is selected by parameter 96.16 Unit selection. a PTC sensor, the unit is ohms.	110 °C, 230 °F or 4000 ohm
	-60 10 -76 18 05000	332 °F or	Warning lim	it for temperature monitoring function 2.	1 = 1 unit
35.24	4 Temperature 2 AI source		source, sele	input for parameter 35.21 Temperature 2 ections KTY84 analog I/O, 1 × Pt100 analog 00 analog I/O, 3 × Pt100 analog I/O and Direct e.	Not selected
	Not sele	cted	None.		0
	Al1 actu	al value	Analog inpu	t Al1 on the control unit.	1
	Al2 actu	al value	Analog inpu	t Al2 on the control unit.	2
	Other		Source sele	ection (see <i>Terms and abbreviations</i> on page	-
35.30	5.30 FPTC configuration word		on the conti	PTC-xx thermistor protection modules installed rol unit of the drive. Using this word, it is also suppress the warnings (but not faults) from e.	0010 1010ь
	Bit	Name		Description	
	0	Module in slo	t 1	1 = Yes: Module installed in slot 1.	
	1	Disable slot 1		1 = Yes: Warnings from the module in slot 1 su	ppressed.
	2	Module in slo		1 = Yes: Module installed in slot 2.	
	<ul><li>3 Disable slot 2 wa</li><li>4 Module in slot 3</li><li>5 Disable slot 3 wa</li></ul>		Ū	1 = Yes: Warnings from the module in slot 2 suppressed. 1 = Yes: Module installed in slot 3.	
			warning	1 = Yes: Warnings from the module in slot 3 su	ppressed.
	615	Reserved			
	0000 00	0044	EDTC ····	adula applicuration ward	1 - 1
	1111b	00b 0011	FP1C-XX M	odule configuration word.	1 = 1

No.	Name/Value	Description	Def/ FbEq16
35.50	Motor ambient temperature	Defines the ambient temperature of the motor for the motor thermal protection model. The unit is selected by parameter 96.16 Unit selection.  The motor thermal protection model estimates the motor temperature on the basis of parameters 35.5035.55.  The motor temperature increases if it operates in the region above the load curve, and decreases if it operates in the region below the load curve.  WARNING! The model cannot protect the motor if the motor does not cool properly because of dust, dirt, etc.	20 °C or 68 °F
	-60100 °C or -75212 °F	Ambient temperature.	1 = 1°
35.51	Motor load curve	Defines the motor load curve together with parameters 35.52 Zero speed load and 35.53 Break point. The load curve is used by the motor thermal protection model to estimate the motor temperature.  When the parameter is set to 100%, the maximum load is taken as the value of parameter 99.06 Motor nominal current (higher loads heat up the motor). The load curve level should be adjusted if the ambient temperature differs from the nominal value set in 35.50 Motor ambient temperature.  I/I <sub>N</sub> (%)	
	50150%	Maximum load for the motor load curve.	1 = 1%
35.52	Zero speed load	Defines the motor load curve together with parameters 35.51 Motor load curve and 35.53 Break point. Defines the maximum motor load at zero speed of the load curve. A higher value can be used if the motor has an external motor fan to boost the cooling. See the motor manufacturer's recommendations.  See parameter 35.51 Motor load curve.	70%
	25150%	Zero speed load for the motor load curve.	1 = 1%

No.	Name/Value	Description	Def/ FbEq16
35.53	Break point	Defines the motor load curve together with parameters 35.51 Motor load curve and 35.52 Zero speed load. Defines the break point frequency of the load curve i.e. the point at which the motor load curve begins to decrease from the value of parameter 35.51 Motor load curve towards the value of parameter 35.52 Zero speed load. See parameter 35.51 Motor load curve.	45.00 Hz
	1.00500.00 Hz	Break point for the motor load curve.	See par. 46.02
35.54	Motor nominal temperature rise	Defines the temperature rise of the motor above ambient when the motor is loaded with nominal current. See the motor manufacturer's recommendations.  The unit is selected by parameter 96.16 Unit selection.  Temperature  Ambient temperature  Time	80 °C or 176 °F
	0300 °C or 32572 °F	Temperature rise.	1 = 1°
35.55	Motor thermal time constant	Defines the thermal time constant for use with the motor thermal protection model, defined as the time to reach 63% of the nominal motor temperature. See the motor manufacturer's recommendations.  Motor current  Temperature rise  100%  63%  Motor thermal time  Time	256 s
	10010000 s	Motor thermal time constant.	1 = 1 s

No.	Name/Value	Description	Def/ FbEq16
35.60	Cable temperature	Shows the calculated temperature of the motor cable. See section <i>Thermal protection of motor cable</i> (page 98). 102% = overtemperature warning ( <i>A480 Motor cable overload</i> ) 106% = overtemperature fault ( <i>4000 Motor cable overload</i> ) This parameter is read-only.	0.0%
	0.0200.0%	Calculated temperature of motor cable.	1 = 1%
35.61	Cable nominal current	Specifies the continuous current of the motor cable for the thermal protection function in the control program.  WARNING! The value entered in this parameter must be limited according to all factors affecting the loadability of the cable, such as ambient temperature, cabling arrangement, and shrouding. Refer to the technical data from the cable manufacturer.	10000.00 A
	0.0010000.00 A	Continuous current-carrying capacity of motor cable.	1 = 1 A
35.62	Cable thermal rise time	Specifies the thermal time of the motor cable for the thermal protection function in the control program. This value is defined as the time to reach 63% of the nominal cable temperature when the cable is loaded with nominal current (parameter 35.61 Cable nominal current).  O s = Thermal protection of motor cable disabled Refer to the technical data from the cable manufacturer.  Cable current  Temperature rise  Time  Cable thermal time  Time	1 s
	0 s	Thermal protection of motor cable disabled.	1 = 1 s
	050000 s	Motor cable thermal time constant.	1 = 1 s

No.	Name/Value	Description	Def/ FbEq16
35.100	DOL starter control source	Parameters 35.10035.106 configure a monitored start/stop control logic for external equipment such as a contactor-controlled motor cooling fan.  This parameter selects the signal that starts and stops the fan.  0 = Stop 1 = Start  The output controlling the fan contactor is to be connected to parameter 35.105, bit 1. On and off delays can be set for the fan by 35.101 and 35.102 respectively. A feedback signal from the fan can be connected to an input selected by 35.103; the loss of the feedback will optionally trigger a warning or fault (see 35.104 and 35.106).	Off, 06.16 b6 (95.20 b6)
	Off	0 (function disabled).	0
	On	1.	1
	Running	Bit 6 of 06.16 Drive status word 1 (see page 136).	2
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
35.101	DOL starter on delay	Defines a start delay for the motor fan. The delay timer starts when the control source selected by parameter 35.100 switches on. After the delay, bit 1 of 35.105 switches on.	0 s
	042949673 s	Motor fan start delay.	1 = 1 s
35.102	DOL starter off delay	Defines a stop delay for the motor fan. The delay timer starts when the control source selected by parameter 35.100 switches off. After the delay, bit 1 of 35.105 switches off.	20 min
	0715828 min	Motor fan stop delay.	1 = 1 min
35.103	DOL starter feedback source	Selects the input for motor fan feedback signal.  0 = Stopped  1 = Running  After the fan is started (bit 1 of 35.105 switches on), feedback is expected within the time set by 35.104.	Not selected; DI5 (95.20 b6)
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-

No.	Name/Valu	ue	Desci	ription	Def/ FbEq16	
35.104	DOL starte delay	The de no feed elapse: Note: signal i		es a feedback delay for the motor fan. elay timer starts when bit 1 of 35.105 switches on. If dback is received from the fan until the delay es, the action selected by 35.106 is taken. This delay is only applied at start. If the feedback is lost during run, the action selected by 35.106 is immediately.	0 s; 5s (95.20 b6)	
	0429496	73 s	Motor	fan start delay.	1 = 1 s	
35.105 DOL starter status word		r status	Bit 1 is source The of and fe	of the motor fan control logic. In the control output for the fan, to be selected as the eof, for example, a digital or relay output. The cher bits indicate the statuses of the selected control edback sources, and the fault status. In arameter is read-only.	-	
	Bit	Name		Description		
	0	Start comr	mand	Status of fan control source selected by 35.100.  0 = Stop requested  1 = Start requested		
	1	Delayed s command	tart	rt Fan control bit (delays observed). Select this bit as the source of the output controlling the fan.  0 = Stopped 1 = Started		
	2 DOL feedl		oack	Status of fan feedback (source selected by 35.103). 0 = Stopped 1 = Running		
	3	DOL fault	(-1)	Fault status.  0 = Fault (fan feedback missing). The action taken is by 35.106.  1 = No fault	selected	
	415	Reserved				
	0000b11	11b	Status	of motor fan control logic.	1 = 1	
35.106	DOL starte type	r event		s the action taken when missing fan feedback is ed by the motor fan control logic.	Fault	
	No action		No act	tion taken.	0	
	Warning		The di	ive generates a warning (A781 Motor fan).	1	
	Fault		Drive	trips on 71B1 Motor fan.	2	

No.	Name/Value	Description	Def/ FbEq16
36 Loa	ad analyzer	Peak value and amplitude logger settings.	
		See also section <i>Load analyzer</i> (page 103).	
36.01	PVL signal source	Selects the signal to be monitored by the peak value logger. The signal is filtered using the filtering time specified by parameter 36.02 PVL filter time. The peak value is stored, along with other pre-selected signals at the time, into parameters 36.1036.15. The peak value logger can be reset using parameter 36.09 Reset loggers. The logger is also reset whenever the signal source is changed. The date and time of the last reset are stored into parameters 36.16 and 36.17 respectively.	Power inu out
	Zero	None (peak value logger disabled).	0
	Motor speed used	01.01 Motor speed used (page 121).	1
	Output frequency	01.06 Output frequency (page 121).	3
	Motor current	01.07 Motor current (page 121).	4
	Motor torque	01.10 Motor torque (page 121).	6
	DC voltage	01.11 DC voltage (page 122).	7
	Power inu out	01.14 Output power (page 122).	8
	Speed ref ramp in	23.01 Speed ref ramp input (page 231).	10
	Speed ref ramped	23.02 Speed ref ramp output (page 232).	11
	Speed ref used	24.01 Used speed reference (page 238).	12
	Torq ref used	26.02 Torque reference used	13
	Freq ref used	28.02 Frequency ref ramp output (page 257).	14
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
36.02	PVL filter time	Defines a filtering time for the peak value logger. See parameter 36.01 PVL signal source.	2.00 s
	0.00120.00 s	Peak value logger filtering time.	100 = 1 s
36.06	AL2 signal source	Selects the signal to be monitored by amplitude logger 2. The signal is sampled at 200 ms intervals and can be scaled using parameter 36.07 AL2 signal scaling. The results are displayed by parameters 36.4036.49. Each parameter represents an amplitude range, and shows what portion of the samples fall within that range. The signal value corresponding to 100% is defined by parameter 36.07 AL2 signal scaling. Amplitude logger 2 can be reset using parameter 36.09 Reset loggers. The logger is also reset whenever the signal source is changed. The date and time of the last reset are stored into parameters 36.50 and 36.51 respectively.	Ambient temperature
	Zero	None (amplitude logger 2 disabled).	0
	Motor speed used	01.01 Motor speed used (page 121).	1
	Output frequency	01.06 Output frequency (page 121).	3
	Motor current	01.07 Motor current (page 121).	4
	Motor torque	01.10 Motor torque (page 121).	6

No.	Name/	/alue	Description	Def/ FbEq16	
	DC volta	age	01.11 DC voltage (page 122).	7	
	Power inu out Speed ref ramp in		01.14 Output power (page 122).	8	
			23.01 Speed ref ramp input (page 231).	10	
	Speed r	ef ramped	23.02 Speed ref ramp output (page 232).	11	
	Speed r	ef used	24.01 Used speed reference (page 238).	12	
	Torq ref	used	26.02 Torque reference used (page 254).	13	
	Freq ref	used	28.02 Frequency ref ramp output (page 257).	14	
	Process	PID out	-	16	
	Process	PID fbk	-	17	
	Process	PID act	-	18	
	Process	PID dev	-	19	
	Ambien	t temperature	01.70 Ambient temperature% (page 124). The amplitude range of 0100% corresponds to 060 °C or 32140 °F.	20	
	Other		Source selection (see <i>Terms and abbreviations</i> on page 118).	1 = 1	
36.07	AL2 sig	nal scaling	Defines the signal value that corresponds to 100% amplitude.	100.00	
	0.003	2767.00	Signal value corresponding to 100%.	1 = 1	
36.08	Logger	function	Determines whether amplitude loggers 1 and 2 are active continuously or only when the drive is modulating.		
		_			
	Bit	Name	Description		
	0	AL1	0 = Amplitude logger 1 active continuously 1 = Amplitude logger 1 active only when the drive is mo	dulating	
	1	AL2	0 = Amplitude logger 2 active continuously 1 = Amplitude logger 2 active only when the drive is modulating		
	215	Reserved			
	0000b	.0011b	Amplitude logger activity selection.	1 = 1	
36.09	Reset lo	oggers	Resets the peak value logger and/or amplitude logger 2. (Amplitude logger 1 cannot be reset.)	Done	
	Done		Reset completed or not requested (normal operation).	0	
	All		Reset both the peak value logger and amplitude logger 2.	1	
	PVL		Reset the peak value logger.	2	
	AL2		Reset amplitude logger 2.	3	
36.10	PVL pe	ak value	Displays the peak value recorded by the peak value logger.	0.00	
	-32768.	0032767.00	Peak value.	1 = 1	
36.11	PVL pe	ak date	Displays the date on which the peak value was recorded.	-	
	-		Peak occurrence date.	-	
			1		
36.12	PVL pe	ak time	Displays the time at which the peak value was recorded.	-	

No.	Name/Value	Description	Def/ FbEq16
36.13	PVL current at peak	Displays the motor current at the moment the peak value was recorded.	0.00 A
	-32768.00 32767.00 A	Motor current at peak.	1 = 1 A
36.14	PVL DC voltage at peak	Displays the voltage in the intermediate DC circuit of the drive at the moment the peak value was recorded.	0.00 V
	0.002000.00 V	DC voltage at peak.	10 = 1 V
36.15	PVL speed at peak	Displays the motor speed at the moment the peak value was recorded.	0.00 rpm
	-32768.00 32767.00 rpm	Motor speed at peak.	See par. 46.01
36.16	PVL reset date	Displays the date on which the peak value logger was last reset.	-
	-	Last reset date of the peak value logger.	-
36.17	PVL reset time	Displays the time at which the peak value logger was last reset.	-
	-	Last reset time of the peak value logger.	-
36.20	AL1 below 10%	Displays the percentage of samples recorded by amplitude logger 1 that were below 10%. Note that this percentage also includes the samples that had a negative value.	0.00%
	0.00100.00%	Amplitude logger 1 sample below 10%.	1 = 1%
36.21	AL1 10 to 20%	Displays the percentage of samples recorded by amplitude logger 1 that fall between 10 and 20%.	0.00%
	0.00100.00%	Amplitude logger 1 samples between 10 and 20%.	1 = 1%
36.22	AL1 20 to 30%	Displays the percentage of samples recorded by amplitude logger 1 that fall between 20 and 30%.	0.00%
	0.00100.00%	Amplitude logger 1 samples between 20 and 30%.	1 = 1%
36.23	AL1 30 to 40%	Displays the percentage of samples recorded by amplitude logger 1 that fall between 30 and 40%.	0.00%
	0.00100.00%	Amplitude logger 1 samples between 30 and 40%.	1 = 1%
36.24	AL1 40 to 50%	Displays the percentage of samples recorded by amplitude logger 1 that fall between 40 and 50%.	0.00%
	0.00100.00%	Amplitude logger 1 samples between 40 and 50%.	1 = 1%
36.25	AL1 50 to 60%	Displays the percentage of samples recorded by amplitude logger 1 that fall between 50 and 60%.	0.00%
	0.00100.00%	Amplitude logger 1 samples between 50 and 60%.	1 = 1%
36.26	AL1 60 to 70%	Displays the percentage of samples recorded by amplitude logger 1 that fall between 60 and 70%.	0.00%
	0.00100.00%	Amplitude logger 1 samples between 60 and 70%.	1 = 1%
36.27	AL1 70 to 80%	Displays the percentage of samples recorded by amplitude logger 1 that fall between 70 and 80%.	0.00%
	0.00100.00%	Amplitude logger 1 samples between 70 and 80%.	1 = 1%
36.28	AL1 80 to 90%	Displays the percentage of samples recorded by amplitude logger 1 that fall between 80 and 90%.	0.00%
	0.00100.00%	Amplitude logger 1 samples between 80 and 90%.	1 = 1%

No.	Name/Value	Description	Def/ FbEq16
36.29	AL1 over 90%	Displays the percentage of samples recorded by amplitude logger 1 that exceed 90%.	0.00%
	0.00100.00%	Amplitude logger 1 samples over 90%.	1 = 1%
36.40	AL2 below 10%	Displays the percentage of samples recorded by amplitude logger 2 that were below 10%. Note that this percentage also includes the samples that had a negative value.	0.00%
	0.00100.00%	Amplitude logger 2 samples below 10%.	1 = 1%
36.41	AL2 10 to 20%	Displays the percentage of samples recorded by amplitude logger 2 that fall between 10 and 20%.	0.00%
	0.00100.00%	Amplitude logger 2 samples between 10 and 20%.	1 = 1%
36.42	AL2 20 to 30%	Displays the percentage of samples recorded by amplitude logger 2 that fall between 20 and 30%.	0.00%
	0.00100.00%	Amplitude logger 2 samples between 20 and 30%.	1 = 1%
36.43	AL2 30 to 40%	Displays the percentage of samples recorded by amplitude logger 2 that fall between 30 and 40%.	0.00%
	0.00100.00%	Amplitude logger 2 samples between 30 and 40%.	1 = 1%
36.44	AL2 40 to 50%	Displays the percentage of samples recorded by amplitude logger 2 that fall between 40 and 50%.	0.00%
	0.00100.00%	Amplitude logger 2 samples between 40 and 50%.	1 = 1%
36.45	AL2 50 to 60%	Displays the percentage of samples recorded by amplitude logger 2 that fall between 50 and 60%.	0.00%
	0.00100.00%	Amplitude logger 2 samples between 50 and 60%.	1 = 1%
36.46	AL2 60 to 70%	Displays the percentage of samples recorded by amplitude logger 2 that fall between 60 and 70%.	0.00%
	0.00100.00%	Amplitude logger 2 samples between 60 and 70%.	1 = 1%
36.47	AL2 70 to 80%	Displays the percentage of samples recorded by amplitude logger 2 that fall between 70 and 80%.	0.00%
	0.00100.00%	Amplitude logger 2 samples between 70 and 80%.	1 = 1%
36.48	AL2 80 to 90%	Displays the percentage of samples recorded by amplitude logger 2 that fall between 80 and 90%.	0.00%
	0.00100.00%	Amplitude logger 2 samples between 80 and 90%.	1 = 1%
36.49	AL2 over 90%	Displays the percentage of samples recorded by amplitude logger 2 that exceed 90%.	0.00%
	0.00100.00%	Amplitude logger 2 samples over 90%.	1 = 1%
36.50	AL2 reset date	Displays the date on which amplitude logger 2 was last reset.	-
	-	Last reset date of amplitude logger 2.	-
36.51	AL2 reset time	Displays the time at which amplitude logger 2 was last reset.	-
	-	Last reset time of amplitude logger 2.	-

No.	Name/Value		Des	cription	Def/ FbEq16
					1 52410
37 Use	37 User load curve		Setti	ngs for user load curve.	
			See	also section <i>User load curve</i> (page 99).	
37.01	ULC out word	put status	word para	lays the status of the monitored signal. (The status is independent of the actions and delays selected by meters 37.03, 37.04, 37.41 and 37.42.) parameter is read-only.	-
	Bit	Name		Information	
	0	Under load lii	mit	1 = Monitored signal is below the underload curve	
	1 Reserved			<u> </u>	
	2	Over load lim	it	1 = Monitored signal is above the overload curve	
	315	Reserved		<u> </u>	
		II.			
	2001	10.11			
	000b			us of the monitored signal.	1 = 1
37.02	ULC sup signal	ervision		cts the signal to be monitored. The function compares absolute value of the signal against the load curve.	Not selected
	Not sele	cted	No s	ignal selected (monitoring disabled).	0
	Motor cu	ırrent%	01.0	7 Motor current (see page 121).	2
	Motor to	rque%	01.1	0 Motor torque (see page 121).	3
	Output p	ower% of ominal	01.1	5 Output power% of motor nom (see page 122).	4
	Other		Sour 118)	ce selection (see <i>Terms and abbreviations</i> on page	-
37.03	ULC ove	erload actions	mon	cts how the drive reacts if the absolute value of the itored signal stays above the overload curve for longer the value of 37.41 ULC overload timer.	Disabled
	Disabled	I	No a	ction taken.	0
	Warning		The warr	drive generates a warning (A8BE ULC overload ning).	1
	Fault		Drive	e trips on 8002 ULC overload fault.	2
	Warning/Fault		over over The stays	drive generates a warning (A8BE ULC overload hing) if the signal stays continuously above the load curve for half of the time defined by 37.41 ULC load timer.  drive trips on 8002 ULC overload fault if the signal is continuously above the overload curve for the time led by 37.41 ULC overload timer.	3
37.04	ULC und actions	derload	mon	cts how the drive reacts if the absolute value of the itored signal stays below the underload curve for er than the value of 37.42 ULC underload timer.	Disabled
	Disabled	I	No a	ction taken.	0
	Warning			drive generates a warning (A8BF ULC underload ing).	1
				e trips on 8001 ULC underload fault.	2

No.	Name/Value	Description	Def/ FbEq16
	Warning/Fault	The drive generates a warning (A8BF ULC underload warning) if the signal stays continuously below the underload curve for half of the time defined by 37.42 ULC underload timer.  The drive trips on 8001 ULC underload fault if the signal stays continuously below the underload curve for the time defined by 37.42 ULC underload timer.	3
37.11	ULC speed table point 1	Defines the 1st speed point on the X-axis of the user load curve.  The speed points are used in DTC motor control mode, and in scalar motor control mode when speed control is being used.  The five points must be in order from lowest to highest. The points are defined as positive values, but the range is symmetrically effective also in the negative direction. The monitoring is not active outside these two areas.	150.0 rpm
	0.0 30000.0 rpm	Speed.	1 = 1 rpm
37.12	ULC speed table point 2	Defines the 2nd speed point on the X-axis of the user load curve.	750.0 rpm
	0.0 30000.0 rpm	Speed.	1 = 1 rpm
37.13	ULC speed table point 3	Defines the 3rd speed point on the X-axis of the user load curve.	1290.0 rpm
	0.0 30000.0 rpm	Speed.	1 = 1 rpm
37.14	ULC speed table point 4	Defines the 4th speed point on the X-axis of the user load curve.	1500.0 rpm
	0.0 30000.0 rpm	Speed.	1 = 1 rpm
37.15	ULC speed table point 5	Defines the 5th speed point on the X-axis of the user load curve.	1800.0 rpm
	0.0 30000.0 rpm	Speed.	1 = 1 rpm
37.16	ULC frequency table point 1	Defines the 1st frequency point on the X-axis of the user load curve.  The frequency points are used in scalar motor control mode when frequency control is being used.  The five points must be in order from lowest to highest.  The points are defined as positive values, but the range is symmetrically effective also in the negative direction. The monitoring is not active outside these two areas.	5.0 Hz
	0.0 500.0 Hz	Frequency.	1 = 1 Hz
37.17	ULC frequency table point 2	Defines the 2nd frequency point on the X-axis of the user load curve.	25.0 Hz
	0.0 500.0 Hz	Frequency.	1 = 1 Hz
37.18	ULC frequency table point 3	Defines the 3rd frequency point on the X-axis of the user load curve.	43.0 Hz
	0.0 500.0 Hz	Frequency.	1 = 1 Hz
37.19	ULC frequency table point 4	Defines the 4th frequency point on the X-axis of the user load curve.	50.0 Hz
	0.0 500.0 Hz	Frequency.	1 = 1 Hz
37.20	ULC frequency table point 5	Defines the 5th frequency point on the X-axis of the user load curve.	60.0 Hz
	0.0 500.0 Hz	Frequency.	1 = 1 Hz

No.	Name/Value	Description	Def/ FbEq16
37.21	ULC underload point 1	Defines the 1st point of the underload curve. Each point of the underload curve must have a lower value than the corresponding overload point.	10.0%
	0.0 1600.0%	Underload point.	1 = 1%
37.22	ULC underload point 2	Defines the 2nd point of the underload curve.	15.0%
	0.0 1600.0%	Underload point.	1 = 1%
37.23	ULC underload point 3	Defines the 3rd point of the underload curve.	25.0%
	0.0 1600.0%	Underload point.	1 = 1%
37.24	ULC underload point 4	Defines the 4th point of the underload curve.	30.0%
	0.0 1600.0%	Underload point.	1 = 1%
37.25	ULC underload point 5	Defines the 5th point of the underload curve.	30.0%
	0.0 1600.0%	Underload point.	1 = 1%
37.31	ULC overload point 1	Defines the 1st point of the overload curve. Each point of the overload curve must have a higher value than the corresponding underload point.	300.0%
	0.0 1600.0%	Overload point.	1 = 1%
37.32	ULC overload point 2	Defines the 2nd point of the overload curve.	300.0%
	0.0 1600.0%	Overload point.	1 = 1%
37.33	ULC overload point 3	Defines the 3rd point of the overload curve.	300.0%
	0.0 1600.0%	Overload point.	1 = 1%
37.34	ULC overload point 4	Defines the 4th point of the overload curve.	300.0%
	0.0 1600.0%	Overload point.	1 = 1%
37.35	ULC overload point 5	Defines the 5th point of the overload curve.	300.0%
	0.0 1600.0%	Overload point.	1 = 1%
37.41	ULC overload timer	Defines the time for which the monitored signal must continuously stay above the overload curve before the drive takes the action selected by 37.03 ULC overload actions.	20.0 s
	0.0 10000.0 s	Overload timer.	1 = 1 s
37.42	ULC underload timer	Defines the time for which the monitored signal must continuously stay below the underload curve before the drive takes the action selected by 37.04 ULC underload actions.	20.0 s
	0.0 10000.0 s	Underload timer.	1 = 1 s

No.	Name/Value	Description	Def/ FbEq16
43 Bra	ake chopper	Settings for the internal brake chopper. See also section <i>DC voltage control</i> (page 90).	
43.01	Braking resistor temperature	Displays the estimated temperature of the brake resistor, or how close the brake resistor is to being too hot.  The value is given in percent where 100% is the eventual temperature the resistor would reach when loaded long enough with its rated maximum load capacity (43.09 Brake resistor Pmax cont).  The temperature calculation is based on the values of parameters 43.08, 43.09 and 43.10, and on the assumption that the resistor is installed as instructed by the manufacturer (ie. it cools down as expected).  This parameter is read-only.	-
	0.0120.0%	Estimated brake resistor temperature.	1 = 1%
43.06	Brake chopper function	Enables brake chopper control and selects the brake resistor overload protection method (calculation or measurement).  Note: Before enabling brake chopper control, ensure that  a brake resistor is connected,  overvoltage control is switched off (parameter 30.30 Overvoltage control), and  the supply voltage range (parameter 95.01 Supply voltage) has been selected correctly.	Disabled
	Disabled	Brake chopper control disabled.	0
	Enabled with thermal model	Brake chopper control enabled with resistor overload protection based on a thermal model. If you select this, you must also specify the values needed by the model, ie. parameters 43.0843.12. See the resistor data sheet.	1
	Enabled without thermal model	Brake chopper control enabled without resistor overload protection. This setting can be used, for example, if the resistor is equipped with a thermal circuit breaker that is wired to stop the drive if the resistor overheats.  Before using this setting, ensure that overvoltage control is switched off (parameter 30.30 Overvoltage control)	2

No.	Name/Value	Description	Def/ FbEq16
	Overvoltage peak protection	Brake chopper starts to conduct at 100% pulse width whenever  • the DC voltage exceeds the overvoltage fault limit (a hysteresis applies), and  • the drive is not modulating (for example, during a coast stop).  The thermal model-based resistor overload protection is not active.  This setting is intended for situations where  • the braking chopper is not needed for runtime operation, ie. to dissipate the inertial energy of the motor,  • the motor is able to store a considerable amount of magnetic energy in its windings, and  • the motor might, deliberately or inadvertently, be stopped by coasting.  In such a situation, the motor would potentially discharge enough magnetic energy towards the drive to cause damage. To protect the drive, the brake chopper can be used with a small resistor dimensioned merely to handle the magnetic energy (not the inertial energy) of the motor.	3
43.07	Brake chopper run enable	Selects the source for quick brake chopper on/off control.  0 = Brake chopper IGBT pulses are cut off  1 = Normal brake chopper IGBT modulation allowed.  This parameter can be used to enable chopper operation only when the supply is missing from a drive with a regenerative supply unit.	On
	Off	0.	0
	On	1.	1
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
43.08	Brake resistor thermal tc	Defines the thermal time constant for the brake resistor thermal model, ie. the rated time to achieve 63% temperature.	0 s
	010000 s	Brake resistor thermal time constant, ie. the rated time to achieve 63% temperature.	1 = 1 s
43.09	Brake resistor Pmax cont	Defines the maximum continuous load of the brake resistor which will eventually raise the resistor temperature to the maximum allowed value (= continuous heat dissipation capacity of the resistor in kW) but not above it. The value is used in the resistor overload protection based on the thermal model. See parameter 43.06 Brake chopper function, and the brake resistor data sheet.	0.00 kW
	0.0010000.00 kW	Maximum continuous braking power.	1 = 1 kW
43.10	Brake resistance	Defines the resistance value of the brake resistor. The value is used for the brake chopper protection based on the thermal model. See parameter 43.06 Brake chopper function.	0.0 ohm
	0.01000.0 ohm	Brake resistor resistance value.	1 = 1 ohm

No.	Name/Value	Description	Def/ FbEq16
43.11	Brake resistor fault limit	Selects the fault limit for the brake resistor protection based on the thermal model. See parameter 43.06 Brake chopper function. When the limit is exceeded, the drive trips on fault 7183 BR excess temperature.  The value is given in percent of the temperature the resistor reaches when loaded with the power defined by parameter 43.09 Brake resistor Pmax cont.	105%
	0150%	Brake resistor temperature fault limit.	1 = 1%
43.12	Brake resistor warning limit	Selects the warning limit for the brake resistor protection based on the thermal model. See parameter 43.06 Brake chopper function. When the limit is exceeded, the drive generates a A793 BR excess temperature warning. The value is given in percent of the temperature the resistor reaches when loaded with the power defined by parameter 43.09 Brake resistor Pmax cont.	95%
	0150%	Brake resistor temperature warning limit.	1 = 1%
45 En	ergy efficiency	Settings for the energy saving calculators. See also section <i>Energy savings calculator</i> (page 103).	
45.01	Saved GW hours	Displays the energy saved in GWh compared to direct-on- line motor connection. This parameter is incremented when 45.02 Saved MW hours rolls over. This parameter is read-only (see parameter 45.21 Energy calculations reset).	-
	065535 GWh	Energy savings in GWh.	1 = 1 GWh
45.02	Saved MW hours	Displays the energy saved in MWh compared to direct-on- line motor connection. This parameter is incremented when 45.03 Saved kW hours rolls over. When this parameter rolls over, parameter 45.01 Saved GW hours is incremented. This parameter is read-only (see parameter 45.21 Energy calculations reset).	-
	0999 MWh	Energy savings in MWh.	1 = 1 MWh
45.03	Saved kW hours	Displays the energy saved in kWh compared to direct-on-line motor connection.  If the internal brake chopper of the drive is enabled, all energy fed by the motor to the drive is assumed to be converted into heat, but the calculation still records savings made by controlling the speed. If the chopper is disabled, then regenerated energy from the motor is also recorded here.  When this parameter rolls over, parameter 45.02 Saved MW hours is incremented.  This parameter is read-only (see parameter 45.21 Energy calculations reset).	-
	0.0999.9 kWh	Energy savings in kWh.	10 = 1 kWh
	-		<u> </u>

No.	Name/Value	Description	Def/ FbEq16
45.05	Saved money x1000	Displays the monetary savings in thousands compared to direct-on-line motor connection. This parameter is incremented when 45.06 Saved money rolls over. The currency is defined by parameter 45.17 Tariff currency unit.  This parameter is read-only (see parameter 45.21 Energy calculations reset).	-
	04294967295 thousands	Monetary savings in thousands of units.	-
45.06	Saved money	Displays the monetary savings compared to direct-on-line motor connection. This value is a calculated by multiplying the saved energy in kWh by the currently active energy tariff (45.14 Tariff selection).  When this parameter rolls over, parameter 45.05 Saved money x1000 is incremented.  The currency is defined by parameter 45.17 Tariff currency unit.  This parameter is read-only (see parameter 45.21 Energy calculations reset).	-
	0.00999.99 units	Monetary savings.	1 = 1 unit
45.08	CO2 reduction in kilotons	Displays the reduction in CO <sub>2</sub> emissions in metric kilotons compared to direct-on-line motor connection. This value is incremented when parameter 45.09 CO2 reduction in tons rolls over.  This parameter is read-only (see parameter 45.21 Energy calculations reset).	-
	065535 metric kilotons	Reduction in CO <sub>2</sub> emissions in metric kilotons.	1 = 1 metric kiloton
45.09	CO2 reduction in tons	Displays the reduction in CO <sub>2</sub> emissions in metric tons compared to direct-on-line motor connection. This value is calculated by multiplying the saved energy in MWh by the value of parameter 45.18 CO2 conversion factor (by default, 0.5 metric tons/MWh).  When this parameter rolls over, parameter 45.08 CO2 reduction in kilotons is incremented.  This parameter is read-only (see parameter 45.21 Energy calculations reset).	-
	0.0999.9 metric tons	Reduction in CO <sub>2</sub> emissions in metric tons.	1 = 1 metric ton
45.11	Energy optimizer	Enables/disables the energy optimization function. The function optimizes the motor flux so that total energy consumption and motor noise level are reduced when the drive operates below the nominal load. The total efficiency (motor and drive) can be improved by 120% depending on load torque and speed.  Note: With a permanent magnet motor or a synchronous reluctance motor, energy optimization is always enabled regardless of this parameter.	Disable
	Disable	Energy optimization disabled.	0
	Enable	Energy optimization enabled.	1

No.	Name/Value	Description	Def/ FbEq16
45.12	Energy tariff 1	Defines energy tariff 1 (price of energy per kWh). Depending on the setting of parameter 45.14 Tariff selection, either this value or 45.13 Energy tariff 2 is used for reference when monetary savings are calculated. The currency is defined by parameter 45.17 Tariff currency unit.  Note: Tariffs are read only at the instant of selection, and are not applied retroactively.	1.000 units
	0.0004294966.296 units	Energy tariff 1.	-
45.13	Energy tariff 2	Defines energy tariff 2 (price of energy per kWh). See parameter 45.12 Energy tariff 1.	2.000 units
	0.0004294966.296 units	Energy tariff 2.	-
45.14	Tariff selection	Selects (or defines a source that selects) which pre- defined energy tariff is used. 0 = 45.12 Energy tariff 1 1 = 45.13 Energy tariff 2	Energy tariff 1
	Energy tariff 1	0.	0
	Energy tariff 2	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
45.17	Tariff currency unit	Specifies the currency used for the savings calculations.	EUR
	Local currency	Local currency. The name of the currency can be edited by choosing Menu - Settings - Edit texts on the control panel.	100
	EUR	Euro.	101
	USD	US dollar.	102
45.18	CO2 conversion factor	Defines a factor for conversion of saved energy into CO <sub>2</sub> emissions (kg/kWh or tn/MWh).	0.500 tn/MWh
	0.000 65.535 tn/MWh	Factor for conversion of saved energy into CO <sub>2</sub> emissions.	1 = 1 tn/MWh

No.	Name/Value	Description	Def/ FbEq16
45.19	Comparison power	Actual power that the motor absorbs when connected direct-on-line and operating the application. The value is used for reference when energy savings are calculated. Note: The accuracy of the energy savings calculation is directly dependent on the accuracy of this value. If nothing is entered here, then the nominal motor power is used by the calculation, but that may inflate the energy savings reported as many motors do not absorb nameplate power.	0.0 kW
	0.0100000.0 kW	Motor power.	See par. 46.04
45.21	Energy calculations reset	Resets the savings counter parameters 45.0145.09	Done
	Done	Reset not requested (normal operation), or reset complete.	0
	Reset	Reset the savings counter parameters. The value reverts automatically to <i>Done</i> .	1

	nitoring/scaling itings	Speed supervision settings; actual signal filtering; general scaling settings.  Note: The 16-bit scalings apply when parameter values are read or written directly. With protocol- and profilespecific read/write commands (eg. communication objects), the scaling depends on the protocol or profile. See the documentation of the adapter module.	
46.01	Speed scaling	Defines the maximum speed value used to define the acceleration ramp rate and the initial speed value used to define the deceleration ramp rate (see parameter group 23 Speed reference ramp). The speed acceleration and deceleration ramp times are therefore related to this value (not to parameter 30.12 Maximum speed).  Also defines the 16-bit scaling of speed-related parameters. The value of this parameter corresponds to 20000 in fieldbus, master/follower etc. communication.	1500.00 rpm; 1800.00 rpm (95.20 b0)
	0.1030000.00 rpm	Acceleration/deceleration terminal/initial speed.	1 = 1 rpm
46.02	Frequency scaling	Defines the maximum frequency value used to define the acceleration ramp rate and the initial frequency value used to define deceleration ramp rate (see parameter group 28 Frequency reference chain). The frequency acceleration and deceleration ramp times are therefore related to this value (not to parameter 30.14 Maximum frequency). Also defines the 16-bit scaling of frequency-related parameters. The value of this parameter corresponds to 20000 in fieldbus, master/follower etc. communication.	50.00 Hz; 60.00 Hz (95.20 b0)
	0.101000.00 Hz	Acceleration/deceleration terminal/initial frequency.	10 = 1 Hz
46.03	Torque scaling	Defines the 16-bit scaling of torque parameters. The value of this parameter (in percent of nominal motor torque) corresponds to 10000 in fieldbus, master/follower etc. communication.  See also parameter 46.42 Torque decimals.	100.0%
	0.1 1000.0%	Torque corresponding to 10000 on fieldbus.	10 = 1%

No.	Name/Value	Description	Def/ FbEq16
46.04	Power scaling	Defines the output power value that corresponds to 10000 in fieldbus, master/follower etc. communication. The unit is selected by parameter 96.16 Unit selection.	1000.00 kW or hp
	0.10 30000.00 kW or 0.10 40214.48 hp	Power corresponding to 10000 on fieldbus.	1 = 1 unit
46.05	Current scaling	Defines the 16-bit scaling of current parameters. The value of this parameter corresponds to 10000 in fieldbus, master/follower etc. communication.	10000 A
	030000 A	Current corresponding to 10000 on fieldbus.	1 = 1 A
46.06	Speed ref zero scaling	Defines a speed corresponding to a zero reference received from fieldbus (either the embedded fieldbus interface, or interface FBA A or FBA B). For example, with a setting of 500, the fieldbus reference range of 02000 would correspond to a speed of 500[46.01] rpm.  Note: This parameter is effective only with the ABB Drives communication profile.	0.00 rpm
	0.00 30000.00 rpm	Speed corresponding to minimum fieldbus reference.	1 = 1 rpm
46.07	Frequency ref zero scaling	Defines a frequency corresponding to a zero reference received from fieldbus (either the embedded fieldbus interface, or interface FBA A or FBA B). For example, with a setting of 30, the fieldbus reference range of 020000 would correspond to a speed of 30[46.02] Hz.  Note: This parameter is effective only with the ABB Drives communication profile.	0.00 Hz
	0.00 1000.00 Hz	Frequency corresponding to minimum fieldbus reference.	10 = 1 Hz
46.11	Filter time motor speed	Defines a filter time for signals 01.01 Motor speed used, 01.02 Motor speed estimated, 01.04 Encoder 1 speed filtered and 01.05 Encoder 2 speed filtered.	500 ms
	020000 ms	Motor speed signal filter time.	1 = 1 ms
46.12	Filter time output frequency	Defines a filter time for signal <i>01.06 Output frequency</i> .	500 ms
	020000 ms	Output frequency signal filter time.	1 = 1 ms
46.13	Filter time motor torque	Defines a filter time for signal 01.10 Motor torque.	100 ms
	020000 ms	Motor torque signal filter time.	1 = 1 ms
46.14	Filter time power out	Defines a filter time for signal 01.14 Output power.	100 ms
	020000 ms	Output power signal filter time.	1 = 1 ms

No.	Name/Value	Description	Def/ FbEq16		
46.21	At speed hysteresis  Defines the "at setpoint" limits for speed control of the drive.  When the absolute difference between reference (22.87 Speed reference act 7) and actual speed (90.01 Motor speed for control) is smaller than 46.21 At speed hysteresis, the drive is considered to be "at setpoint". This is indicated by bit 8 of 06.11 Main status word.  The bit switches off when the absolute difference between reference and actual speed exceeds the value of 46.21 At speed hysteresis.				
		90.01 (rpm)  Hysteresis  Drive at setpoint (06.11 bit 8 = 1)  Hysteresis  Hysteresis  22.87 + 46.21 (rpm)  22.87 + 0.5 x 46.21 (rpm)  22.87 - 0.5 x 46.21 (rpm)  22.87 - 46.21 (rpm)  0 rpm			
	0.00 30000.00 rpm	Limit for "at setpoint" indication in speed control.	See par. 46.01		
46.22	At frequency hysteresis	Defines the "at setpoint" limits for frequency control of the drive. When the absolute difference between reference (28.96 Frequency ref ramp input) and actual frequency (01.06 Output frequency) is smaller than 46.22 At frequency hysteresis, the drive is considered to be "at setpoint". This is indicated by bit 8 of 06.11 Main status word.  01.06 (Hz)  Drive at setpoint (06.11 bit 8 = 1)	10.00 Hz		
	0.00 1000.00 Hz	Limit for "at setpoint" indication in frequency control.	See par.		
	0.30 1000.00 112	Emiliar at suppoint indication in frequency control.	46.02		
46.23	At torque hysteresis	Defines the "at setpoint" limits for torque control of the drive. When the absolute difference between reference and actual torque (01.10 Motor torque) is smaller than 46.23 At torque hysteresis, the drive is considered to be "at setpoint". This is indicated by bit 8 of 06.11 Main status word.	10.0%		
	0.0 300.0%	Limit for "at setpoint" indication in torque control.	See par. 46.03		

No.	Name/Value	Description	Def/ FbEq16
46.31	Above speed limit	Defines the trigger level for "above limit" indication in speed control. When actual speed exceeds the limit, bit 10 of 06.17 Drive status word 2 is set.	1500.00 rpm
	0.00 30000.00 rpm	"Above limit" indication trigger level for speed control.	See par. 46.01
46.32	Above frequency limit	Defines the trigger level for "above limit" indication in frequency control. When actual frequency exceeds the limit, bit 10 of 06.17 Drive status word 2 is set.	50.00 Hz
	0.00 1000.00 Hz	"Above limit" indication trigger level for frequency control.	See par. 46.02
46.33	Above torque limit	Defines the trigger level for "above limit" indication in torque control. When actual torque exceeds the limit, bit 10 of 06.17 Drive status word 2 is set.	300.0%
	0.0 1600.0%	"Above limit" indication trigger level for torque control.	-
46.42	Torque decimals	Defines the number of decimal places of torque-related parameters.	1
	02	Number of decimal places of torque parameters.	1 = 1
46.200	Rod torque scaler	Defines 16-bit scaling of rod torque parameters. The value of this parameter corresponds to 16-bit fieldbus equivalent to 1 torque value. (Nm, lbft). For example, if 46.200 Rod torque scaler = 10, then 10 = 1 Nm in fieldbus.	10
	0100000	16-bit scaling of rod torque parameters.	1 = 1
46.201	Rod speed scaler	Defines 16-bit scaling of rod speed parameters. The value of this parameter corresponds to 16-bit fieldbus equivalent to 1 Prpm. For example, if 46.201 Rod speed scaler = 10, then 10 = 1 Prpm in fieldbus.	10
	1100000 Prpm	16-bit scaling of rod speed parameters.	1 = 1 Prpm
46.202	Pump speed ref scaler	Defines 16-bit scaling for writing pump speed reference from Fieldbus, when parameter 74.05 Speed ref source is set to FBA or panel or EFB or panel.  The value of this parameter corresponds to 16-bit fieldbus equivalent to 1 ref value (Prpm or Rpm).  For example, if parameter 46.202 Pump speed ref scaler = 10, then 10 = 1 Prpm. When 46.202 Pump speed ref scaler is set to 0, then 74.08 Maximum speed corresponds to 20000 in Fieldbus.	1
	110000 Prpm	16-bit scaling for writing pump speed reference.	1 = 1 Prpm
46.203	Motor speed ref scaler	Defines 16-bit scaling of parameter 09.06 Motor speed reference.  The value of this parameter corresponds to 16-bit fieldbus equivalent to 1 rpm.  For example, if 46.203 Motor speed ref scaler = 10, then 10 = 1 rpm. When 46.203 Motor speed ref scaler is set to 0, then 74.08 Maximum speed corresponds to 20000 in Fieldbus.	0
	110000 rpm	16-bit scaling for motor speed reference.	1 = 1 rpm

No.	Name/Value	Description	Def/ FbEq16
47 Dat	a storage	Data storage parameters that can be written to and read from using other parameters' source and target settings. Note that there are different storage parameters for different data types. Integer-type storage parameters cannot be used as the source of other parameters. See also section <i>Data storage parameters</i> (page 107).	
47.01	Data storage 1 real32	Data storage parameter 1.  Parameters 47.0147.08 are real 32-bit numbers that can be used as source values of other parameters.  Storage parameters 47.0147.08 can be used as the target of received 16-bit data. The scaling and range are defined by parameters 47.3147.38.	0.000
	See par. 47.31	32-bit data real (floating point) number.	See par. 47.31
47.02	Data storage 2 real32	Data storage parameter 2. See also parameter 47.01 Data storage 1 real32.	0.000
	See par. 47.32	32-bit data real (floating point) number.	See par. 47.32
47.03	Data storage 3 real32	Data storage parameter 3. See also parameter 47.01 Data storage 1 real32.	0.000
	See par. 47.33	32-bit data real (floating point) number.	See par. 47.33
47.04	Data storage 4 real32	Data storage parameter 4. See also parameter 47.01 Data storage 1 real32.	0.000
	See par. 47.34	32-bit data real (floating point) number.	See par. 47.34
47.05	Data storage 5 real32	Data storage parameter 5. See also parameter 47.01 Data storage 1 real32.	0.000
	See par. 47.35	32-bit data real (floating point) number.	See par. 47.35
47.06	Data storage 6 real32	Data storage parameter 6. See also parameter 47.01 Data storage 1 real32.	0.000
	See par. 47.36	32-bit data real (floating point) number.	See par. 47.36
47.07	Data storage 7 real32	Data storage parameter 7. See also parameter 47.01 Data storage 1 real32.	0.000
	See par. 47.37	32-bit data real (floating point) number.	See par. 47.37
47.08	Data storage 8 real32	Data storage parameter 8. See also parameter 47.01 Data storage 1 real32.	0.000
	See par. 47.38	32-bit data real (floating point) number.	See par. 47.38
47.11	Data storage 1 int32	Data storage parameter 9.	0
	-2147483648 2147483647	32-bit integer.	-
47.12	Data storage 2 int32	Data storage parameter 10.	0
	-2147483648 2147483647	32-bit integer.	-

No.	Name/Value	Description	Def/ FbEq16
47.13	Data storage 3 int32	Data storage parameter 11.	0
	-2147483648 2147483647	32-bit integer.	-
47.14	Data storage 4 int32	Data storage parameter 12.	0
	-2147483648 2147483647	32-bit integer.	-
47.15	Data storage 5 int32	Data storage parameter 13.	0
	-2147483648 2147483647	32-bit integer.	-
47.16	Data storage 6 int32	Data storage parameter 14.	0
	-2147483648 2147483647	32-bit integer.	-
47.17	Data storage 7 int32	Data storage parameter 15.	0
	-2147483648 2147483647	32-bit integer.	-
47.18	Data storage 8 int32	Data storage parameter 16.	0
	-2147483648 2147483647	32-bit integer.	-
47.21	Data storage 1 int16	Data storage parameter 17.	0
	-3276832767	16-bit integer.	1 = 1
47.22	Data storage 2 int16	Data storage parameter 18.	0
	-3276832767	16-bit integer.	1 = 1
47.23	Data storage 3 int16	Data storage parameter 19.	0
	-3276832767	16-bit integer.	1 = 1
47.24	Data storage 4 int16	Data storage parameter 20.	0
	-3276832767	16-bit integer.	1 = 1
47.25	Data storage 5 int16	Data storage parameter 21.	0
	-3276832767	16-bit integer.	1 = 1
47.26	Data storage 6 int16	Data storage parameter 22.	0
	-3276832767	16-bit integer.	1 = 1
47.27	Data storage 7 int16	Data storage parameter 23.	0
	-3276832767	16-bit integer.	1 = 1
47.28	Data storage 8 int16	Data storage parameter 24.	0
	-3276832767	16-bit integer.	1 = 1
47.31	Data storage 1 real32 type	Defines the scaling of parameter 47.01 Data storage 1 real32 to and from 16-bit integer format. This scaling is used when the data storage parameter is the target of received 16-bit data.  The setting also defines the visible range of the storage parameter.	Unscaled
	Unscaled	Data storage only. Range: -2147483.264 2147473.264.	0
	Transparent	Scaling: 1 = 1. Range: -32768 32767.	1
	General	Scaling: 1 = 100. Range: -327.68 327.67.	2

No.	Name/Value	Description	Def/ FbEq16
	Torque	The scaling is defined by parameter 46.03 Torque scaling. Range: -1600.0 1600.0.	3
	Speed	The scaling is defined by parameter 46.01 Speed scaling. Range: -30000.00 30000.00.	4
	Frequency	The scaling is defined by parameter 46.02 Frequency scaling. Range: -600.00 600.00.	5
47.32	Data storage 2 real32 type	Defines the 16-bit scaling of parameter 47.02 Data storage 2 real32. See parameter 47.31 Data storage 1 real32 type.	Unscaled
47.33	Data storage 3 real32 type	Defines the 16-bit scaling of parameter 47.03 Data storage 3 real32.  See parameter 47.31 Data storage 1 real32 type.	Unscaled
47.34	Data storage 4 real32 type	Defines the 16-bit scaling of parameter 47.04 Data storage 4 real32. See parameter 47.31 Data storage 1 real32 type.	Unscaled
47.35	Data storage 5 real32 type	Defines the 16-bit scaling of parameter 47.05 Data storage 5 real32.  See parameter 47.31 Data storage 1 real32 type.	Unscaled
47.36	Data storage 6 real32 type	Defines the 16-bit scaling of parameter 47.06 Data storage 6 real32. See parameter 47.31 Data storage 1 real32 type.	Unscaled
47.37	Data storage 7 real32 type	Defines the 16-bit scaling of parameter 47.07 Data storage 7 real32.  See parameter 47.31 Data storage 1 real32 type.	Unscaled
47.38	Data storage 8 real32 type	Defines the 16-bit scaling of parameter 47.08 Data storage 8 real32.  See parameter 47.31 Data storage 1 real32 type.	Unscaled

49 Panel port communication		Communication settings for the control panel port on the drive.	
49.01	Node ID number	Defines the node ID of the drive. All devices connected to the network must have a unique node ID.  Note: For networked drives, it is advisable to reserve ID 1 for spare/replacement drives.	1
	132	Node ID.	1 = 1
49.03	Baud rate	Defines the transfer rate of the link.	230.4 kbps
	38.4 kbps	38.4 kbit/s.	1
	57.6 kbps	57.6 kbit/s.	2
	86.4 kbps	86.4 kbit/s.	3
	115.2 kbps	115.2 kbit/s.	4
	230.4 kbps	230.4 kbit/s.	5
49.04	Communication loss time	Sets a timeout for control panel (or PC tool) communication. If a communication break lasts longer than the timeout, the action specified by parameter 49.05 Communication loss action is taken.	10.0 s
	0.33000.0 s	Panel/PC tool communication timeout.	10 = 1 s

No.	Name/Value	Description	Def/ FbEq16
49.05	Communication loss action	Selects how the drive reacts to a control panel (or PC tool) communication break.  Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 49.06 Refresh settings.  See also parameters 49.07 Panel comm supervision force and 49.08 Secondary comm. loss action.	Fault
	No action	No action taken.	0
	Fault	Drive trips on 7081 Control panel loss. This only occurs if control is expected from the control panel (it is selected as source of start/stop/reference in the currently active control location), or if supervision is forced using parameter 49.07 Panel comm supervision force.	1
	Last speed	Drive generates an ATEE Control panel loss warning and freezes the speed to the level the drive was operating at. This only occurs if control is expected from the control panel, or if supervision is forced using parameter 49.07 Panel comm supervision force.  The speed is determined on the basis of actual speed using 850 ms low-pass filtering.  WARNING! Make sure that it is safe to continue operation in case of a communication break.	2
	Speed ref safe	Drive generates an A7EE Control panel loss warning and sets the speed to the speed defined by parameter 22.41 Speed ref safe (or 28.41 Frequency ref safe when frequency reference is being used). This only occurs if control is expected from the control panel, or if supervision is forced using parameter 49.07 Panel comm supervision force.  WARNING! Make sure that it is safe to continue operation in case of a communication break.	3
	Fault always	Drive trips on 7081 Control panel loss. This occurs even though no control is expected from the panel (or PC tool).	4
	Warning	Drive generates an A7EE Control panel loss warning. This only occurs if control is expected from the control panel, or if supervision is forced using parameter 49.07 Panel comm supervision force.  WARNING! Make sure that it is safe to continue operation in case of a communication break.	5
49.06	Refresh settings	Applies the settings of parameters 49.0149.05.  Note: Refreshing may cause a communication break, so reconnecting the drive may be required.	Done
	Done	Refresh done or not requested.	0
	Refresh	Refresh parameters 49.0149.05. The value reverts automatically to <i>Done</i> .	1

No.	Name/\	/alue	Description	Def/ FbEq16
49.07	Panel comm supervision force		Activates control panel communication monitoring separately for each control location (see section <i>Local control vs. external control</i> on page <i>54</i> ). The parameter is primarily intended for monitoring the communication with the panel when it is connected to the application program and not selected as a control source by drive parameters.	0000Ь
	Bit	Name	Value	
	0	Ext 1	1 = Communication monitoring active when Ext 1 is	peing used.
	1	Ext 2	1 = Communication monitoring active when Ext 2 is	peing used.
	2	Local	1 = Communication monitoring active when local cor used.	trol is being
	315	Reserved		
	0000b	0111h	Panel communication monitoring selection.	1 = 1
49.08		ary comm.	Selects how the drive reacts to a control panel (or PC tool)	<u> </u>
	loss act	ion	<ul> <li>communication break. This action is taken when</li> <li>the panel is parametrized as an alternative control or reference source but is not currently the active source, and</li> <li>communication supervision for the active control location is not forced by parameter 49.07 Panel comm supervision force.</li> </ul>	
	No actio	n	No action taken.	0
	Warning	I	Drive generates an A7EE Control panel loss warning.  WARNING! Make sure that it is safe to continue operation in case of a communication break.	5
49.14	Panel s <sub>i</sub>		Defines the unit for speed reference when given from the control panel.	rpm
	rpm		rpm.	0
	%		Percent of parameter 46.01 Speed scaling.	1
49.15	Minimur ref pane	m ext speed el	Defines a minimum limit for control panel speed reference in external control.  In local control, the limits in parameter group 30 Limits are in force. See section Local control vs. external control (page 54).	-30000.00 rpm
	-30000.0 30000.0		Minimum speed reference.	See par. 46.01
49.16	Maximu ref pane	m ext speed	Defines a maximum limit for control panel speed reference in external control.  In local control, the limits in parameter group 30 Limits are in force. See section Local control vs. external control (page 54).	30000.00 rpm
	-30000.0 30000.0		Maximum speed reference.	See par. 46.01

No.	Name/Value	Description	Def/ FbEq16
49.17	Minimum ext frequency ref panel	Defines a minimum limit for control panel frequency reference in external control.	-500.00 Hz
		In local control, the limits in parameter group 30 Limits are in force. See section Local control vs. external control (page 54).	
	-500.00 500.00 Hz	Minimum frequency reference.	See par. 46.02
49.18	Maximum ext frequency ref panel	Defines a maximum limit for control panel frequency reference in external control.  In local control, the limits in parameter group 30 Limits are in force. See section Local control vs. external control (page 54).	500.00 Hz
	-500.00 500.00 Hz	Maximum frequency reference.	See par. 46.02
49.24	Panel actual source	Selects an actual value to be displayed in the top right corner of the control panel. This parameter is only effective when the control panel is not an active reference source.	Automatic
	Automatic	The active reference is displayed.	0
	Process PID setpoint actual	-	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
50 Fie	ldbus adapter	Fieldbus communication configuration.	

	ldbus adapter BA)	Fieldbus communication configuration. See also chapter <i>Fieldbus control through a fieldbus adapter</i> (page 549).	
50.01	FBA A enable	Enables/disables communication between the drive and fieldbus adapter A, and specifies the slot the adapter is installed into.  Note: This parameter cannot be changed while the drive is running.	Disable
	Disable	Communication between drive and fieldbus adapter A disabled.	0
	Option slot 1	Communication between drive and fieldbus adapter A enabled. The adapter is in slot 1.	1
	Option slot 2	Communication between drive and fieldbus adapter A enabled. The adapter is in slot 2.	2
	Option slot 3	Communication between drive and fieldbus adapter A enabled. The adapter is in slot 3.	3
50.02	FBA A comm loss func	Selects how the drive reacts upon a fieldbus communication break. A time delay for the action can be defined by parameter 50.03 FBA A comm loss t out.  See also parameter 50.26 FBA A comm supervision force.	No action
	No action	No action taken.	0
	Fault	Drive trips on 7510 FBA A communication. This only occurs if control is expected from the FBA A interface (FBA A selected as source of start/stop/reference in the currently active control location), or if supervision is forced using parameter 50.26 FBA A comm supervision force.	1

No.	Name/Value	Description	Def/ FbEq16
	Last speed	Drive generates an A7C1 FBA A communication warning and freezes the speed to the level the drive was operating at. This only occurs if control is expected from the FBA A interface, or if supervision is forced using parameter 50.26 FBA A comm supervision force.  WARNING! Make sure that it is safe to continue	2
		operation in case of a communication break.	
	Speed ref safe	Drive generates an A7C1 FBA A communication warning and sets the speed to the value defined by parameter 22.41 Speed ref safe (when speed reference is being used) or 28.41 Frequency ref safe (when frequency reference is being used). This only occurs if control is expected from the FBA A interface, or if supervision is forced using parameter 50.26 FBA A comm supervision force.	3
		WARNING! Make sure that it is safe to continue operation in case of a communication break.	
	Fault always	Drive trips on 7510 FBA A communication. This occurs even though no control is expected from the FBA A interface.	4
	Warning	Drive generates an A7C1 FBA A communication warning. This only occurs if control is expected from the FBA A interface, or if supervision is forced using parameter 50.26 FBA A comm supervision force.  WARNING! Make sure that it is safe to continue operation in case of a communication break.	5
50.03	FBA A comm loss t out	Defines the time delay before the action defined by parameter 50.02 FBA A comm loss func is taken. Time count starts when the communication link fails to update the message.  As a rule of thumb, this parameter should be set to at least 3 times the transmit interval of the master.  Note: There is a 60-second boot-up delay immediately after power-up. During the delay, the communication break monitoring is disabled (but communication itself can be active).	0.3 s
	0.36553.5 s	Time delay.	1 = 1 s
50.04	FBA A ref1 type	Selects the type and scaling of reference 1 received from fieldbus adapter A.  Note: Fieldbus-specific communication profiles may use different scalings. For more information, see the manual of the fieldbus adapter.	Speed
	Auto	Type and scaling are chosen automatically according to which reference chain (see settings <i>Torque</i> , <i>Speed</i> , <i>Frequency</i> ) the incoming reference is connected to. If the reference is not connected to any chain, no scaling is applied (as with setting <i>Transparent</i> ).	0
	Transparent	No scaling is applied (the 16-bit scaling is 1 = 1 unit).	1
	General	Generic reference with a 16-bit scaling of 100 = 1 (ie. integer and two decimals).	2
	Torque	The scaling is defined by parameter 46.03 Torque scaling.	3
	Speed	The scaling is defined by parameter 46.01 Speed scaling.	4

No.	Name/Value	Description	Def/ FbEq16
	Frequency	The scaling is defined by parameter 46.02 Frequency scaling.	5
50.05	FBA A ref2 type	Selects the type and scaling of reference 2 received from fieldbus adapter A. See parameter 50.04 FBA A ref1 type.	Auto
50.07	FBA A actual 1 type	Selects the type/source and scaling of actual value 1 transmitted to the fieldbus network through fieldbus adapter A.  Note: Fieldbus-specific communication profiles may use different scalings. For more information, see the manual of the fieldbus adapter.	Auto
	Auto	Type/source and scaling follow the type of reference 1 selected by parameter 50.04 FBA A ref1 type. See the individual settings below for the sources and scalings.	0
	Transparent	The value selected by parameter 50.10 FBA A act1 transparent source is sent as actual value 1. No scaling is applied (the 16-bit scaling is 1 = 1 unit).	1
	General	The value selected by parameter 50.10 FBA A act1 transparent source is sent as actual value 1 with a 16-bit scaling of 100 = 1 unit (ie. integer and two decimals).	2
	Torque	01.10 Motor torque is sent as actual value 1.	3
	Speed	01.01 Motor speed used is sent as actual value 1. The scaling is defined by parameter 46.01 Speed scaling.	4
	Frequency	01.06 Output frequency is sent as actual value 1. The scaling is defined by parameter 46.02 Frequency scaling.	5
	Position	Motor position is sent as actual value 1. See parameter 90.06 Motor position scaled.	6
50.08	FBA A actual 2 type	Selects the type/source and scaling of actual value 2 transmitted to the fieldbus network through fieldbus adapter A.  See parameter 50.07 FBA A actual 1 type.	Auto
50.09	FBA A SW transparent source	Selects the source of the fieldbus status word when the fieldbus adapter is set to a transparent communication profile eg. by its configuration parameters (group 51 FBA A settings).	Not selected
	Not selected	No source selected.	-
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
50.10	FBA A act1 transparent source	When parameter 50.07 FBA A actual 1 type is set to Transparent or General this parameter selects the source of actual value 1 transmitted to the fieldbus network through fieldbus adapter A.	Not selected
	Not selected	No source selected.	-
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
50.11	FBA A act2 transparent source	When parameter 50.08 FBA A actual 2 type is set to Transparent or General this parameter selects the source of actual value 2 transmitted to the fieldbus network through fieldbus adapter A.	Not selected
	Not selected	No source selected.	-

No. Name/Value		Description	Def/ FbEq16
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
50.12	FBA A debug mode	Enables the display of raw (unmodified) data received from and sent to fieldbus adapter A in parameters 50.1350.18.  This functionality should only be used for debugging.  Note: This parameter cannot be changed while the drive is running.	Fast
	Disable	Display of raw data from fieldbus adapter A disabled.	0
	Fast	Display of raw data from fieldbus adapter A enabled.	1
50.13	FBA A control word	Displays the raw (unmodified) control word sent by the master (PLC) to fieldbus adapter A if debugging is enabled by parameter 50.12 FBA A debug mode.  This parameter is read-only.	-
	00000000h FFFFFFFh	Control word sent by master to fieldbus adapter A.	-
50.14	FBA A reference 1	Displays raw (unmodified) reference REF1 sent by the master (PLC) to fieldbus adapter A if debugging is enabled by parameter 50.12 FBA A debug mode.  This parameter is read-only.	-
	-2147483648 2147483647	Raw REF1 sent by master to fieldbus adapter A.	-
50.15	FBA A reference 2	Displays raw (unmodified) reference REF2 sent by the master (PLC) to fieldbus adapter A if debugging is enabled by parameter 50.12 FBA A debug mode.  This parameter is read-only.	-
	-2147483648 2147483647	Raw REF2 sent by master to fieldbus adapter A.	-
50.16	FBA A status word	Displays the raw (unmodified) status word sent by fieldbus adapter A to the master (PLC) if debugging is enabled by parameter 50.12 FBA A debug mode.  This parameter is read-only.	-
	00000000h FFFFFFFh	Status word sent by fieldbus adapter A to master.	-
50.17	FBA A actual value 1	Displays raw (unmodified) actual value ACT1 sent by fieldbus adapter A to the master (PLC) if debugging is enabled by parameter 50.12 FBA A debug mode.  This parameter is read-only.	-
	-2147483648 2147483647	Raw ACT1 sent by fieldbus adapter A to master.	-
50.18	FBA A actual value 2	Displays raw (unmodified) actual value ACT2 sent by fieldbus adapter A to the master (PLC) if debugging is enabled by parameter 50.12 FBA A debug mode.  This parameter is read-only.	-
	-2147483648 2147483647	Raw ACT2 sent by fieldbus adapter A to master.	-

No.	Name/V	alue	Description	Def/ FbEq16			
50.21	FBA A tin	nelevel sel	In general, lo	he table below show ervices for cyclic hig	levels. ead/write services red vs the time levels of the h and cyclic low data	ne	
			Selection	Cyclic high *	Cyclic low **		
			Monitoring	10 ms	2 ms		
			Normal	2 ms	10 ms		
			Fast	500 µs	2 ms		
			Very fast	250 µs	2 ms		
			and Act2.  ** Cyclic low to parameter out, and acy Control word generated or Note: This p running.	** Cyclic low data consists of the parameter data mapped to parameter groups 52 FBA A data in and 53 FBA A data out, and acyclic data.  Control word, Ref1 and Ref2 are handled as interrupts generated on receipt of cyclic high messages.  Note: This parameter cannot be changed while the drive is running.  This parameter is read only for Fieldbus time level			
	Normal		Normal spee	ed .		0	
	Fast		Fast speed.	, u.		1	
	Very fast		Very fast spe	eed.		2	
	Monitorir			Optimized for PC to	ol communication and		
50.26	FBA A co supervis	omm ion force	for each con external con The parame communicat	trol location (see se trol on page 54). ter is primarily inten- ion with FBAA when brogram and not sele	on monitoring separate ction Local control vs ded for monitoring the n it is connected to the ected as a control sou		
	_					<u> </u>	
	Bit	Name	Value				
	0	Ext 1		mmunication monitor	oring active when Ext	1 is being used.	
	1	Ext 2			oring active when Ext	•	
	2	Local			oring active when loca		
	315	Reserved					
	0000b	0111b	FBA A comm	nunication monitorin	g selection.	1 = 1	
50.31	FBA B e	nable	fieldbus ada installed into	pter B, and specifies	n between the drive a s the slot the adapter changed while the dri	is	
Disable			Communicat disabled.	tion between drive a	and fieldbus adapter B	0	

No.	Name/Value	Description	Def/ FbEq16
	Option slot 1	Communication between drive and fieldbus adapter B enabled. The adapter is in slot 1.	1
	Option slot 2	Communication between drive and fieldbus adapter B enabled. The adapter is in slot 2.	2
	Option slot 3	Communication between drive and fieldbus adapter B enabled. The adapter is in slot 3.	3
50.32	FBA B comm loss func	Selects how the drive reacts upon a fieldbus communication break. A time delay for the action can be defined by parameter 50.33 FBA B comm loss timeout.  See also parameter 50.56 FBA B comm supervision force.	No action
	No action	No action taken.	0
	Fault	Drive trips on 7520 FBA B communication. This only occurs if control is expected from the FBA B interface (FBA B selected as source of start/stop/reference in the currently active control location), or if supervision is forced using parameter 50.56 FBA B comm supervision force.	1
	Last speed	Drive generates an A7C2 FBA B communication warning and freezes the speed to the level the drive was operating at. This only occurs if control is expected from the FBA B interface, or if supervision is forced using parameter 50.56 FBA B comm supervision force.  The speed is determined on the basis of actual speed using 850 ms low-pass filtering.  WARNING! Make sure that it is safe to continue operation in case of a communication break.	2
	Speed ref safe	Drive generates an A7C2 FBA B communication warning and sets the speed to the value defined by parameter 22.41 Speed ref safe (when speed reference is being used) or 28.41 Frequency ref safe (when frequency reference is being used). This only occurs if control is expected from the FBA B interface, or if supervision is forced using parameter 50.56 FBA B comm supervision force.  WARNING! Make sure that it is safe to continue operation in case of a communication break.	3
	Fault always	Drive trips on 7520 FBA B communication. This occurs even though no control is expected from the FBA B interface.	4
	Warning	Drive generates an A7C2 FBA B communication warning. This only occurs if control is expected from the FBA B interface, or if supervision is forced using parameter50.56 FBA B comm supervision force.  WARNING! Make sure that it is safe to continue operation in case of a communication break.	5

No.	Name/Value	Description	Def/ FbEq16
50.33	Defines the time delay before the action defined by parameter 50.32 FBA B comm loss func is taken. Time count starts when the communication link fails to update the message.  As a rule of thumb, this parameter should be set to at least 3 times the transmit interval of the master.  Note: There is a 60-second boot-up delay immediately after power-up. During the delay, the communication break monitoring is disabled (but communication itself can be active).		0.3 s
	0.36553.5 s	Time delay.	1 = 1 s
50.34	FBA B ref1 type	Selects the type and scaling of reference 1 received from fieldbus adapter B.  See parameter 50.04 FBA A ref1 type.	Auto
50.35	FBA B ref2 type	Selects the type and scaling of reference 2 received from fieldbus adapter B.  See parameter 50.04 FBA A ref1 type.	Auto
50.37	FBA B actual 1 type	Selects the type/source and scaling of actual value 1 transmitted to the fieldbus network through fieldbus adapter B.  See parameter 50.07 FBA A actual 1 type.	Auto
50.38	FBA B actual 2 type	Selects the type/source and scaling of actual value 2 transmitted to the fieldbus network through fieldbus adapter B.  For the selections, see parameter 50.08 FBA A actual 2 type.	Auto
50.39	FBA B SW transparent source	Selects the source of the fieldbus status word when the fieldbus adapter is set to a transparent communication profile eg. by its configuration parameters (group 54 FBA B settings).	Not selected
	Not selected	No source selected.	-
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
50.40	FBA B act1 transparent source	When parameter 50.37 FBA B actual 1 type is set to Transparent or General this parameter selects the source of actual value 1 transmitted to the fieldbus network through fieldbus adapter B.	Not selected
	Not selected	No source selected.	-
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
50.41	FBA B act2 transparent source	When parameter 50.38 FBA B actual 2 type is set to Transparent or General this parameter selects the source of actual value 2 transmitted to the fieldbus network through fieldbus adapter B.	Not selected
	Not selected	No source selected.	-
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-

No.	Name/Value	Description	Def/ FbEq16		
50.42	FBA B debug mode  Enables the display of raw (unmodified) data received from and sent to fieldbus adapter B in parameters 50.4350.48.  This functionality should only be used for debugging.  Note: This parameter cannot be changed while the drive is running.				
	Disable	Display of raw data from fieldbus adapter B disabled.	0		
	Fast	Display of raw data from fieldbus adapter B enabled.	1		
50.43	FBA B control word	Displays the raw (unmodified) control word sent by the master (PLC) to fieldbus adapter B if debugging is enabled by parameter 50.42 FBA B debug mode.  This parameter is read-only.	-		
	00000000h FFFFFFFh	Control word sent by master to fieldbus adapter B.	-		
50.44	FBA B reference 1	Displays raw (unmodified) reference REF1 sent by the master (PLC) to fieldbus adapter B if debugging is enabled by parameter 50.42 FBA B debug mode.  This parameter is read-only.	-		
	-2147483648 2147483647	Raw REF1 sent by master to fieldbus adapter B.	-		
50.45	FBA B reference 2	Displays raw (unmodified) reference REF2 sent by the master (PLC) to fieldbus adapter B if debugging is enabled by parameter 50.42 FBA B debug mode.  This parameter is read-only.	-		
	-2147483648 2147483647	Raw REF2 sent by master to fieldbus adapter B.	-		
50.46	FBA B status word	Displays the raw (unmodified) status word sent by fieldbus adapter B to the master (PLC) if debugging is enabled by parameter 50.42 FBA B debug mode.  This parameter is read-only.	-		
	00000000h FFFFFFFh	Status word sent by fieldbus adapter B to master.	-		
50.47	FBA B actual value 1	Displays raw (unmodified) actual value ACT1 sent by fieldbus adapter B to the master (PLC) if debugging is enabled by parameter 50.42 FBA B debug mode.  This parameter is read-only.	-		
	-2147483648 2147483647	Raw ACT1 sent by fieldbus adapter B to master.	-		
50.48	FBA B actual value 2	Displays raw (unmodified) actual value ACT2 sent by fieldbus adapter B to the master (PLC) if debugging is enabled by parameter 50.42 FBA B debug mode.  This parameter is read-only.	-		
	-2147483648 2147483647	Raw ACT2 sent by fieldbus adapter B to master.	-		

No.	Name/V	alue alue	Description			Def/ FbEq16
50.51	50.51 FBA B timelevel sel  Selects the communication time levels. In general, lower time levels of read/write services reduce CPU load. The table below shows the time levels of the read/write services for cyclic high and cyclic low data with each parameter setting.					:
			Selection	Cyclic high *	Cyclic low **	
			Monitoring	10 ms	2 ms	
			Normal	2 ms	10 ms	
			Fast	500 µs	2 ms	
			Very fast	250 µs	2 ms	
	* Cyclic high data consists of fieldbus Status word, Act1 and Act2.  ** Cyclic low data consists of the parameter data mapped to parameter groups 55 FBA B data in and 56 FBA B data out, and acyclic data.  Control word, Ref1 and Ref2 are handled as interrupts generated on receipt of cyclic high messages.  Note: This parameter cannot be changed while the drive i running.  This parameter is read only for Fieldbus time level selection.				ed ata	
	Normal		Normal speed.			0
	Fast		Fast speed.			1
	Very fast	į	Very fast speed.		2	
	Monitorir	ng	Low speed. Optimize monitoring usage.	ed for PC tool cor	mmunication and	3
50.56	FBA B co supervis		Activates fieldbus communication monitoring separately			
	Bit	Name	Value			
	0	Ext 1		ation monitoring	active when Ext 1	is being used
	1	Ext 2			active when Ext 2	<u> </u>
	2	Local			active when local	
	315 Reserved					
			·		•	
0000b0111b			FBA B communication	on monitoring sel	ection.	1 = 1

No.	Name/Value	Description	Def/ FbEq16
51 FB/	A A settings	Fieldbus adapter A configuration.	
51.01	FBA A type	Displays the type of the connected fieldbus adapter module.  0 = Module is not found or is not properly connected, or is disabled by parameter 50.01 FBA A enable; 1 = FPBA; 32 = FCAN; 37 = FDNA; 101 = FCNA, 128 = FENA-11/21; 135 = FECA; 136 = FEPL; 485 = FSCA.  This parameter is read-only.	-
51.02	FBA A Par2	Parameters 51.0251.26 are adapter module-specific. For more information, see the documentation of the fieldbus adapter module. Note that not all of these parameters are necessarily in use.	-
	065535	Fieldbus adapter configuration parameter.	1 = 1
51.26	FBA A Par26	See parameter 51.02 FBA A Par2.	-
	065535	Fieldbus adapter configuration parameter.	1 = 1
51.27	FBA A par refresh	Validates any changed fieldbus adapter module configuration settings. After refreshing, the value reverts automatically to <i>Done</i> .  Note: This parameter cannot be changed while the drive is running.	Done
	Done	Refreshing done.	0
	Refresh	Refreshing.	1
51.28	FBA A par table ver	Displays the parameter table revision of the fieldbus adapter module mapping file (stored in the memory of the drive).  In format axyz, where ax = major table revision number; yz = minor table revision number.  This parameter is read-only.	-
		Parameter table revision of adapter module.	-
51.29	FBA A drive type code	Displays the drive type code in the fieldbus adapter module mapping file (stored in the memory of the drive). This parameter is read-only.	-
	065535	Drive type code stored in the mapping file.	1 = 1
51.30	FBA A mapping file ver	Displays the fieldbus adapter module mapping file revision stored in the memory of the drive in decimal format. This parameter is read-only.	-
	065535	Mapping file revision.	1 = 1
51.31	D2FBA A comm status	Displays the status of the fieldbus adapter module communication.	-
	Not configured	Adapter is not configured.	0
	Initializing	Adapter is initializing.	1
	Time out	A timeout has occurred in the communication between the adapter and the drive.	2
	Configuration error	Adapter configuration error: mapping file not found in the file system of the drive, or mapping file upload has failed more than three times.	3
	Off-line	Fieldbus communication is off-line.	4

No.	Name/Value	Description	Def/ FbEq16
	On-line	Fieldbus communication is on-line, or fieldbus adapter has been configured not to detect a communication break. For more information, see the documentation of the fieldbus adapter.	5
	Reset	Adapter is performing a hardware reset.	6
51.32	FBA A comm SW ver	Displays the patch and build versions of the adapter module firmware in format xxyy, where xx = patch version number, yy = build version number.  Example: C802 = 200.02 (patch version 200, build version 2).	
		Patch and build versions of adapter module firmware.	-
51.33	FBA A appl SW ver	Displays the major and minor versions of the adapter module firmware in format xyy, where x = major revision number, yy = minor revision number.  Example: 300 = 3.00 (major version 3, minor version 00).	
		Major and minor versions of adapter module firmware.	-

52 FBA A data in	Selection of data to be transferred from drive to fieldbus controller through fieldbus adapter A.  Note: 32-bit values require two consecutive parameters. Whenever a 32-bit value is selected in a data parameter, the next parameter is automatically reserved.	
52.01 FBA A data in1	Parameters 52.0152.12 select data to be transferred from the drive to the fieldbus controller through fieldbus adapter A.	None
None	None.	0
CW 16bit	Control Word (16 bits)	1
Ref1 16bit	Reference REF1 (16 bits)	2
Ref2 16bit	Reference REF2 (16 bits)	3
SW 16bit	Status Word (16 bits)	4
Act1 16bit	Actual value ACT1 (16 bits)	5
Act2 16bit	Actual value ACT2 (16 bits)	6
CW 32bit	Control Word (32 bits)	11
Ref1 32bit	Reference REF1 (32 bits)	12
Ref2 32bit	Reference REF2 (32 bits)	13
SW 32bit	Status Word (32 bits)	14
Act1 32bit	Actual value ACT1 (32 bits)	15
Act2 32bit	Actual value ACT2 (32 bits)	16
SW2 16bit	Status Word 2 (16 bits)	24

No.	Name/Value	Description	Def/ FbEq16
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
52.12	FBA A data in12	See parameter 52.01 FBA A data in1.	None
53 FB	A A data out	Selection of data to be transferred from fieldbus controller to drive through fieldbus adapter A.  Note: 32-bit values require two consecutive parameters. Whenever a 32-bit value is selected in a data parameter, the next parameter is automatically reserved.	
53.01	FBA A data out1	Parameters 53.0153.12 select data to be transferred from the fieldbus controller to the drive through fieldbus adapter A.	None
	None	None.	0
	CW 16bit	Control Word (16 bits)	1
	Ref1 16bit	Reference REF1 (16 bits)	2
	Ref2 16bit	Reference REF2 (16 bits)	3
	CW 32bit	Control Word (32 bits)	11
	Ref1 32bit	Reference REF1 (32 bits)	12
	Ref2 32bit	Reference REF2 (32 bits)	13
	CW2 16bit	Control Word 2 (16 bits)	21
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
53.12	FBA A data out12	See parameter 53.01 FBA A data out1.	None

54 FB	A B settings	Fieldbus adapter B configuration.	
54.01	FBA B type	Displays the type of the connected fieldbus adapter module.  0 = Module is not found or is not properly connected, or is disabled by parameter 50.31 FBA B enable; 1 = FPBA; 32 = FCAN; 37 = FDNA; 101 = FCNA, 128 = FENA-11/21; 135 = FECA; 136 = FEPL; 485 = FSCA.  This parameter is read-only.	-
54.02	FBA B Par2	Parameters 54.0254.26 are adapter module-specific. For more information, see the documentation of the fieldbus adapter module. Note that not all of these parameters are necessarily in use.	-
	065535	Fieldbus adapter configuration parameter.	1 = 1
54.26	FBA B Par26	See parameter 54.02 FBA B Par2.	-
	065535	Fieldbus adapter configuration parameter.	1 = 1
54.27	FBA B par refresh	Validates any changed fieldbus adapter module configuration settings. After refreshing, the value reverts automatically to <i>Done</i> .  Note: This parameter cannot be changed while the drive is running.	Done
	Done	Refreshing done.	0

No.	Name/Value	Description	Def/ FbEq16
	Refresh	Refreshing.	1
54.28	FBA B par table ver	Displays the parameter table revision of the fieldbus adapter module mapping file (stored in the memory of the drive).  In format axyz, where ax = major table revision number; yz = minor table revision number.  This parameter is read-only.	-
		Parameter table revision of adapter module.	-
54.29	FBA B drive type code	Displays the drive type code in the fieldbus adapter module mapping file (stored in the memory of the drive). This parameter is read-only.	-
	065535	Drive type code stored in the mapping file.	1 = 1
54.30	FBA B mapping file ver	Displays the fieldbus adapter module mapping file revision stored in the memory of the drive in decimal format.  This parameter is read-only.	-
	065535	Mapping file revision.	1 = 1
54.31	D2FBA B comm status	Displays the status of the fieldbus adapter module communication.	-
	Not configured	Adapter is not configured.	0
	Initializing	Adapter is initializing.	1
	Time out	A timeout has occurred in the communication between the adapter and the drive.	2
	Configuration error	Adapter configuration error: mapping file not found in the file system of the drive, or mapping file upload has failed more than three times.	3
	Off-line	Fieldbus communication is off-line.	4
	On-line	Fieldbus communication is on-line, or fieldbus adapter has been configured not to detect a communication break. For more information, see the documentation of the fieldbus adapter.	5
	Reset	Adapter is performing a hardware reset.	6
54.32	FBA B comm SW ver	Displays the patch and build versions of the adapter module firmware in format xxyy, where xx = patch version number, yy = build version number.  Example: C802 = 200.02 (patch version 200, build version 2).	
		Patch and build versions of adapter module firmware.	-
54.33	FBA B appl SW ver	Displays the major and minor versions of the adapter module firmware in format xyy, where x = major revision number, yy = minor revision number.  Example: 300 = 3.00 (major version 3, minor version 00).	
	-	Major and minor versions of adapter module firmware.	-
55 FB.	A B data in	Selection of data to be transferred from drive to fieldbus controller through fieldbus adapter B.	
55.01	FBA B data in1	Parameters 55.0155.12 select data to be transferred from the drive to the fieldbus controller through fieldbus adapter B.	None
	None	None.	0
		1	l .

No.	Name/Value	Description	Def/ FbEq16
	CW 16bit	Control Word (16 bits)	1
	Ref1 16bit	Reference REF1 (16 bits)	2
	Ref2 16bit	Reference REF2 (16 bits)	3
	SW 16bit	Status Word (16 bits)	4
	Act1 16bit	Actual value ACT1 (16 bits)	5
	Act2 16bit	Actual value ACT2 (16 bits)	6
	CW 32bit	Control Word (32 bits)	11
	Ref1 32bit	Reference REF1 (32 bits)	12
	Ref2 32bit	Reference REF2 (32 bits)	13
	SW 32bit	Status Word (32 bits)	14
	Act1 32bit	Actual value ACT1 (32 bits)	15
	Act2 32bit	Actual value ACT2 (32 bits)	16
	SW2 16bit	Status Word 2 (16 bits)	24
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
55.12	FBA B data in12	See parameter 55.01 FBA B data in1.	None

56 FB	A B data out	Selection of data to be transferred from fieldbus controller to drive through fieldbus adapter B.		
56.01	FBA B data out1	Parameters 56.0156.12 select data to be transferred from the fieldbus controller to the drive through fieldbus adapter B.	None	
	None	None.	0	
	CW 16bit	Control Word (16 bits)	1	
	Ref1 16bit	Reference REF1 (16 bits)	2	
	Ref2 16bit	Reference REF2 (16 bits)	3	
	CW 32bit	Control Word (32 bits)	11	
	Ref1 32bit	Reference REF1 (32 bits)	12	
	Ref2 32bit	Reference REF2 (32 bits)	13	
	CW2 16bit	Control Word 2 (16 bits)	21	
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-	
56.12	FBA B data out12	See parameter 56.01 FBA B data out1.	None	

No.	Name/Value	Description	Def/ FbEq16
58 Em	bedded fieldbus	Configuration of the embedded fieldbus (EFB) interface. See also chapter <i>Fieldbus control through the embedded fieldbus interface (EFB)</i> (page 525).	
58.01	Protocol enable	Enables/disables the embedded fieldbus interface and selects the protocol to use.  Note:  When the embedded fieldbus interface is enabled, the drive-to-drive link functionality is automatically disabled.  This parameter cannot be changed while the drive is running.	None
	None	None.	0
	Modbus RTU	Embedded fieldbus interface is enabled and uses the Modbus RTU protocol.	1
58.02	Protocol ID	Displays the protocol ID and revision. This parameter is read-only.	-
		Protocol ID and revision.	1 = 1
58.03	Node address	Defines the node address of the drive on the fieldbus link. Values 1247 are allowable. Two devices with the same address are not allowed on-line.  Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control.	1
	0255	Node address (values 1247 are allowable).	1 = 1
58.04	Baud rate	Selects the transfer rate of the fieldbus link. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control.	19.2 kbps
	9.6 kbps	9.6 kbit/s.	2
	19.2 kbps	19.2 kbit/s.	3
	38.4 kbps	38.4 kbit/s.	4
	57.6 kbps	57.6 kbit/s.	5
	76.8 kbps	76.8 kbit/s.	6
	115.2 kbps	115.2 kbit/s.	7
58.05	Parity	Selects the type of parity bit and the number of stop bits. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control.	8 EVEN 1
	8 NONE 1	Eight data bits, no parity bit, one stop bit.	0
	8 NONE 2	Eight data bits, no parity bit, two stop bits.	1
	8 EVEN 1	Eight data bits, even parity bit, one stop bit.	2
	8 ODD 1	Eight data bits, odd parity bit, one stop bit.	3
58.06	Communication control	Validates any changes in the EFB settings, or activates silent mode.	Enabled
	Enabled	Normal operation.	0
	Refresh settings	Validates any changed EFB configuration settings. Reverts automatically to <i>Enabled</i> .	1

No.	Name/Value	Description	Def/ FbEq16
	Silent mode	Activates silent mode (no messages are transmitted). Silent mode can be terminated by activating the <i>Refresh settings</i> selection of this parameter.	2
58.07	Communication diagnostics	Displays the status of the EFB communication. This parameter is read-only.	-

Bit	Name	Description
0	Init failed	1 = EFB initialization failed
1	Addr config err	1 = Node address not allowed by protocol
2	Silent mode	1 = Drive not allowed to transmit
		0 = Drive allowed to transmit
3	Autobauding	Reserved
4	Wiring error	1 = Errors detected (A/B wires possibly swapped)
5	Parity error	1 = Error detected: check parameters 58.04 and 58.05
6	Baud rate error	1 = Error detected: check parameters 58.05 and 58.04
7	No bus activity	1 = 0 bytes received during last 5 seconds
8	No packets	1 = 0 packets (addressed to any device) detected during last 5
		seconds
9	Noise or addressing error	1 = Errors detected (interference, or another device with the same address on line)
10	Comm loss	1 = 0 packets addressed to the drive received within timeout
		(58.16)
11	CW/Ref loss	1 = No control word or references received within timeout (58.16)
12	Not active	Reserved
13	Protocol 1	Reserved
14	Protocol 2	Reserved
15	Internal error	Reserved

	0000hFFFFh	EFB communication status.	1 = 1
58.08	Received packets	Displays a count of valid packets addressed to the drive. During normal operation, this number increases constantly. Can be reset from the control panel by keeping Reset depressed for over 3 seconds.	-
	04294967295	Number of received packets addressed to the drive.	1 = 1
58.09	Transmitted packets	Displays a count of valid packets transmitted by the drive. During normal operation, this number increases constantly. Can be reset from the control panel by keeping Reset depressed for over 3 seconds.	-
	04294967295	Number of transmitted packets.	1 = 1
58.10	All packets	Displays a count of valid packets addressed to any device on the bus. During normal operation, this number increases constantly.  Can be reset from the control panel by keeping Reset depressed for over 3 seconds.	-
	04294967295	Number of all received packets.	1 = 1

No.	Name/Value	Description	Def/ FbEq16
58.11	UART errors	Displays a count of character errors received by the drive. An increasing count indicates a configuration problem on the bus.  Can be reset from the control panel by keeping Reset depressed for over 3 seconds.	-
	04294967295	Number of UART errors.	1 = 1
58.12	CRC errors	Displays a count of packets with a CRC error received by the drive. An increasing count indicates interference on the bus.  Can be reset from the control panel by keeping Reset depressed for over 3 seconds.	-
	04294967295	Number of CRC errors.	1 = 1
58.14	Communication loss action	Selects how the drive reacts to an EFB communication break. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control. See also parameters 58.15 Communication loss mode and 58.16 Communication loss time.	Fault
	No	No action taken (monitoring disabled).	0
	Fault	Drive trips on 6681 EFB comm loss. This only occurs if control is expected from the EFB (EFB selected as source of start/stop/reference in the currently active control location), or if supervision is forced using parameter 58.36 EFB comm supervision force.	1
	Last speed	Drive generates an A7CE EFB comm loss warning and freezes the speed to the level the drive was operating at. This only occurs if control is expected from the EFB, or if supervision is forced using parameter 58.36 EFB comm supervision force.  The speed is determined on the basis of actual speed using 850 ms low-pass filtering.  WARNING! Make sure that it is safe to continue operation in case of a communication break.	2
	Speed ref safe	Drive generates an A7CE EFB comm loss warning and sets the speed to the speed defined by parameter 22.41 Speed ref safe (or 28.41 Frequency ref safe when frequency reference is being used). This only occurs if control is expected from the EFB, or if supervision is forced using parameter 58.36 EFB comm supervision force.  WARNING! Make sure that it is safe to continue operation in case of a communication break.	3
	Fault always	Drive trips on 6681 EFB comm loss. This occurs even though no control is expected from the EFB.	4
	Warning	Drive generates an A7CE EFB comm loss warning. This only occurs if control is expected from the EFB, or if supervision is forced using parameter 58.36 EFB comm supervision force.	5

No.	Name/Value	Description	Def/ FbEq16
58.15	Communication loss mode	Defines which message types reset the timeout counter for detecting an EFB communication loss.  Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control.  See also parameters 58.14 Communication loss action and 58.16 Communication loss time.	Cw / Ref1 / Ref2
	Any message	Any message addressed to the drive resets the timeout.	1
	Cw / Ref1 / Ref2	A write of the control word or a reference from the fieldbus resets the timeout.	2
58.16	Communication loss time	Sets a timeout for EFB communication. If a communication break lasts longer than the timeout, the action specified by parameter 58.14 Communication loss action is taken. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control.  Note: There is a 30-second boot-up delay immediately after power-up. During the delay, the communication break monitoring is disabled (but communication itself can be active).  See also parameter 58.15 Communication loss mode.	3.0 s
	0.0 6000.0 s	EFB communication timeout.	1 = 1
58.17	Transmit delay	Defines a minimum response delay in addition to any fixed delay imposed by the protocol.  Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control.	0 ms
	065535 ms	Minimum response delay.	1 = 1
58.18	EFB control word	Displays the raw (unmodified) control word sent by the Modbus controller to the drive. For debugging purposes. This parameter is read-only.	-
	0000hFFFFh	Control word sent by Modbus controller to the drive.	1 = 1
58.19	EFB status word	Displays the raw (unmodified) status word sent by the drive to the Modbus controller. For debugging purposes. This parameter is read-only.	-
	0000hFFFFh	Status word sent by the drive to the Modbus controller.	1 = 1
58.25	Control profile	Defines the control profile used by the protocol.	ABB Drives
	ABB Drives	ABB Drives profile (with a 16-bit control word) with registers in the classic format for backward compatibility.	0
	Transparent	Transparent profile (16-bit or 32-bit control word) with registers in the classic format.	2
58.26	EFB ref1 type	Selects the type and scaling of reference 1 received through the embedded fieldbus interface.  The scaled reference is displayed by 03.09 EFB reference 1.	Auto
	Auto	Type and scaling are chosen automatically according to which reference chain (see settings <i>Torque</i> , <i>Speed</i> , <i>Frequency</i> ) the incoming reference is connected to. If the reference is not connected to any chain, no scaling is applied (as with setting <i>Transparent</i> ).	
	Transparent	No scaling is applied.	1

No.	Name/Value	Description	Def/ FbEq16
	General	Generic reference with a specific scaling of 100 = 1 ((ie. integer and two decimals).	2
	Torque	The scaling is defined by parameter 46.03 Torque scaling.	3
	Speed	The scaling is defined by parameter 46.01 Speed scaling.	4
	Frequency	The scaling is defined by parameter 46.02 Frequency scaling.	5
58.27	EFB ref2 type	Selects the type and scaling of reference 2 received through the embedded fieldbus interface.  The scaled reference is displayed by 03.10 EFB reference 2.  For the selections, see parameter 58.26 EFB ref1 type.	Torque
58.28	EFB act1 type	Selects the type of actual value 1.	Auto
	Auto	Type/source and scaling follow the type of reference 1 selected by parameter 58.26 EFB ref1 type. See the individual settings below for the sources and scalings.	0
	Transparent	The value selected by parameter <i>58.31 EFB act1 transparent source</i> is sent as actual value 1. No scaling is applied (the 16-bit scaling is 1 = 1 unit).	1
	General	The value selected by parameter 58.31 EFB act1 transparent source is sent as actual value 1 with a 16-bit scaling of 100 = 1 unit (ie. integer and two decimals).	2
	Torque	01.10 Motor torque is sent as actual value 1. The scaling is defined by parameter 46.03.	3
	Speed	01.01 Motor speed used is sent as actual value 1. The scaling is defined by parameter 46.01 Speed scaling.	4
	Frequency	01.06 Output frequency is sent as actual value 1. The scaling is defined by parameter 46.02 Frequency scaling.	5
	Position	Motor position is sent as actual value 1. See parameter 90.06 Motor position scaled.	6
58.29	EFB act2 type	Selects the type of actual value 2. For the selections, see parameter 58.28 EFB act1 type.	Auto
58.30	EFB status word transparent source	Selects the source of the status word when 58.25 Control profile is set to Transparent.	Not selected
	Not selected	None.	0
	Other	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
58.31	EFB act1 transparent source	Selects the source of actual value 1 when 58.28 EFB act1 type is set to Transparent or General.	Not selected
	Not selected	None.	0
	Other	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
58.32	EFB act2 transparent source	Selects the source of actual value 1 when 58.29 EFB act2 type is set to Transparent or General.	Not selected
	Not selected	None.	0
	Other	Source selection (see <i>Terms and abbreviations</i> on page 118).	-

1 = 1

No.	Name/Value	Description	Def/ FbEq16
58.33	Addressing mode	Defines the mapping between parameters and holding registers in the 400101465535 Modbus register range. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control.	Mode 0
	Mode 0	16-bit values (groups 199, indexes 199): Register address = 400000 + 100 × parameter group + parameter index. For example, parameter 22.80 would be mapped to register 400000 + 2200 + 80 = 402280.  32-bit values (groups 199, indexes 199): Register address = 420000 + 200 × parameter group + 2 × parameter index. For example, parameter 22.80 would be mapped to register 420000 + 4400 + 160 = 424560.	0
	Mode 1	16-bit values (groups 1255. indexes 1255): Register address = 400000 + 256 × parameter group + parameter index. For example, parameter 22.80 would be mapped to register 400000 + 5632 + 80 = 405712.	1
	Mode 2	32-bit values (groups 1127, indexes 1255): Register address = 400000 + 512 × parameter group + 2 × parameter index. For example, parameter 22.80 would be mapped to register 400000 + 11264 + 160 = 411424.	2
58.34	Word order	Selects in which order 16-bit registers of 32-bit parameters are transferred.  For each register, the first byte contains the high order byte and the second byte contains the low order byte.  Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control.	LO-HI
	HI-LO	The first register contains the high order word, the second contains the low order word.	0
	LO-HI	The first register contains the low order word, the second contains the high order word.	1
58.36	EFB comm supervision force	Activates fieldbus communication monitoring separately for each control location (see section Local control vs. external control on page 54).  The parameter is primarily intended for monitoring the communication with EFB when it is connected to the application program and not selected as a control source by drive parameters.	0000Ь

Bit	Name	Value
0	Ext 1	1 = Communication monitoring active when Ext 1 is being used.
1	Ext 2	1 = Communication monitoring active when Ext 2 is being used.
2	Local	1 = Communication monitoring active when local control is being used.
315	Reserved	
	•	

EFB communication monitoring selection.

0000b...0111b

No.	Name/Value	Description	Def/ FbEq16
58.101	Data I/O 1	Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400001.  The master defines the type of the data (input or output). The value is transmitted in a Modbus frame consisting of two 16-bit words. If the value is 16-bit, it is transmitted in the LSW (least significant word). If the value is 32-bit, the subsequent parameter is also reserved for it and must be set to <i>None</i> .	CW 16bit
	None	None.	0
	CW 16bit	Control Word (16 bits).	1
	Ref1 16bit	Reference REF1 (16 bits).	2
	Ref2 16bit	Reference REF2 (16 bits).	3
	SW 16bit	Status Word (16 bits).	4
	Act1 16bit	Actual value ACT1 (16 bits).	5
	Act2 16bit	Actual value ACT2 (16 bits).	6
	CW 32bit	Control Word (32 bits).	11
	Ref1 32bit	Reference REF1 (32 bits).	12
	Ref2 32bit	Reference REF2 (32 bits).	13
	SW 32bit	Status Word (32 bits).	14
	Act1 32bit	Actual value ACT1 (32 bits).	15
	Act2 32bit	Actual value ACT2 (32 bits).	16
	CW2 16bit	Control Word 2 (16 bits). When a 32-bit control word is used, this setting means the most-significant 16 bits.	21
	SW2 16bit	Status Word 2 (16 bits). When a 32-bit control word is used, this setting means the most-significant 16 bits.	24
	RO/DIO control word	Parameter 10.99 RO/DIO control word.	31
	AO1 data storage	Parameter 13.91 AO1 data storage.	32
	AO2 data storage	Parameter 13.92 AO2 data storage.	33
	Feedback data storage	Parameter 40.91 Feedback data storage.	40
	Setpoint data storage	Parameter 40.92 Setpoint data storage.	41
	Other	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
58.102	Data I/O 2	Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400002. For the selections, see parameter 58.101 Data I/O 1.	Ref1 16bit
58.103	Data I/O 3	Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400003.  For the selections, see parameter 58.101 Data I/O 1.	Ref2 16bit

No.	Name/Value	Description	Def/ FbEq16
58.104	Data I/O 4	Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 40004.  For the selections, see parameter 58.101 Data I/O 1.	SW 16bit
58.105	Data I/O 5	Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400005.  For the selections, see parameter 58.101 Data I/O 1.	Act1 16bit
58.106	Data I/O 6	Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 40006.  For the selections, see parameter 58.101 Data I/O 1.	Act2 16bit
58.107	Data I/O 7	Parameter selector for Modbus register address 400007. For the selections, see parameter 58.101 Data I/O 1.	None
58.124	Data I/O 24	Parameter selector for Modbus register address 400024. For the selections, see parameter 58.101 Data I/O 1.	None

74 Pump setup		Basic functions of applications. See section <i>Pump starting speed</i> (page 37).	
74.01	Pump enable	Enables the pump functions related to parameters in group 74 Pump setup to 79 Pump temperature protection.	Enable
	Disable	Disables pump function.	0
	Enable	Enables pump function.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	8
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	9
	Other	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
74.02	Run-time hours reset source	Defines the command source used to reset the run-time hour counter (09.07 Run-time hours) of the pump.	No
	No	Run-time hours reset disabled.	0
	Yes	Run-time hours reset enabled.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	8

No.	Name/Value	Description	Def/ FbEq16
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	9
	Other	Source selection (see <i>Terms and abbreviations</i> on <i>118</i> ).	-
74.03	Gear reduction ratio	Defines the transmission reduction ratio for PCP application.	1.000
	1.0001000.000	Value range.	1000 = 1
74.04	Reference type	Selects the reference type between motor speed or pump speed.	Pump speed/torque
	Pump speed/torque	Speed reference of the pump.	0
	Motor speed/torque	Speed reference of the motor.	1
74.05	Speed ref source	Selects the source for the speed reference.	Al1 scaled
	Zero	Source not selected.	0
	Al1 scaled	12.12 Al1 scaled value (see page 169).	1
	Al2 scaled	12.22 Al2 scaled value (see page 169).	2
	FBA1 ref	Fieldbus adapter A reference1.	3
	FBA2 ref	Fieldbus adapter A reference2.	4
	EFB1 ref	Embedded fieldbus reference 1.	
	EFB2 ref	Embedded fieldbus reference 2.	
	Motor potentiometer ref	22.80 Motor potentiometer ref act (output of the motor potentiometer)	5
	Constant ref	Constant speed reference. See par. 74.06.	6
	Panel reference	Reference from the panel	7
	EFB or panel	Embedded fieldbus reference 1 or reference from control panel.  Note: The reference from the control panel can be used only when EFB ref 1 is zero or EFB communication is lost (see parameter 58.07 Communication diagnostics, bit 10). The EFB or panel selection also allows to start and stop the drive from embedded fieldbus using EFB control word, bit 3.	8
	FBA or panel	Fieldbus adapter A reference 1 or reference from control panel.  Note: The reference from the control panel can be used only when 03.05 FB A reference 1 is zero or FBA communication is lost (see parameter 51.31 D2FBA A comm status).  The selection FBA or panel also allows to start and stop the drive from the fieldbus using Fieldbus control word, bit 3.	9
	Other	Source selection (see <i>Terms and abbreviations</i> on <i>118</i> ).	-
74.06	Speed ref	Sets the speed reference for parameter 74.05 Speed ref source, if set as Constant ref.	0.00 Prpm, rpm or Hz
	0.0030000.00 Prpm	Speed reference.	10 = 1 Prpm, rpm or Hz

No.	Name/Value	Description	Def/ FbEq16
74.07	Minimum speed	Defines the minimum allowed rod/pump speed.  WARNING! This value must not be higher than 74.06 Speed ref  Note: Operational unit for PCP is Prpm.	0.00 Prpm, rpm or Hz
	-10000.00 10000.00 Prpm	Minimum rod speed.	10 = 1 Prpm, rpm or Hz
74.08	Maximum speed	Defines the maximum allowed rod/pump speed.  WARNING! This value must not be lower than 74.07 Minimum speed.	1500.00 Prpm, rpm or Hz
		Note: Operational unit for PCP is rpm.	
	-10000.00 10000.00 Prpm	Maximum rod speed.	10 = 1 Prpm, rpm or Hz
74.10	Acc time	Defines the acceleration time for the rod/pump: from zero to 74.08 Maximum speed.	20.000 s
	0.00010000.000 s	Rod acceleration time.	10 = 1 s
74.11	Dec time	Defines the deceleration time for the rod/pump: from 74.08 Maximum speed to zero speed.	20.000 s
	0.00010000.000 s	Rod acceleration time.	10 = 1 s
74.12	Starting speed enable	Enables the pump starting speed function. See section Pump starting speed on page 37.	Disable
	Disable	Disables pump ramp up.	0
	Enable	Enables pump ramp up.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
74.13	Starting speed	Defines the starting speed. See section <i>Pump starting speed</i> on page 37.	0.00 Prpm, rpm or Hz
	-10000.00 10000.00 Prpm	Pump starting speed.	10 = 1 Prpm, rpm or Hz
74.14	Starting speed acc time	Defines the acceleration time for the Pump starting speed function. See section <i>Pump starting speed</i> on page 37.	0.000 s
	0.000 10000.000 s	Pump starting speed acceleration time.	10 = 1 s
74.15	Starting speed time delay	Defines the delay time for the Pump starting speed function. After this delay, start up procedure ends and the function releases control over speed reference.	0.000 s
	0.000 10000.000 s	Starting speed delay time.	10 = 1 s
74.18	Minimum torque	Defines minimum allowed torque reference for PCP.  WARNING! Default = 0 is recommended for safety purpose to avoid unexpected backward rotation and rod damages.	0.00 N•m or lbft
	-10000.000.00 N•m	Minimum rod torque reference.	See par. 46.200
74.19	Maximum torque	Defines maximum allowed torque reference for PCP.	0.00 N•m or lbft

No.	Name/Value	Description	Def/ FbEq16
	0.0010000.00 N•m	Maximum rod torque reference.	See par. 46.200
74.21	Brake confirmation enable	Enables the Brake confirmation function or selects the source for the enable signal. See section <i>Pump backspin control</i> on page 52.	Disable
	Disable	Disables brake confirmation function.	0
	Enable	Enables brake confirmation function.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
74.22	Brake confirmation source	Selects the source of the actual signal used in the Brake confirmation function. The analog signal feedback from the brake device is compared to 74.23 Brake confirmation limit.  If the actual value is below the limit longer than 74.25 Brake confirmation time, the function controls the mechanical brake on. See also section Pump backspin control on page 52.	Zero
	Zero	Source not selected.	0
	Al1 scaled	12.12 Al1 scaled value (see page 169).	1
	Al2 scaled	12.22 Al2 scaled value (see page 170).	2
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
74.23	Brake confirmation limit	Defines the limit in percentage of range selected by analog input source in parameter 74.22 Brake confirmation source.	0.00%
	0.00100.00%	Brake confirmation limit.	100 = 1%
74.24	Brake confirmation speed	Defines the reference value used in the Brake confirmation function. See parameter 74.22 Brake confirmation source.	0.00 Prpm, rpm or Hz
	-500.000.00 Prpm	Reference speed.	10 = 1 Prpm, rpm or Hz
74.25	Brake confirmation time	Defines the time limit for the Brake confirmation function. See parameter 74.22 Brake confirmation source.	0.000 s
	0.00030.000 s	Brake confirmation time.	10 = 1 s
74.26	Pressure unit selection	Selects the unit to display for pressure related values on the keypad.	kPa
	kPa	kPa	0
	psi	psi	1
74.27	Depth unit selection	Selects the unit to display for depth related values on the keypad.	m
	m	Meters	0
	ft	Feet	1
	Joints	Joints	2
74.81	Pump speed reference	Displays the pump speed reference. This parameter is read-only.	-
	-30000.00 30000.00 Prpm	Pump speed reference.	10 = 1 Prpm

No.	Name/Value	Description	Def/ FbEq16
75 Pu	mp level control	Pump level control function. See section <i>Pump level control</i> (page 38).	
75.01	Level control enable	Enables Pump level control function.	Disable
	Disable	Disables Pump level control function.	0
	Enable	Enables Pump level control function.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
75.02	Fluid level ref	Defines the fluid level set point for the Pump level control function.	0.00 m, ft or Joints
	0.00100000.00 m	Reference	1 = 1 m, ft or Joints
75.03	Fluid level source function	Selects a mathematical function between the feedback sources selected by parameters 75.04 Fluid level source 1 and 75.05 Fluid level source 2.	Source1
	Source1	See parameter 75.04	0
	Source2	See parameter 75.05	1
	Source1 + Source2	Sum of sources 1 and 2	2
	Source1 - Source2	Source 2 subtracted from source 1	3
	Source1 x Source2	Source 1 multiplied by source 2	4
	Source1/Source2	Source 1 divided by source 2	5
75.04	Fluid level source 1	Defines source 1 for parameter 75.03 Fluid level source function.	Zero
	Zero	Source not selected	0
	Al1 scaled	12.12 Al1 scaled value (see page 169)	1
	Al2 scaled	12.22 Al2 scaled value (see page 170)	2
	FBA1 ref	Fieldbus adapter A reference1	3
	FBA2 ref	Fieldbus adapter A reference2	4
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> )	-
75.05	Fluid level source 2	Defines source 2 for parameter 75.03 Fluid level source function.	Zero
	Zero	Source not selected	0
	Al1 scaled	12.12 Al1 scaled value (see page 169)	1
	Al2 scaled	12.22 Al2 scaled value (see page 170)	2
	FBA1 ref	Fieldbus adapter A reference1	3
	FBA2 ref	Fieldbus adapter A reference2	4
	Other	Source selection (see <i>Terms and abbreviations</i> on page 118)	-
75.06	Level meas range	Defines the measuring range for the Pump level control function.	0.00 m, ft or Joints
	0.00100000.00 m	Measuring range	1 = 1 m, ft or Joints

No.	Name/Value	Description	Def/ FbEq16
75.07	Fluid level p-gain	Defines the gain for the Pump level control function.  Note: This value should be kept low to avoid unwanted oscillation from the drive speed reference causing the pump to cycle up and down in rpm.	0.00
	0.005.00	Proportional gain	100 = 1
75.08	Fluid level i-time	Defines the integration time for the Pump level control function.  Note: This value should be kept at a fairly large value to avoid unwanted oscillation from the drive speed reference causing the pump to cycle up and down in rpm.	0.000 s
	0.0003600.000 s	Integration time	10 = 1 s
75.09	Level control invert	Selects the reaction characteristics of the Pump level control function.	Disable
	Disable	When the feedback signal selected by 75.03 Fluid level source 1 is less than 75.02 Fluid level ref, the PI regulator output increases, causing the speed reference to increase.	0
	Enable	When the feedback signal selected by 75.03 Fluid level source 1 is greater than 75.02 Fluid level ref, the PI regulator output increases, causing the speed reference to increase.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
75.10	Level ref change rate	Defines the pump level reference change rate.	0.0000
	0.000030000.0000	Level reference change rate	100 = 1 m/min, 1 ft/min or 1 Joint/min
75.30	Sleep control enable	Enables the Sleep and wake up function. See section Sleep and wake up function on page 40.	Disable
	Disable	Disables sleep and wake up control function.	0
	Enable	Enables sleep and wake up control function.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> )	-
75.31	Sleep warning enable	Enables the warning for the Sleep and wake up function. See section <i>Sleep and wake up function</i> on page <i>40</i> .	Disable
	Disable	Disables sleep and wake up warning.	0
	Enable	Enables sleep and wake up warning.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page 118)	-
75.32	Sleep limit type	Selects the sleep function type: sleep at low limit or sleep at high limit.	Low limit
	Low limit	If 75.30 Sleep control enable is enabled and 75.34 Sleep signal source 1 is less than or equal to 75.36 Sleep level and the condition is true longer than the time 75.08 Fluid level i-time, the pump will shut down.  The Sleep function is active until 75.34 Sleep signal source 1 increases to a level greater than or equal to 75.38 Wakeup level.  See section Sleep and wake up function on page 40.	0

No.	Name/Value	Description	Def/ FbEq16
	High limit	If 75.34 Sleep signal source 1 is greater than or equal to 75.36 Sleep level and the condition is true longer than time 75.08 Fluid level i-time, the pump will shut down.  The Sleep function is active until 75.34 Sleep signal source 1 increases to a level less than or equal to 75.38 Wakeup level.  See section Sleep and wake up function on page 40.	1
75.33	Sleep signal source function	Selects a mathematical function between the feedback sources selected by parameters 75.34 Sleep signal source 1 and 75.35 Sleep signal source 2.	Source1
	Source1	See parameter 75.34.	0
	Source2	See parameter 75.35.	1
	Source1 + Source2	Sum of sources 1 and 2.	2
	Source1 - Source2	Source 2 subtracted from source 1.	3
	Source1 x Source2	Source 1 multiplied by source 2.	4
	Source1 / Source2	Source 1 divided by source 2.	5
75.34	Sleep signal source 1	Defines the source 1 signal monitored for activation of sleep function.	Zero
	Zero	Zero	0
	Al1 scaled	12.12 Al1 scaled value (see page 169)	1
	Al2 scaled	12.22 Al2 scaled value (see page 170)	2
	FBA1 ref	Fieldbus adapter A reference1	3
	FBA2 ref	Fieldbus adapter A reference2	4
	Rod speed	Actual rod speed	5
	Other	Source selection (see <i>Terms and abbreviations</i> on page 118)	-
75.35	Sleep signal source 2	Defines the source 2 signal monitored for activation of sleep function.	Zero
	Zero	Zero	0
	Al1 scaled	12.12 Al1 scaled value (see page 169).	1
	Al2 scaled	12.22 Al2 scaled value (see page 170).	2
	FBA1 ref	Fieldbus adapter A reference1	3
	FBA2 ref	Fieldbus adapter A reference2	4
	Rod speed	Actual rod speed	5
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
75.36	Sleep level	Defines the set point for activation of sleep function. The set point percentage of range selected by analog input source in parameter 75.34 Sleep signal source 1 or 75.35 Sleep signal source 2. See section Sleep and wake up function on page 40. Note: The Wakeup level has higher priority than the Sleep level.	0.00 SourceUnit
	0.00100000000.00 SourceUnit	Sleep level.	10 = 1 SourceUnit

No.	Name/Value	Description	Def/ FbEq16
75.37	Sleep delay time	Defines the time period required to verify Sleep condition.	0.000 s
	0.00010000.000 s	Sleep delay time.	10 = 1 s
75.38	Wakeup level	Defines the set point for the deactivation of sleep function. The set point percentage of range selected by analog input source in parameter 75.34 Sleep signal source 1 or 75.35 Sleep signal source 2.  Note: The Wakeup level has higher priority than the Sleep level.	0.00 SourceUnit
	0.00100000000.00 SourceUnit	Wakeup level.	10 = 1 SourceUnit
75.39	Wakeup delay time	Defines the time period required for verifying Wakeup condition.	0.000 s
	0.00010000.000 s	Wakeup delay time.	10 = 1 s
75.40	Maximum sleep time	Maximum period of time allowed for pump to stay in sleep mode.  Note: To disable this function set parameter value to 0.000.	0.000 s
	0.000100000.000 s	Value range	10 = 1 s

76 Pump pressure protection		Pump pressure protection function. See section <i>Pump pressure protection</i> (page 44).	
76.01	Pressure protection function	Enables Pump pressure protection function.	Disable
	Disable	Disables Pump pressure protection function.	0
	Enable	Enables Pump pressure protection function.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
76.02	Pressure protection latching	Defines the latching type for pump pressure protection.	Non latching
	Non latching	A high pressure or high discharge pressure activates the warning message that is displayed as long as the high pressure condition is active. If the high pressure condition is missing, the pump regains a normal run condition. If the shutdown process finishes and the pump shuts off and the high pressure condition is missing, the pump starts automatically if a valid start command is present.	0
	Latching	The main difference from "Non latching" function is the pump trips on a fault and does not start automatically even if a valid start command is present. A fault reset is required to start the pump.	1
	Latch zero speed	Until the speed is above zero, the pump is in the "Non latching" type and after the speed reaches zero the pump is in the "Latching" type function.	2
76.03	Digital feedback source enable	Enables the source of digital feedback for high pressure protection.	FALSE
	FALSE	Disables digital feedback.	0
	TRUE	Enables digital feedback.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-

No.	Name/Value	Description	Def/ FbEq16
76.04	Digital feedback source	Selects the source of digital feedback for high pressure protection.	FALSE
	FALSE	High pressure condition detected.	0
	TRUE	No high pressure condition.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1(11.02 DIO delayed status, bit 0).	8
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 0).	9
	Other	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
76.05	Analog feedback source enable	Enables the source of analog feedback for high pressure protection.	FALSE
	FALSE	Disables analog feedback.	0
	TRUE	Enables digital feedback.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
76.06	Analog feedback source	Selects the source of analog feedback for high pressure protection.	Zero
	Zero	Zero	0
	Al1 scaled	12.12 Al1 scaled value (see page 169).	1
	Al2 scaled	12.22 Al2 scaled value (see page 170).	2
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
76.07	Analog feedback limit	Defines the analog feedback limit. If the feedback is above this limit, a fault or warning is indicated.	0.00 kPa or psi
	0.0010000.00 kPa	Analog feedback limit.	10 = 1 kPa or psi
76.08	Analog feedback limit delay time	Defines the time period required to verify the analog feedback limit.	0.000 s
	0.0003600.000 s	Analog feedback limit delay time.	10 = 1 s
	mp torque otection	Pump torque protection function. See section <i>Pump torque protection</i> (page 45).	
77.01	Rod torq limit display	Selects the rod protection measurement as torque or current.	Torque
	Torque	Rod torque value for rod torque protection. See parameters 77.04 Rod torq1 limit and 77.09 Rod torq2 limit.	0
	Current	Motor current value for rod current protection. See parameters 77.04 Rod torq1 limit and 77.09 Rod torq2 limit.	1

No.	Name/Value	Description	Def/ FbEq16
77.02	Rod torq1 function	Enables the Rod torque 1 function for pump torque protection.	Disable
	Disable	Disables the Rod torque 1 function.	0
	Enable	Enables the Rod torque 1 function.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
77.03	Rod torq1 limit type	Selects the Rod torque 1 limit type of the fault condition in 77.04 Rod torq1 limit.  Note: A warning is displayed during the shutdown process.	Low limit
	Low limit	The control program triggers the Torque pressure protection function when 09.01 Rod torque is less than or equal to 77.04 Rod torq1 limit and 09.05 Rod speed is less than or equal to 77.05 Rod torq1 speed for a period of time greater than 77.06 Rod torq1 delay time.  A hysteresis (of Rod torque * 5%) is present in the comparator meaning, once the condition is set, it latches until the 09.01 Rod torque increases to a value of [Rod torq1 limit + (Rod torque * 05)].	0
	High limit	The control program triggers the Torque pressure protection function when 09.01 Rod torque is greater than or equal to 77.04 Rod torq1 limit and 09.05 Rod speed is greater than or equal to 77.05 Rod torq1 speed for a period of time greater than 77.06 Rod torq1 delay time. A hysteresis (of Rod torque * 5%) is present in the comparator meaning, once the condition is set, it latches until the 09.01 Rod torque decreases to a value of [Rod torq1 limit - (Rod torque * 05)].	1
77.04	Rod torq1 limit	Defines the torque limit for Rod torque 1 function in engineering units.	0.00 N•m. lbft or A
	0.0010000.00 N•m	Rod torque 1 limit.	10 = 1 N•m, lbft or A
77.05	Rod torq1 speed	Defines the speed limit for rod torque 1 functionality in engineering units.	0.00 Prpm, rpm or Hz
	-3600.00 3600.00 Prpm	Rod torque 1 speed.	10 = 1 Prpm, rpm or Hz
77.06	Rod torq1 delay time	Defines the time period for confirming the high torque 1 condition.	0.000 s
	0.00010000.000 s	Rod torque 1 delay time.	10 = 1 s
77.07	Rod torq2 function	Defines the Rod torque 2 function for pump torque protection.	Disable
	Disable	0	0
	Enable	1	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-

No.	Name/Value	Description	Def/ FbEq16
77.08	Rod torq2 limit type	Selects the Rod torque 2 limit type for the fault condition in 77.09 Rod torq2 limit.  Note: A warning is displayed during the shutdown process.	Low limit
	Low limit	The control program triggers the Torque pressure protection function when 09.01 Rod torque is less than or equal to 77.09 Rod torq2 limit for the time period greater than 77.10 Rod torq2 delay time.  A hysteresis (of Rod torque * 5%) is present in the comparator meaning, once the condition is set, it latches until the Rod torque increases to a value of [Rod torq2 limit+ (Rod torque * 05)].	0
	High limit	The control program triggers the Torque pressure protection function when 09.01 Rod torque is greater than or equal to 77.09 Rod torque limit for a period of time greater than 77.10 Rod torque delay time.  A hysteresis (of Rod torque * 5%) is present in the comparator meaning, once the condition is set, it latches until the Rod torque decreases to a value of [Rod torque limit - (Rod torque * 05)].	1
77.09	Rod torq2 limit	Defines the torque limit for Rod torque 2 limit in engineering units.	0.00 N•m, lbft or A
	0.0010000.00 N•m	Rod torque 2 limit.	10 = 1 N•m, lbft or A
77.10	Rod torq2 delay time	Defines the time period for confirming high torque 2 condition.	0.000 s
	0.00010000.000 s	Rod torque 2 delay time.	10 = 1 s
77.11	Rod torq2 additive speed ref	Defines the additional speed reference that adds to the speed reference once the Rod torque 2 limit function is triggered.	0.00 Prmp, rpm or Hz
	-3600.00 3600.00 Prpm	Rod torque 2 additive speed reference.	10 = 1 Prpm, rpm or Hz
77.12	Rod torq2 speed delay time	Defines the time period to keep the parameter 77.11 Rod torq2 additive speed ref active even when the required condition is not available.	0.000 s
	0.000100000.000 s	Rod torque 2 speed delay time.	10 = 1 s
77.13	Rod torq2 limit counter	Counts the number of times the additional speed reference is added to speed reference.  Note: One counted cycle is considered as appliance of 77.11 Rod torq2 additive speed ref and returning the previous value.	0
	0100	Rod torque 2 limit counter.	1 = 1
77.14	Rod torq2 time window	Defines the time period at which 77.13 Rod torq2 limit counter exceeds its limit and triggers a fault condition.	0.000 s
	0.0007200.000 s	Rod torque 2 time window.	10 = 1 s

No.	Name/Value	Description	Def/ FbEq16
	mp underload otection	Pump underload protection function. See section Pump underload protection (page 49).	
78.01	Underload limit display	Selects the pump underload protection measurement as torque or current.	Torque
	Torque	Rod torque value for rod torque protection. See parameters 78.03 Torque1, 78.05 Torque2 and 78.07 Torque3, which are percentage of rod torque limits in parameter 74.19 Maximum torque.	0
	Current	Motor current value for pump underload protection. See parameters, 78.03 Torque1, 78.05 Torque2 and 78.07 Torque3, which are percentage of motor current limits in parameter 99.06 Motor nominal current.	1
78.02	Underload function	Selects the Pump underload protection function. See section Settings on page 48.	No
	No	No reaction on protection condition.	0
	Warning	Display warning message.	1
	Fault	The control program triggers a fault condition and displays the warning message.  Note: The fault is triggered only after the pump stops.	2
78.03	Torque1	Defines the torque 1 value used for the Y position of the first X-Y plot to create the user defined underload curve for the system.	1600.00 T(%) or A(%)
	0.0010000.00 T (%)	Torque 1	10 = 1 T(%) or A(%)
78.04	Speed1	Defines the Rod speed 1 value used for the X position of the first X-Y plot to create the user defined underload curve for the system.	0.00 Prpm, rpm or Hz
	-3600.00 3600.00 Prpm	Speed 1	10 = 1 Prpm, rpm or Hz
78.05	Torque2	Defines the Rod torque 2 value used for the Y position of the second X-Y plot to create the user defined underload curve for the system.	1600.00 T(%) or A(%)
	0.0010000.00 T(%)	Torque 2	10 = 1 T(%) or A(%)
78.06	Speed2	Defines the Rod speed 2 value used for the X position of the second X-Y plot to create the user defined underload curve for the system.	1000.00 Prpm, rpm or Hz
	-3600.00 3600.00 Prpm	Speed 2	10 = 1 Prpm, rpm or Hz
78.07	Torque3	Defines the Rod torque 3 value used for the Y position of the third X-Y plot to create the user defined underload curve for the system.	1600.00 T(%) or A(%)
	0.0010000.00 T(%)	Torque 3	10 = 1 T(%) or A(%)
78.08	Speed3	Defines the Rod speed 3 value used for the X position of the third X-Y plot to create the user defined underload curve for the system.	1500.00 Prpm, rpm or Hz
	-3600.00 3600.00 Prpm	Speed 3	10 = 1 Prpm, rpm or Hz

No.	Name/Value	Description	Def/ FbEq16
78.09	Underload delay time	Defines the time required to confirm the underload condition.	0.000 s
	0.000100000.000 s	Underload delay time.	10 = 1 s

	mp temperature otection	Pump temperature protection function. See section <i>Pump temperature protection</i> (page <i>50</i> ).	
79.01	Temperature protection function	Selects the Pump temperature protection function.	No
	No	No reaction on protection condition.  Note: However, the PT100 feedback temperature can still be monitored on the keypad at 09.10 Measured temperature.	0
	Warning	Displays warning message. Warning is triggered when the 09.10 Measured temperature is greater than 79.08 Warning temperature limit for 5 sec or the Klixon digital input is false.	1
	Fault	Protection condition triggers fault condition and displays fault message. Fault is triggered when the 09.10 Measured temperature is greater than 79.09 Fault temperature limit for 5 sec or the Klixon digital input is false.  Note: Fault condition means, that fault is triggered after pump stops.	2
79.02	Temperature protection device	Selects 79.01 Temperature protection function feedback source.	Klixon
	Klixon	Using digital sensor.	0
	PT-100	Using analog sensor.	1
	Both	Using both sensors simultaneously.	2
9.03	Klixon signal source	Digital feedback source for the Klixon device.	FALSE
	FALSE	Disables digital feedback functionality.	0
	TRUE	Enables digital feedback functionality.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1(11.02 DIO delayed status, bit 0).	8
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 0).	9
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
9.04	PT100 source	Analog feedback source for PT100.	Zero
	Zero	Zero.	0
	Al1 scaled	12.12 Al1 scaled value (see page 169).	1
	Al2 scaled	12.22 Al2 scaled value (see page 170).	2
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-

No.	Name/Value	Description	Def/ FbEq16
79.05	PT100 exitation source	Feeding current for 13 PT100 sensors.	Zero
	Zero	Zero.	0
	Internal selection	See par 79.06 PT100 internal selection.	1
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
79.06	PT100 internal selection	User defined feeding current.	9.10 mA
	0.0020.00 mA	PT100 internal selection.	100 = 1 mA
79.07	Number of PT100 sensors in series	Number of connected PT100 sensors.	1
	13	Number of PT100 sensors connected in series.	1 = 1
79.08	Warning temperature limit	Temperature limit for displaying warning message.	0.00 °C
	0.00200.00 °C	Warning temperature limit.	10 = 1 °C
79.09	Fault temperature limit	Temperature limit, that triggers a fault.	0.00 °C
	0.00200.00 °C	Fault temperature limit.	10 = 1 °C

	np backspin ntrol	Pump backspin control function. See section <i>Pump backspin control</i> (page 52).	
80.01	Backspin enable	Enables the Backspin function.	Disable
	Disable	Disable backspin function.	0
	Enable	Enable backspin function.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
80.02	Backspin ref limit	Defines the reference speed/frequency limit for the Backspin function. See section <i>Pump backspin control</i> on page 52.  WARNING! If <i>Backspin ref limit</i> is set to 0, the <i>Pump backspin control</i> procedure is ineffective.	0.00 Prpm, rpm or Hz
	-30000.00 0.00 Prpm	Reference limit	10 = 1 Prpm, rpm or Hz
80.03	Backspin acc time	Defines the acceleration time for the Backspin function: from zero speed to 80.02 Backspin ref limit.	60.000
	0.00010000.000 s	Acceleration time	10 = 1 s
80.04	Backspin stop torque	Defines a torque limit for the Backspin function. See section <i>Pump backspin control</i> on page <i>52</i> .  When the actual torque is below the limit, Backspin function is complete and it gives coast to stop command to the drive. <b>Note:</b> This setting eliminates excessive shut down times.	0.00 N•m or lbft
	0.0010000.00 N•m or lbft	Torque limit	See par. 46.200

No.	Name/Value	Description	Def/ FbEq16
80.05	Backspin speed range trim	Sets the speed reference regulation range for the Backspin function. The figure below illustrates how the range changes depending on the load and the speed range setting.  Note: Default = 0% is recommended because it is the safest range of backspin operation to avoid rod damages and drive overvoltage.     0	0.00%
	0.00100.00%	Speed reference in percent of 80.02 Backspin ref limit.	100 = 1%
80.06	Backspin stop delay	Defines the time delay for the Backspin control.  If the torque is below parameter 80.04 Backspin stop torque longer than the time set in parameter 80.06 Backspin stop delay then the controlled backspin function is complete.	3.000 s
	0.0003600.000 s	Delay time	1000 = 1 s
80.11	Restart delay enable	Enables start delay function. See <i>Pump backspin control</i> on page <i>52</i> .	Disable
	Disable	Disables start delay function.	0
	Enable	Enables start delay function.	1
	DI1	Digital input DI1.	2
	DI2	Digital input DI2.	3
	DI3	Digital input DI3.	4
	DI4	Digital input DI4.	5
	DI5	Digital input DI5.	6
	DI6	Digital input DI6.	7
	DIO1	Digital input/output DIO1.	8
	DIO2	Digital input/output DIO2.	9
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
80.12	Restart delay time	Defines the time delay from the previous drive stop to the next possible start. During this time drive is not allowed to start.	3600.000s
		Start delay time	t

No.	Name/Value	Description	Def/ FbEq16
80.21	Backspin dec time	If a new start is given during Backspin operation then the parameter 80.21 Backspin dec time defines the deceleration ramp time when ramped from backspin speed to zero speed. When zero speed is reached then the normal acceleration ramp defined in parameter 74.10 Acc time is followed to ramp to the given reference speed. If the value is zero then the ramp time defined in parameter 74.11 Dec time is followed.	0.000 s
	0.0001800.000 s	Deceleration time	1000 = 1 s

90 Feedback selection		Motor and load feedback configuration. See also sections <i>Encoder support</i> (page 71) and <i>Position counter</i> (page 73), and the diagram on page 569.	
90.01	Motor speed for control	Displays the estimated or measured motor speed that is used for speed control, ie. final motor speed feedback selected by parameter 90.41 Motor feedback selection and filtered by 90.42 Motor speed filter time. In case measured feedback is selected, it is also scaled by the motor gear function (90.43 Motor gear numerator and 90.44 Motor gear denominator).  This parameter is read-only.	-
	-32768.00 32767.00 rpm	Motor speed used for control.	See par. 46.01
90.02	Motor position	Displays the motor position (within one revolution) received from the source selected by parameter 90.41 Motor feedback selection.  In case measured feedback is selected, it is also scaled by the motor gear function (90.43 Motor gear numerator and 90.44 Motor gear denominator).  This parameter is read-only.	-
	0.00000000 1.00000000 rev	Motor position.	32767 = 1 rev
90.03	Load speed	Displays the estimated or measured load speed that is used for motor control, ie. final load speed feedback selected by parameter 90.51 Load feedback selection and filtered by parameter 90.52 Load speed filter time. In case measured feedback is selected, it is also scaled by the load gear function (90.53 Load gear numerator and 90.54 Load gear denominator). In case motor feedback or estimated feedback is used, it is inversely scaled by 90.61 Gear numerator and 90.62 Gear denominator (ie. 90.62 divided by 90.61). This parameter is read-only.	-
	-32768.00 32767.00 rpm	Load speed.	See par. 46.01

No. Name/Value Description		Description	Def/ FbEq16
90.04	Load position	Displays the load position received from the source selected by parameter 90.51 Load feedback selection. The value is multiplied as specified by parameter 90.57 Load position resolution.  In case measured feedback is selected, it is also scaled by the load gear function (90.53 Load gear numerator and 90.54 Load gear denominator).  In case motor feedback or estimated feedback is used, it is	-
		inversely scaled by 90.61 Gear numerator and 90.62 Gear denominator (ie. 90.62 divided by 90.61).  An offset can be defined by 90.56 Load position offset.  This parameter is read-only.	
	-2147483648 2147483647	Load position.	-
90.05	Load position scaled	Displays the scaled load position in decimal format. The position is relative to the initial position set by parameters 90.65 and 90.66.  The number of decimal places is defined by parameter 90.38 Pos counter decimals.  Note: This is a floating point parameter, and the accuracy is compromised near the ends of the range. Consider using parameter 90.07 Load position scaled int instead of this parameter.  This parameter is read-only.	-
	-2147483.648 2147483.647	Scaled load position in decimal format.	-
90.06	Motor position scaled	Displays the calculated motor position.  The axis mode (linear or rollover) and resolution are defined by parameters 90.48 Motor position axis mode and 90.49 Motor position resolution respectively.  Note: The position value can be sent on a fast time level to the fieldbus controller by selecting Position in either 50.07 FBA A actual 1 type, 50.08 FBA A actual 2 type, 50.37 FBA B actual 1 type or 50.38 FBA B actual 2 type.  This parameter is read-only.	-
	-2147483.648 2147483.647	Motor position.	-
90.07	Load position scaled int	Displays the output of the position counter function. The position is relative to the initial position set by parameters 90.58 and 90.59. See section Position counter (page 73), and the block diagram on page 570. This parameter is read-only.	
	-2147483.648 2147483.647	Motor position.	-
90.10	Encoder 1 speed	Displays encoder 1 speed in rpm. This parameter is read-only.	-
	-32768.00 32767.00 rpm	Encoder 1 speed.	See par. 46.01

No.	Name/Value	Description	Def/ FbEq16
90.11	Encoder 1 position	Displays the actual position of encoder 1 within one revolution.  This parameter is read-only.	-
	0.00000000 1.00000000 rev	Encoder 1 position within one revolution.	32767 = 1 rev
90.12	Encoder 1 multitum revolutions	Displays the revolutions of (multiturn) encoder 1 within its value range (see parameter 92.14 Revolution data width). This parameter is read-only.	-
	016777215	Encoder 1 revolutions.	-
90.13	Encoder 1 revolution extension	Displays the revolution count extension for encoder 1. With a single-turn encoder, the counter is incremented when encoder position (parameter 90.11) wraps around in the positive direction, and decremented in the negative direction. With a multiturn encoder, the counter is incremented when the revolutions count (parameter 90.12) exceeds the value range in the positive direction, and decremented in the negative direction. This parameter is read-only.	-
	-2147483648 2147483647	Encoder 1 revolution count extension.	-
90.14	Encoder 1 position raw	Displays the raw measurement data of encoder 1 position (within one revolution) as a 24-bit unsigned integer received from the encoder interface.  This parameter is read-only.	-
	016777215	Raw encoder 1 position within one revolution.	-
90.15	Encoder 1 revolutions raw	Displays the revolutions of (multiturn) encoder 1 within its value range (see parameter 92.14 Revolution data width) as a raw measurement.  This parameter is read-only.	-
	016777215	Raw encoder 1 revolution count.	-
90.20	Encoder 2 speed	Displays encoder 2 speed in rpm. This parameter is read-only.	-
	-32768.00 32767.00 rpm	Encoder 2 speed.	See par. 46.01
90.21	Encoder 2 position	Displays the actual position of encoder 2 within one revolution. This parameter is read-only.	-
	0.00000000 1.00000000 rev	Encoder 2 position within one revolution.	-
90.22	Encoder 2 multitum revolutions	Displays the revolutions of (multiturn) encoder 2 within its value range (see parameter 93.14 Revolution data width). This parameter is read-only.	-
	016777215	Encoder 2 revolutions.	-

No.	Name/Value	Description	Def/ FbEq16
90.23	Encoder 2 revolution extension	Displays the revolution count extension for encoder 2. With a single-turn encoder, the counter is incremented when encoder position (parameter 90.21) wraps around in the positive direction, and decremented in the negative direction.  With a multiturn encoder, the counter is incremented when the revolutions count (parameter 90.22) exceeds the value range in the positive direction, and decremented in the negative direction.  This parameter is read-only.	-
	-2147483648 2147483647	Encoder 2 revolution count extension.	-
90.24	Encoder 2 position raw	Displays the raw measurement data of encoder 2 position (within one revolution) as a 24-bit unsigned integer received from the encoder interface.  This parameter is read-only.	-
	016777215	Raw encoder 2 position within one revolution.	-
90.25	Encoder 2 revolutions raw	Displays the revolutions of (multiturn) encoder 2 within its value range (see parameter 93.14 Revolution data width) as a raw measurement.  This parameter is read-only.	-
	016777215	Raw encoder 2 revolution count.	-
90.26	Motor revolution extension	Displays the motor revolution count extension. The counter is incremented when the position selected by 90.41 Motor feedback selection wraps around in the positive direction, and decremented in the negative direction. This parameter is read-only.	-
	-2147483648 2147483647	Motor revolution count extension.	-
90.27	Load revolution extension	Displays the load revolution count extension. The counter is incremented when the position selected by 90.51 Load feedback selection wraps around in the positive direction, and decremented in the negative direction. This parameter is read-only.	-
	-2147483648 2147483647	Load revolution count extension.	-

selection

Estimate

Encoder 1

Encoder 2

time

Motor speed filter

0 ... 10000 ms

90.42

No. Name/Value		/alue	Description	1	Def/ FbEq16	
90.35	Pos cou	inter status	See section	nation related to the position counter function.  Position counter (page 73).  ter is read-only.	-	
	Bit	Name		Value		
	0	Encoder 1 fe	edback	1 = Encoder 1 selected as load feedback sou	rce	
	1	Encoder 2 fe	edback	1 = Encoder 2 selected as load feedback sou	rce	
	2	Internal posit	ion feedback	1 = Internal load position estimate selected as feedback source		
	3	Motor feedba	ick	1 = Motor feedback selected as load feedbac	k source	
	4	Pos counter i	nit ready	O = Position counter not initialized, or encode was lost.  Fresh counter initialization recommended.  1 = Position counter successfully initialized	r feedback	
	5	Position cour disabled	nter re-init	1 = Position counter initialization is being prevented by p		
	6	Position data	inaccurate	1 = Encoder feedback intermittent or lost. (If trunning, estimated position is used whenever feedback is unavailable. If the drive is in stopl position counting will continue based on encothe connection is restored.)	encoder ped state,	
	715	Reserved		1		
	0000h	CCCCh	Position cou	nter status word.	1 = 1	
90.38 Pos counter decimals		Scales the v scaled and S or read to fro setting corre For example 66770 writte by 1000, so Likewise, the	alues of parameters 90.05 Load position 90.65 Pos counter init value when written from om an external source (eg. fieldbus). The sponds to the number of decimal places. e, with the setting of 3, an integer value of n into 90.65 Pos counter init value is divided the final value applied will be 66.770. e value of 90.05 Load position scaled is 1000 when read.	3		
	09			osition counter decimal places.	1 = 1	
90.41	Motor fe	eedback	Selects the r	motor speed feedback value used during	Estimate	

**Note:** With a permanent magnet motor, make sure an autophasing routine (see page 82) is performed using the selected encoder. If necessary, set parameter 99.13 ID run requested to Autophasing to request a fresh autophasing

A calculated speed estimate generated from the DTC core

Actual speed measured by encoder 1. The encoder is set up by the parameters in group 92 Encoder 1 configuration.

Actual speed measured by encoder 2. The encoder is set

up by the parameters in group 93 Encoder 2 configuration.

3 ms

1 = 1 ms

Defines a filter time for motor speed feedback used for

speed control (90.01 Motor speed for control).

motor control.

routine.

is used.

Motor speed filter time.

No.	Name/Value	Description	Def/ FbEq16
90.43	Motor gear numerator	Parameters 90.43 and 90.44 define a gear function between the motor speed feedback and motor control. The gear is used to correct a difference between the motor and encoder speeds for example if the encoder is not mounted directly on the motor shaft.	1
		90.43 Motor gear numerator Motor speed	
		90.44 Motor gear denominator Encoder speed	
		See also section <i>Load and motor feedback</i> (page 72). <b>Note:</b> This parameter cannot be changed while the drive is running.	
	-2147483648 2147483647	Motor gear numerator.	-
90.44	Motor gear denominator	See parameter 90.43 Motor gear numerator.  Note: This parameter cannot be changed while the drive is running.	1
	-2147483648 2147483647	Motor gear denominator.	-
90.45	Motor feedback fault	Selects how the drive reacts to loss of measured motor feedback.	Fault
	Fault	Drive trips on a 7301 Motor speed feedback or 7381 Encoder 1 fault.	0
	Warning	Drive generates a A798 Encoder option comm loss or A7E1 Encoder warning and continues operation using estimated feedbacks.  Note: Before using this setting, test the stability of the speed control loop with estimated feedback by running the drive on estimated feedback (see 90.41 Motor feedback selection).	1
90.46	Force open loop	Forces the DTC motor model to use estimated motor speed as feedback. This parameter can be activated when the encoder data is obviously unreliable because of slippage, for example.  Note: This parameter only affects the selection of feedback or the motor model, not for the speed controller.	No
	No	The motor model uses the feedback selected by 90.41 Motor feedback selection.	0
	Yes	The motor model uses the calculated speed estimate (regardless of the setting of 90.41 Motor feedback selection, which in this case only selects the source of feedback for the speed controller).	1
90.48	Motor position axis mode	Selects the axis type for motor position measurement.	Rollover
	Linear	Linear.	0
	Rollover	The value is between 0 and 1 revolutions, and rolls over at 360 degrees.	1
90.49	Motor position resolution	Defines how many bits are used for motor position count within one revolution. For example, with the setting of 24, the position value is multiplied by 16777216 for display in parameter 90.06 Motor position scaled (or for fieldbus).	24
	031	Motor position resolution.	-

No.	Name/Value	Description	Def/ FbEq16
90.51	Load feedback selection	Selects the source of load speed and position feedbacks used in control.	None
	None	No load feedback selected.	0
	Encoder 1	Load feedbacks are updated based on the speed and position values read from encoder 1.  The values are scaled by the load gear function (90.53 Load gear numerator and 90.54 Load gear denominator).  The encoder is set up by the parameters in group 92 Encoder 1 configuration.	1
	Encoder 2	Load feedbacks are updated based on the speed and position values read from encoder 2. The values are scaled by the load gear function (90.53 Load gear numerator and 90.54 Load gear denominator). The encoder is set up by the parameters in group 93 Encoder 2 configuration.	2
	Estimate	Calculated speed and position estimates are used. The values are scaled from the motor side to the load side using the inverted ratio between 90.61 Gear numerator and 90.62 Gear denominator (ie. 90.62 divided by 90.61).	3
	Motor feedback	The source selected by parameter 90.41 Motor feedback selection for motor feedback is also used for load feedback.  Any difference between the motor and load speeds (and positions) can be compensated by using the inverted ratio between 90.61 Gear numerator and 90.62 Gear denominator (90.62 divided by 90.61).	4
90.52	Load speed filter time	Defines a filter time for load speed feedback (90.03 Load speed).	4 ms
	010000 ms	Load speed filter time.	-
90.53	Load gear numerator	Parameters 90.53 and 90.54 define a gear function between the load (ie. driven equipment) speed and the encoder feedback selected by parameter 90.51 Load feedback selection. The gear can be used to correct a difference between the load and encoder speeds for example if the encoder is not mounted directly on the rotated machinery.	1
		90.53 Load gear numerator Load speed	
		90.54 Load gear denominator Encoder speed  See also section Load and motor feedback (page 72).  Note: This parameter cannot be changed while the drive is running.	
	-2147483648 2147483647	Load gear numerator.	-
90.54	Load gear denominator	See parameter 90.53 Load gear numerator.  Note: This parameter cannot be changed while the drive is running.	1
	-2147483648 2147483647	Load gear denominator.	-
90.55	Load feedback fault	Selects how the drive reacts to loss of load feedback.	Fault
	Fault	Drive trips on a 73A1 Load feedback fault.	0

No.	Name/Value	Description	Def/ FbEq16
	Warning	Drive generates a A798 Encoder option comm loss or A7B1 Load speed feedback warning and continues operation using estimated feedbacks.	1
90.56	Load position offset	Defines a load-side position offset. The resolution is determined by parameter 90.57 Load position resolution.	0 rev
	-214748364821474 83647 rev	Load-side position offset.	-
90.57	Load position resolution	Defines how many bits are used for load position count within one revolution. For example, with the setting of 16, the position value is multiplied by 65536 for display in parameter 90.04 Load position.	16
	031	Load position resolution.	-
90.58	Pos counter init value int	Defines an initial position (or distance) for the position counter (as an integer value) when parameter 90.59 Pos counter init value int source is set to Pos counter init value int.  See also section Position counter (page 73).	0
	-2147483648 2147483647	Initial integer value for position counter.	-
90.59	Pos counter init value int source	Selects the source of the initial position integer value. When the source selected by 90.67 Pos counter init cmd source activates, the value selected in this parameter is assumed to be the position of the load.	Pos counter init value int
	Zero	0.	0
	Pos counter init value int	Parameter 90.58 Pos counter init value int.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
90.60	Pos counter error and boot action	Selects how the position counter reacts to loss of load feedback.	Request re- initialization
	Request re- initialization	Bit 4 of 90.35 Pos counter status is cleared. Reinitialization of position counter is recommended.	0
	Continue from previous value	Position counting resumes from the previous value over a loss of load feedback or control unit reboot. Bit 4 of 90.35 Pos counter status is not cleared, but bit 6 is set to indicate that an error has occurred.  WARNING! If load feedback is lost when the drive is in stopped state or not powered, the counter is not updated even if the load moves.	1
90.61	Gear numerator	Parameters 90.61 and 90.62 define a gear function between the motor and load speeds.	1
		90.61 Gear numerator Motor speed	
		90.62 Gear denominator Load speed	
		See also section Load and motor feedback (page 72).	
	-2147483648 2147483647	Gear numerator (motor-side).	-
90.62	Gear denominator	See parameter 90.61 Gear numerator.	1
	-2147483648 2147483647	Gear denominator (load-side).	-

No.	Name/Value	Description	Def/ FbEq16
90.63	Feed constant numerator	Parameters 90.63 and 90.64 define the feed constant for the position calculation:	1
		90.63 Feed constant numerator	
		90.64 Feed constant denominator	
		The feed constant converts rotational motion into translatory motion. The feed constant is the distance the load moves during one turn of the motor shaft.  The translatory load position is shown by parameter 90.07 Load position scaled int. Note that the load position is only updated after new position input data is received.	
	-2147483648 2147483647	Feed constant numerator.	-
90.64	Feed constant denominator	See parameter 90.63 Feed constant numerator.	1
	-2147483648 2147483647	Feed constant denominator.	-
90.65	Pos counter init value	Defines an initial position (or distance) for the position counter (as a decimal number) when parameter 90.66 Pos counter init value source is set to Pos counter init value.	0.000
		See also section <i>Position counter</i> (page 73). The translatory load position is shown by parameter 90.07 Load position scaled int. Note that the load position is only updated after new position input data is received.	
	-2147483.648 2147483.647	Initial value for position counter.	-
90.66	Pos counter init value source	Selects the source of the initial position value. When the source selected by 90.67 Pos counter init cmd source activates, the value selected in this parameter is assumed to be the position of the load (in decimal format).	Pos counter init value
	Zero	0.	0
	Pos counter init value	Parameter 90.65 Pos counter init value.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
90.67	Pos counter init cmd source	Selects a digital source (for example, a limit switch connected to a digital input) that initializes the position counter. When the digital source activates, the value selected by 90.66 Pos counter init value source is assumed to be the position of the load.  Note: Position counter initialization can be prevented by parameter 90.68 Disable pos counter initialization.	Not selected
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7

No.	Name/Value	Description	Def/ FbEq16
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit] Source selection (see Terms and abbreviations on page 118).		-
90.68	Disable pos counter initialization	Selects a source that prevents the initialization of the position counter.	Not selected
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
90.69	Reset pos counter init ready	Selects a source that enables a new initialization of the position counter, ie. resets bit 4 of 90.35 Pos counter status.	Not selected
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-

No.	Name/Value		Descri	otion	Def/ FbEq16
91 Encoder module settings		Configu	ration of encoder interface modules.		
91.01	FEN DI stat	tus	interface	s the status of the digital inputs of FEN-xx encoder e modules. ameter is read-only.	-
	Bit	Name		Information	
	0	DI1 /modu	le 1	DI1 of interface module 1 (see parameters 91.11 at	nd 91.12)
	1	DI2 /modu	le 1	DI2 of interface module 1 (see parameters 91.11 ar	
	23	Reserved		1 1	
	4	DI1 /modu	le 2	DI1 of interface module 2 (see parameters 91.13 a	nd 91.14)
	5	DI2 /modu	le 2	DI2 of interface module 2 (see parameters 91.13 a	nd <b>91.14</b> )
	615	Reserved			
	0000 0000k		Status v	vord of digital inputs on FEN-xx modules.	1 = 1
91.02	Module 1 st	tatus	location	s the type of the interface module found in the specified by parameter 91.12 Module 1 location. rameter is read-only.	-
	No option		No mod	ule detected in the specified slot.	0
	No commun	nication	A module has been detected but cannot be communicated with.		1
	Unknown		The mo	dule type is unknown.	2
	FEN-01		An FEN	-01 module has been detected and is active.	16
	FEN-11		An FEN-11 module has been detected and is active.		17
	FEN-21		An FEN	-21 module has been detected and is active.	18
	FEN-31		An FEN-31 module has been detected and is active.		21
	FSE-31		An FSE	-31 module has been detected and is active.	25
91.03	Module 2 status		location For the	s the type of the interface module found in the specified by parameter 91.14 Module 2 location. indications, see parameter 91.02 Module 1 status. rameter is read-only.	-
91.04	Module 1 temperature		input of parame Note: W	s the temperature measured through the sensor interface module 1. The unit is selected by ter 96.16 Unit selection.  Fith a PTC sensor, the unit is ohms. rameter is read-only.	-
	ohm  06 Module 2 Displays the temperature input of interface more parameter 96.16 Unit		Tempera	ature measured through interface module 1.	-
91.06			input of parame Note: W	s the temperature measured through the sensor interface module 2. The unit is selected by ter 96.16 Unit selection.  Tith a PTC sensor, the unit is ohms. rameter is read-only.	-
	01000 °C ohm	, °F or	Tempera	ature measured through interface module 2.	-

No.	Name/Value	Description	Def/ FbEq16
91.10	Encoder parameter refresh	Validates any changed encoder interface module parameters. This is needed for any parameter changes in groups 9093 to take effect.  After refreshing, the value reverts automatically to <i>Done</i> .  Note:  Permanent magnet motors only: The drive will perform a fresh autophasing routine (see page 82) at next start if the motor feedback encoder settings have been changed.  The parameter cannot be changed while the drive is running.	Done
	Done	Refreshing done.	0
	Refresh	Refreshing.	1
91.11	Module 1 type	Defines the type of the module used as interface module 1.	None
	None	None (communication disabled).	0
	FEN-01	FEN-01.	1
	FEN-11	FEN-11.	2
	FEN-21	FEN-21.	3
	FEN-31	FEN-31.	4
	FSE-31	FSE-31.	5
91.12	Module 1 location	Specifies the slot (13) on the control unit of the drive into which the interface module is installed. Alternatively, specifies the node ID of the slot on an FEA-03 extension adapter.	Slot 2
	Slot 1	Slot 1.	1
	Slot 2	Slot 2.	2
	Slot 3	Slot 3.	3
	4254	Node ID of the slot on the FEA-03 extension adapter.	1 = 1
91.13	Module 2 type	Defines the type of the module used as interface module 2.	None
	None	None (communication disabled).	0
	FEN-01	FEN-01.	1
	FEN-11	FEN-11.	2
	FEN-21	FEN-21.	3
	FEN-31	FEN-31.	4
	FSE-31	FSE-31.	5
91.14	Module 2 location	Specifies the slot (13) on the control unit of the drive into which the interface module is installed. Alternatively, specifies the node ID of the slot on an FEA-03 extension adapter.	Slot 3
	Slot 1	Slot 1.	1
	Slot 2	Slot 2.	2
	Slot 3	Slot 3.	3
	4254	Node ID of the slot on the FEA-03 extension adapter.	1 = 1

No.	Name/Value	Description	Def/ FbEq16
91.21	Module 1 temp sensor type	Specifies the type of temperature sensor connected to interface module 1. Note that the module must also be activated by parameters 91.1191.12.	None
	None	None.	0
	PTC	PTC. (The unit is ohms.)	1
	KTY-84	KTY84. (The unit is selected by parameter 96.16 <i>Unit selection</i> .)	2
91.22	Module 1 temp filter time	Defines a filtering time for the temperature measurement through interface module 1.	1500 ms
	010000 ms	Filtering time for temperature measurement.	-
91.24	Module 2 temp sensor type	Specifies the type of temperature sensor connected to interface module 2. Note that the module must also be activated by parameters 91.1391.14.	None
	None	None.	0
	PTC	PTC. (The unit is ohms.)	1
	KTY-84	KTY84. (The unit is selected by parameter 96.16 Unit selection.)	2
91.25	Module 2 temp filter time	Defines a filtering time for the temperature measurement through interface 2.	1500 ms
	010000 ms	Filtering time for temperature measurement.	-
91.31	Module 1 TTL output source	Selects the encoder input on interface module 1 whose signal is echoed by or emulated to the TTL output.  See also section <i>Encoder support</i> (page 71).	Not selected
	Not selected	TTL output not in use.	0
	Module input 1	Input 1 is echoed by or emulated to the TTL output.	1
	Module input 2	Input 2 is echoed by or emulated to the TTL output.	2
91.32	Module 1 emulation pulses/rev	Defines the number of TTL pulses per revolution for encoder emulation output of interface module 1.	0
	065535	Number of TTL pulses for emulation.	1 = 1
91.33	Module 1 emulated Z- pulse offset	With interface module 1, defines when zero pulses are emulated in relation to zero position received from the encoder.  For example, with a value of 0.50000, a zero pulse is emulated whenever the encoder position passes 0.5 revolutions. With a value of 0.00000, a zero pulse is emulated whenever the encoder position passes zero position.	0.00000
	0.00000 1.00000 rev	Position of emulated zero pulses.	32767 = 1 rev
91.41	Module 2 TTL output source	Selects the encoder input on interface module 2 whose signal is echoed by or emulated to the TTL output.  See also section <i>Encoder support</i> (page 71).	Not selected
	Not selected	TTL output not in use.	0
	Module input 1	Input 1 is echoed by or emulated to the TTL output.	1
	Module input 2	Input 2 is echoed by or emulated to the TTL output.	2

No.	Name/Value	Description	Def/ FbEq16
91.42	Module 2 emulation pulses/rev	Defines the number of TTL pulses per revolution for encoder emulation output of interface module 2.	0
	065535	Number of TTL pulses for emulation.	1 = 1
91.43	Module 2 emulated Z- pulse offset	With interface module 2, defines when zero pulses are emulated in relation to zero position received from the encoder.  For example, with a value of 0.50000, a zero pulse is emulated whenever the encoder position passes 0.5 revolutions. With a value of 0.00000, a zero pulse is emulated whenever the encoder position passes zero position.	0
	0.00000 1.00000 rev	Position of emulated zero pulses.	32767 = 1 rev
	coder 1 onfiguration	Settings for encoder 1.  Notes:  The contents of the parameter group vary according to the selected encoder type.  It is recommended that encoder connection 1 (this group) is used whenever possible since the data received through that interface is fresher than the data received through connection 2 (group 93 Encoder 2 configuration).	
92.01	Encoder 1 type	Selects the type of encoder/resolver 1.	None configured
	None configured	None.	0
	TTL	TTL. Module type (input): FEN-01 (X31), FEN-11 (X41) or FEN-21 (X51).	1
	TTL+	TTL+. Module type (input): FEN-01 (X32).	2
	Absolute encoder	Absolute encoder. Module type (input): FEN-11 (X42).	3
	Resolver	Resolver. Module type (input): FEN-21 (X52).	4
	HTL	HTL. Module type (input): FEN-31 (X82).	5
	HTL 1	HTL. Module type (input): FSE-31 (X31).	6
	HTL 2	HTL. Module type (input): FSE-31 (X32). Not supported at the time of publication.	7
92.02	Encoder 1 source	Selects the interface module that the encoder is connected to. (The physical locations and types of encoder interface modules are defined in parameter group 91 Encoder module settings.)	Module 1
	Module 1	Interface module 1.	0
	Module 2	Interface module 2.	1
92.10	Pulses/revolution	(Visible when TTL, TTL+ or HTL encoder is selected) Defines the pulse number per revolution.	2048

Number of pulses.

0...65535

No.	Name/Value	Description	Def/ FbEq16
92.10	Sine/cosine number	(Visible when an Absolute encoder is selected) Defines the number of sine/cosine wave cycles within one revolution.  Note: This parameter need not be set when an EnDat or SSI encoder is used in continuous mode. See parameter 92.30 Serial link mode.	0
	065535	Number of sine/cosine wave cycles within one revolution.	-
92.10	Excitation signal frequency	(Visible when a resolver is selected) Defines the frequency of the excitation signal.  Note: With an EnDat or HIPERFACE encoder and FEN-11 FPGA version VIE12200 or later, this parameter is automatically set upon validation of encoder settings (91.10 Encoder parameter refresh).	1 kHz
	120 kHz	Excitation signal frequency.	1 = 1 kHz
92.11	Pulse encoder type	(Visible when a TTL, TTL+ or HTL encoder is selected) Defines the rms amplitude of the excitation signal.	Quadrature
	Quadrature	Quadrature encoder (with two channels, A and B)	0
	Single track	Single-track encoder (with one channel, A).  Note: With this setting, the measured speed value is always positive regardless of direction of rotation.	1
92.11	Absolute position source	(Visible when absolute encoder is selected) Selects the source of the absolute position information.	None
	None	Not selected.	0
	Commut signals	Commutation signals.	1
	EnDat	Serial interface: EnDat encoder.	2
	Hiperface	Serial interface: HIPERFACE encoder.	3
	SSI	Serial interface: SSI encoder.	4
	Tamagawa	Serial interface: Tamagawa 17/33-bit encoder.	5
92.11	Excitation signal amplitude	(Visible when a resolver is selected) Defines the rms amplitude of the excitation signal.	4.0 V
	4.012.0 V	Excitation signal amplitude.	10 = 1 V
92.12	Speed calculation mode	(Visible when a TTL, TTL+ or HTL is selected) Selects the speed calculation mode.  *With a single-track encoder (parameter 92.11 Pulse encoder type is set to Single track), the speed is always positive.	Auto rising
	A&B all	Channels A and B: Rising and falling edges are used for speed calculation.  *Channel B: Defines the direction of rotation.  Note: With a single-track encoder (parameter 92.11 Pulse encoder type), this setting acts like setting A all.	0
	A all	Channel A: Rising and falling edges are used for speed calculation. *Channel B: Defines the direction of rotation.	1
	A rising	Channel A: Rising edges are used for speed calculation. *Channel B: Defines the direction of rotation.	2
	A falling	Channel A: Falling edges are used for speed calculation. *Channel B: Defines the direction of rotation.	3

No.	Name/Value	Description		Def/ FbEq16
	Auto rising	One of the above modes is selected depending on the pulse frequence		4
		Pulse frequency of the channel(s)	Used mode	
		< 2442 Hz	A&B all	
		24424884 Hz	A all	
		> 4884 Hz	A rising	
	Auto falling	One of the above modes is select depending on the pulse frequence		5
		Pulse frequency of the channel(s)	Used mode	
		< 2442 Hz	A&B all	
		24424884 Hz	A all	
		> 4884 Hz	A falling	
92.12	Zero pulse enable	(Visible when an absolute encode Enables the encoder zero pulse tinput (X42) of the FEN-11 interfar Note: No zero pulse exists with s parameter 92.11 Absolute position Hiperface, SSI or Tamagawa.	for the absolute encoder ce module. erial interfaces, ie. when	Disable
	Disable	Zero pulse disabled.		0
	Enable	Zero pulse enabled.		1
92.12	Resolver polepairs	(Visible when is resolver is select Defines the number of pole pairs	,	1
	132	Number of resolver pole pairs.		1 = 1
92.13	Position estimation enable	(Visible when TTL, TTL+ or HTL Selects whether position estimati to increase position data resolution	on is used with encoder 1	Enable
	Disable	Measured position used. (The re- revolution for quadrature encode revolution for single-track encode	rs, 2 × pulses per	0
	Enable	Estimated position used. (Uses pertrapolated at the time of data re		1
92.13	Position data width	(Visible when an absolute encode Defines the number of bits used one revolution. For example, a secorresponds to 32768 positions of The value is used when paramete source is set to EnDat, Hiperface 92.11 Absolute position source is parameter is internally set to 17.  Note: With an EnDat or HIPERFAFPGA version VIE12200 or later, automatically set upon validation (91.10 Encoder parameter refress	to indicate position within etting of 15 bits oer revolution. er 92.11 Absolute position e or SSI. When parameter is set to Tamagawa, this  ACE encoder and FEN-11 this parameter is of encoder settings	0
_	032	Number of bits used in position in revolution.	ndication within one	1 = 1

No.	Name/Value	Description	Def/ FbEq16
92.14	Speed estimation enable	(Visible when TTL, TTL+ or HTL is selected) Selects whether calculated or estimated speed is used. Estimation increases the speed ripple in steady state operation, but improves the dynamics.  Note: This parameter is not effective with FEN-xx modules with FPGA version VIEx 2000 or later.	Disable
	Disable	Last calculated speed used. (The calculation interval is 62.5 microseconds to 4 milliseconds.)	0
	Enable	Estimated speed (estimated at the time of data request) is used.	1
92.14	Revolution data width	(Visible when an absolute encoder is selected) Defines the number of bits used in revolution counting with a multiturn encoder. For example, a setting of 12 bits would support counting up to 4096 revolutions. The value is used when parameter 92.11 Absolute position source is set to EnDat, Hiperface or SSI. When parameter 92.11 Absolute position source is set to Tamagawa, setting this parameter to a non-zero value activates multiturn data requesting.  Note: With an EnDat or HIPERFACE encoder and FEN-11 FPGA version VIE12200 or later, this parameter is automatically set upon validation of encoder settings (91.10 Encoder parameter refresh).	0
	032	Number of bits used in revolution count.	1 = 1
92.15	Transient filter	(Visible when a TTL, TTL+ or HTL is selected) Activates transient filtering for the encoder (changes in direction of rotation are ignored above the selected pulse frequency).	4880 Hz
	4880 Hz	Change in direction of rotation allowed below 4880 Hz.	0
	2440 Hz	Change in direction of rotation allowed below 2440 Hz.	1
	1220 Hz	Change in direction of rotation allowed below 1220 Hz.	2
	Disabled	Change in direction of rotation allowed at any pulse frequency.	3
92.17	Accepted pulse freq of encoder 1	(Visible when parameter 92.01 Encoder 1 type = HTL 1 or HTL 2) Defines the maximum pulse frequency of encoder 1.	0 kHz
	0300 kHz	Pulse frequency.	1 = 1 kHz
92.21	Encoder cable fault mode	(Visible when a TTL, TTL+ or HTL is selected) Selects which encoder cable channels and wires are monitored for wiring faults.	А, В
	A, B	A and B.	0
	A, B, Z	A, B and Z.	1
	A+, A-, B+, B-	A+, A-, B+ and B	2
	A+, A-, B+, B-, Z+, Z-	A+, A-, B+, B-, Z+ and Z	3

No.	Name/Value	Description	Def/ FbEq16
92.23	Maximum pulse waiting time	(Visible when parameter 92.01 Encoder 1 type = TTL or HTL)  Determines a pulse waiting time used in speed calculation for the encoder interface. If no pulse edges are detected within this time, the measured speed is zeroed by the interface.  Increasing the setting can improve measuring performance especially at low, near zero speeds.  Notes:  The parameter is only supported by FEN-xx modules with FPGA version VIEx 2000 or later. On older modules, the pulse waiting time is fixed to 4 ms.  The parameter only affects speed measurement. Position is updated whenever a new pulse edge is detected. When the measured speed from the interface is zero, the drive updates its speed data based on position changes.	4 ms
	1200 ms	Maximum pulse waiting time.	1 = 1 ms
92.24	Pulse edge filtering	(Visible when parameter 92.01 Encoder 1 type = HTL) Enables pulse edge filtering. Pulse edge filtering can improve the reliability of measurements especially from encoders with a single-ended connection.  Notes:  Pulse edge filtering is only supported by FEN-31 modules with FPGA version VIE3 2200 or later.  Pulse edge filtering decreases the maximum pulse frequency. With 2 µs filtering time, the maximum pulse frequency is 200 kHz.	No filtering
	No filtering	Filtering disabled.	0
	1 µs	Filtering time: 1 microsecond.	1
	2 µs	Filtering time: 2 microseconds.	2
92.25	Pulse overfrequency function	(Visible when parameter 92.01 Encoder 1 type = HTL) Selects how the drive reacts when the encoder interface detects a pulse overfrequency condition. Note: This parameter is effective only with FEN-xx module FPGA version VIEx 2200 or later.	Fault
	Warning	The drive generates a warning, 7381 Encoder 1. The FEN-xx module will continue to update speed and position data.	0
	Fault	The drive trips on fault A7E1 Encoder.	1
92.30	Serial link mode	(Visible when an absolute encoder is selected) Selects the serial link mode with an EnDat or SSI encoder.	Initial position
	Initial position	Single position transfer mode (initial position).	0
	Continuous	Continuous position data transfer mode.	1
	Continuous speed and position	Continuous speed and position data transfer mode. This setting is intended for EnDat 2.2 encoders without sin/cos signals.  Note: This setting requires an FEN-11 interface revision H or later.	2

No.	Name/Value	Description	Def/ FbEq16
92.31	EnDat max calculation time	(Visible when an absolute encoder is selected) Selects the maximum encoder calculation time for an EnDat encoder. Note: This parameter needs to be set only when an EnDat encoder is used in continuous mode, ie. without incremental sin/cos signals (supported only as encoder 1). See also parameter 92.30 Serial link mode.	50 ms
	10 us	10 microseconds.	0
	100 us	100 microseconds.	1
	1 ms	1 millisecond.	2
	50 ms	50 milliseconds.	3
92.32	SSI cycle time	(Visible when an absolute encoder is selected) Selects the transmission cycle for an SSI encoder. Note: This parameter needs to be set only when an SSI encoder is used in continuous mode, ie. without incremental sin/cos signals (supported only as encoder 1). See also parameter 92.30 Serial link mode.	100 us
	50 us	50 microseconds.	0
	100 us	100 microseconds.	1
	200 us	200 microseconds.	2
	500 us	500 microseconds.	3
	1 ms	1 millisecond.	4
	2 ms	2 milliseconds.	5
92.33	SSI clock cycles	(Visible when an absolute encoder is selected)  Defines the length of an SSI message. The length is defined as the number of clock cycles. The number of cycles can be calculated by adding 1 to the number of bits in an SSI message frame.	2
	2127	SSI message length.	-
92.34	SSI position msb	(Visible when an absolute encoder is selected) With an SSI encoder, defines the location of the MSB (most significant bit) of the position data within an SSI message.	1
	1126	Position data MSB location (bit number).	-
92.35	SSI revolution msb	(Visible when an absolute encoder is selected) With an SSI encoder, defines the location of the MSB (most significant bit) of the revolution count within an SSI message.	1
	1126	Revolution count MSB location (bit number).	-
92.36	SSI data format	(Visible when an absolute encoder is selected) Selects the data format for an SSI encoder.	Binary
	Binary	Binary code.	0
	Gray	Gray code.	1
92.37	SSI baud rate	(Visible when an absolute encoder is selected) Selects the baud rate for an SSI encoder.	100 kBit/s
	10 kBit/s	10 kbit/s.	0
	50 kBit/s	50 kbit/s.	1

No.	Name/Value	Description	Def/ FbEq16
	100 kBit/s	100 kbit/s.	2
	200 kBit/s	200 kbit/s.	3
	500 kBit/s	500 kbit/s.	4
	1000 kBit/s	1000 kbit/s.	5
92.40	SSI zero phase	(Visible when an absolute encoder is selected) Defines the phase angle within one sine/cosine signal period that corresponds to the value of zero on the SSI serial link data. The parameter is used to adjust the synchronization of the SSI position data and the position based on sine/cosine incremental signals. Incorrect synchronization may cause an error of ±1 incremental period.  Note: This parameter needs to be set only when an SSI encoder is used in initial position mode (see parameter 92.30 Serial link mode).	315-45 deg
	315-45 deg	315-45 degrees.	0
	45-135 deg	45-135 degrees.	1
	135-225 deg	135-225 degrees.	2
	225-315 deg	225-315 degrees.	3
92.45	Hiperface parity	(Visible when an absolute encoder is selected) Defines the use of parity and stop bits with a HIPERFACE encoder. Typically this parameter need not be set.	Odd
	Odd	Odd parity indication bit, one stop bit.	0
	Even	Even parity indication bit, one stop bit.	1
92.46	Hiperface baud rate	(Visible when an absolute encoder is selected) Defines the transfer rate of the link with a HIPERFACE encoder. Typically this parameter need not be set.	4800 bits/s
	4800 bits/s	4800 bit/s.	0
	9600 bits/s	9600 bit/s.	1
	19200 bits/s	19200 bit/s.	2
	38400 bits/s	38400 bit/s.	3
92.47	Hiperface node address	(Visible when an absolute encoder is selected) Defines the node address for a HIPERFACE encoder. Typically this parameter need not be set.	64
	0255	HIPERFACE encoder node address.	-

No.	Name/Value	Description	Def/ FbEq16
	coder 2 nfiguration	Settings for encoder 2.  Note:  The contents of the parameter group vary according to the selected encoder type.  It is recommended that encoder connection 1 (group 92 Encoder 1 configuration) is used whenever possible since the data received through that interface is fresher than the data received through connection 2 (this group).	
93.01	Encoder 2 type	Selects the type of encoder/resolver 2.	None configured
	None configured	None.	0
	TTL	TTL. Module type (input): FEN-01 (X31), FEN-11 (X41) or FEN-21 (X51).	1
	TTL+	TTL+. Module type (input): FEN-01 (X32).	2
	Abs enc	Absolute encoder. Module type (input): FEN-11 (X42).	3
	Resolver	Resolver. Module type (input): FEN-21 (X52).	4
	HTL	HTL. Module type (input): FEN-31 (X82).	5
	HTL 1	HTL. Module type (input): FSE-31 (X31).	6
	HTL 2	HTL. Module type (input): FSE-31 (X32). Not supported at the time of publication.	7
93.02	Encoder 2 source	Selects the interface module that the encoder is connected to. (The physical locations and types of encoder interface modules are defined in parameter group 91 Encoder module settings.)	Module 1
	Module 1	Interface module 1.	1
	Module 2	Interface module 2.	2
93.10	Pulses/revolution	(Visible when TTL, TTL+ or HTL encoder is selected) See parameter 92.10 Pulses/revolution.	2048
93.10	Sine/cosine number	(Visible when an absolute encoder is selected) See parameter 92.10 Sine/cosine number.	0
93.10	Excitation signal frequency	(Visible when a resolver is selected) See parameter 92.10 Excitation signal frequency.	1 kHz
93.11	Pulse encoder type	(Visible when TTL, TTL+ or HTL encoder is selected) See parameter 92.11 Pulse encoder type.	Quadrature
93.11	Absolute position source	(Visible when an absolute encoder is selected) See parameter 92.11 Absolute position source.	None
93.11	Excitation signal amplitude	(Visible when a resolver is selected) See parameter 92.11 Excitation signal amplitude.	4.0 V
93.12	Speed calculation mode	(Visible when TTL, TTL+ or HTL encoder is selected) See parameter 92.12 Speed calculation mode.	Auto rising
93.12	Zero pulse enable	(Visible when an absolute encoder is selected) See parameter 92.12 Zero pulse enable.	Disable
93.12	Resolver polepairs	(Visible when a resolver is selected) See parameter 92.12 Resolver polepairs.	1
93.13	Position estimation enable	(Visible when TTL, TTL+ or HTL encoder is selected) See parameter 92.13 Position estimation enable.	Enable

No.	Name/Value	Description	Def/ FbEq16
93.13	Position data width	(Visible when an absolute encoder is selected) See parameter 92.13 Position data width.	0
93.14	Speed estimation enable	(Visible when TTL, TTL+ or HTL encoder is selected) See parameter 92.14 Speed estimation enable.	Disable
93.14	Revolution data width	(Visible when an absolute encoder is selected) See parameter 92.14 Revolution data width.	0
93.15	Transient filter	(Visible when TTL, TTL+ or HTL encoder is selected) See parameter 92.15 Transient filter.	4880 Hz
93.17	Accepted pulse freq of encoder 2	(Visible when parameter 93.01 Encoder 2 type = HTL 1 or HTL 2) See parameter 92.17 Accepted pulse freq of encoder 1.	0 kHz
93.21	Encoder cable fault mode	((Visible when TTL, TTL+ or HTL encoder is selected) See parameter 92.21 Encoder cable fault mode.	А, В
93.23	Maximum pulse waiting time	(Visible when parameter 93.01 Encoder 2 type = TTL or HTL) See parameter 92.23 Maximum pulse waiting time.	4 ms
93.24	Pulse edge filtering	(Visible when parameter 93.01 Encoder 2 type = HTL) See parameter 92.24 Pulse edge filtering.	No filtering
93.25	Pulse overfrequency function	(Visible when parameter 93.01 Encoder 2 type = HTL) See parameter 92.25 Pulse overfrequency function.	Fault
93.30	Serial link mode	(Visible when an absolute encoder is selected) See parameter 92.30 Serial link mode.	Initial position
93.31	EnDat calc time	(Visible when an absolute encoder is selected) See parameter 92.31 EnDat max calculation time.	50 ms
93.32	SSI cycle time	(Visible when an absolute encoder is selected) See parameter 92.32 SSI cycle time.	100 us
93.33	SSI clock cycles	(Visible when an absolute encoder is selected) See parameter 92.33 SSI clock cycles.	2
93.34	SSI position msb	(Visible when an absolute encoder is selected) See parameter 92.34 SSI position msb.	1
93.35	SSI revolution msb	(Visible when an absolute encoder is selected) See parameter 92.35 SSI revolution msb.	1
93.36	SSI data format	(Visible when an absolute encoder is selected) See parameter 92.36 SSI data format.	Binary
93.37	SSI baud rate	(Visible when an absolute encoder is selected) See parameter 92.37 SSI baud rate.	100 kBit/s
93.40	SSI zero phase	(Visible when an absolute encoder is selected) See parameter 92.40 SSI zero phase.	315-45 deg
93.45	Hiperface parity	(Visible when an absolute encoder is selected) See parameter 92.45 Hiperface parity.	Odd
93.46	Hiperface baud rate	(Visible when an absolute encoder is selected) See parameter 92.46 Hiperface baud rate.	4800 bits/s
93.47	Hiperface node address	(Visible when an absolute encoder is selected) See parameter 92.47 Hiperface node address.	64

No.	Name/Value	Description	Def/ FbEq16
94 LS	U control	Control of the supply unit of the drive, such as DC voltage and reactive power reference.  See section Control of a supply unit (LSU) (page 61).  Note that the references defined here must also be selected as the reference source in the supply control program to be effective.  This group is only visible when supply unit control has been activated by parameter 95.20 HW options word 1.  See also section Control of a supply unit (LSU) (page 61).	
94.01	LSU control	Enables/disables the internal INU-LSU state machine. When the state machine is enabled, the inverter unit (INU) controls the supply unit (LSU) and prevents the inverter unit from starting until the supply unit is ready. When the state machine is disabled, the status of the supply unit (LSU) is ignored by the inverter unit.	On
	Off	INU-LSU state machine disabled.	0
	On	INU-LSU state machine enabled.	1
94.02	LSU panel communication	Enables/disables control panel and PC tool access to the supply unit (line-side converter) via the inverter unit (motor-side converter).  Note: This feature is only supported by the following drives:  ACS880-11  ACS880-31  ACS880-37 based on an integrated drive module  ACS880-37 based on an integrated drive module.	Disable
	Disable	Control panel and PC tool access to supply unit via inverter unit disabled.	0
	Enable	Control panel and PC tool access to supply unit via inverter unit enabled.	1
94.04	INU-LSU status word profile	(Only visible with certain drive types.) Selects the functionality of bit 1 of 06.11 Main status word	ABB single drives standard SW
	ABB single drives standard SW	The drive sets bit 1 of 06.11 Main status word after the DC link is charged.	0
	Backwards compatible SW	The drive sets bit 1 of 06.11 Main status word after the main contactor is closed and the supply unit (line-side converter) is running.  This setting can be used eg. when installing the drive into an existing set-up with other ACS880 as well as ACS800 drives.	1
94.10	LSU max charging time	Defines the maximum time the supply unit (LSU) is allowed for charging before a fault (7584 LSU charge failed) is generated.	15 s
	065535 s	Maximum charging time.	1 = 1 s
94.11	LSU stop delay	Defines a stop delay for the supply unit. This parameter can be used to delay the opening of the main breaker/contactor when a restart is expected.	600.0 s
	0.0 3600.0 s	Supply unit stop delay.	10 = 1 s

No.	Name/Value	Description	Def/ FbEq16
94.20	DC voltage reference	(Only visible when IGBT supply unit control activated by 95.20) Displays the DC voltage reference sent to the supply unit. This parameter is read-only.	0.0 V
	0.0 2000.0 V	DC voltage reference sent to supply unit.	10 = 1 V
94.21	DC voltage ref source	(Only visible when IGBT supply unit control activated by 95.20) Selects the source of the DC voltage reference to be sent to the supply unit.	User ref
	Zero	None.	0
	User ref	94.22 User DC voltage reference.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
94.22	User DC voltage reference	(Only visible when IGBT supply unit control activated by 95.20) Defines the DC voltage reference for the supply unit when 94.21 DC voltage ref source is set to User ref.	0.0 V
	0.0 2000.0 V	User DC reference.	10 = 1 V
94.30	Reactive power reference	(Only visible when IGBT supply unit control activated by 95.20) Displays the reactive power reference sent to the supply unit. This parameter is read-only.	0.0 kvar
	-3276.8 3276.7 kvar	Reactive power reference sent to the supply unit.	10 = 1 kvar
94.31	Reactive power ref source	(Only visible when IGBT supply unit control activated by 95.20) Selects the source of the reactive power reference to be sent to the supply unit.	User ref
	Zero	None.	0
	User ref	94.32 User reactive power reference.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
94.32	User reactive power reference	(Only visible when IGBT supply unit control activated by 95.20) Defines the reactive power reference for the supply unit when 94.31 Reactive power ref source is set to User ref.	0.0 kvar
	-3276.8 3276.7 kvar	User reactive power reference.	10 = 1 kvar
94.40	Power mot limit on net loss	Defines the maximum shaft power for motoring mode upon a supply network failure when IGBT supply unit control is active (bit 15 of 95.20 HW options word 1 is on). The value is given in percent of nominal motor power.  Note: With a diode supply unit (bit 11 of 95.20 is on), the motoring shaft power is limited to 20% upon a network failure regardless of this parameter.	600.00%
	0.00 600.00%	Maximum shaft power for motoring mode upon a supply network failure.	1 = 1%

No.	Name/Value	Description	Def/ FbEq16
94.41	Power gen limit on net loss	Defines the maximum shaft power for generating upon a supply network failure when supply unit control is active (bit 11 or 15 of 95.20 HW options word 1 is on).  The value is given in percent of nominal motor power.	-600.00%
	-600.00 0.00%	Maximum shaft power for generating mode upon a supply network failure.	1 = 1%

95 HW configuration		Various hardware-related settings.	
95.01	Supply voltage	Selects the supply voltage range. This parameter is used by the drive to determine the nominal voltage of the supply network. The parameter also affects the current ratings and the DC voltage control functions (trip and brake chopper activation limits) of the drive.  MARNING! An incorrect setting may cause the motor to rush uncontrollably, or the brake chopper or resistor to overload.  Note:  The selections shown depend on the hardware of the drive. If only one voltage range is valid for the drive in question, it is selected by default.  This parameter cannot be changed while the drive is running.	Not given
	Not given	No voltage range selected. The drive will not start modulating before a range is selected.	0
	208240 V	208240 V	1
	380415 V	380415 V	2
	440480 V	440480 V	3
	500 V	500 V	4
	525600 V	525600 V	5
	660690 V	660690 V	6
95.02	Adaptive voltage limits	Enables adaptive voltage limits.  Adaptive voltage limits can be used if, for example, an IGBT supply unit is used to raise the DC voltage level. If the communication between the inverter and the IGBT supply unit is active (95.20 HW options word 1), the voltage limits are related to the DC voltage reference transmitted to the supply unit assuming that the reference is high enough. Otherwise, the limits are calculated based on the measured DC voltage at the end of the pre-charging sequence.  This function is also useful if the AC supply voltage to the drive is high, as the warning levels are raised accordingly.	Disable, Enable (95.20 b15)
	Disable	Adaptive voltage limits disabled.	0
	Enable	Adaptive voltage limits enabled.	1

No.	Name/Value	Description	Def/ FbEq16
95.04	Control board supply	Specifies how the control unit of the drive is powered. The default value depends on the type of the control unit and the setting of parameter 95.20.	Internal 24V (ZCU); External 24V (BCU; 95.20 b4)
	Internal 24V	The drive control unit is powered from the drive power unit it is connected to.  Note: If reduced run (see page 107) is required, select External 24V or Redundant external 24V instead.	0
	External 24V	The drive control unit is powered from an external power supply. The drive power unit and power unit link faults are masked when the drive is in stopped state, so the main circuit can be powered down without faults while the control unit is powered.	1
	Redundant external 24V	(Type BCU control units only) The drive control unit is powered from two redundant external power supplies. The loss of one of the supplies generates a warning (AFEC External power signal missing). The drive power unit and power unit link faults are masked when the drive is in stopped state, so the main circuit can be powered down without faults while the control unit is powered.	2

No. Name/Value	Description	Def/ FbEq16
95.08 DC switch monitoring	(Only visible with a ZCU control unit) Enables/disables DC switch monitoring via the DIIL input. This setting is intended for use with inverter modules with an internal charging circuit that are connected to the DC bus through a DC switch.  An auxiliary contact of the DC switch must be wired to the DIIL input so that the input switches off when the DC switch is opened.  DC bus  DC switch is opened with the inverter running, the inverter is given a coast-to-stop command, and its charging circuit activated.  Starting the inverter is prevented until the DC switch is closed and the DC circuit in the inverter unit recharged. Notes:  By default, DIIL is the input for the Run enable signal. Adjust 20.12 Run enable 1 source if necessary.  An internal charging circuit is standard on some inverter module types but optional on others; check with your local ABB representative.	Disable; Enable (95.20 b5)
Disable	DC switch monitoring through the DIIL input disabled.	0
Enable	DC switch monitoring through the DIIL input enabled.	1
95.09 Switch fuse controller	Activates communication to a xSFC charging controller. This setting is intended for use with inverter modules that are connected to a DC bus through a DC switch/charging circuit controlled by a charging controller. On units without a DC switch, this parameter should be set to <i>Disable</i> . The charging controller monitors the charging of the inverter unit, and sends an enable command when the charging has finished. (ie. DC switch is closed after the 'charging OK' lamp lights, and charging switch opened). For more information, see xSFC documentation.	Enable
Disable	Communication with xSFC disabled.	0
Enable	Communication with xSFC enabled.	1

Specifies the number of inverter modules available. This parameter must be set if reduced run is required. A value other than 0 activates the reduced run function. If the control program cannot detect the number of modules specified by this parameter, a fault (5695 Reduced run) is generated.  See section Reduced run function (page 107). 0 = Reduced run disabled 112 = Number of modules available Note: This parameter cannot be changed while the drive is running.  065535  Number of inverter modules available -	No.	Name/Value	Description	Def/ FbEq16
95.14 Connected modules (Only visible with a BCU control unit) Shows which of the parallel-connected inverter modules	95.13	Reduced run mode	Specifies the number of inverter modules available. This parameter must be set if reduced run is required. A value other than 0 activates the reduced run function. If the control program cannot detect the number of modules specified by this parameter, a fault (5695 Reduced run) is generated.  See section Reduced run function (page 107). 0 = Reduced run disabled 112 = Number of modules available Note: This parameter cannot be changed while the drive is	0
Shows which of the parallel-connected inverter modules		065535	Number of inverter modules available	-
	95.14	Connected modules	Shows which of the parallel-connected inverter modules	-

Bit	Name	Description		
0	Module 1 1 = Module 1 has been detected.			
1	Module 2	1 = Module 2 has been detected.		
11	Module 12	1 = Module 12 has been detected.		
1215	Reserved			

0000hFFFFh	Inverter modules connected.	1 = 1
95.15 Special HW settings	Contains hardware-related settings that can be enabled and disabled by toggling the specific bits.  Note:  The installation of the hardware specified by this parameter may require derating of drive output, or impose other limitations. Refer to the hardware manual of the drive.  This parameter cannot be changed while the drive is running.	

Bit	Name	Information
0	EX motor	1 = The driven motor is an Ex motor provided by ABB for potentially explosive atmospheres. This sets the required minimum switching frequency for ABB Ex motors. <b>Note:</b> For non-ABB Ex motors, contact your local ABB representative.
1	ABB sine filter	1 = An ABB sine filter is connected to the output of the drive/inverter.
2	High speed mode	1 = Minimum switching frequency limit adaptation to output frequency active. This setting improves control performance at high output frequencies (typically above 120 Hz).
3	Custom sine filter	1 = A custom sine filter is connected to the output of the drive/inverter. See also parameters 97.01, 97.02, 99.18, 99.19.
415	Reserved	

0000b0111b	Hardware options configuration word.	1 = 1

No.	Name/V	/alue	Descrip	tion	Def/ FbEq16	
95.16 Router mode			Enables/ When rou to anothe channel of modules) See secti	(Only visible with a BCU control unit) Enables/disables router mode of the BCU control unit. When router mode is active, the PSL2 channels connected to another BCU (ie. those selected by 95.17 Router channel config) are routed to the power units (inverter modules) connected to this BCU.  See section Router mode for BCU control unit (page 109). Note: This parameter cannot be changed while the drive is running.		
	Off		Router m	node inactive.	0	
	On		Router m	node active.	1	
	Other [b	it]	Source s 118).	election (see <i>Terms and abbreviations</i> on page	-	
95.17	Se co un No		Selects v connecte unit. Notes: The lo chann conne from the to the There there: This p runnin	Notes:  The local power units are to be connected to successive channels starting from CH1. The other BCU is then connected to one or more successive channels starting from the first free channel.		
	Bit	Name		Description		
	0	ch1		0		
	1	ch2		1 = Channel CH2 is routed to the local power unit (which is connected to CH1).		
	11	ch12	1 = Channel CH12 is routed to a local power unit.			
	1215	Reserved				
	0000h	FFFFh	Selection	of routed BCU channels.	1 = 1	

No.	Name/Value	Description	Def/ FbEq16
95.20	HW options word 1	Specifies hardware-related options that require differentiated parameter defaults. Activating a bit in this parameter makes the necessary changes in other parameters – for example, activating an emergency stop option reserves a digital input. In most cases, the differentiated parameters will also be write-protected. This parameter, as well as the changes in other parameters implemented by it, are not affected by a parameter restore.  WARNING! After switching any bits in this word, recheck the values of the affected parameters.  Note: This parameter cannot be changed while the drive is running.	-

Bit	Name Information				
0	Supply frequency 60 Hz	0 = 50 Hz; 1 = 60 Hz. Affects parameters 11.45, 11.59, 12.20, 13.18, 30.11, 30.12, 30.13, 30.14, 31.26, 31.27, 46.01, 46.02.			
1	Emergency stop Cat 0	1 = Emergency stop, Category 0, without FSO module. Affects 21.04, 21.05, 23.11.			
2	Emergency stop Cat 1	1 = Emergency stop, Category 1, without FSO module. Affects 10.24, 21.04, 21.05, 23.11.			
3	RO2 for -07 cabinet cooling fan	1 = Control of cabinet cooling fan (used only with specific ACS880-07 hardware). Affects 10.27, 10.28, 10.29.			
4	Externally powered control unit	1 = Control unit powered externally. Affects 95.04. (Only visible with a ZCU control unit)			
5	DC supply switch	1 = DC switch monitoring active. Affects 20.12, 31.03, 95.08. (Only visible with a ZCU control unit)			
6	DOL motor switch	1 = Motor fan control active. Affects 10.24, 35.100, 35.103, 35.104.			
7	xSFC-01 fuse switch controller	1 = xSFC charging controller used. Affects 95.09. (Only visible with a BCU control unit)			
8	Service switch or PTC/Pt100 relay	1 = Service switch or PTC/Pt100 relay connected. Affects 31.01, 31.02.			
9	Output contactor	1 = Output contactor present. Affects 10.24, 20.12.			
10	Brake resistor, sine filter, IP54 fan	1 = Status (eg. thermal) switches connected to DIIL input. Affects 20.11, 20.12.			
11	INU-DSU communication	*1 = Diode supply unit control by inverter unit active. Makes several parameters visible in group <i>06</i> .			
12	Reserved				
13	du/dt filter activation	1 = Active: An external du/dt filter is connected to the drive output. The setting will limit the output switching frequency. With inverter module frame sizes R5i to R7i, the fan of the module will be forced to full speed.  Note: This bit is to be left at 0 if the drive/inverter module is equipped with internal du/dt filtering (for example, frame R8i inverter modules with option +E205).			
14	DOL fan activation	1 = The inverter unit consists of frame R8i modules with direct-on- line cooling fans (option +C188). Disables fan feedback monitoring and changes fan control to ON/OFF type.			
15	INU-ISU communication	*1 = IGBT supply unit control by inverter unit active. Affects 31.23 and 95.02. Makes several parameters visible in groups 01, 05, 06, 07, 30, 31, and 96.			

<sup>\*</sup>See section Control of a supply unit (LSU) (page 61).

No.	Name/	Value	Description		
	0000h	.FFFFh	Hardware options configuration word 1.	1 = 1	
95.21	diffe HW		Specifies more hardware-related options that require differentiated parameter defaults. See parameter 95.20 HW options word 1.  WARNING! After switching any bits in this word, recheck the values of the affected parameters.  Note: This parameter cannot be changed while the drive is running.	-	
	Bit	Name	Information		
	0	Dual use	1 = Dual use active. For drives with option +N8200. (a output frequencies and frequency reference limits.)	Allows higher	
	1	SynRM	1 = Synchronous reluctance motor used. Affects para 25.03, 25.15, 99.03, and 99.13.	meters 25.02,	
	2	Salient PM	1 = Salient-pole permanent magnet motor used. Affect 25.02, 25.03, 25.15, 99.03, and 99.13.	cts parameters	
	3	LV Synchro	1 = Externally-excited synchronous motor used. Requires a licens Contact your local ABB representative for more information.		
	415 Reserved				
	0000b0111b Ha		Hardware options configuration word 2.	1 = 1	
95.30	Parallel	type list filter	(Only visible with a BCU control unit) Filters the list of drive/inverter types listed by parameter 95.31 Parallel type configuration.	No filter	
	No filter		All types listed.	1	
	-3 (380-415V)		-3 (380415 V) types listed.	2	
	-5 (380-500V)		-5 (380500 V) types listed.	3	
	-7 (525-690V)		-7 (525690 V) types listed.	4	
	-7 LC (525-690V)		Liquid-cooled -7 (525690 V) types listed.	5	
95.31	configuration Defir conn If the value Note		(Only visible with a BCU control unit) Defines the drive/inverter type if it consists of parallel- connected modules. If the drive/inverter consists of a single module, leave the  value at Not selected. Note: This parameter cannot be changed while the drive is  running.	Not selected	
	Not sele	ected	The drive/inverter does not consist of parallel-connected modules, or type not selected.	0	
			Drive/inverter type consisting of parallel-connected modules.	-	

Def/ FbEq16

			LDEdio
95.35	Adjustable supply voltage	Enables manual setting for the supply voltage limits with parameters 95.36 Supply voltage low and 95.37 Supply voltage high.  Note: Enabling Adjustable supply voltage limits overrides limits based on 95.01 Supply voltage or 95.02 Adaptive voltage limits. This affects other soft limits in the drive associated with the supply voltage.  WARNING! An incorrect setting may cause the motor to rush uncontrollably, or the brake chopper or resistor to overload.	Disable
	Disable	Adjustable supply voltage is disabled.	0
	Enable	Adjustable supply voltage is enabled.	1
95.36	Supply voltage low	Defines the low limit for the supply voltage allowed for normal operation.  This parameter is active only when 95.35 Adjustable supply voltage is enabled.  Note: This is an expert level parameter and should not be adjusted without appropriate skills.  WARNING! An incorrect setting may cause the motor to rush uncontrollably, or the brake chopper or resistor to overload.	0.0
	0.01000.0 V	Supply voltage low.	
95.37	Supply voltage high	Defines the high limit for the supply voltage allowed for normal operation.  This parameter is active only when 95.35 Adjustable supply voltage is enabled.  Note: This is an expert level parameter and should not be adjusted without appropriate skills.  WARNING! An incorrect setting may cause the motor to rush uncontrollably, or the brake chopper or resistor to overload.	0.0
	0.01000.0 V	Supply voltage high.	
95.40	Transformation ratio	Defines the ratio of the step-up transformer.	0.000
	0.000100.000	Step-up transformer ratio.	1000 = 1
96 Sys	stem	Language selection; access levels; macro selection; parameter save and restore; control unit reboot; ; unit selection; data logger triggering; parameter checksum calculation; user lock.	
96.01	Language	Selects the language of the parameter interface and other displayed information when viewed on the control panel.  Note:  Not all languages listed below are necessarily supported.  This parameter does not affect the languages visible in the Drive composer PC tool. (Those are specified under View – Settings.)	-
	Not selected	None.	0
	English	English.	1033
		German.	1031
	Deutsch	German.	1001

No.

Name/Value

Description

No.	Name/Value	Description	Def/ FbEq16	
	Español	Spanish.	3082	
	Portugues	Portuguese.	2070	
	Nederlands	Dutch.	1043	
	Français	French.	1036	
	Dansk	Danish.	1030	
	Suomi	Finnish.	1035	
	Svenska	Swedish.	1053	
	Russki	Russian.	1049	
	Polski	Polish.	1045	
	Czech	Czech.	1029	
	Chinese (Simplified, PRC)	Simplified Chinese.	2052	
	Türkçe	Turkish.	1055	
	Japanese	Japanese	1041	
96.02	Pass code	Pass codes can be entered into this parameter to activate further access levels (see parameter 96.03 Access levels active) or to configure the user lock.  Entering "358" toggles the parameter lock, which prevents the changing of all other parameters through the control panel or the Drive composer PC tool.  Entering the user pass code (by default, "10000000") enables parameters 96.10096.102, which can be used to define a new user pass code and to select the actions that are to be prevented.  Entering an invalid pass code will close the user lock if open, ie. hide parameters 96.10096.102. After entering the code, check that the parameters are in fact hidden. If they are not, enter another (random) pass code.  Entering several invalid pass codes introduces a delay before a new attempt can be made. Entering further invalid codes will progressively lengthen the delay.  Note: You must change the default user pass code to maintain a high level of cybersecurity. Store the code in a safe place – the protection cannot be disabled even by ABB if the code is lost.  See also section User lock (page 106).	0	
	099999999	Pass code.	-	

No.	Name/Value	Descrip	Description				
96.03	Access levels active	els active  Shows which access levels have been activated by pass codes entered into parameter 96.02 Pass code.  This parameter is read-only.					
			Bit	Name			
			0	End user			
			1	Service			
			2	Advanced programmer			
			310	Reserved			
			11	OEM access level 1			
			12	OEM access level 2			
			13	OEM access level 3			
			14	Parameter lock			
			15	Reserved			
	0000hFFFFh	Active ac	cess lev	rels.	-		
96.04	Macro select	ACS880 (3AUA00 After a se automati	Selects the application macro. For more information, see ACS880 primary control program firmware manual (3AUA0000085967[English]).  After a selection is made, the parameter reverts automatically to Done.  Note: This parameter cannot be changed while the drive is running.				
	Done	Macro se	Macro selection complete; normal operation.				
	Factory	Factory r	nacro		1		
	Hand/Auto	Hand/Au	to macro	)	2		
	Sequence control	Sequenti	al contro	ol macro	5		
	FIELDBUS	Reserve	d.		6		
96.05	Macro active	more info	Shows which application macro is currently selected. For more information, see ACS880 primary control program firmware manual (3AUA0000085967[English]).  To change the macro, use parameter 96.04 Macro select.				
	Factory	Factory r	1				
	Hand/Auto	Hand/Auto macro			2		
	Sequence control	Sequenti	5				
	FIELDBUS	Fieldbus	6				
96.06	Parameter restore	paramete	er defaul	inal settings of the control program, ie. t values. neter cannot be changed while the drive is	Done		
	Done	Restoring	g is com	pleted.	0		

No.	Name/Value	Description	Def/ FbEq16
	Restore defaults	All editable parameter values are restored to default values, except  • motor data and ID run results  • parameter 31.42 Overcurrent fault limit  • control panel/PC communication settings  • I/O extension module settings  • fieldbus adapter settings  • encoder configuration data  • application macro selection and the parameter defaults implemented by it  • parameter 95.01 Supply voltage  • parameter 95.09 Switch fuse controller  • differentiated defaults implemented by parameters 95.20 HW options word 1 and 95.21 HW options word 2  • user lock configuration parameters 96.10096.102.	8
	Clear all	All editable parameter values are restored to default values, except  control panel/PC communication settings  application macro selection and the parameter defaults implemented by it  parameter 95.01 Supply voltage  parameter 95.09 Switch fuse controller  differentiated defaults implemented by parameters 95.20 HW options word 1 and 95.21 HW options word 2  user lock configuration parameters 96.10096.102.  PC tool communication is interrupted during the restoring.  Note: Activating this selection will restore the default settings of the fieldbus adapter if one is connected, potentially including settings that cannot be accessed through drive parameters	62
	Reset all fieldbus settings	Fieldbus adapter and embedded fieldbus interface settings (parameter groups 5058) are restored to default values. This will also restore the default settings of the fieldbus adapter if one is connected, potentially including settings that cannot be accessed through drive parameters.	32
96.07	Parameter save manually	Saves the valid parameter values to permanent memory. This parameter should be used to store values sent from a fieldbus, or when using an external power supply to the control board as the supply might have a very short hold-up time when powered off.  Note: A new parameter value is saved automatically when changed from the PC tool or control panel but not when altered through a fieldbus adapter connection.	Done
	Done	Save completed.	0
	Save	Save in progress.	1
96.08	Control board boot	Changing the value of this parameter to 1 reboots the control unit (without requiring a power off/on cycle of the complete drive module).  The value reverts to 0 automatically.  Note: This parameter cannot be changed while the drive is running.	0
	01	1 = Reboot the control unit.	1 = 1

No.	Name/Value	Description	Def/ FbEq16
96.09	FSO reboot	Changing the value of (or the source selected by) this parameter to 1 reboots the optional FSO-xx safety functions module.  Note: The value does not reverts to 0 automatically.	FALSE
	FALSE	0.	0
	True	1.	1
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page <i>118</i> ).	-
96.10	User set status	Shows the status of the . This parameter is read-only. See also section <i>User parameter sets</i> (page 105).	-
	n/a	No have been saved.	0
	Loading	A user set is being loaded.	1
	Saving	A user set is being saved.	2
	Faulted	Invalid or empty parameter set.	3
	User set 1	User set 1 has been loaded.	4
	User set 2	User set 2 has been loaded.	5
	User set 3	User set 3 has been loaded.	6
	User set 4	User set 4 has been loaded.	7
96.11	User set save/load	Enables the saving and restoring of up to four custom sets of parameter settings. See section <i>User parameter sets</i> (page 105).  The set that was in use before powering down the drive is in use after the next power-up.  Notes:  Hardware configuration settings such as I/O extension module, fieldbus and encoder configuration parameters (groups 1416, 5156, 58 and 9293, part of group 95, and parameters 50.01 and 50.31), are forced input/output values (such as 10.03 and 10.04) are not included in .  Parameter changes made after loading a set are not automatically stored – they must be saved using this parameter.  If no sets have been saved, attempting to load a set will create all sets from the currently active parameter settings.  Switching between sets is only possible with the drive stopped.	No action
	No action	Load or save operation complete; normal operation.	0
	User set I/O mode	Load user parameter set using parameters 96.12 User set IO mode in1 and 96.13 User set IO mode in2.	1
	Load set 1	Load user parameter set 1.	2
	Load set 2	Load user parameter set 2.	3
	Load set 3	Load user parameter set 3.	4
	Load set 4	Load user parameter set 4.	5
	Save to set 1	Save user parameter set 1.	18
	Save to set 2	Save user parameter set 2.	19

No.	Name/Value	Description		Def/ FbEq16	
	Save to set 3	Save user param	neter set 3.		20
	Save to set 4	Save user param	neter set 4.		21
96.12	User set IO mode in1	When parameter 96.11 User set save/load is set to User set I/O mode, selects the user parameter set together with parameter 96.13 User set IO mode in2 as follows:			
		Status of source defined by par. 96.12	Status of source defin by par. 96.13		
		0	0	Set 1	
		1	0	Set 2	
		0	1	Set 3	
		1	1	Set 4	
		-		300.1	
	Not selected	0.			0
	Selected	1.			1
	DI1	Digital input DI1	(10.02 DI delayed	status, bit 0).	2
	DI2	Digital input DI2	(10.02 DI delayed	status, bit 1).	3
	DI3	Digital input DI3	(10.02 DI delayed	status, bit 2).	4
	DI4	Digital input DI4	(10.02 DI delayed	status, bit 3).	5
	DI5	Digital input DI5	(10.02 DI delayed	status, bit 4).	6
	DI6	Digital input DI6	(10.02 DI delayed	status, bit 5).	7
	DIO1	Digital input/outp	out DIO1 (11.02 DI	O delayed status, b	oit 0). 10
	DIO2	Digital input/outp	out DIO2 (11.02 DI	O delayed status, b	oit 1). 11
	Other [bit]	Source selection page 118).	(see Terms and a	bbreviations on	-
96.13	User set IO mode in2	See parameter 9	6.12 User set IO r	mode in1.	Not selected
96.16	Unit selection	Selects the unit of temperature and	of parameters indictorque.	cating power,	0000 0000Ь
		Bit 1	Name	Information	
		0 F	Power unit	0 = kW	
				1 = hp	
			Reserved emperature unit	0 = C (°C)	
		'	emperature unit	1 = F (°F)	
		3 F	Reserved	( . )	
		4 T	orque unit	0 = Nm (N·m)	
				1 = lbft (lb·ft)	
		515 F	Reserved		
	0000 0000b0001 0101b	Unit selection wo	ord.		1 = 1

No.	Name/Value	Description	Def/ FbEq16
96.20	Time sync primary source	Defines the 1st priority external source for synchronization of the drive's time and date.  The date and time can also be directly set into 96.2496.26 in which case this parameter is ignored.	DDCS Controller
	Internal	No external source selected.	0
	DDCS Controller	External controller.	1
	Fieldbus A or B	Fieldbus interface A or B.	2
	Fieldbus A	Fieldbus interface A.	3
	Fieldbus B	Fieldbus interface B.	4
	D2D or M/F	The master station on a master/follower or drive-to-drive link.	5
	Embedded FB	Embedded fieldbus interface.	6
	Panel link	Control panel, or Drive composer PC tool connected to the control panel.	8
	Ethernet tool link	Drive composer PC tool through an FENA module.	9
96.24	Full days since 1st Jan 1980	Number of full days passed since beginning of the year 1980.  This parameter, together with 96.25 Time in minutes within 24 h and 96.26 Time in ms within one minute makes it possible to set the date and time in the drive via the parameter interface from a fieldbus or application program. This may be necessary if the fieldbus protocol does not support time synchronization.	-
	159999	Days since beginning of 1980.	1 = 1
96.25	Time in minutes within 24 h	Number of full minutes passed since midnight. For example, the value 860 corresponds to 2:20 pm. See parameter 96.24 Full days since 1st Jan 1980.	0 min
	11439	Minutes since midnight.	1 = 1
96.26	Time in ms within one minute	Number of milliseconds passed since last minute. See parameter 96.24 Full days since 1st Jan 1980.	0 ms
	059999	Number of milliseconds since last minute.	1 = 1

No.	Name/Value	Description	Def/ FbEq16
96.29	Time sync source status	Time source status word. This parameter is read-only.	-

Bit	Name	Description	
0	Time tick received	1 = 1st priority tick received: Tick has been received from 1st priority source (or from 96.2496.26).	
1	Aux Time tick received	1 = 2nd priority tick received: Tick has been received from 2nd priority source.	
2	Tick interval is too long	1 = Yes: Tick interval too long (accuracy compromised).	
3	DDCS controller	1 = Tick received: Tick has been received from an external controller.	
4	Master/Follower	1 = Tick received: Tick has been received through the master/follower link.	
5	Reserved	·	
6	D2D	1 = Tick received: Tick has been received through the drive-to-drive link.	
7	FbusA	1 = Tick received: Tick has been received through fieldbus interface A.	
8	FbusB	1 = Tick received: Tick has been received through fieldbus interface B.	
9	EFB	1 = Tick received: Tick has been received through the embedded fieldbus interface.	
10	Reserved		
11	Panel link	1 = Tick received: Tick has been received from the control panel, or Drive composer PC tool connected to the control panel.	
12	Ethernet tool link	1 = Tick received: Tick has been received from Drive composer PC tool through an FENA module.	
13	Parameter setting	1 = Tick received: Tick has been set by parameters 96.2496.26.	
14	RTC	1 = RTC time in use: Time and date have been read from the real-time clock.	
15	Drive On-Time	1 = Drive on-time in use: Time and date are displaying drive on- time.	

	0000hFFFFh	Time source status word 1.	1 = 1
96.31	Drive ID number	Specifies an ID number for the drive. The ID can be read by an external controller through DDCS, for example, for comparison with an ID contained by the controller's application.	0
	032767	Drive ID number	1 = 1
96.39	Power up event logging	Enables/disables power-up logging. When enabled, an event ( <i>B5A2 Power up</i> ) is logged by the drive upon each power-up.	Enable
	Disable	Power-up event logging disabled.	0
	Enable	Power-up event logging enabled.	1
96.51	Clear fault and event logger	Clears the contents of the event logs. See section <i>Event logs</i> (page 475).	00000
	00001	Clear the event logs. (The value will automatically revert to 00000.)	1

No.	Name/Value	Description	Def/ FbEq16
96.53	Actual checksum	Displays the actual parameter configuration checksum. The checksum is generated and updated whenever an action is selected in 96.54 Checksum action.  The parameters included in the calculation have been preselected, but the selection can be edited using the Drive customizer PC tool.  See also section Parameter checksum calculation (page 105).	0h
	00000000h FFFFFFFh	Actual checksum.	-
96.54	Checksum action	Selects how the drive reacts if the parameter checksum (96.53 Actual checksum) does not match any of the active approved checksums (96.5696.59). The active checksums are selected by 96.55 Checksum control word.	No action
	No action	No action taken. (The checksum feature is not in use.)	0
	Pure event	The drive generates an event log entry (B686 Checksum mismatch).	1
	Warning	The drive generates a warning (A686 Checksum mismatch).	2
	Warning and prevent start	The drive generates a warning (A686 Checksum mismatch). Starting the drive is prevented.	3
	Fault	The drive trips on 6200 Checksum mismatch.	4
96.55	Checksum control word	Bits 03 select to which approved checksums (out of 96.5696.59) the actual checksum (96.53) is compared. Bits 47 select an approved (reference) checksum parameter (96.5696.59) into which the actual checksum from parameter 96.53 is copied.	0000000b

Bit	Name	Description
0	Approved checksum 1	1 = Enabled: Checksum 1 (96.56) is observed.
1	Approved checksum 2	1 = Enabled: Checksum 2 (96.57) is observed.
2	Approved checksum 3	1 = Enabled: Checksum 3 (96.58) is observed.
3	Approved checksum 4	1 = Enabled: Checksum 4 (96.59) is observed.
4	Set approved checksum 1	1 = Set: Copy value of 96.53 into 96.56.
5	Set approved checksum 2	1 = Set: Copy value of 96.53 into 96.57.
6	Set approved checksum 3	1 = Set: Copy value of 96.53 into 96.58.
7	Set approved checksum 4	1 = Set: Copy value of 96.53 into 96.59.
815	Reserved	

	00000000b 11111111b	Checksum control word.	1 = 1
96.56	Approved checksum 1	Approved (reference) checksum 1.	0h
	00000000h FFFFFFFh	Approved checksum 1.	-
96.57	Approved checksum 2	Approved (reference) checksum 2.	0h
	00000000h FFFFFFFh	Approved checksum 2.	-

No.	Name/Value	Description	Def/ FbEq16
96.58	Approved checksum 3	Approved (reference) checksum 3.	0h
	00000000h FFFFFFFh	Approved checksum 3.	-
96.59	Approved checksum 4	Approved (reference) checksum 4.	0h
	00000000h FFFFFFFh	Approved checksum 4.	-
96.61	User data logger status word	Provides status information on the user data logger (see page 476). This parameter is read-only.	0000b

Bit	Name	Description
0	Running	1 = The user data logger is running. The bit is cleared after the post-trigger time has passed.
1	Triggered	1 = The user data logger has been triggered. The bit is cleared when the logger is restarted.
2	Data available	1 = The user data logger contains data that can be read. Note that the bit is not cleared because the data is saved to the memory unit.
3	Configured	The user data logger has been configured. Note that the bit is not cleared because the configuration data is saved to the memory unit.
415	Reserved	

	0000b1111b	User data logger status word.	1 = 1
96.63	User data logger trigger	Triggers, or selects a source that triggers, the user data logger.	Off
	Off	0.	0
	On	1.	1
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
96.64	User data logger start	Starts, or selects a source that starts, the user data logger.	Off
	Off	0.	0
	On	1.	1
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
96.65	Factory data logger time level	Selects the sampling interval for the factory data logger (see page 475).	500us
	500us	500 microseconds.	500
	2ms	2 milliseconds.	2000
	10ms	10 milliseconds.	10000
96.70	Disable adaptive program	Enables/disables the adaptive program (if present). See also section <i>Adaptive programming</i> (page 58).  Note: This parameter cannot be changed while the drive is running.	No
	No	Adaptive program enabled.	0
	Yes	Adaptive program disabled.	1

No.	Name/Value	Description	Def/ FbEq16
96.100	Change user pass code	(Visible when user lock is open)  To change the current user pass code, enter a new code into this parameter as well as 96.101 Confirm user pass code. A warning will be active until the new pass code is confirmed. To cancel changing the pass code, close the user lock without confirming. To close the lock, enter an invalid pass code in parameter 96.02 Pass code, activate parameter 96.08 Control board boot, or cycle the power. See also section User lock (page 106).	1000000
	10000000 99999999	New user pass code.	-
96.101	Confirm user pass code	(Visible when user lock is open) Confirms the new user pass code entered in 96.100 Change user pass code.	
	10000000 99999999	Confirmation of new user pass code.	-

0...1

No.	Name/V	alue	Descr	iption	Def/ FbEq16	
96.102	1		Selects the use when the code. Note: N	when user lock is open) the actions or functionalities to be prevented by the actions or functionalities to be prevented by the lock. Note that the changes made take effect only the user lock is closed. See parameter 96.02 Pass  We recommend you select all the actions and nalities unless otherwise required by the tion.	1000b	
	Bit	Name		Information		
	0	Disable ABB levels	access	1 = ABB access levels (service, advanced programmed 96.03) disabled	mer, etc.; see	
	1	Freeze paran lock state	neter	1 = Changing the parameter lock state prevented, ic 358 has no effect	e. pass code	
	2	Disable file download		Loading of files to drive prevented. This applies     firmware upgrades     safety functions module (FSO-xx) configuration     parameter restore     loading an adaptive program     loading and debugging an application program     changing home view of control panel     editing drive texts     editing the favorite parameters list on control pane     configuration settings made through control pane     time/date formats and enabling/disabling clock di	el I such as splay.	
	3	Disable FB write to hidden		1 = Access to parameters on disabled access levels from fieldbus prevented.		
	45	Reserved				
	6	Protect AP		1 = Creating a backup and restoring from a backup prevented.		
	7	Disable pane Bluetooth	I	1 = Bluetooth disabled on ACS-AP-W control panel, part of a panel bus, Bluetooth is disabled on all panel		
	810	Reserved				
	11	level 1		1 = OEM access level 1 disabled		
	12	level 2		1 = OEM access level 2 disabled		
	13	level 3	access	1 = OEM access level 3 disabled		
	1415	Reserved				
	000b1	11b	Selecti	on of actions to be prevented by user lock.	-	
96.108	LSU con boot	trol board	95.20) Changi supply of the o	ing the value of this parameter to 1 reboots the control unit (without requiring a power off/on cycle drive system).	0	
					I	

1 = Reboot the supply control unit.

1 = 1

No.	Name/Value	Description	Def/ FbEq16
97 Mo	tor control	Motor model settings.	
97.01	Switching frequency reference	When parameter 97.09 Switching freq mode is set to Custom, defines the switching frequency when it is not otherwise being internally limited.  Note: This is an expert level parameter and should not be adjusted without appropriate skill.	4.500 kHz
	0.000 24.000 kHz	Switching frequency reference.	1000 = 1 kHz
97.02	Minimum switching frequency	When parameter 97.09 Switching freq mode is set to Custom, defines a minimum switching frequency reference. The actual switching frequency will not fall below this limit under any circumstances.  Notes:  • This is an expert level parameter and should not be adjusted without appropriate skill.  • The drive has internal switching frequency limits that may override the value entered here.	1.500 kHz
	0.000 24.000 kHz	Minimum switching frequency.	1000 = 1 kHz
97.03	Slip gain	Defines the slip gain which is used to improve the estimated motor slip. 100% means full slip gain; 0% means no slip gain. The default value is 100%. Other values can be used if a static speed error is detected despite having the setting at full slip gain.  Example (with nominal load and nominal slip of 40 rpm): A 1000 rpm constant speed reference is given to the drive. Despite having full slip gain (= 100%), a manual tachometer measurement from the motor axis gives a speed value of 998 rpm. The static speed error is 1000 rpm - 998 rpm = 2 rpm. To compensate the error, the slip gain should be increased to 105% (2 rpm / 40 rpm = 5%).	100%
	0200%	Slip gain.	1 = 1%
97.04	Voltage reserve	Defines the minimum allowed voltage reserve. When the voltage reserve has decreased to the set value, the drive enters the field weakening area.   Note: This is an expert level parameter and should not be adjusted without appropriate skill.   If the intermediate circuit DC voltage $U_{\rm dc}$ = 550 V and the voltage reserve is 5%, the rms value of the maximum output voltage in steady-state operation is $0.95 \times 550 \text{ V}$ / sqrt(2) = 369 V The dynamic performance of the motor control in the field weakening area can be improved by increasing the voltage reserve value, but the drive enters the field weakening area earlier.	-2%
	-450%	Voltage reserve.	1 = 1%
97.05	Flux braking	Defines the level of flux braking power. (Other stopping and braking modes can be configured in parameter group 21 Start/stop mode).  See section Flux braking (page 85).  Note: This is an expert level parameter and should not be adjusted without appropriate skill.	Disabled
	Disabled	Flux braking is disabled.	0

No.	Name/Value	Description	Def/ FbEq16
	Moderate	Flux level is limited during the braking. Deceleration time is longer compared to full braking.	1
	Full	Maximum braking power. Almost all available current is used to convert the mechanical braking energy to thermal energy in the motor.	2
97.06	Flux reference select	Defines the source of flux reference.  Note: This is an expert level parameter and should not be adjusted without appropriate skill.	User flux reference
	Zero	None.	0
	User flux reference	Parameter 97.07 User flux reference.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page 118).	-
97.07	User flux reference	Defines the flux reference when parameter 97.06 Flux reference select is set to User flux reference.	100.00%
	0.00200.00%	User-defined flux reference.	100 = 1%
97.08	Optimizer minimum torque	This parameter can be used to improve the control dynamics of a synchronous reluctance motor or a salient permanent magnet synchronous motor.  As a rule of thumb, define a level to which the output torque must rise with minimum delay. This will increase the motor current and improve the torque response at low speeds.	0.0%
	0.0 1600.0%	Optimizer torque limit.	10 = 1%
97.09	Switching freq mode	An optimization setting for balancing between control performance and motor noise level.     Note:	Normal
	Normal	Control performance optimized for long motor cables.	0
	Low noise	Minimizes motor noise.	1
	Cyclic	Control performance optimized for cyclic load applications.	2
	Custom	This setting is to be used by ABB-authorized service personnel only.	3
97.10	Signal injection	Enables signal injection. A high-frequency alternating signal is injected into the motor at low speeds to improve the stability of torque control. Signal injection can be enabled with different amplitude levels.  Notes:  This is an expert level parameter and should not be adjusted without appropriate skill.  Use as low a level as possible that gives satisfactory performance.  Signal injection cannot be applied to asynchronous motors.	Disabled
	Disabled	Signal injection disabled.	0
	Enabled (5%)	Signal injection enabled with an amplitude level of 5%.	1
		0: 1:1:::::::::::::::::::::::::::::::::	2
	Enabled (10%)	Signal injection enabled with an amplitude level of 10%.	2

No.	Name/Value	Description	Def/ FbEq16
	Enabled (20%)	Signal injection enabled with an amplitude level of 20%.	4
97.11	TR tuning	Rotor time constant tuning.  This parameter can be used to improve torque accuracy in closed-loop control of an induction motor. Normally, the motor identification run provides sufficient torque accuracy, but manual fine-tuning can be applied in exceptionally demanding applications to achieve optimal performance.  Note: This is an expert level parameter and should not be adjusted without appropriate skill.	100%
	25400%	Rotor time constant tuning.	1 = 1%
97.12	IR comp step-up frequency	IR compensation (ie. output voltage boost) can be used in step-up applications to compensate for resistive losses in the step-up transformer, cabling and motor. As voltage cannot be fed through a step-up transformer at 0 Hz, a specific type of IR compensation should be used. This parameter adds a frequency breakpoint for parameter 97.13 IR compensation as shown below.  U/UN (%)  Relative output voltage with IR compensation  100%  Relative output voltage with IR compensation  100%  Field weakening point  0.0 Hz = Breakpoint disabled  Note: This parameter cannot be changed while the drive is running.	0.0 Hz
	0.050.0 Hz	IR compensation breakpoint for step-up applications.	1 = 1 Hz

No.	Name/Value	Description	Def/ FbEq16
97.13	IR compensation	Defines the relative output voltage boost at zero speed (IR compensation). The function is useful in applications with a high break-away torque where direct torque control (DTC mode) cannot be applied.  U / U <sub>N</sub> (%)  Relative output voltage with. IR compensation  100%  Relative output voltage with. IR compensation.    Field weakening point   Field weakening point	0.00%
	0.0050.00%	Voltage boost at zero speed in percent of nominal motor voltage.	1 = 1%
97.15	Motor model temperature adaptation	Selects whether the temperature-dependent parameters (such as stator or rotor resistance) of the motor model adapt to actual (measured or estimated) temperature or not.  See parameter group 35 Motor thermal protection for selection of temperature measurement sources.	Disabled
	Disabled	Temperature adaptation of motor model disabled.	0
	Estimated temperature	Estimated temperature (35.01 Motor estimated temperature) used for adaptation of motor model.	1
	Measured temperature 1	Measured temperature 1 (35.02 Measured temperature 1) used for adaptation of motor model.	2
	Measured temperature 2	Measured temperature 2 (35.03 Measured temperature 2) used for adaptation of motor model.	3
97.18	Hexagonal field weakening	Activates hexagonal motor flux pattern in the field weakening area, ie. above the limit defined by parameter 97.19 Hexagonal field weakening point.  Note: This parameter is only effective in scalar motor control mode.  See also section Hexagonal motor flux pattern (page 88).	Off
	Off	The rotating flux vector follows a circular pattern.	0
	On	The flux vector follows a circular pattern below, and a hexagonal pattern above, the hexagonal field weakening point (97.19).	1

No.	Name/Value	Description	Def/ FbEq16
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	DIO1	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).	10
	DIO2	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).	11
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 118).	-

	er motor rameters	Motor values supplied by the user that are used in the motor model.  These parameters are useful for non-standard motors, or to just get more accurate motor control of the motor on site. A better motor model always improves the shaft performance.	
98.01	User motor model mode	Activates the motor model parameters 98.0298.14 and the rotor angle offset parameter 98.15.  Notes:  Parameter value is automatically set to zero when ID run is selected by parameter 99.13 ID run requested. The values of parameters 98.0298.15 are then updated according to the motor characteristics identified during the ID run.  Measurements made directly from the motor terminals during the ID run are likely to produce slightly different values than those on a datasheet from a motor manufacturer.  This parameter cannot be changed while the drive is running.	Not selected
	Not selected	Parameters 98.0298.15 inactive.	0
	Motor parameters	The values of parameters 98.0298.14 are used as the motor model.	1
	Position offset	The value of parameter 98.15 is used as the rotor angle offset. Parameters 98.0298.14 are inactive.	2
	Motor parameters & position offset	The values of parameters 98.0298.14 are used as the motor model, and the value of parameter 98.15 is used as the rotor angle offset.	3
98.02	Rs user	Defines the stator resistance $R_{\rm S}$ of the motor model. With a star-connected motor, $R_{\rm S}$ is the resistance of one winding. With a delta-connected motor, $R_{\rm S}$ is one-third of the resistance of one winding. Resistance value is given at 20 °C (68 °F).	0.00000 p.u.
	0.00000 0.50000 p.u.	Stator resistance in per unit.	-
98.03	Rr user	Defines the rotor resistance $R_R$ of the motor model. Resistance value is given at 20 °C (68 °F). <b>Note:</b> This parameter is valid only for asynchronous motors.	0.00000 p.u.
	0.00000 0.50000 p.u.	Rotor resistance in per unit.	-

No.	Name/Value	Description	Def/ FbEq16
98.04	Lm user	Defines the main inductance $L_{\rm M}$ of the motor model. <b>Note:</b> This parameter is valid only for asynchronous motors.	0.00000 p.u.
	0.00000 10.00000 p.u.	Main inductance in per unit.	-
98.05	SigmaL user	Defines the leakage inductance $\sigma L_S$ . <b>Note:</b> This parameter is valid only for asynchronous motors.	0.00000 p.u.
	0.00000 1.00000 p.u.	Leakage inductance in per unit.	-
98.06	Ld user	Defines the direct axis (synchronous) inductance.  Note: This parameter is valid only for permanent magnet motors.	0.00000 p.u.
	0.00000 10.00000 p.u	Direct axis inductance in per unit.	-
98.07	Lq user	Defines the quadrature axis (synchronous) inductance.  Note: This parameter is valid only for permanent magnet motors.	0.00000 p.u.
	0.00000 10.00000 p.u	Quadrature axis inductance in per unit.	-
98.08	PM flux user	Defines the permanent magnet flux.  Note: This parameter is valid only for permanent magnet motors.	0.00000 p.u.
	0.00000 2.00000 p.u	Permanent magnet flux in per unit.	-
98.09	Rs user SI	Defines the stator resistance $R_S$ of the motor model. Resistance value is given at 20 °C (68 °F).	0.00000 ohm
	0.00000 100.00000 ohm	Stator resistance.	-
98.10	Rr user SI	Defines the rotor resistance $R_R$ of the motor model. Resistance value is given at 20 °C (68 °F).  Note: This parameter is valid only for asynchronous motors.	0.00000 ohm
	0.00000 100.00000 ohm	Rotor resistance.	-
98.11	Lm user SI	Defines the main inductance $L_{\rm M}$ of the motor model. <b>Note:</b> This parameter is valid only for asynchronous motors.	0.00 mH
	0.00100000.00 mH	Main inductance.	1 = 10 mH
98.12	SigmaL user SI	Defines the leakage inductance $\sigma L_{S}$ . Note: This parameter is valid only for asynchronous motors.	0.00 mH
	0.00100000.00 mH	Leakage inductance.	1 = 10 mH

No.	Name/Value	Description	Def/ FbEq16
98.13	Ld user SI	Defines the direct axis (synchronous) inductance.  Note: This parameter is valid only for permanent magnet motors.	0.00 mH
	0.00100000.00 mH	Direct axis inductance.	1 = 10 mH
98.14	Lq user SI	Defines the quadrature axis (synchronous) inductance.  Note: This parameter is valid only for permanent magnet motors.	0.00 mH
	0.00100000.00 mH	Quadrature axis inductance.	1 = 10 mH
98.15	Position offset user	Defines an angle offset between the zero position of the synchronous motor and the zero position of the position sensor.  This value is initially set by the autophasing routine when parameter 21.13 Autophasing mode is set to Turning with Z-pulse, and can be fine-tuned later on.  Notes:  The value is in electrical degrees. The electrical angle equals the mechanical angle multiplied by the number of motor pole pairs.  This parameter is valid only for permanent magnet motors.	0 deg
	0360 deg	Angle offset.	1 = 1 deg

99 Mo	tor data	Motor configuration settings.	
99.03	Motor type	Selects the motor type.  Note: This parameter cannot be changed while the drive is running.	Asynchronous motor; SynRM (95.21 b1), Permanent magnet motor (95.21 b2)
	Asynchronous motor	Standard squirrel cage AC induction motor (asynchronous induction motor).	0
	Permanent magnet motor	Permanent magnet motor. Three-phase AC synchronous motor with permanent magnet rotor and sinusoidal BackEMF voltage.	1
	SynRM	Synchronous reluctance motor. Three-phase AC synchronous motor with salient pole rotor without permanent magnets.	2

No.	Name/Value	Description	Def/ FbEq16
99.04	Motor ctrl mode	Selects the motor control mode.  Note: This parameter cannot be changed while the drive is running.	DTC
	DTC	Direct torque control. This mode is suitable for most applications.  Note: Instead of direct torque control, scalar control is also available, and should be used in the following situations:  • with multimotor applications 1) if the load is not equally shared between the motors, 2) if the motors are of different sizes, or 3) if the motors are going to be changed after the motor identification (ID run)  • if the nominal current of the motor is less than 1/6 of the nominal output current of the drive  • if the drive is used with no motor connected (for example, for test purposes).  See also section Operating modes of the drive (page 56).	0
	Scalar	Scalar control. The outstanding motor control accuracy of DTC cannot be achieved in scalar control.  Refer to the <i>DTC</i> selection above for a list of applications where scalar control should definitely be used.  Note:  Correct motor operation requires that the magnetizing current of the motor does not exceed 90% of the nominal current of the inverter.  Some standard features are disabled in scalar control mode.  See also section <i>Scalar motor control</i> (page <i>81</i> ), and section <i>Operating modes of the drive</i> (page <i>56</i> ).	1
99.06	Motor nominal current	Defines the nominal motor current. This setting must match the value on the rating plate of the motor. If multiple motors are connected to the drive, enter the total current of the motors  Note:  Correct motor operation requires that the magnetizing current of the motor does not exceed 90% of the nominal current of the drive.  This parameter cannot be changed while the drive is running.	0.0 A
	0.06400.0 A	Nominal current of the motor. The allowable range is $1/62 \times I_N$ (nominal current) of the drive $(02 \times I_N$ with scalar control mode).	1 = 1 A

No.	Name/Value	Description	Def/ FbEq16
99.07	Defines the nominal motor voltage supplied to the motor. This setting must match the value on the rating plate of the motor.  Note:  • With permanent magnet motors, the nominal voltage is the BackEMF voltage at nominal speed of the motor. If the voltage is given as voltage per rpm, e.g. 60 V per 1000 rpm, the voltage for a nominal speed of 3000 rpm is 3 × 60 V = 180 V. Note that nominal voltage is not the same as equivalent DC motor voltage (EDCM) given by some manufacturers. The nominal voltage can be calculated by dividing the EDCM voltage by 1.7 (or square root of 3).  • The stress on the motor insulation is always dependent on the drive supply voltage. This also applies to the case where the motor voltage rating is lower than that of the drive and the supply.  • This parameter cannot be changed while the drive is running.		0.0 V
	0.0800.0 V	Nominal voltage of the motor. The allowable range is $1/62 \times U_{\rm N}$ (nominal voltage) of the drive. $U_{\rm N}$ equals the upper bound of the supply voltage range selected by parameter 95.01 Supply voltage.	10 = 1 V
99.08	Motor nominal frequency	Defines the nominal motor frequency. This setting must match the value on the rating plate of the motor.  Note: This parameter cannot be changed while the drive is running.	50.00 Hz
	0.00 1000.00 Hz	Nominal frequency of the motor.	10 = 1 Hz
99.09	Motor nominal speed	Defines the nominal motor speed. The setting must match the value on the rating plate of the motor.  Note: This parameter cannot be changed while the drive is running.	0 rpm
	030000 rpm	Nominal speed of the motor.	1 = 1 rpm
99.10	Motor nominal power	Defines the nominal motor power. The setting must match the value on the rating plate of the motor. If nominal power is not shown on the rating plate, nominal torque can be entered instead in parameter 99.12.  If multiple motors are connected to the drive, enter the total power of the motors.  The unit is selected by parameter 96.16 Unit selection.  Note: This parameter cannot be changed while the drive is running.	0.00 kW or hp
	0.00 10000.00 kW or 0.0013404.83 hp	Nominal power of the motor.	1 = 1 unit

No.	Name/Value	Description Def/FbEq	
99.11	Motor nominal cos ?	Defines the cosphi of the motor for a more accurate motor model. The value is not obligatory, but is useful with an asynchronous motor, especially when performing a standstill identification run. The setting should match the value on the rating plate of the motor. With a permanent magnet or synchronous reluctance motor, this value is not needed.  Notes:  Do not enter an estimated value. If you do not know the exact value, leave the parameter at zero.  This parameter cannot be changed while the drive is running.	0.00
	0.001.00	Cosphi of the motor.	100 = 1
99.12	Motor nominal torque	Defines the nominal motor shaft torque. This value can be given instead of nominal power (99.10) if shown on the rating plate of the motor.  The unit is selected by parameter 96.16 Unit selection.  Note:  This setting is an alternative to the nominal power value (99.10). If both are entered, 99.12 takes priority.  This parameter cannot be changed while the drive is running.	0.000 N·m or lb·ft
	0.0004000000.000 N·m or lb·ft	Nominal motor torque.	1 = 1 unit

No. N	Name/Value	Description	Def/ FbEq16
99.13 IE	D run requested	Selects the type of the motor identification routine (ID run) performed at the next start of the drive. During the ID run, the drive will identify the characteristics of the motor for optimum motor control.  If no ID run has been performed yet (or if default parameter values have been restored using parameter 96.06 Parameter restore), this parameter is automatically set to Standstill, signifying that an ID run must be performed.  After the ID run, the drive stops and this parameter is automatically set to None.  Note:  • For the Advanced ID run, the machinery must always be de-coupled from the motor.  • Before activating the ID run, configure motor temperature measurement (if used) in parameter group 35 Motor thermal protection before activating the ID run.  If a sine filter is installed, set the appropriate bit in parameter 95.15 Special HW settings before activating the ID run. With a non-ABB (custom) filter, set also 99.18 and 99.19.  With scalar control mode (99.04 Motor ctrl mode = Scalar), only the Current measurement calibration ID run mode is possible.  • Once the ID run is activated, it can be canceled by stopping the drive.  • The ID run must be performed every time any of the motor parameters (99.04, 99.0699.12) have been changed.  • Ensure that the Safe torque off and emergency stop circuits (if any) are closed during the ID run.  • Mechanical brake (if present) is not opened by the logic for the ID run.  • This parameter cannot be changed while the drive is running.	None; Standstill (95.21 b1/b2)
N	lone	No motor ID run is requested. This mode can be selected only if the ID run ( <i>Normal, Reduced, Standstill, Advanced, Advanced Standstill)</i> has already been performed once.	0
N	lormal	Normal ID run. Guarantees good control accuracy for all cases. The ID run takes about 90 seconds. This mode should be selected whenever it is possible.  Note:  If the load torque will be higher than 20% of motor nominal torque, or if the machinery is not able to withstand the nominal torque transient during the ID run, then the driven machinery must be de-coupled from the motor during a Normal ID run.  Check the direction of rotation of the motor before starting the ID run. During the run, the motor will rotate in the forward direction.  WARNING! The motor will run at up to approximately 50100% of the nominal speed during the ID run.  ENSURE THAT IT IS SAFE TO RUN THE MOTOR BEFORE PERFORMING THE ID RUN!	1

No. Name/\	/alue	Description	Def/ FbEq16
Advance	ed	Advanced ID run. Guarantees the best possible control accuracy. The ID run can take a couple of minutes. This mode should be selected when top performance is needed across the whole operating area.  Note: The driven machinery must be de-coupled from the motor because of high torque and speed transients that are applied.  WARNING! The motor will run at up to approximately 50100% of the nominal speed during the ID run. Several accelerations and decelerations are done. ENSURE THAT IT IS SAFE TO RUN THE MOTOR BEFORE PERFORMING THE ID RUN!	6
Advance	ed Standstill	Advanced Standstill ID run. This selection is recommended with AC induction motors up to 75 kW instead of the <i>Standstill</i> ID run if  • the exact nominal ratings of the motor are not known, or  • the control performance of the motor is not satisfactory after a <i>Standstill</i> ID run.  Note: The time it takes for the <i>Advanced Standstill</i> ID run to complete varies according to motor size. With a small motor, the ID run typically completes within 5 minutes; with a large motor, the ID run may take up to an hour.	7
99.14 Last ID	run performed	Shows the type of ID run that was performed last. For more information about the different modes, see the selections of parameter 99.13 ID run requested.	None
None		No ID run has been performed.	0
Normal		Normal ID run.	1
Reduce	d	Reduced ID run.	2
Standsti	11	Standstill ID run.	3
Advance	ed	Advanced ID run.	6
Advance	ed Standstill	Advanced Standstill ID run.	7
99.15 Motor po calculate		Calculated number of pole pairs in the motor.	0
01000	)	Number of pole pairs.	1 = 1

No.	Name/Value	Description	Def/ FbEq16
99.16 Motor phase order		Switches the rotation direction of motor. This parameter can be used if the motor turns in the wrong direction (for example, because of the wrong phase order in the motor cable), and correcting the cabling is considered impractical.  Note:  • Changing this parameter does not affect speed reference polarities, so positive speed reference will rotate the motor forward. The phase order selection just ensures that "forward" is in fact the correct direction.  • After changing this parameter, the sign of encoder feedback (if any) must be checked. This can be done by setting parameter 90.41 Motor feedback selection to Estimate, and comparing the sign of 90.01 Motor speed for control to 90.10 Encoder 1 speed (or 90.20 Encoder 2 speed). If the sign of the measurement is incorrect, the encoder wiring must be corrected or the sign of 90.43 Motor gear numerator reversed.  • This parameter cannot be changed while the drive is running.	UVW
	UVW	Normal.	0
	UWV	Reversed rotation direction.	1
99.18	Sine filter inductance	Defines the inductance of a custom sine filter, ie. when parameter 95.15 Special HW settings bit 3 is activated.  Note: For an ABB sine filter (95.15 Special HW settings bit 1), this parameter is set automatically and should not be adjusted.	0.000 mH
	0.000 100000.000 mH	Inductance of custom sine filter.	1000 = 1 mH

No.	Name/Value	Description	Def/ FbEq16
99.19	Sine filter capacitance	Defines the capacitance of a custom sine filter, ie. when parameter 95.15 Special HW settings bit 3 is activated. If the capacitors are star/wye-connected, enter the capacitance of one leg into the parameter.    March	0.00 μF
	0.00 100000.00 μF	Capacitance of custom sine filter.	100 = 1 μF

#### **200 Safety** FSO-xx settings.

This group contains parameters related to the optional FSO-xx safety functions module. For details, refer to the documentation of the FSO-xx module.

206 I/O bus configuration		
207 I/O bus service	These groups are only visible with a BCU control unit.	
208 I/O bus diagnostics		
209 I/O bus fan		
identification		

These groups contain parameters related to the distributed I/O bus, which is used with some drives for monitoring the cooling fans of the cabinet system. For details, refer to ACS880 distributed I/O bus supplement (3AXD50000126880 [English]).



# Additional parameter data

## Contents of this chapter

This chapter lists the parameters with some additional data. For parameter descriptions, see chapter Parameters (page 117).

#### Terms and abbreviations

Term	Definition
FbEq32	32-bit fieldbus equivalent: The scaling between the integer used in communication and the value shown on the panel when a 32-bit value is selected for transmission to an external system.  The corresponding 16-bit scaling are listed in chapter <i>Parameters</i> (page <i>117</i> ).
int16	16-bit integer value (15 bits + sign).
int32	32-bit integer value (31 bits + sign).
No.	Parameter number.
real32	32-bit floating point number.
uint16	16-bit unsigned integer.
uint32	32-bit unsigned integer.
Туре	Parameter type. See int16, int32, real32, uint16, uint32.

### Fieldbus addresses

Refer to the User's Manual of the fieldbus adapter.

# Parameter groups 1...9

No.	Name	Туре	Range	Unit	FbEq32		
01 Act	01 Actual values						
01.01	Motor speed used	real32	-30000.00 30000.00	rpm	100 = 1 rpm		
01.02	Motor speed estimated	real32	-30000.0030000.00	rpm	100 = 1 rpm		
01.03	Motor speed%	real32	-1000.001000.00	%	100 = 1%		
01.04	Encoder 1 speed filtered	real32	-30000.0030000.00	rpm	100 = 1 rpm		
01.05	Encoder 2 speed filtered	real32	-30000.0030000.00	rpm	100 = 1 rpm		
01.06	Output frequency	real32	-500.00500.00	Hz	100 = 1 Hz		
01.07	Motor current	real32	0.0030000.00	Α	100 = 1 A		
01.08	Motor current% of motor nom	real32	0.0 1000.0	%	10 = 1%		
01.10	Motor torque	real32	-1600.01600.0	%	10 = 1%		
01.11	DC voltage	real32	0.00 2000.00	V	100 = 1 V		
01.13	Output voltage	real32	02000	V	1 = 1 V		
01.14	Output power	real32	-32768.0032767.00	kW or hp	100 = 1 unit		
01.15	Output power% of motor nom	real32	-300.00300.00	%	10 = 1%		
01.17	Motor shaft power	real32	-32768.0032767.00	kW or hp	100 = 1 unit		
01.18	Inverter GWh motoring	int16	032767	GWh	1 = 1 GWh		
01.19	Inverter MWh motoring	int16	01000	MWh	1 = 1 MWh		
01.20	Inverter kWh motoring	real32	01000	kWh	1 = 1 kWh		
01.21	U-phase current	real32	-30000.00 30000.00	Α	100 = 1 A		
01.22	V-phase current	real32	-30000.00 30000.00	Α	100 = 1 A		
01.23	W-phase current	real32	-30000.00 30000.00	Α	100 = 1 A		
01.24	Flux actual%	real32	0200	%	1 = 1%		
01.25	INU momentary cos fii	real32	-1.001.00	-	100 = 1		
01.29	Speed change rate	real32	-1500015000	rpm/s	1 = 1 rpm/s		
01.30	Nominal torque scale	uint32	0.0004000000.000	N•m or lb.ft	1000 = 1 unit		
01.31	Ambient temperature	real32	-40120	°C or °F	10 = 1 °		
01.32	Inverter GWh regenerating	int16	032767	GWh	1 = 1 GWh		
01.33	Inverter MWh regenerating	int16	01000	MWh	1 = 1 MWh		
01.34	Inverter kWh regenerating	real32	01000	kWh	1 = 1 kWh		
01.35	Mot - regen energy GWh	int16	-32768 32767	GWh	1 = 1 GWh		
01.36	Mot - regen energy MWh	int16	-10001000	MWh	1 = 1 MWh		
01.37	Mot - regen energy kWh	real32	-10001000	kWh	1 = 1 kWh		
01.61	Abs motor speed used	real32	0.00 30000.00	rpm	100 = 1 rpm		
01.62	Abs motor speed%	real32	0.00 1000.00	%	100 = 1%		
01.63	Abs output frequency	real32	0.00 500.00	Hz	100 = 1 Hz		
01.64	Abs motor torque	real32	0.0 1600.0	%	10 = 1%		

No.	Name	Туре	Range	Unit	FbEq32
01.65	Abs output power	real32	0.00 32767.00	kW or hp	100 = 1 unit
01.66	Abs output power% motor nom	real32	0.00 300.00	%	10 = 1%
01.68	Abs motor shaft power	real32	0.00 32767.00	kW or hp	100 = 1 unit
01.70	Ambient temperature%	real32	-200.00 200.00	%	100 = 1%
01.71	Step-up motor current	real32	0.0030000.00	Α	100 = 1 A
01.72	U-phase RMS current	real32	0.0030000.00	Α	100 = 1 A
01.73	V-phase RMS current	real32	0.0030000.00	Α	100 = 1 A
01.74	W-phase RMS current	real32	0.0030000.00	Α	100 = 1 A
(F	Parameters 01.10201.164 (	only visible	when IGBT supply unit control	activated b	y 95.20)
01.102	Line current	real32	0.00 30000.00	Α	100 = 1 A
01.104	Active current	real32	0.00 30000.00	Α	100 = 1 A
01.106	Reactive current	real32	0.00 30000.00	Α	100 = 1 A
01.108	Grid frequency	real32	0.00 100.00	Hz	100 = 1 Hz
01.109	Grid voltage	real32	0.00 2000.00	V	100 = 1 V
01.110	Grid apparent power	real32	-30000.00 30000.00	kVA	100 = 1 kVA
01.112	Grid power	real32	-30000.00 30000.00	kW	100 = 1 kW
01.114	Grid reactive power	real32	-30000.00 30000.00	kvar	100 = 1 kvar
01.116	LSU cos ?	real32	-1.00 1.00	-	100 = 1
01.164	LSU nominal power	real32	030000	kW	1 = 1 kW
03 Inpu	ıt references				<u> </u>
03.01	Panel reference	real32	-100000.00100000.00	-	100 = 1
03.02	Panel reference 2	real32	-30000.0030000.00	-	100 = 1
03.05	FB A reference 1	real32	-100000.00100000.00	-	100 = 1
03.06	FB A reference 2	real32	-100000.00100000.00	-	100 = 1
03.07	FB B reference 1	real32	-100000.00100000.00	-	100 = 1
03.08	FB B reference 2	real32	-100000.00100000.00	-	100 = 1
03.09	EFB reference 1	real32	-30000.00 30000.00	-	100 = 1
03.10	EFB reference 2	real32	-30000.00 30000.00	-	100 = 1
03.30	FB A reference 1 int32	int32	-21474836482147483647	-	1 = 1
03.31	FB A reference 2 int32	int32	-21474836482147483647	-	1 = 1
03.51	IEC application panel reference	real32	-100000.0 100000.0	-	1 = 1
04 War	nings and faults				
04.01	Tripping fault	uint16	0000hFFFFh	-	1 = 1
04.02	Active fault 2	uint16	0000hFFFFh	-	1 = 1
04.03	Active fault 3	uint16	0000hFFFFh	-	1 = 1
04.04	Active fault 4	uint16	0000hFFFFh	-	1 = 1
04.05	Active fault 5	uint16	0000hFFFFh	-	1 = 1
04.06	Active warning 1	uint16	0000hFFFFh	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32
04.07	Active warning 2	uint16	0000hFFFFh	-	1 = 1
04.08	Active warning 3	uint16	0000hFFFFh	-	1 = 1
04.09	Active warning 4	uint16	0000hFFFFh	-	1 = 1
04.10	Active warning 5	uint16	0000hFFFFh	-	1 = 1
04.11	Latest fault	uint16	0000hFFFFh	-	1 = 1
04.12	2nd latest fault	uint16	0000hFFFFh	-	1 = 1
04.13	3rd latest fault	uint16	0000hFFFFh	-	1 = 1
04.14	4th latest fault	uint16	0000hFFFFh	-	1 = 1
04.15	5th latest fault	uint16	0000hFFFFh	-	1 = 1
04.16	Latest warning	uint16	0000hFFFFh	-	1 = 1
04.17	2nd latest warning	uint16	0000hFFFFh	-	1 = 1
04.18	3rd latest warning	uint16	0000hFFFFh	-	1 = 1
04.19	4th latest warning	uint16	0000hFFFFh	-	1 = 1
04.20	5th latest warning	uint16	0000hFFFFh	-	1 = 1
04.21	Fault word 1	uint16	0000hFFFFh	-	1 = 1
04.22	Fault word 2	uint16	0000hFFFFh	-	1 = 1
	(Parameter	04.25 only	visible with a BCU control unit)		
04.25	Faulted modules	uint16	0000hFFFFh	-	1 = 1
04.31	Warning word 1	uint16	0000hFFFFh	-	1 = 1
04.32	Warning word 2	uint16	0000hFFFFh	-	1 = 1
04.40	Event word 1	uint16	0000hFFFFh	-	1 = 1
04.41	Event word 1 bit 0 code	uint16	0000hFFFFh	-	1 = 1
04.42	Event word 1 bit 0 aux code	uint32	0000 0000h FFFF FFFFh	-	1 = 1
04.43	Event word 1 bit 1 code	uint16	0000hFFFFh	-	1 = 1
04.44	Event word 1 bit 1 aux code	uint32	0000 0000h FFFF FFFFh	-	1 = 1
04.71	Event word 1 bit 15 code	uint16	0000hFFFFh	-	1 = 1
04.72	Event word 1 bit 15 aux code	uint32	0000 0000h FFFF FFFFh	-	1 = 1
04.120	Fault/Warning word compatibility	uint16	01	1	1 = 1
05 Diag	nostics				
05.01	On-time counter	uint16	065535	d	1 = 1 d
05.02	Run-time counter	uint16	065535	d	1 = 1 d
05.04	Fan on-time counter	uint16	065535	d	1 = 1 d
05.09	Time from power-up	uint32	04294967295	-	1 = 1
05.11	Inverter temperature	real32	-40.0160.0	%	10 = 1%
05.22	Diagnostic word 3	uint16	0000hFFFFh	-	1 = 1
05.41	Main fan service counter	real32	0150	%	1 = 1%
05.42	Aux. fan service counter	real32	0150	%	1 = 1%

No.	Name	Type	Range	Unit	FbEq32					
(	(Parameters 05.11105.121 c	only visible	when IGBT supply unit control	activated b	y 95.20)					
05.111	Line converter temperature	real32	-40.0 160.0	%	10 = 1%					
05.121	MCB closing counter	uint32	04294967295	%	1 = 1					
06 Cor	06 Control and status words									
06.01	Main control word	uint16	0000hFFFFh	-	1 = 1					
06.02	Application control word	uint16	0000hFFFFh	-	1 = 1					
06.03	FBA A transparent control word	uint32	00000000hFFFFFFFh	-	1 = 1					
06.04	FBA B transparent control word	uint32	00000000hFFFFFFFh	-	1 = 1					
06.05	EFB transparent control word	uint32	00000000hFFFFFFFh	-						
06.11	Main status word	uint16	0000hFFFFh	-	1 = 1					
06.16	Drive status word 1	uint16	0000hFFFFh	-	1 = 1					
06.17	Drive status word 2	uint16	0000hFFFFh	-	1 = 1					
06.18	Start inhibit status word	uint16	0000hFFFFh	-	1 = 1					
06.19	Speed control status word	uint16	0000hFFFFh	-	1 = 1					
06.20	Constant speed status word	uint16	0000hFFFFh	-	1 = 1					
06.21	Drive status word 3	uint16	0000hFFFFh	-	1 = 1					
06.25	Drive inhibit status word 2	uint16	0000hFFFFh	-	1 = 1					
06.29	MSW bit 10 sel	uint32	-	-	1 = 1					
06.30	MSW bit 11 sel	uint32	-	-	1 = 1					
06.31	MSW bit 12 sel	uint32	-	-	1 = 1					
06.32	MSW bit 13 sel	uint32	-	-	1 = 1					
06.33	MSW bit 14 sel	uint32	-	-	1 = 1					
	(Parameters 06.3606.43	only visibl	e when supply unit control activ	ated by 95	5.20)					
06.36	LSU Status Word	uint16	0000hFFFFh	-	1 = 1					
06.39	Internal state machine LSU CW	uint16	0000hFFFFh	-	1 = 1					
06.40	LSU CW user bit 0 selection	uint32	-	-	1 = 1					
06.41	LSU CW user bit 1 selection	uint32	-	-	1 = 1					
06.42	LSU CW user bit 2 selection	uint32	-	-	1 = 1					
06.43	LSU CW user bit 3 selection	uint32	-	-	1 = 1					
06.50	User status word 1	uint16	0000hFFFFh	-	1 = 1					
06.60	User status word 1 bit 0 sel	uint32	-	-	1 = 1					
06.61	User status word 1 bit 1 sel	uint32	-	-	1 = 1					

No.	Name	Туре	Range	Unit	FbEq32
06.62	User status word 1 bit 2 sel	uint32	-	-	1 = 1
06.63	User status word 1 bit 3 sel	uint32	-	-	1 = 1
06.64	User status word 1 bit 4 sel	uint32	-	-	1 = 1
06.65	User status word 1 bit 5 sel	uint32	-	-	1 = 1
06.66	User status word 1 bit 6 sel	uint32	-	-	1 = 1
06.67	User status word 1 bit 7 sel	uint32	-	-	1 = 1
06.68	User status word 1 bit 8 sel	uint32	-	-	1 = 1
06.69	User status word 1 bit 9 sel	uint32	-	-	1 = 1
06.70	User status word 1 bit 10 sel	uint32	-	-	1 = 1
06.71	User status word 1 bit 11 sel	uint32	-	-	1 = 1
06.72	User status word 1 bit 12 sel	uint32	-	-	1 = 1
06.73	User status word 1 bit 13 sel	uint32	-	-	1 = 1
06.74	User status word 1 bit 14 sel	uint32	-	-	1 = 1
06.75	User status word 1 bit 15 sel	uint32	-	-	1 = 1
06.100	User control word 1	uint16	0000hFFFFh	-	1 = 1
06.101	User control word 2	uint16	0000hFFFFh	-	1 = 1
(1	Parameters 06.11606.118	only visible	when IGBT supply unit control	activated b	y 95.20)
06.116	LSU drive status word 1	uint16	0000hFFFFh	-	1 = 1
06.118	LSU start inhibit status word	uint16	0000hFFFFh	-	1 = 1
07 Sys	tem info				
07.03	Drive rating id	uint16	-	-	1 = 1
07.04	Firmware name	uint32	-	-	1 = 1
07.05	Firmware version	uint32	-	-	1 = 1
07.06	Loading package name	uint32	-	-	1 = 1
07.07	Loading package version	uint32	-	-	1 = 1
07.08	Bootloader version	uint32	-	-	1 = 1
07.11	Cpu usage	uint32	0100	%	1 = 1%
07.13	PU logic version number	uint16	-	-	1 = 1
07.15	FPGA logic version number	uint16	0000hFFFFh	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32
	(Parameters 07.2107.24 o	nly visible v	vith option +N8010 [application	programm	ability])
07.21	Application environment status 1	uint16	0000hFFFFh	-	1 = 1
07.22	Application environment status 2	uint16	0000hFFFFh	-	1 = 1
07.23	Application name	uint32	-	-	1 = 1
07.24	Application version	uint32	-	-	1 = 1
07.25	Customization package name	uint32	-	-	1 = 1
07.26	Customization package version	uint32	-	-	1 = 1
07.30	Adaptive program status	uint16	0000hFFFFh	-	1 = 1
	(Parameters 07.4007.41 o	nly visible v	vith option +N8010 [application	programm	ability])
07.40	IEC application Cpu usage peak	real32	0.0 100.0	%	10 = 1%
07.41	IEC application Cpu load average	real32	0.0 100.0	%	10 = 1%
07.51	Slot 1 option module	uint16	-	-	1 = 1
07.52	Slot 2 option module	uint16	-	-	1 = 1
07.53	Slot 3 option module	uint16	-	-	1 = 1
(F	Parameters 07.10607.107	only visible	when IGBT supply unit control	activated b	y 95.20)
07.106	LSU loading package name	uint32	-	-	1 = 1
07.107	LSU loading package version	uint32	-	-	1 = 1
09 Pun	np actuals				
09.01	Rod torque	real32	-100000.00100000.00	N•m or lbft	100 = 1 Nm or lbft
09.02	Maximum rod torque	real32	-100000.00100000.00	N•m or lbft	100 = 1 Nm or lbft
09.03	Motor torque	real32	-100000.00100000.00	N•m or lbft	100 = 1 Nm or lbft
09.04	Maximum motor torque	real32	-100000.00100000.00	N•m or lbft	100 = 1 Nm or lbft
09.05	Rod speed	real32	-100000.00100000.00	Prpm, rpm or Hz	100 = 1 Prpm, rpm or Hz
09.06	Motor speed reference	real32	-100000.00100000.00	rpm or Hz	100 = 1 rpm or Hz
09.07	Run-time hours	real32	0.00100000.00	h	100 = 1 h
09.08	Fluid level	real32	-100000.00100000.00	m, ft or Joints	100 = 1 m, ft or Joints
09.09	Pressure	real32	-100000.00100000.00	kPa or psi	100 = 1 kPa or psi
09.10	Measured temperature	real32	-100000.00100000.00	°C	100 = 1 °C

## 432 Additional parameter data

No.	Name	Туре	Range	Unit	FbEq32
09.11	Backspin speed reference	real32	-100000.00100000.00	Prpm, rpm or Hz	100 = 1 Prpm, rpm or Hz
09.12	Start delay remain	real32	04294967.295	s	1000 = 1 s
09.13	Backspin status word	uint16	0000hFFFFh	-	1 = 1
09.14	Pump status word	uint16	0000hFFFFh	-	1 = 1
09.15	Sleep feedback value	real32	-100000.00100000.00	Source Unit	100 = 1 SourceUnit
09.16	Sleep time	real32	0.00010000.000	s	1000 = 1 s
09.17	Backspin operation	uint32	-	-	1 = 1
09.18	Fault word 1	uint16	0000hFFFFh	-	1 = 1
09.19	Fault word 2	uint16	0000hFFFFh	-	1 = 1
09.20	Application status word	uint16	0000hFFFFh	-	1 = 1
09.70	Inverter kWh motoring	real32	01000	kWh	1 = 1

## Parameter groups 10...99

No.	Name	Туре	Range	Unit	FbEq32					
10 Sta	10 Standard DI, RO									
10.01	DI status	uint16	0000hFFFFh	-	1 = 1					
10.02	DI delayed status	uint16	0000hFFFFh	-	1 = 1					
10.03	DI force selection	uint16	0000hFFFFh	-	1 = 1					
10.04	DI force data	uint16	0000hFFFFh	-	1 = 1					
10.05	DI1 ON delay	uint32	0.03000.0	S	10 = 1 s					
10.06	DI1 OFF delay	uint32	0.03000.0	S	10 = 1 s					
10.07	DI2 ON delay	uint32	0.03000.0	S	10 = 1 s					
10.08	DI2 OFF delay	uint32	0.03000.0	s	10 = 1 s					
10.09	DI3 ON delay	uint32	0.03000.0	s	10 = 1 s					
10.10	DI3 OFF delay	uint32	0.03000.0	s	10 = 1 s					
10.11	DI4 ON delay	uint32	0.03000.0	s	10 = 1 s					
10.12	DI4 OFF delay	uint32	0.03000.0	s	10 = 1 s					
10.13	DI5 ON delay	uint32	0.03000.0	s	10 = 1 s					
10.14	DI5 OFF delay	uint32	0.03000.0	S	10 = 1 s					
10.15	DI6 ON delay	uint32	0.03000.0	S	10 = 1 s					
10.16	DI6 OFF delay	uint32	0.03000.0	s	10 = 1 s					
10.21	RO status	uint16	0000hFFFFh	-	1 = 1					
10.24	RO1 source	uint32	-	-	1 = 1					
10.25	RO1 ON delay	uint32	0.03000.0	s	10 = 1 s					
10.26	RO1 OFF delay	uint32	0.03000.0	s	10 = 1 s					
10.27	RO2 source	uint32	-	-	1 = 1					
10.28	RO2 ON delay	uint32	0.03000.0	s	10 = 1 s					
10.29	RO2 OFF delay	uint32	0.03000.0	s	10 = 1 s					
10.30	RO3 source	uint32	-	-	1 = 1					
10.31	RO3 ON delay	uint32	0.03000.0	s	10 = 1 s					
10.32	RO3 OFF delay	uint32	0.03000.0	s	10 = 1 s					
10.51	DI filter time	uint32	0.3100.0	ms	10 = 1 ms					
10.99	RO/DIO control word	uint16	0000hFFFFh	-	1 = 1					
11 Sta	indard DIO, FI, FO									
11.01	DIO status	uint16	0000b0011b	-	1 = 1					
11.02	DIO delayed status	uint16	0000b0011b	-	1 = 1					
11.05	DIO1 function	uint16	02	-	1 = 1					
11.06	DIO1 output source	uint32	-		1 = 1					
11.07	DIO1 ON delay	uint32	0.03000.0	s	10 = 1 s					
11.08	DIO1 OFF delay	uint32	0.03000.0	s	10 = 1 s					
11.09	DIO2 function	uint16	02	-	1 = 1					
11.10	DIO2 output source	uint32	-		1 = 1					
11.11	DIO2 ON delay	uint32	0.03000.0	s	10 = 1 s					

No.	Name	Туре	Range	Unit	FbEq32
11.12	DIO2 OFF delay	uint32	0.03000.0	S	10 = 1 s
11.38	Freq in 1 actual value	real32	016000	Hz	1 = 1 Hz
11.39	Freq in 1 scaled	real32	-32768.00032767.000	-	1000 = 1
11.42	Freq in 1 min	real32	016000	Hz	1 = 1 Hz
11.43	Freq in 1 max	real32	016000	Hz	1 = 1 Hz
11.44	Freq in 1 at scaled min	real32	-32768.00032767.000	-	1000 = 1
11.45	Freq in 1 at scaled max	real32	-32768.00032767.000	-	1000 = 1
11.54	Freq out 1 actual value	real32	016000	Hz	1 = 1 Hz
11.55	Freq out 1 source	uint32	-	-	1 = 1
11.58	Freq out 1 src min	real32	-32768.00032767.000	-	1000 = 1
11.59	Freq out 1 src max	real32	-32768.00032767.000	-	1000 = 1
11.60	Freq out 1 at src min	real32	016000	Hz	1 = 1 Hz
11.61	Freq out 1 at src max	real32	016000	Hz	1 = 1 Hz
11.81	DIO filter time	uint32	0.3 100.0	ms	10 = 1 ms
12 Sta	ndard Al				
12.01	Al tune	uint16	04	-	
12.03	Al supervision function	uint16	04	-	1 = 1
12.04	Al supervision selection	uint16	0000hFFFFh	-	1 = 1
12.05	Al supervision force	uint16	0000hFFFFh	-	1 = 1
12.11	Al1 actual value	real32	-22.00022.000	V or mA	1000 = 1 unit
12.12	Al1 scaled value	real32	-32768.00032767.000	-	1000 = 1
12.15	Al1 unit selection	uint16	-	-	1 = 1
12.16	Al1 filter time	real32	0.00030.000	S	1000 = 1 s
12.17	Al1 min	real32	-22.00022.000	mA or V	1000 = 1 mA or V
12.18	Al1 max	real32	-22.00022.000	mA or V	1000 = 1 mA or V
12.19	Al1 scaled at Al1 min	real32	-32768.00032767.000	-	1000 = 1
12.20	Al1 scaled at Al1 max	real32	-32768.00032767.000	-	1000 = 1
12.21	Al2 actual value	real32	-22.00022.000	mA or V	1000 = 1 mA or V
12.22	Al2 scaled value	real32	-32768.00032767.000	-	1000 = 1
12.25	Al2 unit selection	uint16	-	-	1 = 1
12.26	Al2 filter time	real32	0.00030.000	s	1000 = 1 s
12.27	Al2 min	real32	-22.00022.000	mA or V	1000 = 1 mA or V
12.28	Al2 max	real32	-22.00022.000	mA or V	1000 = 1 mA or V
12.29	Al2 scaled at Al2 min	real32	-32768.00032767.000	-	1000 = 1
12.30	Al2 scaled at Al2 max	real32	-32768.00032767.000	-	1000 = 1
13 Sta	ndard AO				
13.11	AO1 actual value	real32	0.00022.000	mA	1000 = 1 mA

No.	Name	Туре	Range	Unit	FbEq32
13.12	AO1 source	uint32	-	-	1 = 1
13.16	AO1 filter time	real32	0.00030.000	s	1000 = 1 s
13.17	AO1 source min	real32	-32768.032767.0	-	10 = 1
13.18	AO1 source max	real32	-32768.032767.0	-	10 = 1
13.19	AO1 out at AO1 src min	real32	0.00022.000	mA	1000 = 1 mA
13.20	AO1 out at AO1 src max	real32	0.00022.000	mA	1000 = 1 mA
13.21	AO2 actual value	real32	0.00022.000	mA	1000 = 1 mA
13.22	AO2 source	uint32	-	-	1 = 1
13.26	AO2 filter time	real32	0.00030.000	S	1000 = 1 s
13.27	AO2 source min	real32	-32768.032767.0	-	10 = 1
13.28	AO2 source max	real32	-32768.032767.0	-	10 = 1
13.29	AO2 out at AO2 src min	real32	0.00022.000	mA	1000 = 1 mA
13.30	AO2 out at AO2 src max	real32	0.00022.000	mA	1000 = 1 mA
13.91	AO1 data storage	real32	-327.68 327.67	-	100 = 1
13.92	AO2 data storage	real32	-327.68 327.67	-	100 = 1
14 I/O	extension module 1				
14.01	Module 1 type	uint16	04	-	1 = 1
14.02	Module 1 location	uint16	1254	-	1 = 1
14.03	Module 1 status	uint16	04	-	1 = 1
	Dlx	(14.01 Mc	odule 1 type = FIO-01)		
14.05	DI status	uint16	00000000hFFFFFFFh	-	1 = 1
14.06	DI delayed status	uint16	00000000hFFFFFFFh	-	1 = 1
14.08	DI filter time	real32	0.8 100.0	ms	10 = 1 ms
14.12	DI1 ON delay	real32	0.00 3000.00	S	100 = 1 s
14.13	DI1 OFF delay	real32	0.00 3000.00	S	100 = 1 s
14.17	DI2 ON delay	real32	0.00 3000.00	S	100 = 1 s
14.18	DI2 OFF delay	real32	0.00 3000.00	s	100 = 1 s
14.22	DI3 ON delay	real32	0.00 3000.00	s	100 = 1 s
14.23	DI3 OFF delay	real32	0.00 3000.00	s	100 = 1 s
	Common parameters	for DIOx (1	14.01 Module 1 type = FIO-01	or <i>FIO-11</i> )	
14.05	DIO status	uint16	0000b1111b	-	1 = 1
14.06	DIO delayed status	uint16	0000b1111b	-	1 = 1
	DIO1/DIO2 (	14.01 Mod	lule 1 type = FIO-01 or FIO-11	1)	
14.08	DIO filter time	real32	0.8100.0	ms	10 = 1 ms
14.09	DIO1 function	uint16	01	-	1 = 1
14.11	DIO1 output source	uint32	-	-	1 = 1
14.12	DIO1 ON delay	real32	0.003000.00	S	10 = 1 s
14.13	DIO1 OFF delay	real32	0.03000.0	S	10 = 1 s
14.14	DIO2 function	uint16	01	-	1 = 1
14.16	DIO2 output source	uint32	-	-	1 = 1
14.17	DIO2 ON delay	real32	0.03000.0	S	10 = 1 s

No.	Name	Туре	Range	Unit	FbEq32				
14.18	DIO2 OFF delay	real32	0.03000.0	s	10 = 1 s				
	DIO3/DIO4 (14.01 Module 1 type = FIO-01)								
14.19	DIO3 function	uint16	01	-	1 = 1				
14.21	DIO3 output source	uint32	-	-	1 = 1				
14.22	DIO3 ON delay	real32	0.003000.00	S	10 = 1 s				
14.23	DIO3 OFF delay	real32	0.003000.00	S	10 = 1 s				
14.24	DIO4 function	uint16	01	-	1 = 1				
14.26	DIO4 output source	uint32	-	-	1 = 1				
14.27	DIO4 ON delay	real32	-32768.00032767.000	s	10 = 1 s				
14.28	DIO4 OFF delay	real32	0.03000.0	s	10 = 1 s				
	RO1/R	O2 (14.01	Module 1 type = FIO-01)						
14.31	RO status	uint16	0000hFFFFh	-	1 = 1				
14.34	RO1 source	uint32	-	-	1 = 1				
14.35	RO1 ON delay	real32	0.03000.0	s	10 = 1 s				
14.36	RO1 OFF delay	real32	0.03000.0	s	10 = 1 s				
14.37	RO2 source	uint32	-	-	1 = 1				
14.38	RO2 ON delay	real32	0.03000.0	s	10 = 1 s				
14.39	RO2 OFF delay	real32	0.03000.0	s	10 = 1 s				
	Common parameter t	or Alx (14.	01 Module 1 type = FIO-11 or	FAIO-01)					
14.19	Al supervision function	uint16	04	-	1 = 1				
14.20	Al supervision selection	uint16	0000hFFFFh	-	1 = 1				
14.21	Al tune	uint16	06 (FIO-11 or FAIO-01)		1 = 1				
14.22	Al force selection	uint16	0000hFFFFh	-	1 = 1				
	AI1/AI2 (14	.01 Module	e 1 type = FIO-11 or FAIO-01)						
14.26	Al1 actual value	real32	-22.00022.000	mA or V	1000 = 1 unit				
14.27	Al1 scaled value	real32	-32768.00032767.000	-	1000 = 1				
14.28	Al1 force data	real32	-22.00022.000	mA or V	1000 = 1 unit				
14.29	Al1 HW switch pos	uint16	-	-	1 = 1				
14.30	Al1 unit selection	uint16	-	-	1 = 1				
14.31	Al1 filter gain	uint16	07	-	1 = 1				
14.32	Al1 filter time	real32	0.00030.000	S	1000 = 1 s				
14.33	Al1 min	real32	-22.00022.000	mA or V	1000 = 1 mA or V				
14.34	Al1 max	real32	-22.00022.000	mA or V	1000 = 1 mA or V				
14.35	Al1 scaled at Al1 min	real32	-32768.00032767.000	-	1000 = 1				
14.36	Al1 scaled at Al1 max	real32	-32768.00032767.000	-	1000 = 1				
14.41	Al2 actual value	real32	-22.00022.000	mA or V	1000 = 1 unit				
14.42	Al2 scaled value	real32	-32768.00032767.000	-	1000 = 1				
14.43	Al2 force data	real32	-22.00022.000	mA or V	1000 = 1 unit				
14.44	Al2 HW switch pos	uint16	-	-	1 = 1				
14.45	Al2 unit selection	uint16	-	-	1 = 1				

No.	Name	Туре	Range	Unit	FbEq32
14.46	Al2 filter gain	uint16	07	-	1 = 1
14.47	Al2 filter time	real32	0.00030.000	s	1000 = 1 s
14.48	Al2 min	real32	-22.00022.000	mA or V	1000 = 1 mA or V
14.49	Al2 max	real32	-22.00022.000	mA or V	1000 = 1 mA or V
14.50	Al2 scaled at Al2 min	real32	-32768.00032767.000	-	1000 = 1
14.51	Al2 scaled at Al2 max	real32	-32768.00032767.000	-	1000 = 1
	AI3	(14.01 Mo	dule 1 type = FIO-11)	•	
14.56	Al3 actual value	real32	-22.00022.000	mA or V	1000 = 1 unit
14.57	Al3 scaled value	real32	-32768.00032767.000	-	1000 = 1
14.58	Al3 force data	real32	-22.00022.000	mA or V	1000 = 1 unit
14.59	AI3 HW switch pos	uint16	-	-	1 = 1
14.60	Al3 unit selection	uint16	-	-	1 = 1
14.61	Al3 filter gain	uint16	07	-	1 = 1
14.62	Al3 filter time	real32	0.00030.000	s	1000 = 1 s
14.63	Al3 min	real32	-22.00022.000	mA or V	1000 = 1 mA or V
14.64	Al3 max	real32	-22.00022.000	mA or V	1000 = 1 mA or V
14.65	Al3 scaled at Al3 min	real32	-32768.00032767.000	-	1000 = 1
14.66	Al3 scaled at Al3 max	real32	-32768.00032767.000	-	1000 = 1
	Common parameters t	or AOx (14	4.01 Module 1 type = FIO-11 o	or <i>FAIO-01</i> )	•
14.71	AO force selection	uint16	00000000hFFFFFFFh	-	1 = 1
	AO1 (14.0	1 Module	1 type = FIO-11 or FAIO-01)		
14.76	AO1 actual value	real32	0.00022.000	mA	1000 = 1 mA
14.77	AO1 source	uint32	-	-	1 = 1
14.78	AO1 force data	real32	0.00022.000	mA	1000 = 1 mA
14.79	AO1 filter time	real32	0.00030.000	s	1000 = 1 s
14.80	AO1 source min	real32	-32768.032767.0	-	10 = 1
14.81	AO1 source max	real32	-32768.032767.0	-	10 = 1
14.82	AO1 out at AO1 src min	real32	0.00022.000	mA	1000 = 1 mA
14.83	AO1 out at AO1 src max	real32	0.00022.000	mA	1000 = 1 mA
	AO2	(14.01 Mo	dule 1 type = FAIO-01)		
14.86	AO2 actual value	real32	0.00022.000	mA	1000 = 1 mA
14.87	AO2 source	uint32	-	-	1 = 1
14.88	AO2 force data	real32	0.00022.000	mA	1000 = 1 mA
14.89	AO2 filter time	real32	0.00030.000	s	1000 = 1 s
14.90	AO2 source min	real32	-32768.032767.0	-	10 = 1
14.91	AO2 source max	real32	-32768.032767.0	-	10 = 1
14.92	AO2 out at AO2 src min	real32	0.00022.000	mA	1000 = 1 mA
14.93	AO2 out at AO2 src max	real32	0.00022.000	mA	1000 = 1 mA

No.	Name	Туре	Range	Unit	FbEq32				
15 I/O	15 I/O extension module 2								
15.01	Module 2 type	uint16	04	-	1 = 1				
15.02	Module 2 location	uint16	1254	-	1 = 1				
15.03	Module 2 status	uint16	02	-	1 = 1				
	Dlx (	15.01 Mod	dule 2 type = FDIO-01)	•	•				
15.05	DI status	uint16	00000000hFFFFFFFh	-	1 = 1				
15.06	DI delayed status	uint16	00000000hFFFFFFFh	-	1 = 1				
15.08	DI filter time	real32	0.8 100.0	ms	10 = 1 ms				
15.12	DI1 ON delay	real32	0.00 3000.00	S	100 = 1 s				
15.13	DI1 OFF delay	real32	0.00 3000.00	S	100 = 1 s				
15.17	DI2 ON delay	real32	0.00 3000.00	S	100 = 1 s				
15.18	DI2 OFF delay	real32	0.00 3000.00	S	100 = 1 s				
15.22	DI3 ON delay	real32	0.00 3000.00	S	100 = 1 s				
15.23	DI3 OFF delay	real32	0.00 3000.00	S	100 = 1 s				
	Common parameters f	or DIOx (1	5.01 Module 2 type = FIO-01	or <i>FIO-11</i> )	•				
15.05	DIO status	uint16	00000000hFFFFFFFh	-	1 = 1				
15.06	DIO delayed status	uint16	00000000hFFFFFFFh	-	1 = 1				
	DIO1/DIO2 (	15.01 Moa	lule 2 type = FIO-01 or FIO-1:	1)	•				
15.08	DIO filter time	real32	0.8100.0	ms	10 = 1 ms				
15.09	DIO1 function	uint16	01	-	1 = 1				
15.11	DIO1 output source	uint32	-	-	1 = 1				
15.12	DIO1 ON delay	real32	0.003000.00	S	100 = 1 s				
15.13	DIO1 OFF delay	real32	0.003000.00	S	100 = 1 s				
15.14	DIO2 function	uint16	01	-	1 = 1				
15.16	DIO2 output source	uint32	-	-	1 = 1				
15.17	DIO2 ON delay	real32	0.003000.00	S	100 = 1 s				
15.18	DIO2 OFF delay	real32	0.003000.00	S	100 = 1 s				
	DIO3/DI	O4 (15.01	Module 2 type = FIO-01)						
15.19	DIO3 configuration	uint16	01	-	1 = 1				
15.21	DIO3 output source	uint32	-	-	1 = 1				
15.22	DIO3 ON delay	real32	0.003000.00	s	100 = 1 s				
15.23	DIO3 OFF delay	real32	0.003000.00	s	100 = 1 s				
15.24	DIO4 configuration	uint16	01	-	1 = 1				
15.26	DIO4 output source	uint32	-	-	1 = 1				
15.27	DIO4 ON delay	real32	0.003000.00	S	100 = 1 s				
15.28	DIO4 OFF delay	real32	0.003000.00	s	100 = 1 s				
	RO1/Re	O2 ( <u>15</u> .01	Module 2 type = FIO-01)						
15.31	RO status	uint16	0000hFFFFh	-	1 = 1				
15.34	RO1 source	uint32	-	-	1 = 1				
15.35	RO1 ON delay	real32	0.003000.00	s	100 = 1 s				
15.36	RO1 OFF delay	real32	0.003000.00	s	100 = 1 s				

No.	Name	Туре	Range	Unit	FbEq32			
15.37	RO2 source	uint32	-	-	1 = 1			
15.38	RO2 ON delay	real32	0.003000.00	s	100 = 1 s			
15.39	RO2 OFF delay	real32	0.003000.00	s	100 = 1 s			
Common parameters for Alx (15.01 Module 2 type = FIO-11 or FAIO-01)								
15.19	Al supervision function	uint16	04	-	1 = 1			
15.20	Al supervision selection	uint16	0000hFFFFh	-	1 = 1			
15.21	Al tune	uint16	0.6( <i>FIO-11</i> )	-	1 = 1			
			0.4( <i>FAIO-01</i> )					
15.22	Al force selection	uint16	00000000hFFFFFFFh	-	1 = 1			
	AI1/AI2 (1	5.01 Modul	e 2 type = FIO-11 or FAIO-01)	)				
15.26	Al1 actual value	real32	-22.00022.000	mA or V	1000 = 1 unit			
15.27	Al1 scaled value	real32	-32768.00032767.000	-	1000 = 1			
15.28	Al1 force data	real32	-22.00022.000	mA or V	1000 = 1 unit			
15.29	Al1 HW switch pos	uint16	-	-	1 = 1			
15.30	Al1 unit selection	uint16	-	-	1 = 1			
15.31	Al1 filter gain	uint16	07	-	1 = 1			
15.32	Al1 filter time	real32	0.00030.000	s	1000 = 1 s			
15.33	Al1 min	real32	-22.00022.000	mA or V	1000 = 1 mA or V			
15.34	Al1 max	real32	-22.00022.000	mA or V	1000 = 1 mA or V			
15.35	Al1 scaled at Al1 min	real32	-32768.00032767.000	-	1000 = 1			
15.36	Al1 scaled at Al1 max	real32	-32768.00032767.000	-	1000 = 1			
15.41	Al2 actual value	real32	-22.00022.000	mA or V	1000 = 1 unit			
15.42	Al2 scaled value	real32	-32768.00032767.000	-	1000 = 1			
15.43	Al2 force data	real32	-22.00022.000	mA or V	1000 = 1 unit			
15.44	Al2 HW switch position	uint16	-	-	1 = 1			
15.45	Al2 unit selection	uint16	-	-	1 = 1			
15.46	Al2 filter gain	uint16	07	-	1 = 1			
15.47	Al2 filter time	real32	0.00030.000	S	1000 = 1 s			
15.48	Al2 min	real32	-22.00022.000	mA or V	1000 = 1 mA or V			
15.49	Al2 max	real32	-22.00022.000	mA or V	1000 = 1 mA or V			
15.50	Al2 scaled at Al2 min	real32	-32768.00032767.000	-	1000 = 1			
15.51	Al2 scaled at Al2 max	real32	-32768.00032767.000	-	1000 = 1			
	AI3 (15.0	01 Module 2	2 type = FIO-11 or FAIO-01)	!	•			
15.56	Al3 actual value	real32	-22.00022.000	mA or V	1000 = 1 unit			
15.57	Al3 scaled value	real32	-32768.00032767.000	-	1000 = 1			
15.58	Al3 force data	real32	-22.00022.000	mA or V	1000 = 1 unit			
15.59	Al3 HW switch position	uint16	-	-	1 = 1			
15.60	Al3 unit selection	uint16	-	-	1 = 1			
15.61	Al3 filter gain	uint16	07	-	1 = 1			

No.	Name	Туре	Range	Unit	FbEq32
15.62	Al3 filter time	real32	0.00030.000	s	1000 = 1 s
15.63	Al3 min	real32	-22.00022.000	mA or V	1000 = 1 mA or V
15.64	Al3 max	real32	-22.00022.000	mA or V	1000 = 1 mA or V
15.65	Al3 scaled at Al3 min	real32	-32768.00032767.000	-	1000 = 1
15.66	Al3 scaled at Al3 max	real32	-32768.00032767.000	-	1000 = 1
	Common parameters f	or AOx (15	5.01 Module 2 type = FIO-11 c	or <i>FAIO-01</i> )	
15.71	AO force selection	uint16	00000000hFFFFFFFh	-	1 = 1
	AO1 (15.0	1 Module	2 type = FIO-11 or FAIO-01)		
15.76	AO1 actual value	real32	0.00022.000	mA	1000 = 1 mA
15.77	AO1 source	uint32	-	-	1 = 1
15.78	AO1 force data	real32	0.00022.000	mA	1000 = 1 mA
15.79	AO1 filter time	real32	0.00030.000	s	1000 = 1 s
15.80	AO1 source min	real32	-32768.032767.0	-	10 = 1
15.81	AO1 source max	real32	-32768.032767.0	-	10 = 1
15.82	AO1 out at AO1 src min	real32	0.00022.000	mA	1000 = 1 mA
15.83	AO1 out at AO1 src max	real32	0.00022.000	mA	1000 = 1 mA
	AO2 (15.0	1 Module	2 type = FIO-11 or FAIO-01)		
15.86	AO2 actual value	real32	0.00022.000	mA	1000 = 1 mA
15.87	AO2 source	uint32	-	-	1 = 1
15.88	AO2 force data	real32	0.00022.000	mA	1000 = 1 mA
15.89	AO2 filter time	real32	0.00030.000	s	1000 = 1 s
15.90	AO2 source min	real32	-32768.032767.0	-	10 = 1
15.91	AO2 source max	real32	-32768.032767.0	-	10 = 1
15.92	AO2 out at AO1 src min	real32	0.00022.000	mA	1000 = 1 mA
15.93	AO2 out at AO1 src max	real32	0.00022.000	mA	1000 = 1 mA
16 I/O	extension module 3				
16.01	Module 3 type	uint16	04	-	1 = 1
16.02	Module 3 location	real32	1254	-	1 = 1
16.03	Module 3 status	uint16	02	-	1 = 1
	DIx (	16.01 Mod	dule 3 type = FDIO-01)		
16.05	DI status	uint16	00000000hFFFFFFFh	-	1 = 1
16.06	DI delayed status	uint16	00000000hFFFFFFFh	-	1 = 1
16.08	DI filter time	real32	0.8 100.0	ms	10 = 1 ms
16.12	DI1 ON delay	real32	0.00 3000.00	s	100 = 1 s
16.13	DI1 OFF delay	real32	0.00 3000.00	s	100 = 1 s
16.17	DI2 ON delay	real32	0.00 3000.00	s	100 = 1 s
16.18	DI2 OFF delay	real32	0.00 3000.00	s	100 = 1 s
16.22	DI3 ON delay	real32	0.00 3000.00	s	100 = 1 s
16.23	DI3 OFF delay	real32	0.00 3000.00	s	100 = 1 s

No.	Name	Туре	Range	Unit	FbEq32			
Common parameters for DIOx (16.01 Module 3 type = FIO-01 or FIO-11)								
16.05	DIO status	uint16	00000000hFFFFFFFh	-	1 = 1			
16.06	DIO delayed status	uint16	00000000hFFFFFFFh	-	1 = 1			
	DIO1/DIO2 (	16.01 Mod	fule 3 type = FIO-01 or FIO-1:	1)				
16.08	DIO filter time	real32	0.8100.0	ms	10 = 1 ms			
16.09	DIO1 function	uint16	01	-	1 = 1			
16.11	DIO1 output source	uint32	-	-	1 = 1			
16.12	DIO1 ON delay	real32	0.00 3000.00	s	100 = 1 s			
16.13	DIO1 OFF delay	real32	0.00 3000.00	s	100 = 1 s			
16.14	DIO2 function	uint16	01	-	1 = 1			
16.16	DIO2 output source	uint32	-	-	1 = 1			
16.17	DIO2 ON delay	real32	0.00 3000.00	s	100 = 1 s			
16.18	DIO2 OFF delay	real32	0.00 3000.00	s	100 = 1 s			
	DIO3/D	IO4 (16.01	Module 3 type = FIO-01)					
16.19	DIO3 function	uint16	01	-	1 = 1			
16.21	DIO3 output source	uint32	-	-	1 = 1			
16.22	DIO3 ON delay	real32	0.003000.00	s	100 = 1 s			
16.23	DIO3 OFF delay	real32	0.003000.00	s	100 = 1 s			
16.24	DIO4 configuration	uint16	01	-	1 = 1			
16.26	DIO4 output source	uint32	-	-	1 = 1			
16.27	DIO4 ON delay	real32	0.003000.00	s	100 = 1 s			
16.28	DIO4 OFF delay	real32	0.003000.00	S	100 = 1 s			
	RIO1/RO2 (1	6.01 Modu	ile 3 type = FIO-01 or FDIO-0	1)				
16.31	RO status	uint16	0000hFFFFh	-	1 = 1			
16.34	RO1 source	uint32	-	-	1 = 1			
16.35	RO1 ON delay	real32	0.003000.00	s	100 = 1 s			
16.36	RO1 OFF delay	real32	0.003000.00	s	100 = 1 s			
16.37	RO2 source	uint32	-	-	1 = 1			
16.38	RO2 ON delay	real32	0.003000.00	s	100 = 1 s			
16.39	RO2 OFF delay	real32	0.003000.00	s	100 = 1 s			
	Common parameters	for Alx (16	.01 Module 3 type = FIO-11 o	r <i>FAIO-01</i> )				
16.19	Al supervision function	uint16	04	-	1 = 1			
16.20	Al supervision selection	uint16	0000hFFFFh	-	1 = 1			
16.21	Al tune	uint16	0.6( <i>FIO-11</i> )	-	1 = 1			
			0.4 (FAIO-01)					
16.22	Al force selection	uint16	00000000hFFFFFFFh	-	1 = 1			
			e 3 type = FIO-11 or FAIO-01)		T			
16.26	Al1 actual value	real32	-22.00022.000	mA or V	1000 = 1 unit			
16.27	Al1 scaled value	real32	-32768.00032767.000	-	1000 = 1			
16.28	Al1 force data	real32	-22.00022.000	mA or V	1000 = 1 unit			
16.29	Al1 HW switch position	uint16	-	-	1 = 1			

No.	Name	Туре	Range	Unit	FbEq32
16.30	Al1 unit selection	uint16	-	-	1 = 1
16.31	Al1 filter gain	uint16	07	-	1 = 1
16.32	Al1 filter time	real32	0.00030.000	s	1000 = 1 s
16.33	Al1 min	real32	-22.00022.000	mA or V	1000 = 1 mA or V
16.34	Al1 max	real32	-22.00022.000	mA or V	1000 = 1 mA or V
16.35	Al1 scaled at Al1 min	real32	-32768.00032767.000	-	1000 = 1
16.36	Al1 scaled at Al1 max	real32	-32768.00032767.000	-	1000 = 1
16.41	Al2 actual value	real32	-22.00022.000	mA or V	1000 = 1 unit
16.42	Al2 scaled value	real32	-32768.00032767.000	-	1000 = 1
16.43	Al2 force data	real32	-22.00022.000	mA or V	1000 = 1 unit
16.44	Al2 HW switch pos	uint16	-	-	1 = 1
16.45	Al2 unit selection	uint16	-	-	1 = 1
16.46	Al2 filter gain	uint16	07	-	1 = 1
16.47	Al2 filter time	real32	0.00030.000	s	1000 = 1 s
16.48	Al2 min	real32	-22.00022.000	mA or V	1000 = 1 mA or V
16.49	Al2 max	real32	-22.00022.000	mA or V	1000 = 1 mA or V
16.50	Al2 scaled at Al2 min	real32	-32768.00032767.000	-	1000 = 1
16.51	Al2 scaled at Al2 max	real32	-32768.00032767.000	-	1000 = 1
	AI13	(16.01 M	odule 3 type = FIO-11)	•	
16.56	Al3 actual value	real32	-22.00022.000	mA or V	1000 = 1 unit
16.57	Al3 scaled value	real32	-32768.00032767.000	-	1000 = 1
16.58	Al3 force data	real32	-22.00022.000	mA or V	1000 = 1 unit
16.59	Al3 HW switch position	uint16	-	-	1 = 1
16.60	Al3 unit selection	uint16	-	-	1 = 1
16.61	Al3 filter gain	uint16	07	-	1 = 1
16.62	Al3 filter time	real32	0.00030.000	S	1000 = 1 s
16.63	Al3 min	real32	-22.00022.000	mA or V	1000 = 1 mA or V
16.64	Al3 max	real32	-22.00022.000	mA or V	1000 = 1 mA or V
16.65	Al3 scaled at Al3 min	real32	-32768.00032767.000	-	1000 = 1
16.66	Al3 scaled at Al3 max	real32	-32768.00032767.000	-	1000 = 1
	Common parameters f	or AOx (16	6.01 Module 3 type = FIO-11 o	or <i>FAIO-01</i> )	
16.71	AO force selection	uint16	00000000hFFFFFFFh	-	1 = 1
	AO1 (16.0	1 Module	3 type = FIO-11 or FAIO-01)		
16.76	AO1 actual value	real32	0.00022.000	mA	1000 = 1 mA
16.77	AO1 source	uint32	-	-	1 = 1
16.78	AO1 force data	real32	0.00022.000	mA	1000 = 1 mA
16.79	AO1 filter time	real32	0.00030.000	s	1000 = 1 s

No.	Name	Туре	Range	Unit	FbEq32
16.80	AO1 source min	real32	-32768.032767.0	-	10 = 1
16.81	AO1 source max	real32	-32768.032767.0	-	10 = 1
16.82	AO1 out at AO1 src min	real32	0.00022.000	mA	1000 = 1 mA
16.83	AO1 out at AO1 src max	real32	0.00022.000	mA	1000 = 1 mA
	AO2	(16.01 Mo	dule 3 type = FAIO-01)		
16.86	AO2 actual value	real32	0.000 22.000	mA	1000 = 1 mA
16.87	AO2 source	uint32	-	-	1 = 1
16.88	AO2 force data	real32	0.000 22.000	mA	1000 = 1 mA
16.89	AO2 filter time	real32	0.000 30.000	s	1000 = 1 s
16.90	AO2 source min	real32	-32768.0 32767.0	-	10 = 1
16.91	AO2 source max	real32	-32768.0 32767.0	-	10 = 1
16.92	AO2 out at AO2 src min	real32	0.000 22.000	mA	1000 = 1 mA
16.93	AO2 out at AO2 src max	real32	0.000 22.000	mA	1000 = 1 mA
19 Op	eration mode				
19.01	Actual operation mode	uint16	-	-	1 = 1
19.11	Ext1/Ext2 selection	uint32	-	-	1 = 1
19.12	Ext1 control mode 1	uint16	17	-	1 = 1
19.14	Ext2 control mode 1	uint16	17	-	1 = 1
19.16	Local control mode	uint16	01	-	1 = 1
19.17	Local control disable	uint16	01	-	1 = 1
19.20	Scalar control reference unit	uint16	01	-	1 = 1
20 Sta	rt/stop/direction				
20.01	Ext1 commands	uint16	-	-	1 = 1
20.02	Ext1 start trigger type	uint16	01	-	1 = 1
20.03	Ext1 in1 source	uint32	-	-	1 = 1
20.04	Ext1 in2 source	uint32	-	-	1 = 1
20.05	Ext1 in3 source	uint32	-	-	1 = 1
20.06	Ext2 commands	uint16	-	-	1 = 1
20.07	Ext2 start trigger type	uint16	01	-	1 = 1
20.08	Ext2 in1 source	uint32	-	-	1 = 1
20.09	Ext2 in2 source	uint32	-	-	1 = 1
20.10	Ext2 in3 source	uint32	-	-	1 = 1
20.11	Run enable stop mode	uint16	02	-	1 = 1
20.12	Run enable 1 source	uint16	-	-	1 = 1
20.19	Enable start command	uint32	-	-	1 = 1
20.23	Positive speed enable	uint32	-	-	1 = 1
20.24	Negative speed enable	uint32	-	-	1 = 1
20.25	Jogging enable	uint32	-	-	1 = 1
20.26	Jogging 1 start source	uint32	-	-	1 = 1
20.27	Jogging 2 start source	uint32	-	-	1 = 1
20.29	Local start trigger type	uint16	01	-	1 = 1

21.03         Stop mode         uint16         01         -           21.04         Emergency stop mode         uint16         02         -           21.05         Emergency stop source         uint32         -         -           21.06         Zero speed limit         real32         0.00 30000.00         rpm         10           21.07         Zero speed delay         real32         030000         ms         -           21.08         DC current control         uint16         0000b0011b         -         -           21.09         DC hold speed         real32         0.001000.00         rpm         10           21.10         DC current reference         real32         0.0100.0         %           21.11         Post magnetization time         uint32         030000         ms           21.12         Continuous magnetization command         uint32         -         -         -	1 = 1  1 = 1  1 = 1 ms  1 = 1  1 = 1  1 = 1  1 = 1  00 = 1 rpm  1 = 1 ms  1 = 1  00 = 1 rpm  1 = 1 ms  1 = 1  1 = 1 ms  1 = 1
21.01         Start mode         uint16         03         -           21.02         Magnetization time         uint16         010000         ms           21.03         Stop mode         uint16         01         -           21.04         Emergency stop mode         uint16         02         -           21.05         Emergency stop source         uint32         -         -           21.06         Zero speed limit         real32         0.00 30000.00         rpm         10           21.07         Zero speed delay         real32         030000         ms         -           21.08         DC current control         uint16         0000b0011b         -         -           21.09         DC hold speed         real32         0.001000.00         rpm         10           21.10         DC current reference         real32         0.0100.0         %           21.11         Post magnetization time         uint32         030000         ms           21.12         Continuous magnetization command         uint32         -         -         -	1 = 1 ms 1 = 1 1 = 1 1 = 1 00 = 1 rpm 1 = 1 ms 1 = 1 00 = 1 rpm 10 = 1 ym 10 = 1 ym
21.02         Magnetization time         uint16         010000         ms           21.03         Stop mode         uint16         01         -           21.04         Emergency stop mode         uint16         02         -           21.05         Emergency stop source         uint32         -         -           21.06         Zero speed limit         real32         0.0030000.00         rpm         10           21.07         Zero speed delay         real32         030000         ms         -           21.08         DC current control         uint16         0000b0011b         -         -           21.09         DC hold speed         real32         0.001000.00         rpm         10           21.10         DC current reference         real32         0.0100.0         %           21.11         Post magnetization time         uint32         030000         ms           21.12         Continuous magnetization command         uint32         -         -         -	1 = 1 ms 1 = 1 1 = 1 1 = 1 00 = 1 rpm 1 = 1 ms 1 = 1 00 = 1 rpm 10 = 1% 1 = 1 ms
21.03         Stop mode         uint16         01         -           21.04         Emergency stop mode         uint16         02         -           21.05         Emergency stop source         uint32         -         -           21.06         Zero speed limit         real32         0.00 30000.00         rpm         10           21.07         Zero speed delay         real32         030000         ms         -           21.08         DC current control         uint16         0000b0011b         -         -           21.09         DC hold speed         real32         0.001000.00         rpm         10           21.10         DC current reference         real32         0.0100.0         %           21.11         Post magnetization time         uint32         030000         ms           21.12         Continuous magnetization command         uint32         -         -         -	1 = 1 1 = 1 1 = 1 00 = 1 rpm 1 = 1 ms 1 = 1 00 = 1 rpm 10 = 1 ym 10 = 1 ym
21.04         Emergency stop mode         uint16         02         -           21.05         Emergency stop source         uint32         -         -           21.06         Zero speed limit         real32         0.00 30000.00         rpm         10           21.07         Zero speed delay         real32         0 30000         ms         -           21.08         DC current control         uint16         0000b0011b         -         -           21.09         DC hold speed         real32         0.001000.00         rpm         10           21.10         DC current reference         real32         0.0100.0         %           21.11         Post magnetization time         uint32         030000         ms           21.12         Continuous magnetization command         uint32         -         -         -	1 = 1 1 = 1 00 = 1 rpm 1 = 1 ms 1 = 1 00 = 1 rpm 10 = 1 ym 10 = 1 ym
21.05         Emergency stop source         uint32         -         -         -           21.06         Zero speed limit         real32         0.00 30000.00         rpm         10           21.07         Zero speed delay         real32         030000         ms           21.08         DC current control         uint16         0000b0011b         -           21.09         DC hold speed         real32         0.001000.00         rpm         10           21.10         DC current reference         real32         0.0100.0         %           21.11         Post magnetization time         uint32         030000         ms           21.12         Continuous magnetization command         uint32         -         -         -	1 = 1 00 = 1 rpm 1 = 1 ms 1 = 1 00 = 1 rpm 10 = 1% 1 = 1 ms
21.06         Zero speed limit         real32         0.00 30000.00         rpm         10           21.07         Zero speed delay         real32         030000         ms           21.08         DC current control         uint16         0000b0011b         -           21.09         DC hold speed         real32         0.001000.00         rpm         10           21.10         DC current reference         real32         0.0100.0         %           21.11         Post magnetization time         uint32         030000         ms           21.12         Continuous magnetization command         uint32         -         -         -	00 = 1 rpm 1 = 1 ms 1 = 1 00 = 1 rpm 10 = 1% 1 = 1 ms
21.07         Zero speed delay         real32         030000         ms           21.08         DC current control         uint16         0000b0011b         -           21.09         DC hold speed         real32         0.001000.00         rpm         10           21.10         DC current reference         real32         0.0100.0         %           21.11         Post magnetization time         uint32         030000         ms           21.12         Continuous magnetization command         uint32         -         -         -	1 = 1 ms 1 = 1 00 = 1 rpm 10 = 1% 1 = 1 ms
21.08         DC current control         uint16         0000b0011b         -           21.09         DC hold speed         real32         0.001000.00         rpm         10           21.10         DC current reference         real32         0.0100.0         %           21.11         Post magnetization time         uint32         030000         ms           21.12         Continuous magnetization command         uint32         -         -	1 = 1 00 = 1 rpm 10 = 1% 1 = 1 ms
21.09         DC hold speed         real32         0.001000.00         rpm         10           21.10         DC current reference         real32         0.0100.0         %           21.11         Post magnetization time         uint32         030000         ms           21.12         Continuous magnetization command         uint32         -         -	00 = 1 rpm 10 = 1% 1 = 1 ms
21.10         DC current reference         real32         0.0100.0         %           21.11         Post magnetization time         uint32         030000         ms           21.12         Continuous magnetization command         uint32         -         -	10 = 1% 1 = 1 ms
21.11 Post magnetization time uint32 030000 ms 21.12 Continuous magnetization command	1 = 1 ms
21.12 Continuous magnetization command	
command	1 = 1
21.13 Autophasing mode real32 02 -	1 = 1
21.14 Pre-heating input source uint32	1 = 1
21.16 Pre-heating current <i>real32</i> 0.0 30.0 %	10 = 1%
21.18 Auto restart time	10 = 1 s
21.19 Scalar start mode <i>real32</i> 02 -	1 = 1
22 Speed reference selection	
22.01 Speed ref unlimited real32 -30000.0030000.00 rpm 10	00 = 1 rpm
22.11 Speed ref1 source <i>uint32</i>	1 = 1
22.12 Speed ref2 source <i>uint32</i>	1 = 1
22.13 Speed ref1 function <i>uint16</i> 05 -	1 = 1
22.14 Speed ref1/2 selection <i>uint32</i>	1 = 1
22.15 Speed additive 1 source uint32	1 = 1
22.16 Speed share real32 -8.0008.000 -	1000 = 1
22.17 Speed additive 2 source uint32	1 = 1
22.21 Constant speed function <i>uint16</i> 0000b0011b -	1 = 1
22.22 Constant speed sel1 uint32	1 = 1
22.23 Constant speed sel2 uint32	1 = 1
22.24 Constant speed sel3 uint32	1 = 1
22.26 Constant speed 1	00 = 1 rpm
22.27 Constant speed 2 real32 -30000.00 30000.00 rpm 10	00 = 1 rpm
22.28 Constant speed 3 real32 -30000.00 30000.00 rpm 10	00 = 1 rpm
22.29 Constant speed 4 real32 -30000.00 30000.00 rpm 10	00 = 1 rpm
22.30 Constant speed 5 real32 -30000.00 30000.00 rpm 10	00 = 1 rpm
22.31 Constant speed 6 real32 -30000.00 30000.00 rpm 10	00 = 1 rpm
22.32 Constant speed 7	00 = 1 rpm

No.	Name	Type	Range	Unit	FbEq32
22.41	Speed ref safe	real32	-30000.0030000.00	rpm	100 = 1 rpm
22.42	Jogging 1 ref	real32	-30000.00 30000.00	rpm	100 = 1 rpm
22.43	Jogging 2 ref	real32	-30000.00 30000.00	rpm	100 = 1 rpm
22.51	Critical speed function	uint16	0000b0011b	-	1 = 1
22.52	Critical speed 1 low	real32	-30000.0030000.00	rpm	100 = 1 rpm
22.53	Critical speed 1 high	real32	-30000.0030000.00	rpm	100 = 1 rpm
22.54	Critical speed 2 low	real32	-30000.0030000.00	rpm	100 = 1 rpm
22.55	Critical speed 2 high	real32	-30000.0030000.00	rpm	100 = 1 rpm
22.56	Critical speed 3 low	real32	-30000.0030000.00	rpm	100 = 1 rpm
22.57	Critical speed 3 high	real32	-30000.0030000.00	rpm	100 = 1 rpm
22.71	Motor potentiometer function	uint16	02	-	1 = 1
22.72	Motor potentiometer initial value	real32	-32768.00 32767.00	-	100 = 1
22.73	Motor potentiometer up source	uint32	-	-	1 = 1
22.74	Motor potentiometer down source	uint32	-	-	1 = 1
22.75	Motor potentiometer ramp time	real32	0.0 3600.0	s	10 = 1 s
22.76	Motor potentiometer min value	real32	-32768.00 32767.00	-	100 = 1
22.77	Motor potentiometer max value	real32	-32768.00 32767.00	-	100 = 1
22.80	Motor potentiometer ref act	real32	-32768.00 32767.00	-	100 = 1
22.81	Speed reference act 1	real32	-30000.0030000.00	rpm	100 = 1 rpm
22.82	Speed reference act 2	real32	-30000.0030000.00	rpm	100 = 1 rpm
22.83	Speed reference act 3	real32	-30000.0030000.00	rpm	100 = 1 rpm
22.84	Speed reference act 4	real32	-30000.0030000.00	rpm	100 = 1 rpm
22.85	Speed reference act 5	real32	-30000.0030000.00	rpm	100 = 1 rpm
22.86	Speed reference act 6	real32	-30000.0030000.00	rpm	100 = 1 rpm
22.87	Speed reference act 7	real32	-30000.0030000.00	rpm	100 = 1 rpm
23 Sp	eed reference ramp				
23.01	Speed ref ramp input	real32	-30000.0030000.00	rpm	100 = 1 rpm
23.02	Speed ref ramp output	real32	-30000.0030000.00	rpm	100 = 1 rpm
23.11	Ramp set selection	uint32	-	-	1 = 1
23.12	Acceleration time 1	real32	0.0001800.000	S	1000 = 1 s
23.13	Deceleration time 1	real32	0.0001800.000	s	1000 = 1 s
23.14	Acceleration time 2	real32	0.0001800.000	S	1000 = 1 s
23.15	Deceleration time 2	real32	0.0001800.000	S	1000 = 1 s
23.16	Shape time acc 1	real32	0.0001800.000	s	1000 = 1 s
23.17	Shape time acc 2	real32	0.0001800.000	s	1000 = 1 s
23.18	Shape time dec 1	real32	0.0001800.000	S	1000 = 1 s
23.19	Shape time dec 2	real32	0.0001800.000	s	1000 = 1 s

No.	Name	Туре	Range	Unit	FbEq32
23.20	Acc time jogging	real32	0.0001800.000	S	1000 = 1 s
23.21	Dec time jogging	real32	0.0001800.000	S	1000 = 1 s
23.23	Emergency stop time	real32	0.0001800.000	S	1000 = 1 s
23.24	Speed ramp in zero source	uint32	-	-	1 = 1
23.26	Ramp out balancing enable	uint32	-	-	1 = 1
23.27	Ramp out balancing ref	real32	-30000.0030000.00	rpm	100 = 1 rpm
23.28	Variable slope enable	uint16	01	-	1 = 1
23.29	Variable slope rate	real32	230000	ms	1 = 1 ms
23.39	Follower speed correction out	real32	-30000.0030000.00	rpm	100 = 1 rpm
23.40	Follower speed correction enable	uint32	-	-	1 = 1
23.41	Follower speed correction gain	real32	0.00100.00	%	100 = 1%
23.42	Follower speed corr torq source	uint32	-	-	1 = 1
24 Spe	eed reference condition	ning			
24.01	Used speed reference	real32	-30000.0030000.00	rpm	100 = 1 rpm
24.02	Used speed feedback	real32	-30000.0030000.00	rpm	100 = 1 rpm
24.03	Speed error filtered	real32	-30000.030000.0	rpm	100 = 1 rpm
24.04	Speed error inverted	real32	-30000.030000.0	rpm	100 = 1 rpm
24.11	Speed correction	real32	-10000.0010000.00	-	100 = 1
24.12	Speed error filter time	real32	010000	ms	1 = 1 ms
24.13	RFE speed filter	uint16	01	-	1 = 1
24.14	Frequency of zero	real32	0.50 500.00	Hz	10 = 1 Hz
24.15	Damping of zero	real32	-1.000 1.000	-	100 = 1
24.16	Frequency of pole	real32	0.50 500.00	Hz	10 = 1 Hz
24.17	Damping of pole	real32	-1.000 1.000	-	100 = 1
24.41	Speed error window control enable	uint32	-	-	1 = 1
24.42	Speed window control mode	uint16	01	-	1 = 1
24.43	Speed error window high	real32	0.003000.00	rpm	100 = 1 rpm
24.44	Speed error window low	real32	0.003000.00	rpm	100 = 1 rpm
24.46	Speed error step	real32	-3000.003000.00	rpm	100 = 1 rpm
25 Spe	eed control				
25.01	Torque reference speed control	real32	-1600.01600.0	%	10 = 1%
25.02	Speed proportional gain	real32	0.00250.00	-	100 = 1
25.03	Speed integration time	real32	0.001000.00	s	100 = 1 s
25.04	Speed derivation time	real32	0.00010000.000	s	1000 = 1 s
25.05	Derivation filter time	real32	010000	ms	1 = 1 ms
25.06	Acc comp derivation time	real32	0.001000.00	s	100 = 1 s
25.07	Acc comp filter time	real32	0.01000.0	ms	10 = 1 ms

No.	Name	Туре	Range	Unit	FbEq32
25.08	Drooping rate	real32	0.00100.00	%	100 = 1%
25.09	Speed ctrl balancing enable	uint32	-	-	1 = 1
25.10	Speed ctrl balancing ref	real32	-300.0300.0	%	10 = 1%
25.11	Speed control min torque	real32	-1600.00.0	%	10 = 1%
25.12	Speed control max torque	real32	0.01600.0	%	10 = 1%
25.13	Min torq sp ctrl em stop	real32	-16000	%	10 = 1%
25.14	Max torq sp ctrl em stop	real32	01600	%	10 = 1%
25.15	Proportional gain em stop	real32	1.00250.00	-	100 = 1
25.18	Speed adapt min limit	real32	030000	rpm	1 = 1 rpm
25.19	Speed adapt max limit	real32	030000	rpm	1 = 1 rpm
25.21	Kp adapt coef at min speed	real32	0.00010.000	-	1000 = 1
25.22	Ti adapt coef at min speed	real32	0.00010.000	-	1000 = 1
25.25	Torque adapt max limit	real32	0.01600.0	%	10 = 1%
25.26	Torque adapt filt time	real32	0.000100.000	S	1000 = 1 s
25.27	Kp adapt coef at min torque	real32	0.00010.000	-	1000 = 1
25.30	Flux adaptation enable	uint16	01	-	1 = 1
25.33	Speed controller autotune	uint32	-	-	1 = 1
25.34	Speed controller autotune mode	uint16	02	-	1 = 1
25.37	Mechanical time constant	real32	0.001000.00	s	100 = 1 s
25.38	Autotune torque step	real32	0.00100.00	%	100 = 1%
25.39	Autotune speed step	real32	0.00100.00	%	100 = 1%
25.40	Autotune repeat times	uint16	110	-	1 = 1
25.41	Torque reference Autotune2	real32	-1600.01600.0	%	10 = 1%
25.42	Integral term enable	uint32	-	-	1 = 1
25.53	Torque prop reference	real32	-30000.0 30000.0	%	10 = 1%
25.54	Torque integral reference	real32	-30000.0 30000.0	%	10 = 1%
25.55	Torque deriv reference	real32	-30000.0 30000.0	%	10 = 1%
25.56	Torque acc compensation	real32	-30000.0 30000.0	%	10 = 1%
25.57	Torque reference unbalanced	real32	-30000.0 30000.0	%	10 = 1%
26 To	rque reference chain				
26.01	Torque reference to TC	real32	-1600.0 1600.0	%	10 = 1%
26.02	Torque reference used	real32	-1600.0 1600.0	%	10 = 1%
26.43	Torque step pointer enable	uint32	-	-	1 = 1
26.44	Torque step source	uint32	-	-	1 = 1
26.51	Oscillation damping	uint32	-	-	1 = 1
26.52	Oscillation damping out enable	uint32	-	-	1 = 1
26.53	Oscillation compensation input	uint16	01	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32
26.55	Oscillation damping frequency	real32	0.1 60.0	Hz	10 = 1 Hz
26.56	Oscillation damping phase	real32	0360	deg	1 = 1 deg
26.57	Oscillation damping gain	real32	0.0 100.0	%	10 = 1%
26.58	Oscillation damping output	real32	-1600.000 1600.000	%	1000 = 1%
26.81	Rush control gain	real32	0.0 10000.0	-	10 = 1
26.82	Rush control integration time	real32	0.0 10.0	s	10 = 1 s
28 Fre	quency reference chai	n			
28.01	Frequency ref ramp input	real32	-500.00500.00	Hz	100 = 1 Hz
28.02	Frequency ref ramp output	real32	-500.00500.00	Hz	100 = 1 Hz
28.11	Frequency ref1 source	uint32	-	-	1 = 1
28.12	Frequency ref2 source	uint32	-	-	1 = 1
28.13	Frequency ref1 function	uint16	05	-	1 = 1
28.14	Frequency ref1/2 selection	uint32	-	-	1 = 1
28.21	Constant frequency function	uint16	00b11b	-	1 = 1
28.22	Constant frequency sel1	uint32	-	-	1 = 1
28.23	Constant frequency sel2	uint32	-	-	1 = 1
28.24	Constant frequency sel3	uint32	-	-	1 = 1
28.26	Constant frequency 1	real32	-500.00 500.00	Hz	100 = 1 Hz
28.27	Constant frequency 2	real32	-500.00 500.00	Hz	100 = 1 Hz
28.28	Constant frequency 3	real32	-500.00 500.00	Hz	100 = 1 Hz
28.29	Constant frequency 4	real32	-500.00 500.00	Hz	100 = 1 Hz
28.30	Constant frequency 5	real32	-500.00 500.00	Hz	100 = 1 Hz
28.31	Constant frequency 6	real32	-500.00 500.00	Hz	100 = 1 Hz
28.32	Constant frequency 7	real32	-500.00 500.00	Hz	100 = 1 Hz
28.41	Frequency ref safe	real32	-500.00500.00	Hz	100 = 1 Hz
28.51	Critical frequency function	uint16	00b11b	-	1 = 1
28.52	Critical frequency 1 low	real32	-500.00500.00	Hz	100 = 1 Hz
28.53	Critical frequency 1 high	real32	-500.00500.00	Hz	100 = 1 Hz
28.54	Critical frequency 2 low	real32	-500.00500.00	Hz	100 = 1 Hz
28.55	Critical frequency 2 high	real32	-500.00500.00	Hz	100 = 1 Hz
28.56	Critical frequency 3 low	real32	-500.00500.00	Hz	100 = 1 Hz
28.57	Critical frequency 3 high	real32	-500.00500.00	Hz	100 = 1 Hz
28.71	Freq ramp set selection	uint32	-	-	1 = 1
28.72	Freq acceleration time 1	real32	0.0001800.000	s	1000 = 1 s
28.73	Freq deceleration time 1	real32	0.0001800.000	s	1000 = 1 s
28.74	Freq acceleration time 2	real32	0.0001800.000	s	1000 = 1 s
28.75	Freq deceleration time 2	real32	0.0001800.000	s	1000 = 1 s
28.76	Freq ramp in zero source	uint32	-	-	1 = 1
28.77	Freq ramp hold	uint32	-	-	1 = 1
28.78	Freq ramp output balancing	real32	-500.00500.00	Hz	100 = 1 Hz

No.	Name	Туре	Range	Unit	FbEq32
28.79	Freq ramp output balancing enable	uint32	-	-	1 = 1
28.90	Frequency ref act 1	real32	-500.00500.00	Hz	100 = 1 Hz
28.91	Frequency ref act 2	real32	-500.00500.00	Hz	100 = 1 Hz
28.92	Frequency ref act 3	real32	-500.00500.00	Hz	100 = 1 Hz
28.96	Frequency ref act 7	real32	-500.00500.00	Hz	100 = 1 Hz
28.97	Frequency ref unlimited	real32	-500.00500.00	Hz	100 = 1 Hz
30 Lin	nits	•			l e e e e e e e e e e e e e e e e e e e
30.01	Limit word 1	uint16	0000hFFFFh	-	1 = 1
30.02	Torque limit status	uint16	0000hFFFFh	-	1 = 1
30.11	Minimum speed	real32	-30000.0030000.00	rpm	100 = 1 rpm
30.12	Maximum speed	real32	-30000.0030000.00	rpm	100 = 1 rpm
30.13	Minimum frequency	real32	-500.00500.00	Hz	100 = 1 Hz
30.14	Maximum frequency	real32	-500.00500.00	Hz	100 = 1 Hz
30.15	Maximum start current enable	uint16	01	-	1 = 1
30.16	Maximum start current	real32	0.0030000.00	Α	100 = 1 A
30.17	Maximum current	real32	0.0030000.00	Α	100 = 1 A
30.18	Minimum torque sel	uint32	-	-	1 = 1
30.19	Minimum torque 1	real32	-1600.00.0	%	10 = 1%
30.20	Maximum torque 1	real32	0.01600.0	%	10 = 1%
30.21	Minimum torque 2 source	uint32	-	-	1 = 1
30.22	Maximum torque 2 source	uint32	-	-	1 = 1
30.23	Minimum torque 2	real32	-1600.00.0	%	10 = 1%
30.24	Maximum torque 2	real32	0.01600.0	%	10 = 1%
30.25	Maximum torque sel	uint32	-	-	1 = 1
30.26	Power motoring limit	real32	0.00600.00	%	100 = 1%
30.27	Power generating limit	real32	-600.000.00	%	100 = 1%
30.30	Overvoltage control	uint16	01	-	1 = 1
30.31	Undervoltage control	uint16	01	-	1 = 1
30.35	Thermal current limitation	uint16	01	-	1 = 1
(	Parameters 30.10130.149 or	nly visible	when IGBT supply unit contro	l activated b	y 95.20)
30.101	LSU limit word 1	uint16	0000hFFFFh	-	1 = 1
30.102	LSU limit word 2	uint16	0000hFFFFh	-	1 = 1
30.103	LSU limit word 3	uint16	0000hFFFFh	-	1 = 1
30.104	LSU limit word 4	uint16	0000hFFFFh	-	1 = 1
30.148	LSU minimum power limit	real32	-200.0 0.0	%	10 = 1%
30.149	LSU maximum power limit	real32	0.0 200.0	%	10 = 1%
31 Fau	ılt functions				
31.01	External event 1 source	uint32	-	-	1 = 1
31.02	External event 1 type	uint16	03	-	1 = 1

No.	Name	Type	Range	Unit	FbEq32			
31.03	External event 2 source	uint32	-	-	1 = 1			
31.04	External event 2 type	uint16	03	-	1 = 1			
31.05	External event 3 source	uint32	-	-	1 = 1			
31.06	External event 3 type	uint16	03	-	1 = 1			
31.07	External event 4 source	uint32	-	-	1 = 1			
31.08	External event 4 type	uint16	03	-	1 = 1			
31.09	External event 5 source	uint32	-	-	1 = 1			
31.10	External event 5 type	uint16	03	-	1 = 1			
31.11	Fault reset selection	uint32	-	-	1 = 1			
31.12	Autoreset selection	uint16	0000hFFFFh	-	1 = 1			
31.13	User selectable fault	uint16	0000hFFFFh	-	1 = 1			
31.14	Number of trials	uint32	05	-	1 = 1			
31.15	Total trials time	real32	1.0600.0	s	10 = 1 s			
31.16	Delay time	real32	0.0120.0	s	10 = 1 s			
31.19	Motor phase loss	uint16	01	-	1 = 1			
31.20	Earth fault	uint16	02	-	1 = 1			
31.22	STO indication run/stop	uint16	05	-	1 = 1			
31.23	Wiring or earth fault	uint16	01	-	1 = 1			
31.24	Stall function	uint16	02	-	1 = 1			
31.25	Stall current limit	real32	0.01600.0	%	10 = 1%			
31.26	Stall speed limit	real32	0.010000.0	rpm	100 = 1 rpm			
31.27	Stall frequency limit	real32	0.00500.00	Hz	100 = 1 Hz			
31.28	Stall time	real32	03600	s	1 = 1 s			
31.30	Overspeed trip margin	real32	0.0010000.00	rpm	100 = 1 rpm			
31.32	Emergency ramp supervision	real32	0300	%	1 = 1%			
31.33	Emergency ramp supervision delay	real32	032767	s	1 = 1 s			
31.35	Main fan fault function	uint16	02	-	1 = 1			
	(Parameter 3	1.36 only	visible with a ZCU control uni	t)				
31.36	Aux fan fault function	uint16	01	-	1 = 1			
31.37	Ramp stop supervision	real32	0300	%	1 = 1%			
31.38	Ramp stop supervision delay	real32	032767	S	1 = 1 s			
31.40	Disable warning messages	uint16	0000hFFFFh	-	1 = 1			
31.42	Overcurrent fault limit	real32	0.00 30000.00	Α	100 = 1 A			
31.54	Fault action	uint16	01	-	1 = 1			
(	(Parameters 31.12031.121 only visible when IGBT supply unit control activated by 95.20)							
31.120	LSU earth fault	uint16	01	-	1 = 1			
31.121	LSU supply phase loss	uint16	01	-	1 = 1			
32 Su	pervision							
32.01	Supervision status	uint16	00000111b	-	1 = 1			
32.05	Supervision 1 function	uint16	06	-	1 = 1			

No.	Name	Туре	Range	Unit	FbEq32
32.06	Supervision 1 action	uint16	03	-	1 = 1
32.07	Supervision 1 signal	uint32	-	-	1 = 1
32.08	Supervision 1 filter time	real32	0.00030.000	s	1000 = 1 s
32.09	Supervision 1 low	real32	-21474830.00 21474830.00	-	100 = 1
32.10	Supervision 1 high	real32	-21474830.00 21474830.00	-	100 = 1
32.15	Supervision 2 function	uint16	06	-	1 = 1
32.16	Supervision 2 action	uint16	03	-	1 = 1
32.17	Supervision 2 signal	uint32	-	-	1 = 1
32.18	Supervision 2 filter time	real32	0.00030.000	s	1000 = 1 s
32.19	Supervision 2 low	real32	-21474830.00 21474830.00	-	100 = 1
32.20	Supervision 2 high	real32	-21474830.00 21474830.00	-	100 = 1
32.25	Supervision 3 function	uint16	06	-	1 = 1
32.26	Supervision 3 action	uint16	03	-	1 = 1
32.27	Supervision 3 signal	uint32	-	-	1 = 1
32.28	Supervision 3 filter time	real32	0.00030.000	S	1000 = 1 s
32.29	Supervision 3 low	real32	-21474830.00 21474830.00	-	100 = 1
32.30	Supervision 3 high	real32	-21474830.00 21474830.00	-	100 = 1
33 Ge	neric timer & counter				
33.01	Counter status	uint16	0000 0000b0011 1111b	l -	1 = 1
33.10	On-time 1 actual	uint32	04294967295	s	1 = 1 s
33.11	On-time 1 warn limit	uint32	04294967295	s	1 = 1 s
33.12	On-time 1 function	uint16	00b11b	-	1 = 1
33.13	On-time 1 source	uint32	-	-	1 = 1
33.14	On-time 1 warn message	uint32	-	-	1 = 1
33.20	On-time 2 actual	uint32	04294967295	S	1 = 1 s
33.21	On-time 2 warn limit	uint32	04294967295	s	1 = 1 s
33.22	On-time 2 function	uint16	00b11b	-	1 = 1
33.23	On-time 2 source	uint32	-	-	1 = 1
33.24	On-time 2 warn message	uint32	-	-	1 = 1
33.30	Edge counter 1 actual	uint32	04294967295	-	1 = 1
33.31	Edge counter 1 warn limit	uint32	04294967295	-	1 = 1
33.32	Edge counter 1 function	uint16	0000b1111b	-	1 = 1
33.33	Edge counter 1 source	uint32	-	-	1 = 1
33.34	Edge counter 1 divider	uint32	14294967295	-	1 = 1
33.35	Edge counter 1 warn message	uint32	-	-	1 = 1

No.	Name	Type	Range	Unit	FbEq32
33.40	Edge counter 2 actual	uint32	04294967295	-	1 = 1
33.41	Edge counter 2 warn limit	uint32	04294967295	-	1 = 1
33.42	Edge counter 2 function	uint16	0000b1111b	-	1 = 1
33.43	Edge counter 2 source	uint32	-	-	1 = 1
33.44	Edge counter 2 divider	uint32	14294967295	-	1 = 1
33.45	Edge counter 2 warn message	uint32	-	-	1 = 1
33.50	Value counter 1 actual	real32	-2147483008 2147483008	-	1 = 1
33.51	Value counter 1 warn limit	real32	-2147483008 2147483008	-	1 = 1
33.52	Value counter 1 function	uint16	00b11b	-	1 = 1
33.53	Value counter 1 source	uint32	-	-	1 = 1
33.54	Value counter 1 divider	real32	0.0012147483.000	-	1000 = 1
33.55	Value counter 1 warn message	uint32	-	-	1 = 1
33.60	Value counter 2 actual	real32	-2147483008 2147483008	-	1 = 1
33.61	Value counter 2 warn limit	real32	-2147483008 2147483008	-	1 = 1
33.62	Value counter 2 function	uint16	00b11b	-	1 = 1
33.63	Value counter 2 source	uint32	-	-	1 = 1
33.64	Value counter 2 divider	real32	0.0012147483.000	-	1000 = 1
33.65	Value counter 2 warn message	uint32	-	-	1 = 1
35 Mo	tor thermal protection				
35.01	Motor estimated temperature	real32	-601000	°C	1 = 1 °C
35.02	Measured temperature 1	real32	-60 1000 °C, -76 1832 °F, 05000 ohm	°C,°F or ohm	1 = 1 unit
35.03	Measured temperature 2	real32	-60 1000 °C, -76 1832 °F, 05000 ohm	°C, °F or ohm	1 = 1 unit
35.04	FPTC status word	uint16	0000hFFFFh	-	1 = 1
35.11	Temperature 1 source	uint16	011	-	1 = 1
35.12	Temperature 1 fault limit	real32	-60 1000 °C, -76 1832 °F or 05000 ohm	°C, °F or ohm	1 = 1 unit
35.13	Temperature 1 warning limit	real32	-60 1000 °C, -76 1832 °F or 05000 ohm	°C, °F or ohm	1 = 1 unit
35.14	Temperature 1 Al source	uint32	-	-	1 = 1
35.21	Temperature 2 source	uint16	011	-	1 = 1
35.22	Temperature 2 fault limit	real32	-60 1000 °C, -76 1832 °F or 05000 ohm	°C, °F or ohm	1 = 1 unit

No.	Name	Туре	Range	Unit	FbEq32
35.23	Temperature 2 warning limit	real32	-60 1000 °C, -76 1832 °F or 05000 ohm	°C, °F or ohm	1 = 1 unit
35.24	Temperature 2 AI source	uint32	-	-	1 = 1
35.30	FPTC configuration word	uint16	0000hFFFFh	-	1 = 1
35.50	Motor ambient temperature	int16	-60 100 °C or -76 212 °F	°C or °F	1 = 1 °
35.51	Motor load curve	uint16	50150	%	1 = 1%
35.52	Zero speed load	uint16	25150	%	1 = 1%
35.53	Break point	uint16	1.00500.00	Hz	100 = 1 Hz
35.54	Motor nominal temperature rise	uint16	0300 °C or 32572 °F	°C	1 = 1 °C
35.55	Motor thermal time constant	uint16	10010000	s	1 = 1 s
35.60	Cable temperature	real32	00200.0	%	10 = 1%
35.61	Cable nominal current	real32	0.0010000.0	Α	100 = 1 A
35.62	Cable thermal rise time	uint16	050000	s	1 = 1 s
35.100	DOL starter control source	uint32	-	-	1 = 1
35.101	DOL starter on delay	uint32	042949673	s	1 = 1 s
35.102	DOL starter off delay	uint32	0715828	min	1 = 1 min
35.103	DOL starter feedback source	uint32	-	-	1 = 1
35.104	DOL starter feedback delay	uint32	042949673	s	1 = 1 s
35.105	DOL starter status word	uint16	0000b1111b	-	1 = 1
35.106	DOL starter event type	uint16	02	-	1 = 1
36 Loa	ad analyzer				
36.01	PVL signal source	uint32	-	-	1 = 1
36.02	PVL filter time	real32	0.00120.00	s	100 = 1 s
36.06	AL2 signal source	uint32	-	-	1 = 1
36.07	AL2 signal scaling	real32	0.0032767.00	-	100 = 1
36.08	Logger function	uint16	00b11b	-	1 = 1
36.09	Reset loggers	uint16	03	-	1 = 1
36.10	PVL peak value	real32	-32768.0032767.00	-	100 = 1
36.11	PVL peak date	uint16	-	-	1 = 1
36.12	PVL peak time	uint32	-	-	1 = 1
36.13	PVL current at peak	real32	-32768.0032767.00	Α	100 = 1 A
36.14	PVL DC voltage at peak	real32	0.002000.00	V	100 = 1 V
36.15	PVL speed at peak	real32	-32768.0032767.00	rpm	100 = 1 rpm
36.16	PVL reset date	uint16	-	-	1 = 1
36.17	PVL reset time	uint32	-	-	1 = 1
36.20	AL1 below 10%	real32	0.00 100.00	%	100 = 1%
36.21	AL1 10 to 20%	real32	0.00100.00	%	100 = 1%
36.22	AL1 20 to 30%	real32	0.00100.00	%	100 = 1%
36.23	AL1 30 to 40%	real32	0.00100.00	%	100 = 1%

No.	Name	Туре	Range	Unit	FbEq32
36.24	AL1 40 to 50%	real32	0.00100.00	%	100 = 1%
36.25	AL1 50 to 60%	real32	0.00100.00	%	100 = 1%
36.26	AL1 60 to 70%	real32	0.00100.00	%	100 = 1%
36.27	AL1 70 to 80%	real32	0.00100.00	%	100 = 1%
36.28	AL1 80 to 90%	real32	0.00100.00	%	100 = 1%
36.29	AL1 over 90%	real32	0.00100.00	%	100 = 1%
36.40	AL2 below 10%	real32	0.00 100.00	%	100 = 1%
36.41	AL2 10 to 20%	real32	0.00100.00	%	100 = 1%
36.42	AL2 20 to 30%	real32	0.00100.00	%	100 = 1%
36.43	AL2 30 to 40%	real32	0.00100.00	%	100 = 1%
36.44	AL2 40 to 50%	real32	0.00100.00	%	100 = 1%
36.45	AL2 50 to 60%	real32	0.00100.00	%	100 = 1%
36.46	AL2 60 to 70%	real32	0.00100.00	%	100 = 1%
36.47	AL2 70 to 80%	real32	0.00100.00	%	100 = 1%
36.48	AL2 80 to 90%	real32	0.00100.00	%	100 = 1%
36.49	AL2 over 90%	real32	0.00100.00	%	100 = 1%
36.50	AL2 reset date	uint16	-	-	1 = 1
36.51	AL2 reset time	uint32	-	-	1 = 1
37 User	load curve				
37.01	ULC output status word	uint16	0000hFFFFh	-	1 = 1
37.02	ULC supervision signal	uint32	-	-	1 = 1
37.03	ULC overload actions	uint16	03	-	1 = 1
37.04	ULC underload actions	uint16	03	-	1 = 1
37.11	ULC speed table point 1	real32	0.0 30000.0	rpm	10 = 1 rpm
37.12	ULC speed table point 2	real32	0.0 30000.0	rpm	10 = 1 rpm
37.13	ULC speed table point 3	real32	0.0 30000.0	rpm	10 = 1 rpm
37.14	ULC speed table point 4	real32	0.0 30000.0	rpm	10 = 1 rpm
37.15	ULC speed table point 5	real32	0.0 30000.0	rpm	10 = 1 rpm
37.16	ULC frequency table point 1	real32	0.0 500.0	Hz	10 = 1 Hz
37.17	ULC frequency table point 2	real32	0.0 500.0	Hz	10 = 1 Hz
37.18	ULC frequency table point 3	real32	0.0 500.0	Hz	10 = 1 Hz
37.19	ULC frequency table point 4	real32	0.0 500.0	Hz	10 = 1 Hz
37.20	ULC frequency table point 5	real32	0.0 500.0	Hz	10 = 1 Hz
37.21	ULC underload point 1	real32	0.0 1600.0	%	10 = 1%
37.22	ULC underload point 2	real32	0.0 1600.0	%	10 = 1%
37.23	ULC underload point 3	real32	0.0 1600.0	%	10 = 1%
37.24	ULC underload point 4	real32	0.0 1600.0	%	10 = 1%
37.25	ULC underload point 5	real32	0.0 1600.0	%	10 = 1%
37.31	ULC overload point 1	real32	0.0 1600.0	%	10 = 1%
37.32	ULC overload point 2	real32	0.0 1600.0	%	10 = 1%
37.33	ULC overload point 3	real32	0.0 1600.0	%	10 = 1%

No.	Name	Туре	Range	Unit	FbEq32			
37.34	ULC overload point 4	real32	0.0 1600.0	%	10 = 1%			
37.35	ULC overload point 5	real32	0.0 1600.0	%	10 = 1%			
37.41	ULC overload timer	real32	0.0 10000.0	S	10 = 1 s			
37.42	ULC underload timer	real32	0.0 10000.0	s	10 = 1 s			
43 Bra	43 Brake chopper							
43.01	Braking resistor temperature	real32	0.0120.0	%	10 = 1%			
43.06	Brake chopper function	uint16	02	-	1 = 1			
43.07	Brake chopper run enable	uint32	-	-	1 = 1			
43.08	Brake resistor thermal to	real32	010000	s	1 = 1 s			
43.09	Brake resistor Pmax cont	real32	0.0010000.00	kW	100 = 1 kW			
43.10	Brake resistance	real32	01000	ohm	10 = 1 ohm			
43.11	Brake resistor fault limit	real32	0150	%	1 = 1%			
43.12	Brake resistor warning limit	real32	0150	%	1 = 1%			
45 En	ergy efficiency							
45.01	Saved GW hours	uint16	065535	GWh	1 = 1 GWh			
45.02	Saved MW hours	uint16	0999	MWh	1 = 1 MWh			
45.03	Saved kW hours	uint16	0.0999.9	kWh	10 = 1 kWh			
45.05	Saved money x1000	uint32	04294967295	thousand	1 = 1 thousand			
45.06	Saved money	uint32	0.00999.99	(selectabl e)	100 = 1 unit			
45.08	CO2 reduction in kilotons	uint16	065535	metric kiloton	1 = 1 metric kiloton			
45.09	CO2 reduction in tons	uint16	0.0999.9	metric ton	10 = 1 metric ton			
45.11	Energy optimizer	uint16	01	-	1 = 1			
45.12	Energy tariff 1	uint32	0.000 4294967.295	(selectabl e)	1000 = 1 unit			
45.13	Energy tariff 2	uint32	0.0004294967.295	(selectabl e)	1000 = 1 unit			
45.14	Tariff selection	uint32	-	-	1 = 1			
45.17	Tariff currency unit	uint16	100102	-	1 = 1			
45.18	CO2 conversion factor	uint16	0.00065.535	metricton/ MWh	1000 = 1 metric ton/MWh			
45.19	Comparison power	real32	0.0100000.0	kW	10 = 1 kW			
45.21	Energy calculations reset	uint16	01	-	1 = 1			
46 Mo	nitoring/scaling setting	js		•				
46.01	Speed scaling	real32	0.1030000.00	rpm	100 = 1 rpm			
46.02	Frequency scaling	real32	0.101000.00	Hz	100 = 1 Hz			
46.03	Torque scaling	real32	0.1 1000.0	%	10 = 1%			
46.04	Power scaling	real32	0.10 30000.00 kW or 0.10 40214.48 hp	kW or hp	100 = 1 unit			

No.	Name	Type	Range	Unit	FbEq32
46.05	Current scaling	real32	030000	Α	1 = 1 A
46.06	Speed ref zero scaling	real32	0.00 30000.00	rpm	100 = 1 rpm
46.07	Frequency ref zero scaling	real32	0.00 1000.00	Hz	100 = 1 Hz
46.11	Filter time motor speed	real32	020000	ms	1 = 1 ms
46.12	Filter time output frequency	real32	020000	ms	1 = 1 ms
46.13	Filter time motor torque	real32	020000	ms	1 = 1 ms
46.14	Filter time power out	real32	020000	ms	1 = 1 ms
46.21	At speed hysteresis	real32	0.00 30000.00	rpm	100 = 1 rpm
46.22	At frequency hysteresis	real32	0.00 1000.00	Hz	100 = 1 Hz
46.23	At torque hysteresis	real32	0.0 300.0	%	1 = 1%
46.31	Above speed limit	real32	0.0030000.00	rpm	100 = 1 rpm
46.32	Above frequency limit	real32	0.001000.00	Hz	100 = 1 Hz
46.33	Above torque limit	real32	0.01600.0	%	10 = 1 %
46.42	Torque decimals	uint16	02	-	1 = 1
46.200	Rod torque scaler	real32	0100000	-	1 = 1
46.201	Rod speed scaler	real32	0100000	Prpm	1 = 1
46.202	Pump speed ref scaler	real32	010000	-	1 = 1
46.203	Motor speed ref scaler	real32	010000	rpm	1 = 1
47 Dat	a storage				
47.01	Data storage 1 real32	real32	Defined by 47.31	-	1000 = 1
47.02	Data storage 2 real32	real32	Defined by 47.32	-	1000 = 1
47.03	Data storage 3 real32	real32	Defined by 47.33	-	1000 = 1
47.04	Data storage 4 real32	real32	Defined by 47.34	-	1000 = 1
47.05	Data storage 5 real32	real32	Defined by 47.35	-	1000 = 1
47.06	Data storage 6 real32	real32	Defined by 47.36	-	1000 = 1
47.07	Data storage 7 real32	real32	Defined by 47.37	-	1000 = 1
47.08	Data storage 8 real32	real32	Defined by 47.38	-	1000 = 1
47.11	Data storage 1 int32	int32	-2147483648 2147483647	-	1 = 1
47.12	Data storage 2 int32	int32	-2147483648 2147483647	-	1 = 1
47.13	Data storage 3 int32	int32	-2147483648 2147483647	-	1 = 1
47.14	Data storage 4 int32	int32	-2147483648 2147483647	-	1 = 1
47.15	Data storage 5 int32	int32	-2147483648 2147483647	-	1 = 1
47.16	Data storage 6 int32	int32	-2147483648 2147483647	-	1 = 1
47.17	Data storage 7 int32	int32	-2147483648 2147483647	-	1 = 1
47.18	Data storage 8 int32	int32	-2147483648 2147483647	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32
47.21	Data storage 1 int16	int16	-3276832767	-	1 = 1
47.22	Data storage 2 int16	int16	-3276832767	-	1 = 1
47.23	Data storage 3 int16	int16	-3276832767	-	1 = 1
47.24	Data storage 4 int16	int16	-3276832767	-	1 = 1
47.25	Data storage 5 int16	int16	-3276832767	-	1 = 1
47.26	Data storage 6 int16	int16	-3276832767	-	1 = 1
47.27	Data storage 7 int16	int16	-3276832767	-	1 = 1
47.28	Data storage 8 int16	int16	-3276832767	-	1 = 1
47.31	Data storage 1 real32 type	uint16	05	-	1 = 1
47.32	Data storage 2 real32 type	uint16	05	-	1 = 1
47.33	Data storage 3 real32 type	uint16	05	-	1 = 1
47.34	Data storage 4 real32 type	uint16	05	-	1 = 1
47.35	Data storage 5 real32 type	uint16	05	-	1 = 1
47.36	Data storage 6 real32 type	uint16	05	-	1 = 1
47.37	Data storage 7 real32 type	uint16	05	-	1 = 1
47.38	Data storage 8 real32 type	uint16	05	-	1 = 1
49 Pa	nel port communication	า			
49.01	Node ID number	uint32	132	-	1 = 1
49.03	Baud rate	uint32	15	-	1 = 1
49.04	Communication loss time	uint32	0.13000.0	S	10 = 1 s
49.05	Communication loss action	uint16	03	-	1 = 1
49.06	Refresh settings	uint16	01	-	1 = 1
49.07	Panel comm supervision force	uint16	0000hFFFFh	-	1 = 1
49.08	Secondary comm. loss action	uint16	05	-	1 = 1
49.14	Panel speed reference unit	uint16	01	-	1 = 1
49.15	Minimum ext speed ref panel	real32	-30000.00 30000.00	rpm	100 = 1 rpm
49.16	Maximum ext speed ref panel	real32	-30000.00 30000.00	rpm	100 = 1 rpm
49.17	Minimum ext frequency ref panel	real32	-500.00 500.00	Hz	100 = 1 Hz
49.18	Maximum ext frequency ref panel	real32	-500.00 500.00	Hz	100 = 1 Hz
49.24	Panel actual source	uint32	-	-	1 = 1
50 Fie	eldbus adapter (FBA)				
50.01	FBA A enable	uint16	01	-	1 = 1
50.02	FBA A comm loss func	uint16	03	-	1 = 1
50.03	FBA A comm loss t out	uint16	0.36553.5	s	10 = 1 s
50.04	FBA A ref1 type	uint16	010	-	1 = 1
50.05	FBA A ref2 type	uint16	010	-	1 = 1
50.07	FBA A actual 1 type	uint16	06	-	1 = 1

No.	Name	Type	Range	Unit	FbEq32
50.08	FBA A actual 2 type	uint16	06	-	1 = 1
50.09	FBA A SW transparent source	uint32	-	-	1 = 1
50.10	FBAA act1 transparent source	uint32	-	-	1 = 1
50.11	FBA A act2 transparent source	uint32	-	-	1 = 1
50.12	FBA A debug mode	uint16	01	-	1 = 1
50.13	FBA A control word	uint32	00000000hFFFFFFFh	-	1 = 1
50.14	FBA A reference 1	int32	-2147483648 2147483647	-	1 = 1
50.15	FBA A reference 2	int32	-2147483648 2147483647	-	1 = 1
50.16	FBA A status word	uint32	00000000hFFFFFFFh	-	1 = 1
50.17	FBA A actual value 1	int32	-2147483648 2147483647	-	1 = 1
50.18	FBA A actual value 2	int32	-2147483648 2147483647	-	1 = 1
50.21	FBA A timelevel sel	uint16	03	-	1 = 1
50.26	FBAA comm supervision force	uint16	0000hFFFh	-	1 = 1
50.31	FBA B enable	uint16	01	-	1 = 1
50.32	FBA B comm loss func	uint16	03	-	1 = 1
50.33	FBA B comm loss timeout	uint16	0.36553.5	s	10 = 1 s
50.34	FBA B ref1 type	uint16	010	-	1 = 1
50.35	FBA B ref2 type	uint16	010	-	1 = 1
50.37	FBA B actual 1 type	uint16	06	-	1 = 1
50.38	FBA B actual 2 type	uint16	06	-	1 = 1
50.39	FBA B SW transparent source	uint32	-	-	1 = 1
50.40	FBA B act1 transparent source	uint32	-	-	1 = 1
50.41	FBA B act2 transparent source	uint32	-	-	1 = 1
50.42	FBA B debug mode	uint16	01	-	1 = 1
50.43	FBA B control word	uint32	00000000hFFFFFFFh	-	1 = 1
50.44	FBA B reference 1	int32	-2147483648 2147483647	-	1 = 1
50.45	FBA B reference 2	int32	-2147483648 2147483647	-	1 = 1
50.46	FBA B status word	uint32	00000000hFFFFFFFh	-	1 = 1
50.47	FBA B actual value 1	int32	-2147483648 2147483647	-	1 = 1
50.48	FBA B actual value 2	int32	-2147483648 2147483647	-	1 = 1
50.51	FBA B timelevel sel	uint16	03	-	1 = 1

No.	Name	Type	Range	Unit	FbEq32					
50.56	FBA B comm supervision force	uint16	000hFFFh	-	1 = 1					
51 FBA	51 FBA A settings									
51.01	FBA A type	uint16	-	-	1 = 1					
51.02	FBA A Par2	uint16	065535	-	1 = 1					
51.26	FBA A Par26	uint16	065535	-	1 = 1					
51.27	FBA A par refresh	uint16	01	-	1 = 1					
51.28	FBA A par table ver	uint16	-	-	1 = 1					
51.29	FBA A drive type code	uint16	065535	-	1 = 1					
51.30	FBA A mapping file ver	uint16	065535	-	1 = 1					
51.31	D2FBA A comm status	uint16	06	-	1 = 1					
51.32	FBA A comm SW ver	uint16	-	-	1 = 1					
51.33	FBA A appl SW ver	uint16	-	-	1 = 1					
52 FBA	A data in									
52.01	FBA A data in1	uint32	-	-	1 = 1					
52.12	FBA A data in12	uint32	-	-	1 = 1					
53 FBA	A data out									
53.01	FBA A data out1	uint32	-	-	1 = 1					
53.12	FBA A data out12	uint32	-	-	1 = 1					
54 FBA	B settings				<u>'</u>					
54.01	FBA B type	uint16								
54.02	FBA B Par2	uint16	065535	-						
54.26	FBA B Par26	uint16	065535	-						
54.27	FBA B par refresh	uint16	01	-						
54.28	FBA B par table ver	uint16	-	-						
54.29	FBA B drive type code	uint16	065535	-						
54.30	FBA B mapping file ver	uint16	065535	-						
54.31	D2FBA B comm status	uint16	06	-						
54.32	FBA B comm SW ver	uint16	-	-						
54.33	FBA B appl SW ver	uint16	-	-						
55 FBA	B data in				•					
55.01	FBA B data in1	uint32	-	-	1 = 1					
55.12	FBA B data in12	uint32	-	-	1 = 1					
56 FBA	B data out	1								
56.01	FBA B data out1	uint32	-	-	1 = 1					
	<b>†</b>				+					

No.	Name	Туре	Range	Unit	FbEq32
56.12	FBA B data out12	uint32	-	-	1 = 1
58 Emb	edded fieldbus			<u>'</u>	
58.01	Protocol enable	uint16	-	-	1 = 1
58.02	Protocol ID	uint16	0000hFFFFh	-	1 = 1
58.03	Node address	uint16	0255	-	1 = 1
58.04	Baud rate	uint16	27	-	1 = 1
58.05	Parity	uint16	03	-	1 = 1
58.06	Communication control	uint16	02	-	1 = 1
58.07	Communication diagnostics	uint16	0000hFFFFh	-	1 = 1
58.08	Received packets	uint32	04294967295	-	1 = 1
58.09	Transmitted packets	uint32	04294967295	-	1 = 1
58.10	All packets	uint32	04294967295	-	1 = 1
58.11	UART errors	uint32	04294967295	-	1 = 1
58.12	CRC errors	uint32	04294967295	-	1 = 1
58.14	Communication loss action	uint16	05	-	1 = 1
58.15	Communication loss mode	uint16	12	-	1 = 1
58.16	Communication loss time	uint16	0.0 6000.0	S	10 = 1 s
58.17	Transmit delay	uint16	065535	ms	1 = 1 ms
58.18	EFB control word	uint32	0000hFFFFh	-	1 = 1
58.19	EFB status word	uint32	0000hFFFFh	-	1 = 1
58.25	Control profile	uint16	0, 2	-	1 = 1
58.26	EFB ref1 type	uint16	05	-	1 = 1
58.27	EFB ref2 type	uint16	05	-	1 = 1
58.28	EFB act1 type	uint16	06	-	1 = 1
58.29	EFB act2 type	uint16	06	-	1 = 1
58.30	EFB status word transparent source	uint32	-	-	1 = 1
58.31	EFB act1 transparent source	uint32	-	-	1 = 1
58.32	EFB act2 transparent source	uint32	-	-	1 = 1
58.33	Addressing mode	uint16	02	-	1 = 1
58.34	Word order	uint16	01	-	1 = 1
58.36	EFB comm supervision force	uint16	0000FFFh	-	1 = 1
58.101	Data I/O 1	uint32	-	-	1 = 1
58.102	Data I/O 2	uint32	-	-	1 = 1
58.103	Data I/O 3	uint32	-	-	1 = 1
58.104	Data I/O 4	uint32	-	-	1 = 1
58.105	Data I/O 5	uint32	-	-	1 = 1
58.106	Data I/O 6	uint32	-	-	1 = 1
58.107	Data I/O 7	uint32	-	-	1 = 1
58.124	Data I/O 24	uint32	-	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32			
74 Pump setup								
74.01	Pump enable	uint32	-	-	1 = 1			
74.02	Run-time hours reset source	uint32	-	-	1 = 1			
74.03	Gear reduction ratio	real32	1.001000.00	-	1000 = 1			
74.04	Reference type	uint32	-	-	1 = 1			
74.05	Speed ref source	uint32	-	Prpm, rpm or Hz	1 = 1			
74.06	Speed ref	real32	0.0030000.00	Prpm, rpm or Hz	100 = 1 Prpm, rpm or Hz			
74.07	Minimum speed	real32	-10000.0010000.00	Prpm, rpm or Hz	100 = 1 Prpm, rpm or Hz			
74.08	Maximum speed	real32	-10000.0010000.00	Prpm, rpm or Hz	100 = 1 Prpm, rpm or Hz			
74.10	Acc time	real32	0.00010000.000	s	1000 = 1 s			
74.11	Dec time	real32	0.00010000.000	s	1000 = 1 s			
74.12	Starting speed enable	uint32	-	-	1 = 1			
74.13	Starting speed	real32	-10000.0010000.00	Prpm, rpm or Hz	100 = 1 Prpm, rpm or Hz			
74.14	Starting speed acc time	uint32	0.00010000.000	S	1000 = 1 s			
74.15	Starting speed time delay	uint32	0.00010000.000	S	1000 = 1 s			
74.18	Minimum torque	uint32	-10000.000.00	N•m or ibft	100 = 1 N•m or lbft			
74.19	Maximum torque	uint32	0.0010000.00	N•m or lbft	100 = 1 N•m or lbft			
74.21	Brake confirmation enable	uint32	-	-	1 = 1			
74.22	Brake confirmation source	uint32	-	-	1 = 1			
74.23	Brake confirmation limit	real32	0.00100.00	%	100 = 1%			
74.24	Brake confirmation speed	real32	-500.000.00	Prpm, rpm or Hz	100 = 1 Prpm, rpm or Hz			
74.25	Brake confirmation time	real32	1.00030.000	S	1000 = 1 s			
74.26	Pressure unit selection	uint32	-	-	1 = 1			
74.27	Depth unit selection	uint32	-	-	1 = 1			
74.81	Pump speed reference	real32	-30000.0030000.00	Prpm	100 = 1 Prpm			
75 Pum	p level control							
75.01	Level control enable	-	-	-	1 = 1			
75.02	Fluid level ref	real32	0.00100000.00	m, ft or Joints	100 = 1 m, ft or Joints			
75.03	Fluid level source function	uint16	05	m	1 = 1			
75.04	Fluid level source 1	uint32	-	m	1 = 1			
75.05	Fluid level source 2	uint32	-	m	1 = 1			
75.06	Level meas range	real32	0.00100000.00	m, ft or Joints	100 = 1 m, ft or Joints			
75.07	Fluid level p-gain	real32	0.005.00	-	100 = 1			
75.08	Fluid level i-time	real32	1.0003600.000	S	1000 = 1 s			

No.	Name	Туре	Range	Unit	FbEq32
75.09	Level control invert	uint32	-	-	1 = 1
75.10	Level ref change rate	real32	0.000030000.0000	m/min	10000=1
75.30	Sleep control enable	uint32	-	-	1 = 1
75.31	Sleep warning enable	uint32	-	-	1 = 1
75.32	Sleep limit type	uint32	-	-	1 = 1
75.33	Sleep signal source function	uint16	05	-	1 = 1
75.34	Sleep signal source 1	uint32	-	-	1 = 1
75.35	Sleep signal source 2	uint32	-	-	1 = 1
75.36	Sleep level	real32	0.00100000000.00	%	100 = 1%
75.37	Sleep delay time	real32	0.00010000.000	s	1000 = 1 s
75.38	Wakeup level	real32	0.00100000000.00	%	100 = 1%
75.39	Wakeup delay time	real32	0.00010000.000	s	1000 = 1 s
75.40	Maximum sleep time	real32	0.000100000.000	s	1000 = 1 s
76 Pum	p pressure protection				
76.01	Pressure protection function	uint32	-	-	1 = 1
76.02	Pressure protection latching	uint16	02	-	1 = 1
76.03	Digital feedback source enable	uint32	-	-	1 = 1
76.04	Digital feedback source	uint32	-	-	1 = 1
76.05	Analog feedback source enable	uint32	-	-	1 = 1
76.06	Analog feedback source	uint32	-	-	1 = 1
76.07	Analog feedback limit	real32	0.0010000.00	kPa or psi	100 = 1 kPa or psi
76.08	Analog feedback limit delay time	real32	0.0003600.000	S	1000 = 1 s
77 Pum	p torque protection				
77.01	Rod torq limit display	uint32	-	-	1 = 1
77.02	Rod torq1 function	uint32	-	-	1 = 1
77.03	Rod torq1 limit type	uint32	-	-	1 = 1
77.04	Rod torq1 limit	real32	0.0010000.00	N•m, lbft or A	100 = 1 N•m, lbft or A
77.05	Rod torq1 speed	real32	-3600.003600.00	Prpm, rpm or Hz	100 = 1 Prpm, rpm or Hz
77.06	Rod torq1 delay time	real32	0.00010000.000	S	1000 = 1 s
77.07	Rod torq2 function	uint32	-	-	1 = 1
77.08	Rod torq2 limit type	uint32	-	-	1 = 1
77.09	Rod torq2 limit	real32	0.0010000.00	N•m, lbft or A	100 = 1 N•m, lbft or A
77.10	Rod torq2 delay time	real32	0.00010000.000	s	100 = 1 s
77.11	Rod torq2 additive speed ref	real32	-3600.003600.00	Prpm, rpm or Hz	100 = 1 Prpm, rpm or Hz
77.12	Rod torq2 speed delay time	real32	0.000100000.000	s	1000 = 1 s
	•	•	•		

No.	Name	Type	Range	Unit	FbEq32
77.13	Rod torq2 limit counter	real32	0100	-	1 = 1
77.14	Rod torq2 time window	real32	0.0007200.000	s	1000 = 1 s
78 Pum	p underload protection			•	
78.01	Underload limit display	uint32	-	-	1 = 1
78.02	Underload function	uint32	-	-	1 = 1
78.03	Torque1	real32	0.0010000.00	T(%) or A(%)	100 = 1 T(%) or A(%)
78.04	Speed1	real32	-3600.003600.00	Prpm, rpm or Hz	100 = 1 Prpm, rpm or Hz
78.05	Torque2	real32	0.0010000.00	T(%) or A(%)	100 = 1 T(%) or A(%)
78.06	Speed2	real32	-3600.003600.00	rpm or Hz	100 = 1 Prpm, rpm, Hz
78.07	Torque3	real32	0.0010000.00	T(%) or A(%)	100 = 1 T(%) or A(%)
78.08	Speed3	real32	-3600.003600.00	Prpm, rpm or Hz	100 = 1 Prpm, rpm or Hz
78.09	Underload delay time	real32	0.000100000.000	s	1000 = 1 s
79 Pum	p temperature protection				
79.01	Temperature protection function	uint32	-	-	1 = 1
79.02	Temperature protection device	uint16	02	-	1 = 1
79.03	Klixon signal source	uint32	-	-	1 = 1
79.04	PT100 source	uint32	-	F,C	1 = 1
79.05	PT100 exitation source	uint32	-	mA	1 = 1
79.06	PT100 internal selection	real32	0.0020.00	mA	100 = 1 mA
79.07	Number of PT100 sensors in series	uint16	13	-	1 = 1
79.08	Warning temperature limit	real32	0.00200.00	°C or °F	100 = 1 °
79.09	Fault temperature limit	real32	0.00200.00	°C or °F	100 = 1 °
80 Pum	p backspin control				
80.01	Backspin enable	uint32	-	-	1 = 1
80.02	Backspin ref limit	real32	-500.000.00	Prpm	1 = 1
80.03	Backspin acc time	real32	0.00010000.000	s	1 = 1
80.04	Backspin stop torque	real32	0.0010000.00	Nm	1 = 1
80.05	Backspin speed range trim	real32	0.00100.00	%	1 = 1
80.06	Backspin stop delay	real32	0.0003600.000	s	1000 = 1 s
80.11	Restart delay enable	uint32	-	-	1 = 1 mA
80.12	Restart delay time	real32	0 4294967.295	s	1000 = 1 s
80.21	Backspin dec time	real32	0.0001800.000	s	1000 = 1 s
90 Feed	back selection			•	
90.01	Motor speed for control	real32	-32768.0032767.00	rpm	100 = 1 rpm

No.	Name	Туре	Range	Unit	FbEq32
90.02	Motor position	real32	0.000000001.00000000	rev	100000000 = 1 rev
90.03	Load speed	real32	-32768.0032767.00	rpm	100 = 1 rpm
90.04	Load position	int32	-2147483648 2147483647	rev	1 = 1
90.05	Load position scaled	real32	-2147483.250 2147483.250	-	100000 = 1
90.06	Motor position scaled	int32	-2147483.648 2147483.647	-	1000 = 1
90.07	Load position scaled int	int32	-2147483648 2147483647	-	1 = 1
90.10	Encoder 1 speed	real32	-32768.0032767.00	rpm	100 = 1 rpm
90.11	Encoder 1 position	real32	0.000000001.00000000	rev	100000000 = 1 rev
90.12	Encoder 1 multiturn revolutions	uint32	016777215	-	1 = 1
90.13	Encoder 1 revolution extension	int32	-2147483648 2147483647	-	1 = 1
90.14	Encoder 1 position raw	uint32	016777215	-	1 = 1
90.15	Encoder 1 revolutions raw	uint32	016777215	-	1 = 1
90.20	Encoder 2 speed	real32	-32768.0032767.00	rpm	100 = 1 rpm
90.21	Encoder 2 position	real32	0.000000001.00000000	rev	100000000 = 1 rev
90.22	Encoder 2 multiturn revolutions	uint32	016777215	-	1 = 1
90.23	Encoder 2 revolution extension	int32	-2147483648 2147483647	-	1 = 1
90.24	Encoder 2 position raw	uint32	016777215	-	1 = 1
90.25	Encoder 2 revolutions raw	uint32	016777215	-	1 = 1
90.26	Motor revolution extension	int32	-2147483648 2147483647	-	1 = 1
90.27	Load revolution extension	int32	-2147483648 2147483647	-	1 = 1
90.35	Pos counter status	uint16	0000000b1111111b	-	1 = 1
90.38	Pos counter decimals	uint16	09	-	1 = 1
90.41	Motor feedback selection	uint16	02	-	1 = 1
90.42	Motor speed filter time	real32	010000	ms	1 = 1 ms
90.43	Motor gear numerator	int32	-2147483648 2147483647	-	1 = 1
90.44	Motor gear denominator	int32	-2147483648 2147483647	-	1 = 1
90.45	Motor feedback fault	uint16	01	-	1 = 1
90.46	Force open loop	uint16	01	-	1 = 1
90.48	Motor position axis mode	uint16	01	1	1 = 1

No.	Name	Type	Range	Unit	FbEq32
90.49	Motor position resolution	uint16	031	-	1 = 1
90.51	Load feedback selection	uint16	04	-	1 = 1
90.52	Load speed filter time	real32	010000	ms	1 = 1 ms
90.53	Load gear numerator	int32	-2147483648	-	1 = 1
			2147483647		
90.54	Load gear denominator	int32	-2147483648	-	1 = 1
			2147483647		
90.55	Load feedback fault	uint16	01	-	1 = 1
90.56	Load position offset	int32	-2147483648 2147483647	rev	1 = 1 rev
90.57	Load position resolution	uint16	031	-	1 = 1
90.58	Pos counter init value int	int32	-2147483648 2147483647	-	1 = 1
90.59	Pos counter init value int source	uint32	-	-	1 = 1
90.60	Pos counter error and boot action	uint16	01	-	1 = 1
90.61	Gear numerator	int32	-2147483648 2147483647	-	1 = 1
90.62	Gear denominator	int32	-2147483648 2147483647	-	1 = 1
90.63	Feed constant numerator	int32	-2147483648 2147483647	-	1 = 1
90.64	Feed constant denominator	int32	-2147483648 2147483647	-	1 = 1
90.65	Pos counter init value	real32	-2147483.648 2147483.647	-	1 = 1
90.66	Pos counter init value source	uint32	-	-	1 = 1
90.67	Pos counter init cmd source	uint32	-	-	1 = 1
90.68	Disable pos counter initialization	uint32	-	-	1 = 1
90.69	Reset pos counter init ready	uint32	-	-	1 = 1
91 Enc	oder module settings				<u>'</u>
91.01	FEN DI status	uint16	0000 0000b0011 0011b	-	1 = 1
91.02	Module 1 status	uint16	-	-	1 = 1
91.03	Module 2 status	uint16	-	-	1 = 1
91.04	Module 1 temperature	real32	01000	°C	1 = 1 °C
91.06	Module 2 temperature	real32	01000	°C	1 = 1 °C
91.10	Encoder parameter refresh	uint16	01	-	1 = 1
91.11	Module 1 type	uint16	04	-	1 = 1
91.12	Module 1 location	uint16	4254	-	1 = 1
91.13	Module 2 type	uint16	04	-	1 = 1
91.14	Module 2 location	uint16	4254	-	1 = 1
91.21	Module 1 temp sensor type	uint16	02	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32
91.22	Module 1 temp filter time	real32	010000	ms	1 = 1 ms
91.24	Module 2 temp sensor type	uint16	02	-	1 = 1
91.25	Module 2 temp filter time	real32	010000	ms	1 = 1 ms
91.31	Module 1 TTL output source	uint16	02	-	1 = 1
91.32	Module 1 emulation pulses/rev	uint16	065535	-	1 = 1
91.33	Module 1 emulated Z-pulse offset	real32	0.00000 1.00000	rev	100000 = 1 rev
91.41	Module 2 TTL output source	uint16	02	-	1 = 1
91.42	Module 2 emulation pulses/rev	uint16	065535	-	1 = 1
91.43	Module 2 emulated Z-pulse offset	real32	0.00000 1.00000	rev	100000 = 1 rev
92 Enco	der 1 configuration				
92.01	Encoder 1 type	uint16	07	-	1 = 1
92.02	Encoder 1 source	uint16	12	-	1 = 1
			n a TTL, TTL+ and HTL encodelepending on encoder type se		ed
92.10	Pulses/revolution	uint16	065535	-	1 = 1
92.11	Pulse encoder type	uint16	01	-	1 = 1
92.12	Speed calculation mode	uint16	05	-	1 = 1
92.13	Position estimation enable	uint16	01	-	1 = 1
92.14	Speed estimation enable	uint16	01	-	1 = 1
92.15	Transient filter	uint16	03	-	1 = 1
92.17	Accepted pulse freq of encoder 1	uint16	0300	kHz	1 = 1 kHz
92.21	Encoder cable fault mode	uint16	03	-	1 = 1
92.23	Maximum pulse waiting time	real32	1200	ms	1 = 1 ms
92.24	Pulse edge filtering	uint16	02	-	1 = 1
92.25	Pulse overfrequency function	uint16	01	-	1 = 1
	Other parameters in	this group	when an absolute encoder is	selected	
92.10	Sine/cosine number	uint16	065535	-	1 = 1
92.11	Absolute position source	uint16	05	-	1 = 1
92.12	Zero pulse enable	uint16	01	-	1 = 1
92.13	Position data width	uint16	032	-	1 = 1
92.14	Revolution data width	uint16	032	-	1 = 1
92.30	Serial link mode	uint16	02	-	1 = 1
92.31	EnDat max calculation time	uint16	03	-	1 = 1
92.32	SSI cycle time	uint16	05	-	1 = 1
92.33	SSI clock cycles	uint16	2127	-	1 = 1
92.34	SSI position msb	uint16	1126	-	1 = 1
92.35	SSI revolution msb	uint16	1126	-	1 = 1
92.36	SSI data format	uint16	01	-	1 = 1

92.40 SSI zero phase	No.	Name	Туре	Range	Unit	FbEq32
92.45 Hiperface parity	92.37	SSI baud rate	uint16	05	-	1 = 1
92.46 Hiperface baud rate	92.40	SSI zero phase	uint16	03	-	1 = 1
Pulses/revolution   wint16	92.45	Hiperface parity	uint16	01	-	1 = 1
Second Color   Seco	92.46	Hiperface baud rate	uint16	03	-	1 = 1
92.10 Excitation signal frequency	92.47	Hiperface node address	uint16	0255	-	1 = 1
92.11 Excitation signal amplitude wint16		Other paramet	ers in this	group when resolver is selec	ted	
	92.10	Excitation signal frequency	uint16	120	kHz	1 = 1 kHz
33   Encoder 2 configuration	92.11	Excitation signal amplitude	uint16	4.012.0	V	10 = 1 V
93.01   Encoder 2 type	92.12	Resolver polepairs	uint16	132	-	1 = 1
1	93 Enco	oder 2 configuration				
Other parameters in this group when a TTL, TTL+ and HTL encoder is selected (93.17, 93.2393.25 visible depending on encoder type selection)  93.10 Pulses/revolution	93.01	Encoder 2 type	uint16	07	-	1 = 1
93.17,   93.2393.25 visible depending on encoder type selection    93.10   Pulses/revolution   uint16   065535   -   1 = 1     93.11   Pulse encoder type   uint16   01   -   1 = 1     93.12   Speed calculation mode   uint16   05   -   1 = 1     93.13   Position estimation enable   uint16   01   -   1 = 1     93.14   Speed estimation enable   uint16   01   -   1 = 1     93.15   Transient filter   uint16   03   -   1 = 1     93.17   Accepted pulse freq of   uint16   0300   kHz   1 = 1 kHz     93.21   Encoder cable fault mode   uint16   03   -   1 = 1     93.23   Maximum pulse waiting time   real32   1200   ms   1 = 1 ms     93.24   Pulse edge filtering   uint16   02   -   1 = 1     93.25   Pulse overfrequency function   uint16   01   -   1 = 1     Other parameters in this group when parameter 93.01 Encoder 2 type = Abs enc     93.10   Sine/cosine number   uint16   065535   -   1 = 1     93.11   Absolute position source   uint16   05   -   1 = 1     93.12   Zero pulse enable   uint16   032   -   1 = 1     93.13   Position data width   uint16   032   -   1 = 1     93.14   Revolution data width   uint16   032   -   1 = 1     93.30   Serial link mode   uint16   03   -   1 = 1     93.31   Sil clock cycles   uint16   05   -   1 = 1     93.32   Sil clock cycles   uint16   05   -   1 = 1     93.33   Sil clock cycles   uint16   05   -   1 = 1     93.34   Sil position msb   uint16   05   -   1 = 1     93.35   Sil data format   uint16   05   -   1 = 1     93.36   Sil data format   uint16   05   -   1 = 1     93.37   Sil baud rate   uint16   05   -   1 = 1	93.02	Encoder 2 source	uint16	12	-	1 = 1
93.10 Pulses/revolution						
93.12 Speed calculation mode	93.10	Pulses/revolution	uint16	065535	-	1 = 1
93.13 Position estimation enable	93.11	Pulse encoder type	uint16	01	-	1 = 1
93.14 Speed estimation enable	93.12	Speed calculation mode	uint16	05	-	1 = 1
93.15 Transient filter	93.13	Position estimation enable	uint16	01	-	1 = 1
93.17 Accepted pulse freq of encoder 2	93.14	Speed estimation enable	uint16	01	-	1 = 1
encoder 2	93.15	Transient filter	uint16	03	-	1 = 1
93.23         Maximum pulse waiting time         real32         1200         ms         1 = 1 ms           93.24         Pulse edge filtering         uint16         02         -         1 = 1           93.25         Pulse overfrequency function         uint16         01         -         1 = 1           Other parameters in this group when parameter 93.01 Encoder 2 type = Abs enc           93.10         Sine/cosine number         uint16         065535         -         1 = 1           93.11         Absolute position source         uint16         05         -         1 = 1           93.12         Zero pulse enable         uint16         01         -         1 = 1           93.12         Zero pulse enable         uint16         032         -         1 = 1           93.13         Position data width         uint16         032         -         1 = 1           93.14         Revolution data width         uint16         032         -         1 = 1           93.30         Serial link mode         uint16         03         -         1 = 1           93.31         EnDat calc time         uint16         05         -         1 = 1           93.32         SS	93.17		uint16	0300	kHz	1 = 1 kHz
93.24 Pulse edge filtering	93.21	Encoder cable fault mode	uint16	03	-	1 = 1
93.25 Pulse overfrequency function	93.23	Maximum pulse waiting time	real32	1200	ms	1 = 1 ms
Other parameters in this group when parameter 93.01 Encoder 2 type = Abs enc           93.10 Sine/cosine number         uint16         065535         -         1 = 1           93.11 Absolute position source         uint16         05         -         1 = 1           93.12 Zero pulse enable         uint16         01         -         1 = 1           93.13 Position data width         uint16         032         -         1 = 1           93.14 Revolution data width         uint16         032         -         1 = 1           93.30 Serial link mode         uint16         02         -         1 = 1           93.31 EnDat calc time         uint16         03         -         1 = 1           93.32 SSI cycle time         uint16         05         -         1 = 1           93.33 SSI clock cycles         uint16         2127         -         1 = 1           93.34 SSI position msb         uint16         1126         -         1 = 1           93.35 SSI revolution msb         uint16         01         -         1 = 1           93.37 SSI baud rate         uint16         05         -         1 = 1           93.37 SSI bard rate         uint16         03         -	93.24	Pulse edge filtering	uint16	02	-	1 = 1
93.10         Sine/cosine number         uint16         065535         -         1 = 1           93.11         Absolute position source         uint16         05         -         1 = 1           93.12         Zero pulse enable         uint16         01         -         1 = 1           93.13         Position data width         uint16         032         -         1 = 1           93.14         Revolution data width         uint16         032         -         1 = 1           93.30         Serial link mode         uint16         03         -         1 = 1           93.31         EnDat calc time         uint16         03         -         1 = 1           93.32         SSI cycle time         uint16         05         -         1 = 1           93.33         SSI clock cycles         uint16         2127         -         1 = 1           93.34         SSI position msb         uint16         1126         -         1 = 1           93.35         SSI revolution msb         uint16         01         -         1 = 1           93.37         SSI baud rate         uint16         05         -         1 = 1           93.37	93.25	Pulse overfrequency function	uint16	01	-	1 = 1
93.11         Absolute position source         uint16         05         -         1 = 1           93.12         Zero pulse enable         uint16         01         -         1 = 1           93.13         Position data width         uint16         032         -         1 = 1           93.14         Revolution data width         uint16         032         -         1 = 1           93.30         Serial link mode         uint16         02         -         1 = 1           93.31         EnDat calc time         uint16         03         -         1 = 1           93.32         SSI cycle time         uint16         05         -         1 = 1           93.33         SSI clock cycles         uint16         2127         -         1 = 1           93.34         SSI position msb         uint16         1126         -         1 = 1           93.35         SSI revolution msb         uint16         01         -         1 = 1           93.37         SSI baud rate         uint16         05         -         1 = 1           93.37         SSI baud rate         uint16         03         -         1 = 1		Other parameters in this g	roup when	parameter 93.01 Encoder 2	type = Abs e	nc
93.12 Zero pulse enable	93.10	Sine/cosine number	uint16	065535	-	1 = 1
93.13 Position data width	93.11	Absolute position source	uint16	05	-	1 = 1
93.14         Revolution data width         uint16         032         -         1 = 1           93.30         Serial link mode         uint16         02         -         1 = 1           93.31         EnDat calc time         uint16         03         -         1 = 1           93.32         SSI cycle time         uint16         05         -         1 = 1           93.33         SSI clock cycles         uint16         2127         -         1 = 1           93.34         SSI position msb         uint16         1126         -         1 = 1           93.35         SSI revolution msb         uint16         1126         -         1 = 1           93.36         SSI data format         uint16         01         -         1 = 1           93.37         SSI baud rate         uint16         05         -         1 = 1           93.40         SSI zero phase         uint16         03         -         1 = 1	93.12	Zero pulse enable	uint16	01	-	1 = 1
93.30         Serial link mode         uint16         02         -         1 = 1           93.31         EnDat calc time         uint16         03         -         1 = 1           93.32         SSI cycle time         uint16         05         -         1 = 1           93.33         SSI clock cycles         uint16         2127         -         1 = 1           93.34         SSI position msb         uint16         1126         -         1 = 1           93.35         SSI revolution msb         uint16         1126         -         1 = 1           93.36         SSI data format         uint16         01         -         1 = 1           93.37         SSI baud rate         uint16         05         -         1 = 1           93.40         SSI zero phase         uint16         03         -         1 = 1	93.13	Position data width	uint16	032	-	1 = 1
93.31         EnDat calc time         uint16         03         -         1 = 1           93.32         SSI cycle time         uint16         05         -         1 = 1           93.33         SSI clock cycles         uint16         2127         -         1 = 1           93.34         SSI position msb         uint16         1126         -         1 = 1           93.35         SSI revolution msb         uint16         1126         -         1 = 1           93.36         SSI data format         uint16         01         -         1 = 1           93.37         SSI baud rate         uint16         05         -         1 = 1           93.40         SSI zero phase         uint16         03         -         1 = 1	93.14	Revolution data width	uint16	032	-	1 = 1
93.32         SSI cycle time         uint16         05         -         1 = 1           93.33         SSI clock cycles         uint16         2127         -         1 = 1           93.34         SSI position msb         uint16         1126         -         1 = 1           93.35         SSI revolution msb         uint16         1126         -         1 = 1           93.36         SSI data format         uint16         01         -         1 = 1           93.37         SSI baud rate         uint16         05         -         1 = 1           93.40         SSI zero phase         uint16         03         -         1 = 1	93.30	Serial link mode	uint16	02	-	1 = 1
93.33     SSI clock cycles     uint16     2127     -     1 = 1       93.34     SSI position msb     uint16     1126     -     1 = 1       93.35     SSI revolution msb     uint16     1126     -     1 = 1       93.36     SSI data format     uint16     01     -     1 = 1       93.37     SSI baud rate     uint16     05     -     1 = 1       93.40     SSI zero phase     uint16     03     -     1 = 1	93.31	EnDat calc time	uint16	03	-	1 = 1
93.34 SSI position msb	93.32	SSI cycle time	uint16	05	-	1 = 1
93.35       SSI revolution msb       uint16       1126       -       1 = 1         93.36       SSI data format       uint16       01       -       1 = 1         93.37       SSI baud rate       uint16       05       -       1 = 1         93.40       SSI zero phase       uint16       03       -       1 = 1	93.33	SSI clock cycles	uint16	2127	-	1 = 1
93.36 SSI data format	93.34	SSI position msb	uint16	1126	-	1 = 1
93.37 SSI baud rate	93.35	SSI revolution msb	uint16	1126	-	1 = 1
93.40 SSI zero phase <i>uint16</i> 03 - 1 = 1	93.36	SSI data format	uint16	01	-	1 = 1
	93.37	SSI baud rate	uint16	05	-	1 = 1
93.45 Hiperface parity <i>uint16</i> 01 - 1 = 1	93.40	SSI zero phase	uint16	03	-	1 = 1
	93.45	Hiperface parity	uint16	01	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32
93.46	Hiperface baud rate	uint16	03	-	1 = 1
93.47	Hiperface node address	uint16	0255	-	1 = 1
	Other paramete	ers in this g	group when a resolver is seled	cted	
93.10	Excitation signal frequency	uint16	120	kHz	1 = 1 kHz
93.11	Excitation signal amplitude	uint16	4.012.0	V	10 = 1 V
93.12	Resolver polepairs	uint16	132	-	1 = 1
94 LSU	control				
	(Group only visible	e when su	pply unit control activated by	95.20)	
94.01	LSU control	uint16	01	-	1 = 1
94.02	LSU panel communication	uint16	01	-	1 = 1
	(Parameter 9	4.04 only	visible with certain drive types	s)	
94.04	INU-LSU status word profile	uint16	01	-	1 = 1
94.10	LSU max charging time	uint16	065535	s	1 = 1 s
94.11	LSU stop delay	uint16	0.0 3600.0	s	10 = 1 s
	(Parameters 94.2094.32 onl	y visible w	hen IGBT supply unit control	activated by	95.20)
94.20	DC voltage reference	real32	0.0 2000.0	V	10 = 1 V
94.21	DC voltage ref source	uint32	-	-	1 = 1
94.22	User DC voltage reference	real32	0.0 2000.0	V	10 = 1 V
94.30	Reactive power reference	real32	-3276.8 3276.7	kvar	10 = 1 kvar
94.31	Reactive power ref source	uint32	-	-	1 = 1
94.32	User reactive power reference	real32	-3276.8 3276.7	kvar	10 = 1 kvar
	(Parameters 94.40 and 94.41	only visib	le when supply unit control ac	ctivated by 9	5. 20)
94.40	Power mot limit on net loss	real32	0.00 600.00	%	100 = 1%
94.41	Power gen limit on net loss	real32	-600.00 0.00	%	100 = 1%
95 HW c	configuration				
95.01	Supply voltage	uint16	06	-	1 = 1
95.02	Adaptive voltage limits	uint16	01	-	1 = 1
95.04	Control board supply	uint16	02	-	1 = 1
	(Parameter 9	5.08 only	visible with a ZCU control uni	t)	
95.08	DC switch monitoring	uint16	01	-	1 = 1
(Parame	eters 95.0995.14 only visible v	vith a BCU	control unit)		
95.09	Switch fuse controller	uint16	01	-	1 = 1
95.13	Reduced run mode	uint16	065535	-	1 = 1
95.14	Connected modules	uint16	0000hFFFh	-	1 = 1
95.15	Special HW settings	uint16	0000b0111b	-	1 = 1
95.16	Router mode	uint32	-	-	1 = 1
95.17	Router channel config	uint16	0000hFFFFh	-	1 = 1
95.20	HW options word 1	uint16	0000hFFFFh	-	1 = 1
95.21	HW options word 2	uint16	0000hFFFFh	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32
	(Parameters 95.3	095.31	only visible with a BCU contro	ol unit)	
95.30	Parallel type list filter	uint16	15	-	1 = 1
95.31	Parallel type configuration	uint16	-	-	1 = 1
95.35	Adjustable supply voltage	real32	-	-	1 = 1
95.36	Supply voltage low	real32	0.01000.0	V	10 = 1
95.37	Supply voltage high	real32	0.01000.0	V	10 = 1
95.40	Transformation ratio	real32	0.000100.000	-	1000 = 1
96 Syst	em				
96.01	Language	uint16	-	-	1 = 1
96.02	Pass code	uint32	099999999	-	1 = 1
96.03	Access levels active	uint16	0000hFFFFh	-	1 = 1
96.04	Macro select	uint16	06	-	1 = 1
96.05	Macro active	uint16	16	-	1 = 1
96.06	Parameter restore	uint16	-	-	1 = 1
96.07	Parameter save manually	uint16	01	-	1 = 1
96.08	Control board boot	uint16	01	-	1 = 1
96.09	FSO reboot	uint32	-	-	-
96.10	User set status	uint16	-	-	-
96.11	User set save/load	uint16	-	-	-
96.12	User set IO mode in1	uint32	-	-	-
96.13	User set IO mode in2	uint32	-	-	
96.16	Unit selection	uint16	0000 0000b0001 0101b	-	1 = 1
96.20	Time sync primary source	uint16	09	-	1 = 1
96.24	Full days since 1st Jan 1980	uint16	159999	-	1 = 1
96.25	Time in minutes within 24 h	uint16	01439	-	1 = 1
96.26	Time in ms within one minute	uint16	059999	-	1 = 1
96.29	Time sync source status	uint16	0000hFFFFh	-	1 = 1
96.31	Drive ID number	uint16	032767	-	1 = 1
96.39	Power up event logging	uint16	01	-	1 = 1
96.51	Clear fault and event logger	uint16	065535	-	1 = 1
96.53	Actual checksum	uint32	00000000hFFFFFFFh	-	1 = 1
96.54	Checksum action	uint16	04	-	1 = 1
96.55	Checksum control word	uint16	0000hFFFFh	-	1 = 1
96.56	Approved checksum 1	uint32	00000000hFFFFFFFh	-	1 = 1
96.57	Approved checksum 2	uint32	00000000hFFFFFFFh	-	1 = 1
96.58	Approved checksum 3	uint32	00000000hFFFFFFFh	-	1 = 1
96.59	Approved checksum 4	uint32	00000000hFFFFFFFh	-	1 = 1
96.61	User data logger status word	uint16	0000hFFFFh	-	1 = 1
96.63	User data logger trigger	uint32	-	-	-
96.64	User data logger start	uint32	-	-	-

No.	Name	Туре	Range	Unit	FbEq32
96.65	Factory data logger time level	uint16	-	-	1 = 1
96.70	Disable adaptive program	uint16	01	-	1 = 1
	(Parameters 96.10096	6.102 only	visible when enabled by para	meter <mark>96.02</mark> )	
96.100	Change user pass code	uint32	1000000099999999	-	1 = 1
96.101	Confirm user pass code	uint32	1000000099999999	-	1 = 1
96.102	User lock functionality	uint16	0000hFFFFh	-	1 = 1
	(Parameter 96.108 only vis	sible when	IGBT supply unit control acti	vated by 95.2	20)
96.108	LSU control board boot	uint16	01	-	1 = 1
97 Moto	r control	•			
97.01	Switching frequency reference	real32	0.000 24.000	kHz	1000 = 1%
97.02	Minimum switching frequency	real32	0.000 24.000	kHz	1000 = 1%
97.03	Slip gain	real32	0200	%	1 = 1%
97.04	Voltage reserve	real32	-450	%	1 = 1%
97.05	Flux braking	uint16	02	-	1 = 1
97.06	Flux reference select	uint32	-	-	1 = 1
97.07	User flux reference	real32	0200	%	100 = 1%
97.08	Optimizer minimum torque	real32	0.0 1600.0	%	10 = 1%
97.09	Switching freq mode	uint16	03	-	1 = 1
97.10	Signal injection	uint16	04	-	1 = 1
97.11	TR tuning	real32	25400	%	1 = 1%
97.12	IR comp step-up frequency	real32	0.050.0	Hz	10 = 1 Hz
97.13	IR compensation	real32	0.0050.00	%	100 = 1%
97.15	Motor model temperature adaptation	uint16	01	-	1 = 1
97.18	Hexagonal field weakening	uint16	01	-	1 = 1
97.19	Hexagonal field weakening point	real32	0.0 500.0	%	10 = 1%
97.32	Motor torque unfiltered	real32	-1600.01600.0	%	10 = 1%
97.33	Speed estimate filter time	real32	0.00100.00	ms	100 = 1 ms
97.90	Total circuit inductance	real32	0.0010.00	p.u	100 = 1 p.u
97.91	Low speed current control enable	uint32	-	-	1 = 1
97.92	Low speed current ref	real32	0.0300.0	%	10 = 1%
97.93	Low speed limit	real32	0.0100.0	%	10 = 1%
97.94	IR comp max frequency	real32	1.01000.0	%	10 = 1%
97.95	Flying start speed measurement	uint32	-	-	1 = 1
98 User	motor parameters				
98.01	User motor model mode	uint16	03	-	1 = 1
98.02	Rs user	real32	0.00000.50000	p.u.	100000 = 1 p.u.

No.	Name	Туре	Range	Unit	FbEq32
98.03	Rr user	real32	0.00000.50000	p.u.	100000 = 1 p.u.
98.04	Lm user	real32	0.0000010.00000	p.u.	100000 = 1 p.u.
98.05	SigmaL user	real32	0.000001.00000	p.u.	100000 = 1 p.u.
98.06	Ld user	real32	0.0000010.00000	p.u.	100000 = 1 p.u.
98.07	Lq user	real32	0.0000010.00000	p.u.	100000 = 1 p.u.
98.08	PM flux user	real32	0.000002.00000	p.u.	100000 = 1 p.u.
98.09	Rs user SI	real32	0.00000100.00000	ohm	100000 = 1 p.u.
98.10	Rr user SI	real32	0.00000100.00000	ohm	100000 = 1 p.u.
98.11	Lm user SI	real32	0.00100000.01	mH	100 = 1 mH
98.12	SigmaL user SI	real32	0.00100000.01	mH	100 = 1 mH
98.13	Ld user SI	real32	0.00100000.01	mH	100 = 1 mH
98.14	Lq user SI	real32	0.00100000.01	mH	100 = 1 mH
98.15	Position offset user	real32	0360	° electrical	1 = 1° electrical
99 Moto	or data				
99.03	Motor type	uint16	02	-	1 = 1
99.04	Motor ctrl mode	uint16	01	-	1 = 1
99.06	Motor nominal current	real32	0.06400.0	Α	10 = 1 A
99.07	Motor nominal voltage	real32	0.0800.0	V	10 = 1 V
99.08	Motor nominal frequency	real32	0.00 1000.00	Hz	100 = 1 Hz
99.09	Motor nominal speed	real32	030000	rpm	1 = 1 rpm
99.10	Motor nominal power	real32	0.0010000.00 kW or 0.0013404.83 hp	kW or hp	100 = 1 unit
99.11	Motor nominal cos ?	real32	0.001.00	-	100 = 1
99.12	Motor nominal torque	uint32	0.0004000000.000	N•m or lb.ft	1000 = 1 unit
99.13	ID run requested	uint16	07	-	1 = 1
99.14	Last ID run performed	uint16	07	-	1 = 1
99.15	Motor polepairs calculated	uint16	01000	-	1 = 1
99.16	Motor phase order	uint16	01	-	1 = 1
99.18	Sine filter inductance	real32	0.000 100000.000	mH	1000 = 1 mH
99.19	Sine filter capacitance	real32	0.00 100000.00	μF	100 = 1 μF

## 200 Safety

This group contains parameters related to the optional FSO-xx safety functions module. For details, refer to the documentation of the FSO-xx module.

## 472 Additional parameter data

No.	Name	Туре	Range	Unit	FbEq32
207 I/O I 208 I/O I	bus configuration bus service bus diagnostics bus fan identification				
(Groups only visible with a BCU control unit) These groups contain parameters related to the distributed I/O					

(Groups only visible with a BCU control unit) These groups contain parameters related to the distributed I/O bus, which is used with some drives for monitoring the cooling fans of the cabinet system. For details, refer to ACS880 distributed I/O bus supplement (3AXD50000126880 [English]).



# Fault tracing

# Contents of this chapter

The chapter lists the warning and fault messages including possible causes and corrective actions. The causes of most warnings and faults can be identified and corrected using the information in this chapter. If not, an ABB service representative should be contacted.

Warnings and faults are listed below in separate tables. Each table is sorted by warning/fault code.

# Safety



**WARNING!** Only qualified electricians are allowed to service the drive. Read the Safety instructions on the first pages of the Hardware manual before working on the drive.

## Indications

### Warnings and faults

Warnings and faults indicate an abnormal drive status. The codes and names of active warnings/faults are displayed on the control panel of the drive as well as the Drive composer PC tool. Only the codes of warnings/faults are available over fieldbus.

Warnings do not need to be reset; they stop showing when the cause of the warning ceases. Warnings do not latch and the drive will continue to operate the motor.

Faults do latch inside the drive and cause the drive to trip, and the motor stops. After the cause of a fault has been removed, the fault can be reset from a selectable source (see parameter 31.11 Fault reset selection) such as the control panel, Drive composer PC tool, the digital inputs of the drive, or fieldbus. After the fault is reset, the drive can be restarted. Note that some faults require a reboot of the control unit either by switching the power off and on, or using parameter 96.08 Control board boot – this is mentioned in the fault listing wherever appropriate.

Warning and fault indications can be directed to a relay output or a digital input/output by selecting *Warning*, *Fault* or *Fault* (-1) in the source selection parameter. See sections

- Programmable digital inputs and outputs (page 59)
- · Programmable relay outputs (page 60), and
- Programmable I/O extensions (page 60).

#### Pure events

In addition to warnings and faults, there are pure events that are only recorded in the event logs of the drive. The codes of these events are included in the *Warning messages* table.

## Editable messages

For some warnings and faults, the message text can be edited and instructions and contact information added. To edit these messages, choose **Menu** - **Settings** - **Edit texts** on the control panel.

# Warning/fault history and analysis

#### Event logs

The drive has two event logs. One log contains faults and fault resets; the other contains warnings, pure events, and clearing entries. Each log contains the 64 most recent events with a time stamp and other information.

The logs can be accessed separately from the main Menu on the control panel. The logs are displayed as a single list when viewed using the Drive composer PC tool.

The logs can be cleared using parameter 96.51 Clear fault and event logger.

## **Auxiliary codes**

Some events generate an auxiliary code that often helps in pinpointing the problem. The auxiliary code is displayed on the control panel together with the message. It is also stored in the event log details. In the Drive composer PC tool, the auxiliary code (if any) is shown in the event listing.

#### Factory data logger

The drive has a data logger that samples preselected drive values at 500microsecond (default; see parameter 96.65 Factory data logger time level) intervals. Approximately 700 samples recorded immediately before and after a fault are saved to the memory unit of the drive. The fault data of the last five faults is accessible in the event log when viewed in the Drive composer pro PC tool. (The fault data is not accessible through the control panel.)

The values that are recorded in the factory data log are 01.07 Motor current, 01.10 Motor torque, 01.11 DC voltage, 01.24 Flux actual%, 06.01 Main control word, 06.11 Main status word, 24.01 Used speed reference, 30.01 Limit word 1, 30.02 Torque limit status and 90.01 Motor speed for control. The selection of parameters cannot be changed by the user.

### Other data loggers

#### User data logger

A custom data logger can be configured using the Drive composer pro PC tool. This functionality enables the free selection of up to eight drive parameters to be sampled at selectable intervals. The triggering conditions and the length of the monitoring period can also be defined by the user within the limit of approximately 8000 samples. In addition to the PC tool, the status of the logger is shown by drive parameter 96.61 User data logger status word. The triggering sources can be selected by parameters 96.63 User data logger trigger and 96.64 User data logger start). The configuration, status and collected data is saved to the memory unit for later analysis.

#### PSL2 data logger

The BCU control unit used with certain drive types (especially those with parallel-connected inverter modules) contains a data logger that collects data from the inverter modules to help fault tracing and analysis. The data is saved onto the SD card attached to the BCU, and can be analyzed by ABB service personnel.

#### Parameters warning/fault information

The drive is able to store a list of the active faults actually causing the drive to trip at the present time. The faults are displayed in parameter group *04 Warnings and faults* (page *126*). The parameter group also displays a list of faults and warnings that have previously occurred.

#### Event word (parameters 04.40...04.72)

Parameter *04.40 Event word 1* can be configured by the user to indicate the status of 16 selectable events (ie. faults, warnings or pure events). It is possible to specify an auxiliary code for each event to filter out other auxiliary codes.

# QR code generation for mobile service application

A QR code (or a series of QR codes) can be generated by the drive for display on the control panel. The QR code contains drive identification data, information on the latest events, and values of status and counter parameters. The code can be read with a mobile device containing the ABB service application, which then sends the data to ABB for analysis. For more information on the application, contact your local ABB service representative.

The QR code can be generated by choosing Menu - Assistants - QR code on the control panel.

# Warning messages

Note: The list also contains events that only appear in the Event log.

Code (hex)	Warning	Cause	What to do
A2A1	Current calibration	Current measurement calibration will occur at next start.	Informative warning.
A2B3	Earth leakage Programmable fault: 31.20 Earth fault	Drive has detected load unbalance typically due to earth fault in motor or motor cable.	Check there are no power factor correction capacitors or surge absorbers in motor cable. Check for an earth fault in motor or motor cables by measuring the insulation resistances of motor and motor cable. If no earth fault can be detected, contact your local ABB representative.
A2B4	Short circuit	Short-circuit in motor cable(s) or motor.	Check motor and motor cable. Check there are no power factor correction capacitors or surge absorbers in motor cable.
A2BA	IGBT overload	Excessive IGBT junction to case temperature. This warning protects the IGBT(s) and can be activated by a short circuit in the motor cable.	Check motor cable.
A3A1	DC link overvoltage	Intermediate circuit DC voltage too high (when the drive is stopped).	Check the supply voltage setting (parameter 95.01 Supply voltage). Note that the wrong setting of the parameter
A3A2	DC link undervoltage	Intermediate circuit DC voltage too low (when the drive is stopped).	may cause the motor to rush uncontrollably, or may overload the brake chopper or resistor. Check the supply voltage.
АЗАА	DC not charged	The voltage of the intermediate DC circuit has not yet risen to operating level.	If the problem persists, contact your local ABB representative.
A3C1	DC voltage difference	Difference in DC voltages between parallel- connected inverter modules.	Contact your local ABB representative.
A480	Motor cable overload	Calculated motor cable temperature has exceeded warning limit.	Check the settings of parameters 35.61 and 35.62. Check the dimensioning of the motor cable in regard to required load.
A490	Incorrect temperature sensor setup	Problem with motor temperature measurement.	Check the auxiliary code (format 0XYY ZZZZ).  "X" identifies the affected temperature monitoring function (1 = parameter 35.11, 2 = parameter 35.21).  "YY" indicates the selected temperature source, ie. the setting of the selection parameter in hexadecimal.  "ZZZZ" indicates the problem (see actions for each code below).

Code (hex)	Warning	Cause	What to do	
	0001	Sensor type mismatch	Check parameters 35.11/35.21 against 91.21/91.24.	
	0002	Temperature under limit	Check parameters	
	0003	Short circuit	35.1135.14/35.2135.24 (and 91.21/91.24 if sensor is connected to	
	0004	Open circuit	an encoder interface). Check the sensor and its wiring.	
A491	External temperature (Editable message text)	Measured temperature 1 or 2 has exceeded warning limit.	Check the values of parameters 35.02 Measured temperature 1 and 35.03 Measured temperature 2. Check the cooling of the motor (or other equipment whose temperature is being measured). Check the warning limits for measured temperatures 1 and 2 in parameter group 35 Motor thermal protection.	
A492	External temperature 2 (Editable message text)	Measured temperature 2 has exceeded warning limit.	Check the value of parameter 35.03  Measured temperature 2. Check the cooling of the motor (or other equipment whose temperature is being measured). Check the value of 35.23 Temperature 2 warning limit.	
A497	Motor temperature 1 (Editable message text)	The thermistor protection module installed in slot 1 indicates overtemperature.	Check the cooling of the motor. Check the motor load and drive ratings. Check the wiring of the temperature sensor. Repair wiring if faulty.	
A498	Motor temperature 2 (Editable message text)	The thermistor protection module installed in slot 2 indicates overtemperature.	Measure the resistance of the sensor. Replace sensor if faulty.	
A499	Motor temperature 3 (Editable message text)	The thermistor protection module installed in slot 3 indicates overtemperature.		
A4A0	Control board temperature	Control unit temperature is excessive.	Check the auxiliary code. See actions for each code below.	
	(none)	Temperature above warning limit	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up.	
	1	Thermistor broken	Contact an ABB service representative for control unit replacement.	
A4A9	Cooling	Drive module temperature is excessive.	Check ambient temperature. If it exceeds 40 °C (104 °F), ensure that load current does not exceed derated load capacity of drive. See appropriate Hardware manual.  Check drive module cooling air flow and fan operation.  Check inside of cabinet and heatsink of drive module for dust pick-up. Clean whenever necessary.	

Code (hex)	Warning	Cause	What to do
A4B0	Excess temperature	Power unit temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check the setting of 31.36 Aux fan fault function (if present). Check heatsink fins for dust pick-up. Check motor power against drive power. Check the auxiliary code (format XXXY YYZZ). "Y YY" specifies through which BCU control unit channel the fault was received. "ZZ" specifies the location (1: U-phase, 2: V-phase, 3: W-phase, 4: INT board, 5: Brake chopper, 6: Air inlet (sensor connected to INT board X10), 7: PCB compartment fan or power supply board, 8: du/dt filter or temperature switch (XT) (sensor connected to INT board X7), 9: Sensor connected to INT board X6, 0FA: Ambient temperature).
A4B1	Excess temperature difference	High temperature difference between the IGBTs of different phases.	Check the motor cabling. Check cooling of drive module(s). Check the auxiliary code (format XXXY YYZZ). "XXX" indicates the source of difference (0: Single module, difference between phase IGBTs, 1: parallel-connected modules, minimum-maximum difference between all IGBTs of all modules, 2: parallel-connected modules, minimum-maximum difference between auxiliary power supply boards). With parallel-connected modules, "YY" specifies through which BCU control unit channel the highest temperature was measured. "ZZ" specifies the phase (0: single module, 1: U-phase [parallel connection], 2: V-phase [parallel connection], 3: W-phase [parallel connection]).
A4B2	PCB space cooling	Temperature difference between ambient and drive module PCB space is excessive.	Check the cooling fan inside the PCB space. With parallel-connected modules, check the auxiliary code (format XXXY YYZZ). "Y YY" specifies through which BCU control unit channel the fault was received.
A4F6	IGBT temperature	Drive IGBT temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against drive power.

Code (hex)	Warning	Cause	What to do
A580	PU communication	Communication errors detected between the drive control unit and the power unit.	Check the connections between the drive control unit and the power unit. Check the auxiliary code (format XXXY YYZZ). With parallel-connected modules, "Y YY" specifies the affected BCU control unit channel (0: broadcast). "ZZ" specifies the error source (8: Transmission errors in PSL link [see "XXX"], 9: Transmitter FIFO warning limit hit). "XXX" specifies the transmission error direction and detailed warning code (0: Rx/communication error, 1: Tx/Reed-Solomon symbol error, 2: Tx/no synchronization error, 3: Tx/Reed-Solomon decoder failures, 4: Tx/Manchester coding errors). Read the PSL2 data log. In Drive composer pro, check the time stamp of the A580 fault. Load the log with the same date and time. When the file opens, click "Show fault log". Check the power unit hardware.
A581	Fan Programmable warning: 31.35 Main fan fault function	Cooling fan stuck or disconnected.	Check the setting of parameter 95.20 HW options word 1, bit 14. Check the auxiliary code to identify the fan. Code 0 denotes main fan 1. Other codes (format XYZ): "X" specifies state code (1: ID run, 2: normal). "Y" specifies the index of the inverter module connected to BCU (0n, always 0 for ZCU control units). "Z" specifies the index of the fan (1: Main fan 1, 2: Main fan 2, 3: Main fan 3). Note that modules are coded starting from 0. For example, the code 101 means that Main fan 1 of module 1 (connected to BCU channel V1T/V1R) has faulted during its ID run. Check fan operation and connection. Replace fan if faulty.
A582	Auxiliary fan not running Programmable warning: 31.36 Aux fan fault function	An auxiliary cooling fan (connected to the fan connectors on the control unit) is stuck or disconnected.	The auxiliary code identifies the fan (1: Auxiliary fan 1, 2: Auxiliary fan 2).  Make sure the front cover of the drive module is in place and tightened.  Check auxiliary fan(s) and connection(s).  Replace faulty fan.
A5A0	Safe torque off Programmable warning: 31.22 STO indication run/stop	Safe torque off function is active, i.e. safety circuit signal(s) connected to connector XSTO is lost.	Check safety circuit connections. For more information, see appropriate drive hardware manual and description of parameter 31.22 STO indication run/stop (page 279).

Code (hex)	Warning	Cause	What to do
A5EA	Measurement circuit temperature	Problem with internal temperature measurement of the drive.	Check the auxiliary code (format XXXY YYZZ). "Y YY" specifies through which BCU control unit channel the fault was received ("0 00" with a ZCU control unit). "ZZ" specifies the location (1: U-phase IGBT, 4: Power supply board, 5: Power unit xINT board, 6: Brake chopper, 7: Air inlet (TEMP3, X10), 8: du/dt filter (TEMP2, X7), 9: TEMP1 (X6)).
A5EB	PU board powerfail	Power unit power supply failure.	Contact your local ABB representative.
A5EC	PU communication internal	Communication errors detected between the drive control unit and the power unit.	Check the connections between the drive control unit and the power unit.
A5ED	Measurement circuit ADC	Measurement circuit fault.	Contact your local ABB representative.
A5EE	Measurement circuit DFF	Measurement circuit fault.	Contact your local ABB representative.
A5EF	PU state feedback	State feedback from output phases does not match control signals.	Contact your local ABB representative.
A5F0	Charging feedback	Charging feedback signal missing.	Informative warning. Wait until charging finishes before starting the inverter unit.
A5F3	Switching frequency below requested	Adequate motor control at requested output frequency cannot be reached because of limited switching frequency (eg. by parameter 95.15).	Informative warning.
A5F4	Control unit battery	The battery of the control unit is low.	Replace control unit battery. This warning can be suppressed using parameter 31.40.
A682	Flash erase speed exceeded	The flash memory (in the memory unit) has been erased too frequently, compromising the lifetime of the memory.	Avoid forcing unnecessary parameter saves by parameter 96.07 or cyclic parameter writes (such as user logger triggering through parameters).  Check the auxiliary code (format XYYY YZZZ). "X" specifies the source of warning (1: generic flash erase supervision). "ZZZ" specifies the flash subsector number that generated the warning.
A683	Data saving to power unit	An error in saving data to the power unit.	Check the auxiliary code. See actions for each code below.
	0	An error is preventing saving from initializing.	Cycle the power to the drive. If the control unit is externally powered, also reboot the control unit (using parameter
	2	Write error.	96.08 Control board boot) or by cycling its power. If the problem persists, contact your local ABB representative.
A684	SD card	Error related to SD card used to store data (BCU control unit only).	Check the auxiliary code. See actions for each code below.

Code (hex)	Warning	Cause	What to do
	1	No SD card	Insert a compatible, writable SD card
	2	SD card write-protected	into the SD CARD slot of the BCU control unit.
	3	SD card unreadable	33
A686	Checksum mismatch Programmable warning: 96.54 Checksum action	The calculated parameter checksum does not match any enabled reference checksum.	Check that all necessary approved (reference) checksums (96.5696.59) are enabled in 96.55 Checksum control word.  Check the parameter configuration.  Using 96.55 Checksum control word, enable a checksum parameter and copy the actual checksum into that parameter.
A687	Checksum configuration	An action has been defined for a parameter checksum mismatch but the feature has not been configured.	Contact your local ABB representative for configuring the feature, or disable the feature in 96.54 Checksum action.
A688	Parameter map configuration	Too much data in parameter mapping table created in Drive customizer.	See the <i>Drive customizer PC tool</i> user's manual (3AUA0000104167 [English]).
A689	Mapped parameter value cut	Parameter value saturated eg. by the scaling specified in parameter mapping table (created in Drive customizer).	Check parameter scaling and format in parameter mapping table. See the Drive customizer PC tool user's manual (3AUA0000104167 [English]).
A6A4	Motor nominal value	The motor parameters are set incorrectly.	Check the auxiliary code. See actions for each code below.
		The drive is not dimensioned correctly.	
	1	Slip frequency is too small	Check the settings of the motor
	2	Synchronous and nominal speeds differ too much	configuration parameters in groups 98 and 99. Check that the drive is sized correctly
	3	Nominal speed is higher than synchronous speed with 1 pole pair	for the motor.
	4	Nominal current is outside limits	
	5	Nominal voltage is outside limits	
	6	Nominal power is higher than apparent power	
	7	Nominal power not consistent with nominal speed and torque	
A6A5	No motor data	Parameters in group 99 have not been set.	Check that all the required parameters in group 99 have been set.  Note: It is normal for this warning to appear during the start-up until the motor data is entered.

Code (hex)	Warning	Cause	What to do
A6A6	Voltage category unselected	The supply voltage range has not been defined.	Define supply voltage range (parameter 95.01 Supply voltage).
A6B0	User lock is open	The user lock is open, ie. user lock configuration parameters 96.10096.102 are visible.	Close the user lock by entering an invalid pass code in parameter 96.02 Pass code. See section User lock (page 106).
A6B1	User pass code not confirmed	A new user pass code has been entered in parameter 96.100 but not confirmed in 96.101.	Confirm the new pass code by entering the same code in 96.101. To cancel, close the user lock without confirming the new code. See section <i>User lock</i> (page 106).
A6D1	FBA A parameter conflict	The drive does not have a functionality requested by PLC, or requested functionality has not been activated.	Check PLC programming. Check settings of parameter groups 50 Fieldbus adapter (FBA) and 51 FBA A settings.
A6D2	FBA B parameter conflict	The drive does not have a functionality requested by a PLC, or requested functionality has not been activated.	Check PLC programming. Check settings of parameter groups 50 Fieldbus adapter (FBA) and 54 FBA B settings.
A6DA	Reference source parametrization	A reference source is simultaneously connected to multiple parameters with different units.	Check the reference source selection parameters. Check the auxiliary code (format XXYY 00ZZ). "XX" and "YY" specify the two sets of parameters where the source was connected to (01 = speed reference chain [22.11, 22.12, 22.15, 22.17], 02 = frequency reference chain [28.11, 28.12], 3D = motor potentiometer, 65 = Al1, 66 = Al2, 6F = frequency input).
A6E5	Al parametrization	The current/voltage jumper setting of an analog input does not correspond to parameter settings.	Check the auxiliary code. The code identifies the analog input whose settings are in conflict.  Adjust either the jumper setting (on the drive control unit) or parameter 12.15/12.25.  Note: Control board reboot (either by cycling the power or through parameter 96.08 Control board boot) is required to validate any changes in the jumper settings.
A6E6	ULC configuration	User load curve configuration error.	Check the auxiliary code (format XXXX ZZZZ). "ZZZZ" indicates the problem (see actions for each code below).
	0000	Speed points inconsistent.	Check that each speed point (parameters 37.1137.15) has a higher value than the previous point.
	0001	Frequency points inconsistent.	Check that each frequency point (37.1637.20) has a higher value than the previous point.

Code (hex)	Warning	Cause	What to do
	0002	Underload point above overload point.	Check that each overload point (37.3137.35) has a higher value than
	0003	Overload point below underload point.	the corresponding underload point (37.2137.25).
A780	Motor stall Programmable warning: 31.24 Stall function	Motor is operating in stall region because of e.g. excessive load or insufficient motor power.	Check motor load and drive ratings. Check fault function parameters.
A781	Motor fan Programmable warning: 35.106 DOL starter event type	No feedback received from external fan.	Check external fan (or other equipment controlled) by the logic. Check settings of parameters 35.10035.106.
A782	FEN temperature	Error in temperature measurement when temperature sensor (KTY or PTC) connected to encoder interface FEN-xx is used.	Check that parameter 35.11 Temperature 1 source / 35.21 Temperature 2 source setting corresponds to actual encoder interface installation. Check the settings of parameters 91.21 and 91.24. Check that the corresponding module is activated in parameters 91.1191.14. Use parameter 91.10 Encoder parameter refresh to validate any changes in the settings.
		Error in temperature measurement when KTY sensor connected to encoder interface FEN-01 is used.	FEN-01 does not support temperature measurement with KTY sensor. Use PTC sensor or other encoder interface module.
A791	Brake resistor	Brake resistor broken or not connected.	Check that a brake resistor has been connected. Check the condition of the brake resistor.
A793	BR excess temperature	Brake resistor temperature has exceeded warning limit defined by parameter 43.12 Brake resistor warning limit.	Stop drive. Let resistor cool down. Check resistor overload protection function settings (parameter group 43 Brake chopper). Check warning limit setting, parameter 43.12 Brake resistor warning limit. Check that braking cycle meets allowed limits.
A794	BR data	Brake resistor data has not been given.	Check the resistor data settings (parameters 43.0843.10). The parameter is specified by the auxiliary code.
	0000 0001	Resistance value too low.	Check value of 43.10.
	0000 0002	Thermal time constant not given.	Check value of 43.08.
	0000 0003	Maximum continuous power not given.	Check value of 43.09.
A797	Speed feedback configuration	Speed feedback configuration has changed.	Use parameter 91.10 Encoder parameter refresh) to validate any changes in the settings.

Code (hex)	Warning	Cause	What to do
	0001	Adapter not found in specified slot.	Check module location (91.12 or 91.14).
	0002	Detected type of interface module does not match parameter setting.	Check the module type (91.11 or 91.13) against status (91.02 or 91.03).
	0003	Logic version too old.	Contact your local ABB representative.
	0004	Software version too old.	Contact your local ABB representative.
	0006	Encoder type incompatible with interface module type.	Check module type (91.11 or 91.13) against encoder type (92.01 or 93.01).
	0007	Adapter not configured.	Check module location (91.12 or 91.14).
	8000	Speed feedback configuration has changed.	Use parameter 91.10 Encoder parameter refresh to validate any changes in the settings.
	0009	No encoders configured to encoder module	Configure the encoder in group 92 Encoder 1 configuration or 93 Encoder 2 configuration.
	000A	Non-existing emulation input.	Check input selection (91.31 or 91.41).
	000B	Echo not supported by selected input (for example, resolver or absolute encoder).	Check input selection (91.31 or 91.41), interface module type, and encoder type.
	000C	Emulation in continuous mode not supported.	Check input selection (91.31 or 91.41) and serial link mode (92.30 or 93.30) settings.
A798	Encoder option comm loss	Encoder feedback not used as actual feedback, or measured motor feedback lost (and parameter 90.45/90.55 is set to Warning).	Check that the encoder is selected as feedback source in parameter 90.41 or 90.51. Check that the encoder interface module is properly seated in its slot. Check that the encoder interface module or slot connectors are not damaged. To pinpoint the problem, try installing the module into a different slot.  If the module is installed on an FEA-03 extension adapter, check the fiber optic connections. Check the auxiliary code (format XXXX YYYY). "YYYY" indicates the problem (see actions for each code below).
	0001	Failed answer to encoder configuration message.	Contact your local ABB representative.
	0002	Failed answer to adapter watchdog disable message.	Contact your local ABB representative.
	0003	Failed answer to adapter watchdog enable message.	Contact your local ABB representative.

Code (hex)	Warning	Cause	What to do
(HOZ)	0004	Failed answer to adapter configuration message.	Contact your local ABB representative.
	0005	Too many failed answers inline to speed and position messages.	Contact your local ABB representative.
	0006	DDCS driver failed.	Contact your local ABB representative.
A79B	BC short circuit	Short circuit in brake chopper IGBT	Replace brake chopper. Ensure brake resistor is connected and not damaged.
A79C	BC IGBT excess temperature	Brake chopper IGBT temperature has exceeded internal warning limit.	Let chopper cool down. Check for excessive ambient temperature. Check for cooling fan failure. Check for obstructions in the air flow. Check the dimensioning and cooling of the cabinet. Check resistor overload protection function settings (parameters 43.0643.10). Check that braking cycle meets allowed limits. Check that drive supply AC voltage is not excessive.
A7AA	Extension AI parametrization	The hardware current/voltage setting of an analog input (on an I/O extension module) does not correspond to parameter settings.	Check the auxiliary code (format XX00 00YY). "XX" specifies the number of the I/O extension module (01: parameter group 14 I/O extension module 2, 03: 16 I/O extension module 2, 03: 16 I/O extension module 3). "YY" specifies the analog input on the module. For example, in case of I/O extension module 1, analog input Al1 (auxiliary code 0000 0101), the hardware current/voltage setting on the module is shown by parameter 14.29. The corresponding parameter setting is 14.30. Adjust either the hardware setting on the module or the parameter to solve the mismatch.  Note: Control board reboot (either by cycling the power or through parameter 96.08 Control board boot) is required to validate any changes in the hardware settings.
A7AB	Extension I/O configuration failure	The I/O extension module types and locations specified by parameters do not match the detected configuration.	Check the type and location settings of the modules (parameters 14.01, 14.02, 15.01, 15.02, 16.01 and 16.02). Check that the modules are properly installed. Check the auxiliary code. See Drive application programming manual (IEC 61131-3) (3AUA0000127808 [English]).

Code (hex)	Warning	Cause	What to do
A7B0	Motor speed feedback Programmable warning: 90.45 Motor feedback fault	No motor speed feedback is received.	Check the auxiliary code (format XXYY ZZZZ). "XX" specifies the number of the encoder interface module (01: 91.11/91.12, 02: 91.13/91.14), "YY" specifies the encoder (01: 92 Encoder 1 configuration, 02: 93 Encoder 2 configuration). "ZZZZ" indicates the problem (see actions for each code below).
	0001	Motor gear definition invalid or outside limits.	Check motor gear settings (90.43 and 90.44).
	0002	Encoder not configured.	Check encoder settings (92 Encoder 1 configuration or 93 Encoder 2 configuration). Use parameter 91.10 Encoder parameter refresh) to validate any changes in the settings.
	0003	Encoder stopped working.	Check encoder status.
	0004	Encoder drift detected.	Check for slippage between encoder and motor.
A7B1	Load speed feedback Programmable warning: 90.55 Load feedback fault	No load speed feedback is received.	Check the auxiliary code (format XXYY ZZZZ). "XX" specifies the number of the encoder interface module (01: 91.11/91.12, 02: 91.13/91.14), "YY" specifies the encoder (01: 92 Encoder 1 configuration, 02: 93 Encoder 2 configuration). "ZZZZ" indicates the problem (see actions for each code below).
	0001	Load gear definition invalid or outside limits.	Check load gear settings (90.53 and 90.54).
	0002	Feed constant definition invalid or outside limits.	Check feed constant settings (90.63 and 90.64).
	0003	Encoder stopped working.	Check encoder status.
A7C1	FBA A communication Programmable warning: 50.02 FBA A comm loss func	Cyclical communication between drive and fieldbus adapter module A or between PLC and fieldbus adapter module A is lost.	Check status of fieldbus communication. See user documentation of fieldbus interface. Check settings of parameter groups 50 Fieldbus adapter (FBA), 51 FBA A settings, 52 FBA A data in and 53 FBA A data out.  Check cable connections.  Check if communication master is able to communicate.
A7C2	FBA B communication Programmable warning: 50.32 FBA B comm loss func	Cyclical communication between drive and fieldbus adapter module B or between PLC and fieldbus adapter module B is lost.	Check status of fieldbus communication. See user documentation of fieldbus interface. Check settings of parameter group 50 Fieldbus adapter (FBA). Check cable connections. Check if communication master is able to communicate.

Code (hex)	Warning	Cause	What to do
A7CE	EFB comm loss Programmable warning: 58.14 Communication loss action	Communication break in embedded fieldbus (EFB) communication.	Check the status of the fieldbus master (online/offline/error etc.). Check cable connections to the XD2D connector on the control unit.
A7E1	Encoder Programmable warning: 90.45 Motor feedback fault	Encoder 1 error.	Check the auxiliary code (format XXYY ZZZZ). "XX" specifies the number of the encoder interface module (01: 91.11/91.12, 02: 91.13/91.14), "YY" specifies the encoder (01: 92 Encoder 1 configuration, 02: 93 Encoder 2 configuration). "ZZZZ" indicates the problem (see actions for each code below).
	0001	Cable fault	Check the conductor order at both ends of the encoder cable. Check the groundings of the encoder cable. If the encoder was working previously, check the encoder, encoder cable and encoder interface module for damage. See also parameter 92.21 Encoder cable fault mode.
	0002	No encoder signal	Check the condition of the encoder.
	0003	Overspeed	Contact your local ABB representative.
	0004	Overfrequency	Contact your local ABB representative.
	0005	Resolver ID run failed	Contact your local ABB representative.
	0006	Resolver overcurrent fault	Contact your local ABB representative.
	0007	Speed scaling error	Contact your local ABB representative.
	0008	Absolute encoder communication error	Contact your local ABB representative.
	0009	Absolute encoder initialization error	Contact your local ABB representative.
	000A	Absolute SSI encoder configuration error	Contact your local ABB representative.
	000B	Encoder reported an internal error	See the documentation of the encoder.
	000C	Encoder reported a battery error	See the documentation of the encoder.
	000D	Encoder reported overspeed or decreased resolution due to overspeed	See the documentation of the encoder.
	000E	Encoder reported a position counter error	See the documentation of the encoder.
	000F	Encoder reported an internal error	See the documentation of the encoder.

Code (hex)	Warning	Cause	What to do
A7E2	Encoder 2	Encoder 2 error.	Check that the parameter settings in groups 93 Encoder 2 configuration are correct.  Note: New settings will only take effect after parameter 91.10 Encoder parameter refresh is used or after the drive control unit is powered up the next time.  Check the auxiliary code. See appropriate actions for each code below.
	Aux code: 1030	Overspeed	Contact your local ABB representative.
	Aux code: 1031	Pulse overfrequency	1
	Aux code: 1032	Cable fault	Check the wiring of the encoder. See also parameters 93.31 Encoder cable fault mode.
	Aux code: 1033	Resolver ID run fault	Contact your local ABB representative.
	Aux code: 1034	Encoder fault	Refer to encoder documentation.
	Aux code: 1035	Encoder warning	
	Aux code: 1036	Unsupported cable fault detection mode.	Try a different setting in 93.31 Encoder cable fault mode.
	Aux code: 1037	Resolver SW version	Contact your local ABB representative.
	Aux code: 1038	Resolver speed scale	
A7EE	Control panel loss Programmable warning: 49.05 Communication loss action	Control panel or PC tool selected as active control location for drive has ceased communicating.	Check PC tool or control panel connection. Check control panel connector. Disconnect and reconnect the control panel.
A880	Motor bearing Programmable warnings: 33.14 On-time 1 warn message 33.24 On-time 2 warn message 33.55 Value counter 1 warn message 33.65 Value counter 2 warn message	Warning generated by an on-time timer or a value counter.	Check the auxiliary code. Check the source of the warning corresponding to the code: 0: 33.13 On-time 1 source 1: 33.23 On-time 2 source 4: 33.53 Value counter 1 source 5: 33.63 Value counter 2 source.
A881	Output relay	Warning generated by an	Check the auxiliary code. Check the
A882	Motor starts	edge counter.  Programmable warnings:	source of the warning corresponding to the code:
A883	Power ups	33.35 Edge counter 1	2: 33.33 Edge counter 1 source
A884	Main contactor	warn message - 33.45 Edge counter 2	3: 33.43 Edge counter 2 source.
A885	DC charge	warn message	
A886	On-time 1 (Editable message text) Programmable warning: 33.14 On-time 1 warn message	Warning generated by ontime timer 1.	Check the source of the warning (parameter 33.13 On-time 1 source).

Code (hex)	Warning	Cause	What to do
A887	On-time 2 (Editable message text) Programmable warning: 33.24 On-time 2 warn message	Warning generated by ontime timer 2.	Check the source of the warning (parameter 33.23 On-time 2 source).
A888	Edge counter 1 (Editable message text) Programmable warning: 33.35 Edge counter 1 warn message	Warning generated by edge counter 1.	Check the source of the warning (parameter 33.33 Edge counter 1 source).
A889	Edge counter 2 (Editable message text) Programmable warning: 33.45 Edge counter 2 warn message	Warning generated by edge counter 2.	Check the source of the warning (parameter 33.43 Edge counter 2 source).
A88A	Value counter 1 (Editable message text) Programmable warning: 33.55 Value counter 1 warn message	Warning generated by value counter 1.	Check the source of the warning (parameter 33.53 Value counter 1 source).
A88B	Value counter 2 (Editable message text) Programmable warning: 33.65 Value counter 2 warn message	Warning generated by value counter 2.	Check the source of the warning (parameter 33.63 Value counter 2 source).
A88C	Device clean	Warning generated by an	Check the auxiliary code. Check the source of the warning corresponding to the code: 0: 33.13 On-time 1 source 1: 33.23 On-time 2 source 10: 05.04 Fan on-time counter.
A88D	DC capacitor	on-time timer. Programmable warnings:	
A88E	Cabinet fan	33.14 On-time 1 warn	
A88F	Cooling fan	message 33.24 On-time 2 warn	
A890	Additional cooling	message	
A8A0	Al supervision Programmable warning: 12.03 Al supervision function	An analog signal is outside the limits specified for the analog input.	Check the auxiliary code (format XYY).  "X" specifies the location of the input (0: Al on control unit; 1: I/O extension module 1, etc.), "YY" specifies the input and limit (01: Al1 under minimum, 02: Al1 over maximum, 03: Al2 under minimum, 04: Al2 over maximum).  Check signal level at the analog input. Check the wiring connected to the input.  Check the minimum and maximum limits of the input in parameter group 12 Standard Al, 14 I/O extension module 1, 15 I/O extension module 2 or 16 I/O extension module 3.
A8B0	Signal supervision (Editable message text) Programmable warning: 32.06 Supervision 1 action	Warning generated by a signal supervision function.	Check the source of the warning (parameter 32.07, 32.17 or 32.28).
A8B1	Signal supervision 2 (Editable message text) Programmable warning: 32.16 Supervision 2 action	Warning generated by the signal supervision 2 function.	Check the source of the warning (parameter 32.17 Supervision 2 signal).

Code (hex)	Warning	Cause	What to do
A8B2	Signal supervision 3 (Editable message text) Programmable warning: 32.26 Supervision 3 action	Warning generated by the signal supervision 3 function.	Check the source of the warning (parameter 32.27 Supervision 3 signal).
A8BE	ULC overload warning Programmable fault: 37.03 ULC overload actions	Selected signal has exceeded the user overload curve.	Check for any operating conditions increasing the monitored signal (for example, the loading of the motor if the torque or current is being monitored). Check the definition of the load curve (parameter group 37 User load curve).
A8BF	ULC underload warning Programmable fault: 37.04 ULC underload actions	Selected signal has fallen below the user underload curve.	Check for any operating conditions decreasing the monitored signal (for example, loss of load if the torque or current is being monitored).  Check the definition of the load curve (parameter group 37 User load curve).
A8C0	Fan service counter	A cooling fan has reached the end of its estimated lifetime. See parameters 05.41 and 05.42.	Check the auxiliary code. The code indicates which fan is to be replaced. 0: Main cooling fan 1: Auxiliary cooling fan 2: Auxiliary cooling fan 2 3: Cabinet cooling fan 4: PCB compartment fan Refer to the hardware manual of the drive for fan replacement instructions.
A981	External warning 1 (Editable message text) Programmable warning: 31.01 External event 1 source 31.02 External event 1 type	Fault in external device 1.	Check the external device. Check setting of parameter 31.01 External event 1 source.
A982	External warning 2 (Editable message text) Programmable warning: 31.03 External event 2 source 31.04 External event 2 type	Fault in external device 2.	Check the external device. Check setting of parameter 31.03 External event 2 source.
A983	External warning 3 (Editable message text) Programmable warning: 31.05 External event 3 source 31.06 External event 3 type	Fault in external device 3.	Check the external device. Check setting of parameter 31.05 External event 3 source.
A984	External warning 4 (Editable message text) Programmable warning: 31.07 External event 4 source 31.08 External event 4 type	Fault in external device 4.	Check the external device. Check setting of parameter 31.07 External event 4 source.
A985	External warning 5 (Editable message text) Programmable warning: 31.09 External event 5 source 31.10 External event 5 type	Fault in external device 5.	Check the external device. Check setting of parameter 31.09 External event 5 source.

Code (hex)	Warning	Cause	What to do
AF85	Line side unit warning	The supply unit (or other converter) has generated a warning.	The auxiliary code specifies the original warning code in the supply unit control program. See section Auxiliary codes for line-side converter warnings (page 518).
AF90	Speed controller autotuning	The speed controller autotune routine did not complete successfully.	Check the auxiliary code (format XXXX YYYY). "YYYY" indicates the problem (see actions for each code below).
	0000	The drive was stopped before the autotune routine finished.	Repeat autotune until successful.
	0001	The drive was started but was not ready to follow the autotune command.	Make sure the prerequisites of the autotune run are fulfilled. See section Before activating the autotune routine (page 67).
	0002	Required torque reference could not be reached before the drive reached maximum speed.	Decrease torque step (parameter 25.38) or increase speed step (25.39).
	0003	Motor could not accelerate/decelerate to maximum/minimum speed.	Increase torque step (parameter 25.38) or decrease speed step (25.39).
	0005	Motor could not decelerate with full autotune torque.	Decrease torque step (parameter 25.38) or speed step (25.39).
AFAA	Autoreset	A fault is about to be autoreset.	Informative warning. See the settings in parameter group 31 Fault functions.
AFE1	Emergency stop (off2)	Drive has received an emergency stop (mode selection off2) command.	Check that it is safe to continue operation. Reset the source of the emergency stop signal (such as an
AFE2	Emergency stop (off1 or off3)	Drive has received an emergency stop (mode selection off1 or off3) command.	emergency stop push button). Restart drive.  If the emergency stop was unintentional, check the source of the stop signal (for example, 21.05  Emergency stop source, or control word received from an external control system).
AFEA	Enable start signal missing (Editable message text)	No enable start signal received.	Check the setting of (and the source selected by) parameter 20.19 Enable start command.
AFEB	Run enable missing	No run enable signal is received.	Check setting of parameter 20.12 Run enable 1 source. Switch signal on (e.g. in the fieldbus Control Word) or check wiring of selected source.
AFEC	External power signal missing	95.04 Control board supply is set to External 24V but no voltage is connected to the XPOW connector of the control unit.	Check the external 24 V DC power supply to the control unit, or change the setting of parameter 95.04.
AFF6	Identification run	Motor ID run will occur at next start.	Informative warning.

Code (hex)	Warning	Cause	What to do
AFF7	Autophasing	Autophasing will occur at next start.	Informative warning.
B5A0	STO event Programmable event: 31.22 STO indication run/stop	Safe torque off function is active, i.e. safety circuit signal(s) connected to connector XSTO is lost.	Check safety circuit connections. For more information, see appropriate drive hardware manual and description of parameter 31.22 STO indication run/stop (page 279).
B5A2	Power up Programmable event: 96.39 Power up event logging	The drive has been powered up.	Informative event.
B5A4	SW internal diagnostics	Control unit rebooted unexpectedly.	Informative event.
B680	SW internal diagnostics	SW internal malfunction	Contact your local ABB representative, quoting the auxiliary code. If the Drive composer tool is available, also create and send a 'support package' (see Drive composer manual for instructions).
B686	Checksum mismatch Programmable event: 96.54 Checksum action	The calculated parameter checksum does not match any enabled reference checksum.	See A686 Checksum mismatch (page 483).
D200	Overtemperature	09.10 Measured temperature exceeded 79.07 Warning temperature limit for 5 sec or the Klixon digital input is false.	Check for problem in measurement device. Check for problem in temperature measurement circuit. Check well and discharge pressures (excessive pressure can cause heating). Check warning function setting in parameters.
D201	Pressure	09.09 Pressure exceeded 76.07 Analog feedback limit for 76.08 Analog feedback limit delay time or 76.04 Digital feedback source is set as false.	Check for problem in measurement device. Check for high gas content. Check warning function setting in parameters.
D202	Underload	78.02 Underload function is set to warning when 09.01 Rod torque and 09.05 Rod speed actual values are lower than user defined curve (parameters 78.03 - 78.08) for 78.09 Underload delay time.	Check parameter settings. Check setting of 78.02 Underload function.
D203	Check curve	There are identical torque values in parameters 78.03 - 78.08.	Check parameter settings and set values as required.
D204	Rod torque 1 limit	Actual 09.01 Rod torque is beyond the limits. Warning condition has been fulfilled. Shut-down procedure is active.	See parameters 77.02 - 77.06. Check warning function setting in parameters and set values as required.

Code (hex)	Warning	Cause	What to do
D205	Rod torque 2 speed	Actual speed reference has been modified by 77.07 Rod torq2 function on 77.11 Rod torq2 additive speed ref value.	Check parameter settings and set values as required.
D206	Rod torque 2 limit	77.11 Rod torq2 additive speed ref has been triggered more than 77.13 Rod torq2 limit counter times during 77.14 Rod torq2 time window. Shutdown procedure is active.	Check parameter settings and set values as required.
D207	Sleep mode	Sleep condition has been fulfilled.	See parameters 75.32 - 75.39. Or set 75.31 Sleep warning enable as disabled.
D208	Backspin limit	Actual 09.05 Rod speed is faster than 09.11 Backspin speed reference.	Check parameter settings and set values as required.
D209	Backspin active	Pump backspin control procedure is in process.	See parameters 80.01 - 80.05. Wait till procedure is completed.
D20A	Brake confirmation active	74.21 Brake confirmation enable is active and p9ocedure is in process.	Wait till procedure is completed.
D20B	Fault delay active	Fault is triggered and tripping is delayed till the drive is stopped.	Wait till drive is tripped.
D20C	Start delay active	Start delay procedure is in progress. It is not allowed to start the drive.	Wait till procedure is completed in time 09.12 Start delay remain.
D20D	Replace ZCU battery	ZCU board battery is empty.	Replace ZCU board battery.

# Fault messages

Code (hex)	Fault	Cause	What to do
2281	Calibration	Measured offset of output phase current measurement or difference between output phase U2 and W2 current measurement is too great (the values are updated during current calibration).	Try performing the current calibration again (select <i>Current measurement calibration</i> at parameter <i>99.13</i> ). If the fault persists, contact your local ABB representative.
2310	Overcurrent	Output current has exceeded internal fault limit.	Check motor load.  If the control unit is externally powered, check the setting of parameter 95.04 Control board supply.  Check acceleration times in parameter group 23 Speed reference ramp (speed control), 26 Torque reference chain (torque control) or 28 Frequency reference chain (frequency control). Also check parameters 46.01 Speed scaling, 46.02 Frequency scaling and 46.03 Torque scaling.  Check motor and motor cable (including phasing and delta/star connection).  Check there are no contactors opening and closing in motor cable. Check that the start-up data in parameter group 99 corresponds to the motor rating plate.  Check that there are no power factor correction capacitors or surge absorbers in motor cable.  Check encoder cable (including phasing).  Check the auxiliary code (format XXXY YYZZ). With parallel-connected inverter modules, "Y YY" specifies through which BCU control unit channel the fault was received. "ZZ" indicates the phase that triggered the fault (0: No detailed information available, 1: U-phase, 2: Vphase, 4: W-phase, 3/5/6/7: multiple phases).

Code	Fault	Cause	What to do
(hex)			
2330	Earth leakage Programmable fault: 31.20 Earth fault	Drive has detected load unbalance typically due to earth fault in motor or motor cable.	If the control unit is externally powered, check the setting of parameter 95.04 Control board supply.  Check there are no power factor correction capacitors or surge absorbers in motor cable.  Check for an earth fault in motor or motor cables by measuring the insulation resistances of motor and motor cable.  Try running the motor in scalar control mode if allowed. (See parameter 99.04 Motor ctrl mode.) With parallel-connected modules, check the auxiliary code (format XXXY YYZZ). "Y YY" specifies through which BCU control unit channel the fault was received. If no earth fault can be detected, contact your local ABB representative.
2340	Short circuit	Short-circuit in motor cable(s) or motor	Check motor and motor cable for cabling errors.  If the control unit is externally powered, check the setting of parameter 95.04 Control board supply.  Check that parameter 99.10 Motor nominal power has been set correctly.  Check there are no power factor correction capacitors or surge absorbers in motor cable.  Check the auxiliary code (format XXXY YYZZ). With parallel-connected inverter modules, "Y YY" specifies through which BCU control unit channel the fault was received. "ZZ" indicates the location of the short circuit (0: No detailed information available, 1: Upper branch of U-phase, 4: Upper branch of V-phase, 8: Lower branch of V-phase, 20: Lower branch of W-phase, 20: Lower branch of W-phase, other: combinations of the above).  After correcting the cause of the fault, reboot the control unit (using parameter 96.08 Control board boot) or by cycling power.

Code (hex)	Fault	Cause	What to do
2381	IGBT overload	Excessive IGBT junction to case temperature. This fault protects the IGBT(s) and can be activated by a short circuit in the motor cable.	Check motor cable. Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against drive power.
2391	BU current difference	AC phase current difference between parallel-connected inverter modules is excessive.	Check motor cabling. Check there are no power factor correction capacitors or surge absorbers in motor cable. Check the auxiliary code (format XXXY YYZZ). "XXX" specifies the source of the first error (see "YYY"). "YYY", when converted to binary, specifies through which BCU control unit channel(s) the fault was received (for example, 001: Channel 1, 002: Channel 2, 003: Channel 3 and 2, 004: Channel 3, etc.). "ZZ" indicates the phase (1: U, 2: V, 3: W).
2392	BU earth leakage	Total earth leakage of inverter modules is excessive.	Check there are no power factor correction capacitors or surge absorbers in motor cable.  Measure insulation resistances of motor cables and motor.  Contact your local ABB representative.
3130	Input phase loss	Intermediate circuit DC voltage is oscillating due to missing input power line phase or blown fuse.	Check input power line fuses. Check for loose power cable connections. Check for input power supply imbalance.
3180	Charge relay lost	No acknowledgement received from charge relay.	Contact your local ABB representative.
3181	Cross connection Programmable fault: 31.23 Wiring or earth fault	The drive hardware is supplied from a common DC bus.	Switch off the protection in parameter <i>31.23</i> .
		Incorrect input power and motor cable connection (i.e. input power cable is connected to drive motor connection).	Check input power connections. Check the input fuses.
		Drive has detected load unbalance typically due to earth fault in motor or motor cable.	Check there are no power factor correction capacitors or surge absorbers in motor cable. Check for an earth fault in motor or motor cables by measuring the insulation resistances of motor and motor cable. Try running the motor in scalar control mode if allowed. (See parameter 99.04 Motor ctrl mode.)

Code (hex)	Fault	Cause	What to do
3210	DC link overvoltage	Excessive intermediate circuit DC voltage.	Check that overvoltage control is on (parameter 30.30 Overvoltage control). Check that the supply voltage matches the nominal input voltage of the drive. Check the supply line for static or transient overvoltage. Check brake chopper and resistor (if present). Check deceleration time. Use coast-to-stop function (if applicable). Retrofit drive with brake chopper and brake resistor.
3220	DC link undervoltage	Intermediate circuit DC voltage is not sufficient because of a missing supply phase, blown fuse or fault in the rectifier bridge.	Check supply cabling, fuses and switchgear. With parallel-connected modules, check the auxiliary code (format XXXY YYZZ). "Y YY" specifies through which BCU control unit channel the fault was received.
3280	Standby timeout	Automatic restart failed (see section <i>Automatic restart</i> on page 91).	Check the condition of the supply (voltage, cabling, fuses, switchgear).
3291	BU DC link difference	Difference in DC voltages between parallel-connected inverter modules.	Check the auxiliary code (format XXXY YYZZ). "XXX" specifies the source of the first error (see "YYY"). "YYY", when converted to binary, specifies through which BCU control unit channel(s) the fault was received (for example, 001: Channel 1, 002: Channel 2, 003: Channels 1 and 2, 004: Channel 3, etc.).
3381	Output phase loss Programmable fault: 31.19 Motor phase loss	Motor circuit fault due to missing motor connection (all three phases are not connected).	Connect motor cable.

Code (hex)	Fault	Cause	What to do
3385	Autophasing	Autophasing routine (see section <i>Autophasing</i> on page 82) has failed.	Try other autophasing modes (see parameter 21.13 Autophasing mode) if possible. If the Turning with Z-pulse mode is selected, check the zero pulse given by the encoder. Check that the motor ID run has been successfully completed. Clear parameter 98.15 Position offset user. Check that the encoder is not slipping on the motor shaft. Check that the motor is not already turning when the autophasing routine starts. Check the setting of parameter 99.03 Motor type.
4000	Motor cable overload	Calculated motor cable temperature has exceeded warning limit.	Check the settings of parameters 35.61 and 35.62. Check the dimensioning of the motor cable in regard to required load.
4210	IGBT overtemperature	Estimated drive IGBT temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against drive power.
4290	Cooling	Drive module temperature is excessive.	Check ambient temperature. If it exceeds 40 °C (104 °F), ensure that load current does not exceed derated load capacity of drive. See appropriate <i>Hardware Manual</i> . Check drive module cooling air flow and fan operation. Check inside of cabinet and heatsink of drive module for dust pick-up. Clean whenever necessary.
42F1	IGBT temperature	Drive IGBT temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against drive power.
4310	Excess temperature	Power unit module temperature is excessive.	See A4B0 Excess temperature (page 480).
4380	Excess temperature difference	High temperature difference between the IGBTs of different phases.	See A4B1 Excess temperature difference (page 480).

Code (hex)	Fault	Cause	What to do
4981	External temperature (Editable message text)	Measured temperature 1 or 2 has exceeded fault limit.	Check the values of parameter 35.02 Measured temperature 1. Check the cooling of the motor (or other equipment whose temperature is being measured). Check the value of parameter 35.12 Temperature 1 fault limit.
4982	External temperature 2 (Editable message text)	Measured temperature 2 has exceeded fault limit.	Check the value of parameter 35.03  Measured temperature 2.  Check the cooling of the motor (or other equipment whose temperature is being measured).  Check the value of parameter 35.22  Temperature 2 fault limit.
4990	FPTC not found	A thermistor protection module has been activated by parameter 35.30 but cannot be detected.	Power down the control unit and check that the module is properly inserted in the correct slot.  The last digit of the auxiliary code identifies the slot.
4991	Safe motor temperature 1 (Editable message text)	The thermistor protection module installed in slot 1 indicates overtemperature.	Check the cooling of the motor. Check the motor load and drive ratings.
4992	Safe motor temperature 2 (Editable message text)	The thermistor protection module installed in slot 2 indicates overtemperature.	Check the wiring of the temperature sensor. Repair wiring if faulty.  Measure the resistance of the
4993	Safe motor temperature 3 (Editable message text)	The temperature monitoring module installed in slot 3 indicates overtemperature.	sensor. Replace sensor if faulty.
5080	Fan Programmable fault: 31.35 Main fan fault function	Cooling fan stuck or disconnected.	See <i>A581 Fan</i> (page <i>481</i> ).
5081	Auxiliary fan not running Programmable fault: 31.36 Aux fan fault function	An auxiliary cooling fan (connected to the fan connectors on the control unit) is stuck or disconnected.	See A582 Auxiliary fan not running (page 481).

Code (hex)	Fault	Cause	What to do
5090	STO hardware failure	Safe torque off hardware failure.	Contact your local ABB representative. The code contains location information, especially with parallel-connected inverter modules. When converted into a 32-bit binary number, the bits of the code indicate the following:  3128: Number of faulty inverter module (011 decimal). 1111: STO_ACT states of control unit and inverter modules in conflict 27: STO_ACT state of inverter modules 26: STO_ACT state of control unit 25: STO1 of control unit 24: STO2 of control unit 2312: STO1 of inverter modules 121 (Bits of non-existing modules set to 1)  110: STO2 of inverter modules 121 (Bits of non-existing modules set to 1)
5091	Safe torque off Programmable fault: 31.22 STO indication run/stop	Safe torque off function is active, i.e. safety circuit signal(s) connected to connector XSTO is broken during start or run.	Check safe torque off circuit connections. For more information, see appropriate drive hardware manual and description of parameter 31.22 STO indication run/stop (page 279).
5092	PU logic error	Power unit memory has cleared.	Cycle the power to the drive. If the control unit is externally powered, also reboot the control unit (using parameter 96.08 Control board boot) or by cycling its power. If the problem persists, contact your local ABB representative.

Code (hex)	Fault	Cause	What to do
5093	Rating ID mismatch	The hardware of the drive does not match the information stored in the memory unit. This may occur eg. after a firmware update or memory unit replacement.	Cycle the power to the drive. Check the auxiliary code. The auxiliary code categories are as follows: 1 = PU and CU ratings not the same. Rating ID has changed. 2 = Parallel connection rating ID has changed. 3 = PU types not the same in all power units. 4 = Parallel connection rating ID is active in a single power unit setup. 5 = It is not possible to implement the selected rating with the current PUs. 6 = PU rating ID is 0. 7 = Reading PU rating ID or PU type failed on PU connection. 8 = PU not supported (illegal rating ID). 9 = Incompatible module current rating (unit contains a module with too low a current rating). 10 = Selected parallel rating ID not found from database. With parallel connection faults (BCU control unit), the format of the auxiliary code is 0X0Y. "Y" indicates the auxiliary code category, "X" indicates the first faulty PU channel in hexadecimal (1C). (With a ZCU control unit, "X" can be 1 or 2 but this is irrelevant to the fault)
5094	Measurement circuit temperature	Problem with internal temperature measurement of the drive.	See A5EA Measurement circuit temperature (page 482).

Code (hex)	Fault	Cause	What to do
5681	PU communication	The way the control unit is powered does not correspond to parameter setting.	Check setting of 95.04 Control board supply.
		Communication errors detected between the drive control unit and the power unit.	Check the connection between the control unit and the power unit. Check the auxiliary code (format XXXY YYZZ). With parallel-connected modules, "Y YY" specifies the affected BCU control unit channel (0: broadcast). "ZZ" specifies the error source (1: Transmitter side [link error], 2: Transmitter side [no communication], 3: Receiver side [link error], 4: Receiver side [no communication], 5: Transmitter FIFO error [see "XXX"], 6: Module [xINT board] not found, 7: BAMU board not found). "XXX" specifies the transmitter FIFO error code (1: Internal error [invalid call parameter], 2: Internal error [configuration not supported], 3: Transmission buffer full).
5682	Power unit lost	Connection between the drive control unit and the power unit is lost.	Check the connection between the control unit and the power unit.
5690	PU communication internal	Internal communication error.	Contact your local ABB representative.
5691	Measurement circuit ADC	Measurement circuit fault.	If the control unit is externally powered, check the setting of parameter 95.04 Control board supply.  If the problem persists, contact your local ABB representative, quoting the auxiliary code.
5692	PU board powerfail	Power unit power supply failure.	Check the auxiliary code. (format ZZZY YYXX). "YY Y" specifies the affected inverter module (0C, always 0 for ZCU control units). "XX" specifies the affected power supply (1: Power supply 1, 2: Power supply 2, 3: both supplies).
5693	Measurement circuit DFF	Measurement circuit fault.	Contact your local ABB representative, quoting the auxiliary code.
5694	PU communication configuration	Number of connected power modules differs from expected.	Check setting of 95.31 Parallel type configuration. Cycle the power to the drive. If the control unit is externally powered, also reboot the control unit (using parameter 96.08 Control board boot) or by cycling its power.  If the problem persists, contact your local ABB representative.

Code (hex)	Fault	Cause	What to do
5695	Reduced run	Number of inverter modules detected does not match the value of parameter 95.13 Reduced run mode.	Check that the value of 95.13 Reduced run mode corresponds to the number of inverter modules present. Check that the modules present are powered from the DC bus and connected by fiber optic cables to the BCU control unit. If all modules of the inverter unit are in fact available (eg. maintenance work has been completed), check that parameter 95.13 is set to 0 (reduced run function disabled).
5696	PU state feedback	State feedback from output phases does not match control signals.	Contact your local ABB representative, quoting the auxiliary code.
5697	Charging feedback	Incorrect parameter setting.	Check the setting of 95.09 Switch fuse controller. The parameter should be enabled only if an xSFC charging controller is installed.
		The charging switch and DC switch were operated out of sequence, or a start command was issued before the unit was ready.	The normal power-up sequence is: 1. Close charging switch. 2. After charging finishes (charging OK lamp lights), close DC switch. 3. Open charging switch.
		Charging circuit fault.	Check the charging circuit. With a frame R6i/R7i inverter module, the auxiliary code "FA" indicates that the charging contactor status feedback does not match the control signal. With parallel-connected frame R8i modules, the auxiliary code (format XX00), "XX" specifies the affected BCU control unit channel.
		Brake circuit fault	Check the wiring and condition of brake resistor.
5698	Unknown power unit fault	Unidentified power unit logic fault.	Check power unit logic and firmware compatibility. Contact your local ABB representative.
6000	Internal SW error	Internal error.	Contact your local ABB representative. Quote the auxiliary code (check the event details in the event log).
6181	FPGA version incompatible	Firmware and FPGA versions are incompatible.	Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power. If the problem persists, contact your local ABB representative.
		Update of power unit logic failed.	Retry.

Code (hex)	Fault	Cause	What to do
6200	Checksum mismatch Programmable fault: 96.54 Checksum action	The calculated parameter checksum does not match any enabled reference checksum.	See A686 Checksum mismatch (page 483).
6306	FBA A mapping file	Fieldbus adapter A mapping file read error.	Contact your local ABB representative.
6307	FBA B mapping file	Fieldbus adapter B mapping file read error.	Contact your local ABB representative.
6481	Task overload	Internal fault.  Note: This fault cannot be reset.	Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power. If the problem persists, contact your local ABB representative.
6487	Stack overflow	Internal fault.  Note: This fault cannot be reset.	Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power. If the problem persists, contact your local ABB representative.
64A1	Internal file load	File read error.  Note: This fault cannot be reset.	Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power. If the problem persists, contact your local ABB representative.
64A2	Internal record load	Internal record load error.	Contact your local ABB representative.
64A3	Application loading	Application file incompatible or corrupted.  Note: This fault cannot be reset.	Contact your local ABB representative.
	8006	Not enough memory for the application.	Reduce the size of the application. Reduce the number of parameter mappings. See the drive-specific log generated by Automation Builder.
	8007	The application contains the wrong system library version.	Update the system library or reinstall Automation Builder. See the drive-specific log generated by Automation Builder.
	8008	The application is empty.	In Automation Builder, give a "Clean" command and reload the application.
	8009	The application contains invalid tasks.	In Automation Builder, check application task configuration, give a "Clean all" command, and reload the application.
	800A	The application contains an unknown target (system) library function.	Update the system library or reinstall Automation Builder. See the drive-specific log generated by Automation Builder.

Code	Fault	Cause	What to do
(hex)			
64A5	Licensing fault	Running the control program is prevented either because a restrictive license exists, or because a required license is missing.	Record the auxiliary codes of all active licensing faults and contact your product vendor for further instructions.
64A6	Adaptive program	Error running the adaptive program.	Check the auxiliary code (format XXXX YYYY). "XXXX" specifies the number of the function block (0000 = generic error). "YYYY" indicates the problem (see actions for each code below).
	000A	Program corrupted or block non-existent	Restore the template program or download the program to the drive.
	000C	Required block input missing	Check the inputs of the block.
	000E	Program corrupted or block non-existent	Restore the template program or download the program to the drive.
	0011	Program too large.	Remove blocks until the error stops.
	0012	Program is empty.	Correct the program and download it to the drive.
	001C	A non existing parameter or block is used in the program.	Edit the program to correct the parameter reference, or to use an existing block.
	001D	Parameter type invalid for selected pin.	Edit the program to correct the parameter reference.
	001E	Output to parameter failed because the parameter was write-protected.	Check the parameter reference in the program. Check for other sources affecting the target parameter.
	0023 0024	Program file incompatible with current firmware version.	Adapt the program to current block library and firmware version.
	002A	Too many blocks.	Edit the program to reduce the number of blocks.
	Other	-	Contact your local ABB representative, quoting the auxiliary code.
64B0	Memory unit detached	The memory unit was detached when the control unit was powered.	Switch off the power to the control unit and reinstall the memory unit. In case the memory unit was not actually removed when the fault occurred, check that the memory unit is properly inserted into its connector and its mounting screw is tight. Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power. If the problem persists, contact your local ABB representative.
64B1	Internal SSW fault	Internal fault.	Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power. If the problem persists, contact your local ABB representative.

Code (hex)	Fault	Cause	What to do
64B2	User set fault	Loading of user parameter set failed because  set is not compatible with control program drive was switched off during loading.	Ensure that a valid user parameter set exists. Reload if uncertain.
64E1	Kernel overload	Operating system error.  Note: This fault cannot be reset.	Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power. If the problem persists, contact your local ABB representative.
64FF	Fault reset	Informative fault.	An active fault has been reset.
6581	Parameter system	Parameter load or save failed.	Try forcing a save using parameter 96.07 Parameter save manually. Retry.
65A1	FBAA parameter conflict	The drive does not have a functionality requested by PLC, or requested functionality has not been activated.	Check PLC programming. Check settings of parameter groups 50 Fieldbus adapter (FBA) and 51 FBA A settings.
65A2	FBA B parameter conflict	The drive does not have a functionality requested by PLC, or requested functionality has not been activated.	Check PLC programming. Check settings of parameter groups 50 Fieldbus adapter (FBA) and 54 FBA B settings.
65B1	Reference source parametrization	A reference source is simultaneously connected to multiple parameters with different units.	See A6DA Reference source parametrization (page 484).
6681	EFB comm loss Programmable fault 58.14 Communication loss action	Communication break in embedded fieldbus (EFB) communication.	Check the status of the fieldbus master (online/offline/error etc.). Check cable connections to the XD2D connector on the control unit.
6682	EFB config file	Embedded fieldbus (EFB) configuration file could not be read.	Contact your local ABB representative.
6683	EFB invalid parameterization	Embedded fieldbus (EFB) parameter settings inconsistent or not compatible with selected protocol.	Check the settings in parameter group 58 Embedded fieldbus.
6684	EFB load fault	Embedded fieldbus (EFB) protocol firmware could not be loaded.	Contact your local ABB representative.
		Version mismatch between EFB protocol firmware and drive firmware.	
6881	Text data overflow	Internal fault.	Reset the fault. Contact your local ABB representative if the fault persists.
6882	Text 32-bit table overflow	Internal fault.	Reset the fault. Contact your local ABB representative if the fault persists.

Code (hex)	Fault	Cause	What to do
6883	Text 64-bit table overflow	Internal fault.	Reset the fault. Contact your local ABB representative if the fault persists.
6885	Text file overflow	Internal fault.	Reset the fault. Contact your local ABB representative if the fault persists.
7080	Option module comm loss	Communication between drive and option module (FEN-xx and/or FIO-xx) is lost.	See A798 Encoder option comm loss (page 486).
7081	Control panel loss Programmable fault: 49.05 Communication loss action	Control panel or PC tool has stopped communicating.	Check PC tool or control panel connection. Check control panel connector. Disconnect and reconnect the control panel. Check the auxiliary code. The code specifies the I/O port used as follows: 0: Panel, 1: Fieldbus interface A, 2: Fieldbus interface B, 3: Ethernet, 4: D2D/EFB port).
7082	Ext I/O comm loss	The I/O extension module types specified by parameters do not match the detected configuration.	Check the auxiliary code (format XXYY YYYY). "XX" specifies the number of the I/O extension module (01: parameter group 14 I/O extension module 1, 02: 15 I/O extension module 2, 03: 16 I/O extension module 3). "YY YYYY" indicates the problem (see actions for each code below).
	00 0001	Communication with module failed.	Check that the module is properly seated in its slot. Check that the module and the slot connector is not damaged. Try installing the module into another slot.
	00 0002	Module not found	Check the type and location settings
	00 0003	Configuration of module failed.	of the modules (parameters 14.01/14.02, 15.01/15.02 or 16.01/16.02).
	00 0004	Configuration of module failed.	Check that the module is properly seated in its slot. Check that the module and the slot connector is not damaged. Try installing the module into another slot.
7083	Panel reference conflict	Use of saved control panel reference in multiple control modes attempted.	The control panel reference can only be saved for one reference type at a time. Consider the possibility of using a copied reference instead of saved reference (see the reference selection parameter).

Code (hex)	Fault	Cause	What to do
7084	Panel/PC tool version conflict	The current version of the control panel and/or PC tool does not support a function. (For example, older panel versions cannot be used as a source of external reference.)	Update control panel and/or PC tool. Contact your local ABB representative if necessary.
7085	Incompatible option module	Option module not supported. (For example, type Fxxx-xx-M fieldbus adapter modules are not supported.)	Check the auxiliary code. The code specifies the interface to which the unsupported module is connected: 1: Fieldbus interface A, 2: Fieldbus interface B.  Replace the module with a supported type.
7121	Motor stall Programmable fault: 31.24 Stall function	Motor is operating in stall region because of e.g. excessive load or insufficient motor power.	Check motor load and drive ratings. Check fault function parameters.
7181	Brake resistor	Brake resistor broken or not connected.	Check that a brake resistor has been connected. Check the condition of the brake resistor. Check the dimensioning of the brake chopper and resistor.
7183	BR excess temperature	Brake resistor temperature has exceeded fault limit defined by parameter 43.11 Brake resistor fault limit.	Stop drive. Let resistor cool down. Check resistor overload protection function settings (parameter group 43 Brake chopper). Check fault limit setting, parameter 43.11 Brake resistor fault limit. Check that braking cycle meets allowed limits.
7184	Brake resistor wiring	Brake resistor short circuit or brake chopper control fault.	Check brake chopper and brake resistor connection. Ensure brake resistor is not damaged. After correcting the cause of the fault, reboot the control unit (using parameter 96.08 Control board boot) or by cycling power.
7191	BC short circuit	Short circuit in brake chopper IGBT.	Ensure brake resistor is connected and not damaged. Check the electrical specifications of the brake resistor against the Hardware manual. Replace brake chopper (if replaceable). After correcting the cause of the fault, reboot the control unit (using parameter 96.08 Control board boot) or by cycling power.

Code (hex)	Fault	Cause	What to do
7192	BC IGBT excess temperature	Brake chopper IGBT temperature has exceeded internal fault limit.	Let chopper cool down. Check for excessive ambient temperature. Check for cooling fan failure. Check for obstructions in the air flow. Check the dimensioning and cooling of the cabinet. Check resistor overload protection function settings (parameter group 43 Brake chopper). Check that braking cycle meets allowed limits. Check that drive supply AC voltage is not excessive.
71B1	Motor fan Programmable fault: 35.106 DOL starter event type	No feedback received from external fan.	Check external fan (or other equipment controlled) by the logic. Check settings of parameters 35.10035.106.
7301	Motor speed feedback Programmable fault: 90.45 Motor feedback fault	No motor speed feedback received.	See A7B0 Motor speed feedback (page 488).
7310	Overspeed	Motor is turning faster than highest allowed speed due to incorrectly set minimum/maximum speed, insufficient braking torque or changes in load when using torque reference.	Check minimum/maximum speed settings, parameters 30.11 Minimum speed, 30.12 Maximum speed and 31.30 Overspeed trip margin. Check adequacy of motor braking torque. Check need for brake chopper and resistor(s).
		Incorrect estimated speed.	Check the status of motor current measurement. Perform a Normal, Advanced or Advanced Standstill ID run instead of, for example, a Reduced or Standstill ID run. See parameter 99.13 ID run requested (page 420).
7380	Encoder internal	Internal fault.	Contact your local ABB representative.
7381	Encoder 1 Programmable fault: 90.45 Motor feedback fault	Encoder 1 feedback fault.	See A7E1 Encoder (page 489).
73A0	Speed feedback configuration	Speed feedback configuration incorrect.	See A797 Speed feedback configuration (page 485).
73A1	Load feedback Programmable fault: 90.55 Load feedback fault	No load feedback received.	Check the auxiliary code (format XXYY ZZZZ). "XX" specifies the number of the encoder interface module (01: 91.11/91.12, 02: 91.13/91.14), "YY" specifies the encoder (01: 92 Encoder 1 configuration, 02: 93 Encoder 2 configuration). "ZZZZ" indicates the problem (see actions for each code below).

Code (hex)	Fault	Cause	What to do
, , ,	0001	No load feedback received.	Check load gear settings (90.53 and 90.54.
	0002	Unexpected load feedback.	Check load gear settings (90.63 and 90.64.
	0003	Motor/load gear definition invalid or outside limits.	Check load gear settings (90.61 and 90.62.
	0004	Encoder not configured.	Check encoder settings (92 Encoder 1 configuration or 93 Encoder 2 configuration). Use parameter 91.10 Encoder parameter refresh) to validate any changes in the settings.
73B0	Emergency ramp failed	Emergency stop did not finish within expected time.	Check the settings of parameters 31.32 Emergency ramp supervision and 31.33 Emergency ramp supervision delay. Check the predefined ramp times (23.1123.19 for mode Off1, 23.23 for mode Off3).
73B1	Stop failed	Ramp stop did not finish within expected time.	Check the settings of parameters 31.37 Ramp stop supervision and 31.38 Ramp stop supervision delay. Check the predefined ramp times in parameter group 23 Speed reference ramp.
73F0	Overfrequency	Maximum allowed output frequency exceeded.	Without a dual-use license, the fault limit is 598 Hz. Contact your local ABB representative for dual-use licensing information.
7510	FBA A communication Programmable fault: 50.02 FBA A comm loss func	Cyclical communication between drive and fieldbus adapter module A or between PLC and fieldbus adapter module A is lost.	Check status of fieldbus communication. See user documentation of fieldbus interface. Check settings of parameter groups 50 Fieldbus adapter (FBA), 51 FBA A settings, 52 FBA A data in and 53 FBA A data out. Check cable connections. Check if communication master is able to communicate.
7520	FBA B communication Programmable fault: 50.32 FBA B comm loss func	Cyclical communication between drive and fieldbus adapter module B or between PLC and fieldbus adapter module B is lost.	Check status of fieldbus communication. See user documentation of fieldbus interface. Check settings of parameter group 50 Fieldbus adapter (FBA). Check cable connections. Check if communication master is able to communicate.
7583	Line side unit faulted	The supply unit (or other converter) connected to the inverter unit has generated a fault.	The auxiliary code specifies the original fault code in the supply unit control program. See section Auxiliary codes for line-side converter faults (page 520).

Code (hex)	Fault	Cause	What to do
7584	LSU charge failed	The supply unit was not ready (ie. the main contactor/breaker could not be closed) within expected time.	Check that communication to the supply unit has been activated by 95.20 HW options word 1. Check setting of parameter 94.10 LSU max charging time. Check that the supply unit is enabled, allowed to start, and can be controlled by the inverter unit (eg. not in local control mode).
8001	ULC underload fault Programmable fault: 37.04 ULC overload actions	Selected signal has fallen below the user underload curve.	See A8BF ULC underload warning (page 492).
8002	ULC overload fault Programmable fault: 37.03 ULC overload actions	Selected signal has exceeded the user overload curve.	See A8BE ULC overload warning (page 492).
80A0	Al supervision Programmable fault: 12.03 Al supervision function	An analog signal is outside the limits specified for the analog input.	Check the auxiliary code (format XXXX XYZZ). "Y" specifies the location of the input (0: Control unit, 1: I/O extension module 1, 2: I/O extension module 2, 3: I/O extension module 3). "ZZ" specifies the limit (01: Al1 under minimum, 02: Al1 above maximum, 03: Al2 under minimum, 04: Al2 above maximum). Check signal level at the analog input. Check the wiring connected to the input. Check the minimum and maximum limits of the input in parameter group 12 Standard AI.
80B0	Signal supervision (Editable message text) Programmable fault: 32.06 Supervision 1 action	Fault generated by a signal supervision function.	Check the source of the fault (parameter 32.07 Supervision 1 signal).
80B1	Signal supervision 2 (Editable message text) Programmable fault: 32.16 Supervision 2 action	Fault generated by the signal supervision 2 function.	Check the source of the fault (parameter 32.17 Supervision 2 signal).
80B2	Signal supervision 3 (Editable message text) Programmable fault: 32.26 Supervision 3 action	Fault generated by the signal supervision 3 function.	Check the source of the fault (parameter 32.27 Supervision 3 signal).
9081	External fault 1 (Editable message text) Programmable fault: 31.01 External event 1 source 31.02 External event 1 type	Fault in external device 1.	Check the external device. Check setting of parameter 31.01 External event 1 source.
9082	External fault 2 (Editable message text) Programmable fault: 31.03 External event 2 source 31.04 External event 2 type	Fault in external device 2.	Check the external device. Check setting of parameter 31.03 External event 2 source.

Code (hex)	Fault	Cause	What to do
9083	External fault 3 (Editable message text) Programmable fault: 31.05 External event 3 source 31.06 External event 3 type	Fault in external device 3.	Check the external device. Check setting of parameter 31.05 External event 3 source.
9084	External fault 4 (Editable message text) Programmable fault: 31.07 External event 4 source 31.08 External event 4 type	Fault in external device 4.	Check the external device. Check setting of parameter 31.07 External event 4 source.
9085	External fault 5 (Editable message text) Programmable fault: 31.09 External event 5 source 31.10 External event 5 type	Fault in external device 5.	Check the external device. Check setting of parameter 31.09 External event 5 source.
B680	SW internal diagnostics	SW internal malfunction.	Contact your local ABB representative quoting the auxiliary code.
FA81	Safe torque off 1 loss	Safe torque off function is active, ie. STO circuit 1 is broken.	Check safety circuit connections. For more information, see appropriate drive hardware manual
FA82	Safe torque off 2 loss	Safe torque off function is active, ie. STO circuit 2 is broken.	and description of parameter 31.22 STO indication run/stop (page 279). Check the auxiliary code, The code contains location information, especially with parallel-connected inverter modules.
			When converted into a 32-bit binary number, the bits of the code indicate the following: 3128: Number of faulty inverter module (011 decimal). 1111: STO_ACT states of control unit and inverter modules in conflict 27: STO_ACT state of inverter modules 26: STO_ACT state of control unit 25: STO_1 of control unit 24: STO2 of control unit 2312: STO1 of inverter modules 121 (Bits of non-existing modules set to 1) 110: STO2 of inverter modules 121 (Bits of non-existing modules set to 1).
FA90	STO diagnostics failure	SW internal malfunction.	Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power.
FB11	Memory unit missing	No memory unit is attached to the control unit.	Power down the control unit. Check that the memory unit is properly inserted into the control unit.
		The memory unit attached to the control unit is empty.	Power down the control unit. Attach a memory unit (with the appropriate firmware) to the control unit.

Code (hex)	Fault	Cause	What to do
FB12	Memory unit incompatible	The memory unit attached to the control unit is incompatible.	Power down the control unit. Attach a compatible memory unit.
FB13	Memory unit FW incompatible	The firmware on the attached memory unit is incompatible with the drive.	Power down the control unit. Attach a memory unit with compatible firmware.
FB14	Memory unit FW load failed	The memory unit is empty, or contains incompatible or corrupted firmware.	Recycle the power to the control unit. Check the sticker on the memory unit to confirm that the firmware is compatible with the control unit (ZCU-1x/BCU-x2). Connect Drive composer PC tool (version 2.3 or later) to the drive. Select Tools - Recover drive. If the problem persists, replace the memory unit.
FF61	ID run	Motor ID run was not completed successfully.	Check the nominal motor values in parameter group 99 Motor data. Check that no external control system is connected to the drive. Cycle the power to the drive (and its control unit, if powered separately). Check that the motor shaft is not locked. Check the auxiliary code. The second number of the code indicates the problem (see actions for each code below).
	0001	Maximum current limit too low.	Check settings of parameters 99.06 Motor nominal current and 30.17 Maximum current. Make sure that 30.17 > 99.06. Check that the drive is dimensioned correctly according to the motor.
	0002	calculated field weakening point too low.	Check settings of parameters  30.11 Minimum speed  30.12 Maximum speed  99.07 Motor nominal voltage  99.08 Motor nominal frequency  99.09 Motor nominal speed.  Make sure that  30.12 > (0.55 × 99.09) > (0.50 × synchronous speed)  30.11 ≤ 0, and  supply voltage ≥ (0.66 × 99.07).
	0003	Maximum torque limit too low.	Check settings of parameter 99.12 Motor nominal torque, and the torque limits in group 30 Limits. Make sure that the maximum torque limit in force is greater than 100%.
	0004	Current measurement calibration did not finish within reasonable time.	Contact your local ABB representative.

Code (hex)	Fault	Cause	What to do
	00050008	Internal error.	Contact your local ABB representative.
	0009	(Asynchronous motors only) Acceleration did not finish within reasonable time.	Contact your local ABB representative.
	000A	(Asynchronous motors only) Deceleration did not finish within reasonable time.	Contact your local ABB representative.
	000B	(Asynchronous motors only) Speed dropped to zero during ID run.	Contact your local ABB representative.
	000C	(Permanent magnet motors only) First acceleration did not finish within reasonable time.	Contact your local ABB representative.
	000D	(Permanent magnet motors only) Second acceleration did not finish within reasonable time.	Contact your local ABB representative.
	000E0010	Internal error.	Contact your local ABB representative.
FF81	FB A force trip	A fault trip command has been received through fieldbus adapter A.	Check the fault information provided by the PLC.
FF82	FB B force trip	A fault trip command has been received through fieldbus adapter B.	Check the fault information provided by the PLC.
FA90	STO diagnostics failure	SW internal malfunction	Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power.
FF8E	EFB force trip	A fault trip command has been received through the embedded fieldbus interface.	Check the fault information provided by the Modbus controller.
D100	Overtemperature fault	09.10 Measured temperature exceeded 79.08 Fault temperature limit for 3 sec or the Klixon digital input is false.	Check for problem in measurement device. Check for problem in temperature measurement circuit. Check well and discharge pressures (excessive pressure can cause heating). Check warning function setting in parameters.
D101	Pressure fault	Measured 09.09 Pressure is over than defined limits. Fault condition has been fulfilled.	Check for problem in measurement device. Check for high gas content. Check warning function setting in parameters. See 76.02 Pressure protection latching.

Code (hex)	Fault	Cause	What to do
D102	Underload fault	78.02 Underload function is set to fault. Point of actual 09.01 Rod torque / 09.05 Rod speed values falls below user defined curve (parameters 78.03 - 78.08) for a time period defined by parameter 78.08 Underload delay time.	Check parameter settings. Check setting of 78.02 Underload function. Check mechanical condition of the pump. Check fluid condition.
D103	Rod torque 1 limit fault	09.01 Rod torque is lower or higher than 77.04 Rod torq1 limit and 09.05 Rod speed is lower that 77.05 Rod torq1 speed for a period of time defined by parameter 77.06 Rod torq1 delay time.	See parameters 77.02 - 77.06. Check warning function setting in parameters and set values as required. Check mechanical condition of the pump.
D104	Rod torque 2 limit fault	77.07 Rod torq2 function has been triggered more than 77.13 Rod torq2 limit counter times during 77.14 Rod torq2 time window.	Check parameter settings and set values as required.
D105	Brake confirmation fault	Mechanical brake (if present) did not pass <i>Pump backspin control</i> procedure.	Check operational condition of mechanical brake (if present). Check parameters 74.2174.25.

## Auxiliary codes for line-side converter warnings

The table below lists the auxiliary codes of *AF85 Line side unit warning*. For advanced troubleshooting, see the firmware manual of the line converter.

Code (hex)	Warning / Aux. code	Cause	What to do
AE01	Overcurrent	Output current has exceeded internal fault limit.	Check supply voltage. Check that there are no power factor correction capacitors or surge absorbers in supply cable. Check motor load and acceleration times. Check power semiconductors (IGBTs) and current transducers.
AE02	Earth leakage Programmable warning: 31.120 LSU earth fault	IGBT supply has detected load unbalance.	Check AC fuses. Check for earth leakages. Check supply cabling. Check power modules. Check there are no power factor correction capacitors or surge absorbers in supply cable.
AE04	IGBT overload	Excessive IGBT junction to case temperature.	Check supply cable.
AE05	BU current difference	Current difference detected by the branching unit (BU).	Check converter fuses. Check converter(s). Check inverter(s). Check LCL filter.
AE06	BU earth leakage	Earth leakage detected by the branching unit: sum of all currents exceeds the level.	Check AC fuses. Check for earth leakages. Check supply cabling. Check power modules. Check there are no power factor correction capacitors or surge absorbers in supply cable.
AE09	DC link overvoltage	Excessive intermediate circuit DC voltage.  Note: This warning can be shown only when the IGBT supply unit is not modulating.	Check that parameter 95.01 Supply voltage is set according to the supply voltage in use.
AE0A	DC link undervoltage	Intermediate circuit DC voltage is not sufficient due to missing phase in supply voltage, blown fuse or rectifier bridge internal fault.  Note: This warning can be shown only when the IGBT supply unit is not modulating.	Check supply and fuses. Check that parameter 95.01 Supply voltage is set according to the supply voltage in use.
AE0B	DC not charged	The voltage of the intermediate DC circuit has not yet risen to operating level.	Check the input voltage setting in parameter 95.01 Supply voltage. Check the input voltage. If the problem persists, contact your local ABB representative.

Code (hex)	Warning / Aux. code	Cause	What to do
AE0C	BU DC link difference	DC link voltage difference detected by the branching unit.	Check DC fuses. Check converter module connections to DC link.
AE0D	BU voltage difference	Main voltage difference detected by the branching unit.	Check AC fuses. Check supply cable.
AE14	Excess temperature	High temperature difference between the IGBTs of different phases.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against IGBT supply unit power.
AE15	Excess temperature difference	High temperature difference between the IGBTs of different phases.	Check the cabling. Check cooling of power module(s).
AE16	IGBT temperature	IGBT temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against IGBT supply unit power.
AE24	Voltage category unselected	The supply voltage range has not been defined.	Define the supply voltage range (parameter 95.01 Supply voltage).
AE5F	Temperature Warning	Supply module temperature is excessive due to eg, module overload or fan failure.	Check module cooling air flow and fan operation. Check ambient temperature. If it exceeds 40 °C (104 °F), ensure that load current does not exceed derated load capacity. See appropriate hardware manual. Check inside of cabinet and heatsink of supply module for dust pick-up. Clean whenever necessary.
AE73	Fan	Cooling fan is stuck or disconnected.	Check the auxiliary code in the line-side converter program to identify the fan. Check fan operation and connection. Replace fan if faulty.
AE78	Net lost	Net lost is detected.	Resynchronize the IGBT supply unit to the grid after net lost.
AE85	Charging count	There are too many DC link charging attempts.	Two attempts in five minutes is allowed to prevent charging circuit overheating.

## Auxiliary codes for line-side converter faults

The table below lists the auxiliary codes of 7583 *Line side unit faulted*. For advanced troubleshooting, see the firmware manual of the line converter.

Code (hex)	Fault / Aux. code	Cause	What to do
2E00	Overcurrent	Output current has exceeded internal fault limit.	Check supply voltage. Check that there are no power factor correction capacitors or surge absorbers in supply cable. Check motor load and acceleration times. Check power semiconductors (IGBTs) and current transducers.
2E01	Earth leakage Programmable fault: 31.120 LSU earth fault	IGBT supply unit has detected an earth fault.	Check AC fuses. Check for earth leakages. Check supply cabling. Check power modules. Check there are no power factor correction capacitors or surge absorbers in supply cable. If no earth fault can be detected, contact your local ABB representative.
2E02	Short circuit	IGBT supply unit has detected short circuit.	Check supply cable. Check there are no power factor correction capacitors or surge absorbers in supply cable. After correcting the cause of the fault, reboot the control unit (using parameter 96.08 Control board boot) or by cycling power.
2E04	IGBT overload	Excessive IGBT junction to case temperature.	Check the load.
2E05	BU current difference	Current difference detected by the branching unit (BU).	Check converter fuses. Check converter(s). Check inverter(s). Check LCL filter. Power off all boards. If the fault persists, contact your local ABB representative.
2E06	BU earth leakage	Earth leakage detected by the branching unit: sum of all currents exceeds the level.	Check AC fuses. Check for earth leakages. Check supply cabling. Check power modules. Check there are no power factor correction capacitors or surge absorbers in supply cable. If no earth fault can be detected, contact your local ABB representative.

Code (hex)	Fault / Aux. code	Cause	What to do
3E00	Input phase loss Programmable fault: 31.121 LSU supply phase loss	Input phase loss detected by the IGBT bridge.	Check the auxiliary code. Check the source of the fault corresponding to the code:  1: Phase A  2: Phase B  4: Phase C  8: Phase cannot be detected Check the AC fuses. Check for input power supply imbalance
3E04	DC link overvoltage	Excessive intermediate circuit DC voltage.	Check that parameter 95.01 Supply voltage is set according to the supply voltage in use.
3E05	DC link undervoltage	Intermediate circuit DC voltage is not sufficient because of a missing supply phase or blown fuse.	Check supply cabling, fuses and switchgear. Check that parameter 95.01 Supply voltage is set according to the supply voltage in use.
3E06	BU DC link difference	Difference in DC voltages between parallel-connected supply modules.	Check the DC fuses. Check the connection to the DC bus. If the problem persists, contact your local ABB representative.
3E07	BU voltage difference	Difference in main voltages between parallel-connected supply modules.	Check the supply network connections. Check the AC fuses. If the problem persists, contact your local ABB representative.
3E08	LSU charging	DC link voltage is not high enough after charging.	Check parameter 95.01 Supply voltage. Check supply voltage and fuses. Check the connection from the relay output to the charging contactor. Check that the DC voltage measuring circuit is working correctly.
4E01	Cooling	Power module temperature is excessive.	Check ambient temperature. If it exceeds 40 °C (104 °F), ensure that load current does not exceed derated load capacity. See appropriate hardware manual. Check power module cooling air flow and fan operation.  Check inside of cabinet and heatsink of power module for dust pick-up. Clean whenever necessary.
4E02	IGBT temperature	IGBT temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against IGBT supply unit power.
4E03	Excess temperature	Power unit module temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up.

Code (hex)	Fault / Aux. code	Cause	What to do
4E04	Excess temperature difference	High temperature difference between the IGBTs of different phases. The amount of available temperatures depends on the frame size.	See AE15 Excess temperature difference (page 519).
4E06	Cabinet or LCL overtemperature	Overtemperature detected either in cabinet, LCL filter or auxiliary transformer.	Check the cooling of the cabinet, LCL filter and auxiliary transformer.
5E05	Rating ID mismatch	The hardware of the supply unit does not match the information stored in the memory unit. This may occur eg, after a firmware update or memory unit replacement.	Cycle the power to the supply unit. If the control unit is externally powered, reboot the control unit (using parameter 96.108 LSU control board boot) or by cycling its power.  If the problem persists, contact your local ABB representative.
5E06	Main contactor Fault	Control program does not receive main contactor on (1) acknowledgement through digital input even control program has closed the contactor control circuit with relay output.  Main contactor / main breaker is not functioning properly, or there is a loose / bad connection.	Check main contactor / main breaker control circuit wiring. Check the status of other switches connected to contactor control circuit. See the delivery-specific circuit diagrams. Check main contactor operating voltage level (should be 230 V). Check digital input DI3 connections.
6E19	Synchronization fault	Synchronization to supply network has failed.	Monitor possible network transients.
6E1A	Rating ID fault	Rating ID load error.	Contact your local ABB representative.
6E1F	Licensing fault	There are two types of licenses being used in ACS880 drives: licenses that need to be found from the unit which allow the firmware to be executed, and licenses that prevent the firmware from running. The license is indicated by the value of the auxiliary code field. The license is Nxxxx, where xxxx is indicated by the 4-digit value of the auxiliary code field.	Check the line-converter control program. Record the auxiliary codes of all active licensing faults and contact your product vendor for further instructions. This fault requires a reboot of the control unit either by switching the power off and on, or using parameter 96.108 LSU control board boot.
	8201	A restrictive license is found from the unit. The firmware on this inverter unit cannot be executed because a Low harmonic license is found from the unit. This unit is meant to be used with IGBT supply control program (2Q) only.	Contact your product vendor for further instructions.
7E01	Panel loss  Control panel or PC tool selected as active control location has ceased communicating.		Check PC tool or control panel connection. Check control panel connector. Replace control panel in mounting platform.

Code (hex)	Fault / Aux. code	Cause	What to do
8E07	Net lost	Net lost is detected. Duration of net lost is too long.	Resynchronize the IGBT supply unit to the grid after net lost.



# Fieldbus control through the embedded fieldbus interface (EFB)

### What this chapter contains


The chapter describes how the drive can be controlled by external devices over a communication network (fieldbus) using the embedded fieldbus interface.

### System overview

The drive can be connected to an external control system through a communication link using either a fieldbus adapter or the embedded fieldbus interface.

The embedded fieldbus interface supports the Modbus RTU protocol. The drive control program can handle 10 Modbus registers in a 10-millisecond time level. For example, if the drive receives a request to read 20 registers, it will start its response within 22 ms of receiving the request - 20 ms for processing the request and 2 ms overhead for handling the bus. The actual response time depends on other factors as well, such as the baud rate (a parameter setting in the drive).

The drive can be set to receive all of its control information through the fieldbus interface, or the control can be distributed between the embedded fieldbus interface and other available sources, for example, digital and analog inputs.



### Connecting the fieldbus to the drive

Connect the fieldbus to terminal XD2D on the control unit of the drive. See the appropriate Hardware Manual for more information on the connection, chaining and termination of the link.

Note: If the XD2D connector is reserved by the embedded fieldbus interface (parameter 58.01 Protocol enable is set to Modbus RTU), the drive-to-drive link functionality is automatically disabled.

### Setting up the embedded fieldbus interface

Set the drive up for the embedded fieldbus communication with the parameters shown in the table below. The Setting for fieldbus control column gives either the value to use or the default value. The Function/Information column gives a description of the parameter.

Parame	eter	Setting for fieldbus control	Function/Information	
COMM	COMMUNICATION INITIALIZATION			
58.01	Protocol enable	Modbus RTU	Initializes embedded fieldbus communication. Drive-to-drive link operation is automatically disabled.	
EMBED	DED MODBUS CO	ONFIGURATION		
58.03	Node address	1 (default)	Node address. There must be no two nodes with the same node address online.	
58.04	Baud rate	19.2 kbps (default)	Defines the communication speed of the link. Use the same setting as in the master station.	
58.05	Parity	8 EVEN 1 (default)	Selects the parity and stop bit setting. Use the same setting as in the master station.	
58.14	Communication loss action	Fault (default)	Defines the action taken when a communication loss is detected.	
58.15	Communication loss mode	Cw / Ref1 / Ref2 (default)	Enables/disables communication loss monitoring and defines the means for resetting the counter of the communication loss delay.	
58.16	Communication loss time	3.0 s (default)	Defines the timeout limit for the communication monitoring.	
58.17	Transmit delay	0 ms (default)	Defines a response delay for the drive.	
58.25	Control profile	ABB Drives (default), Transparent	Selects the control profile used by the drive. See section <i>Basics of the embedded fieldbus interface</i> (page <i>530</i> ).	
58.26 	EFB ref1 type	Auto, Transparent, General, Torque,	Selects the reference and actual value types. With the <i>Auto</i> setting, the type is selected	
58.29	EFB act2 type	Speed, Frequency	automatically according to the currently active drive control mode.	
58.30	EFB status word transparent source	Other	Defines the source of status word when 58.25 Control profile = Transparent.	
58.31	EFB act1 transparent source	Other	Defines the source of actual value 1 when 58.28 EFB act1 type = Transparent or General.	
58.32	EFB act2 transparent source	Other	Defines the source of actual value 2 when 58.29 EFB act2 type = Transparent or General.	

Parameter		Setting for fieldbus control	Function/Information
58.33	Addressing mode	eg. <i>Mode 0</i> (default)	Defines the mapping between parameters and holding registers in the 400001465536 (10065535) Modbus register range.
58.34	Word order	LO-HI (default)	Defines the order of the data words in the Modbus message frame.
	Data I/O 1  Data I/O 24	For example, the default settings (I/Os 16 contain the control word, the status word, two references and two actual values)	Define the address of the drive parameter which the Modbus master accesses when it reads from or writes to the register address corresponding to Modbus In/Out parameters. Select the parameters that you want to read or write through the Modbus I/O words.
		RO/DIO control word, AO1 data storage, AO2 data storage, Feedback data storage, Setpoint data storage	These settings write the incoming data into storage parameters 10.99 RO/DIO control word, 13.91 AO1 data storage, 13.92 AO2 data storage.
58.06	Communication control	Refresh settings	Validates the settings of the configuration parameters.

The new settings will take effect when the drive is powered up the next time, or when they are validated by parameter 58.06 Communication control.

### Setting the drive control parameters

After the embedded fieldbus interface has been set up, check and adjust the drive control parameters listed in the table below. The Setting for fieldbus control column gives the value or values to use when the embedded fieldbus signal is the desired source or destination for that particular drive control signal. The Function/Information column gives a description of the parameter.

Parameter	Setting for fieldbus control	Function/Information			
CONTROL COMMAND SOURCE SELECTION					
20.01 Ext1 commands	Embedded fieldbus	Selects fieldbus as the source for the start and stop commands when EXT1 is selected as the active control location.			
20.02 Ext2 commands	Embedded fieldbus	Selects fieldbus as the source for the start and stop commands when EXT2 is selected as the active control location.			
SPEED REFERENCE SELECTION					
22.11 Speed ref1 source	EFB ref1 or EFB ref2	Selects a reference received through the embedded fieldbus interface as speed reference 1.			

Parameter	Setting for fieldbus control	Function/Information			
22.12 Speed ref2 source	EFB ref1 or EFB ref2	Selects a reference received through the embedded fieldbus interface as speed reference 2.			
FREQUENCY REFERENCE SELECTION					
28.11 Frequency ref1 source	EFB ref1 or EFB ref2	Selects a reference received through the embedded fieldbus interface as frequency reference 1.			
28.12 Frequency ref2 source	EFB ref1 or EFB ref2	Selects a reference received through the embedded fieldbus interface as frequency reference 2.			
PCP REFERENCE SELECTION					
74.05 Speedrefsource	EFB1 ref or EFB2 ref	Selects a reference received through the embedded fieldbus interface as speed reference 1 or reference 2.			

#### OTHER SELECTIONS

EFB references can be selected as the source at virtually any signal selector parameter by selecting *Other*, then either 03.09 *EFB reference 1* or 03.10 *EFB reference 2*.


CONTROL OF RELAY OUTPUTS, ANALOG OUTPUTS AND DIGITAL INPUT/OUTPUTS				
10.24 RO1 source	RO/DIO control word bit0	Connects bit 0 of storage parameter 10.99 RO/DIO control word to relay output RO1.		
10.27 RO2 source	RO/DIO control word bit1	Connects bit 1 of storage parameter 10.99 RO/DIO control word to relay output RO2.		
10.30 RO3 source	RO/DIO control word bit2	Connects bit 2 of storage parameter 10.99 RO/DIO control word to relay output RO3.		
11.05 DIO1 function 11.09 DIO2 function	Output (default)	Sets the digital input/output to output mode.		
11.06 DIO1 output source	RO/DIO control word bit8	Connects bit 8 of storage parameter 10.99  RO/DIO control word to digital input/output DIO1.		
11.10 DIO2 output source	RO/DIO control word bit9	Connects bit 9 of storage parameter 10.99  RO/DIO control word to digital input/output DIO2.		
13.12 AO1 source	AO1 data storage	Connects storage parameter 13.91 AO1 data storage to analog output AO1.		
13.22 AO2 source	AO2 data storage	Connects storage parameter 13.92 AO2 data storage to analog output AO2.		

SYSTEM CONTROL INPUTS			
96.07 Parameter save manually	Save (reverts to Done)	Saves parameter value changes (including those made through fieldbus control) to permanent memory.	

### Basics of the embedded fieldbus interface

The cyclic communication between a fieldbus system and the drive consists of 16-bit data words or 32-bit data words (with the transparent control profiles).

The diagram below illustrates the operation of the embedded fieldbus interface. The signals transferred in the cyclic communication are explained further below the diagram.



- 1. See also other parameters which can be controlled through fieldbus.
- 2. Data conversion if parameter 58.25 Control profile is set to ABB Drives. See section About the control profiles (page 533).
- 3. If parameter 58.25 Control profile is set to Transparent,
- the sources of the status word and actual values are selected by parameters 58.30...58.32 (otherwise, actual values 1 and 2 are automatically selected according to reference type), and
- the control word is displayed by 06.05 EFB transparent control word.

#### Control word and Status word

The Control Word (CW) is a 16-bit or 32-bit packed boolean word. It is the principal means of controlling the drive from a fieldbus system. The CW is sent by the fieldbus controller to the drive. By drive parameters, the user selects the EFB CW as the source of drive control commands (such as start/stop, emergency stop, selection between external control locations 1/2, or fault reset). The drive switches between its states according to the bit-coded instructions of the CW.

The fieldbus CW is either written to the drive as it is (see parameter 06.05 EFB transparent control word)or the data is converted. See section About the control profiles (page 533).

The fieldbus Status Word (SW) is a 16-bit or 32-bit packed boolean word. It contains status information from the drive to the fieldbus controller. The drive SW is either written to the fieldbus SW as it is or the data is converted. See section About the control profiles (page 533).

#### References

EFB references 1 and 2 are 16-bit or 32-bit signed integers. The contents of each reference word can be used as the source of virtually any signal, such as the speed, frequency, torque or process reference. In embedded fieldbus communication. references 1 and 2 are displayed by 03.09 EFB reference 1 and 03.10 EFB reference 2 respectively. Whether the references are scaled or not depends on the settings of 58.26 EFB ref1 type and 58.27 EFB ref2 type. See section About the control profiles (page 533).

#### **Actual values**

Fieldbus actual signals (ACT1 and ACT2) are 16-bit or 32-bit signed integers. They convey selected drive parameter values from the drive to the master. Whether the actual values are scaled or not depends on the settings of 58.28 EFB act1 type and 58.29 EFB act2 type. See section About the control profiles (page 533).

#### Data input/outputs

Data input/outputs are 16-bit or 32-bit words containing selected drive parameter values. Parameters 58.101 Data I/O 1 ... 58.124 Data I/O 24 define the addresses from which the master either reads data (input) or to which it writes data (output).

#### Control of drive outputs through EFB

The address selection parameters of the data input/outputs have a setting with which the data can be written into a storage parameter in the drive. These storage parameters are readily selectable as signal sources of the drive outputs.

The desired values of the relay outputs (RO) and digital input/outputs (DIO) can be written in a 16-bit word into 10.99 RO/DIO control word, which is then selected as the source of those outputs. Each of the analog outputs (AO) of the drive have a

dedicated storage parameter (13.91 AO1 data storage and 13.92 AO2 data storage), which are available in the source selection parameters 13.12 AO1 source and 13.22 AO2 source.

#### Register addressing

The address field of Modbus requests for accessing holding registers is 16 bits. This allows the Modbus protocol to support addressing of 65536 holding registers.

Historically, Modbus master devices used 5-digit decimal addresses from 40001 to 49999 to represent holding register addresses. The 5-digit decimal addressing limited to 9999 the number of holding registers that could be addressed.

Modern Modbus master devices typically provide a means to access the full range of 65536 Modbus holding registers. One of these methods is to use 6-digit decimal addresses from 400001 to 465536. This manual uses 6-digit decimal addressing to represent Modbus holding register addresses.

Modbus master devices that are limited to the 5-digit decimal addressing may still access registers 400001 to 409999 by using 5-digit decimal addresses 40001 to 49999. Registers 410000 to 465536 are inaccessible to these masters.


Note: Register addresses of 32-bit parameters cannot be accessed by using 5-digit register numbers.

### About the control profiles

A control profile defines the rules for data transfer between the drive and the fieldbus master, for example:

- if packed boolean words are converted and how
- how drive register addresses are mapped for the fieldbus master.

You can configure the drive to receive and send messages according to the ABB Drives profile or the Transparent profile. With the ABB Drives profile, the embedded fieldbus interface of the drive converts the control word and status word to and from the native data used in the drive. The Transparent profile involves no data conversion. The figure below illustrates the effect of the profile selection.



Control profile selection with parameter 58.25 Control profile:

- (0) ABB Drives
- · (2) Transparent

Note that scaling of references and actual values can be selected independent of the profile selection by parameters 58.26...58.29.

### The ABB Drives profile

#### Control Word

The table below shows the contents of the fieldbus Control Word for the ABB Drives control profile. The embedded fieldbus interface converts this word to the form in which it is used in the drive. The upper case boldface text refers to the states shown in *State transition diagram* on page 537.

Bit	Name	Value	STATE/Description
	0 OFF1_ CONTROL	1	Proceed to READY TO OPERATE.
		0	Stop along currently active deceleration ramp. Proceed to OFF1 ACTIVE; proceed to READY TO SWITCH ON unless other interlocks (OFF2, OFF3) are active.
1	OFF2_	1	Continue operation (OFF2 inactive).
	CONTROL	0	Emergency OFF, coast to stop. Proceed to OFF2 ACTIVE, proceed to SWITCH-ON INHIBITED.
2	OFF3_	1	Continue operation (OFF3 inactive).
	CONTROL	0	Emergency stop, stop within time defined by drive parameter. Proceed to OFF3 ACTIVE; proceed to SWITCH-ON INHIBITED.  Warning: Ensure that the motor and driven machine can
			be stopped using this stop mode.
3	INHIBIT_	1	Proceed to OPERATION ENABLED.
	OPERATION		<b>Note:</b> Run enable signal must be active; see the drive documentation. If the drive is set to receive the Run enable signal from the fieldbus, this bit activates the signal.
		0	Inhibit operation. Proceed to <b>OPERATION INHIBITED</b> .
4	RAMP_OUT_ ZERO	1	Normal operation. Proceed to RAMP FUNCTION GENERATOR: OUTPUT ENABLED.
		0	Force Ramp Function Generator output to zero. Drive ramps to stop (current and DC voltage limits in force).
5	RAMP_HOLD	1	Enable ramp function. Proceed to RAMP FUNCTION GENERATOR: ACCELERATOR ENABLED.
		0	Halt ramping (Ramp Function Generator output held).
6	RAMP_IN_ ZERO	1	Normal operation. Proceed to <b>OPERATING</b> .
			<b>Note:</b> This bit is effective only if the fieldbus interface is set as the source for this signal by drive parameters.
		0	Force Ramp Function Generator input to zero.
7	RESET	0=>1	Fault reset if an active fault exists. Proceed to <b>SWITCH-ON INHIBITED</b> .
			<b>Note:</b> This bit is effective only if the fieldbus interface is set as the source for this signal by drive parameters.
		0	Continue normal operation.

Bit	Name	Value	STATE/Description
8	JOGGING_1	1	Accelerate to jogging 1 reference.  Notes: Bits 46 must be 0. See also section Jogging (page 78).
		0	Jogging 1 disabled.
9	9 JOGGING_2	1	Accelerate to jogging 2 reference. See notes at bit 8.
		0	Jogging 2 disabled.
10	REMOTE_	1	Fieldbus control enabled.
	CMD	0	Control word and reference will not get through to the drive, except for CW bits OFF1, OFF2 and OFF3.
11	11 EXT_CTRL_ LOC	1	Select External Control Location EXT2. Effective if the control location is parameterized to be selected from the fieldbus.
		0	Select External Control Location EXT1. Effective if the control location is parameterized to be selected from the fieldbus.
1215	Reserved		


#### Status Word

The table below shows the fieldbus Status Word for the ABB Drives control profile. The embedded fieldbus interface converts the drive Status Word into this form for the fieldbus. The upper case boldface text refers to the states shown in *State transition diagram* on page 537.

Bit	Name	Value	STATE/Description
0	RDY_ON	1	READY TO SWITCH ON.
		0	NOT READY TO SWITCH ON.
1	RDY_RUN	1	READY TO OPERATE.
		0	OFF1 ACTIVE.
2	RDY_REF	1	OPERATION ENABLED.
		0	OPERATION INHIBITED.
3	TRIPPED	1	FAULT.
		0	No fault.
4	OFF_2_STA	1	OFF2 inactive.
		0	OFF2 ACTIVE.
5	OFF_3_STA	1	OFF3 inactive.
		0	OFF3 ACTIVE.
6	SWC_ON_ INHIB	1	SWITCH-ON INHIBITED.
		0	-
7	ALARM	1	Warning/Alarm.
		0	No warning/alarm.
8	AT_ SETPOINT	1	OPERATING. Actual value equals Reference = is within tolerance limits, i.e. in speed control, speed error is 10% max. of nominal motor speed.
		0	Actual value differs from Reference = is outside tolerance limits.
9	REMOTE	1	Drive control location: REMOTE (EXT1 or EXT2).
		0	Drive control location: LOCAL.
10	ABOVE_ LIMIT	1	Actual frequency or speed equals or exceeds supervision limit (set by drive parameter). Valid in both directions of rotation.
		0	Actual frequency or speed within supervision limit.
11	USER_0		S
12	EXT_RUN_ ENABLE	1	External Run enable signal received.
		0	No external Run enable signal received.
1315	Reserved		
	•		

#### State transition diagram


The diagram below shows the state transitions in the drive when the drive is using the ABB Drives profile, and configured to follow the commands of the control word from the embedded fieldbus interface. The upper case texts refer to the states which are used in the tables representing the fieldbus Control and Status words. See sections Control Word on page 534 and Status Word on page 536.



#### References

The ABB drives profile supports the use of two references, EFB reference 1 and EFB reference 2. The references are 16-bit words each containing a sign bit and a 15-bit integer. A negative reference is formed by calculating the two's complement from the corresponding positive reference.

The references are scaled as defined by parameters 46.01... 46.07; which scaling is in use depends on the setting of 58.26 EFB ref1 type and 58.27 EFB ref2 type (see page 348).




The scaled references are shown by parameters 03.09 EFB reference 1 and 03.10 EFB reference 2.

#### Actual values

The ABB Drives profile supports the use of two fieldbus actual values, ACT1 and ACT2. The actual values are 16-bit words each containing a sign bit and a 15-bit integer. A negative value is formed by calculating the two's complement from the corresponding positive value.

The actual values are scaled as defined by parameters 46.01...46.04; which scaling is in use depends on the setting of parameters 58.28 EFB act1 type and 58.29 EFB act2 type (see page 348).



### Modbus holding register addresses

The table below shows the default Modbus holding register addresses for drive data. This profile provides a converted 16-bit access to the data.

Register address	Register data (16-bit words)
400001	Control word. See section Control Word (page 534).
	The selection can be changed using parameter 58.101 Data I/O 1.
400002	Reference 1 (REF1).
	The selection can be changed using parameter 58.102 Data I/O 2.
400003	Reference 2 (REF2).
	The selection can be changed using parameter 58.103 Data I/O 3.
400004	Status Word (SW). See section Status Word (page 536).
	The selection can be changed using parameter 58.104 Data I/O 4.
400005	Actual value 1 (ACT1).
	The selection can be changed using parameter 58.105 Data I/O 5.
400006	Actual value 2 (ACT2).
	The selection can be changed using parameter 58.106 Data I/O 6.
400007400024	Data in/out 724.
	Selected by parameters 58.107 Data I/O 7 58.124 Data I/O 24.
400025400089	Unused
400090400100	Error code access. See section <i>Error code registers</i> (holding registers 400090400100) (page 547).
400101465536	Parameter read/write.
	Parameters are mapped to register addresses according to parameter 58.33 Addressing mode.

## The Transparent profile

The Transparent profile enables a customizable access to the drive.

The contents of the control word are user-definable. The control word received from the fieldbus is visible in parameter 06.05 EFB transparent control word, and can be used to control the drive using pointer parameters and/or application programming.

The status word to be sent to the fieldbus controller is selected by parameter 58.30 EFB status word transparent source. This can be, for example, the user-configurable status word in 06.50 User status word 1.

The Transparent profile involves no data conversion of the control or status word. Whether references or actual values are scaled depends on the setting of parameters 58.26...58.29. The references received from the fieldbus are visible in parameters 03.09 EFB reference 1 and 03.10 EFB reference 2.

The Modbus holding register addresses for the Transparent profile are as with the ABB Drives profile (see page 540).

## **Modbus function codes**

The table below shows the Modbus function codes supported by the embedded fieldbus interface.

Code	Function name	Description
01h	Read Coils	Reads the 0/1 status of coils (0X references).
02h	Read Discrete Inputs	Reads the 0/1 status of discrete inputs (1X references).
03h	Read Holding Registers	Reads the binary contents of holding registers (4X references).
05h	Write Single Coil	Forces a single coil (0X reference) to 0 or 1.
06h	Write Single Register	Writes a single holding register (4X reference).
08h	Diagnostics	Provides a series of tests for checking the communication, or for checking various internal error conditions.
		Supported subcodes:
		00h Return Query Data: Echo/loopback test.
		01h Restart Comm Option: Restarts and initializes the EFB, clears communications event counters.
		04h Force Listen Only Mode
		0Ah Clear Counters and Diagnostic Register
		0Bh Return Bus Message Count
		0Ch Return Bus Comm. Error Count
		0Dh Return Bus Exception Error Count
		0Eh Return Slave Message Count
		OFh Return Slave No Response Count
		10h Return Slave NAK (negative acknowledge)     Count
		11h Return Slave Busy Count
		12h Return Bus Character Overrun Count
		14h Clear Overrun Counter and Flag
0Bh	Get Comm Event Counter	Returns a status word and an event count.
0Fh	Write Multiple Coils	Forces a sequence of coils (0X references) to 0 or 1.
10h	Write Multiple Registers	Writes the contents of a contiguous block of holding registers (4X references).
16h	Mask Write Register	Modifies the contents of a 4X register using a combination of an AND mask, an OR mask, and the register's current contents.
17h	Read/Write Multiple Registers	Writes the contents of a contiguous block of 4X registers, then reads the contents of another group of registers (the same or different than those written) in a server device.

Code	Function name	Description
2Bh / 0Eh	Encapsulated Interface	Supported subcodes:
	Transport	0Eh Read Device Identification: Allows reading the identification and other information.
		Supported ID codes (access type):
		00h: Request to get the basic device identification (stream access)
		04h: Request to get one specific identification object (individual access)
		Supported Object IDs:
		00h: Vendor Name ("ABB")
		01h: Product Code (for example, "AINFX")
		02h: Major Minor Revision (combination of contents of parameters 07.05 Firmware version and 58.02 Protocol ID).
		03h: Vendor URL ("www.abb.com")
		04h: Product name (for example, "ACS880")

# **Exception codes**

The table below shows the Modbus exception codes supported by the embedded fieldbus interface.

Code	Name	Description
01h	ILLEGAL FUNCTION	The function code received in the query is not an allowable action for the server.
02h	ILLEGAL DATA ADDRESS	The data address received in the query is not an allowable address for the server.
03h	ILLEGAL DATA VALUE	The requested Quantity of Registers is larger than the drive can handle.  Note: This error does not mean that a value written to a drive parameter is outside the valid range.
04h	SLAVE DEVICE FAILURE	The value written to a drive parameter is outside the valid range. See section <i>Error code registers (holding registers 400090400100)</i> (page 547).
06h	SLAVE DEVICE BUSY	The server is engaged in processing a long-duration program command.

# Coils (0xxxx reference set)

Coils are 1-bit read/write values. Control Word bits are exposed with this data type. The table below summarizes the Modbus coils (0xxxx reference set).

Reference	ABB drives profile	Transparent profile
00001	OFF1_CONTROL	Control Word bit 0
00002	OFF2_CONTROL	Control Word bit 1
00003	OFF3_CONTROL	Control Word bit 2
00004	INHIBIT_OPERATION	Control Word bit 3
00005	RAMP_OUT_ZERO	Control Word bit 4
00006	RAMP_HOLD	Control Word bit 5
00007	RAMP_IN_ZERO	Control Word bit 6
80000	RESET	Control Word bit 7
00009	JOGGING_1	Control Word bit 8
00010	JOGGING_2	Control Word bit 9
00011	REMOTE_CMD	Control Word bit 10
00012	EXT_CTRL_LOC	Control Word bit 11
00013	User-defined (0)	Control Word bit 12
00014	User-defined (1)	Control Word bit 13
00015	User-defined (2)	Control Word bit 14
00016	User-defined (3)	Control Word bit 15
00017	Reserved	Control Word bit 16
00018	Reserved	Control Word bit 17
00019	Reserved	Control Word bit 18
00020	Reserved	Control Word bit 19
00021	Reserved	Control Word bit 20
00022	Reserved	Control Word bit 21
00023	Reserved	Control Word bit 22
00024	Reserved	Control Word bit 23
00025	Reserved	Control Word bit 24
00026	Reserved	Control Word bit 25
00027	Reserved	Control Word bit 26
00028	Reserved	Control Word bit 27
00029	Reserved	Control Word bit 28
00030	Reserved	Control Word bit 29
00031	Reserved	Control Word bit 30
00032	Reserved	Control Word bit 31
00033	Reserved	10.99 RO/DIO control word, bit 0
00034	Reserved	10.99 RO/DIO control word, bit 1

Reference	ABB drives profile	Transparent profile
00035	Reserved	10.99 RO/DIO control word, bit 2
00036	Reserved	10.99 RO/DIO control word, bit 3
00037	Reserved	10.99 RO/DIO control word, bit 4
00038	Reserved	10.99 RO/DIO control word, bit 5
00039	Reserved	10.99 RO/DIO control word, bit 6
00040	Reserved	10.99 RO/DIO control word, bit 7
00041	Reserved	10.99 RO/DIO control word, bit 8
00042	Reserved	10.99 RO/DIO control word, bit 9

# **Discrete inputs (1xxxx reference set)**

Discrete inputs are 1-bit read-only values. Status Word bits are exposed with this data type. The table below summarizes the Modbus discrete inputs (1xxxx reference set).

Reference	ABB drives profile	Transparent profile
10001	RDY_ON	Status Word bit 0
10002	RDY_RUN	Status Word bit 1
10003	RDY_REF	Status Word bit 2
10004	TRIPPED	Status Word bit 3
10005	OFF_2_STA	Status Word bit 4
10006	OFF_3_STA	Status Word bit 5
10007	SWC_ON_INHIB	Status Word bit 6
10008	ALARM	Status Word bit 7
10009	AT_SETPOINT	Status Word bit 8
10010	REMOTE	Status Word bit 9
10011	ABOVE_LIMIT	Status Word bit 10
10012	User-defined (0)	Status Word bit 11
10013	User-defined (1)	Status Word bit 12
10014	User-defined (2)	Status Word bit 13
10015	User-defined (3)	Status Word bit 14
10016	Reserved	Status Word bit 15
10017	Reserved	Status Word bit 16
10018	Reserved	Status Word bit 17
10019	Reserved	Status Word bit 18
10020	Reserved	Status Word bit 19
10021	Reserved	Status Word bit 20
10022	Reserved	Status Word bit 21
10023	Reserved	Status Word bit 22
10024	Reserved	Status Word bit 23

Reference	ABB drives profile	Transparent profile
10025	Reserved	Status Word bit 24
10026	Reserved	Status Word bit 25
10027	Reserved	Status Word bit 26
10028	Reserved	Status Word bit 27
10029	Reserved	Status Word bit 28
10030	Reserved	Status Word bit 29
10031	Reserved	Status Word bit 30
10032	Reserved	Status Word bit 31
10033	Reserved	10.02 DI delayed status, bit 0
10034	Reserved	10.02 DI delayed status, bit 1
10035	Reserved	10.02 DI delayed status, bit 2
10036	Reserved	10.02 DI delayed status, bit 3
10037	Reserved	10.02 DI delayed status, bit 4
10038	Reserved	10.02 DI delayed status, bit 5
10039	Reserved	10.02 DI delayed status, bit 6
10040	Reserved	10.02 DI delayed status, bit 7
10041	Reserved	10.02 DI delayed status, bit 8
10042	Reserved	10.02 DI delayed status, bit 9
10043	Reserved	10.02 DI delayed status, bit 10
10044	Reserved	10.02 DI delayed status, bit 11
10045	Reserved	10.02 DI delayed status, bit 12
10046	Reserved	10.02 DI delayed status, bit 13
10047	Reserved	10.02 DI delayed status, bit 14
10048	Reserved	10.02 DI delayed status, bit 15

# Error code registers (holding registers 400090...400100)

These registers contain information about the last query. The error register is cleared when a query has finished successfully.

Reference	Name	Description
90	Reset Error Registers	1 = Reset internal error registers (9195).
91	Error Function Code	Function code of the failed query.
92	Error Code	Set when exception code 04h is generated (see table above).  • 00h No error  • 02h Low/High limit exceeded  • 03h Faulty Index: Unavailable index of an array parameter  • 05h Incorrect Data Type: Value does not match the data type of the parameter  • 65h General Error: Undefined error when handling query
93	Failed Register	The last register (discrete input, coil, or holding register) that failed to be read or written.
94	Last Register Written Successfully	The last register that was written successfully.
95	Last Register Read Successfully	The last register that was read successfully.

548	Fieldbus control through the embedded fieldbus interface (EFB)



# Fieldbus control through a fieldbus adapter

## Contents of this chapter

This chapter describes how the drive can be controlled by external devices over a communication network (fieldbus) through an optional fieldbus adapter module.

The fieldbus control interface of the drive is described first, followed by a configuration example.

## System overview


The drive can be connected to an external control system through an optional fieldbus adapter mounted onto the control unit of the drive. The drive actually has two independent interfaces for fieldbus connection, called "fieldbus adapter A" (FBAA) and "fieldbus adapter B" (FBAB). The drive can be configured to receive all of its control information through the fieldbus interface(s), or the control can be distributed between the fieldbus interface(s) and other available sources such as digital and analog inputs, depending on how control locations EXT1 and EXT2 are configured.

Note: The text and examples in this chapter describe the configuration of one fieldbus adapter (FBAA) by parameters 50.01...50.21 and parameter groups 51...53. The second adapter (FBA B), if present, is configured in a similar fashion by parameters 50.31...50.51 and parameter groups 54 FBA B settings...56 FBA B data out. It is recommended that the FBAB interface is only used for monitoring.

Fieldbus adapters are available for various communication systems and protocols, for example

- CANopen (FCAN-01 adapter)
- ControlNet (FCNA-01 adapter)
- DeviceNet (FDNA-01 adapter)
- EtherCAT® (FECA-01 adapter)
- EtherNet/IP<sup>™</sup> (FENA-11 or FENA-21 adapter)
- Modbus/RTU (FSCA-01 adapter)
- Modbus/TCP (FENA-11 or FENA-21 adapter)
- POWERLINK (FEPL-02 adapter)
- PROFIBUS DP (FPBA-01 adapter)
- PROFINET IO (FENA-11 or FENA-21 adapter).


Note: Fieldbus adapters with the suffix "M" (eg. FPBA-01-M) are not supported.



#### Basics of fieldbus control interface

The cyclic communication between a fieldbus system and the drive consists of 16 and 32-bit input and output data words. The drive supports the use of maximum 12 data words (16 bits) in each direction.

Data transmitted from the drive to the fieldbus controller is defined by parameters 52.01 FBA A data in1 ... 52.12 FBA A data in12. The data transmitted from the fieldbus controller to the drive is defined by parameters 53.01 FBA A data out1 ... 53.12 FBA A data out12.



- 1) See also other parameters which can be controlled from fieldbus.
- 2) The maximum number of used data words is protocol-dependent.
- 3) Profile/instance selection parameters. Fieldbus module specific parameters. For more information, see the User's Manual of the appropriate fieldbus adapter
- 4) With DeviceNet, the control part is transmitted directly.
- 5) With DeviceNet, the actual value part is transmitted directly.

#### Control word and Status word

The Control word is used for controlling the drive from a fieldbus system. It is sent by the fieldbus master station to the drive through the adapter module. The drive switches between its states according to the bit coded instructions on the Control word, and returns status information to the master in the Status word.

For the ABB Drives communication profile, the contents of the Control word and the Status word are detailed on pages 554 and 556 respectively. The drive states are presented in the state diagram (page 557).

When a transparent communication profile is selected eg. by parameter group 51 FBA A settings, the control word received from the PLC is available in 06.03 FBA A transparent control word. The individual bits of the word can then be used for drive control through bit pointer parameters. The source of the status word, for example 06.50 User status word 1, can be selected in 50.09 FBA A SW transparent source.

#### Debugging the network words

If parameter 50.12 FBA A debug mode is set to Fast, the Control word received from the fieldbus is shown by parameter 50.13 FBA A control word, and the Status word transmitted to the fieldbus network by 50.16 FBA A status word. This "raw" data is very useful to determine if the fieldbus master is transmitting the correct data before handing control to the fieldbus network.

#### References

References are 16-bit words containing a sign bit and a 15-bit integer. A negative reference (indicating reversed direction of rotation) is formed by calculating the two's complement from the corresponding positive reference.

ABB drives can receive control information from multiple sources including analog and digital inputs, the drive control panel and a fieldbus adapter module. In order to have the drive controlled through the fieldbus, the module must be defined as the source for control information such as reference. This is done using the source selection parameters in groups 22 Speed reference selection, 26 Torque reference chain and 28 Frequency reference chain.


#### Debugging the network words

If parameter 50.12 FBA A debug mode is set to Fast, the references received from the fieldbus are displayed by 50.14 FBA A reference 1 and 50.15 FBA A reference 2.

#### Scaling of references

Note: The scalings described below are for the ABB Drives communication profile. Fieldbus-specific communication profiles may use different scalings. For more information, see the manual of the fieldbus adapter.

The references are scaled as defined by parameters 46.01...46.07 which scaling is in use depends on the setting of 50.04 FBA A ref1 type and 50.05 FBA A ref2 type.



The scaled references are shown by parameters 03.05 FB A reference 1 and 03.06 FB A reference 2.

#### Actual values

Actual values are 16-bit words containing information on the operation of the drive. The types of the monitored signals are selected by parameters 50.07 FBA A actual 1 type and 50.08 FBA A actual 2 type.


#### Debugging the network words

If parameter 50.12 FBA A debug mode is set to Fast, the actual values sent to the fieldbus are displayed by 50.17 FBA A actual value 1 and 50.18 FBA A actual value 2.

#### Scaling of actual values

Note: The scalings described below are for the ABB Drives communication profile. Fieldbus-specific communication profiles may use different scalings. For more information, see the manual of the fieldbus adapter.

The actual values are scaled as defined by parameters 46.01...46.04; which scaling is in use depends on the setting of parameters 50.07 FBA A actual 1 type and 50.08 FBA A actual 2 type.



## Contents of fieldbus Control word (ABB Drives profile)

The upper case boldface text refers to the states shown in the state diagram (page 557).

Bit	Name	Value	STATE/Description
0	Off1 control	1	Proceed to READY TO OPERATE.
		0	Stop along currently active deceleration ramp. Proceed to <b>OFF1 ACTIVE</b> ; proceed to <b>READY TO SWITCH ON</b> unless other interlocks (OFF2, OFF3) are active.
1	Off2 control	1	Continue operation (OFF2 inactive).
		0	Emergency OFF, coast to a stop. Proceed to OFF2 ACTIVE, proceed to SWITCH-ON INHIBITED.
2	Off3 control	1	Continue operation (OFF3 inactive).
		0	Emergency stop, stop within time defined by drive parameter. Proceed to OFF3 ACTIVE; proceed to SWITCH-ON INHIBITED.  WARNING: Ensure motor and driven machine can be stopped using this stop mode.


Bit	Name	Value	STATE/Description
3	Run	1	Proceed to <b>OPERATION ENABLED</b> . <b>Note:</b> Run enable signal must be active; see drive documentation. If the drive is set to receive the Run enable signal from the fieldbus, this bit activates the signal.  See also parameters 06.18 Start inhibit status word and 06.25 Drive inhibit status word 2.
		0	Inhibit operation. Proceed to OPERATION INHIBITED.
4	Ramp out zero	1	Normal operation. Proceed to RAMP FUNCTION GENERATOR: OUTPUT ENABLED.
		0	Force Ramp function generator output to zero. The drive immediately decelerates to zero speed (observing the torque limits).
5	Ramp hold	1	Enable ramp function. Proceed to RAMP FUNCTION GENERATOR: ACCELERATOR ENABLED.
		0	Halt ramping (Ramp Function Generator output held).
6	Ramp in zero	1	Normal operation. Proceed to <b>OPERATING</b> . <b>Note:</b> This bit is effective only if the fieldbus interface is set as the source for this signal by drive parameters.
		0	Force Ramp function generator input to zero.
7	Reset	0=>1	Fault reset if an active fault exists. Proceed to SWITCH-ON INHIBITED.  Note: This bit is effective only if the fieldbus interface is set as the source of the reset signal by drive parameters.
		0	Continue normal operation.
8	Inching 1	1	Accelerate to inching (jogging) setpoint 1.  Notes: Bits 46 must be 0. See also section Jogging (page 78).
		0	Inching (jogging) 1 disabled.
9	Inching 2	1	Accelerate to inching (jogging) setpoint 2. See notes at bit 8.
		0	Inching (jogging) 2 disabled.
10	Remote cmd	1	Fieldbus control enabled.
		0	Control word and reference not getting through to the drive, except for bits 02.
11	Ext ctrl loc	1	Select External Control Location EXT2. Effective if control location is parameterized to be selected from fieldbus.
		0	Select External Control Location EXT1. Effective if control location is parameterized to be selected from fieldbus.
1215	Reserved.		

### Contents of the fieldbus Status word (ABB Drives profile)

The upper case boldface text refers to the states shown in the state diagram (page 557).

Bit	Name	Value	STATE/Description	
0	Ready to switch ON	1	READY TO SWITCH ON.	
		0	NOT READY TO SWITCH ON.	
1	1 Ready run		READY TO OPERATE.	
		0	OFF1 ACTIVE.	
2	Ready ref	1	OPERATION ENABLED.	
		0	<b>OPERATION INHIBITED</b> . See parameters 06.18 Start inhibit status word and 06.25 Drive inhibit status word 2 for the inhibiting condition.	
3	Tripped	1	FAULT.	
		0	No fault.	
4	Off 2 inactive	1	OFF2 inactive.	
		0	OFF2 ACTIVE.	
5	Off 3 inactive	1	OFF3 inactive.	
		0	OFF3 ACTIVE.	
6	Switch-on inhibited 1 SWITCH-ON I		SWITCH-ON INHIBITED.	
		0	_	
7	Warning	1	Warning active.	
		0	No warning active.	
8	At setpoint	1	<b>OPERATING</b> . Actual value equals reference = is within tolerance limits.	
		0	Actual value differs from reference = is outside tolerance limits.	
9	Remote	1	Drive control location: REMOTE (EXT1 or EXT2).	
		0	Drive control location: LOCAL.	
10	Above limit	-	See parameter 06.29 MSW bit 10 sel.	
11	User bit 0	-	See parameter 06.30 MSW bit 11 sel.	
12	User bit 1	-	See parameter 06.31 MSW bit 12 sel.	
13	User bit 2	-	See parameter 06.32 MSW bit 13 sel.	
14	User bit 3	-	See parameter 06.33 MSW bit 14 sel.	
15	Reserved			

## The state diagram (ABB Drives profile)



## Setting up the drive for fieldbus control

- 1. Install the fieldbus adapter module mechanically and electrically according to the instructions given in the User's manual of the module.
- 2. Power up the drive.
- 3. Enable the communication between the drive and the fieldbus adapter module by setting parameter 50.01 FBA A enable to Enable.
- 4. With 50.02 FBA A comm loss func, select how the drive should react to a fieldbus communication break.
  - Note: This function monitors both the communication between the fieldbus master and the adapter module and the communication between the adapter module and the drive.
- 5. With 50.03 FBA A comm loss t out, define the time between communication break detection and the selected action.
- 6. Select application specific values for the rest of the parameters in group 50 Fieldbus adapter (FBA), starting from 50.04. Examples of appropriate values are shown in the tables below.
- 7. Set the fieldbus adapter module configuration parameters in group 51 FBA A settings. At the minimum, set the required node address and the communication profile.
- 8. Define the process data transferred to and from the drive in parameter groups 52 FBA A data in and 53 FBA A data out.
  - Note: Depending on the communication protocol and profile being used, the Control word and Status word may already be configured to be sent/received by the communication system.
- 9. Save the valid parameter values to permanent memory by setting parameter 96.07 Parameter save manually to Save.
- 10. Validate the settings made in parameter groups 51, 52 and 53 by setting parameter 51.27 FBA A par refresh to Refresh.
- 11. Configure control locations EXT1 and EXT2 to allow control and reference signals to come from the fieldbus. Examples of appropriate values are shown in the tables below.

## Parameter setting example: FPBA (PROFIBUS DP)

This example shows how to configure a basic speed control application that uses the PROFIdrive communication profile with PPO Type 2. The start/stop commands and reference are according to the PROFIdrive profile, speed control mode.

The reference values sent over the fieldbus have to be scaled within the drive so they have the desired effect. The reference value ±16384 (4000h) corresponds to the range of speed set in parameter 46.01 Speed scaling (both forward and reverse directions). For example, if 46.01 is set to 480 rpm, then 4000h sent over fieldbus will request 480 rpm.

Direction	PZD1	PZD2	PZD3	PZD4	PZD5	PZD6
Out	Control word	Speed reference Acc time 1		Dec time 1		
In	Status word	Speed actual value	eed actual value Motor current		DC voltage	

The table below gives the recommended drive parameter settings.

Drive parameter Setting for ACS880 drives		Description		
50.01 FBA A enable	13 = [slot number]	Enables communication between the drive and the fieldbus adapter module.		
50.04 FBA A ref1 type	4 = Speed	Selects the fieldbus A reference 1 type and scaling.		
50.07 FBA A actual 1 type	<b>0</b> = <i>Auto</i>	Selects the actual value type/source and scaling according to the currently active control mode (as displayed by parameter 19.01).		
51.01 FBA A type	<b>1</b> = FPBA <sup>1)</sup>	Displays the type of the fieldbus adapter module.		
51.02 Node address	3 <sup>2)</sup>	Defines the PROFIBUS node address of the fieldbus adapter module.		
51.03 Baud rate	12000 <sup>1)</sup>	Displays the current baud rate on the PROFIBUS network in kbit/s.		
51.04 MSG type	<b>1</b> = PPO1 <sup>1)</sup>	Displays the telegram type selected by the PLC configuration tool.		
51.05 Profile	0 = PROFIdrive	Selects the Control word according to the PROFIdrive profile (speed control mode).		
51.07 RPBA mode	0 = Disabled	Disables the RPBA emulation mode.		
52.01 FBA data in1	<b>4</b> = SW 16bit <sup>1)</sup>	Status word		
52.02 FBA data in2	<b>5</b> = Act1 16bit	Actual value 1		
52.03 FBA data in3	01.07 <sup>2)</sup>	Motor current		
52.05 FBA data in5	01.11 <sup>2)</sup>	DC voltage		
53.01 FBA data out1	<b>1</b> = CW 16bit <sup>1)</sup>	Control word		
53.02 FBA data out2	2 = Ref1 16bit	Reference 1 (speed)		
53.03 FBA data out3	23.12 <sup>2)</sup>	Acceleration time 1		
53.05 FBA data out5	23.13 <sup>2)</sup>	Deceleration time 1		
51.27 FBA A par refresh	1 = Refresh	Validates the configuration parameter settings.		
19.12 Ext1 control mode 1	2 = Speed	Selects speed control as the control mode 1 for external control location EXT1.		

_	_	-
^	n	•

Drive parameter	Setting for ACS880 drives	Description
20.01 Ext1 commands	12 = Fieldbus A	Selects fieldbus adapter A as the source of the start and stop commands for external control location EXT1.
20.02 Ext1 start trigger type	1 = Level	Selects a level-triggered start signal for external control location EXT1.
22.11 Speed ref1 source	<b>4</b> = FB A ref1	Selects fieldbus A reference 1 as the source for speed reference 1.

<sup>1)</sup> Read-only or automatically detected/set

The start sequence for the parameter example above is given below.

#### Control word

- after power-on, fault or emergency stop:
  - 476h (1142 decimal) -> NOT READY TO SWITCH ON
- in normal operation:
  - 477h (1143 decimal) -> READY TO SWITCH ON (stopped)
  - 47Fh (1151 decimal) -> OPERATING (running)

#### Parameter setting example: Using PCP application through FPBA

This example shows how to configure a PCP application for Profibus communication using ABB Drives profile with PPO Type 8 telegram type. The start/stop commands are according to the Main control word (06.01 Main control word). Reference is according to application reference (74.05 Speed ref source).

**Example:** Assume that pump maximum speed is 80 Prpm and required speed is 60 Prpm. For ABB Drive profile fieldbus speed reference value 20000 corresponds to maximum motor speed. For gear reduction ratio value 10 (74.03 Gear reduction ratio) maximum pump speed 80 Prpm corresponds to fieldbus reference value 2000. Fieldbus reference for 60 Prpm can be calculated as: 60 \* 2000/80 = 1500.

Speed ref 1 in PZD 2 OUT should be equal to 1500.

If actual value 1 in PZD 2 IN equals 50, then pump speed is 50 Prpm.

The table below gives the recommended drive parameter settings.

Direction	PZD1	PZD2	PZD3	PZD4
Out	Main control word	Speed ref1		
In	Drive status word	Rod speed		Rod torque

Direction	PZD5	PZD6	PZD7	PZD8
Out				
In		Output frequency		Pump status word

<sup>2)</sup> Example

The table below gives the recommended drive parameter settings.

Drive parameter	Setting for ACS880 drive	Description
20.01 Ext1 commands	Fieldbus A	Selects the source of start command.
50.01 FBA A enable Option slot 3		Enables communication between the drive and the fieldbus adapter module. Fieldbus adapter module must be attached to slot 3.
51.02 Node address	3 <sup>2)</sup>	Defines the PROFIBUS node address of the fieldbus adapter module.
51.03 Baud rate	12000 <sup>1)</sup>	Displays the current baud rate on the PROFIBUS network in kbit/s.
51.05 Profile	ABB Drives <sup>2)</sup>	Selects the Control word according to the ABB Drives profile.
51.27 FBA A par refresh	Refresh	Validates the configuration parameter settings.
52.01 FBA data in1	SW 16bit <sup>2)</sup>	Status word of the drive is sent to the master (PLC).
52.02 FBA data in2	9.6 Rod speed <sup>2)</sup>	Rod speed
53.04 FBA data in4	9.1 Rod torque <sup>2)</sup>	Rod torque
52.06 FBA data in6	1.6 Output frequency <sup>2)</sup>	Output frequency of the drive
52.08 FBA data in8	9.14 Pump status word <sup>2)</sup>	Pump status word (16 bit)
53.01 FBA data out1	CW 16bit <sup>2)</sup>	Command word from master to the drive.
53.02 FBA data out2	Ref1 16bit <sup>2)</sup>	Speed reference from master to the drive.
74.01 Pump enable	Enable	Enables the pump related application features.
74.03 Gear reduction ratio	10 <sup>2)</sup>	Transmission reduction ratio.
74.05 Speed ref source	FBA1 ref	Set FBA Ref1 as a source for application speed reference.
74.07 Minimum speed	-10 <sup>2)</sup>	Minimum allowed rod speed.
74.08 Maximum speed	80 <sup>2)</sup>	Maximum allowed rod speed.
74.19 Maximum torque	12 <sup>2)</sup>	Maximum allowed torque.
74.10 Acc time	20 <sup>2)</sup>	Time period that is required to accelerate from zero to 46.01 Speed scaling.
74.11 Dec time	20 <sup>2)</sup>	Time period that is required to decelerate from 46.01 Speed scaling to zero speed.

<sup>&</sup>lt;sup>1)</sup> Read-only or automatically detected/set <sup>2)</sup> Example

The start sequence for the parameter example above is given below. Application command word (06.02 Application control word):

- 47Eh (1150 decimal) -> READY TO SWITCH ON
- 47Fh (1151 decimal) -> OPERATING (Speed mode)
- 477h (1143 decimal) -> STOP (Coast)



# **Control chain diagrams**


## Contents of this chapter

The chapter presents the reference chains of the drive. The control chain diagrams can be used to trace how parameters interact and where parameters have an effect within the drive parameter system.


For a more general diagram, see section Operating modes of the drive (page 56).

564

# Speed reference source selection I for PCP application




# Speed reference source selection I




#### 566


# Speed reference source selection II for PCP application




## Speed reference source selection II




# Speed reference ramping and shaping




# Motor feedback configuration




# Load feedback and position counter configuration




# Speed error calculation




# Speed controller



## Frequency reference selection



# Frequency reference modification



# **Further information**

## **Product and service inquiries**

Address any inquiries about the product to your local ABB representative, quoting the type designation and serial number of the unit in question. A listing of ABB sales, support and service contacts can be found by navigating to abb.com/searchchannels.

## **Product training**

For information on ABB product training, navigate to new.abb.com/service/training.

## **Providing feedback on ABB Drives manuals**

Your comments on our manuals are welcome. Navigate to new.abb.com/drives/manuals-feedback-form.

#### Document library on the Internet

You can find manuals and other product documents in PDF format on the Internet at abb.com/drives/documents.



abb.com/drives