

Options for ABB drives

## User's manual

# Emergency stop, stop category 0 (option +Q951) for ACS880-07CLC drives



Power and productivity  
for a better world™





# User's manual

Emergency stop, stop category 0 (option +Q951) for  
ACS880-07CLC drives

Table of contents



1. Safety instructions





# Table of contents

---

## **1 Safety instructions**

Contents of this chapter .....	7
--------------------------------	---

## **2 Introduction to the manual**

Contents of this chapter .....	9
Applicability .....	9
Target Audience .....	9
Exclusion of liability .....	9
Quick reference guide for implementing a safety system .....	10
Terms and abbreviations .....	10
Related documents .....	11

## **3 Option description and instructions**

Contents of this chapter .....	13
Overview .....	13
Operation principle .....	14
Fault reaction function .....	15
Parameter settings .....	15
Hardware settings .....	15
Wiring .....	16
Start-up and acceptance test .....	17
Use of the safety function .....	18
Activating .....	18
Resetting .....	18
Emergency stop indications .....	18
Fault tracing .....	18
Maintenance .....	19
Proof test interval .....	19
Competence .....	20
Residual risk .....	20
Intentional misuse .....	20
Decommissioning .....	20
Safety data .....	21
Safety data values .....	21
Safety component types .....	21
Safety block diagram .....	22
Relevant failure modes .....	22
Fault exclusions .....	22
Operation delays .....	22
General rules, notes and definitions .....	23
Validation of the safety functions .....	23
Validation procedure .....	23
Acceptance test reports .....	23
Competence .....	23
Ambient conditions .....	23
Reporting problems and failures related to safety functions .....	23

---



6 *Table of contents*

Related standards and directives ..... 24

Compliance with the European Machinery Directive ..... 24



# 1

## Safety instructions

---

### Contents of this chapter

Only a qualified electrician who has appropriate knowledge on functional/machine/process safety is allowed to install, start up and maintain the safety circuit.

---



#### **WARNING!**

After you have made additions to the drive safety circuit or modified it, changed circuit boards inside the drive, always test the operation of the safety circuit according to its acceptance test procedure. The change can affect unexpectedly. All customer-made changes are on the customer's responsibility.

---



#### **WARNING!**

Read and obey all safety instructions given for the drive in its hardware manual. If you ignore them, injury or death, or damage to the equipment can occur.

---

This manual does not repeat the complete safety instructions of the drive but it only includes the instructions related to the scope of this manual.

---







# 2

## Introduction to the manual

---

### Contents of this chapter

This chapter describes the manual in short and gives some general information for the reader. This chapter also contains a quick reference for implementing a safety system.

### Applicability

The manual applies to the ACS880-07CLC drives which have the option: Emergency stop, stop category 0, with safety relays (option +Q951).

### Target Audience

The manual is intended for people who install, start up, use and service the safety option of the drive. Read the manual before working on the drive. You are expected to know the fundamentals of electricity, wiring, electrical components, electrical schematic symbols, and functional safety.

### Exclusion of liability

ABB is not responsible for the implementation, verification and validation of the overall safety system. It is the responsibility of the system integrator (or other party) who is responsible for the overall system and system safety.

The system integrator (or other responsible party) must make sure that the entire implementation complies with all relevant standards, directives and local electrical code, and that the system is tested, verified and validated correctly.

---

## Quick reference guide for implementing a safety system

Task	<input checked="" type="checkbox"/>
Select the appropriate functional safety standard for the implementation: EN ISO 13849-1, EN/IEC 62061, IEC 61511 or other.	<input type="checkbox"/>
If you select EN/IEC 62061 or IEC 61511, make a safety plan. See EN/IEC 62061 or IEC 61511.	<input type="checkbox"/>
Assess safety: analyze and evaluate risks (estimate SIL/PL) and define risk reduction strategies. Define the safety requirements.	<input type="checkbox"/>
Design the safety system. The part of the design made by ABB is described in section Option description and instructions.	<input type="checkbox"/>
If you made any changes to the delivered safety system, verify the achieved SIL/PL with, for example, FSDT-01 Functional safety design tool or similar. See <i>Functional safety design tool user's manual</i> (3AXD10000102417 [English]).	<input type="checkbox"/>
Connect the wiring. See section Wiring.	<input type="checkbox"/>
Set the parameters. See section Parameter settings.	<input type="checkbox"/>
Validate that the implemented system meets the safety requirements: Do the acceptance test. See section Start-up and acceptance test.	<input type="checkbox"/>
Write the necessary documentation.	<input type="checkbox"/>

## Terms and abbreviations

Term/Abbr.	Description
Cat.	Classification of the safety-related parts of a control system in respect of their resistance to faults and their subsequent behavior in the fault condition, and which is achieved by the structural arrangement of the parts, fault detection and/or by their reliability. The categories are: B, 1, 2, 3 and 4. (EN ISO 13849-1)
CCF	Common cause failure (%) (EN ISO 13849-1)
DC	Diagnostic coverage (EN ISO 13849-1)
EMC	Electromagnetic compatibility
HFT	Hardware fault tolerance (IEC 61508)
PFD <sub>avg</sub>	Average probability of dangerous failure on demand (IEC 61508)
PFH	Average frequency of dangerous failures per hour (IEC 61508)
PL	Performance level. Levels a...e correspond to SIL (EN ISO 13849-1)
SC	Systematic capability (IEC 61508)
SIL	Safety integrity level (1...3) (IEC 61508)
SILCL	Maximum SIL (level 1...3) that can be claimed for a safety function or subsystem (IEC/EN 62061)
STO	Safe torque off (IEC/EN 61800-5-2)
T1	Proof test interval. Defines the probabilistic failure rate (PFH or PFD) for the safety function or subsystem. Performing a proof test at a maximum interval of T1 is required to keep the SIL capability valid. The same interval must be followed to keep the PL capability (EN ISO 13849) valid. Note that any T1 values given cannot be regarded as a guarantee or warranty.

## Related documents

Manual	Code
<b>Drive hardware manuals and guides</b>	
ACS880-07CLC drives hardware manual	3AXD50000131457
ACX-AP-x assistant control panels user's manual	3AUA0000085685
<b>Drive firmware manuals and guides</b>	
ACS880 primary control program firmware manual	3AUA0000085967
ACS880 primary control program quick start-up guide	3AUA0000098062
ACS880 diode supply control program firmware manual	3AUA0000103295
ACS880 distributed I/O bus supplement	3AXD50000126880
<b>General safety guides</b>	
Functional safety design tool user's manual	3AXD10000102417
Functional safety; Technical guide No. 10 Safety and functional safety; A general guide	3AUA0000048753
<b>Option manuals and guides</b>	
Drive composer start-up and maintenance PC tool user's manual	3AUA0000094606
Emergency stop, stop category 0 (option +Q951) for ACS880-07CLC drives user's manual	3AXD50000123384
Manuals and quick guides for I/O extension modules, fieldbus adapters, etc.	
<b>Other documents</b>	
Circuit diagrams delivered with the drive	
Part lists delivered with the drive	

You can find manuals and other product documents in PDF format on the Internet. See [Document Library](#). For manuals not available in the Document library, contact your local ABB representative.

For additional ABB safety information and solutions visit <http://www.abb.com/safety>.



# 3

## Option description and instructions

---

### Contents of this chapter

This chapter describes the safety function and instructs how to wire, start up, test, validate, use and maintain it. The safety data is also given.

### Overview

This emergency stop function corresponds to an uncontrolled stop in accordance with stop category 0 (EN/IEC 60204-1). After the emergency stop command has been given, the drive trips the main contactors which cut off the input power of the drive. The motor coasts to a stop.

The design principles of the safety function comply with EN ISO 13850.

For a list of related standards and European directives, see section [Related standards and directives \(page 24\)](#).



Step	Operation
1.	The user activates emergency stop, for example, by pushing the emergency stop button [S61].
2.	<p>The emergency stop safety relay [A640] switches off the XSTO inputs IN1 and IN2 of the inverter control unit [A41]. The XSTO.OUT terminal delivers the signal to the inverter modules and opens the STO circuit of the inverter modules.</p> <p>The emergency stop safety relay [A640] de-energizes the main contactors [Q2.1/Q2.2] and the charging contactor [Q4] and activates the DIIL input on the supply control unit [X51]</p> <p>The main contactors [Q2.1/Q2.2] switch off the power supply to the inverter modules [T11.1/T11.2].</p>
3.	The emergency stop indication lamp [P62] switches on.
4.	The motor coasts to zero speed and remains at zero speed while the emergency stop is active.
5.	<p>Normal operation resumes after the user:</p> <ul style="list-style-type: none"> <li>• releases the emergency stop button [S61] to normal (up) position</li> <li>• resets the emergency stop circuit (customer-defined)</li> <li>• resets the inverter unit (if the STO indication parameter 31.22 has been set so that a fault is generated).</li> </ul> <p>If the drive is used in remote control mode, see the firmware manual for more information.</p>

## Fault reaction function

**Definition:** A safety function requires a “fault reaction function” that attempts to initiate a safe state if the safety function's diagnostics detect a fault within the hardware/software that performs the safety function.

The fault reaction function of the emergency stop safety relay trips if it detects a failure (short circuit between signals, open circuits, redundancy fault when the emergency stop button is pushed) in the safety circuit. The fault reaction function shifts the drive immediately into the safe state by switching on the drive emergency stop command, opening the main contactor, and keeping them on until the detected fault has been repaired. The indication lamp of the reset button is on until the fault has been repaired.

The emergency stop reset circuit must be open when the user releases the emergency stop button. The emergency stop safety relay detects if the reset circuit is closed and the relay does not close.

## Parameter settings

The parameter setting in the inverter control program:

- parameter 31.22 *STO indication run/stop* is set to value *Warning/Warning* (recommended).

The parameter settings in the supply control program:

- parameter 121.04 *Emergency stop mode* is set to value *Stop and warning*
- parameter 121.05 *Emergency stop source* is set to value *DIIL*.

For more information, see the firmware manuals.

## Hardware settings

Appropriate hardware settings have been preset at the factory for the safety function.

The emergency stop safety relay [A640] is wired to the manual reset mode at the factory.

## Wiring

The customer must wire an emergency stop button to the safety system. One emergency stop button is installed on the cabinet door.

There are double contacts in the emergency stop button and double wiring (two-channel connection) between the button and the emergency stop safety relay. The safety relay detects cross faults and faults across one contact from the emergency stop button. This function must be used in a redundant manner, that is, the emergency stop button must be connected to both terminals with a separate contact.

If needed, install additional emergency stop buttons on site and wire them to the appropriate terminal block inside the drive cabinet. See the circuit diagrams delivered with the drive.

Obey these rules:

1. Use only double-contact buttons approved for the emergency stop circuits.
2. Connect the emergency stop buttons with two conductors (two-channel connection).

**Note:**

Keep the channels separate. If you use only one channel, or if the first and second channels are connected together (for example, in a chain), the cross fault detection of the emergency stop safety relay trips and activates the emergency stop command of the drive as it detects a redundancy fault.

3. Use a shielded, twisted pair cable. We recommend a double-shielded cable and gold-plated contacts in the emergency stop button.
4. Ensure that the sum resistance for one channel (loop resistance) from the field to the safety relay does not exceed 70 ohm.
5. Obey the general control cable installation instructions given in the drive hardware manual.

You must install and wire a reset button (or similar) to terminal block [X22.2] on the drive. See the circuit diagrams delivered with the drive. We recommend gold-plated contacts in the reset button. Obey these rules:

1. Sum resistance of the external reset circuit must not exceed 70 ohm.
2. Obey the general control cable installation instructions given in the drive hardware manual.

**Note:**


The safety system and customer-made wirings are on the customer's responsibility.



## Start-up and acceptance test

You need the Drive composer PC tool or a control panel to perform the start-up and acceptance test.

Initial status: Make sure that the drive is ready for use, that is, you have done the tasks of the drive start-up procedure. See the hardware manual.

Action	<input checked="" type="checkbox"/>
 <b>WARNING!</b> Obey the safety instructions. If you ignore them, injury or death, or damage to the equipment can occur.	<input type="checkbox"/>
<b>Checks and settings with no voltage connected</b>	
Check the connections against the appropriate circuit diagrams: the emergency stop button, reset circuit, STO circuits, and connections to the contactors.	<input type="checkbox"/>
Check that the hardware settings relevant to the safety function are set as defined in section Hardware settings.	<input type="checkbox"/>
<b>Settings with voltage connected</b>	
Check that the parameters relevant to the safety function are set as defined in section Parameter settings.	<input type="checkbox"/>
<b>Acceptance test</b>	
Make sure that you can run and stop the motor freely during the test.	<input type="checkbox"/>
Start the drive and make sure that the motor is running. If possible, use a motor speed close to the maximum speed of the application.	<input type="checkbox"/>
Push the emergency stop button.	<input type="checkbox"/>
Make sure that the drive stops the motor by coasting and displays the correct warnings. See section Emergency stop indications.	<input type="checkbox"/>
Make sure that the indication lamp switches on.	<input type="checkbox"/>
Make sure that you cannot switch the power on with the operating switch.	<input type="checkbox"/>
Make sure that you cannot start the drive and motor from any control location: Make sure that the motor does not start even if you switch the start signal off and on or push the start key of the panel.	<input type="checkbox"/>
Turn the emergency stop button until it releases and returns to the up position.	<input type="checkbox"/>
Reset the emergency stop circuit.	<input type="checkbox"/>
Make sure that the indication lamp switches off.	<input type="checkbox"/>
Switch off the drive start signal.	<input type="checkbox"/>
Power up the drive (see the hardware and firmware manuals).	<input type="checkbox"/>
Restart the drive and motor and check that they operate normally.	<input type="checkbox"/>
Repeat the test from each operating location (every emergency stop button and reset button).	<input type="checkbox"/>
Fill in and sign the acceptance test report which verifies that the safety function is safe and accepted to operation.	<input type="checkbox"/>

## Use of the safety function

### ■ Activating

1. Push the emergency stop button. The emergency stop activates and the button locks in “ON” (open) position.

### ■ Resetting

1. Turn the emergency stop button until it releases.
2. Reset the emergency stop circuit (customer-defined).  
The indication lamp switches off. The emergency stop function deactivates.
3. Reset the drive if necessary.
4. Close the main contactors with the operating switch if necessary (see the hardware and firmware manuals).  
The main contactors close and the drive is powered up.
5. Make sure that the drive has received the start signal (depends on the configuration, see the firmware manual).
6. You can now restart the drive.

#### **Note:**

You have to reset the emergency stop circuit also after you have powered up the drive.

## Emergency stop indications

When the emergency stop is on:

- the inverter control program has the *Safe torque off* warning active,
- the supply control program has the *Emergency stop* warning active,
- the emergency stop indication lamp on the cabinet door is illuminated.

## Fault tracing

The emergency stop safety relay type is Phoenix Contact PSR-MC34. For more information, see the data sheet of the relay ([www.phoenixcontact.com](http://www.phoenixcontact.com)).

This table describes the status LEDs of the safety relay.

PWR LED	IN1/2 LED	K1 LED	K2 LED	LED is lit and steady
ON	OFF	OFF	OFF	All relays are not activated. The sensor circuit is off. Possible error. For more information, see the data sheet of the relay.
ON	ON	OFF	OFF	Relay K1 is energized.
ON	ON	ON	ON	Relay K2 is energized.

## Maintenance

After the operation of the safety function is tested at start-up, it does not need any scheduled maintenance, excluding the main contactor which has a limited lifetime. Replace the contactor before the end of its lifetime. See the contactor data sheet or manual. Repeat the acceptance test for the function after the replacement. See section Start-up and acceptance test.

In addition to proof testing, it is a good practice to check the operation of the function when other maintenance routines of the machinery are carried out. Do acceptance test described in section Start-up and acceptance test.

If you change any wiring or component after the start-up, or restore parameters to their default values:

- Use only ABB approved spare parts.
- Register the change to the change log for the safety circuit.
- Test the safety function again after the change. Obey the rules given in section Start-up and acceptance test.
- Document the tests and store the report into the logbook of the machine.

### ■ Proof test interval

After the operation of the safety function is validated at start-up, the safety function must be maintained by periodic proof testing. In high demand mode of operation, the maximum proof test interval is 20 years. In low demand mode of operation, the maximum proof test interval is 1 year (high or low demand as defined in IEC 61508, EN/IEC 62061 and EN ISO 13849-1). Regardless of the mode of operation, it is a good practice to check the operation of the safety function at least once a year. Do the test as described in section Start-up and acceptance test.

The person responsible for the design of the complete safety function should also note the Recommendation of Use CNB/M/11.050 published by the European co-ordination of Notified Bodies for Machinery concerning dual-channel safety-related systems with electromechanical outputs:

- When the safety integrity requirement for the safety function is SIL 3 or PL e (cat. 3 or 4), the proof test for the function must be performed at least every month.
- When the safety integrity requirement for the safety function is SIL 2 (HFT = 1) or PL d (cat. 3), the proof test for the function must be performed at least every 12 months.

This is a recommendation and depends on the required (not achieved) SIL/PL. For example, safety relays, contactor relays, emergency stop buttons, switches etc. are typically safety devices which contain electromechanical outputs.

---

### ■ **Competence**

The maintenance and proof test activities of the safety function must be carried out by a competent person with expertise and knowledge of the safety function as well as functional safety, as required by IEC 61508-1 clause 6.

### ■ **Residual risk**

The safety functions are used to reduce the recognized hazardous conditions. In spite of this, it is not always possible to eliminate all potential hazards. Therefore the warnings for the residual risks must be given to the operators.

### ■ **Intentional misuse**

The safety circuit is not designed to protect a machine against intentional misuse.

### ■ **Decommissioning**

When you decommission an emergency stop circuit or a drive, make sure that the safety of the machine is maintained until the decommissioning is complete.

## Safety data

The safety data given below is valid for the default design of the safety circuit. In case the final design differs from the default, ABB calculates new safety data and delivers it separately to the customer.

### ■ Safety data values

The safety data calculations are based on the following assumptions on the operation of the main contactors [Q2.1/Q2.2]:

- It is switched at low load current (normal use, ~0%, AC-1).
- It is used for the emergency stop once a month.
- It is used for the ordinary on and off once a day.

ACS880-07CLC type	Contactors	SIL / SILCL	PL	PFH <sup>1)</sup> [1/h]	PFD <sub>avg</sub>	DC <sup>2)</sup> [%]	SC	Cat.	HFT	CCF	Life time [a]	T1 <sup>3)4)</sup> [a]
-1470A-7	AF1250 and AF16	2	d	9.6E-7	4.6E-03	>90	3	2	0	65	20	20 / 1

3AXD10000097591 Rev E

<sup>1)</sup> PFH values according to EN ISO 13849.  
<sup>2)</sup> DC for low demand mode is 0% (determined by the DC of the worst component in the subsystem).  
<sup>3)</sup> See also the Recommendation of Use CNB/M/11.050 published by the European coordination of Notified Bodies for lower T1 requirement.  
<sup>4)</sup> T1 = 20 a stands for high demand use. T1 = 1 a is used with low demand mode of operation.

**Note:**

If T<sub>1</sub> > 1 a is needed in low demand mode of operation, SIL 1 / PL c levels shall be used and PFD calculated separately.


### ■ Safety component types

Safety component types as defined in IEC 61508-2:

- emergency stop button: type A
- emergency stop safety relay: type A
- auxiliary safety relay: type A
- main contactors: type A
- charging contactor: type A

## ■ Safety block diagram

The components that are included in the safety circuit are shown in this safety block diagram.



## ■ Relevant failure modes

- The main contactor does not open when requested. (All contactor failures are considered dangerous.)
- Internal failures of safety relays and the emergency stop button. These failures are included in the PFH value of the function.

## ■ Fault exclusions

Fault exclusions (not considered in the calculations):

- any short and open circuits in the cables of the safety circuit
- any short and open circuits in the cabinet terminal blocks of the safety circuits.

## ■ Operation delays

Emergency stop total delay: less than 250 ms.

## General rules, notes and definitions

### ■ Validation of the safety functions

You must do an acceptance test (validation) to validate the correct operation of safety functions.

#### **Validation procedure**

You must do the acceptance test using the checklist given in section Start-up and acceptance test.

- at initial start-up of the safety function
- after any changes related to the safety function (wiring, components, safety function related parameter settings etc.)
- after any maintenance action related to the safety function.

The acceptance test must include at least the following steps:

- you must have an acceptance test plan
- you must test all commissioned functions for proper operation, from each operation location
- you must document all acceptance tests.

#### **Acceptance test reports**

You must store the signed acceptance test reports in the logbook of the machine. The report must include, as required by the referred standards:

- a description of the safety application (including a figure)
- a description and revisions of safety components that are used in the safety application
- a list of all safety functions that are used in the safety application
- a list of all safety related parameters and their values
- documentation of start-up activities, references to failure reports and resolution of failures
- the test results for each safety function, checksums, date of the tests and confirmation by the test personnel.

You must store any new acceptance test reports performed due to changes or maintenance in the logbook of the machine.

#### **Competence**

The acceptance test of the safety function must be carried out by a competent person with expertise and knowledge of the safety function as well as functional safety, as required by IEC 61508-1 clause 6. The test procedures and report must be documented and signed by this person.

### ■ Ambient conditions

For the environmental limits for the safety functions and the drive, refer to the hardware manual of your drive.

### ■ Reporting problems and failures related to safety functions

Contact your local ABB representative.

---

## Related standards and directives

Standard	Name
EN 60204-1:2006 + AC:2010 IEC 60204-1:2016	Safety of machinery – Electrical equipment of machines – Part 1: General requirements
IEC 61508 Parts 1-3, Ed. 2.0:2010	Functional safety of electrical/electronic/programmable electronic safety-related systems
IEC 61800-5-2:2016 EN 61800-5-2:2007	Adjustable speed electrical power drive systems – Part 5-2: Safety requirements – Functional
IEC 62061:2015 Ed. 1.2 EN 62061:2005 +AC:2010+A1:2013+A2:2015	Safety of machinery – Functional safety of safety-related electrical, electronic and programmable electronic control systems
EN ISO 12100:2010	Safety of machinery – General principles for design – Risk assessment and risk reduction
EN ISO 13849-1:2015	Safety of machinery – Safety-related parts of control systems – Part 1: General principles for design
EN ISO 13849-2:2012	Safety of machinery – Safety-related parts of control systems – Part 2: Validation
EN 61800-3:2004 + A1:2012	Adjustable Speed Electrical Power Drive Systems - Part 3: EMC requirements and specific test methods
IEC 61326-3-1:2008	Electrical equipment for measurement, control and laboratory use - EMC requirements - Part 3-1: Immunity requirements for safety-related systems and for equipment intended to perform safety-related functions (functional safety) – General industrial applications
IEC 60533:2015	Electrical and electronic installations in ships – Electromagnetic compatibility (EMC) – Ships with a metallic hull
IEC 61511-1:2016	Functional safety – Safety instrumented systems for the process industry sector – Part 1: Framework, definitions, system, hardware and application programming requirements
EN ISO 13850:2015	Safety of machinery – Emergency stop – Principles for design
2006/42/EC	European Machinery Directive
Other	Sector-specific C-type standards

## Compliance with the European Machinery Directive

The drive is an electronic product which is covered by the European Low Voltage Directive. However, the drive internal safety function of this manual is in the scope of the Machinery Directive as a safety component. This function complies with European harmonized standards such as EN/IEC 61800-5-2. The declaration of conformity is delivered with the drive.







## Further information

### Product and service inquiries

Address any inquiries about the product to your local ABB representative, quoting the type designation and serial number of the unit in question. A listing of ABB sales, support and service contacts can be found by navigating to [www.abb.com/searchchannels](http://www.abb.com/searchchannels).

### Product training

For information on ABB product training, navigate to [new.abb.com/service/training](http://new.abb.com/service/training).

### Providing feedback on ABB manuals

Your comments on our manuals are welcome. Navigate to [new.abb.com/drives/manuals-feedback-form](http://new.abb.com/drives/manuals-feedback-form).

### Document library on the Internet

You can find manuals and other product documents in PDF format on the Internet at [www.abb.com/drives/documents](http://www.abb.com/drives/documents).

# Contact us

[www.abb.com/drives](http://www.abb.com/drives)

3AXD50000123384 A (EN) EFFECTIVE 2017-09-12



3AXD50000123384A