

FSM4000

Electromagnetic flowmeter



Valid for software versions C.10 and higher

Measurement made easy

—
FSM4000-SE41F
FSM4000-SE21
FSM4000-SE21F
FSM4000-S4

Introduction

The FSM4000 is a robust flowmeter for high process requirements. It masters critical applications and conserves valuable resources with highly accurate measurement of process parameters in a wide range of sectors.

The design of the flowmeter allows for a wide range of sector-specific liner materials, electrodes and nominal diameters in accordance with respective needs. The high-performance transmitter is easy to use and offers a highly stable signal output. Maximum measuring accuracy in applications with high cellulose or high solids content, pulsating flows and other applications with disruptions.

Additional Information

Additional documentation on FSM4000 is available for download free of charge at www.abb.com/flow. Alternatively simply scan this code:



Table of contents

1 Safety.....4	
General information and instructions.....4	
Warnings.....4	
Intended use.....5	
Improper use.....5	
Warranty provisions.....5	
Cyber security disclaimer.....6	
Software downloads.....6	
Manufacturer's address.....6	
Customer service center.....6	
2 Design and function.....7	
Overview.....7	
Measuring principle.....9	
Design.....9	
Device designs.....9	
3 Product identification.....10	
Position of the name plate / factory plate.....10	
Identification of the device design.....10	
Name plate.....10	
Sensor.....10	
Transmitter.....10	
Factory tag.....11	
4 Transport and storage.....12	
Inspection.....12	
Transport.....12	
Flange devices ≤ DN 450.....12	
Flange devices > DN 450.....12	
Storing the device.....13	
Temperature data.....13	
Storage temperature.....13	
Returning devices.....13	
5 Installation.....14	
Safety instructions.....14	
Installation conditions.....14	
General.....14	
Brackets.....15	
Gaskets.....15	
Flow direction.....15	
Electrode axis.....15	
Mounting position.....16	
Grounding.....16	
Sensor insulation.....16	
Inlet and outlet sections.....17	
Free inlet or outlet.....17	
Mounting with heavily contaminated measuring media.....17	
Mounting with pipe vibration.....18	
Installation in piping with larger nominal diameter.....18	
Installation in 3A compliant installations.....19	
Installing the sensor.....19	
Torque information.....21	
Flange and wafer type devices, model SE41F / SE21F / SE21W.....21	
Variable process connections model SE21.....24	
Nominal diameter, nominal pressure, measuring range.....25	
Grounding.....26	
General information on grounding.....26	
Metal pipe with fixed flanges.....26	
Metal pipe with loose flanges.....27	
Non-metallic pipes or pipes with insulating liner.....27	
Stainless steel sensor model SE21.....28	
Ground for devices with protection plates.....28	
Grounding with conductive PTFE grounding plate.....28	
6 Electrical connections.....28	
Safety instructions.....28	
Preparing and routing the signal and magnetic coil cable.....29	
Preparing for sensor model SE21, SE21F.....29	
Preparing for sensor model SE41F.....30	
Routing the signal and magnetic coil cable.....31	
Connecting the sensor.....32	
Connecting the signal and magnet coil cables.....32	
Connection with IP rating IP 68.....33	
Connecting the transmitter.....34	
Connecting the power supply.....34	
Connecting the signal and magnet coil cables.....35	
Terminal assignment.....36	
Standard DN 3 to DN 1000 ($\frac{1}{16}$ to 40").....36	
With preamplifier DN 3 to DN 1000 ($\frac{1}{16}$ to 40").....37	
DN 3 to DN 1000 ($\frac{1}{16}$ to 40") with PROFIBUS PA / FOUNDATION Fieldbus.....38	
Retrofit for model 10D1422: DN 3 to DN 1000 ($\frac{1}{16}$ to 40"); model 10DI1425 and 10DS3111A-E: DN 500 to DN 1000 (20 to 40").....40	
Digital communication.....41	
HART® protocol.....41	
PROFIBUS PA protocol.....41	
FOUNDATION Fieldbus® (FF).....42	
Connection examples for peripherals (incl. HART).....43	
Current output.....43	
Switch output.....43	
Switch input.....44	
Pulse output.....44	
PROFIBUS PA® / FOUNDATION Fieldbus®.....45	
Bus termination for S4 transmitter.....45	
Connection via M12 plug (for PROFIBUS PA only).....45	

7 Commissioning	46	13 Specification	125
Safety instructions.....	46	Measuring accuracy.....	125
Checks before commissioning	46	Reference conditions in accordance with EN 29104 ..	125
Commissioning.....	47	Maximum measuring error.....	125
Power Supply Power-Up.....	47	Analog output effects	125
Device configuration	48	Sensor SE41F	125
Easy Set-up, for uncomplicated parameterization.....	49	Temperature graph	125
Commissioning of PROFIBUS PA® devices.....	50	Max. permissible cleaning temperature	
Information on voltage/current consumption	51	PTFE-, PFA-design.....	125
System integration	51	Min. permissible pressure as a function of measuring	
Commissioning of FOUNDATION FIELDBUS® devices....	52	medium temperature.....	126
Information on voltage/current consumption	52	Sensor material	126
8 Operation	53	Process connection material	126
Safety instructions.....	53	Storage temperature	127
Display options.....	53	IP rating in accordance with EN 60529	127
Data entry.....	54	Pipe vibration according to EN 60068-2-6.....	127
Initiating the ENTER function when using the magnet		Designs	127
stick for operation	55	Material loads for process connections	127
Entering data in short form.....	56	Sensor SE21 / SE21F	129
Parameter descriptions	57	Minimum permissible absolute pressure	129
Additional information regarding use of enhanced		Maximum permissible cleaning temperature.....	129
diagnostic functions.....	97	Maximum Allowable Temperature Shock.....	129
Recommended settings for diagnosis limit values ..	101	Maximum permissible ambient temperature as a	
Displaying the diagnostic values.....	103	function of measuring medium temperature.....	129
Readjusting the coil temperature	106	Sensor material	129
Software history.....	107	Process connection material	129
For transmitters without communication or HART		Gasket material (internal)	129
protocol.....	107	Storage temperature	130
For transmitter with PROFIBUS PA communication.....	108	IP rating in accordance with EN 60529	130
For transmitter with FOUNDATION Fieldbus		Pipe vibration according to EN 60068-2-6.....	130
communication.....	108	Material loads for process connections	130
S4 operation with older sensor	109	Transmitter.....	132
9 Diagnosis / error messages	112	14 Additional documents	133
Overview of error states and alarms	112	15 Appendix	134
Error messages during operation and with data entry.....	113	Overview of setting parameters and technical design.....	134
Warning messages during operation	115	Return form.....	135
10 Maintenance / Repair.....	117		
Safety instructions.....	117		
Sensor	117		
Gaskets	117		
Replacing the transmitter	118		
Returning devices.....	119		
11 Recycling and disposal.....	120		
Dismounting	120		
Disposal	120		
12 Spare parts list	121		
Fuses for transmitter electronics	121		
Spare parts for transmitter S4	122		
Field mount housing.....	122		
Spare parts for sensor	123		
Terminal box stainless steel DN 3 to DN 100	123		
Terminal box, aluminum DN 3 to DN 1000.....	124		

1 Safety

General information and instructions

These instructions are an important part of the product and must be retained for future reference.

Installation, commissioning, and maintenance of the product may only be performed by trained specialist personnel who have been authorized by the plant operator accordingly. The specialist personnel must have read and understood the manual and must comply with its instructions.

For additional information or if specific problems occur that are not discussed in these instructions, contact the manufacturer.

The content of these instructions is neither part of nor an amendment to any previous or existing agreement, promise or legal relationship.

Modifications and repairs to the product may only be performed if expressly permitted by these instructions.

Information and symbols on the product must be observed. These may not be removed and must be fully legible at all times. The operating company must strictly observe the applicable national regulations relating to the installation, function testing, repair and maintenance of electrical products.

Warnings

The warnings in these instructions are structured as follows:

 **DANGER**

The signal word '**DANGER**' indicates an imminent danger. Failure to observe this information will result in death or severe injury.

 **WARNING**

The signal word '**WARNING**' indicates an imminent danger. Failure to observe this information may result in death or severe injury.

 **CAUTION**

The signal word '**CAUTION**' indicates an imminent danger. Failure to observe this information may result in minor or moderate injury.

NOTICE

The signal word '**NOTICE**' indicates possible material damage.

Note

'**Note**' indicates useful or important information about the product.

Intended use

This device is intended for the following uses:

- For the transmission of fluid, pulpy or pasty measuring media with electrical conductivity.
- For volume flow measurement (in operating conditions).
- For mass flow measurement (based on a non-adjustable density value).

The device has been designed for use exclusively within the technical limit values indicated on the identification plate and in the data sheets.

When using measuring media, the following points must be observed:

- Wetted parts such as measuring electrodes, liner, grounding electrodes, grounding plates or protection plates must not be damaged by the chemical and physical properties of the measuring medium during the operating time.
- Measuring media with unknown properties or abrasive measuring media may only be used if the operator is able to perform regular and suitable tests to ensure the safe condition of the device
- The indications on the name plate must be observed
- Before use of corrosive or abrasive measuring media, the operator must clarify the level of resistance of wetted parts.

ABB will gladly support you in the selection, but cannot accept any liability in doing so.

Improper use

The following are considered to be instances of especially improper use of the device:

- Operation as a flexible compensating adapter in piping, for example for compensating pipe offsets, pipe vibrations, pipe expansions, etc.
- For use as a climbing aid, for example for mounting purposes.
- For use as a bracket for external loads, for example as a support for piping, etc.
- Material application, for example by painting over the housing, name plate or welding/soldering on parts.
- Material removal, for example by spot drilling the housing.

Warranty provisions

Using the device in a manner that does not fall within the scope of its intended use, disregarding this manual, using underqualified personnel, or making unauthorized alterations releases the manufacturer from liability for any resulting damage. This renders the manufacturer's warranty null and void.

... 1 Safety

Cyber security disclaimer

This product is designed to be connected to and to communicate information and data via a network interface. It is operator's sole responsibility to provide and continuously ensure a secure connection between the product and your network or any other network (as the case may be).

Operator shall establish and maintain any appropriate measures (such as but not limited to the installation of firewalls, application of authentication measures, encryption of data, installation of anti-virus programs, etc.) to protect the product, the network, its system and the interface against any kind of security breaches, unauthorized access, interference, intrusion, leakage and/or theft of data or information.

ABB and its affiliates are not liable for damages and/or losses related to such security breaches, any unauthorized access, interference, intrusion, leakage and/or theft of data or information.

Software downloads

By visiting the web pages indicated below, you will find notifications about newly found software vulnerabilities and options to download the latest software. It is recommended that you visit this web pages regularly:

www.abb.com/cybersecurity

[ABB Library - FSM4000](#)



Manufacturer's address

ABB Limited

Measurement & Analytics

Oldends Lane, Stonehouse
Gloucestershire, GL10 3TA
UK

Tel: +44 (0)1453 826661

Fax: +44 (0)1453 829671

Email: instrumentation@gb.abb.com

ABB Engineering (Shanghai) Ltd.

Measurement & Analytics

No. 4528, Kangxin Highway, Pudong New District
Shanghai, 201319,
P.R. China

Tel: +86(0) 21 6105 6666

Fax: +86(0) 21 6105 6677

Email: china.instrumentation@cn.abb.com

Customer service center












Customer service center

Tel: +49 180 5 222 580

Email: automation.service@de.abb.com

2 Design and function

Overview

Housing material	Alu. Housing, Series 4000				Stainless Steel Housing, Series 2000				
	 DN 3 ... 400 (1/10 ... 16")  DN 450 ... 1000 (18 ... 40")		 DN 3 ... 100 (1/10 ... 4")		 DN 3 ... 40 (1/10 ... 1 1/2")  DN 50 ... 100 (2 ... 4")		 DN 50 ... 100 (2 ... 4")  DN 3 ... 40 (1/10 ... 1 1/2")  1)  2)  3)  4)		
	Fixed Flange		Fixed Flange		Wafer type		Variable Connections		
1) Welded spud					3) Pipe fitting				
2) Tri-clamp					4) Male thread				
Sensor									
Model number	SE41F		SE21F		SE21W		SE21_*		
Measured error	0.5% of rate (> DN 2)								
	DN	PN	DN	PN	DN	PN	DN	PN	*
Wafer type	—		—		3 to 50 65 to 100	10 to 40 10 to 16	—	—	—
Flange DIN 2501/EN 1092-1	3 to 1000	10 to 40	3 to 100		10 to 40	—	—		
Flange ASME B16.5/B16.47	$\frac{1}{10}$ to 40"	CL 150	$\frac{1}{10}$ " to 4"		CL150 to	$\frac{1}{10}$ " bis 2"	CL300/JIS	—	
JIS B2210-10K	$\frac{1}{10}$ to 12"	CL 300			CL300/JIS	3" bis 4"	CL150/JIS		
Pipe fitting	—		—		—		3 to 40 ($\frac{1}{10}$ to 1 $\frac{1}{2}$ ")	40	S
DIN 11851							50, 80 (2", 3")	16	S
							65, 100 (2 $\frac{1}{2}$ ", 4")	10	S
Weld stubs DIN 11850	—		—		—		3 to 40 ($\frac{1}{10}$ to 1 $\frac{1}{2}$ ")	40	R
							50, 80 (2", 3")	16	R
							65, 100 (2 $\frac{1}{2}$ ", 4")	10	R
Welded spuds DIN 2463 / ISO 1127	—		—		—		3 to 40 ($\frac{1}{10}$ to 1 $\frac{1}{2}$ ")	40	Q/J
							50, 80 (2", 3")	16	Q/J
							65, 100 (2 $\frac{1}{2}$ ", 4")	10	Q/J
Weld stubs ISO 2037 / SMS	—		—		—		25 to 40 (1 to 1 $\frac{1}{2}$ ")	40	P/X
							50, 80 (2", 3")	16	P/X
							65, 100 (2 $\frac{1}{2}$ ", 4")	10	P/X
Tri-clamp DIN 32676 / ASME BPE	—		—		—		3 to 50 ($\frac{1}{10}$ to 2")	16/10	T/K
							65, 100 (2 $\frac{1}{2}$ ", 4")	10/10	T/K
External thread ISO 228 / DIN 2999	—		—		—		3 to 25 ($\frac{1}{10}$ bis 1")	16	E
Liner	Hard/soft rubber, ceramic carbide, PTFE, PFA, ETFE, other		PFA (vacuum-tight)		PFA, PFA vacuum-tight				
Conductivity	≥ 20 μS/cm (optional ≥ 5/0.5 μS/cm)								
Electrodes	Stainless steel 1.4571 (316 Ti), 1.4539 (904 L), Hastelloy B-3/C-4, platinum-iridium, tantalum, titanium								
Process connection material	Steel, stainless steel		—		Stainless steel 1.4404 (316 L)				
IP degree of protection in accordance with EN 60529	IP 65 / IP 67 / IP 68		IP 65 / IP 67 / IP 68		IP 65 / IP 67 / IP 68				
Measuring medium temperature	-25 to 130 °C / 180 °C (-13 to 266 °F / 356 °F)		-25 to 130 °C (-13 to 266 °F)		-40 to 130 °C (-40 to 266 °F)		-25 to 130 °C (-13 to 266 °F)		

... 2 Design and function


... Overview

Approvals

Model number	SE41F	SE21F	SE21W	SE21_*
Hygienic and sterile requirements	—	CIP/SIP capable		3A, CIP/SIP capable
Pressure Equipment Directive 97/23/EC	Conformity assessment in accordance with category III, fluid group 1			
CRN (Canadian Reg. Number)	On request			

Transmitter

Model number	S4
Power supply	85 to 253 V AC, 24 V AC/DC
Current output	0/2 to 10 mA, 0/4 to 20 mA
Pulse output	active (24 V), optocoupler (220 mA)
Ext. output switch-off	yes
Ext. totalizer reset	yes
Forward / reverse flow measurement	yes
Communication	HART® protocol, PROFIBUS PA®, FOUNDATION Fieldbus®
Pipe empty detection std.	yes, DN 10 or higher and $\geq 20 \mu\text{S/cm}$
Self-monitoring, extended diagnosis functions	yes, extended diagnostic functions / fingerprint only in connection with sensors SE21, SE21F and SE41F for DN 10 or higher
Local display / totalization	yes
Density correction	yes, manual entry (totalize and display in mass units)
IP rating in accordance with EN 60529	IP 65 / IP 67, NEMA 4X
Chassis	Field mount housing



Measuring principle

Measurements performed by the electromagnetic flowmeter are based on Faraday’s law of induction. A voltage is generated in a conductor when it moves through a magnetic field.




Figure 1: Electromagnetic flowmeter diagram

$U_1 \sim B \times D \times v$	$qv = \frac{D^2 \times \pi}{4} \times v$	$U_1 \sim qv$
U_1 Measuring span	v Average flow velocity	
B Magnetic induction	qv Volume flow rate	
D Electrode spacing		

With the device-relevant application of this measuring principle, a conductive measuring medium flows through a tube in which a magnetic field is generated perpendicular to the flow direction (see Figure 1).

The voltage induced in the measuring medium is tapped by two diametrically opposed electrodes. This measurement voltage is proportional to the magnetic induction, the electrode spacing and the average medium velocity v .

Taking into account that the magnetic induction and the electrode spacing are constant values results in a proportion between the measurement voltage U_1 and the average medium velocity.

From the calculation of the volume flow rate follows that the measurement voltage is linear and proportional to the volume flow rate

The induced voltage is converted by the transmitter to standardized, analog and digital signals.

Design

An electromagnetic flowmeter system consists of a flowmeter sensor and a transmitter. The flowmeter sensor (model SE41F, SE21W, SE21F, SE21) is installed in the specified pipeline while the transmitter (S4) is mounted locally or at a central location.

Device designs




Figure 2: Device designs

The μ P transmitter is mounted at a separate location from the sensor. Up to 50 m signal cable length for a minimum conductivity of 20 μ S/cm. For sensors with preamplifiers, the signal cable length is increased to 200 m. The electrical connection between the transmitter and the sensor primary is provided by a signal cable and a magnetic coil cable in the terminal box.

The transmitter is available in the design:

- Field mount housing model S4

The flowmeter sensor comes with aluminum or stainless steel housing:

- Aluminum housing: model FSM4000-SE41F
- Stainless steel housing: model FSM4000-SE21W / -SE21F / -SE21

Note

Older model flowmeter sensors can be connected to S4 transmitters. For additional information, see **Checks before commissioning** on page 46 or **S4 operation with older sensor** on page 109.

3 Product identification

Position of the name plate / factory plate

The factory tag or name plate can be found in the following places on the meter housing:




Figure 3: Plate positions

Identification of the device design

1. Identifying the model:

The model number of the flowmeter primary or transmitter (see nos. 1 or 2 in the description of the model plates) can be found on the model plate. The electrical connection for the respective model can be found in the chapter 'Electrical connections'. Technical data, material load curves, etc., appear sorted by model in the chapter 'Specification'.

2. Identifying the transmitter design:

The transmitter design can be identified from the name plate on the transmitter housing.

3. Identifying the software version:

The software version can be displayed when the transmitter is switched on.

Note



Products that are marked with the adjacent symbol may **not** be disposed of as unsorted municipal waste (domestic waste).


They should be disposed of through separate collection of electric and electronic devices.

Name plate

Note

The name plates displayed are examples. The device identification plates affixed to the device can differ from this representation.


Sensor



- | | |
|--|--|
| ① Model no. | ⑧ Max. flow rate at $v = 10 \text{ m/s}$ |
| ② CE mark (EG conformity) | ⑨ Power consumption |
| ③ Order number | ⑩ Phase relationship between signal and reference voltages |
| ④ Meter tube lining / electrode material | ⑪ Reference voltage |
| ⑤ Nominal diameter / Nominal pressure | ⑫ Cs calibration factor span |
| ⑥ Max. measuring medium temperature | ⑬ Cz calibration factor zero point |
| ⑦ IP rating of the housing | |

Figure 4: Name plate sensor

Transmitter



- | | |
|--|--|
| ① CE mark (EG conformity) | ⑥ Design according to order with/without HART® protocol or PROFIBUS PA® or FOUNDATION Fieldbus® |
| ② Model no. | |
| ③ Order number | |
| ④ Power supply - voltage range / frequency | ⑦ Design according to order active (24 V pulse) or passive (optoelectronic coupler) (Switch to active or passive) can be made on site) |
| ⑤ Power consumption transmitter and sensor | |

Figure 5: Name plate transmitter S4

Factory tag

The factory plate is on the flowmeter in addition to the name plate. Depending on the nominal diameter of the flowmeter ($> \text{DN } 25$ or $\leq \text{DN } 25$), it is identified with two different factory plates (also refer to article 4, paragraph 3, Pressure Equipment Directive 2014/68/EU):

Pressure equipment in the scope of the Pressure Equipment Directive




Figure 6: Factory plate for nominal diameter $> \text{DN } 25$ (example)

The number of the notified body is specified underneath the CE mark to confirm that the device meets the requirements of the Pressure Equipment Directive.

The respective fluid group in accordance with the Pressure Equipment Directive is indicated under PED.

Example: Fluid Group 1 = hazardous fluids, gaseous.

Pressure equipment outside the scope of the Pressure Equipment Directive




Figure 7: Factory plate for nominal diameter $\leq \text{DN } 25$ (example)

In PED the exception to article 4 paragraph 3 of the Pressure Equipment Directive is specified.

The pressure equipment is classified in the SEP (= Sound Engineering Practice) 'Good Engineering Practice' category.

Note

If the factory plate is missing all together, the device is not in compliance with the requirements of the Pressure Equipment Directive 2014/68/EU. Networks for the supply, distribution and discharge of water and related specific accessories are classed as an exception in accordance with guideline 1/16 of Art. 1, Para. 3.2 of the Pressure Equipment Directive.

4 Transport and storage

Inspection

Check the devices immediately after unpacking for possible damage that may have occurred from improper transport. Details of any damage that has occurred in transit must be recorded on the transport documents. All claims for damages must be submitted to the shipper without delay and before installation.

Transport

⚠ DANGER

Life-threatening danger due to suspended loads.

In the case of suspended loads, a danger of the load falling exists.

- Standing under suspended loads is prohibited.

⚠ WARNING

Risk of injury due to device slipping.

The device's center of gravity may be higher than the harness suspension points.

- Make sure that the device does not slip or turn during transport.
- Support the device laterally during transport.

NOTICE

Potential damage to the device!

The protection plates or protection caps mounted at the process connections on devices with PTFE / PFA liners may only be removed immediately before installation.

- To prevent possible leakage, make sure that the liner on the flange is not cut or damaged.




Figure 8: Transport instructions - ≤ DN 450

Flange devices ≤ DN 450

- Use carrying straps to transport flange designs smaller than DN 450.
- Wrap the carrying straps around both process connections when lifting the device.
- Chains should not be used, since these may damage the housing.

Flange devices > DN 450




Figure 9: Transport instructions - > DN 450

- Using a forklift to transport flange device can dent the housing.
- Flange devices must not be lifted by the center of the housing when using a forklift for transport.
- Flange devices must not be lifted by the terminal box or by the center of the housing.
- Only the transport lugs fitted to the device can be used to lift the device and insert it into the piping.

Storing the device

Bear the following points in mind when storing devices:

- Store the device in its original packaging in a dry and dust-free location.
- Observe the permitted ambient conditions for transport and storage.
- Avoid storing the device in direct sunlight.
- In principle, the devices may be stored for an unlimited period. However, the warranty conditions stipulated in the order confirmation of the supplier apply.

Temperature data

Storage temperature

Model SE41F

–20 to 70 °C (–4 to 158 °F)

Model SE21_

–25 to 70 °C (–13 to 158 °F)

The ambient conditions for the transport and storage of the device correspond to the ambient conditions for operation of the device.

Adhere to the device data sheet!

Returning devices

For the return of devices, follow the instructions in **Returning devices** on page 119.

5 Installation

Safety instructions

WARNING

Risk of injury due to process conditions.

The process conditions, for example high pressures and temperatures, toxic and aggressive measuring media, can give rise to hazards when working on the device.

- Before working on the device, make sure that the process conditions do not pose any hazards.
- If necessary, wear suited personal protective equipment when working on the device.
- Depressurize and empty the device / piping, allow to cool and purge if necessary.

WARNING

Risk of injury due to live parts!

When the housing is open, contact protection is not provided and EMC protection is limited.

- Before opening the housing, switch off the power supply.

Installation conditions

General

The following points must be observed during installation:

- The flow direction must correspond to the marking, if present
- The maximum torque for all flange screws must be complied with
- Secure flange screws and nuts against pipe vibration.
- The devices must be installed without mechanical tension (torsion, bending)
- Install flange devices / wafer-type devices with plane parallel counterflanges and use appropriate gaskets only
- Use gaskets made from a material that is compatible with the measuring medium and measuring medium temperature.
- Gaskets must not extend into the flow area, since possible turbulence could influence the accuracy of the device
- The piping may not exert any inadmissible forces or torques on the device.
- Make sure that the temperature limits are not up-scaled during operation of the device.
- Vacuum shocks in the piping should be avoided to prevent damage to the liners (PTFE liner). Vacuum shocks can destroy the device.
- Do not remove the sealing plugs in the cable glands until you are ready to install the electrical cable
- Make sure the gaskets for the housing cover are seated correctly. Carefully seal the cover. Tighten the cover fittings
- The transmitter with a remote mount design must be installed at a largely vibration-free location
- Do not expose the transmitter and sensor to direct sunlight. Provide appropriate sun protection as necessary. If necessary, provide a suited means of sun protection.
- When installing the transmitter in a control cabinet, make sure adequate cooling is provided

Brackets

NOTICE

Potential damage to the device!

Improper support for the device may result in a deformed housing and damage to internal magnetic coils.

- Place the supports at the edge of the sensor housing (see arrows in **Figure 10**).




Figure 10: Support for nominal diameters greater than DN 400

Devices with nominal diameters larger than DN 400 must be mounted on a sufficiently strong foundation with support.

Gaskets

The following points must be observed when installing gaskets:

- To achieve the best results, make sure that the gaskets and meter tube fit concentrically.
- To make sure that the flow profile is not distorted, the gaskets may not intrude in the piping cross-section.
- The use of graphite with the flange or process connection gaskets is prohibited. This is because, in some instances, an electrically conductive coating may form on the inside of the meter tube.

Devices with hard rubber or soft rubber liner

- Devices with a hard / soft rubber liner always require additional gaskets
- ABB recommends using gaskets made from rubber or rubber-like sealing materials
- When selecting the gaskets, make sure that the tightening torques specified in chapter **Torque information** on page 21 are not up-scaled.

Devices with a PTFE, PFA or ETFE liner

- In principle, devices with a PTFE, PFA or ETFE liner do not require additional gaskets.

Flow direction





Figure 11: Flow direction

The device measures the flow rate in both flow directions. Forward flow is the factory setting, as shown in Figure 11.

Electrode axis



① Electrode axis

Figure 12: Orientation of the electrode axis

The flowmeter sensor should be mounted in the piping in such a manner that the electrode axis is oriented as horizontally as possible.

A maximum deviation of 45° from the horizontal position is permissible.

... 5 Installation

... Installation conditions

Mounting position




Figure 13: Mounting position

- Ⓐ Vertical installation for measuring abrasive materials, preferably with flow in upward direction.
- Ⓑ For a horizontal installation, the meter tube must always be completely filled with the measuring medium. Provide for a slight incline of the connection for degassing.

Note

For hygienic applications, the vertical mounting position is preferred.

For a horizontal mounting position, make sure that the sensor is installed to be self-draining.


Grounding

The flowmeter sensor must be connected to ground potential. For technical reasons, this potential must be identical to the potential of the measuring medium.

In piping made of plastic or with insulating liner, grounding of the measuring medium is done by installing grounding plates.

If stray potential is present in the piping, adding a grounding plate on both ends of the flowmeter sensor is recommended.

Sensor insulation




① Insulation

Figure 14: Insulation of the flowmeter sensor

In the high temperature design, the flowmeter sensor can be completely thermally insulated. After the unit is installed, the piping and sensor must be insulated in accordance with the figure.

Inlet and outlet sections



- ① Double manifold ② Turn-off device

Figure 15: Inlet and outlet section, turn-off devices

The measuring principle is independent of the flow profile as long as standing eddies do not extend into the measured value formation, such as may for example occur after double manifolds, in the event of tangential inflow, or where half-open gate valves are located upstream of the sensor. In such cases, measures must be put in place to normalize the flow profile.

- Ⓐ Do not install fittings, manifolds, valves, etc., right before the flowmeter sensor.
 Ⓑ Inlet / outlet sections: length of the straight piping upstream and downstream on the sensor.

Experience has shown that, in most installations, straight inlet sections $3 \times \text{DN}$ long and straight outlet sections $2 \times \text{DN}$ long are sufficient (DN = nominal diameter of the flowmeter sensor).

For test stands, the reference conditions of $10 \times \text{DN}$ straight inlet and $5 \times \text{DN}$ straight outlet must be provided, in accordance with EN 29104 / ISO 9104.

Valves or other turn-off devices should be installed in the outlet section.

Valve flaps must be installed so that the valve damper plate does not extend into the flowmeter sensor.

Free inlet or outlet




Figure 16: Free inflow and outflow

- Ⓐ For a free outflow, do not install flowmeter at the highest point of the piping or on its outflow side, since the measuring tube may run empty, creating air bubbles.
 Ⓑ For free inflow/outflow, provide an invert to make sure that the piping is always full

Mounting with heavily contaminated measuring media




Figure 17: Bypass line

For strongly contaminated measuring media, a bypass line in accordance with the figure is recommended so that operation of the system can continue to run without interruption during mechanical cleaning.

... 5 Installation

... Installation conditions

Mounting with pipe vibration




Figure 18: Vibration damping

If pipe vibration occurs, it needs to be damped using damping devices.

The damping devices must be installed outside the support section and outside of the piping section between the turn-off devices.

Avoid connecting damping devices directly to the flowmeter sensor.

Installation in piping with larger nominal diameter




Figure 19: Using reducers

Determine the resulting pressure loss when using reducers:

1. Determine diameter ratios d/D .
2. Determine the flow velocity based on the flow rate nomogram (Figure 20).
3. Read the pressure loss on the Y-axis in Figure 20.




Figure 20: Flow rate nomogram for flange transition piece at $\alpha/2 = 8^\circ$

Installation in 3A compliant installations




Figure 21: 3A compliant installation

Please observe the following points:

- (A) Do not install the device vertically with the terminal box or transmitter housing pointing downward.
- (B) The 'angel bracket' option is not 3A compliant.
- (C) If concentric reducers are installed on the device, it must be mounted in a vertical position. See also **Installation in piping with larger nominal diameter** on page 18.
- (D) Please make sure that the leakage hole of the process connection is located at the lowest point of the installed device.
 - A vertical mounting position is preferred. For a horizontal mounting position, make sure that the sensor is installed to be self-draining.
 - Make sure that the cover of terminal box and / or transmitter housing is properly sealed. There can be no gaps between the housing and the cover.

Only devices with the following process connections fulfill 3A compliance.

- Welded spuds
- Tri-clamp

Installing the sensor

NOTICE

Damage to the device

Damage to the device due to improper assembly.

- The use of graphite with the flange or process connection gaskets is prohibited. This is because, in some instances, an electrically conductive coating may form on the inside of the meter tube.
- Vacuum shocks in the piping should be avoided to prevent damage to the liners (PTFE liner). Vacuum shocks can destroy the device.

The flowmeter sensor can be installed at any location in the piping while taking the installation conditions into account.

1. Remove protective plates, if present, to the right and left of the meter tube. To prevent possible leakage, make sure that the liner on the flange is not cut or damaged.
2. Position the flowmeter sensor plane parallel and centered between the piping.
3. Install gaskets between the surfaces, see **Gaskets** on page 15.

Note

For achieve the best results, ensure the gaskets fit concentrically with the meter tube

To guarantee that the flow profile is not distorted, the gaskets must not protrude into the piping.

... 5 Installation

... Installing the sensor

4. Use the appropriate screws for the holes in accordance with **Torque information** on page 21.
5. Slightly grease the threaded nuts.
6. Tighten the nuts in a crosswise manner as shown in the figure. Observe the tightening torques in accordance with **Torque information** on page 21!

First tighten the nuts to approx. 50 % of the maximum torque, then to 80 %, and finally a third time to the maximum torque. Do not exceed the max. torque.




Figure 22: Tightening sequence for the flange screws

Torque information

Flange and wafer type devices, model SE41F / SE21F / SE21W

Nominal diameter DN		Nominal pressure	Max. tightening torque [Nm]			
mm	In	PN	Hard/soft rubber lining		PTFE, PFA, ETFE lining	
			Steel flange	Stainless steel flange	Steel flange	Stainless steel flange
3 to 10 ¹⁾	$\frac{1}{10}$ to $\frac{3}{8}$ " ¹⁾	PN40	-	-	12.43	12.43
		PN63/100	-	-	12.43	12.43
		CL150	-	-	12.98	12.98
		CL300	-	-	4.94	17.38
		JIS 10K	-	-	12.43	12.43
15	$\frac{1}{2}$ "	PN40	6.74	4.29	14.68	14.68
		PN63/100	13.19	11.2	22.75	22.75
		CL150	3.65	3.65	12.98	12.98
		CL300	4.94	3.86	4.94	17.38
		CL600	9.73	9.73	-	-
20	$\frac{3}{4}$ "	JIS 10K	2.84	1.37	14.68	14.68
		PN40	9.78	7.27	20.75	20.75
		PN63/100	24.57	20.42	42.15	42.15
		CL150	5.29	5.29	18.49	18.49
		CL300	9.77	9.77	33.28	33.28
25	1"	CL600	15.99	15.99	-	-
		JIS 10K	4.1	1.88	20.75	20.75
		PN40	13.32	8.6	13.32	8.6
		PN63/100	32.09	31.42	53.85	53.85
		CL150	5.04	2.84	23.98	23.98
32	1 $\frac{1}{4}$ "	CL300	17.31	16.42	65.98	38.91
		CL600	22.11	22.11	-	-
		JIS 10K	8.46	5.56	26.94	26.94
		PN40	27.5	15.01	45.08	45.08
		PN63/100	42.85	41.45	74.19	70.07
40	1 $\frac{1}{2}$ "	CL150	4.59	1.98	29.44	29.44
		CL300	25.61	14.22	45.52	45.52
		CL600	34.09	34.09	-	-
		JIS 10K	9.62	4.9	45.08	45.08
		PN40	30.44	23.71	56.06	56.06
		PN63/100	62.04	51.45	97.08	97.08
		CL150	5.82	2.88	36.12	36.12
		CL300	33.3	18.41	73.99	73.99
		CL600	23.08	23.08	-	-
		JIS 10K	12.49	6.85	56.06	56.06

1) Connection flange DIN/EN1092-1 = DN10 (3/8"), connection flange ASME = DN15 (1/2")

... 5 Installation

... Torque information

Nominal diameter DN		Nominal pressure	Max. tightening torque [Nm]			
mm	Inch	PN	Hard/soft rubber lining		PTFE, PFA, ETFE lining	
			Steel flange	Stainless steel flange	Steel flange	Stainless steel flange
50	2"	PN40	41.26	27.24	71.45	71.45
		PN63	71.62	60.09	109.9	112.6
		CL150	22.33	22.33	66.22	66.22
		CL300	17.4	22.33	38.46	38.46
		CL600	35.03	35.03	-	-
		JIS 10K	17.27	10.47	71.45	71.45
65	2½"	PN16	14.94	8	37.02	39.1
		PN40	30.88	21.11	43.03	44.62
		PN63	57.89	51.5	81.66	75.72
		CL150	30.96	30.96	89.93	89.93
		CL300	38.38	27.04	61.21	61.21
		CL600	53.91	53.91	-	-
		JIS 10K	14.94	8	37.02	39.1
80	3"	PN40	38.3	26.04	51.9	53.59
		PN63	63.15	55.22	64.47	80.57
		CL150	19.46	19.46	104.6	104.6
		CL300	75.54	26.91	75.54	75.54
		CL600	84.63	84.63	-	-
		JIS 10K	16.26	9.65	45.07	47.16
100	4"	PN16	20.7	12.22	49.68	78.19
		PN40	67.77	47.12	78.24	78.19
		PN63	107.4	95.79	148.5	119.2
		CL150	17.41	7.82	76.2	76.2
		CL300	74.9	102.6	102.6	102.6
		CL600	147.1	147.1	-	-
		JIS 10K	20.7	12.22	49.68	78.19
125	5"	PN16	29.12	18.39	61.4	64.14
		PN40	108.5	75.81	123.7	109.6
		PN63	180.3	164.7	242.6	178.2
		CL150	24.96	11.05	98.05	98.05
		CL300	81.64	139.4	139.4	139.4
		CL600	244.1	244.1	-	-
150	6"	PN16	46.99	23.7	81.23	85.08
		PN40	143.5	100.5	162.5	133.5
		PN63	288.7	269.3	371.3	243.4
		CL150	30.67	13.65	111.4	111.4
		CL300	101.4	58.4	123.6	123.6
		CL600	218.4	218.4	-	-
200	8"	PN10	45.57	27.4	113	116.9
		PN16	49.38	33.82	70.42	73
		PN25	100.6	69.17	109.9	112.5
		PN40	196.6	144.4	208.6	136.8
		PN63	350.4	331.8	425.5	282.5
		CL150	49.84	23.98	158.1	158.1
		CL300	133.9	78.35	224.3	224.3

Nominal diameter DN		Nominal pressure	Max. tightening torque [Nm]			
mm	Inch	PN	Hard/soft rubber lining		PTFE, PFA, ETFE lining	
			Steel flange	Stainless steel flange	Steel flange	Stainless steel flange
250	10"	PN10	23.54	27.31	86.06	89.17
		PN16	88.48	61.71	99.42	103.1
		PN25	137.4	117.6	166.5	133.9
		PN40	359.6	275.9	279.9	241
		CL150	55.18	27.31	146.1	148.3
		CL300	202.7	113.2	246.4	246.4
300	12"	PN10	58.79	38.45	91.29	94.65
		PN16	122.4	85.64	113.9	114.8
		PN25	180.6	130.2	151.1	106.9
		PN40	On request	On request	On request	On request
		CL150	90.13	50.37	203.5	198
		CL300	333.3	216.4	421.7	259.1
350	14"	PN10	69.62	47.56	72.49	75.22
		PN16	133.6	93.61	124.9	104.4
		PN25	282.3	204.3	226.9	167.9
		CL150	144.8	83.9	270.5	263
		CL300	424.1	252.7	463.9	259.4
400	16"	PN10	108.2	75.61	120.1	113.9
		PN16	189	137.2	191.4	153.8
		PN25	399.4	366	404	246.7
		CL150	177.6	100	229.3	222.8
		CL300	539.5	318.8	635.8	328.1
450	18"	CL150	218.6	120.5	267.3	192.3
		CL300	553.8	327.2	660.9	300
500	20"	PN10	141.6	101.4	153.9	103.5
		PN16	319.7	245.4	312.1	224.8
		PN25	481.9	350.5	477.1	286
		CL150	212.5	116	237.3	230.4
		CL300	686.3	411.8	786.8	363.1
600	24"	PN10	224.7	164.8	238.7	149.1
		PN16	515.1	399.9	496.7	365.3
		PN25	826.2	600.3	750.7	539.2
		CL150	356.6	202.8	451.6	305.8
		CL300	1188	719	1376	587.4
700	28"	PN10	267.7	204.9	On request	On request
		PN16	455.7	353.2	On request	On request
		PN25	905.9	709.2	On request	On request
		CL150	364.1	326.2	449.2	432.8
		CL300	1241	On request	On request	On request
750	30"	CL150	423.8	380.9	493.3	442
		CL300	1886	On request	On request	On request

... 5 Installation

... Torque information

Nominal diameter DN		Nominal pressure	Max. tightening torque [Nm]			
mm	Inch	PN	Hard/soft rubber lining		ETFE lining	
			Steel flange	Stainless steel flange	Steel flange	Stainless steel flange
800	32"	PN10	391.7	304.2	On request	On request
		PN16	646.4	511.8	On request	On request
		PN25	1358	1087	On request	On request
		CL150	410.8	380.9	493.3	380.9
		CL300	2187	On request	On request	On request
900	36"	PN10	387.7	296.3	On request	On request
		PN16	680.8	537.3	On request	On request
		PN25	1399	1119	On request	On request
		CL150	336.2	394.6	511	458.5
		CL300	1972	On request	On request	On request
1000	40"	PN10	541.3	419.2	On request	On request
		PN16	955.5	756.1	On request	On request
		PN25	2006	1612	On request	On request
		CL150	654.2	598.8	650.6	385.1
		CL300	2181	On request	On request	On request

Variable process connections model SE21

Nominal diameter DN		Max. tightening torque
mm	inch	Nm
3 to 10	3/8"	8
15	1/2"	10
20	3/4"	21
25	1"	31
32	1 1/4"	60
40	1 1/2"	80
50	2"	5
65	2 1/2"	5
80	3"	15
100	4"	14

Nominal diameter, nominal pressure, measuring range

Nominal diameter		Standard pressure rating PN	Min. flow velocity measuring range						Max. flow velocity measuring range					
DN			0 to 0.5 m/s						0 to 10 m/s					
3	$\frac{1}{10}$	40	0	up to	0.2	l/min	0.0529	US gal/min	0	up to	4	l/min	1.06	US gal/min
4	$\frac{5}{32}$	40	0	up to	0.4	l/min	0.1	US gal/min	0	up to	8	l/min	2.1	US gal/min
6	$\frac{1}{4}$	40	0	up to	1	l/min	0.3	US gal/min	0	up to	20	l/min	5.3	US gal/min
8	$\frac{5}{16}$	40	0	up to	1.5	l/min	0.4	US gal/min	0	up to	30	l/min	7.9	US gal/min
10	$\frac{3}{8}$	40	0	up to	2.25	l/min	0.6	US gal/min	0	up to	45	l/min	12	US gal/min
15	$\frac{1}{2}$	40	0	up to	5.0	l/min	1.3	US gal/min	0	up to	100	l/min	36	US gal/min
20	$\frac{3}{4}$	40	0	up to	7.5	l/min	2.0	US gal/min	0	up to	150	l/min	40	US gal/min
25	1	40	0	up to	10	l/min	2.6	US gal/min	0	up to	200	l/min	53	US gal/min
32	1 $\frac{1}{4}$	40	0	up to	20	l/min	5.3	US gal/min	0	up to	400	l/min	106	US gal/min
40	1 $\frac{1}{2}$	40	0	up to	30	l/min	7.9	US gal/min	0	up to	600	l/min	159	US gal/min
50	2	40	0	up to	3	m3/h	13	US gal/min	0	up to	60	m3/h	264	US gal/min
65	2 $\frac{1}{2}$	40	0	up to	6	m3/h	26	US gal/min	0	up to	120	m3/h	528	US gal/min
80	3	40	0	up to	9	m3/h	40	US gal/min	0	up to	180	m3/h	793	US gal/min
100	4	16	0	up to	12	m3/h	53	US gal/min	0	up to	240	m3/h	1057	US gal/min
125	5	16	0	up to	21	m3/h	92	US gal/min	0	up to	420	m3/h	1849	US gal/min
150	6	16	0	up to	30	m3/h	132	US gal/min	0	up to	600	m3/h	2642	US gal/min
200	8	10/16	0	up to	54	m3/h	238	US gal/min	0	up to	1080	m3/h	4755	US gal/min
250	10	10/16	0	up to	90	m3/h	396	US gal/min	0	up to	1800	m3/h	7925	US gal/min
300	12	10/16	0	up to	120	m3/h	528	US gal/min	0	up to	2400	m3/h	10567	US gal/min
350	14	10/16	0	up to	165	m3/h	726	US gal/min	0	up to	3300	m3/h	14529	US gal/min
400	16	10/16	0	up to	225	m3/h	991	US gal/min	0	up to	4500	m3/h	19813	US gal/min
450	18	10/16	0	up to	300	m3/h	1321	US gal/min	0	up to	6000	m3/h	26417	US gal/min
500	20	10	0	up to	330	m3/h	1453	US gal/min	0	up to	6600	m3/h	29059	US gal/min
600	24	10	0	up to	480	m3/h	2113	US gal/min	0	up to	9600	m3/h	30380	US gal/min
700	28	10	0	up to	660	m3/h	2906	US gal/min	0	up to	13200	m3/h	58118	US gal/min
800	32	10	0	up to	900	m3/h	3963	US gal/min	0	up to	18000	m3/h	79252	US gal/min
900	36	10	0	up to	1200	m3/h	5283	US gal/min	0	up to	24000	m3/h	105669	US gal/min
1000	40	10	0	up to	1350	m3/h	5944	US gal/min	0	up to	27000	m3/h	118877	US gal/min

... 5 Installation

Grounding

General information on grounding

Observe the following items when grounding the device:

- Use the supplied green/yellow cable as a grounding wire.
- Connect the ground screw for the sensor (on flange and transmitter housing) to the station ground.
- The terminal box must also be grounded.
- For plastic piping or piping with insulating liner, the ground is provided by the grounding plate or grounding electrodes.
- When stray potentials are present, install a grounding plate upstream and downstream of the sensor.
- For measurement-related reasons, the potential in the station ground and in the piping should be identical.
- Additional grounding on the terminals is not required.

Note

If the flowmeter is installed in plastic or earthenware pipelines, or in pipelines with an insulating lining, transient current may flow through the grounding electrode in special cases. In the long term, this may destroy the sensor, since the ground electrode will in turn degrade electrochemically. In these special cases, the connection to the ground must be performed using grounding plates.

Metal pipe with fixed flanges




Figure 23: Grounding connections

1. Insert M6×12 threads (2) in the flanges for the piping and the sensor.
2. Secure the ground straps (1) with screw, spring washer and washer in accordance with the figure.
3. Use a copper wire (minimum 2.5 mm² (14 AWG)) to establish a connection between the ground connection of the sensor and a suited grounding point.

Metal pipe with loose flanges




Figure 24: Grounding connections

1. Solder the threaded nuts (2) M6 to the piping.
2. Insert M6x12 threads (3) in the flanges of the sensor.
3. Secure the ground straps (1) with nuts, spring washer and washer in accordance with the figure, and connect to the sensor with ground connection (3).
4. Use a copper wire (minimum 2.5 mm² (14 AWG)) to establish a connection between the ground connection (3) and a suited grounding point.

Non-metallic pipes or pipes with insulating liner




Figure 25: Grounding connections


For plastic piping or piping with an insulating liner, the grounding of the measuring medium is provided by the grounding plate as shown in the figure below or via grounding electrodes that must be installed in the device (option). If grounding electrodes are used, the grounding plate is not necessary.

1. Install the sensor with grounding plate (1) in the piping.
2. Insert M6x12 threads (2) in the flange of the sensor.
3. Connect the terminal lug for the grounding plate (3) and ground connection on the sensor (2) with the grounding strap.
4. Use a copper wire (minimum 2.5 mm² (14 AWG)) to establish a connection between the ground connection (2) and a good grounding point.

... 5 Installation

... Grounding

Stainless steel sensor model SE21



G10533

Figure 26: Grounding connections

Ground the stainless steel model as shown in the figure. The measuring medium is grounded via the adapter ① and additional grounding is not required.

Ground for devices with protection plates

The protection plates are used to protect the edges of the meter tube liner, e.g. for abrasive media. In addition, they function as a grounding plate.

- For plastic protection plates or piping with an insulating liner, electrically connect in the same manner as a grounding plate.

Grounding with conductive PTFE grounding plate

Grounding plates made of conductive PTFE are optionally available for nominal diameter ranges of DN 10 to 250. These are installed similar to conventional grounding plates.

6 Electrical connections

Safety instructions

WARNING

Risk of injury due to live parts.

Improper work on the electrical connections can result in electric shock.

- Connect the device only with the power supply switched off.
- Observe the applicable standards and regulations for the electrical connection.

The electrical connection may only be established by authorized specialist personnel and in accordance with the connection diagrams.

The electrical connection information in this manual must be observed; otherwise, the IP rating may be adversely affected. Ground the measurement system according to requirements.

Preparing and routing the signal and magnetic coil cable

Preparing for sensor model SE21, SE21F


Cut to length and terminate both cables as shown.

Note


Use wire end sleeves.

Signal cable D173D025U01



Preparing the transmitter side





Magnet coil cable D173D147U01



Preparing the sensor side



Cable identifiers



- ① Measuring potential, yellow
- ② Reference, white
- ③ Signal cable, red
- ④ Signal cable, blue
- ⑤ SE clamp

- ① Magnetic coil, black
- ② Magnetic coil, black
- ③ SE clamp

Figure 27: Preparing the signal and magnetic coil cable sensor model SE21, SE21F

Note

The shielding may not touch (signal short circuit).

... 6 Electrical connections

... Preparing and routing the signal and magnetic coil cable

Preparing for sensor model SE41F

Cut to length and terminate both cables as shown.

Note

Use wire end sleeves.




Figure 28: Preparing the signal and magnetic coil cable sensor model SE21, SE21F

Note

The shielding may not touch (signal short circuit).

Routing the signal and magnetic coil cable

Observe the following points when routing cables:

- The signal and magnetic coil cable carries a voltage signal of only a few millivolts and therefore must be routed the shortest distance possible. The maximum permissible signal cable length is 50 m or 200 m, if the flowmeter primary is equipped with a preamplifier.
- Avoid the vicinity of electrical equipment or switching elements that can create stray fields, switching pulses and induction. If this is not possible, run the signal / magnet coil cable through a metal pipe and connect this to the station ground.
- All lines must be shielded and connected to operational ground.
- Do not run the signal cable and the magnetic coil cable over junction boxes or terminal blocks.
- To shield against magnetic interspersion, the cable contains outer shielding that is attached to the SE clamp.
- Make sure during installation that the cable is provided with a water trap ①. For vertical installation, align the cable glands pointing downward.




Figure 29: Water trap

... 6 Electrical connections

Connecting the sensor

Connecting the signal and magnet coil cables

The flowmeter sensor is connected to the transmitter via the signal / magnet coil cables (part no. D173D025U01 / D173D147U01). The coils of the flowmeter sensor are supplied with a field voltage by the transmitter over terminals M1/M3. Connect the cables to the sensor in accordance with the following drawing, using a screwdriver with proper size and width.





Figure 30: Connection to sensor

Terminal designation	Connection
1 + 2	Wires for the measuring signal (red, blue)
1S, 2S	Shielding for signal wires
U+, U-	Power supply for preamplifier via signal cable shielding
16	Wire for reference signal (white)
3A	Shielding for reference signal cable
3	Measuring ground (yellow)
M1 + M3	Connections for magnetic field excitation (black)
SE	Outer cable shield

Connection with IP rating IP 68



① Maximum flooding height 5 m (16.4 ft)

Figure 31: Maximum flooding height for IP 68 sensors

For sensors with IP rating IP 68, the maximum flooding height is 5 m (16.4 ft).

The supplied signal cable fulfills all the submersion requirements.

The sensor is type-tested in accordance with EN 60529. Test conditions:

14 days at a flooding height of 5 m 16.4 ft).

Electrical connection

NOTICE

Adverse effect on the IP rating IP 68

The IP rating IP 68 of the sensor may be adversely affected as a result of damage to the signal cable.

- The sheathing of the signal cable must not be damaged.

1. Use the supplied signal cable to connect the sensor and the transmitter.
2. Connect the signal cable in the terminal box of the sensor.
3. Route the cable from the terminal box to above the maximum flooding height of 5 m (16.4 ft).
4. Tighten the cable gland.
5. Carefully seal the terminal box. Make sure the gasket for the cover is seated properly.

Note

As an option, the sensor can be ordered with the signal cable already connected to the sensor and the terminal box already potted.

Potting the terminal box on-site

⚠ CAUTION

Danger to health!

The two-component potting compound is toxic – observe all relevant safety measures!

Comply with the safety data sheet of the two-component potting compound before preparations are started.

Risk notes:


- R20: Damaging to health when inhaled.
- R36/37/38: Irritates the eyes, respiratory organs and the skin.
- R42/43: Sensitization through inhaling and skin contact is possible.

Safety advice:

- S23: Do not inhale gas/smoke/humidity/aerosol.
- S24: Avoid contact with the skin.
- S37: Wear suited protective gloves.
- S63: In case of an accident due to inhaling: take the injured person out into the fresh air to rest.

... 6 Electrical connections

... Connection with IP rating IP 68



① Maximum fill level

Figure 32: Maximum fill level

If the terminal box is to be potted subsequently on-site, a special two-component potting compound can be ordered separately. Potting is only possible if the sensor is installed horizontally.

Observe the following instructions during work activity:

- Complete the installation before potting in order to avoid moisture penetration. Before starting, check all the connections for correct fitting and stability
- Do not overfill the terminal box. Keep the potting compound away from the O-ring and the gasket / groove (see Figure 32).
- Prevent the two-component potting compound from penetrating the cable conduit (Conduit) for an ½ in NPT installation (if used).

Connecting the transmitter

Connecting the power supply

The line voltage and power consumption are indicated on the name plate for the transmitter. The wire cross-section for the power supply must meet the requirements for the main fuse (VDE 0100). The power consumption is ≤ 45 VA (sensor including transmitter).

The power supply is connected to terminal L (phase), N (neutral), or 1+, 2-, and \oplus , in accordance with the information on the name plate.

The power supply cable must be rated for the current consumption of the flowmeter system. The leads must comply with IEC 227 and/or IEC 245.

Connect a switch or a line switch in the power supply line to the transmitter. This switch should be located near the transmitter and marked as being associated with the device. The transmitter and the sensor should be connected to functional ground \oplus in accordance with international standards.

Note

Please observe the limit values of the power supply (see 'Specification'). Please note that there is a voltage drop of the 24 V AC/DC power supply line if the cables are extremely long or if the conductor cross section is extremely small.

The pin configuration must be made in accordance with the electrical connections in **Terminal assignment** on page 36.

Connecting the signal and magnet coil cables




Figure 33: Transmitter

The outer shielding of the magnet coil cable is attached to the busbar via the 6 mm clip (from the accessory bag in the connection area). The outer shielding of the signal is routed in a similar manner. Use the 7 mm clip (from the accessory bag in the connection chamber). The shielding for the signal wires function as a 'driven shield' to transmit the measurement signal. The signal-reference voltage cable is attached to the sensor and transmitter according to the electrical connection.

Note

The power supply of the FSM4000 with preamplifier is connected via -U and +U, instead of 1S and 2S. If the flow indicator shows the incorrect flow direction after successful commissioning of the measuring system, e.g., reverse instead of forward, correct this in the 'Operating mode submenu' of the transmitter.

First switch off the programming protection ('Prog. Level / Specialist'). Then select the parameter 'Directional display' in the 'Operating mode submenu' and change 'normal' to 'inverse'. Finally, reactivate programming protection by selecting 'Prog. Level / Locked'.

Note

If the flowmeter sensor for older model meters (10D1422, 10DI1425, 10DS3111, DS4_, DS2_, 10D1462/72) is not yet equipped with the SE clamp, the outer shielding is connected to one side of the transmitter only. Use the 12 mm clip (from the accessory bag), if necessary (e.g., 10D1422).

... 6 Electrical connections

Terminal assignment

Standard DN 3 to DN 1000 ($\frac{1}{16}$ to 40")





Figure 34: Electrical connection sensor standard DN 10 ... DN 1000 ($\frac{1}{16}$... 40")

1) See the chapter 'Connection examples for peripherals' in the operating instruction and/or on the data sheet

Note

We recommend that shielded output cables be used with the shields connected to the functional ground at one end.

With preamplifier DN 3 to DN 1000 ($\frac{1}{16}$ to 40")



Sensor

- | | |
|---|--|
| ① Functional ground (busbar) | ⑧ Steel shielding |
| ② Pulse output ¹⁾ | ⑨ Aluminum foil |
| ③ Switch input ¹⁾ | ⑩ Yellow |
| ④ Switch output ¹⁾ | ⑪ Shield |
| ⑤ Current output ¹⁾ | ⑫ Blue |
| ⑥ Magnetic coil cable:
shielded 2 x 1 mm ² CE type 227 TEC 74
ABB order no. D173D147U01, 10 m included in shipment, standard | ⑬ Red |
| ⑦ Power supply
Low voltage: 100 to 230 V AC, terminals L, N, \perp
Extra-low voltage: 20.4 to 26.4 V AC;
20.4 to 31.2 V DC
Terminals 1+, 2-, \perp
Frequency: 47 Hz $\leq f \leq$ 53 Hz; 50 Hz power supply
56 Hz $\leq f \leq$ 64 Hz; 60 Hz power supply | ⑭ White |
| | ⑮ Shielded signal cable:: ABB order no. D173D025U01,
10 m included in delivery |
| | ⑯ with preamplifier (always at DN 3 to DN 8 [$\frac{1}{16}$ to $\frac{5}{16}$ "]) |

Figure 35: Electrical connection sensor with preamplifier DN 3 to DN 1000 ($\frac{1}{16}$ to 40"), transmitter field mount housing

1) See the chapter 'Connection examples for peripherals' in the operating instruction and/or on the data sheet

Note

- We recommend that shielded output cables be used with the shields connected to the functional ground at one end.
- If the sensor is equipped with a preamplifier for low conductivity or in nominal diameter range of DN 3 to DN 8 ($\frac{1}{16}$ to $\frac{5}{16}$ "), the shieldings of the signal wires must be connected to terminals U+ and U- on both the sensor and the transmitter.

... 6 Electrical connections

... Terminal assignment

DN 3 to DN 1000 ($\frac{1}{16}$ to 40") with PROFIBUS PA / FOUNDATION Fieldbus




Figure 36: Electrical connection transmitter S4 with PROFIBUS PA / FOUNDATION Fieldbus


Note

- We recommend that shielded output cables be used with the shields connected to the functional ground at one end.
- If the sensor is equipped with a preamplifier for low conductivity or in nominal diameter range of DN 1 to DN 8 ($\frac{1}{10}$ to $\frac{5}{16}$ "), the shieldings of the signal wires must be connected to terminals U+ and U- on both the sensor and the transmitter.

... 6 Electrical connections

... Terminal assignment

Retrofit for model 10D1422: DN 3 to DN 1000 ($\frac{1}{10}$ to 40"); model 10DI1425 and 10DS3111A-E:
DN 500 to DN 1000 (20 to 40")



① Functional ground (busbar)

② Pulse output¹⁾

③ Switch input¹⁾

④ Switch output¹⁾

⑤ Current output¹⁾

⑥ Power supply

Low voltage: 100 to 230 V AC, terminals L, N, \oplus

Frequency: 47 Hz $\leq f \leq$ 53 Hz; 50 Hz power supply

56 Hz $\leq f \leq$ 64 Hz; 60 Hz power supply

Sensor

⑦ Shielded signal cable: ABB order no. D173D025U01
or incorporate in existing wiring

⑧ Reference cable:
Only for connection to model 10D1422
Close terminals: 6,7 and hook switch S903

⑨ Magnetic coil supply:
Magnet coil supply via supply power

⑩ Terminal board: D685A1020U03

Figure 37: Sensor standard DN 3 to DN 1000 ($\frac{1}{10}$ to 40"), transmitter field mount housing

1) See the chapter 'Connection examples for peripherals' in the operating instruction and/or on the data sheet

Note

We recommend that shielded output cables be used with the shields connected to the functional ground at one end.

Digital communication

HART® protocol

The device is registered with the HART Communication Foundation.

Note

The HART® protocol is an unsecured protocol, as such the intended application should be assessed to ensure that these protocols are suitable before implementation.




Figure 38: HART communication

HART protocol

Configuration	Directly on the device Software DAT200 Asset Vision Basic (+ HART-DTM)
Transmission	FSK modulation on current output 4 ... 20 mA according to Bell 202 Standard
Max. signal amplitude	1.2 mAss
Current output load	Min. 250 Ω, max. = 560 Ω
Cable	AWG 24 twisted
Max. cable length	1500 m
Baud rate	1200 baud
Display	Log. 1: 1200 HZ Log. 0: 2200 Hz

For additional information, see the separate interface description.

System integration

In conjunction with the DTM (Device Type Manager) available for the device (software version B.10 and higher), communication (configuration, parameterization) can occur with the corresponding framework applications according to FDT 1.21 (DAT200 Asset Vision Basic).

Other tool/system integrations (e.g., Emerson AMS/Siemens S7) are available upon request.

A free of charge version of the DAT200 Asset Vision Basic framework application for HART® or PROFIBUS is available upon request.

The required DTMs are contained on the DAT200 Asset Vision Basic DVD or in the DTM Library.

They can also be downloaded from www.abb.com/flow.

PROFIBUS PA protocol

The interface conforms to Profile 3.0 (PROFIBUS standard, EN 50170, DIN 19245 [PRO91]).

Note

The PROFIBUS PA® protocol is an unsecured protocol, as such the intended application should be assessed to ensure that these protocols are suitable before implementation.




Figure 39: Example for PROFIBUS PA connection

PROFIBUS PA ID No.:	0x078C
Alternative Standard-Ident-No.	0x9700 or 0x9740
Configuration	Directly on the device Software DAT200 Asset Vision Basic (+ PROFIBUS PA-DTM)
Transmission signal	Acc. to IEC 61158-2
Cable	Shielded, twisted cable (acc. to IEC 61158-2, types A or B are preferred)

Bus topology

- Tree and / or line structure.
- Bus connection: Passive at both ends of the main bus line (RC element $R = 100 \Omega$, $C = 1 \mu F$).

Voltage / current consumption

- Mean current consumption: 10 mA.
- In the event of an error, the FDEfunction (= Fault Disconnection Electronic) integrated in the device makes sure that the current consumption cannot exceed a maximum of 13 mA.
- The upper current limit is restricted electronically.
- The voltage on the bus line must lie in the range of 9 to 32 V DC

... 6 Electrical connections

... Digital communication

Bus address

In the case of devices with a PROFIBUS PA interface, check the bus address prior to commissioning. If no specifications exist to the contrary, the address is set to 126. During commissioning, the address must be set to a valid value in the range 0 to 125.

System integration

Use of PROFIBUS PA profile B, B3.0 ensures interoperability and interchangeability of units. Interoperability means that devices from different manufacturers can be physically connected to a bus and are communication-ready.

The devices can be interchanged without having to reconfigure the process control system.

To support interchangeability, three different GSD files (equipment master data) are provided, which can be integrated in the system.

For additional information, see the separate interface description.

The manufacturer-specific GSD file ABB_078C can be downloaded from <http://www.abb.com/flow>.
The standard GSD files PA1397xx.gsd can be downloaded from <http://www.profibus.com>.

FOUNDATION Fieldbus® (FF)

Note

The FOUNDATION Fieldbus® protocol is an unsecured protocol, as such the intended application should be assessed to ensure that these protocols are suitable before implementation.




Figure 40: Example for FOUNDATION Fieldbus connection

FF interface	Compliant with FF standard 890/891 and FF 902/90
Interoperability test campaign no.	IT 027200 (ITK 4.6)
Manufacturer ID	0x000320
Device ID	0x0017
Configuration	<ul style="list-style-type: none">• Directly on the device• Via services integrated in the system• National configurator
Transmission signal	Acc. to IEC 61158-2

Bus topology

- Tree and / or line structure.
- Bus connection: Passive at both ends of the main bus line (RC element $R = 100\ \Omega$, $C = 1\ \mu F$).

Voltage / current consumption

- Mean current consumption: 10 mA.
- In the event of an error, the FDEfunction (= Fault Disconnection Electronic) integrated in the device makes sure that the current consumption cannot exceed a maximum of 13 mA.
- The upper limit of the current is electronically restricted.
- The voltage on the bus line must lie in the range of 9 to 32 V DC

Connection examples for peripherals
(incl. HART)

Current output




Figure 41: Current output active with / without HART protocol (4 ... 20 mA)

Current output active with / without HART protocol (4 ... 20 mA)	
Terminals	31, 32
Current output	can be selected via software
Function	Active
	0/4 ... 20 mA ($0 \Omega \leq R_B \leq 560 \Omega$)
	0/2 ... 10 mA ($0 \Omega \leq R_B \leq 1120 \Omega$)
	(for HART only 4 ... 20 mA)

Switch output




Figure 42: Switch output for system monitoring, Max. / Min. alarm for empty meter tube or forward / reverse signal

Switch output for system monitoring	
Terminals	41, 42
Current output	can be selected via software
Function	Passive
	• 'closed': $0 \text{ V} \leq U_{CE} \leq 2 \text{ V}$, $2 \text{ mA} \leq I_{CE} \leq 220 \text{ mA}$
	• 'open': $16 \text{ V} \leq U_{CEH} \leq 30 \text{ V}$, $0 \text{ mA} \leq I_{CEH} \leq 2 \text{ mA}$

Note

Horn and alarm light are shown only as examples. Other suitable devices such as bells, sirens, buzzers, etc., can also be used.

Bus address

The bus address is automatically assigned or can be set in the system manually.

Addresses are detected using a unique combination of manufacturer ID, device ID, and device serial number.

System integration

The following are required:

- DD (Device Description) file, which includes the device description.
- CFF (Common File Format) file is required for engineering the segment. Engineering can be performed online or offline.

For additional information, see the separate interface description.

The files required for operation can be downloaded from <http://www.fieldbus.org>.

... 6 Electrical connections

... Connection examples for peripherals (incl. HART)

Switch input





Figure 43: Switch input for external totalizer reset and external zero return


Switch input, passive	
Terminals	81, 82
Current output	can be selected via software
Function	Passive
	• 'On': 16 V ≤ UKL ≤ 30 V
	• 'Off': 0 V ≤ UKL ≤ 2 V
	Ri = 2 kΩ

Pulse output

Active pulse output



Pulse output, passive, optocoupler



$$* R_B \geq \frac{U_{CE}}{I_{CE}}$$

I internal E external

Figure 44: Pulse output, active and passive, optoelectronic coupler

Current output active with / without HART protocol (4 ... 20 mA)	
Terminals	51, 52
Current output	can be selected via software
Operating mode	Active / passive, selectable via jumper (see 'Commissioning' chapter in operating instruction)
f _{max}	5 kHz
f _{min}	0.00016 Hz
Adjustment range	Pulse / unit, pulse width (observe dynamic limits)
Function	Active
	• 150 Ω ≤ load < 10 kΩ: pulse width ≤ 50 ms, max. pulse frequency ≤ 3 Hz,
	• 500 Ω ≤ load < 10 kΩ pulse width ≤ 0.1 ms, max. pulse frequency: 5 kHz
	Passive
	• 'closed': 0 V ≤ U _{CEL} ≤ 2 V, 2 mA ≤ I _{CEL} ≤ 220 mA
	• 'open': 16 V ≤ U _{CEH} ≤ 30 V, 0 mA ≤ I _{CEH} ≤ 2 mA

PROFIBUS PA® / FOUNDATION Fieldbus®




Figure 45: Digital communication PROFIBUS PA / FOUNDATION Fieldbus

The resistance R and condenser C form the bus termination. They must be installed when the device is connected to the end of the entire bus cable.

$$R = 100 \, \Omega; C = 1 \, \mu\text{F}$$

Bus termination for S4 transmitter





Figure 46: Bus termination

To terminate the bus if the instrument is at the end of the bus cable, the termination components in the S4 transmitter can be used. To do so, close both hook switches in the connection area of the transmitter.

Note

If the transmitter module is removed, bus termination is also canceled.

Connection via M12 plug (for PROFIBUS PA only)



Pin assignment (front view showing pin insert and pins)

1	PA+	3	PA-
2	nc	4	Shielding

Figure 47: M12 plug-in connector PROFIBUS PA

As an option, the bus can also be connected via an M12 plug instead of the cable gland (see order information for device). The device can be shipped completely prewired. For information about suitable connectors (type EPG300) and other accessories, refer to the data sheet 10/63.6.44 DE.

7 Commissioning

Safety instructions

⚠ CAUTION

Risk of burns due to hot measuring media

The device surface temperature may exceed 70 °C (158 °F), depending on the measuring medium temperature!

- Before starting work on the device, make sure that it has cooled sufficiently.

Aggressive or corrosive media may lead to the damage of wetted parts of the sensor. As a result, measuring medium under pressure can leak out.

Wear to the flange gasket or process connection gaskets (e.g. pipe fitting, Tri-clamp, etc.) may caused a pressurized measuring medium to escape.

When using internal flat gaskets, they can become brittle through CIP- / SIP processes.


If pressure surges above the permissible nominal pressure of the device occur permanently during operation, this may affect the service life of the device.

If there is a chance that safe operation is no longer possible, take the device out of operation and secure it against unintended startup.

Checks before commissioning

The following points must be checked before commissioning:

- The power supply must be switched off.
- The power supply used must match the information on the name plate.
- The terminal assignment must be made in accordance with the electrical connection.
- Sensor and transmitter must be grounded properly.
- The temperature limit values must be observed.
- When the sensor (SE41F, SE21, SE21F) and transmitter (S4) are delivered as a pair, the data memory module (external FRAM) is located in the sensor. The data module stores the sensor data, e.g., size, Cs, Cz, type, etc., as well as the setup data on the transmitter after commissioning.
- Prior to commissioning, plug the external FRAM for the appropriate sensor (order no. is printed on the FRAM and, if available, a TAG no.) to the terminal board for the installed transmitter. Then screw to the connection board (captive).



① External FRAM

Figure 48: Plugging the FRAM into the transmitter

Note

If a transmitter is ordered for an older model sensor (see model number), an external FRAM is already connected to the connection board. You will also find the information $C_s = 100\%$ and $C_z = 0\%$, which is required for flowmeters primary from older product lines. In this regard, see also **S4 operation with older sensor** on page 109.

- The transmitter must be installed at a location largely free of vibrations.
- Monitoring of pulse output.

The pulse output can be operated as active output (24 VDC pulse) or as passive output (optocoupler). The current setting is provided on the name plate for the transmitter. Modification as shown in the following illustration.




Figure 49: Setting the pulse output using jumpers

Commissioning

Power Supply Power-Up

After switching on the power supply, the sensor data in the external FRAM is compared with the data saved internally. If the data is not identical, the transmitter data is replaced automatically. Once completed, Warning 7 'Sensor data loaded' and Warning 8b 'Update external FRAM' are displayed. The measuring equipment is now ready for operation. The display shows the current flowrate.

... 7 Commissioning

... Commissioning

Device configuration

The device can be factory calibrated to customer specifications upon request. If no customer information is available, the device is delivered with factory settings.

On-site configuration requires only a few parameter settings. For entry or selection of parameters, refer to the section titled 'Entering data in short form'. A short overview of the menu structure can be found in the section titled 'Parameter overview'. The Easy Set-up menu enables users to configure the unit quickly and conveniently, see **Easy Set-up, for uncomplicated parameterization** on page 49.

The following parameters should be checked or set for commissioning:

1. **Upper range value** (menu item ' Q_{\max} ' and menu item 'Unit').
The device is factory calibrated to the largest flow range end value, unless customer information to the contrary is available. Upper range values that correspond to a flow velocity of 2 to 3 m/s are ideal. First set the unit Q_{\max} (e.g. m³/h oder l/s) in the menu item 'Unit' and then the upper range value in menu item ' Q_{\max} '. The smallest and largest possible upper range values are shown in Table **Nominal diameter, nominal pressure, measuring range** on page 25.
2. **Current output** (menu item 'Current output')
Selected the desired current range here (0 to 20 mA or 4 to 20 mA)
3. For devices with a fieldbus, the bus address must be set (menu item 'Interface').
4. **Pulse output** (menu items 'Pulse' and 'Unit').
To set the number of pulses per volume flow unit, a unit for the totalizer (e.g., m³ or l) must be selected in the menu item 'Unit'. Afterward the number of pulses has to be entered in the menu item 'Pulse output'.
5. **Pulse width** (menu item 'pulse output')
For external processing of the counting pulses at terminals 51 and 52, the pulse width can be set between 0.1 ms and 2000 ms.
6. **System zero point** (menu item 'Syst.-Adjust')
When commissioning an older model flowmeter sensor or checking the system, you can set the system zero point on the transmitter after a warmup period. The fluid in the flowmeter sensor must be at absolute standstill. The measuring tube must be completely full. The adjustment can now be made manually or automatically on the transmitter via the 'System zero point' parameter. Select the parameter by pressing ENTER, use the arrow buttons for example to call up 'automatic' and press ENTER again to start the adjustment. The adjustment runs approx. 60 seconds and should be within a range of $\pm 10\%$. If the value measured is outside this limit, no calibration is performed. The adjustment can also be performed via the external switch input / ext. sys. zero point (see parameter **Switch input** on page 77).
7. **Detector empty pipe**
(Menu item 'Detector e. pipe'), for devices with nominal diameter DN 10 and/or without preamplifier.
When the 'Standard' DEP mode is selected, you do not need to perform an adjustment on site. The transmitter works with standard setup data. If the function is not performed correctly, a new adjustment must be run with the fluid onsite. The adjustment can be made with a full or empty meter pipe.
8. **Extended diagnostic functions**
To measure the DC resistance or the coil temperature, the signal cable length must be entered. To use the functions Electrode voltage, Electrode balance and Electrode state, the electrode zero must be adjusted. See submenu **Alarm Coil Current** on page 85 or **Additional information regarding use of enhanced diagnostic functions** on page 97.

Note


If the flow indicator shows the incorrect flow direction after successful commissioning of the measuring system, e.g., reverse instead of forward, correct this in the 'Operating mode submenu' of the transmitter.

First switch off the programming protection ('Prog. Level' → 'Specialist'). Then select the parameter 'Directional display' in the 'Operating mode submenu' and change 'normal' to 'inverse'. Finally, reactivate programming protection by selecting 'Prog. Level' → 'Locked').

Easy Set-up, for uncomplicated parameterization



The Easy Set-up function enables users to configure the transmitter for quick and convenient startup. For further setup options, see **Parameter descriptions** on page 57.



Press any key in the process display, then use STEP or DATA to scroll to the "Easy Set-up" menu.

Note!
Parameters can be changed only when the Program protection is turned off.




Figure 50: Easy Set-up function

... 7 Commissioning

Commissioning of PROFIBUS PA® devices

Note
The PROFIBUS PA® protocol is an unsecured protocol, as such the intended application should be assessed to ensure that these protocols are suitable before implementation.

For units with PROFIBUS PA, the bus address must be checked or configured prior to commissioning. If no bus address information was supplied by the customer, the unit was shipped with its BUS address set to '126'.

The address must be set during commissioning to a number within the valid range (0 to 125).

Note
The set address may only appear once in the segment.


The address can be set either locally on the device (via the DIP switches on the digital board), using system tools, or via a PROFIBUS DP master class 2 such as Asset Vision Basic (DAT200).

The factory setting for DIP switch 8 is OFF, i.e., the address is set using the fieldbus.
The front cover can be unscrewed to change the settings. It is also possible to set the address via menu by using the buttons on the display board.

The PROFIBUS PA interface of the device conforms with Profile 3.0 (fieldbus standard PROFIBUS, EN 50170, alias DIN 19245 [PRO91]). The transmitter transmission signal is designed according to IEC 61158-2.

Note
The manufacturer-specific PROFIBUS PA ID no. is: 0x078C hex. The unit can also be operated with the PROFIBUS standard ID nos. 0x9700 or 0x9740.

Example for local address setup
(DIP switch 8 = On)



① Transmitter plug-in unit ② DIP switch

Figure 51: Position of the DIP switches

Switch 1, 5, 7 = ON means: 1+16+64 = 81 → bus address 81

Switch	1	2	3	4	5	6	7	8	9	A
Status	Device address							Address mode	No function	No function
Off	0	0	0	0	0	0	0	Bus	No function	No function
On	1	2	4	8	16	32	64	Local	No function	No function

Switch assignments

Switch	Assignment
1 to 7	PROFIBUS address
8	Defines the addressing mode: Off = Set address via bus (factory setting) On = Set address via DIP switches 1 to 7

Behavior with power supply powered-up

After the power supply has been powered-up, DIP switch 8 is polled:

Status	
ON	The address defined by DIP switches 1 to 7 applies. The address can no longer be changed via the bus once the device is in operation, since DIP switch 8 is polled only once when the power supply is powered-up.
OFF (Default)	The transmitter uses the address stored in the FRAM of the gateway. Upon shipment the address is set to 126 or to the address specified by the customer. Once the unit is in operation, the address can be changed via the bus or directly on the unit using the keys on the display board. The unit must be connected to the bus.

Unit behavior after replacing transmitter electronics

If the transmitter is located at the bus end and if the bus termination is activated via both hook switches, the bus termination is canceled when the transmitter plug-in unit is removed. The bus is no longer terminated properly. To ensure proper operation, the bus termination must be connected at another location. If the transmitter plug-in unit is reinstalled, the old bus termination can be used again.

Note

The factory default for the selector is ID no. 0x078C hex. The following ID numbers can also be selected: 0x9700 or 0x9740.

Information on voltage/current consumption

The mean current consumption of the device is 10 mA. The voltage on the bus line must lie in the range of 9 to 32 V DC

Note

The upper limit of the current is electronically limited. In the event of an error, the FDEfunction (Fault Disconnection Electronic) integrated in the device makes sure that the current consumption cannot exceed a maximum of 13 mA.

System integration

Use of PROFIBUS PA profile B, B3.0 ensures interoperability and interchangeability of units. Interoperability means that devices from different manufacturers can be physically connected to a bus and are communication-ready. In addition, third-party devices can be interchanged without having to reconfigure the process control system.

To support interchangeability, ABB provides three different GSD files (equipment master data) that can be integrated in the system.

Users decide at system integration whether to install the full range of functions or only part.

Note

Units are interchanged using the parameter ID number selector, which can only be modified on an acyclical basis.

The following table describes the available GSD files:

Number and type of function blocks	ID number	GSD file name
1 x AI	0x9700	PA139700.gsd
1 x AI; 1 x TOT	0x9740	PA139740.gsd
1 x AI; 2 x TOT; and all manufacturer-specific parameters	0x078C	ABB_078C.gsd

The manufacturer-specific GSD file "ABB_078B" is available to download from the ABB website <http://www.abb.com/flow>.

The standard GSD files PA1397xx.gsd are available for download from the Profibus International homepage: <http://www.profibus.com>

... 7 Commissioning

Commissioning of FOUNDATION FIELDBUS® devices

For devices with a FOUNDATION Fieldbus, the settings of the DIP switch must be checked prior to commissioning.

When integrating the unit in a process control system, a DD file (device description) and a CFF file (common file format) are required. The DD file contains the device description. The CFF file is required for segment engineering. Engineering can be performed online or offline. The DD and CFF files are available to download from the ABB homepage <http://www.abb.com/flow>.

The DIP switches on the unit must be set correctly as follows:

- DIP switch 1 must be set to OFF.
- DIP switch 2 must also be set to OFF. Otherwise, the hardware write protection and the process control system prevent the unit from recording information.

The FOUNDATION Fieldbus interface for the device is compliant with the standards FF-890/891 and FF-902/90. The transmitter transmission signal is designed according to IEC 61158-2.

The device is registered with the FOUNDATION fieldbus. The registration number is IT 027200.

Registration for the FOUNDATION fieldbus is recorded under manufacturer ID 0x000320 and unit ID 0x0017.

Assigning of DIP switches

- DIP switch 1:
Releases the simulation of the AI function blocks.
- DIP switch 2:
Hardware write protection for write access via bus (locks all blocks).

DIP switch	1	2	3 to 10
Status	Simulation Mode	Write Protect	No function
Off	Disabled	Disabled	No function
On	Enabled	Enabled	No function

Bus address settings

The bus address is automatically allocated at the FF via LAS (link active scheduler). For address detection, a unique number is used (DEVICE_ID). This number is a combination of manufacturer ID, device ID and device serial number.

Switch-on behavior


The behavior when switching on the unit corresponds to Draft DIN IEC/65C/155/CDV of June 1996.

Information on voltage/current consumption

The mean current consumption of the device is 10 mA. The voltage on the bus line must lie in the range of 9 to 32 V DC

Note

The upper limit of the current is electronically limited. In the event of an error, the FDEfunction (Fault Disconnection Electronic) integrated in the device makes sure that the current consumption cannot exceed a maximum of 13 mA.



1 Transmitter plug-in unit 2 DIP switch

Figure 52: Position of the DIP switches

8 Operation

Safety instructions

CAUTION

Risk of burns due to hot measuring media

The device surface temperature may exceed 70 °C (158 °F), depending on the measuring medium temperature!

- Before starting work on the device, make sure that it has cooled sufficiently.

Aggressive or corrosive media may lead to the damage of wetted parts of the sensor. As a result, measuring medium under pressure can leak out.

Wear to the flange gasket or process connection gaskets (e.g. pipe fitting, Tri-clamp, etc.) may caused a pressurized measuring medium to escape.

When using internal flat gaskets, they can become brittle through CIP- / SIP processes.

If pressure surges above the permissible nominal pressure of the device occur permanently during operation, this may affect the service life of the device.

If there is a chance that safe operation is no longer possible, take the device out of operation and secure it against unintended startup.

Display options

After switching on the power supply, the current process information for the measuring point is displayed.

In the first line of the display, the current flow direction (→ F for forward, ← R for reverse) is displayed along with the flowrate as a percentage or a physical unit. The second line of the display shows the totalizer value (7-digit) for the current flow direction, followed by the relevant unit.

Independent of the pulse factor, the totalizer value is always the current flowrate with relevant unit. This indicator is displayed in the following text as process information.

The 4 lines of the display can be customized in the 'Display' submenu.

Examples:

```
→ V 98.14 l/h
→ V 12.30000 m³
← R 516.0000 m³
```

- | | |
|---------|---|
| 1. line | Current upstream flow rate |
| 2. line | Totalizer value, forward |
| 3. line | Totalizer value, reverse (multiplex mode) |

Totalizer overflow always occurs at a value of 9,999,999 units. If the totalizer value for a flow direction is larger than 9,999,999 units, Warning 9 is displayed in the 4th line. The totalizer software can register up to 250 overflows. The overflow notification can be cleared in the Totalizer submenu by using the 'Reset totalizer' function.

... 8 Operation

... Display options

Error condition

In the event of an error, an error or warning message is displayed in the 4th display line.

Flow rate > 103 %

This message is displayed alternatively in plain text and with the relevant error or warning number. The plain text error message provides the error or warning with the highest priority only. However, all existing errors and warnings are shown in the number display.


For a list of all possible error messages, refer to the chapter ‘Error messages’.

In addition to the error message, the current output is set to the limit value (menu ‘lout for alarm’). The alarm can be indicated optionally via the switch output, if selected.

Note

Error messages for ‘enhanced diagnosis’ are only indicated on the display or optionally via the switch output (select ‘General Alarm’ or ‘ext. Diag. Alarm”).

Data entry



- ①

Magnet sensor C/CE
- ④

Control buttons
- ②

Magnet sensor DATA / ENTER
- ⑤

Magnet
- ③

Magnet sensor STEP

Figure 53: Controls on the transmitter

Use the buttons ④ to enter data when housing is open. If the housing cover is closed, use the magnet stick ⑤ and the magnet sensors. The stick is held over the appropriate NS symbol.

When entering data, the transmitter remains online, i.e., current and pulse outputs still show the current operating mode.

The functions of the individual keys are explained below:

	C/CE	Toggle between operating mode and menu.
	STEP	The STEP key is one of two arrow keys. Use STEP to scroll forward through the menu. All the required parameters can be called up.
	DATA	The DATA key is one of two arrow keys. Use DATA to scroll backward through the menu. All the required parameters can be called up.
	ENTER	<p>The ENTER function requires that both arrow keys, STEP and DATA, be pressed simultaneously. ENTER has the following functions:</p> <ul style="list-style-type: none">Access the parameter to be changed and set the new, selected, or default parameter. <p>The ENTER function is effective for approx. 10 s only. If a new value is not entered within 10 s, the display reverts to the old value.</p>

Initiating the ENTER function when using the magnet stick for operation

The ENTER function is initiated when the DATA/ENTER sensor is activated for longer than 3 seconds. The display flashes to indicate that the function is active.

There are two different methods of entering data:

- Numerical entry
- Entry from specified table


Note

When entering data, the values are checked for plausibility and, if necessary, rejected with an appropriate message. In addition, in the 3th and 4th line, the limit values (min/max) are displayed.

... 8 Operation

... Data entry

Entering data in short form



Parameter descriptions

Submenu / parameter	Value range	Remark
<div>Prog.Level Disabled</div> <div> <div>Prog. level Disabled</div> <div> <div>Prog. level Standard</div> <div> <div>Prog. level specialists</div> <div> <div>Prog. level Service</div> <div> <div>Service code? 0</div> <div> <div>Prog. level Prog. prot. code</div> <div> <div>Old PP code: 0</div> <div>New PP code 0</div> </div> </div> </div> </div> </div> </div> </div>	<div>1 ... 9999</div> <div>1 ... 9999</div>	<p>"Locked": All entries in the standard menus can be read</p> <p>"Standard" menus are shaded in gray</p> <p>"Standard": Menu with all menu items needed to operate the device.</p> <p>'Specialist': Specialist menu with all menu items accessible by the customer.</p> <p>"Service": Additional service menus can be displayed by entering the correct service code number (for ABB Service personnel only).</p> <p>The Prog. Protection Code is normally '0'. If Prog. Protection is selected, the question 'New PP code?' is displayed. If the user enters an incorrect code between 1 ... 9999, a message **Prog.Prot.** appears, indicating that the menu is locked and requires the correct PP code. To suspend the PP-Code function, you must access the 'PP-Code' menu. Select ENTER and you will be asked for the old PP code. You must enter the correct old code before the message 'New PP-Code?' is displayed. Enter a new code or select '0' to disable the PP-Code function.</p>

... 8 Operation

... Parameter descriptions

Submenu / parameter	Value range	Remark
<div>Submenu</div> <div>EASY SETUP</div> <div>EASY SETUP</div>	Language Unit Qmax Unit totalizer Qmax Damping 1,000 Display mode Display line 1 Display line 2 Display line 3 Display line 4 Iout for alarm Low Alarm High alarm Pulse factor Vol. Pulse width	The EASY SETUP function allows you to configure the measuring system in an easy manner for operation. Menus are displayed in sequential order by EASY SETUP. If the display mode 1 big, 1 small is selected, the selection menus for Display 3rd line and Display 4th line are not displayed. For HART devices, the selection menu 'Iout type' is also not displayed. The ENTER function allows you to change parameters; the C/CE button jumps to the next entry. Press ENTER again to change parameters and, if necessary, you can call the next parameter via the STEP button. For numeric entries, the minimum and maximum settings are displayed.
<div>Language</div> <div>German</div> <div>Language</div> <div>German</div>	German English French Finnish Spanish Italian Dutch Danish Swedish Turkish	The languages available are displayed in the present language selection. Menus in the Service Code section are displayed in English.
<div>Submenu</div> <div>Operating mode</div> <div>Operating mode</div> <div>Normal</div> <div>Directional display</div> <div>Normal</div>	Normal Fast Piston Pump Standard, inverse	"Normal": Selection used for continuous flow measurement. "Quick": Accelerated data processing (e.g., short batch time dosing). "Piston pump": For pulsating flows. In this operating mode, data logging improves reproducibility for pulsating flows and during pump operation. The totalizer is automatically set to the difference totalizer operating mode. Any possible re-flow is automatically deducted from the totalizer count. Standard/inverse, change the flow direction indicators in the display for forward and reverse flow.

Submenu / parameter		Value range	Remark
<div>Submenu</div> <div>Unit</div>	<div>Flow direction</div> <div>Forward/reverse flow</div>	Supply/Return Forward	When the flow direction 'Forward/reverse flow' is selected, the flow direction is indicated in the display with '→ V' for forward and '← R' for reverse. If the forward flow setting is selected, the totalizer counts the forward flow only. If the flow is reversed, warning 10 'Reverse flow Q' is displayed.
	<div>Noise reduction</div> <div>Off</div>	Off, 1, 2, 3, 4	The noise reduction is switched on when the flow rate signal is: <ul style="list-style-type: none"> very unstable or temporarily or permanently frozen (error E) Notice: Activating noise reduction increases the response time.
	<div>Unit totalizer</div> <div>ml</div>	ml; l; m3; ugl; igl; bbl; g; kg; t; lb; prog unit ¹⁾ ; ft ^{3 2)}	Select the engineering units for volume and mass flowrate totalization. If the physical units are changed, the transmitter checks and changes the pulse factor and pulse width (0.1 ms to 2000 ms) depending on the measuring range. The transmitter first changes the pulse factor and then the pulse width. <p>1) kgal = Factory setting</p> <p>2) ft³ = added only for PROFIBUS PA</p>
	<div>Unit Qmax</div> <div>l/s</div>	l/s; l/min; l/h; m3/s; m3/min; m3/h; m3/d; usgps; usgpm; usgph; usmgd; igps; igpm; igph; igpd; bbl/s; bbl/m; bbl/h; bbl/d; g/s; g/min; g/h; kg/s; kg/min; kg/h; kg/d; t/min; t/h; t/d; lb/s; lb/min; lb/h; lb/d; ml/s, ml/min Prog. Unit/s1) Prog. Unit/min1) Prog. Unit/h1) Prog. Unit/d1)	Select the unit for volume and mass flow. This unit refers to Qmax DN, Qmax and the instantaneous status, if these are displayed in physical units. <p>For PROFIBUS PA, the following units are also displayed: ft3/s; ft3/min; ft3/h; ft3/d .</p> <p>For PROFIBUS PA, the following units are not displayed: Prog. unit and ml/s.</p> <p>1) kgal = Factory setting</p>

... 8 Operation

... Parameter descriptions

Submenu / parameter		Value range	Remark
<div> <div>Submenu Prog. Unit</div> <div>Unit name kgal</div> <div>Units factor 3785.1</div> <div>Prog. Unit Without density With density</div> <div>Density 1 g/cm³</div> <div>Submenu System data</div> <div>Submenu Transmitter</div> <div>Submenu Data 50 Hz</div> <div>Channel -123 μs</div> <div>Zero 0 %</div> <div>Voltage → V 91 %</div> <div>Voltage ← R -91 %</div> </div>			This menu does not appear for the PROFIBUS PA or FOUNDATION fieldbus.
	Text entry		Four character name for the user programmable unit. kgal = Factory setting.
	Numerical entry		Reference factor for the user-defined units based on liters; default value in kgal units (factory setting).
	Without density With density		Unit for mass (with density) or volume (without density).
	Numerical entry		Density range 0.1 ... -5 g/cm ³ . Mass flowrate for display and totalization. The density is only considered when mass flow units are and/or totalizer mass units are selected.
			This menu does not appear with an excitation frequency of 60 Hz or 70 Hz. Only for old (legacy) sensors.
	View only		Adjustment value for Channel can be monitored for the excitation frequency setting (displayed when an older primary 50 Hz has been selected).
	View only		Adjustment value for zero point can be monitored to check the excitation frequency setting (displayed when an older 50 Hz sensor has been selected).
	View only		Adjustment value for Span Forward can be monitored for the excitation frequency setting (displayed when an older primary 50 Hz has been selected).
	View only		Adjustment value for Span Reverse can be monitored for the excitation frequency setting (displayed when an older primary 50 Hz has been selected).

Submenu / parameter	Value range	Remark
<div data-bbox="320 369 564 441"> Submenu Data 60 Hz </div> <div data-bbox="400 474 644 541"> Channel -123 μs </div> <div data-bbox="400 604 644 672"> Zero 0 % </div> <div data-bbox="400 735 644 802"> Voltage \rightarrow V 91 % </div> <div data-bbox="400 865 644 932"> Voltage \leftarrow R -91 % </div>	<div data-bbox="691 474 778 499">View only</div> <div data-bbox="691 611 778 636">View only</div> <div data-bbox="691 743 778 768">View only</div> <div data-bbox="691 875 778 900">View only</div>	<div data-bbox="930 369 1509 432">This menu does not appear with an excitation frequency of 50 Hz or 70 Hz. Only for old (legacy) sensors.</div> <div data-bbox="930 474 1509 569">Adjustment value for channel can be monitored to check the excitation frequency setting (displayed when an older 60 Hz sensor has been selected).</div> <div data-bbox="930 611 1509 705">Adjustment value for zero point can be monitored to check the excitation frequency setting (displayed when an older 60 Hz sensor has been selected).</div> <div data-bbox="930 743 1509 837">Adjustment value for Span Forward can be monitored to check the excitation frequency setting (displayed when an older 60 Hz sensor has been selected).</div> <div data-bbox="930 875 1509 963">Adjustment value for Span Reverse can be monitored to check the excitation frequency setting (displayed when an older 60 Hz sensor has been selected).</div>

... 8 Operation

... Parameter descriptions

Submenu / parameter		Value range	Remark
	<div>Submenu</div> <div>Data 70 Hz</div>		This menu does not appear with an excitation frequency of 50 Hz or 60 Hz. Only for SE41F and SE21 transmitters.
	<div>Channel</div> <div>-123 μs</div>	View only	Display of the phase deviation between signal and reference voltage in μ s.
	<div>Zero</div> <div>Span >V</div> <div>Span <R</div>	View only	Display of the adjustment values for zero point, span forward and span reverse when amplification 'High' is selected in the 'Service / Primary Adjust / Amplification' menu.
	<div>Zero_2</div> <div>Span 2 >V</div> <div>Span 2 <R</div>	View only	Display of the adjustment values for zero point, span forward and span reverse when amplification 'Middle High' is selected in the 'Service / Primary Adjust / Amplification' menu.
	<div>Zero_4</div> <div>Span 4 >V</div> <div>Span 4 <R</div>	View only	Display of the adjustment values for zero point, span forward and span reverse when amplification 'Middle Low' is selected in the 'Service / Primary Adjust / Amplification' menu.
	<div>Zero_8</div> <div>Span 8 >V</div> <div>Span 8 <R</div>	View only	Display of the adjustment values for zero point, span forward and span reverse when amplification 'Low' is selected in the 'Service / Primary Adjust / Amplification' menu.
	<div>Zero_Pre/FIR</div>	View only	Display of the zero point offset with activated filter in 'Service / Noise Handling / Prefilter /' and 'Service / Noise Handling / Prefilter / FIR EA'
	<div>Zero_Pre</div>	View only	Display of the zero point offset with activated filter in 'Service / Noise Handling / Prefilter /'

Submenu / parameter	Value range	Remark
<div>Submenu</div> <div>Data lout</div>	View only	This menu does not appear for the PROFIBUS or FOUNDATION fieldbus.
<div>Adjust lout 4 mA</div> <div>4.0 mA</div>		Display adjustment value for transmitter for the current output at 4.0 mA.
<div>Adjust lout 4 mA</div> <div>20.0 mA</div>	View only	Display adjustment value for transmitter for the current output at 20.0 mA.
<div>Submenu</div> <div>Flowmeter sensor</div>	View only	<p>Display the connected flowmeter model: The selection is imported with the FRAM automatically by the transmitter. If an older flowmeter sensor model (see list) is selected, the FRAM with Cs = 100%, Cz = 100% must be used. The models 10D1422 (10DI1425, 10DS3111A-C ≥ DN 500) can only be connected to a specially designed terminal board on the transmitter. Close switch S903 on the connection board. The other models are put into operation with their assigned FRAM. For this reason, when older model flowmeter sensors are connected to the transmitter, a 'Primary Setup' menu is displayed at initial startup. Additional settings can be entered in the system data submenu 'Primary'. See also page 109.</p>
<div>Sensor model</div> <div>DS2_, DS4</div>		
<div>Line frequency</div> <div>50 Hz</div>		Display the mains frequency for which the flowmeter sensor was calibrated. Displayed only for 50/60 Hz older models. Not displayed, if SE41F or SE21 sensor is selected.

... 8 Operation

... Parameter descriptions

Submenu / parameter			Value range	Remark
		<div>Nominal diameter</div> <div>1 mm 1/25 in</div>	<div>View only</div> <div>1 mm 1/25 in</div> <div>1.5 mm 1/17 in</div> <div>2 mm 1/12 in</div> <div>3 mm 1/10 in</div> <div>4 mm 5/32 in</div> <div>6 mm 1/4 in</div> <div>8 mm 5/16 in</div> <div>10 mm 3/8 in</div> <div>15 mm 1/2 in</div> <div>20 mm 3/4 in</div> <div>25 mm 1 in</div> <div>32 mm 1-1/4 in 40 mm 1-1/2 in</div> <div>50 mm 2 in</div> <div>65 mm 2-1/2 in</div> <div>80 mm 3 in</div> <div>100 mm 4 in</div> <div>125 mm 5 in</div> <div>150 mm 6 in</div> <div>200 mm 8 in</div> <div>250 mm 10 in</div> <div>300 mm 12 in</div> <div>350 mm 14 in</div> <div>400 mm 16 in</div> <div>450 mm 18 in</div> <div>500 mm 20 in</div> <div>600 mm 24 in</div> <div>700 mm 28 in</div> <div>750 mm 30 in</div> <div>800 mm 32 in</div> <div>900 mm 36 in</div> <div>1000 mm 40 in</div>	Display the flowmeter sensor size. Not displayed, if no flowmeter sensor type is selected (flowmeter sensor type = none).

Submenu / parameter		Value range	Remark
<div> <div>Span Cs</div> <div>100.0 %</div> </div> <div> <div>Zero Cz</div> <div>0.0 %</div> </div> <div> <div>Phase</div> <div>90</div> </div> <div> <div>Reference voltage</div> <div>70 mV</div> </div> <div> <div>Meter factor</div> <div>1.0</div> </div> <div> <div>Order no.</div> <div>'-----'</div> </div> <div> <div>Submenu</div> <div>Primary Setup</div> </div> <div> <div>Line frequency</div> <div>50 Hz</div> </div> <div> <div>Sensor model</div> <div>DS4_</div> </div> <div> <div>Nominal diameter</div> <div>100 mm 4 in</div> </div> <div> <div>Reference voltage</div> <div>70 mV</div> </div> <div> <div>Meter factor</div> <div>1.0</div> </div>		View only	Flowmeter sensor span value Cs.
		View only	Flowmeter sensor zero value Cz. For old sensor always 0 %.
		View only	Phase relationship between reference and signal voltages. For SE41F and SE21 transmitters always 90°.
		View only	Display the reference voltage, for 'Older Model' selection. Not displayed for model 10D1422.
		View only	Displayed only if flowmeter sensor 10D1462/72 is selected
		View only	Display the ABB order number for the flowmeter sensor.
		Option available only with 'Older sensor'	Menu required for older sensors only. Visible only if 50 or 60 Hz has been selected in the 'Service/Primary Adjust/Frequency Primary' menu. By selecting 'Yes', the primary setting is started and the user is guided in a similar manner as for the 'Easy Set-Up' direction.
		50, 60 Hz	Displays the mains frequency for the flowmeter sensor. Option available only with 'Older sensor'.
		Selection of the older sensor	Display the connected flowmeter sensor model:
		Select the size of the connected flowmeter sensor	Select the size of the flowmeter sensor. Option available only with 'Older sensor'.
		Enter the reference voltage	Display the reference voltage, only for 'Older sensor' option, see name plate for sensor. Not displayed for models 10D1422, 10D1462/72.
		Numerical entry	Display the meter factor, only for older model 10D1462/72; see name plate for flowmeter sensor. See also page 109.

... 8 Operation

... Parameter descriptions

Submenu / parameter	Value range	Remark
Qmax DN 50 m ³ /h	View only	Display the max. possible flow range. Automatically selected based on size.
Qmax 50 m ³ /h	Numerical entry	Flow range end value for forward and reverse flow. Flow range end value configurable from 0.5 ... 10 m/s.
Damping 1τ 1 sec	Numerical entry	Response time, after 1τ the value displayed has reached 63% of its end value (after 5τ). The following values can be selected, operating mode: Standard 0.2 ... 20 s, Quick/piston pump 0.07 ... 20 s.
Low flow 1.0 %	Numeric entry 0 ... 10% of Qmax	Applicable for display and all outputs. The switching limit for the low flow cutoff has a built-in hysteresis of 0.1%.
Submenu Detector e. pipe		<p>Note</p> <p>The meter pipe must be completely filled to ensure proper measurement. The function 'Detector empty pipe' can be used to continuously monitor this condition. If the measuring medium drops below the electrode level, all output signals can be automatically set to zero. This ensures false pulses or incorrect displays are avoided when the meter pipe is empty. In addition to the message in the display, this condition can be reported via the switch contact output. If the meter tube is filled, the error message 'empty pipe' is turned off and the measuring system returns to normal operation.</p>
Detector e. pipe Off	Off A	<p>Turn on/off the 'Detector empty pipe' function. Not configurable for sizes:</p> <p>1 mm 1/25 in 1.5 mm 1/17 in 2 mm 1/12 in 3 mm 1/10 in 4 mm 5/32 in 6 mm 1/4 in 8 mm 5/16 in</p> <p>Note</p> <p>The 'empty pipe' function is not available for flowmeter sensors with preamplifiers. The menu is hidden.</p>

Submenu / parameter	Value range	Remark
<div>DLR Mode</div> <div>Standard</div>	Standard New adjustment	Selection of operating mode for empty tube detection. <ul style="list-style-type: none"> Standard: Factory adjustment to water, appropriate for most measuring media. New adjustment: Start new adjustment to the current medium. Note During adjustment, the pipe must be empty and fill afterwards. Not displayed, if DEP is switched off.
<div>Adj. DLR empty</div> <div>1000</div>	Manual Automatic	Menu visible when 'New adjustment' is selected in the 'DLR Mode' parameter. Adjustment value for empty meter pipe. The pipeline must be empty. <ul style="list-style-type: none"> Automatic: Start the empty tube adjustment. After the adjustment is completed, the transmitter displays the adjustment value in the bottom line. Manual: Fine adjustment of the automatically determined adjustment value. Not displayed, if DEP is switched off or DEP mode is standard.
<div>Adj. DLR full</div> <div>500</div>	Manual Automatic	Menu visible when 'New adjustment' is selected in the 'DLR Mode' parameter. Adjustment value for full meter pipe. The piping must be completely filled. <ul style="list-style-type: none"> Automatic: Start the adjustment. After the adjustment is completed, the transmitter displays the adjustment value in the bottom line. Manual: Fine adjustment of the automatically determined adjustment value. Not displayed, if DEP is switched off or DEP mode is standard.

... 8 Operation

... Parameter descriptions

Submenu / parameter	Value range	Remark
<div><div>Switching threshold</div><div>100000</div></div>	Numerical entry	<p>Menu visible when 'New adjustment' is selected in the 'DLR Mode' parameter. Switching threshold for turning off the 'Empty pipe' function. The switching threshold is calculated by the transmitter from both values 'Adj. DLR empty' and 'Adj. DLR full'.</p> <p>The calculated value can be changed here for fine adjustment in the range from 100 to 1000000.</p> <p>Not displayed, if DEP is switched off or DEP mode is standard.</p>
<div><div>Alarm e. pipe:</div><div>Off</div></div>	Off A	<p>If the alarm is switched on, the empty pipe contact is actuated when the pipe empties. The 'empty pipe' or 'General alarm' switch output must be selected in the 'Switch contacts' submenu. When the function is turned off, the alarm does not respond.</p> <p>Not displayed, if DEP is switched off.</p>
<div><div>lout for e. pipe</div><div>Low Alarm</div></div>	Low Alarm High alarm 0 %	<p>Set the current output value to Low or High in event of error.</p> <p>Not displayed, if DEP is switched off.</p>

Submenu / parameter	Value range	Remark
<div data-bbox="81 369 323 438"> Submenu Display </div> <div data-bbox="240 533 483 602"> Display mode 1 big, 1 small </div> <div data-bbox="240 665 483 735"> Display 1st line Q [Percent] </div> <div data-bbox="240 1272 483 1341"> Display 1st line PA Addr + State </div>	<div data-bbox="691 541 815 598"> 1 big, 1 small, 4 small </div> <div data-bbox="691 674 914 1241"> Q [percent]; Q [Unit]; Iout [mA]; Q [m/s]; Q BargraphTotalizer; Totalizer → V; Totalizer ← R; Totalizer Diff.; HART TAGDetector I.pipe Blank line Additional selection for extended diagnosis: Fprt1; Fprt2; Fprt3; Fprt4; Hist Max Error; Hist Min Error; Curr Max Error; Curr Min Error; Curr Max Warn; Curr Min Warn; Wiring. Warning; Wiring Failure </div>	<div data-bbox="930 380 1497 468"> Select each different line displayed for the process indicators in this submenu. You can also adapt the contrast of the display to local conditions by pressing the arrow keys. </div> <div data-bbox="930 541 1310 567"> Select 1 big and 1 small line or 4 small lines. </div> <div data-bbox="930 674 1509 793"> Selection of 1st display line Notes regarding the measured values Fprt1 to Fprt4 (assignment of measured values in the submenu Diagnosis / Fingerprint) as well as the diagnosis error register, see page 97. </div> <div data-bbox="930 1283 1501 1497"> Devices with PROFIBUS PA, in addition to the following options: Flow rate in percentage, Physical unit, in m/s, Bar graph, Totalizer, Totalizer → F, Totalizer ← R, Totalizer diff., Detector empty tube; have additional options: PA Addr+State. The bus address and status of cyclic communication is displayed (STOP, CLEAR or OPERATE) is displayed. </div>

... 8 Operation

... Parameter descriptions

Submenu / parameter	Value range	Remark
<div>Display 1st line TB VolFlow Value</div>		TB VolFlow Value. Displays the value for Volume_Flow (Transducer block Index 17).
<div>Display 1st line TB VolFlow Status</div>		TB VolFlow Status. Displays the status of Volume_Flow (Transducer block Index 17).
<div>Display 1st line TBT → Value</div>		TB Total → F Value. Displays the value for Totalizer → F (Transducer block Index 102).
<div>Display 1st line TBT → Status</div>		TB Total → Status. Displays the status of the Totalizer → F (Transducer block Index 102).
		TB Total ← R Value. Displays the value for Totalizer ← R (Transducer block Index 104).
		TB Total ← R Status. Displays the status of Totalizer ← R (Transducer block Index 104).
		TB Total Diff Value. Displays the value for the diff. totalizer (Transducer block Index 106).
		TB Total Diff Status. Displays the status of the diff. totalizer (Transducer block Index 106).
<div>Display 1st line FB AI OUT</div>		FB AI OUT. Displays the OUT value of the AI block. The decimal places are generated from the OUT_SCALE structure. The unit displayed is UNIT_INDEX from the OUT_SCALE structure.
<div>Display 1st line FB AI Status.</div>		FB AI Status. Displays the current mode of the particular block and the status of the output variables (OUT. Status). The substatus is displayed after the status, if applicable. Example: BAD 3 means status is BAD, substatus 3 = device failure. For information about the numeric code, refer to the interface documentation.

Submenu / parameter	Value range	Remark
<div>Display 1st line TBT → Value</div>		<p>FB TOT1 Total. Displays the total value for the totalizer block. The displayed unit is UNIT_TOTAL.</p> <p>FB TOT1 Status. Displays the current mode of the particular block and the status of the output variables (Total. Status). The substatus is displayed after the status, if applicable. Example: BAD 3 means status is BAD, substatus 3 = device failure.</p> <p>FB TOT2 Total. Displays the total value for the totalizer block. The displayed unit is UNIT_TOTAL.</p> <p>FB TOT2 Status. Displays the current mode of the particular block and the status of the output variables (Total. Status). The substatus is displayed after the status, if applicable. Example: BAD 3 means status is BAD, substatus 3 = device failure. For information about the numeric code, refer to the interface documentation.</p>
<div>Display 1st line TBT → Status</div>		<p>Devices with FOUNDATION Fieldbus, in addition to the following options: Flow rate in percentage, Physical unit, in m/s, Bar graph, Totalizer, Totalizer → F, Totalizer ← R, Totalizer diff., Detector empty tube; have additional options: FF address, this is displayed hexadecimal.</p>
<div>Display 1st line TB VolFlowValue</div>		<p>Displays the value or status of the flowrate (TB Primary_Value, Index 14).</p>
<div>Display 1st line TB Total → F Value.</div>		<p>Displays the value or status of the totalizer →Forward (TB Secondary_Value, Index 28).</p>
<div>Display 1st line TB Total ← R Value.</div>		<p>Displays the value or status of the Totalizer ← R (TB Third_Value, Index 30).</p>

... 8 Operation

... Parameter descriptions

Submenu / parameter	Value range	Remark
<div>Display 1st line</div> <div>TB TotalDiffValue</div>		Displays the value or status of the totalizer (TB Fourth_Value, Index 31).
<div>Display 1st line</div> <div>TB AI1 Out. Value</div>		Displays the value or status of the Out parameter for the function block AI1.
<div>Display 1st line</div> <div>TB AI2 Out. Value</div>		Displays the value or status of the Out parameter for the function block AI2.
<div>Display 1st line</div> <div>TB AI3 Out. Value</div>		Displays the value or status of the Out parameter for the function block AI3.
<div>Display 1st line</div> <div>PID In. Value</div>		Displays the value or status of the In parameter for the function block PID.
<div>Display 1st line</div> <div>PID Out. Value</div>		Displays the value or status of the Out parameter for the function block PID.
<div>Display 1st line</div> <div>PID Cas_In. Value</div>		Displays the value or status of the parameter Cas_In for the function block PID.
<div>Display 1st line</div> <div>PID FF_Val.Value</div>		Displays the value or status of the parameter FF_Val for the function block PID.

Submenu / parameter	Value range	Remark
<div>Display 1st line</div> <div>PID Trk_Value</div>		Displays the value or status of the parameter Trk_Val for the function block PID.
<div>Display 1st line</div> <div>TB VolF GOOD0</div>		The status is displayed in plain text format, the substatus in numeric form after the status.
<div>Display 1st line</div> <div>AI1 Auto GOOD0</div>		Displays the current mode for the function blocks.
<div>Display 2nd line</div> <div>Q [Percent]</div>	Like display 1st line	Selection of 2nd display line
<div>Display 3rd line</div> <div>Q [Percent]</div>	Like display 1st line	Option unavailable if 1 big, 1 small is selected for the display mode
<div>Display 4th line</div> <div>Q [Percent]</div>	Like display 1st line	Option unavailable if 1 big, 1 small is selected for the display mode
<div>Contrast</div>		Set the contrast for the display to adjust to local conditions, STEP = darker; DATA = lighter. Note Adjust the contrast so that the display remains readable.

... 8 Operation

... Parameter descriptions

Submenu / parameter	Value range	Remark
<div> <div>Submenu Alarm</div> <div> <div>Min. alarm 0 %</div> <div>Max. alarm 100 %</div> </div> </div>	<div>Numerical entry 0% – Max. Alarm</div> <div>Numerical entry Min. Alarm – 103%</div>	<div>Range limit for the Min. Alarm 0% – Max. Alarm of configured measuring range. Configurable in 1% increments, 1% switching hysteresis.</div> <div>Range limit for the Max. Alarm Min. Alarm – 103% of configured measuring range. Configurable in 1% increments, 1% switching hysteresis.</div>
<div>Submenu Counter</div> <div> <div>Overflow → F 0</div> </div>	<div>Read only</div>	<div> <p>The totalizer function is set automatically in the 'Operating mode' submenu. Standard operating mode = standard totalizer function, Piston pump operating mode = Totalizer function Diff. totalizer.</p> <p>Standard = For the standard totalizer function, the counting pulse for forward and reverse flow is registered on two separate totalizers. If Forward is selected as flow direction, only the forwards totalizer counts.</p> <p>Diff. totalizer = For differential count, a shared totalizer is used for both flow directions. For the forward flow direction, the pulses are added, for the reverse flow direction, they are subtracted. If the totalizer count is negative, i.e. the reverse flow amount is greater than the forward flow amount, the direction indicator on the display changes from "F" to "R". The pulse output (active or passive) is not affected by this setting.</p> </div> <div> <p>Overflow totalizer max. 65535. 1 overflow = pulse totalizer 9,999,999 units. Resets the display status and increments the overflow counter by one. Overflow example:</p> <p>Overflow 012 12 x 10,000,000 units = 120,000,000 units + 23,455 current totalizer value results in a total of 120,023,455 units</p> </div>

Submenu / parameter	Value range	Remark
<div>Totalizer → F 0.0 kg/h</div> <div>Overflow ← R 0</div> <div>Totalizer ← R 0</div> <div>Reset totalizer</div> <div>Overflow Diff. 0</div> <div>Totalizer Diff. 0.0 kg/h</div>	<div>Numerical entry 0 ... 9999999</div> <div>Read only</div> <div>Numerical entry 0 ... 9999999</div> <div></div> <div>Read only</div> <div>Numerical entry 0 ... 9999999</div>	<div>Display or input the forward totalizer value.</div> <div>Overflow totalizer max. 65535. 1 overflow = pulse totalizer 9,999,999 units. Resets the display status and increments the overflow counter by one.</div> <div>Display or input the reverse flow totalizer value.</div> <div>Select ENTER to reset the forward/reverse flow totalizer and overflow counters.</div> <div>Display the overflow for the diff. totalizer.</div> <div>Display or input the diff. totalizer value.</div>
<div>Submenu Current output</div> <div>Current output 0 - 20 mA</div> <div>lout for alarm Low Alarm</div> <div>lout low alarm 3.60 mA</div>	<div></div> <div>0 - 20 mA, 4 - 20 mA 0 - 10 mA, 2 - 10 mA</div> <div>Low Alarm High alarm</div> <div>Numerical entry</div>	<div>This menu does not appear for the PROFIBUS PA or FOUNDATION fieldbus.</div> <div>Select the current output range. For HART protocol always 4 - 20 mA.</div> <div>Behavior of the current output during an alarm. Low-Alarm is available only for current output of 2 - 10 mA and 4 - 20 mA. If error 0 (empty tube) occurs, the current output is set to the value programmed for the parameter 'lout during empty tube' in the submenu 'Detector empty tube'. If error 3 (flow rate > 103 %) occurs, 'High Alarm' is always signaled.</div> <div>Low-Alarm is available only for current output of 2 -10 mA or 4 - 20 mA. Set the current output value during Low Alarm condition. No selection available if High Alarm is selected for the current output selection for lout during alarm and if the transmitter version is standard and the current output range is 0 - 20 mA 0 - 10 mA .</div>

... 8 Operation

... Parameter descriptions

Submenu / parameter		Value range	Remark
<div>Submenu</div> <div>Pulse output</div>	<div>Iout high Alarm</div> <div>21.80 mA</div>	Numerical entry	Set the current output value during High Alarm condition. If error 3 (flow rate > 103 %) occurs, 'High Alarm' is always signaled. No selection available for current output if Low Alarm is selected for Iout during Alarm.
	<div>Error 3 mask</div> <div>Off</div>	Off, On	Deactivates error 3 (flowrate > 103%), if masking = on
	<div>Error 4 mask</div> <div>Off</div>	Off, On	Deactivates error 4 (ext. zero return), if masking = on
	<div>Qmax pulse</div> <div>2.5 m³/h</div>	Numerical entry	Expanded flow totalization to the maximum flow range Qmax DN. This parameter is displayed only if the measuring range specified is less than Qmax DN.
	<div>Pulse factor</div> <div>100/m³</div>	Numerical entry Dynamic limits	The pulse width is configurable only for the limits calculated by the transmitter. The limits are based on the pulse factor. The transmitter cannot leave the max. limits of 2000 ms and 0.1 ms.
	<div>Pulse width</div> <div>0.1 ms</div>	Numerical entry Dynamic limits	The pulse width is configurable only for the limits calculated by the transmitter. The limits are based on the pulse factor. The transmitter cannot leave the max. limits of 2000 ms and 0.1 ms.
	<div>Pulse (Act./Pas.)</div> <div>Active</div>	Read only	Displays the 'active' or 'passive' jumper position see also page 47.

Submenu / parameter	Value range	Remark
<div> <div>Submenu</div> <div> <div>Progr. Input/output</div> <div> <div>Switch input</div> <div>No function</div> </div> <div> <div>Switch output</div> <div>No function</div> </div> </div> </div>	<div>No function</div> <div>Totalizer reset</div> <div>Ext. cut-off</div> <div>Ext. Syst. NP.</div> <div>No function</div> <div>F/R signal /_</div> <div>F/R Signal __</div> <div>General Alarm /_</div> <div>General Alarm __</div> <div>Max/Min Alarm/_</div> <div>Max/Min Alarm __</div> <div>Min Alarm /_</div> <div>Min Alarm __</div> <div>Max Alarm /_</div> <div>Max Alarm __</div> <div>Empty Pipe /_</div> <div>Empty Pipe __</div> <div>Ext. Diag. Alarm /_</div> <div>Ext. Diag. Alarm __</div>	<div>The contact input function is not displayed for PROFIBUS PA or FOUNDATION Fieldbus.</div> <div>Selection of the function for switch input terminals 81/82.</div> <div>'Totalizer Reset' resets the internal totalizer and counter overflows by connecting a switching voltage. For 'Ext. Zero Return' all outputs are switched off, if a switching voltage is connected. Example of use: undefined filled meter tube condition after turning off pumps or cyclic cleaning or flushing procedures, the measured values of which must be hidden.</div> <div>Select 'Ext. Syst. NP' to adjust the system zero point. The fluid must be at absolute standstill during the adjustment. The message 'Warning 13' is displayed during the adjustment.</div> <div>The switching behavior for the contact outputs (terminal 41/42) can be selected as normally open (/_ _) or normally closed (_ _).</div> <div>For the 'General Alarm' all detected errors (0 - 6, A, B, C, D, E, F, G) are signaled via the terminals. Select "Ext. Diag. Alarm" to signal only diagnosis errors that have occurred. If you want to report a low flow condition, select 'Min Alarm'. Similarly, a high flow condition is signaled with 'Max Alarm'. If the signal is set for 'Max/Min Alarm', then a signal is sent over the terminals when the flow rate is above or below the range between the 'Max-Alarm' value and the 'Min-Alarm' value, i.e., when the flow rate is larger than the 'Max-Alarm' value or less than the 'Min-Alarm' value.</div>

... Parameter descriptions

Submenu / parameter	Value range	Remark
Submenu Identifier		
Curr. Variant	Read only Active pulse without HART Active pulse with HART Passive pulse without HART Passive pulse with HART PROFIBUS PA FOUNDATION Fieldbus FF Variant error	Displays the pulse output and communication configuration for the shipped model.
Sensor TAG '_____'	User-defined text	A TAG number to identify the flowmeter sensor, max. 32-character limit.
Transmitter TAG '_____'	User-defined text	A TAG number to identify the transmitter, max. 32-character limit.
Submenu Interface		
Communication without	Without HART	1. HART communication Set the HART communication to ON or OFF. When HART communication is not required, Current Output ranges 0-20, 0-10, 2-10 mA can be selected. For HART communication, the current output is always 4 - 20 mA. No selection available for standard devices (without HART hardware).
Device address 0	Numerical entry 0 ... 15	For devices with HART protocol, an address between 0 ... 15 can be selected. If Address 0 is entered, the current output for the flow rate will also change by 4 - 20 mA. If more devices are connected to the bus and the address 1 - 15 is selected, the transmitter will work in multidrop mode. The current output value then remains frozen at 4 mA. In this case, the output values can only be read using HART communication. Warning 11 is displayed. No entry for standard devices (without HART hardware).

Submenu / parameter	Value range	Remark
<div data-bbox="240 369 483 436">HART TAG 'HART TAG'</div>	User-defined text	Unique identifier for unit using HART TAG number. Max. 8-character TAG number (PCKASCII string). Only capital letters are recognized, no special characters can be used. No entry for standard devices (without HART hardware).
<div data-bbox="240 562 483 630">HART descriptor 'HART descriptor'</div>	User-defined text	Description max. 16-character (PCKASCII string). Only capital letters are recognized, no special characters can be used. No entry for standard devices (without HART hardware).
<div data-bbox="240 758 483 825">HART Date 11/3/2003</div>	Day Month year	Enter and output a date in this submenu. No entry for standard devices (without HART hardware).

... 8 Operation

... Parameter descriptions

Submenu / parameter	Value range	Remark
<div>PA Address</div> <div>126</div>	Numeric entry 0 - 125	<p>2. PROFIBUS PA communication</p> <p>Only available if PROFIBUS PA version was ordered.</p> <p>Display of the slave address. Factory setting 126 (valid addresses 0 - 125). The PA address can be set via the following functions: Hardware switch (see page 50), Bus or the PA Address menu. The hardware switch has highest priority. The hardware switch setting has the highest priority. An address using this setting switch cannot be changed, either by bus or menu. If the switch address is not active (DIP switch 8 = off), the address can be changed via the bus or via the menu, however, only when no cyclical communication is running.</p>
<div>Dip Switch</div> <div>123456789A</div> <div>-----</div>	Read only	<p>Displays the settings for the DIP switches (- = OFF, X = ON).</p> <p>If DIP switch 8 = ON, the address is binary coded using switches 1 - 7. Switches 9 and A have no function. Example: Use switches to set address 50. 50dec = 32hex = 110010 binary → DIP switch 2, 5, 6 and 8 to ON = PA Address 50. The address switch setting is only adopted when the device is restarted, not during running operation. The factory setting of the switch is: OFF</p>
<div>IdentNo Selector</div> <div>FSM4000 0x078C</div> <div>AI + 2* TOT</div>		<p>Setting the ID no. for the selector. Modes can only be changed when in STOP and not during cyclic communication.</p> <p>Profile 0x078C: AI + 2* TOT (AI-Block + 2 Totalizer).</p>
<div>IdentNo Selector</div> <div>Profile 0x9700</div> <div>AI</div>		<p>Profil 0x9700 (AI-Block)</p>
<div>IdentNo Selector</div> <div>Profile 0x9700</div> <div>AI + TOT</div>		<p>Profile 0x9740 (AI-Block + Totalizer)</p>

Submenu / parameter	Value range	Remark
<div> <div>AI Channel</div> <div>TB Flow Value</div> </div> <div> <div>AI Channel</div> <div>TB Total → F</div> </div> <div> <div>AI Channel</div> <div>TB Total ← R</div> </div> <div> <div>AI Channel</div> <div>TB Diff Total</div> </div> <div> <div>TOT 1 Channel</div> <div>TB Flow Value</div> </div> <div> <div>TOT 2 Channel</div> <div>TB Flow Value</div> </div> <div> <div>Software Rev.</div> <div>Communication: 0</div> </div> <div> <div>FF Address 0x15</div> <div>Dev-ID</div> <div>0003200017_FSM40</div> <div>00_12345</div> </div>	<div>Read only</div>	<p>Channel setting for AI block. When setting the channel, the unit for the channel is also copied to the AI block (from OUT_SCALE. UNIT_INDEX).</p> <p>Selection:</p> <p>TB (Transducer Block) Flow Value</p> <p>TB Total → F</p> <p>TB Total ← R</p> <p>TB Diff Total</p> <p>Channel setting for totalizer block.</p> <p>Available only as option TB Flow Value. When setting the channel, the volume and mass unit is also copied to UNIT_TOT (example: m³/h → m³).</p> <p>See TOT 1.</p> <p>Displays the communication software version.</p> <p>3. FOUNDATION Fieldbus communication.</p> <p>Displays the address and device ID:</p> <p>000320 = manuf. code ABB, hex</p> <p>0017 = Device Type Code FSM4000, hex</p> <p>_FSM4000_ = Device name</p> <p>12345 = serial number of device, 5-digit</p>

... 8 Operation

... Parameter descriptions

Submenu / parameter	Value range	Remark
<div> <div>Dip Switch</div> <div> IdentNo Selector Profile 0x9700 AI </div> </div> <div> <div>Error Mask</div> <div> Bitstring 0 ON EF0F0000 Error A Max Alarm </div> </div> <div> <div>Warning Mask</div> <div> Bitstring 0 OFF 020000100 Warning: 10 Reverse Q </div> </div> <div> <div>Software Rev. Communication: 1</div> </div>	<div>Read only</div>	<p>Hardware switch.</p> <p>There is a 10-position DIP switch in the transmitter. It can be accessed after opening the cover of the housing. The switch position is displayed on the device in the data link submenu. It can also be read via the FF communication in the transducer block. An open switch is shown as – while a closed switch as x. The following switches are assigned: Switch 1 = Simulate Enable off = Simulation mode disable on = Simulation Mode enabled. Switch 2 = Write Protect Off = Simulation Mode disabled on = Write protect enabled. 'Simulation mode enabled' only allows you to run a AI block simulation. The simulation is switched on/off via the 'Simulate' parameter. 'Write protect enabled' prevents overwriting of block parameters. Switches 3-10 have no function.</p> <p>This menu shows the screen for the error register (TB Index 95).</p> <p>Line 1 shows the setting of the bit (on/off), which is indicated by its bitstring number. Line 2 shows the complete screen in hex characters. Lines 3 and 4 provide plaintext descriptions of each bit. Select the bits via the keys Data and Step, and select ENTER to switch the bit on/off.</p> <p>See also the 'Error Register' in the interface description D184B093U31.</p> <p>This menu shows the screen for the warning register (TB Index 96).</p> <p>Operation is identical to Error screen. See Warning Register 9.8.3 and interface description D184B093U31, page 47.</p> <p>Displays the communication software version.</p>

Submenu / parameter	Value range	Remark
<div data-bbox="81 369 323 436"> Submenu Function test </div> <div data-bbox="240 562 483 630"> Memory Test </div> <div data-bbox="240 693 483 760"> Pulse output 0 Hz </div> <div data-bbox="240 856 483 924"> Current output 4 mA </div> <div data-bbox="240 1121 483 1188"> Contact input Off </div> <div data-bbox="240 1348 483 1415"> Switch output Off </div> <div data-bbox="240 1512 483 1579"> Display </div> <div data-bbox="240 1675 483 1743"> Test Mode Off </div>	<div data-bbox="683 701 836 726">Numerical entry</div> <div data-bbox="683 865 895 919">0 - 20 mA, 4 - 20 mA 0 - 10 mA, 2 - 10 mA</div> <div data-bbox="683 1129 724 1184">Off A</div> <div data-bbox="683 1356 724 1411">Off A</div> <div data-bbox="683 1684 724 1738">Off A</div>	<div data-bbox="919 378 1517 1709"> <p>Note</p> <p>Once the self-test function is initiated, the transmitter no longer operates in online mode, i.e., the outputs no longer track the flowrate.</p> <p>Test the memory. Internal FRAM, ext. FRAM and calc. Flash can be queried in order via ENTER function.</p> <p>This menu does not appear for the PROFIBUS PA or FOUNDATION fieldbus.</p> <p>Test the pulse output. Enter a value directly in Hz.</p> <p>This menu does not appear for the PROFIBUS PA or FOUNDATION fieldbus.</p> <p>Test the current output. Check the value displayed at the connection terminals using a digital voltmeter or the process instrumentation. Enter a value directly in mA.</p> <p>No selection available if the HART device address is anything other than 0.</p> <p>This menu does not appear for the PROFIBUS PA or FOUNDATION fieldbus.</p> <p>Test the contact input. If no signal is applied to the switch input, the text 'Off' is displayed in this menu. Once a signal is applied, the text 'On' is displayed (to check via simulator, use the Totalizer Reset button).</p> <p>Test the contact output. When you set the value to 'On', the switch output selected is displayed for the configured contact logic under the item Switch Contacts - Switch Output.</p> <p>Test the display. Every point in the dot matrix is activated one after another. Once all points are activated, a missing point is easily detected.</p> <p>Only for checking the transmitter using Simulator 55XC4000.</p> </div>

... 8 Operation

... Parameter descriptions

Submenu / parameter		Value range	Remark
<div> <div>Submenu Diagnosis</div> <div> <div>Simulation Mode Off</div> <div>Simulation Value 0.0 %</div> </div> <div> <div>Diagnosis Manual</div> <div> <div>Start? Yes → Enter</div> <div> <div>Submenu Diag. Interval</div> <div>Cycle Time Manual</div> </div> </div> </div> </div>		Off A	On/Off function for Simulation mode. Before operation with flow, a flowrate can be simulated. The output values correspond to the simulated flowrate entered. The information ** Q Simulation** is displayed in the lower line of the display. After completing the simulation, change the parameter in the Simulation Mode menu to 'Off'.
		Numerical entry -130 % - +130 %	Select the simulation value for the display and outputs. Current and pulse output follow the flowrate value.
			Menu available only if the required hardware is available.
			Menu is displayed only with 'Manual' diagnosis interval.
		Yes, exit via C/CE	Manually start manual diagnostic. The value is displayed after a delay of 30 s.
		Manual; 10 s; 60 s; 10 min; 60 min; 6 h; 12 h; 24 h; 7 d	<p>Select the time interval between the individual diagnostic measurements. For the values for Coil Resistance, Coil Temperature, Insulation Resistance, and Magnetic Linearity, however, there are minimum measurement intervals for technical reasons related to the measurement:</p> <ul style="list-style-type: none"> • 60 seconds for Coil Resistance and Coil Temperature • 5 minutes for Magnetic Linearity • 10 minutes for measurement of Insulation Resistance <p>These times are not undershot independently of the configured diagnostic cyclic.</p>

Submenu / parameter	Value range	Remark
<div> <div>Submenu</div> <div>Alarm Settings</div> </div>		In this menu you can set minimum and maximum values for each measurement value. Depending on the selected configuration, you can select for no message, a warning, or an error message to be displayed, if the value falls below or exceeds this threshold.
<div> <div>Submenu</div> <div>Alarm Coil Voltage</div> </div>		Set the time-out limits and alarm behavior for values over or under the coil AC voltage.
<div> <div>Min. value</div> <div>1.0 V</div> </div>	0 ... 150	Lower range limit for alarm
<div> <div>Max. value</div> <div>150 V</div> </div>	0 ... 150	Upper range limit for alarm
<div> <div>Message</div> <div>Off</div> </div>	Off, warning, error	Defines the alarm behavior
<div> <div>Submenu</div> <div>Alarm Coil Current</div> </div>		Set the time-out limits and alarm behavior for values over or under the coil AC.
<div> <div>Min. value</div> <div>20.0 mA</div> </div>	0 ... 500	Lower range limit for alarm.
<div> <div>Max. value</div> <div>500.0 mA</div> </div>	0 ... 500	Upper range limit for alarm.
<div> <div>Message</div> <div>Off</div> </div>	Off, warning, error	Defines the alarm behavior.

... 8 Operation

... Parameter descriptions

Submenu / parameter		Value range	Remark
	<div>Submenu</div> <div>Alarm Coil Resist</div>		Set the time-out limits and alarm behavior for values over or under the coil resistance. Notice: To correctly display the coil resistance or coil temperature, an adjustment is required or the cable length must be entered. For additional information, see 'Submenu Adjustment' on page 93.
	<div>Min. value</div> <div>2 ohms</div>	0 ... 1500	Lower range limit for alarm.
	<div>Max. value</div> <div>500 ohms</div>	0 ... 500	Upper range limit for alarm.
	<div>Message</div> <div>Off</div>	Off, warning, error	Defines the alarm behavior. Notice: If coil resistance is being measured (at least every 60 s), the most recently acquired flow rate is retained during the measurement (2 s approx.).

Submenu / parameter		Value range	Remark
	<div> <div>Submenu</div> <div>Alarm Coil Temp</div> </div>		<p>Set the time-out limits and alarm behavior for values over or under the coil temperature.</p> <p>Notice: To correctly display the coil resistance or coil temperature, an adjustment is required or the cable length must be entered. For additional information, see 'Submenu Adjustment' on page 93.</p>
	<div> <div>Min. value</div> <div>-50 °C</div> </div>	-100 ... 200	Lower range limit for alarm.
	<div> <div>Max. value</div> <div>200 °C</div> </div>	-100 ... 200	Upper range limit for alarm.
	<div> <div>Message</div> <div>Off</div> </div>	Off, warning, error	<p>Defines the alarm behavior.</p> <p>Notice: If coil resistance is being measured (at least every 60 s), the most recently acquired flow rate is retained during the measurement (2 s approx.).</p>
	<div> <div>Submenu</div> <div>Alarm Ins Resist</div> </div>		Set the time-out limits and alarm behavior for values over or under the coil temperature.
	<div> <div>Min. value</div> <div>1 megaohm</div> </div>	0 ... 100000	Lower range limit for alarm.
	<div> <div>Max. value</div> <div>50 megaohm</div> </div>	0 ... 100000	Upper range limit for alarm.
	<div> <div>Message</div> <div>Off</div> </div>	Off, warning, error	<p>Defines the alarm behavior.</p> <p>Notice: If coil insulation resistance is being measured (at least every 10 minutes), the most recently acquired flow rate is retained during the measurement (2 s approx.).</p>

... 8 Operation

... Parameter descriptions

Submenu / parameter		Value range	Remark
	<div> <div>Submenu</div> <div>Alarm E1 Voltage</div> </div>		Set the time-out limits and alarm behavior for values over or under the electrode AC voltage for electrode E1.
	<div> <div>Min. value</div> <div>0.0 μV</div> </div>	0 ... 3000	Lower range limit for alarm.
	<div> <div>Max. value</div> <div>3000.0 μV</div> </div>	0 ... 3000	Upper range limit for alarm.
	<div> <div>Message</div> <div>Off</div> </div>	Off, warning, error	Defines the alarm behavior. Notice: To properly display the electrode voltage, the electrode zero point must be adjusted. For additional information, see 'Submenu Adjustment' on page 93.
	<div> <div>Submenu</div> <div>Alarm E2 Voltage</div> </div>		Set the time-out limits and alarm behavior for values over or under the electrode AC voltage for electrode E2.
	<div> <div>Min. value</div> <div>0.0 μV</div> </div>	0 ... 3000	Lower range limit for alarm.
	<div> <div>Max. value</div> <div>3000.0 μV</div> </div>	0 ... 3000	Upper range limit for alarm.
	<div> <div>Message</div> <div>Off</div> </div>	Off, warning, error	Defines the alarm behavior. Notice: To properly display the electrode voltage, the electrode zero point must be adjusted. For additional information, see 'Submenu Adjustment' on page 93.

Submenu / parameter		Value range	Remark
	<div> <div>Submenu</div> <div>Alarm Elec Bal</div> </div>		<p>Set the time-out limits and alarm behavior for values over or under the electrode balance.</p> <p>The electrode balance is calculated as the ratio between the electrode AC voltages E1/E2. This value is displayed in [%]. If the electrode voltage E2 is larger than E1, the value is assigned a minus sign and the ratio E2/E1 is displayed.</p>
		<div> <div>Min. value</div> <div>0.0 %</div> </div>	<div>100 ... 300</div> <div>Lower range limit for alarm.</div>
		<div> <div>Max. value</div> <div>300.0 %</div> </div>	<div>100 ... 300</div> <div>Upper range limit for alarm.</div>
		<div> <div>Message</div> <div>Off</div> </div>	<div>Off, warning, error</div> <div>Defines the alarm behavior.</div> <p>Notice: To properly display the electrode voltage, the electrode zero point must be adjusted. For additional information, see 'Submenu Adjustment' on page 93.</p>
	<div> <div>Submenu</div> <div>Alarm Mag Lin</div> </div>		<p>Set the time-out limits and alarm behavior for values over or under the magnetic linearity.</p>
		<div> <div>Min. value</div> <div>0.0 %</div> </div>	<div>0 ... 100</div> <div>Lower range limit for alarm.</div>
		<div> <div>Max. value</div> <div>100.0 %</div> </div>	<div>0 ... 100</div> <div>Upper range limit for alarm.</div>
		<div> <div>Message</div> <div>Off</div> </div>	<div>Off, warning, error</div> <div>Defines the alarm behavior.</div> <p>Notice: If magnetic linearity is being measured (at least every 5 minutes), the most recently acquired flow rate during the measurement is retained (approx. 2 s).</p>

... 8 Operation

... Parameter descriptions

Submenu / parameter		Value range	Remark
	<div><div>Submenu Alarm SNR</div><div>Min. value 0.0 %</div><div>Max. value 100.0 %</div><div>Message Off</div><div>Submenu Alarm DAC Value</div><div>Min. value 16</div><div>Max. value 700</div><div>Message Off</div></div>		Set the time-out limits and alarm behavior for values over or under the signal-to-noise ratio.
		0 ... 100	Lower range limit for alarm.
		0 ... 100	Upper range limit for alarm.
		Off, warning, error	Defines the alarm behavior.
			Set the time-out limits and alarm behavior for values over or under the DAC value. The DAC value is a criterion for the amount of coil current.
		0 ... 1024	Lower range limit for alarm.
		0 ... 1024	Upper range limit for alarm.
		Off, warning, error	Defines the alarm behavior.

Submenu / parameter	Value range	Remark
<div data-bbox="384 369 616 436"> Submenu Alarm Factory Set </div> <div data-bbox="464 468 616 535"> Accept Yes → Enter </div> <div data-bbox="233 600 464 667"> Submenu Wired-on. Failure </div> <div data-bbox="384 699 616 766"> Submenu CoilShtCircGnd </div> <div data-bbox="464 898 616 966"> Message Off </div> <div data-bbox="384 997 616 1064"> Submenu Electrode State </div> <div data-bbox="464 1194 616 1262"> Message Off </div>	<p data-bbox="667 478 818 501">Yes, exit via C/CE</p> <p data-bbox="667 905 826 928">Off, warning, error</p> <p data-bbox="667 1203 826 1226">Off, warning, error</p>	<p data-bbox="890 380 1398 432">Sets the status of all alarms to 'Off' and the alarms to the default values.</p> <p data-bbox="890 709 1414 732">Defines alarm behavior in case of an accidental coil ground.</p> <p data-bbox="890 774 1441 861">Notice: If the coil circuit is being checked (at least every 10 minutes) for an accidental ground, the most recently acquired flow rate is maintained (approx. 2 s).</p> <p data-bbox="890 1005 1390 1058">Defines alarm behavior in case of a short circuit or a wire break in the electrode circuit.</p> <p data-bbox="890 1071 1441 1157">Notice: This function can only be used after the electrode zero has been adjusted. For additional information, see 'Submenu Adjustment' on page 93.</p>

... 8 Operation

... Parameter descriptions

Submenu / parameter	Value range	Remark
<div><div>Submenu Fingerprint</div><div><div>Submenu Fprt1</div><div><div>Diagnostic Value AC Volt. coil</div><div><div>Data set Current</div><div>Submenu Fprt4</div></div></div></div></div>	<div>AC Volt. coil; AC Current coil; ohm. res. coil; Temp. coil; ins. res. coil; Volt. E1; Volt. E2; Electr. balan.; Magn. linear; SNR noise ratio; Max. DAC value; Oprtg. hrs trn; Oprtg. hrs sens</div> <div>Current; Prod1; Prod2; Startup; Factory; Hist1; Hist2; Hist3; Hist4; Hist5; Hist6; Hist7; Hist8; Hist9</div> <div>As for Fprt1</div>	<div>Preselect the diagnostic measurement values that you want to display and manage in the Fingerprint data.</div> <div>Assign the rate for Fprt1. The display line for the process indicator is assigned in the submenu.</div> <div>Select the value: <div><div>AC Volt. Coil:</div><div>Coil voltage AC</div></div><div><div>AC Current Coil:</div><div>Coil current AC</div></div><div><div>ohm. res. Coil:</div><div>Ohmic resistance of coil</div></div><div><div>Temp. coil:</div><div>Coil temperature</div></div><div><div>ins. res. Coil:</div><div>Insulation resistance of coil</div></div><div><div>Volt. E1:</div><div>AC voltage at electrode 1</div></div><div><div>Volt. E2:</div><div>AC voltage at electrode 2</div></div><div><div>Electr. balan.:</div><div>Electrode balance</div></div><div><div>Magn Linear:</div><div>Magnetic linearity</div></div><div><div>SNR Noise ratio:</div><div>Signal-to-noise ratio</div></div><div><div>Max DAC value:</div><div>Maximum DAC value</div></div><div><div>Oprtg. hrs trn::</div><div>Operating hours for transmitter</div></div><div><div>Oprtg. hrs sens::</div><div>Operating hours for sensor</div></div></div> <div>These values are updated only if the status was set to Warning or Error in the 'Alarm Settings' submenu.</div> <div><div>Current:</div><div>Data set for current measured value</div></div> <div><div>Prod1:</div><div>Product1 fingerprint</div></div> <div><div>Prod2:</div><div>Product2 fingerprint</div></div> <div><div>Start-up:</div><div>Commissioning fingerprint</div></div> <div><div>Default:</div><div>Default fingerprint</div></div> <div><div>Hist1-9:</div><div>Data set 1 ... 9 for the preceding measured values</div></div> <div>Assign the rate for Fprt1. The display line for the process indicator is assigned in the submenu.</div>

Submenu / parameter	Value range	Remark
<div data-bbox="233 365 464 438"> Submenu Transfer </div> <div data-bbox="384 501 616 564"> As Product1 </div> <div data-bbox="461 596 616 669"> Accept Yes → Enter </div> <div data-bbox="384 701 616 764"> As Product2 </div> <div data-bbox="461 795 616 869"> Accept Yes → Enter </div> <div data-bbox="384 953 616 1026"> As Startup </div> <div data-bbox="461 1058 616 1131"> Accept Yes → Enter </div> <div data-bbox="233 1152 464 1226"> Submenu Adjustment </div> <div data-bbox="384 1289 616 1352"> Submenu Coil Temp </div> <div data-bbox="461 1383 616 1457"> Temp. in °C 0.0 </div>	<div data-bbox="659 606 820 638">Yes, exit via C/CE</div> <div data-bbox="659 806 820 837">Yes, exit via C/CE</div> <div data-bbox="659 1068 820 1100">Yes, exit via C/CE</div> <div data-bbox="659 1394 756 1425">-100 ... 100</div>	<div data-bbox="882 375 1278 407">Import the current data set in a Fingerprint.</div> <div data-bbox="882 512 1414 543">Copies the current data set in the Fingerprint 'as Product1'.</div> <div data-bbox="882 711 1414 743">Copies the current data set in the Fingerprint 'as Product2'.</div> <div data-bbox="882 974 1414 1037">Copies the current data set in the Fingerprint 'as Start-up' (commissioning fingerprint).</div> <div data-bbox="882 1299 1378 1394">Enter the current coil temperature to readjust the coil resistance at 20 °C. Perform adjustment only on a 'cold' device. See page 97 in this regard.</div>

... 8 Operation

... Parameter descriptions

Submenu / parameter	Value range	Remark
<div> <div>Submenu</div> <div>CabLength</div> <div>Length [m]</div> <div>0.0</div> </div>	0 ... 200	Enter the length of the signal cable. Notice: Information must be entered to calculate the coil resistance / coil temperature.
<div> <div>Submenu</div> <div>Temp. Offset</div> <div>Temp. in °C</div> <div>0.0</div> </div>	-100 ... 100	Offset correction for temperature display.
<div> <div>Import RT20</div> <div> Accept New 500 ohms Old 450 ohms Yes → Enter </div> </div>	Yes, exit C/CE	Import the reference resistance for the coil. See page 97 in this regard. Notice: This menu is displayed only when the coil resistance or coil temperature are enabled as an error or warning message.
<div> <div>Electr. Zero Point</div> <div> Electr. Zero Point New 150 180 µV Old 200 190 µV Yes → Enter </div> </div>	Yes, exit C/CE	This adjustment is required in order to use the diagnostic measurement values for the electrode voltage E1/E2 and the electrode balance as well as the wiring errors for the electrode state. Display the current (new) and stored (old) zero values for electrode E1/E2. Select 'Enter' to import the current zero points Notice: The liquid in the sensor must be at absolute standstill.
<div> <div>Electr. Analysis</div> <div> N1: 12 µV 286° N2: 10 µV 283° A1: 650 µV 133° A2: 670 µV 135° </div> </div>	Yes, exit C/CE	Displays stored electrode zero and current electrode AC voltage acc. to amount and phase. Where N1: Current measured electrode AC voltage E1 N2: Current measured electrode AC voltage E2 A1: Stored zero point E1 A2: Stored zero point E2

Submenu / parameter	Value range	Remark
<div data-bbox="81 369 311 436"> Submenu Status </div> <div data-bbox="233 470 620 1730"> <div data-bbox="233 470 464 537">Error register Amount: 1</div> <div data-bbox="384 569 620 636">C (Current) Ext. Database</div> <div data-bbox="384 667 620 735">Reset: Enter Help text: Step</div> <div data-bbox="384 766 620 833">0 Empty pipe</div> <div data-bbox="233 865 464 932">Warning register Amount: 2</div> <div data-bbox="384 963 620 1031">3 (Pending) * Test Mode *</div> <div data-bbox="384 1062 620 1129">Reset: Enter Help text: Step</div> <div data-bbox="384 1161 620 1228">2 Counter reset</div> <div data-bbox="233 1260 464 1327">Power outage 0</div> <div data-bbox="233 1358 464 1425">HMx -----</div> <div data-bbox="233 1457 464 1524">HMj -----</div> <div data-bbox="233 1556 464 1623">EMx -----</div> <div data-bbox="233 1654 464 1722">EMj -----</div> </div>		<p data-bbox="882 478 1426 695">After calling up the error register, the error register text is displayed with the number of pending errors. Press ENTER again to display the pending errors with error number and text. If you press ENTER again, you will be asked whether you want to reset the error or view the help text. Select STEP to display all of the pending errors with error numbers and text. Press ENTER to reset the pending errors.</p> <p data-bbox="882 877 1434 1123">After calling up the warning register, the warning register text is displayed with the number of pending warnings. Press ENTER again to display the pending warnings with warning number and text. If you press ENTER again, you will be asked whether you want to reset the warnings or view the help text. Select STEP to display all of the pending warnings with warning numbers and text. Press ENTER to reset the pending warnings.</p> <p data-bbox="882 1276 1281 1299">Display the power outages during operation.</p> <p data-bbox="882 1375 1252 1430">Status register for enhanced diagnostics. For more information see page 97.</p>

... 8 Operation

... Parameter descriptions

Submenu / parameter	Value range	Remark
<div>WMx -----</div> <div>Wmi -----</div> <div>ConWarn -----</div> <div>ConErr-----</div>		
<div>Submenu</div> <div>Syst. Adjust</div> <div>Start System Zero</div> <div>0.0 %</div> <div>System zero point</div> <div>0.0 %</div>	Manual Autom, adjustment Numerical entry	Check zero, if necessary (when adapting an older flowmeter sensor). Manual entry, e.g., when replacing the transmitter. Automatic adjustment: Valve must be closed, liquid in sensor must be at absolute standstill. Press ENTER to perform the automatic adjustment. The limit for the zero point is $\pm 10\%$. If the value is outside this limit, no calibration is performed.
<div>FSM4000 12/2019</div> <div>3KXF00001S0001 D.14</div>	Read only	Display software version. 01.2010 specifies the date of the release. C.11 = Version level, for standard and HART protocol.
<div>FSM4000 PA3.0</div> <div>D699G004U02 C.13</div>	Read only	For PROFIBUS PA software.
<div>FSM4000 FF</div> <div>D699G004U03 C.14</div>	Read only	For FOUNDATION Fieldbus communication software.

Additional information regarding use of enhanced diagnostic functions

Additional diagnostic functions are available in combination with sensors SE41F, SE21 and SE21F with nominal diameters > DN 8 and larger. The following section describes how to determine individual values.

Determining the coil alternating current or coil alternating voltage




Figure 54

For detecting changes in the coil circuit.

The current and voltage are measured directly. These do not influence the flow measurements.

To perform the measurement, you need to power-up one of the relevant errors or a warning in the submenu 'Diagnostics/Alarm Settings' (see **Diagnosis** on page 84).

Determining the coil DC resistance




Figure 55

$$R_{\text{Spule}} = \frac{U_{\text{Spule}}}{I_{\text{Spule}}}$$

For monitoring changes in the coil circuit, e.g., fine short of the coil.

When measuring the coil DC resistance, a DC field excitation of approx. 1 sec is used as a test signal. Because the incoming test signal prevents flow measurement, the most recent value is retained.

To perform this test, you need to power-up one of the relevant errors or warnings in the submenu 'Diagnostics / Alarm Settings' (see page **Alarm Settings** on page 85).

Note

To make sure that information is displayed properly, the signal cable length must be entered in the submenu 'Diagnostic / Adjustment / CabLength' (see **CabLength** on page 94).

... 8 Operation

... Additional information regarding use of enhanced diagnostic functions

Determining the coil temperature

The coil temperature is a factor of the ambient and fluid temperatures. The measurement can be for example used to monitor overtemperature through the medium.

The coil temperature is measured indirectly via the coil DC resistor (ABB Patent GB 2 348 011).

To perform the measurement, you need to power-up one of the relevant errors or a warning in the submenu 'Diagnostics / Alarm Settings' (see **Alarm Settings** on page 85).

$$T_{Coil} = \frac{R_{Coil} - R_{Ref}}{\alpha_{Ref} \cdot R_{Ref}} + 20\text{ °C}$$

T_{Coil}	Coil temperature
R_{Coil}	Coil resistance
R_{Ref}	Reference coil resistance at 20 °C
α_{Ref}	Temperature coefficient of copper at 20 °C (0.39 %/K)

Note

The coil resistance of the flowmeter sensor must be adjusted for a reference temperature. This applies to newly shipped systems consisting of SE41F / SE21 and S4. When connecting an S4 transmitter to previously shipped SE41F / SE21 sensors, you need to additionally perform the adjustment. For more information in this regard, see **Readjusting the coil temperature** on page 106.

Determining the insulation resistance for the coil




Figure 56

Detecting problems with the coil insulation. Can be caused, e.g., by dampness in the flowmeter sensor or in the connection box. When determining the insulation resistance of the coil to ground, a DC field test signal of approx. 1 sec is sent to the coil, separating the ground connection in the transmitter. In spite of the separation provided by the coil, the current flowing to ground is used to calculate the insulation resistance. During this measurement, the flowrate cannot be measured and the most recent value is retained.

To perform this test, you need to power-up one of the relevant errors or warnings in the submenu 'Diagnostics / Alarm Settings' (see page **Alarm Settings** on page 85).

Determining the E1 and E2 electrode AC voltage




Figure 57

Primary signal for determining the electrode balance.

The electrode AC voltages are measured at the electrodes E1 and E2 to ground. The voltage measured is proportional to the flowrate.

The electrode AC voltage can be measured without affecting the flow measurement in any way.

To perform this measurement, you need to power-up one of the relevant errors or a warning in the submenu 'Diagnostics / Alarm Settings' (see **Alarm Settings** on page 85).

Note

The electrode zero point must be adjusted in the submenu 'Diagnostics / Adjustments / Electr. Zero Point' (see **Electr. Zero Point** on page 94).

Determining the electrode balance

$$E1 \geq E2 \rightarrow EB = \frac{E1}{E2} \%$$

$$E1 < E2 \rightarrow EB = (-) \frac{E2}{E1} \%$$

Detect distorted flow profile, e.g., due to improper installation.

Detect interference in electrode circuit, e.g., failure of electrode due to insulating coating or a collapsed liner (vacuum shock).

The electrode balance (EB) is calculated as the ratio between the electrode AC voltages E1/E2 or E2/E1. This value is displayed in [%]. To prevent false alarms, alarms are not triggered for electrode AC voltages below 20 µV, regardless of the alarm setting which has been selected.

The EB is measured without affecting the flow measurement in any way. To perform this measurement, you need to power-up one of the relevant errors or a warning in the submenu 'Diagnostics / Alarm Settings' (see **Alarm Settings** on page 85).

Note

The electrode zero point must be adjusted in the submenu 'Diagnostics / Adjustments / Electr. Zero Point' (see **Electr. Zero Point** on page 94).

... 8 Operation

... Additional information regarding use of enhanced diagnostic functions

Determining the signal-to-noise ratio




Illustration58:

Detect changes in the measuring medium, e.g., gas bubbles, increased/reduced solid content.

To determine the signal-to-noise ratio (SNR), the electrode AC voltage - raw signal for the sensor is set in relation to the digitally filtered signal.

$$SNR = \frac{GefiltertesSignal}{Signal\ vom\ Messwertaufnehmer}$$

The SNR is measured without impairing the flow measurement in any way. To perform this calculation, you need to power-up one of the relevant errors or a warning in the submenu Diagnostics / Alarm Settings (see **Alarm Settings** on page 85).

Determining the magnetic linearity




Figure 59

$$ML = \frac{I_1 * U_{R2}}{I_2 * U_{R1}}$$

Detect magnetic field interference. This can affect the accuracy of the measurement.

When measuring magnetic linearity (ML), the coil current I_1 is measured at current reference voltage U_{R1} and coil current I_2 at approximately half the reference voltage U_{R2} .

The operating time at half the reference voltage is approx. 1 sec.

During this period, the most recently acquired value is retained.

To perform this test, you need to power-up one of the relevant errors or warnings in the submenu 'Diagnostics / Alarm Settings' (see **Alarm Settings** on page 85).

Determining the maximum DAC value




Figure 60

For detecting changes in the coil circuit.

To compensate the set reference voltage U_{ref} , the level of the digital/analog converter (DAC) value is manipulated in the transmitter driver circuit to vary the excitation signal of the coil. The amplitude of this value then serves as an indicator of the level of the excitation signal.

The DAC value is measured without affecting the flow measurement in any way.

To perform this measurement, you need to power-up one of the relevant errors or a warning in the submenu 'Diagnostics / Alarm Settings' (see **Alarm Settings** on page 85).

Recommended settings for diagnosis limit values

The values indicated are only intended as a rough guide and may need to be adapted in line with on-site conditions.

Parameter	Minimum value		Maximum value	
Electrode voltage 1	These values depend on the flowrate, so no recommendations can be made here.			
Electrode voltage 2				
Electrode balance ¹⁾	-150 %		150 %	
Coil current	Factory or commissioning fingerprint x 0.95		Factory or commissioning fingerprint x 1.05	
Coil voltage	This value depends on the measuring medium temperature T _{medium}			
	T _{medium}		T _{medium}	
	-40 °C (-40 °F)	Factory fingerprint x 0.81	-40 °C (-40 °F)	Factory fingerprint x 0.89
	-20 °C (-4 °F)	Factory fingerprint x 0.86	-20 °C (-4 °F)	Factory fingerprint x 0.95
	0 °C (32 °F)	Factory fingerprint x 0.9	0 °C (32 °F)	Factory fingerprint x 1
	20 °C (68 °F)	Factory fingerprint x 0.95	20 °C (68 °F)	Factory fingerprint x 1.05
	60 °C (140 °F)	Factory fingerprint x 1.05	60 °C (140 °F)	Factory fingerprint x 1.16
	90 °C (194 °F)	Factory fingerprint x 1.14	90 °C (194 °F)	Factory fingerprint x 1.26
	130 °C (266 °F)	Factory fingerprint x 1.24	130 °C (266 °F)	Factory fingerprint x 1.37
	180 °C (356 °F)	Factory fingerprint x 1.33	180 °C (356 °F)	Factory fingerprint x 1.47
Coil resistance	This value depends on the measuring medium temperature T _{medium}			
	T _{medium}		T _{medium}	
	-40 °C (-40 °F)	Factory fingerprint * 0.71	-40 °C (-40 °F)	Factory fingerprint * 0.79
	-20 °C (-4 °F)	Factory fingerprint * 0.81	-20 °C (-4 °F)	Factory fingerprint * 0.89
	0 °C (32 °F)	Factory fingerprint * 0.9	0 °C (32 °F)	Factory fingerprint * 1
	20 °C (68 °F)	Factory fingerprint * 0.95	20 °C (68 °F)	Factory fingerprint * 1.05
	60 °C (140 °F)	Factory fingerprint * 1.19	60 °C (140 °F)	Factory fingerprint * 1.31
	90 °C (194 °F)	Factory fingerprint * 1.28	90 °C (194 °F)	Factory fingerprint * 1.42
	130 °C (266 °F)	Factory fingerprint * 1.43	130 °C (266 °F)	Factory fingerprint * 1.58
	180 °C (356 °F)	Factory fingerprint * 1.62	180 °C (356 °F)	Factory fingerprint * 1.79
Coil temperature	This value depends on the ambient / measuring medium temperature, so no recommendations can be made here.			

1) This function is only guaranteed if an electrode zero point adjustment has been carried out (see page 94).

... 8 Operation

... Additional information regarding use of enhanced diagnostic functions

Parameter	Minimum value	Maximum value		
Accidental coil ground	10 MΩ	99.9 MΩ		
DAC max		Design level of the flowmeter sensor		
		Nominal diameter	A	B
		DN 1 to2 (1/25 to1/12")	500	-
		DN 3 to10 (1/10 to3/8")	300	300
		DN 15 (1/2")	400	300
		DN 20 to25 (3/4 to1")	400	400
		DN 32 (1 1/4")	400	500
		DN 40 to50 (1 1/2 to2")	500	500
		DN 65 (2 1/2")	400	300
		DN 80 (3")	500	300
		DN 100 to125 (4 to5")	500	600
		DN 150 (6")	400	600
		DN 200 to300 (8 to12")	400	700
		DN 350 to400 (14 to16")	500	700
		DN 450 to1000 (18 to40")	700	700
Magn. linearity	This value depends on the measuring medium temperature T _{medium}			
	T _{medium}	T _{medium}		
	-40 °C (-40 °F)	Factory fingerprint x 0.86	-40 °C (-40 °F)	Factory fingerprint x 0.95
	-20 °C (-4 °F)	Factory fingerprint x 0.90	-20 °C (-4 °F)	Factory fingerprint x 1
	0 °C (32 °F)	Factory fingerprint x 0.93	0 °C (32 °F)	Factory fingerprint x 1.03
	20 °C (68 °F)	Factory fingerprint x 0.95	20 °C (68 °F)	Factory fingerprint x 1.05
	60 °C (140 °F)	Factory fingerprint x 1	60 °C (140 °F)	Factory fingerprint x 1.10
	90 °C (194 °F)	Factory fingerprint x 1.05	90 °C (194 °F)	Factory fingerprint x 1.16
	130 °C (266 °F)	Factory fingerprint x 1.09	130 °C (266 °F)	Factory fingerprint x 1.21
	180 °C (356 °F)	Factory fingerprint x 1.14	180 °C (356 °F)	Factory fingerprint x 1.26
SNR (signal-to-noise ratio)	60 % of the commissioning fingerprint or a higher value, depending on the application.			100 %

Displaying the diagnostic values


Measured values

A maximum of four diagnostic values can be displayed (Fprt1, Fprt2, Fprt3, Fprt4). These values are selected in the submenu Diagnosis / Fingerprint / Fprt1 - 4. In addition to the type of measured value, the desired data set should also be set. This combination of settings can be used to display all stored values.

To enable users to display the different numerical values, an ID code is displayed with each value.

As a result, each line appears as follows:

e.g., CV_RCL 80.5 ohm to display the current coil resistance.



Data set	Type	Numerical value	Unit
CV_: Current value	UAC: Coil voltage (AC)	X.X	V
H1_: History 1	IAC: Coil current (AC)	X	mA
H2_: History 2	RCL: Coil resistance	Value > 100 X Value < 100 X.X	Ohm
H3_: History 3	TCL: Coil temperature	X	°C
H4_: History 4	RIS: Insulation resistance	Value > 100 X Value < 100 X.X	MOhm
H5_: History 5	UE1: Electrode voltage E1	X	μV
H6_: History 6	UE2: Electrode voltage E2	X	μV
H7_: History 7	BAL: Electrode balance	E1 ≥ E2 → +X E1 < E2 → -X	% %
H8_: History 8	LIN: Magnetic linearity	X	%
H9_: History 9	SNR: Signal-to-noise ratio	X	%
FV_: Default fingerprint	DAC: Maximum DAC value	X	Dig = Digits
DF_: Commissioning fingerprint			
P1_: Product 1 fingerprint			
P2_: Product 2 fingerprint			

... 8 Operation

... Additional information regarding use of enhanced diagnostic functions

When displaying the operating hours / log time, the ID code combines data set and type without underscore.

Data set	Type	Numerical value	Unit
CVC: Current transmitter operating hours counter		H:Min:Sec	-
P1C: Product1 fingerprint transmitter log time		H:Min:Sec	-
P2C: Product2 fingerprint transmitter log time		H:Min:Sec	-
DFC: Commissioning fingerprint transmitter log time		H:Min:Sec	-
FVC: Default fingerprint transmitter log time		H:Min:Sec	-
H1C – H9C: History 1 – 9 transmitter log time		H:Min:Sec	-
CVP: Current sensor operating hours counter		H:Min:Sec	-
P1P: Product1 fingerprint sensor log time		H:Min:Sec	-
P2P: Product2 fingerprint sensor log time		H:Min:Sec	-
DFP: Commissioning fingerprint sensor log time		H:Min:Sec	-
FVP: Default fingerprint sensor log time		H:Min:Sec	-
H1P – H9P: History 1 – 9 sensor log time		H:Min:Sec	-

Diagnostic warning and error messages

All values acquired during diagnostics or a wiring error can trigger warnings or error messages.

Warnings are displayed in the 4th display line only. In case of an error, in addition to the signal in the 4th display line, the switch output ('General alarm' setting or 'ext. Diag. Alarm' is set to the alarm condition.

To activate this option, select in the submenu 'Diagnosis / Alarm Settings' whether the error or warning is triggered in the event of up-scale or down-scale of the specified range. To check for wiring errors, you can activate this function in the 'Diagnostics / Wiring Error' submenu.

For additional information, refer to the relevant error registers. These can be selected or called up in the 'Display' or 'Status' submenu

The error registers for diagnostic values are structured as follows:

ID code	Set	Off	Designation
	S	-	Signal quality
	L	-	Magnetic linearity
	B	-	Electrode balance
	m	-	Electrode voltage E1
	E	-	Electrode voltage E2
	D	-	DAC value
	I	-	Insulation resistance
	T	-	Coil temperature
	L	-	Coil resistance
	R	-	Coil voltage
	C	-	Coil current

↓

ID code	Register name	Content of register
HMx	Hist Max Errors	Error / Warning: Limit value up-scale (max.) while transmitter is powered-up.
HMi	Hist Min Errors	Error / Warning: Limit value down-scale (min.) while transmitter is powered-up.
EMx	Curr Max Errors	Error: Number of current limit value up-scales (max.).
EMi	Curr Min Errors	Error: Number of current limit value down-scales (min.).
WMx	Curr Max Warn	Warning: Number of current limit value up-scales (max.).
WMi	Curr Min Warn	Warning: Number of current limit value down-scales (min.).

The display EMx _R____B_ indicates for example a max. alarm in the current values for the coil resistance and electrode balance.

The error registers for wiring errors are structured as follows:

ID code	Set	Off	Designation
	M	-	Coil short-circuit to ground
	E	-	Wiring error for electrodes

↓

ID code	Register name	Content of register
ConWarn	Wiring Warning	Current warnings for wiring
ConErr	Wiring Failure	Current errors for wiring

... 8 Operation

... Additional information regarding use of enhanced diagnostic functions

Readjusting the coil temperature

If a readjustment is required, make sure that the sensor and coil are relatively close to ambient temperature. You might need to allow the sensor to cool off overnight.

Work steps:

- Power-up the transmitter.
- In the submenu 'Diagnostics / Adjustment / CabLength', enter or check the correct signal cable length.
- Enter the ambient temperature in the submenu 'Diagnostics / Adjustment / Coil Temp'.
- Import the new reference resistance in the submenu 'Diagnostics / Adjustment / Import RT20'.

Software history

For transmitters without communication or HART protocol

Software D200S021U01		
Software version	Type of changes	Documentation / Supplements
B.10	Original software	–
B.11	Improve min. contrast limit. After changing from 50 → 60 Hz the system data now displays the correct frequency.	–
B.12	Shortened Finnish texts. Aut. simulator detection for counter management improved.	–
B.14	FRAM management optimized.	–
B.20	Added Turkish as new language. Added error E (DC too high) Updated flowmeter sensor 10D1462/72.	Added documentation for the additional points.
B.22	Always display the flowrate with 4 decimal places.	–
B.30	Menu item for noise reduction Menu item Meter factor Support for sensors SE21, DN 1 to DN 2	Added documentation for the additional points.
B.31	Hardware compatibility for C-level hardware	–
B.32	Improved totalizer management	–
B.33/B.34	FRAM management optimized	–
C.10	Extended diagnostic functions. Extended noise reduction by 2 more levels. Software supports external zero point adjustment via contact input.	Added documentation for the additional points.
C.11	Improved support for older flowmeter sensor	–
C.20	Improved display operation	–
D.13	Firmware update due to a new microprocessor	–
D.14	Troubleshooting, display freeze	–

... 8 Operation

... Software history

For transmitter with PROFIBUS PA communication

Software D200S021U02

Software version	Type of changes	Documentation/Supplements
B.11	Original software.	–
B.14	Shortened Finnish texts. Aut. Simulator detection for counter management improved; FRAM management improved.	–
C.10	Extended diagnostic functions, etc.	Added documentation for the additional points
C.12	PA stack optimized.	–
C.13	Improved support for older flowmeter sensor	–
C.14	Improved diagnostic function	–

For transmitter with FOUNDATION Fieldbus communication

Software D200S021U03

Software version	Type of changes	Documentation/Supplements
B.14	Original software.	–
B.15	FF stack optimized	–
C.10	Extended diagnostic functions, etc.	Added documentation for the additional points
C.12	FF stack optimized.	–
C.13	Control response of the PID block adapted	–
C.14	Improved support for older flowmeter sensor	–

S4 operation with older sensor

When operating a transmitter with an older model, the FRAM must be used with the values $C_s = 100\%$ and $C_z = 0\%$. If the transmitter is equipped as such and the devices are mounted according to the electrical connection (see page **Terminal assignment** on page 36 and on), the menu 'Primary Setup' is displayed after power-up of the power supply. Press any key to enter the following information. If you need to correct your entry, you can do so afterward in the system data submenu 'Sensor': in 'Primary Setup'. See page **Primary Setup** on page 65.




Figure 61: 'Primary Setup' submenu

Entries can be made one after another. In the submenu 'Primary Setup', select the line frequency at which the sensor was calibrated. See name plate. Select the flowmeter sensor type from the list in the table. Check that the letter after the model number and the nominal diameter range are correct. Otherwise, the transmitter will not access the correct reference data.

Enter the relevant meter size. The values are listed for DIN and ANSI sizes. Enter the reference voltage (see the name plate on the flowmeter sensor) in numerical format. (For sensor model 10D1422 or 10DI1425 > DN500, the reference voltage is not required.)

Enter the meter factor (for model 10D1462/72 only). See name plate.

Select the measuring range and other process parameters (damping, low cut-off, current/pulse output, display format, etc.). A system zero adjustment must be performed with a full pipeline at standstill (0 m/s).

Note

If no values are listed for the reference voltage on the name plate, you can request this information from ABB Service. Please provide order number with your request.

e-mail: parts-repair-goettingen@de.abb.com

Phone: +49 180 5222-580

Note

If the flow indicator shows the incorrect flow direction after successful commissioning of the measuring system, e.g., reverse flow instead of forward flow, you should correct this in the Operating Mode submenu of the transmitter.

First switch off the programming protection ('Prog. Level' → 'Specialist'). Then select the parameter 'Directional display' in the submenu 'Operating Mode'. Change 'normal' to 'inverse'. Finally, reactivate programming protection by selecting 'Prog. Level' → 'Locked'.

... 8 Operation

... S4 operation with older sensor

⚠ WARNING


Danger due to electric current!

When the housing is open, EMC protection is impaired and there is no longer any protection against accidental contact.

- Power to all connection leads must be switched off.

Adapting the transmitter to the sensor 10D1422 (DN 3 to 1000), 10DI1425 (\geq DN 500):

1. Switch off the power supply. After waiting 40 minutes, remove the housing cover from the field housing unit.
2. Remove the shock protection cover ① by loosening the 3 ② screws.




① Shock protection cover

② Fixing screw cover

Figure 62: Screwing on the shock protection cover

3. Then close switch S903 ①.



① Switch S903

Figure 63: Close switch S903

Type of flowmeter sensor, Nominal diameter DN version level		Connection board with voltage splitter (switch S903 must be closed)	FRAM Version	Coil current supply via:	Reference voltage
SE2_, SE4	1 to 1000	No	With sensor calib. value Cs = see name plate Cz = see name plate	Transmitter S4	automatic
DS2_ DS4_ 10DS3111(A-D) 10DS3111(E)	1 to 1000 ≤ 300 ≤ 400 ≤ 300	No	Cs = calculated; Cz = 0%	Transmitter S4	from name plate
10DI1425	≤ 400	No	Cs = calculated; Cz = 0%	Transmitter S4	90 mV
DS4_ 10DS3111(E)	≥ 350 to 1000 ≥ 350 to 400	No	Cs = calculated; Cz = 0%	Transmitter S4	from name plate
10DS3111(A-C) 10DS3111(D) 10DS3111(E)	≥ 500 ≥ 500 ≥ 500	No	Cs = calculated; Cz = 0%	External power supply	from name plate
10D1422, 10DI1425	3 to 1000 ≥ 500	yes yes	Cs = calculated; Cz = 0%	External power supply	–
10DS3111A 10D1462 10D1472	350 to 600 150 to 900 15 to 100	no, use 1000 Ω adapter board	calculated	External power supply	from name plate

9 Diagnosis / error messages

Overview of error states and alarms

State / Error	Flow rate indicator display	Notification with simulation at current output	Current output	Pulse output	Switch output					Message with HART
					Collective alarm	Min Alarm	Max Alarm	Max/Min Alarm	Empty conduit	
0 = 'Empty conduit'	0 %	–	Prog.Al. DLR	0 %	Alarm				Alarm	More Stat avai.
1 = 'AD converter/DSP'	0 %	–	Prog.Al.	0 %	Alarm					Trans Mal F.
2 = 'Driver'	0 %	–	Prog.Al.	0 %	Alarm					Trans Mal F.
3= 'Flow rate > 103 %'	103 %	Yes	High.Al	103 %	Alarm					PV out Limits
4 = 'Ext. Zero Return"	0 %	–	0 %	0 %	Alarm					More Stat avai.
5 = 'Database'	0 %	Yes	Prog.Al.	0 %	Alarm					Trans Mal F.
6 = 'Totalizer'	–	Yes	–	–	Alarm					More Stat avai.
A = 'Max Alarm'	–	Yes	–	–	Alarm		Alarm	Alarm		More Stat avai.
B = Min Alarm'	–	Yes	–	–	Alarm	Alarm		Alarm		More Stat avai.
C = 'ext. database"	0 %	Yes	Prog.Al.	0 %	Alarm					Trans Mal F.
D = 'Old sensor'	0 %	Yes	Prog.Al.	0 %	Alarm					Trans Mal F.
E = 'DC to high'	0 %	Yes	Prog.Al.	0 %	Alarm					Trans Mal F.
F = 'FRAM in sensor'	0 %	Yes	Prog.Al.	0 %	Alarm					Trans Mal F.
G = 'Diagnosis error'	–	–	–	–	Alarm				Alarm	Trans Mal F.

Error messages during operation and with data entry

The error messages listed below include explanations of the error codes shown in the display. When entering information, the error codes 0 to 6, A, B, C, D, E, G do not appear.

Error code and clear text message	Priority	Description	Possible cause	Corrective action
Error: 0 Empty pipe	5	The meter tube is not full.	The piping is empty and the electrodes are not coming into contact with the measuring medium.	Refill the meter tube. Detector empty tube is on, but the adjustment has not been run. Adjust DLR.
Error: 1 "AD converter / DSP	4	The AD converter is overloaded and is not responding.	Input metering signal is too large.	Check ground (flowmeter sensor). Check the signal cable and the measuring range setting; the measuring range selected may be too small.
			The AD converter/DSP is defective.	Change DSP board.
Error: 2 Driver	7	Positive or negative reference too small.	Check the cables, no reference voltage is present. The flow restrictor in the driver has responded because the driver current is insufficient. Defective driver fuse.	Check connection board and transmitter.
Error: 3 Flow rate > 103 %	6	The max. set measuring range was up-scaled by more than 3 %.	The flowrate is set too high or the measuring range is set too small.	Increase the measuring range, reduce the flowrate.
Error: 4 Ext. Zero Return	8	The flow rate is set to zero; the totalizer is stopped.	The external contact is closed.	The external contact is open again.
Error: 5 Database	2	Loss of the internal database.	Memory module is defective.	Turn unit off and power-up again, call up and run functional test for the transmitter.
Error: 6 Counter	9	Error in totalizer > F.	The forward function of the totalizer failed.	Reset forward/reverse flow totalizer or preset new values in totalizer. Totalizer forward, reverse defective.
		Error totalizer < R	The reverse function of the totalizer failed.	Check transmitter and cables.
		Error totalizer	The totalizer function of forward, reverse flow or difference totalizer failed.	

... 9 Diagnosis / error messages

... Error messages during operation and with data entry

Error code and clear text message	Priority	Description	Possible cause	Corrective action
Error: A Max. alarm	10, 11	Max alarm limit value.	The configured Max alarm for the flow rate was up-scaled.	Reduce flowrate.
Error: B Min. alarm		Min alarm limit value	The configured Min alarm for the flow rate was down-scaled.	Increase the flow rate.
Error: C Ext. Database	3	External database FRAM is defective or not available.	Missing FRAM or defective FRAM ¹⁾ .	Install and screw in place the FRAM for the relevant flowmeter sensor to the connection board in the field housing unit. Refer to Commissioning on page 46. If the FRAM cannot be read, it must be replaced.
Error: D Old sensor	12	Sensor type from the older model sensor series was selected.	Configuration in the parameter 'Primary Setup' is incomplete.	Please complete parameter configuration in 'Primary Setup'. See also chapter 11 of the operating instruction.
Error: E DC too high	13	Increased analog reset, measurement signal with large DC marked	Air bubbles, deposits on electrodes, too high interference signal. Empty measuring tube.	Activate 'Noise reduction' in the operating mode submenu. Use a de-aerator, clean electrodes, activate empty conduit detector. Contact ABB Service.
Error: F FRAM in sensor	1	Missing data from external FRAM.	FRAM for the flowmeter sensor is still installed in the terminal box.	Install and screw in place the FRAM for the relevant flowmeter sensor to the connection board in the field housing unit. Refer to Commissioning on page 46.
Error: G Diagnosis error	14	Diagnosis or wiring error	Min-Max over/undershoot for diagnostic values.	Retrieve details of error message under the Status submenu in the Wiring error register. Where applicable, Adjust limit value.
			Wiring error for electrode circuit. Coil short-circuit to ground	Retrieve details of error message under the Status submenu in the Wiring error register.

1) Replacing a defective FRAM. If the FRAM is defective and commissioning cannot be performed, a new FRAM can be requested from the Göttingen plant. To properly process requests, you must include the ABB order number and device number of the sensor. After installing the FRAM and switching on the power supply, you can commission the system. Review all sensor data and setup data for the system, and enter this information again, if necessary.

Warning messages during operation

Warning code and ID letter	Priority	Description	Possible cause	Corrective action
Warning: 1 Q Simulation	2	Before operation with flow, a flowrate can be simulated. The output values correspond to the simulated flowrate entered.	Simulation mode on.	After completing the simulation program, switch off the parameter 'Simulation Mode'.
Warning: 2 Totalizer reset	1	All totalizers (forward/reverse, diff. and overflow counters are reset.)	External totalizer reset was performed.	Open the switch at the contact input (terminal 81, 82).
Warning: 3 Test Mode	3	Only for checking the transmitter using Simulator 55XC4000.	Test Mode on.	After running the simulation on the simulator, switch off the parameter 'Test Mode'.
Warning: 4 Function test	4	If during HART communication, the functional test for the switch output or switch input was started, the Warning '4' is displayed.	Function test on.	Leave the routine once the functional test has completed.
Warning: 7 ¹⁾ Ext.Data.loaded	9	Transmitter has detected additional flowmeterDefective FRAM, repair unit, sensor data and loaded it to the internal FRAM.replacement unit. System data and sensor data are loaded.	Defective FRAM, repair unit, replacement unit.	Write down all totalizer values, totalizers should be reset.
Warning: 8a ¹⁾ Update int.Dat.	10	Transmitter has detected an error in the internal FRAM and has repaired the data with content of the external FRAM.	Defective FRAM, repair unit, replacement unit.	Check the setup data and correct, if necessary.
Warning: 8b ¹⁾ Update ext.Dat.		Transmitter has detected an error in the external FRAM and has repaired the data with content of the internal FRAM.	Defective FRAM or data was modified.	Check the setup data and correct, if necessary.
Warning: 9a Overflow > F	5	Forward totalizer has reached the maximum count and has restarted at zero.	Max. totalizer value up-scaled, 1 Reset totalizer, if necessary. overflow as value was totalized.	
Warning: 9b Overflow < R	6	Reverse totalizer has reached the maximum count and has restarted at zero.	Max. totalizer value up-scaled, 1 Reset totalizer, if necessary. overflow as value was totalized.	
Warning: 9c Overflow Diff.	7	The difference totalizer has reached the maximum count and has restarted at zero.	Max. totalizer value up-scaled, 1 Reset totalizer, if necessary. overflow as value was totalized.	

1) Warning is displayed for 30 seconds.

... 9 Diagnosis / error messages

... Warning messages during operation

Warning code and ID letter	Priority	Description	Possible cause	Corrective action
Warning: 10 Reverse Q	8	If the flow direction is forward, the warning is displayed in case of reverse flow.	Reverse flow direction, possibly defective damper or check valve.	Prevent reverse flow or change flow direction to forward/reverse.
Warning: 11 ²⁾ Poll. Adr. > 0	12	The HART device address was changed to an address other than zero. The current output remains frozen at 4 mA.	Address 1 to 15 selected. The current output thereby remains set at 4 mA.	Select 0 as address, if the current output should be 4 to 20 mA.
Warning: 12a ^{2) 3)} Simulation Iout	13	Test the current output. Check the value set at the terminals using a digital voltmeter or the process instrumentation.	Enter the functional test of the current output directly in mA for simulation.	Exit the functional test of current output.
Warning: 12b ^{2) 3)} Simulat. Pulses	14	Test the pulse output. Check the configured pulse at the output with a meter.	Simulation pulse output on.	Exit the functional test for the pulse output.
Warning: 13 ^{2) 3)} Auto. Calibration	15	Adjustment started for system zero point adjustment via the contact input for internal adjustment (for ABB Service only).	The external contact is closed For ABB Service personnel only.	The external contact is open again. For ABB Service personnel only.
Warning: 14 Hold MW	16	Warning results only when the 'Noise reduction' function is activated.	Measuring signal affected by powerful interference signal.	Reduce interference to lower level or shut off. Where applicable, Consult with the factory service department.
Warning 15 Warn. Diagnosis	17	Diagnostic or wiring warning	Min-Max over/undershoot for diagnostic values. Wiring error for electrode circuit. Coil short-circuit to ground	Retrieve details of warning message under the Status submenu in the Diagnosis warning register. Where applicable, Adjust limit value. Retrieve details of warning message under the Status submenu in the Wiring warning register.
Warning 16		Warning 16 only for Profibus PA and FF devices.— Warning 16 corresponds to Warning 15 in HART devices		—

2) Transmitter must be equipped with HART communication protocol.

3) Warning is displayed only if the function is called by an external HART protocol command.

10 Maintenance / Repair

Safety instructions

WARNING

Risk of injury due to live parts!

When the housing is open, contact protection is not provided and EMC protection is limited.

- Before opening the housing, switch off the power supply.

CAUTION

Risk of burns due to hot measuring media

The device surface temperature may exceed 70 °C (158 °F), depending on the measuring medium temperature!

- Before starting work on the device, make sure that it has cooled sufficiently.

NOTICE

Damage to components!

The electronic components of the printed circuit board can be damaged by static electricity (observe ESD guidelines).

- Make sure that the static electricity in your body is discharged before touching electronic components.

Repair and maintenance activities may only be performed by authorized customer service personnel.

When replacing or repairing individual components, original spare parts must be used.

NOTICE

Caution - Potential damage to parts!

The electronic components of the printed circuit board can be damaged by static electricity (observe ESD guidelines). Make sure that the static electricity in your body is discharged when touching electronic components.

Sensor

Essentially no maintenance is required for the sensor. The following items should be checked annually:

- Ambient conditions (air circulation, humidity),
- Tightness of the process connections,
- Cable entries and cover screws,
- Operational reliability of the power supply, lightning protection, and station ground.

The flowmeter sensor electrodes must be cleaned when the flowrate information on the transmitter changes when recording the identical flowrate volume. If the display shows a higher flowrate, the contamination is insulating. If the flowrate displayed is lower, the contamination results in a short-circuit. For repairs to the lining, electrodes or magnet coil, the flowmeter must be returned to the head office in Göttingen.

Note

When sending the sensor for repair to the head office of ABB AG, complete the return form in the appendix and include with device.

When cleaning the exterior of measuring devices, make sure that the cleaning agent used does not corrode the housing surface and the gaskets.

Gaskets

Some device designs are shipped with special gaskets. These gaskets must be used and installed properly to prevent leakage. For all other device designs, use commercially available gaskets made from a compatible material for the measuring medium and prevailing temperature (rubber, PTFE, It, EPDM, silicon, Viton, etc.) or use 'Hygienic Design' compliant gasket materials for hygienic devices.

Note

A wafer type sensor is installed without gaskets directly in the pipeline.

... 10 Maintenance / Repair

Replacing the transmitter

The transmitter plug-in unit can be replaced without loss of function for nominal diameters DN 3 to DN 1000.

When replacing the FRAM-calibrated flowmeter sensor (identifiable by the Cs and Cz values on the name plate), please take into consideration the following points:

- Does the replacement transmitter plug-in unit use the same power supply?
- Does the replacement transmitter plug-in unit have the same input/output functions or use the same type of communication?

NOTICE

Important for plug-in units with PROFIBUS PA / FOUNDATION Fieldbus

If the transmitter is located at the bus end and if the bus termination is activated via both hook switches, the bus termination is canceled when the transmitter plug-in unit is removed. The bus is no longer terminated properly.


WARNING

Warning - Electrical dangers!

When the housing is open, EMC protection is impaired and there is no longer any protection against accidental contact.

- Power to all connection leads must be switched off.


1. Switch off the power supply before installing the replacement transmitter plug-in unit. After waiting 40 minutes, remove the housing cover from the field housing unit. First, remove the shock protection covers (3 screws). Next, remove the upper mounting screw and the center stay-bolt on the plug-in. The plug-in module can now be pulled up and off the connection plug. Install the replacement transmitter plug-in in reverse order.



① Shock protection cover

② Fixing screw cover

Figure 64: Removing the shock protection cover



① Fixing screw for plug-in unit

③ Stud bolt for plug-in unit

② Transmitter plug-in unit

Figure 65: Disassembling the transmitter plug-in unit

2. Power-up the power supply; the model number for the transmitter and the current software revision are displayed. The flowmeter sensor and system data from the external FRAM are imported:
 - a) The following information is displayed:
 - Warning 7 – External data is loaded.
 When replacing the transmitter all flowmeter sensor and measuring point parameters are imported by the replacement transmitter. After successful data transfer, the 'Warning 7' message is deleted after approx. 30 sec.
 - b) Transmitter and sensor are recommissioned (e.g., after a power failure):

No warning is displayed; the transmitter runs automatically with the data from the internal and external FRAM.
 - c) Only the transmitter is replaced; order numbers are not identical. The external sensor and system data is imported. The following message is displayed:
 - Warning 7 – External data is loaded.
 - d) If the order number, unit number, Cs, Cz and nominal diameter are identical (e.g., if the transmitter is used from a delivery with identical configuration data), the process data is imported from the internal to external FRAM. The sensor data continues to be imported from the external to internal FRAM. The following message is displayed:
 - Warning 8b – (Update external data).

If the external data cannot be loaded in scenarios a) to d), the program attempts to repair the defective data. The following messages may be displayed:

- Warning 8a – (Update internal data) - for data flow direction external → internal
- Warning 8b – (Update external data) - for data flow direction internal → external

Both messages can be displayed simultaneously.

If this occurs, the following error is displayed:

- Error C – for the external FRAM, the FRAM thus must be replaced
 - Error 5 – for the internal FRAM, the transmitter starts automatically with default values. In some instances, it may be possible to eliminate this error by turning the supply power off and on. If the error does not disappear, the transmitter or the transmitter plug-in unit must be replaced.
3. Check whether the language, display format, measuring ranges, limit values and sensor data match the values listed on the name plate of the sensor. If parameters are subsequently changed, these are stored automatically in the external FRAM.
 4. The measuring system is ready for operation.

Returning devices

Use the original packaging or a secure transport container of an appropriate type if you need to return the device for repair or recalibration purposes.

Fill out the return form (see **Return form** on page 135) and include this with the device.

In accordance with the EU Directive governing hazardous materials, the owner of hazardous waste is responsible for its disposal or must observe the following regulations for shipping purposes:

All devices delivered to ABB must be free from any hazardous materials (acids, alkalis, solvents, etc.).

Address for returns:

Please contact Customer Center Service according to page 6 for nearest service location.

11 Recycling and disposal

Dismounting

WARNING

Risk of injury due to process conditions.

The process conditions, for example high pressures and temperatures, toxic and aggressive measuring media, can give rise to hazards when dismantling the device.

- If necessary, wear suited personal protective equipment during disassembly.
- Before disassembly, make sure that the process conditions do not pose any safety risks.
- Depressurize and empty the device / piping, allow to cool and purge if necessary.

Bear the following points in mind when dismantling the device:

- Switch off the power supply.
- Disconnect electrical connections.
- Allow the device / piping to cool and depressurize and empty. Collect any escaping medium and dispose of it in accordance with environmental guidelines.
- Use suited tools to disassemble the device, taking the weight of the device into consideration.
- If the device is to be used at another location, the device should preferably be packaged in its original packing so that it cannot be damaged.
- Observe the notices in **Returning devices** on page 13.

Disposal

Note



Products that are marked with the adjacent symbol may **not** be disposed of as unsorted municipal waste (domestic waste).

They should be disposed of through separate collection of electric and electronic devices.

This product and its packaging are manufactured from materials that can be recycled by specialist recycling companies.


Bear the following points in mind when disposing of them:

- As of 8/15/2018, this product will be under the open scope of the WEEE Directive 2012/19/EU and relevant national laws (for example, ElektroG - Electrical Equipment Act - in Germany).
- The product must be supplied to a specialist recycling company. Do not use municipal waste collection points. These may be used for privately used products only in accordance with WEEE Directive 2012/19/EU.
- If there is no possibility to dispose of the old equipment properly, our Service can take care of its pick-up and disposal for a fee.

12 Spare parts list

Note
Spare parts can be ordered from ABB Service.
www.abb.com/contacts

Fuses for transmitter electronics

**WARNING**


Danger due to electric current!

When the housing is open, EMC protection is impaired and there is no longer any protection against accidental contact.

- Power to all connection leads must be switched off.


Replacing the fuse

1. Switch off the power supply. After waiting 40 minutes, remove the housing cover from the field housing unit.
2. To replace the fuses for shock protection cover ①, loosen and remove the 3 screws ②.



- ① Shock protection cover
- ② Fixing screw cover

Figure 66: Removing the shock protection cover



- ① Fuse for driver circuit on the backplane
- ② Backup fuse for power supply on the backplane
- ③ Fuses for power supply on the transmitter electronics

Figure 67: Fuses

Item	Designation	Ordering number
①	Driver circuit fuse F103 (0.8 A)	D151F003U18
②	Backup fuse for power supply on backplane (4 A-T)	D151B003U08
③	Fuse for power supply on the transmitter electronics	
	Fuse for 24 V AC/DC (4 A-T)	D151B003U08
	Fuse for 100 to 230 V AC (1 A-T)	D151B003U05

... 12 Spare parts list

Spare parts for transmitter S4

Field mount housing




Figure 68: Field mount housing

Item	Designation	Ordering number
①	Transmitter (100 to 230 V AC) without HART	3KXF002961U0100
	Transmitter (100 to 230 V AC) with HART	3KXF002961U0200
	Transmitter (100 to 230 V AC) with PROFIBUS PA / FF ¹⁾	D674A859U06
	Transmitter (24 V AC/DC) without HART	3KXF002961U0100
	Transmitter (24 V AC/DC) with HART	3KXF002961U0200
	Transmitter (24 V AC/DC) with PROFIBUS PA / FF ¹⁾	D674A860U04
②	Connection board, standard	D685A1020U01
	Connection board, PA/FF	D685A1020U02
③	Large cover, complete	D641A030U01
④	PVC cover	D626A005U01
⑤	Spacer bolts M4 × 75, galvanized steel	D124E009U20
⑥	Small cover	D641A029U01
⑦	Connection diagram, standard / HART	D338D311U01
	Connection diagram, PROFIBUS PA / FF	D338D311U02
⑧	Flat cable holder	D174D002U03
⑨	Field housing unit, empty	D641A033U01
⑩	Cable gland M 20 × 1.5	D150A008U15
⑪	Pan head Phillips screw M4 × 10, galvanized steel	D004G108AU01
⑫	Spring washer A 4.0 DIN 137, Niro	D085D020AU20
⑬	Spacer bolts M4 × 41 I/A, galvanized steel	D403B104U01
⑭	Shock protection cover	D355H305U01

1) When ordering spare parts, please provide the communication version to help us select the proper software.

Spare parts for sensor

Terminal box stainless steel DN 3 to DN 100




Figure 69: Stainless steel terminal box

Item	Designation	Ordering number
(1)	Terminal board standard > D N8	D685A1025U01
(1).1	Connection board with preamplifier	D685A1028U01
(2)	Lower section SS 1.4301, model SE21_	D612A128U01
(3)	Seal	D333F016U01
(4)	Pan head screw M3 × 6, DIN 7985	D004F106AU20
(5)	Serrated lock washer A3.2, DIN 6798	D085G017AU32
(6)	Cable gland, plastic, grey	D150A008U02
(7)	Spacer	D375A018U01
(8)	Hexagon head screw M4 × 14, DIN 7964, stainless steel	D024G110AU20
(9)	Insert ring 'Nyltite Seal' F.M4	D115B004U01
(10)	Cover SS no. 1.4301	D612A178U01
(11)	Connection diagram, standard	D338D309U01
(12)	Connection diagram, with preamplifier	D338D310U01

... 12 Spare parts list

... Spare parts for sensor

Terminal box, aluminum DN 3 to DN 1000




Figure 70: Aluminum terminal box

Item	Designation	Ordering number
①	Connection board, standard > DN 8	D685A1025U01
	Terminal board with preamplifier, type A	D685A1028U01
②	Terminal box with cable gland M20×1.5	3KXF000112U0100
—	Cover for terminal box	D612A226U01

13 Specification

Note

The device data sheet is available in the ABB download area at www.abb.com/flow.

Measuring accuracy

Reference conditions in accordance with EN 29104

Measuring medium temperature	20 °C (68 °F) ±2 K
Ambient temperature	20 °C (68 °F) ±2 K
Power supply	Nominal voltage as per name plate UN ± 1 %
Installation conditions	<ul style="list-style-type: none"> Inlet section: > 10 × DN straight section Outlet section: > 5 × DN straight section
	DN = Sensor nominal diameter
Warm-up phase	30 min

Maximum measuring error


Pulse output

- DN 3 to DN 1000 ($\frac{1}{16}$ to 40"):
 - $Q > 0.05 Q_{\max}$ DN ±0.5 % of measured value
 - $Q < 0.05 Q_{\max}$ DN ± 0.00025 Q_{\max} DN

Q_{\max} DN = maximum flow rate of the nominal diameter at 10 m/s

Analog output effects

Same as pulse output plus ±0.1 % of measured value ±0.01 mA



Y Measured error ± of measured value

X Flow velocity v

Figure 71: Analog output effects

Sensor SE41F

Temperature graph




Figure 72: Measuring medium temperature dependent on the ambient temperature

Max. permissible cleaning temperature PTFE-, PFA-design

CIP cleaning	Liner Flowmeter sensor	T_{\max}	t_{\max} Min	$T_{\text{amb.}}$
Steam cleaning	PTFE, PFA	150 °C (302 °F)	60	25 °C (77 °F)
Wet cleaning	PTFE, PFA	140 °C (284 °F)	60	25 °C (77 °F)

If the ambient temperature is > 25 °C, the difference must be subtracted from the max. cleaning temperature.

$$T_{\max} - \Delta \text{ °C} \cdot \Delta \text{ °C} = (T_{\text{amb.}} - 25 \text{ °C})$$

... 13 Specification

... Sensor SE41F

Min. permissible pressure as a function of measuring medium temperature

Liner	Nominal diameter DN	P _{Operation} mbar abs	at T _{Operation}
Hard rubber	15 to 1000 (1/2 to 40")	0	< 90 °C (194 °F)
Soft rubber	50 to 1000 (2 to 40")	0	< 60 °C (140 °F)
PTFE	10 to 600 (3/8 to 24")	270	< 20 °C (68 °F)
		400	< 100 °C (212 °F)
		500	< 130 °C (266 °F)
Thick PTFE	25 to 80 (1 to 3")	0	< 180 °C (356 °F)
high	100 to 250 (4 to 10")	67	< 180 °C (356 °F)
temperature	300 (12")	27	< 180 °C (356 °F)
design			
PFA	3 to 200 (1/10 to 8")	0	< 130 °C (266 °F)
		0	< 180 °C (356 °F)
ETFE	25 to 1000 (1 to 40")	100	< 130 °C (266 °F)
Ceramic	25 to 1000	0	< 80 °C (176 °F)
carbide	(1 to 40")		

Sensor material

Parts	Standard	Others
Liner	PTFE, PFA, hard rubber, soft rubber, ETFE	Ceramic carbide
Signal and ground electrode for	Stainless steel 1.4571 (316 Ti)	Hastelloy B-3 (2.4600), Hastelloy C-4 (2.4610), titanium, tantalum, platinum-iridium, stainless steel 1.4539 (904 L)
• Hard rubber		
• Soft rubber		
• PTFE, PFA, ETFE	Hastelloy C-4 (2.4610)	Stainless steel 1.4571 (316 Ti), Hastelloy B-3 (2.4600), titanium, tantalum, platinum-iridium, stainless steel 1.4539 (904 L)
Grounding plate	Stainless steel 1.4571 (316 Ti)	On request
Protection plate	Stainless steel 1.4571 (316 Ti)	On request

Process connection material

Parts	Standard	Others
Flange		
DN 3 to DN 15 (1/10 to 1/2")	stainless steel*	stainless steel*
DN 20 to DN 300 (3/4 to 12")	Steel galvanized**	
DN 350 to DN 1000 (14 to 40")	Steel painted**	
Chassis		
DN 3 to 300 (1/10 to 12")	Pair case cast aluminum, painted, paint coat, ≥ 80 µm thick, RAL 9002	—
DN 350 to DN 1000 (14 to 40")	Steel welded construction, painted, paint coat, ≥ 80 µm thick, RAL 9002	—
Terminal box	Aluminum alloy, painted, ≥ 80 µm thick, frame: dark gray, RAL 7012 Cover: light gray, RAL 9002	—
Meter tube	Stainless steel 1.4301 (304)	—
Cable gland	Polyamide	—

The process connections are made of one of the materials listed below:

- * 1.4301 (304), 1.4307, 1.4404 (316L), 1.4435 (316L), 1.4541 (321), 1.4571 (316Ti), ASTM A182 F304, ASTM A182 F304L, ASTM A182 F316L, ASTM A182 F321, ASTM A182 F316Ti, ASTM A182 F316, 0Cr18Ni9, 0Cr18Ni10, 0Cr17Ni13Mo2, 0Cr27Ni12Mo3, 1Cr18Ni9Ti, 0Cr18Ni12Mo2Ti
- ** 1.0038, 1.0460, 1.0570, 1.0432, ASTM A105, Q255A, 20#, 16Mn

Storage temperature

–20 to 70 °C (–4 to 158 °F)

IP rating in accordance with EN 60529

IP 65/IP 67

IP 68 (option)

Pipe vibration according to EN 60068-2-6**Transmitter**

- In the range of 10 to 55 Hz, max. deflection 0.15 mm

Sensor

- In the range of 10 to 55 Hz, max. deflection 0.15 mm
- In the range of 10 to 55 Hz, max. acceleration 2 g

Designs

The flange devices are compliant with the installation lengths determined according to ISO 13359.

Material loads for process connections

Limits for allowable fluid temperature (TS) and allowable pressure (PS) are a function of the liner and flange material used (see the factory tag and name plate of the unit).

Temperature limits

Liner	Flange material	Max. temperature		
		Min. temperature	Standard	High
Hard rubber	Steel	–10 °C (14 °F)	90 °C (194 °F)	—
	Stainless steel	–15 °C (5 °F)	90 °C (194 °F)	—
Soft rubber	Steel	–10 °C (14 °F)	60 °C (140 °F)	—
	Stainless steel	–15 °C (5 °F)	60 °C (140 °F)	—
PTFE / ETFE	Steel	–10 °C (14 °F)	130 °C (266 °F)	—
	Stainless steel	–25 °C (–13 °F)	130 °C (266 °F)	—
Thick PTFE / PFA	Steel	–10 °C (14 °F)	130 °C (266 °F)	180 °C (356 °F)
	Stainless steel	–25 °C (–13 °F)	130 °C (266 °F)	180 °C (356 °F)
Ceramic carbide	Steel	–10 °C (14 °F)	80 °C (176 °F)	—
	Stainless steel	–20 °C (–4 °F)	80 °C (176 °F)	—




Figure 73: Stainless steel DIN flange up to DN 600 (24")

... 13 Specification

... Sensor SE41F




Figure 74: Stainless steel ASME flange up to DN 400 (16") (CL150/300) to DN 1000 (40") (CL150) to DN 200 (8") (CL 600)




Figure 75: Steel DIN flange up to DN 600 (24")





Figure 76: Steel ASME flange up to DN 400 (16") (CL150/300) to DN 1000 (40") (CL150)


JIS 10K-B2210 flange

Nominal diameter	Material	PN	TS	PS [bar]
DN 32 to 400 (1¼ to 16")	Stainless steel	10	-25 to +180 °C (-13 to +356 °F)	10
DN 32 to 400 (1¼ to 16")	Steel	10	-10 to +180 °C (14 to 266 °F)	10



- A DN 1000 PN 10
- B DN 900 PN10, DN 800 PN 10, DN 700 PN 10
- C DN 1000 PN 16
- D DN 900 PN 16, DN 800 PN 16
- E DN 700 PN 16

Figure 77: Stainless steel DIN flange, DN 700 to DN 1000 (28 to 40")



- A DN 1000 PN 10
- B DN 900 PN10, DN 800 PN 10, DN 700 PN 10
- C DN 1000 PN 16
- D DN 900 PN 16, DN 800 PN 16
- E DN 700 PN 16

Figure 78: Steel DIN flange, DN 700 to DN 1000 (28 to 40")

Sensor SE21 / SE21F

Minimum permissible absolute pressure

Liner	Nominal diameter DN	P _{Operation} mbar abs	at	T _{Operation} ¹⁾ °C
PFA	3 to 100 (1/10 to 4")	0	≤	130 °C (266 °F)

- 1) For CIP/SIP cleaning, higher temperatures are permitted for limited time periods; refer to the table entitled 'Maximum permissible cleaning temperature'.

Maximum permissible cleaning temperature

CIP cleaning	Liner	T _{max} °C	T _{max} Minutes	T _{amb.} °C
Steam cleaning	PFA	150 °C (302 °F)	60	25 °C (77 °F)
Wet cleaning	PFA	140 °C (284 °F)	60	25 °C (77 °F)


If the ambient temperature is > 25 °C (77 °F), then the difference must be subtracted from the max. cleaning temperature.

$$T_{\max} - \Delta \text{ °C}, \Delta \text{ °C} = (T_{\text{amb}} - 25 \text{ °C})$$

Maximum Allowable Temperature Shock

Lining	Temp shock max. temp. diff. °C	Temp. gradient °C/min diff. °C
PFA	Any	Any

Maximum permissible ambient temperature as a function of measuring medium temperature



(A) Ambient temperature T_{amb.}

(B) Measuring medium temperature T_{medium}

Figure 79: Temperature graph

Sensor material

Liner	Electrode material		Electrode design	
	Standard	Others	Standard	Others
PFA	Hast.-C4 (2.4610) (1.4539 [904 L] for pipe conn. and Tri-Clamp)	Hast.-B3 (2.4600), 1.4539 (904 L), 1.4571 (316 Ti), Titanium, tantalum, platinum- iridium	Flat head (≥ DN 10)	Pointed head 1.4539 (904 L)

1/8" sanitary connectors always with 2 grounding electrodes in the same material as measuring electrodes, standard.

Process connection material

Process connection	Standard
Flange	Stainless steel 1.4571 (316 Ti)
Wafer type	without
Welded spuds	Stainless steel 1.4404 (316 L)
Pipe fitting	Stainless steel 1.4404 (316 L)
Tri-Clamp	Stainless steel 1.4404 (316 L)
External threads	Stainless steel 1.4404 (316 L)
Terminal box	
• without/with preamplifier, type A	Stainless steel 1.4301 (304)
• with preamplifier, type B	Aluminum alloy, painted, paint coat frame: dark gray, RAL 7012 cover: light gray, RAL 9002
Meter tube	Stainless steel 1.4301 (304)
Cable gland	Polyamide
Flowmeter sensor housing	Stainless steel 1.4301 (304)

Gasket material (internal)

Process connection	Standard	Option
Wafer type	without	—
Welded spuds	EPDM (Ethylene-Propylene) with FDA approval, silicone with FDA approval (CIP-resistant, no oils or grease)	Silicon with FDA approval (optional, resistant to oils and grease)
Pipe fitting		
Tri-Clamp		
External threads		
Flat gaskets	Silicon (resistant to oil, grease)	—

... 13 Specification

... Sensor SE21 / SE21F

Storage temperature

-25 to 70 °C (-13 to 158 °F)

IP rating in accordance with EN 60529

- IP 67
- IP 68 (Option)

Pipe vibration according to EN 60068-2-6

Transmitter

- In the range of 10 to 55 Hz, max. deflection 0.15 mm

Sensor

- In the range of 10 to 55 Hz, max. deflection 0.15 mm
- In the range of 10 to 55 Hz, max. acceleration 2 g

Material loads for process connections

Limits for allowable fluid temperature (TS) and allowable pressure (PS) are a function of the liner and flange material used (see the factory tag and name plate of the unit).

Devices with variable process connections / wafer type SE21 DN 3 to 100 ($\frac{1}{10}$ to 4")


Process connection	Nominal diameter	PS _{max}	TS _{min}	TS _{max}
PFA liner	DN	[bar]		
Wafer type	3 to 50	40	-40 °C	130 °C
	($\frac{1}{10}$ to 2")		(-40 °F)	(266 °F)
	65 to 100	16		
	(2½ to 4")			
Welded spuds	3 to 40	40	-25 °C	130 °C
	($\frac{1}{10}$ to 1½")		(-13 °F)	(266 °F)
	50; 80	16		
	(2", 3")			
	65, 100	10		
	(2½ to 4")			
Threaded pipe connection conforming to DIN 11851	3 to 40	40	-25 °C	130 °C
	($\frac{1}{10}$ to 1½")		(-13 °F)	(266 °F)
	50; 80	16		
	(2", 3")			
	65, 100	10		
	(2½ to 4")			
Tri-Clamp conforming to DIN 32676	3 to 50	16	-25 °C	121 °C
	($\frac{1}{10}$ to 2")		(-13 °F)	(250 °F)
	65 to 100	10		
	(2½ to 4")			
Tri-Clamp in acc. with ASME BPE	3 to 100	10	-25 °C	130 °C
	($\frac{1}{10}$ to 4")		(-13 °F)	(266 °F)
External threads ISO 228 3	3 to 25	16	-25 °C	130 °C
	($\frac{1}{10}$ to 1")		(-13 °F)	(266 °F)

JIS B2210-10K wafer type


Nominal diameter DN	Material	PN	TS	PS [bar]
32 to 100 (1¼ to 4")	1.4404 (316 L), 1.4435 (316 L), 1.4301 (304)	10	-40 to 130 °C (-40 to 266 °F)	10

Material load for flange design model SE21F

Liner: PFA

**Figure 80: DIN flange, stainless steel 1.4571 (316 Ti) up to DN 100 (4")**


*) Higher temperatures are allowed for CIP/SIP cleaning for limited time periods, see Table 'Maximum permissible cleaning temperature'.

**Figure 81: ASME flange, stainless steel 1.4571 (316 Ti) up to DN 100 (4")**

*) Higher temperatures are allowed for CIP/SIP cleaning for limited time periods, see Table 'Maximum permissible cleaning temperature'.

Material load for wafer type design model SE21W

Liner: PFA wafer type

**Figure 82: Wafer type design model SE21W**

*) Higher temperatures are allowed for CIP/SIP cleaning for limited time periods, see Table 'Maximum permissible cleaning temperature'.

... 13 Specification

Transmitter

Meas. range	Any flow range whose 100% value corresponds to a flow velocity between 0.5 m/s and 10 m/s can be selected.	
Minimum conductivity	$\geq 20 \mu\text{S/cm}$ standard	DN 10 to DN 1000 ($\frac{3}{8}$ to 40")
	$\geq 20 \mu\text{S/cm}$ with preamplifier	DN 3 to DN 8 ($\frac{1}{25}$ to $\frac{5}{16}$ ")
	$\geq 5 \mu\text{S/cm}$ with preamplifier	DN 3 to 1000 ($\frac{1}{25}$ to 40")
	$\geq 0.5 \mu\text{S/cm}$ with preamplifier	DN 10 to DN 1000 ($\frac{3}{8}$ to 40")
Repeatability (measurement period = 100 s)	DN 3 to 1000 (1/10 to 40"): $\leq \pm (0.1 \% \text{ of measured value} + 0.01 \% \text{ of } Q_{\text{max DN}})$	
Response time	1 τ = 70 ms (0 to 66 %) Fast operating mode 1 τ = 200 ms (0 to 66 %) Standard/piston pump operating mode	
Power supply	U = 100 to 230 V, 50/60 Hz U _{rat} = 85 to 253 V, 50/60 Hz 50/60 Hz \pm 6% 20.4 to 26.4 V AC, 20.4 to 31.2 V DC, ripple \leq 5 %	
Power consumption	S \leq 45 VA (sensor including transmitter)	
Ambient temperature	-20 to 60 °C (-4 to 140 °F)	
Storage temperature	-20 to 80 °C (-4 to 176 °F)	

IP rating in accordance with EN 60529

IP 67 for field-mount housing and NEMA 4X

Relative humidity

Acc. to IEC 60068-2-30 classification of environmental conditions, natural factors, temperature and air humidity.

No effect under the following operating conditions: temperature ranging from 25 to 55 °C (77 to 131 °F) and a relative air humidity of 94 to 97 %.

Vibration

In accordance with IEC 60068-2-6 (03/95), grouping of devices according to table C2 for general industry applications. No additional effect on the following levels of vibration. Frequency range 10 to 55 Hz; amplitude max. 0.15 mm.

Design

Field-mount housing made of cast aluminum per DIN 1725, painted.

Paint coat thickness 80 μm . Lower section (RAL 7012), upper section (RAL 9002). For dimensions, see Dimensions in the Datasheet. Weight, approx. 3.3 kg.

Signal cable

Max. cable length between flowmeter sensor and transmitter is:

- 50 m for the standard design and versions with automatic zero return, from DN 10 (3/8") and from 20 $\mu\text{S/cm}$.
- 200 m for designs with preamplifier.

A 5 m signal cable is included with each flowmeter. If a cable longer than 5 m is required, refer to the ordering information for the sensor.

Coil supply cable

Is required to connect the flowmeter sensor to the transmitter. For EMC reasons, the 2-wire cable is shielded. A 5 m cable is included with each flowmeter. If a cable longer than 5 m is required, refer to the ordering information for the sensor.

14 Additional documents

Note

All documentation, declarations of conformity, and certificates are available in ABB's download area.

www.abb.com/flow

Trademarks

HART is a registered trademark of FieldComm Group, Austin, Texas, USA

Modbus is a registered trademark of Schneider Automation Inc.

PROFIBUS and PROFIBUS DP are registered trademarks of PROFIBUS & PROFINET International (PI)

FOUNDATION Fieldbus is a registered trademark of FieldComm Group, Austin, Texas, USA.

15 Appendix

Overview of setting parameters and technical design

Measuring point:		TAG no.:
Sensor model:		Transmitter type:
Order no.:	Device no.:	Order no.:
Measuring medium temperature:		Voltage supply:
Lining:	Electrodes:	Exciter frequency:
C _{zero} :	C _{span} :	System zero point:

Parameter	Adjustment range
Prog. Protection code:	0-9999 (0 = factory setting)
Language:	e.g., German, English, French, etc.
Flowmeter sensor	see name plate or the submenu 'System Data/Sensor'
Nominal size:	DN 1 to DN 1000
Q _{max} :	0.05 Q _{max} DN to 1 Q _{max} DN
Pulse factor:	Imp./phys. Unit
Pulse width:	0.100 to 2000 ms
Offset suppression:	0 to 10 % of upper range value
Damping:	0.2 (0.07) to 20 seconds
Noise reduction	OFF / 1 / 2 / 3 / 4
Density:	0.01 g/cm ³ to 5.0 g/cm ³
Unit Q _{max} :	e.g., l/s, l/min, l/h, hl/s, hl/min, hl/h, etc.
Unit totalizer:	e.g. l, hl, m ³ , igal, gal etc.
Max. alarm:	%
Min. alarm:	%
Switching output:	Max. Alarm, Min. Alarm, Max./Min. Alarm, General alarm, empty conduit etc.
Contact input:	External zero return, Totalizer reset, External system zero, no function
Current output:	0/4 to 20 mA, 0/2 to 10 mA, 0 to 5 mA, 0 to 10-20 mA, 4 to 12 to 20 mA
I _{out} with alarm:	0 %, 103 %, 3.8 mA, Low, High
Detector e. pipe:	ON / OFF
Calibrate e. pipe:	0 to 10000
Alarm e. pipe:	ON / OFF
I _{out} for e. pipe:	0 %, 103 %, 3.8 mA, Low, High
Totalizer function:	Standard, difference totalizer
1. display line:	Q (%), Q (unit), Q (mA), counter V/R, TAG number, blank line, bar graph
2. display line:	Q (%), Q (unit), Q (mA), counter V/R, TAG number, blank line, bar graph
3. display line:	Q (%), Q (unit), Q (mA), counter V/R, TAG number, blank line, bar graph
4. display line:	Q (%), Q (unit), Q (mA), counter V/R, TAG number, blank line, bar graph
Operating mode:	Standard / Piston Pump / Fast
Flow direction:	Forward / reverse flow, Forward flow
Directional display:	Standard, inverse
Pulse output:	<input type="checkbox"/> Active <input type="checkbox"/> Passive
Communication:	<input type="checkbox"/> HART <input type="checkbox"/> PROFIBUS PA <input type="checkbox"/> FOUNDATION Fieldbus <input type="checkbox"/> Without
Diagnosis	Measured value E/W Min. Max. Measured value E/W Min. Max.
Threshold monitoring	Coil current AC Coil voltage DC
Error (E)	Coil resistance Coil temperature
Warning (W)	Coil insulation resistance DAC value
	Electrode voltage Electrode balance
	Signal-to-noise ratio Magnetic linearity

Return form

Statement on the contamination of devices and components

Repair and/or maintenance work will only be performed on devices and components if a statement form has been completed and submitted.

Otherwise, the device/component returned may be rejected. This statement form may only be completed and signed by authorized specialist personnel employed by the operator.

Customer details:

Company:

Address:

Contact person:

Telephone:

Fax:

Email:

Device details:

Type:

Serial no.:

Reason for the return/description of the defect:

Was this device used in conjunction with substances which pose a threat or risk to health?

☐ Yes ☐ No

If yes, which type of contamination (please place an X next to the applicable items):

☐ biological

☐ corrosive / irritating

☐ combustible (highly / extremely combustible)

☐ toxic

☐ explosive

☐ other toxic substances

☐ radioactive

Which substances have come into contact with the device?

1.

2.

3.

We hereby state that the devices/components shipped have been cleaned and are free from any dangerous or poisonous substances.

Town/city, date

Signature and company stamp

ABB Measurement & Analytics

For your local ABB contact, visit:
www.abb.com/contacts

For more product information, visit:
www.abb.com/flow

We reserve the right to make technical changes or modify the contents of this document without prior notice. With regard to purchase orders, the agreed particulars shall prevail. ABB does not accept any responsibility whatsoever for potential errors or possible lack of information in this document.

We reserve all rights in this document and in the subject matter and illustrations contained therein. Any reproduction, disclosure to third parties or utilization of its contents – in whole or in parts – is forbidden without prior written consent of ABB.