

ABB DRIVES

ACS580-01..., ACH580-01... and ACQ580-01... +C135 drives with flange mounting kit

Supplement



ACS580-01..., ACH580-01... and ACQ580-01... +C135 drives with flange mounting kit

Supplement

Table of contents	
4. Mechanical installation – Frames R1R3	Z
5. Mechanical installation – Frames R1R3 +B063 +B066	S.
6. Mechanical installation – Frames R4 and R5	Ż
7. Mechanical installation – Frames R6R9	E.

3AXD50000349821 Rev C EN Original instructions EFFECTIVE: 2023-12-19

IΞ

Table of contents

1 Introduction to the supplement

Contents of this chapter	9
Applicability	9
Target audience	9
Purpose of the supplement	
Related documents	

2 Hardware description

Contents of this chapter	11
Product overview	
Layout and mounting position	11
Example: tilted position, frames R1R3	12
Example: upright position, frames R4 to R9	13
Degree of protection	13
Special requirements	14
Ordering codes	14

3 Mechanical installation - General

Contents of this chapter	15
Safety instructions	
Examining the installation site	
Free space requirements	16
Additional requirements for cabinet installations	
Necessary tools	18
Unpacking and examining the delivery	18

4 Mechanical installation – Frames R1...R3

Contents of this chapter	19
Flange mounting kit package contents	20
Mounting template	21
Installation procedure	22
Optional steps	27
Installation of the grounding plate	27
Installation of the power cable grounding shelf lower on the	
bottom bracket	29
Installing the drive on the mounting plate	31

6 Table of contents

5 Mechanical installation - Frames R1...R3 +B063 +B066

35
36
37
38
39
40
43

6 Mechanical installation – Frames R4 and R5

Contents of this chapter	45
Flange mounting kit package contents	46
Mounting template	47
Installation procedure	48
Installing the drive on the mounting plate	54

T Mechanical installation – Frames R6...R9

Contents of this chapter	57
Safety	57
Flange mounting kit package contents	
Mounting template	59
Installation procedure	60
Installing the drive on the mounting plate	62

8 Dimension drawings

Contents of this chapter	65
Frame R1	66
Attaching points and hole dimensions	68
Frame R1 (options +B063 and +B066)	69
Attaching points and hole dimensions	70
Frame R2	71
Attaching points and hole dimensions	73
Frame R2 (options +B063 and +B066)	74
Attaching points and hole dimensions	75
Frame R3	76
Attaching points and hole dimensions	78
Frame R3 (options +B063 and +B066)	79
Attaching points and hole dimensions	80
Frame R4	81
Attaching points and hole dimensions	83
Frame R5	84
Attaching points and hole dimensions	86

87
89
90
92
93
95
96
98

Further information

E



Introduction to the supplement

Contents of this chapter

This chapter describes the supplement.

Applicability

This supplement is applicable to ACS580-01, ACH580-01 and ACQ580-01 drives with the flange mounting kit (option +C135).

Target audience

This supplement is intended for people who plan the installation and install the drive with the flange mounting kit. Read the supplement before you work on the drive. You are expected to know the fundamentals of electricity, wiring, electrical components and electrical schematic symbols.

The supplement is written for readers worldwide. Both SI and imperial units are shown.

Purpose of the supplement

This supplement tells you how to install the drive mechanically onto an opening in a mounting plate with the flange mounting kit.

10 Introduction to the supplement

Related documents

You can find manuals on the Internet. See below for the relevant code/link. For more documentation, go to www.abb.com/drives/documents.



2

Hardware description

Contents of this chapter

This chapter describes the flange mounting kit.


Product overview


The flange mounting kit contains brackets to attach the drive onto a mounting plate. The heatsink of the drive can be located in the cooling air channel, and the front part of the drive on the other side of the mounting plate.

Layout and mounting position

You can install the flange-mounted drive in a tilted or an upright position depending on the drive type.

Example: tilted position, frames R1...R3





Example: upright position, frames R4 to R9

- 1 Hood (in the cooling air channel; required for UL Type 12)
- 2 Top flange bracket
- 3 Mounting plate
- 4 Lifting hole
- 5 Drive heatsink in the cooling air channel
- 6 Side flange bracket
- 7 Drive front side
- 8 Bottom flange bracket

Degree of protection

The degree of protection of the back of the drive (heatsink) is always IP55 (UL Type 12) regardless of the cover. When the cover is not in position, the degree of protection of the front part of the drive is IP20 (UL Open Type). The IP55 (UL Type 12) cover can only be in position for frame R3.

Frame sizes R1...R3 with option +B063: The degree of protection of the back of the drive (heatsink) is IP66.

Frame sizes R1...R3 with option +B066: The degree of protection of the back of the drive (heatsink) is UL Type 4X.

Special requirements

Frame size	IP21 (UL Type 1)
R1	Install a sealing plug and an auxiliary cooling fan, or remove the front cover. To order the auxiliary cooling fan, refer to Ordering codes.
R2 R3	An auxiliary cooling fan is necessary because the sealing plug prevents cooling air flow to the control circuits of the drive.
R4	Exception: In a dry environment, you can leave the cover in position without the sealing plug.

Ordering codes

The flange mounting kit is a plus code option (+C135) or ordered separately with these ordering codes.

Frame size	Ordering code of flange mounting kit
R1	3AXD50000105311 (IP21, UL Type 1)
R1	3AXD50001125462 (IP66, UL Type 4X)
R2	3AXD50000105328 (IP21, UL Type 1)
R2	3AXD50001125479 (IP66, UL Type 4X)
R3	3AXD50000105335 (IP21 and IP55, UL Type 1 and UL Type 12)
R3	3AXD50001125486 (IP66, UL Type 4X)
R4	3AXD50000031460 (IP21, UL Type 1)
R5	3AXD50000031461 (IP21, UL Type 1)
R6	3AXD50000018852 (IP21, UL Type 1)
R7	3AXD50000018853 (IP21, UL Type 1)
R8	3AXD50000018854 (IP21, UL Type 1)
R9	3AXD50000018855 (IP21, UL Type 1)

Frame size	Ordering code of IP55 (UL Type 12) internal cooling fan for IP21 (UL Type 1) drives		
R1	3AXD50000050128		
R2	3AXD50000050128		
R3	3AUA0000088115		
R4	3AXD50000034334		

3

Mechanical installation – General

Contents of this chapter

This chapter gives a general description of how to mechanically install the drive with the flange mounting kit.

Safety instructions

Obey the general safety instructions in the hardware manual and the task-specific instructions in this supplement.

Wear protective gloves and long sleeves. Some parts have sharp edges.

Examining the installation site


Make sure that the installation site complies with these requirements:

- The installation site has sufficient ventilation to prevent overheating of the drive. Refer to Losses, cooling data and noise in the hardware manual for the required air flow in the cooling air channel and in the front part of the drive.
- The operation conditions of the drive agree with the specifications in Ambient conditions in the hardware manual.
- The mounting plate is vertical, non-flammable and strong enough to hold the weight of the drive.
- The material behind, above and below the drive is non-flammable.


- There is enough free space above and below the drive for cooling air flow, service and maintenance. There is enough free space in front of the drive for operation, service and maintenance. Refer to Free space requirements in this supplement and Dimensions, weights and free space requirements in the hardware manual.
- When you install drives above one another, make sure that the hot air from the outlet of the drive flows away from the inlet of the drive above it.

Free space requirements

You can install the flange-mounted drives side by side. For additional requirements, refer to Examining the installation site (page 15) and Additional requirements for cabinet installations (page 18).



Note: The free space requirements below are for the heatsink side of the mounting plate. There is no free space requirement for the front side of the mounting plate. That area can be occupied by other equipment (for example, contactors, relays, wires, ducts, and so on).



1) Distance from the drive / distance from the back hood

Additional requirements for cabinet installations

Make sure that the cooling air gratings of the drive are not covered. Make sure that the required cooling air flow is achieved. In a fully closed cabinet with no forced ventilation, a fan for circulating air inside the cabinet may be needed.

For UL installations, plan the wire bending radius of input power and motor cables according to UL rules.

Necessary tools

To move a heavy drive, you need a crane, fork-lift or pallet truck (check load capacity).

To lift a heavy drive, you need a hoist.

To install the drive mechanically, you need the following tools:

- drill with suitable bits
- screwdriver set (Torx, flat and/or Phillips, as appropriate)
- torque wrench
- socket set, Hex key set (metric)

Unpacking and examining the delivery

The flange mounting kit package is tied with straps onto the drive package or sent separately.

To unpack:

- Cut the straps.
- Remove the flange mounting kit package. For the contents of the kit package, refer to the kit package contents section in the mechanical installation chapter of the drive frame size later in this manual.
- To open the drive package, refer to the drive hardware manual.

Examine that all items are present and that there are no signs of damage. Read the data on the type designation label of the drive to make sure that the drive is of the correct type.

4

Mechanical installation – Frames R1...R3

Contents of this chapter


This chapter describes how to mechanically install drive frame sizes R1...R3 with the flange mounting kit.



Q

Flange mounting kit package contents

The figure below show the layout of the flange mounting kit package. Examine that all items are present and that there are no signs of damage.



2	Side brackets	13	Quick guide		
3	Bottom bracket	14	Hood (required for UL Type 12)		
4	Top bracket (In frame R3 different)	15	Screw package:		
5	Bottom U-bracket R3: 14 pcs) ¹⁾ Top U bracket M6 nut (R1R2: 18 pcs)		• M5x20 screw (4 pcs)		
6			R3: 14 pcs) ¹⁾		
7					
8					
9					
10					
11					
	4)				


1) The delivery does not include the Rivet or Kalei nuts for the M6 screws.

R

Mounting template


The flange mounting kit package includes a template in actual size to drill the attaching holes and to cut the hole in the mounting plate.

An example template is shown below.




Installation procedure

1. For IP21 (UL Type 1): To remove the fan assembly, push the retaining clips and pull the fan assembly from the frame.



3. For IP21 (UL Type 1): Install the fan assembly.



4. For IP21 (UL Type 1): To install the auxiliary fan, refer to Replacing the auxiliary cooling fan, IP55 (UL Type 12) frames R1 ...R2 or Replacing the auxiliary cooling fan, IP55 (UL Type 12) frame R3 in the hardware manual.


5. For IP55 (UL Type 12): The cover can be in position only for frame R3 but it must be removed from frames R1 ...R2.


To remove the cover:

- Remove the tightening screws with a T20 Torx screwdriver (a).
- Lift the cover up (b).
- Lift the cover off (c).

Ω


Recycle the cover according to ACH580-01, ACQ580-01 and ACS580-01 drives recycling instructions and environmental information (3AXD50000040612 [English]).






6. Attach the U-brackets (b and c) to the back of the drive.

- 7. Attach the side brackets (d) to the U-brackets which were attached in step 6 using M6 nuts finger-tight.
- 8. Attach the tightening brackets (e) with M5x20 screws to press the side brackets against the module.
- 9. Tighten the side bracket nuts.



Ø

- Attach the top bracket (f) and the bottom bracket (g) to the side brackets, first the inner sides (1) (the sides that touch the drive), then the outer sides (2).
- 11. Remove the tightening bracket (e) from the top to enable the replacement of the cooling fan.




Ń

Optional steps

Installation of the grounding plate


For R1 and R2:

- 1. Push the grounding plate onto the alignment pins on the bottom bracket.
- 2. Attach the grounding plate with the screws and nuts.




S.

For R3: Attach the grounding plate to the bottom plate with the cable entry plate screw (h).



Installation of the power cable grounding shelf lower on the bottom bracket


1. Remove the cover and the cable entry plate.



SI

- 2. To remove the power cable shelf, remove screws (i).
- 3. Install the screws (1.5 N·m/1.1 lbf·ft) to avoid moisture exchange through the empty holes.
- 4. Attach the power cable shelf to the bottom bracket with M4 nuts.


Frame R3 is shown as an example. The cable shelf varies in different frame sizes.




R)

Installing the drive on the mounting plate


- 1. Refer to Dimension drawings (page 65) for the dimensions of the flange and the required opening in the mounting plate.
- 2. Attach the mounting template from the flange mounting kit package onto the mounting plate.
- 3. Make the opening and drill the holes for the mounting screws. Consider the hole size for Rivet or Kalei nuts (not included in the delivery).
- 4. Remove the mounting template.



5. To fulfill UL Type 12 requirements at the backside of the drive, attach the hood to the cooling channel. This is not required for IP55 drives.



- 6. Attach chains to the drive lifting holes and lift the drive with a lifting device onto the opening in the mounting plate.
- 7. Attach the bottom bracket with one screw.
- 8. Attach the top bracket with one screw.
- 9. Attach the rest of the mounting screws. Remove the chains.



34 Mechanical installation – Frames R1...R3

Ŋ

5

R


Mechanical installation – Frames R1...R3 +B063 +B066

Contents of this chapter


This chapter describes how to mechanically install drive frame sizes R1...R3 with option +B063 or +B066 with the flange mounting kit.

Flange mounting kit package contents

The figures below show the layout of the flange mounting kit packages. Examine that all items are present and that there are no signs of damage.



Back hood




38 Mechanical installation - Frames R1...R3 +B063 +B066

Mounting template

The flange mounting kit package includes a template in actual size to drill the attaching holes and to cut the hole in the mounting plate.

An example template is shown below.




Q


Ŋ

Installation procedure

- 1. Remove the front cover. Recycle the cover according to ACH580-01, ACQ580-01 and ACS580-01 drives recycling instructions and environmental information (3AXD50000040612 [English]).
- 2. Remove the conduit plate.




3. Install the flange onto the drive frame.



Installing the drive on the mounting plate


- 1. Refer to Dimension drawings (page 65) for the dimensions of the flange and the required opening in the mounting plate.
- 2. Attach the mounting template from the flange mounting kit package onto the mounting plate.
- 3. Make the opening and drill the holes for the mounting screws.
- 4. Remove the mounting template.

W




S.

5. Attach chains to the flange lifting holes and lift the drive with a lifting device onto the opening in the mounting plate.



42 Mechanical installation - Frames R1...R3 +B063 +B066

- 6. Attach the bottom corner of the flange with one screw.
- 7. Attach the top corner of the flange with one screw.
- 8. Attach the rest of the mounting screws.




 $^{1\!)}$ Minimum length of 25 mm (length varies with installation)

- 9. Remove the chains.
- 10. Apply a thick layer of silicone or similar sealant around each screw on the back side of the mounting plate.

Installing the back hood

- 1. On the back of the drive, remove the four screws on the top and bottom.
- 2. Start two M4x12 screws (delivered with the flange kit) on the top holes.
- 3. Install the back hood by hanging it from the two top screws using the keyholes at the top of the hood.
- 4. Attach the two bottom screws through the hood into the drive.
- 5. Torque all four screws to 2.0 N·m (1.5 lbf·ft).



6

S


Mechanical installation – Frames R4 and R5

Contents of this chapter

This chapter describes how to mechanically install drive frame sizes R4 and R5 with the flange mounting kit.

Flange mounting kit package contents

The figure below shows the layout of the flange mounting kit packages. Examine that all items are present and that there are no signs of damage.



¹⁾ The delivery does not include Rivet or Kalei nuts for the M6 screws.


S

S

Mounting template

The flange mounting kit package includes a template in actual size to drill the attaching holes and to cut the hole in the mounting plate.


An example template is shown below.




Installation procedure


2

1. For R4, IP21 (UL Type 1): To remove the fan assembly, push the retaining clip with a flat screwdriver and pull the fan assembly out of the frame.




2. For R4, IP21 (UL Type 1): Insert the sealing plug (a) into the hole.





3. For R4, IP21 (UL Type 1): Install the fan assembly.

4. For R4, IP21 (UL Type 1): To install the auxiliary fan for IP21 drives, first remove the covers.



To install the fan, refer to Replacing the auxiliary cooling fan, IP55 (UL Type 12) frame R4; IP21 and IP55 (UL Type 1 and UL Type 12) frame R5 in the hardware manual.


5. For IP55 (UL Type 12):

Q


To remove the cover:

- Remove the tightening screws with a T20 Torx screwdriver (a).
- Lift the cover up (b)
- Lift the cover off (c).

Recycle the cover according to ACH580-01, ACQ580-01 and ACS580-01 drives recycling instructions and environmental information (3AXD50000040612 [English]).




6. For R4 and R5: Attach the U-brackets (b and c) to the back of the drive.



S.


For R4 and R5:


- 7. Attach the side brackets (d) to the U-brackets with M6 nuts finger-tight.
- 8. Attach the tightening brackets (e) with M5x20 screws to press the side brackets against the module.
- 9. Tighten the side bracket nuts.



Q


10. For R4 and R5: Attach the top (f) and bottom (g) brackets to the side brackets, first the inner sides (1) (the sides that touch the drive), then the outer sides (2).





11. For R4 and R5: Remove the tightening bracket (e) from the front of the fan.

12. For R5: Attach the clamp plate.




SI


Installing the drive on the mounting plate


- 1. Refer to Dimension drawings (page 65) for the dimensions of the flange and the required opening in the mounting plate.
- 2. Attach the mounting template from the flange mounting kit package onto the mounting plate.
- 3. Make the opening and drill the holes for the mounting screws. Consider the hole size for the Rivet or Kalei nuts (not included in the delivery).
- 4. Remove the mounting template.

Q



SI






- 6. Attach the chains to the lifting holes of the flange and lift the drive with a lifting device onto the opening in the mounting plate.
- 7. Attach the bottom bracket with one screw.
- 8. Attach the top bracket with one screw.

Q

9. Attach the rest of the mounting screws. Remove the chains.



7

Mechanical installation – Frames R6...R9

Contents of this chapter


This chapter describes how to mechanically install drive frames sizes R6...R9 with the flange mounting kit.


Safety



WARNING!

For frame sizes R6 to R9: Use the lifting eyes of the drive when you lift the drive. Do not tilt the drive. The drive is heavy and its center of gravity is high. An overturning drive can cause physical injury.





Flange mounting kit package contents

Ŷ


1) The delivery does not include Rivet or Kalei nuts for the M6 screws.

Q

Mounting template

The flange mounting kit package includes a template in actual size to drill the attaching holes and to cut the hole in the mounting plate.

An example template is shown below.




Installation procedure

1. For IP55 (UL Type 12):

To remove the cover:

- Remove the tightening screws with a T20 Torx screwdriver (a).
- Lift the cover up (b)
- Lift the cover off (c).


Recycle the cover according to ACH580-01, ACQ580-01 and ACS580-01 drives recycling instructions and environmental information (3AXD50000040612 [English]).



Q


- $12 \times M6 \times 10 T30$
- 2. Attach the side brackets to the drive.

3. Attach the top bracket and the bottom bracket.




Installing the drive on the mounting plate


- 1. Refer to Dimension drawings (page 65) for the dimensions of the flange and the required opening in the mounting plate.
- 2. Attach the mounting template from the flange mounting kit package into the mounting plate.
- 3. Make the opening and drill the holes for the mounting screws. Consider the hole size for Rivet or Kalei nuts (not included in the delivery).
- 4. Remove the mounting template.



5. To fulfill UL Type 12 requirements at the backside of the drive, attach the hood to the cooling channel. This is not required for IP55 drives.



- 6. Attach the chains to the lifting holes of the flange and lift the drive with a lifting device onto the opening in the mounting plate.
- 7. Attach the bottom bracket with one screw.
- 8. Attach the top bracket with one screw.
- 9. Attach the rest of the mounting screws. Remove the chains.




8

Dimension drawings


Contents of this chapter


This chapter contains the dimension drawings of the flange mounting kits and the required openings in the mounting plate. The drawings for frames R6...R9 show ACS880-01 but the flange dimensions are equal for ACH580-01, ACQ580-01 and ACS580-01.

Frame R1




⊕ ∏ 3AXD50000131310








3AXD50000131242



The hood is needed for UL Type 12 installation only.









Attaching points and hole dimensions

3AXD50000035517


☐ 3AXD50001012694








Attaching points and hole dimensions




3AXD50001012694

Frame R2



Hood is needed for UL Type 12 installation only.




0

0


0


0


3AXD50000131242





Frame R2 (options +B063 and +B066)

































Frame R3 (options +B063 and +B066)


80 Dimension drawings


Attaching points and hole dimensions




























 \oplus \Box 3AXD5000038123

































































98 Dimension drawings

Attaching points and hole dimensions



Further information

Product and service inquiries

Address any inquiries about the product to your local ABB representative, quoting the type designation and serial number of the unit in question. A listing of ABB sales, support and service contacts can be found by navigating to www.abb.com/contact-centers.

Product training

For information on ABB product training, navigate to new.abb.com/service/training.

Providing feedback on ABB manuals

Your comments on our manuals are welcome. Navigate to new.abb.com/drives/manuals-feedback-form.

Document library on the Internet

You can find manuals and other product documents in PDF format on the Internet at www.abb.com/drives/documents.



www.abb.com/drives



© Copyright 2023 ABB. All rights reserved. Specifications subject to change without notice.