
Quick Installation Guide
615 series

Power and productivity
for a better world™

Document validity



Mounting the 615 series

Contents

5 Loose parts

6 Attaching the protective film

7 Withdrawing the plug-in unit from the case

8 Flush mounting

10 19” Rack mounting

12 Semi-Flush mounting

14 Inclined Semi-Flush mounting

16 Wall mounting


18 Inserting the plug-in unit into the case


19 Locking the handle

20 Sealing the handle


Loose parts


(Not available in version D)






Attaching the protective film














Withdrawing the plug-in unit from the case




Flush mounting






⑥





See page 18

⑦





19” Rack mounting





See page 7







5




See pages 18

Semi-Flush mounting







See page 7



③





④




See page 18


⑤






Inclined Semi-Flush mounting







See page 7



③




④




See page 18


⑤

mm
in





Wall mounting






See page 7




5
Torx T25
B
Torque 0,7...1Nm
0,52...0,74 lbf·ft
A
B
6
177(4U)
6,97
270
10,63
455
17,91
A
B
See page 18
7
214
8,43
mm
in
50
1,97
50
1,97
50
1,97
≥ 6mm²/ AWG10
Torx T20


Inserting the plug-in unit into the case




Locking the handle

See page 5


1



2



Sealing the handle





Notes

Notes

Contact us

ABB Oy
Medium Voltage Products,
Distribution Automation
P.O. Box 699
FI-65101 VAASA, Finland
Phone +358 10 22 11
Fax +358 10 22 41094

ABB Inc.
Distribution Automation
4300 Coral Ridge Drive
Coral Springs, FL 33065, USA
Phone +1 (800) 523-2620
Phone +1 954-752-6700
Fax +1 954 345-5329

ABB Transmission and Distribution
Automation Equipment (Xiamen) Co. Ltd.
ABB Industrial Park, Torch Hi-tech
Development Zone 361006
Xiamen, Fujian, China
Phone +86 592 5702288
Fax +86 592 5718598

ABB Limited
Distribution Automation
Maneja, Vadodara 390013, India
Phone: +91 265 2604032
Fax: +91 265 2638922

www.abb.com/substationautomation

© Copyright 2014 ABB. All rights reserved.

1MRS756237