


Emax-Tmax T8

DOC. N.° 1SDH000460R0604 - L6132


Contatto segnalazione sganciatore di minima tensione eccitato
Contact for signalling undervoltage release energised
Meldescharter Unterspannungsauslöser ausgelöst
Contact de signalisation déclencheur à minimum de tension excité
Contacto de señalización del relé de mínima tensión excitado



Tensione	Corrente (carico resistivo)
Voltage	Current (resistive load)
Spannung	Strom (ohmsche Last)
Tension	Courant (charge résistive)
Tensión	Corriente (carga resistiva)
250 V ~ 50-60 Hz	5 A

A


Emax-Tmax T8



APERTO
OPEN
AUS-STELLUNG
OUVERT
ABIERTO

BIANCO
WHITE
WEISS
BLANC
BLANCO

B




Emax


Tmax T8




C




D



E



F



G




ABB S.p.A.

ABB SACE Division

Via Baioni, 35

24123 Bergamo Italy

Tel.: +39 035 395.111 - Telefax: +39 035 395.306-433

<http://www.abb.com>