


Installation note

F-series fieldbus adapter modules


Installation instruction

When you install or remove the module from a control unit:

1. Pull out the lock.



2. Install the module according to the installation instructions in the manual.
3. Push in the lock.



4. Fasten the screw.