TH / TF



- This Version Matrix document helps you to find out what kind of software is available for this field device and which software version you have to use with which kind of Hardware and Firmware Revision.
- You will find the latest software, documentations or this Version Matrix (recommended) available on: http://www.abb.com/Fieldbus
 - -> select "[Fieldbus protocol] field devices" -> go to [device type name] -> select "latest info" Tab "Fieldbus & HART Files" opens

TH02(-EX), TH102(-EX), TH202(-EX)

(-2.1),(-2.1),(,
HART	Revision
Hardware	all released
Software	≤ 01.10
Title (ID-0008) Device [DocNo.]	01
DTM (FDT 1.2) part of DTM400 [3KXD800400S0030]	01.00.11
EDD (General) [3KDE115000S0003] This driver is not needed, if available from your Tool supplier!	01 01 (Dev. / EDD)
EDD for PDM V5.2 [3KDE115000S0003]	01 04 (Dev. / EDD)
EDD (PDM) Available in Tool Version ≥ V6.0.	01 04 (Dev. / EDD)
Supplem. InfoDriver (DTM, EDD) [3KDE115001R39xx]	√

TF12(-EX), TF212(-EX)

=(==:,, = :=(==:,		
PROFIBUS PA		Revision
	Hardware	all released
Tide (ID 04C4)		01.16.xx
Title (ID-04C4) [DocNo.]	Firmware	01.16.XX
GSD		01.01.01
[3KDE115200S0004]		
DTM (FDT 1.2) part of DTM400		01.00.25
[3KXD800400S0030]		
EDD for PDM V5.2		02
[3KDE115200S0006]		
EDD (PDM) Available in Tool Version	≥ V6.0.	02
Supplem. InfoDriver(DTM, EDD,	GSD)	✓
[3KDE115004R39xx]		•

TF02(-EX), TF202(-EX)

FOUNDATION Fieldbus-H1		Revision
Hai	rdware	all released
Fir	mware	01.02.xx -
		01.03.xx
Title (ID-001E)	Device	01
[DocNo.]		
EDD/CF (General-registered)		010101
[3KDE115200S0007] This driver is not no	eeded,	Rev01.02
if available from your Tool supplier!		