

Spare Parts

Service product description

Genuine spare parts for ABB drives allow you to continue operation fast and reliably in case of a failure. Parts are delivered in one package, so that you get all the material you need for the installation.

Value to customer

- Genuine spare parts mean trouble-free process operation
- ABB's global network allows efficient delivery of spare parts, wherever they are needed

Service includes

- Original spare parts for defined purposes
- Packaging the spare parts according to the material need
- Instructions for installation
- Accessories for installation (e.g. connectors and screws)
- Delivering the parts to the site
- Warranty for the ordered parts

Service does not include

- Installing spare parts or repair work

Customer responsibilities

- Selecting the correct spare parts for the purpose (ABB can provide tools to support this)
- Submitting the order for spare parts
- Following the installation instructions and using a qualified engineer to change the parts
- Registering the service event
- Recycling the old material

Other terms

- Other terms according to the agreement between ABB and the customer



For more information, please contact your local ABB representative or visit:

www.abb.com/drives
www.abb.com/searchchannels

We reserve the right to make technical changes or modify the contents of this document without prior notice. With regard to purchase orders, the agreed particulars shall prevail. ABB does not accept any responsibility whatsoever for potential errors or possible lack of information in this document.

We reserve all rights in this document and in the subject matter and illustrations contained therein. Any reproduction, disclosure to third parties or utilization of its contents – in whole or in parts – is forbidden without prior written consent of ABB. Copyright © 2018 ABB
 All rights reserved