




NOTES:

1. WARNING: This drawing does not illustrate the installation methods required for hazardous locations. Prior to any installation in a Classified Hazardous Location, verify installation methods by the Control Drawing referenced on the product's name tag and national and local codes.

RS-485 Communications Module
Totalflow P/N 2015193-002/003
In this configuration, COMM1 may not be used to communicate with other devices. To attach other devices, such as other flow computers, use COMM2



Connect the Shield GND from the RS-485 cable at the enclosure end of the cable to the Chassis GND Lug located on the bottom of the enclosure. For every other RS-485 cable to an additional device, attach Shield GND to Shield GND. DO NOT ground at any other place.



REF:N/A



TOTALFLOW
Products

ACTION
D24201

DOC TYPE
UD

TITLE
XRC^{G4} (2103329 BD) COMM1 TO IMV25
MULTIVARIABLE (1641200) W/RTD PROBE

DWG NO.
2104276

REV
AB

SHEET
1 OF 1