

Configure

Differential Pressure Measurement

Process variable

This tag is separated into the upper range

Scaling

and the lower range

Parallel shift

Parallel Shift

This function carries out a parallel shift of the characteristic curve so that it runs through a point determined by the user. This means that the output signal from

Digitalization Behaviour

This function allows the adaptation of the pressure/differential pressure input to

